

Instrumental Analytical Chemistry

An Introduction

James W. Robinson Eileen M. Skelly Frame George M. Frame II



Instrumental Analytical Chemistry



Instrumental Analytical Chemistry

An Introduction

James W. Robinson, Eileen M. Skelly Frame, and George M. Frame II



First edition published 2021 by CRC Press 6000 Broken Sound Parkway NW, Suite 300, Boca Raton, FL 33487-2742

and by CRC Press 2 Park Square, Milton Park, Abingdon, Oxon, OX14 4RN

© 2021 Taylor & Francis Group, LLC

CRC Press is an imprint of Taylor & Francis Group, LLC

The right of James W. Robinson, Eileen M. Skelly Frame, George M. Frame II to be identified as author[/s] of this work has been asserted by them in accordance with sections 77 and 78 of the Copyright, Designs and Patents Act 1988.

Reasonable efforts have been made to publish reliable data and information, but the author and publisher cannot assume responsibility for the validity of all materials or the consequences of their use. The authors and publishers have attempted to trace the copyright holders of all material reproduced in this publication and apologize to copyright holders if permission to publish in this form has not been obtained. If any copyright material has not been acknowledged please write and let us know so we may rectify in any future reprint.

Except as permitted under U.S. Copyright Law, no part of this book may be reprinted, reproduced, transmitted, or utilized in any form by any electronic, mechanical, or other means, now known or hereafter invented, including photocopying, microfilming, and recording, or in any information storage or retrieval system, without written permission from the publishers.

For permission to photocopy or use material electronically from this work, access www.copyright.com or contact the Copyright Clearance Center, Inc. (CCC), 222 Rosewood Drive, Danvers, MA 01923, 978-750-8400. For works that are not available on CCC please contact mpkbookspermissions@tandf.co.uk

Trademark Notice: Product or corporate names may be trademarks or registered trademarks and are used only for identification and explanation without intent to infringe.

Library of Congress Cataloging-in-Publication Data

Names: Robinson, James W., 1923-2018, author. | Frame, Eileen M. Skelly, 1953- author. | Frame, George M., II, author.

Title: Instrumental analytical chemistry: an introduction / James W. Robinson, Eileen M. Skelly Frame, George M. Frame II.

Description: First edition. | Boca Raton: CRC Press, 2021. | Includes bibliographical references and index.

Identifiers: LCCN 2020055162 (print) | LCCN 2020055163 (ebook) | ISBN 9781138196476 (hardback) | ISBN 9781315301150 (ebook)

Subjects: LCSH: Instrumental analysis. | Analytical chemistry.

Classification: LCC QD79.I5 .R59 2021 (print) | LCC QD79.I5 (ebook) | DDC 543/.19--dc23

LC record available at https://lccn.loc.gov/2020055162

LC ebook record available at https://lccn.loc.gov/2020055163

ISBN: 978-1-138-19647-6 (hbk) ISBN: 978-0-367-76819-5 (pbk) ISBN: 978-1-315-30115-0 (ebk)

Typeset in Warnock

by KnowledgeWorks Global Ltd.

Access the [companion website/Support Material]:

https://www.routledge.com/Instrumental-Analytic-al-Chemistry-An-Introduction/Robinson-Frame-II/p/book/9781138196476

Permission for the publication herein of Sadtler Spectra has been granted by Bio-Rad Laboratories, Informatics Division. All Sadtler Spectra are Copyright Bio-Rad Laboratories, Informatics Division, Sadtler Software and Databases 2014. All rights reserved.

J.T.Baker* and ULTREX* are trademarks of Avantor Performance Materials, Inc.

Contents

		Acronyms Index					
		5					
Chapter 1	Concepts of Instrumental Analytical Chemistry						
	1.1	Introduction: What is Instrumental Analytical Chemistry?	1				
	1.2	Analytical Approach					
		1.2.1 Defining the Problem					
		1.2.1.1 Qualitative Analysis	4				
		1.2.1.2 Quantitative Analysis	6				
		1.2.2 Designing the Analytical Method	9				
		1.2.3 Sampling					
		1.2.3.1 Gas Samples					
		1.2.3.2 Liquid Samples					
		1.2.3.3 Solid Samples					
	4.0	1.2.4 Storage of Samples					
	1.3	Sample Preparation					
		1.3.1 Acid Dissolution and Digestion					
		1.3.2 Fusions					
		1.3.3 Dry Ashing and Combustion					
		1.3.4.1 Solvent Extraction					
		1.3.4.2 Solid Phase Extraction (SPE)					
		1.3.4.3 QuEChERS					
		1.3.4.4 Solid Phase Microextraction (SPME)					
	1.4	Basic Statistics and Data Handling					
		1.4.1 Accuracy and Precision					
		1.4.2 Types of Errors					
		1.4.2.1 Determinate Error					
		1.4.2.2 Indeterminate Error					
		1.4.3 Definitions for Statistics					
		1.4.4 Quantifying Random Error	35				
		1.4.4.1 Confidence Limits	39				
		1.4.4.2 Variance					
		1.4.5 Rejection of Results					
	1.5	Performing the Measurement					
		1.5.1 Signals and Noise					
	1.6	Methods of Calibration					
		1.6.1 Plotting Calibration Curves					
		1.6.2 Calibration with External Standards					
		1.6.3 Method of Standard Additions					
	1 7	1.6.4 Internal Standard Calibration					
	1.7	Assessing the Data					
		1.7.1 Limit of Detection					
	Probl	lems					
		ography	58				

3.3

3.3.1

3.3.2

Analytical Applications _______134

Quantitative Analysis......134

		3.3.3	Multico	mponent Determinations	139
		3.3.4		pplications	
			3.3.4.1	Reaction Kinetics	140
			3.3.4.2	Spectrophotometric Titrations	141
			3.3.4.3	Spectroelectrochemistry	142
			3.3.4.4	Analysis of Solids	142
		3.3.5	Measure	ement of Color	142
	3.4	Nephe	elometry a	and Turbidimetry	144
	3.5	Molec	ular Emiss	iion Spectrometry	146
		3.5.1	Fluores	cence and Phosphorescence	146
		3.5.2	Relation	nship Between Fluorescence Intensity and Concentration	148
	3.6	Instrur	mentation	for Luminescence Measurements	150
		3.6.1	Wavele	ngth Selection Devices	150
		3.6.2	Radiatio	on Sources	151
		3.6.3	Detecto	ors	152
		3.6.4	Sample	Cells	153
	3.7	Analyt	ical Appli	cations of Luminescence	153
		3.7.1	Advanta	ages of Fluorescence and Phosphorescence	155
		3.7.2	Disadva	antages of Fluorescence and Phosphorescence	155
	Sugo	gested Ex	kperiment		156
	Prob	lems			157
	Biblio	ography.			161
Chapter 4	Infra	red, Neai	r-Infrared,	and Raman Spectroscopy	163
	4.1	Absor	ption of IF	Radiation by Molecules	164
		4.1.1	•	Moments in Molecules	
		4.1.2		f Vibrations in Molecules	
		4.1.3		nal Motion	
	4.2			on	
		4.2.1		on Sources	
			4.2.1.1	Mid-IR Sources	
			4.2.1.2	NIR Sources	
			4.2.1.3	Far-IR Sources	
			4.2.1.4	IR Laser Sources	
		4.2.2		hromators and Interferometers	
		11212	4.2.2.1	FT Spectrometers	
				Interferometer Components	
		4.2.3		Drs	
		1.2.3	4.2.3.1	Bolometer	
			4.2.3.2	Pyroelectric Detectors	
			4.2.3.3	Photon Detectors	
		4.2.4		or Response Time	
	4.3			iques	
		4.3.1		ques for Transmission (Absorption) Measurements	
			4.3.1.1	Solid Samples	
			4.3.1.2	Liquid Samples	
			4313	Gas Samples	
		4.3.2		ound Correction in Transmission Measurements	
		1.5.2	4.3.2.1	Solvent Absorption	
			4.3.2.2	Air Absorption	
		4.3.3		ques for Reflectance and Emission Measurements	
		1.5.5	4.3.3.1	Attenuated Total Reflectance (ATR)	
			4.3.3.2	Specular Reflectance	
			4.3.3.3	Diffuse Reflectance	
			4.3.3.4	IR Emission	

	4.4	FTIR Mi	licroscopy	196
	4.5	Nondis	spersive IR Systems	200
	4.6		ical Applications of IR Spectroscopy	
		4.6.1	Qualitative Analyses and Structural Determination by Mid-IR Absorption Spectroscopy.	
		4.6.2	Quantitative Analyses by IR Spectrometry	
	4.7		R Spectroscopy	
	4.7			
		4.7.1	Instrumentation	
		4.7.2	NIR Vibrational Bands	
		4.7.3	NIR Calibration: Chemometrics	
		4.7.4	Sampling Techniques for NIR Spectroscopy	
			4.7.4.1 Liquids and Solutions	214
			4.7.4.2 Solids	214
			4.7.4.3 Gases	214
		4.7.5	Applications of NIR Spectroscopy	214
	4.8	Raman	ı Spectroscopy	21
		4.8.1	Principles of Raman Scattering	217
		4.8.2	Raman Instrumentation	219
			4.8.2.1 Light Sources	219
			4.8.2.2 Dispersive Spectrometers Systems	
			4.8.2.3 FT-Raman Spectrometers	
			4.8.2.4 Fiber Optic-Based Modular and Handheld Systems	
			4.8.2.5 Samples and Sample Holders for Raman Spectroscopy	
		4.8.3	Applications of Raman Spectroscopy	
		4.8.4	The Resonance Raman Effect	
		4.8.5	Surface-Enhanced Raman Spectroscopy (SERS)	
		4.8.6		
	4.0		Raman Microscopy	
	4.9		cal Imaging Using NIR, IR, and Raman Spectroscopy	
			periments	
	RIDIIC	graphy		24.
Chapter 5	Magr	netic Reso	onance Spectroscopy	245
	5.1	Nuclea	r Magnetic Resonance Spectroscopy: Introduction	24
	5.1	5.1.1		
		5.1.2	Quantization of ¹ H Nuclei in a Magnetic Field	
		J.1.Z	5.1.2.1 Saturation and Magnetic Field Strength	
		5.1.3	Width of Absorption Lines	
		5.1.5	·	
			5.1.3.1 The Homogeneous Field	
			5.1.3.2 Relaxation Time	
			5.1.3.3 The Chemical Shift	
			5.1.3.4 Magic Angle Spinning	
			5.1.3.5 Other Sources of Line Broadening	
	5.2		NMR Experiment	
	5.3		cal Shifts	
	5.4	Spin-Sp	pin Coupling	26
	5.5	Instrum	nentation	269
		5.5.1	Sample Holder	269
		5.5.2	Sample Probe	272
		5.5.3	Magnet	
		5.5.4	RF Generation and Detection	274
		5.5.4 5.5.5		
	5.6	5.5.5	Signal Integrator and Computer	274
	5.6	5.5.5	Signal Integrator and Computerical Applications of NMR	274 275
	5.6	5.5.5 Analyti 5.6.1	Signal Integrator and Computerical Applications of NMRSamples and Sample Preparation for NMR	274 275
	5.6	5.5.5 Analyti	Signal Integrator and Computerical Applications of NMR	274 275 275

			5.6.2.2	Chemical Exchange	277
			5.6.2.3	Double Resonance Experiments	
		5.6.3	¹³ C NMR		280
			5.6.3.1	Heteronuclear Decoupling	282
			5.6.3.2	The Nuclear Overhauser Effect	282
			5.6.3.3	¹³ C NMR Spectra of Solids	283
		5.6.4	2D NMR		
		5.6.5	Qualitati	ve Analyses: Other Applications	287
		5.6.6	Quantita	tive Analyses	288
	5.7	Hyphe	enated NMI	R Techniques	291
	5.8	NMR I	maging and	d MRI	292
	5.9	Low-F	ield, Portab	ole, and Miniature NMR Instruments	294
	5.10	Limita	tions of NN	1R	297
	Sugg	gested Ex	xperiments		298
	Prob	lems			298
	Biblio	ography.			300
Chapter 6	Atom	nic Abso	rntion Snev	ctrometry	303
Chapter o					
	6.1			diant Energy by Atoms	
		6.1.1		Linewidthof Radiant Energy Absorption	
	6.2	6.1.2		9/	
	6.2			Courses	
		6.2.1		n Sources	
			6.2.1.1	Hollow Cathode Lamp (HCL)	
		622	6.2.1.2	Electrodeless Discharge Lamp (EDL)	
		6.2.2		'S	
			6.2.2.1 6.2.2.2	Flame Atomizers	
				Electrothermal Atomizers	
		622	6.2.2.3	Other Atomizers	
		6.2.3		neter Optics	
			6.2.3.1 6.2.3.2	Monochromator Optics and Spectrometer Configuration	
		6.2.4		Optics and spectrometer configuration	
		6.2.5			
				ioncial AAS Systems	
		6.2.6	6.2.6.1	High-Resolution Continuum Source AAS	
	6.2	The At		3	
	6.3	6.3.1		Process	
		6.3.2		omizationFurnace Atomization	
	6.4			AS	
	0.4	6.4.1		ctral Interferences	
		0.4.1	6.4.1.1	Chemical Interference	
			6.4.1.1	Matrix Interference	
			6.4.1.3	Ionization Interference	
			6.4.1.4		
			6.4.1.5	Non-Spectral Interferences in GFAASChemical Modification	
		612			
		6.4.2	•	Interferences	
			6.4.2.1	Atomic Spectral Interference	
			6.4.2.2	Background Absorption and its Correction	
			6.4.2.3	Continuum Source Background Correction	
			6.4.2.4	Zeeman Background Correction	
			6.4.2.5	Smith-Hieftje Background Correction	
	<i>-</i> -	A 1 :	6.4.2.6	Spectral Interferences In GFAAS	
	6.5			ations of AAS	
		6.5.1	Qualitati	ve Analysis	338

		7.4.2	Applica	tions of GD Atomic Emission Spectrometry	405
			7.4.2.1	Bulk Analysis	405
			7.4.2.2	Depth Profile Analysis	406
	7.5	Atomi		ence Spectroscopy	
		7.5.1	Instrum	entation for AFS	409
		7.5.2	Interfere	ences in AFS	
			7.5.2.1	Chemical Interference	410
			7.5.2.2	Spectral Interference	
		7.5.3	Applica	tions of AFS	
			7.5.3.1	Mercury Determination and Speciation by AFS	
			7.5.3.2	Hydride Generation and Speciation by AFS	
	7.6	Laser-l	nduced B	reakdown Spectroscopy (LIBS)	412
		7.6.1		e of Operation	
		7.6.2		entation	
		7.6.3	Applica	tions of LIBS	414
			7.6.3.1	Qualitative Analysis	415
			7.6.3.2	Quantitative Analysis	416
			7.6.3.3	Remote Analysis	417
	7.7	Atomi	c Emissior	Literature and Resources	419
	Sugg	gested Ex	kperiment	S	419
	Prob	lems			421
	Bibli	ography.			423
		3 , ,			
Chapter 8	X-ray	/Spectro	sconv		427
Chapter o					
	8.1			pectra	
		8.1.1		Levels in Atoms	
		8.1.2		y's Law	
		8.1.3		ethods	
				X-ray Absorption Process	
				X-ray Fluorescence Process	
	0.0	\/ F	8.1.3.3	X-ray Diffraction Process	
	8.2			nce	
		8.2.1		ource	
				X-ray Tube	
			8.2.1.2	Secondary XRF Sources	
			8.2.1.3	Radioisotope Sources	
		8.2.2		entation for Energy Dispersive X-ray Spectrometry	
			8.2.2.1	Excitation Source	
			8.2.2.2	Primary Beam Modifiers	
			8.2.2.3	Sample Holders	
			8.2.2.4	EDXRF Detectors	
			8.2.2.5	Multichannel Pulse Height Analyzer	
			8.2.2.6	Detector Artifact Escape Peaks and Sum PeaksPeaks	
		8.2.3		entation for Wavelength Dispersive X-ray Spectrometry	
			8.2.3.1	Collimators	
			8.2.3.2	Analyzing Crystals	
			8.2.3.3	Detectors	
			8.2.3.4	Electronic Pulse Processing Units	
			8.2.3.5	Sample Changers	
		8.2.4		neous WDXRF Spectrometers	
		8.2.5	Micro-X	RF Instrumentation	
			8.2.5.1	Micro X-ray Beam Optics	
			8.2.5.2	Micro-XRF System Components	475
		8.2.6		flection XRF	
		8.2.7	Compa	rison Between EDXRF and WDXRF	476

	8.2.8		XRF App	olications	476
			8.2.8.1	The Analyzed Layer	477
			8.2.8.2	Sample Preparation Considerations for XRF	479
			8.2.8.3	Qualitative Analysis by XRF	
			8.2.8.4	Quantitative Analysis by XRF	
	8.3	X-ray A	Absorption	1	
	8.4				
		8.4.1		rystal X-ray Diffractometry	
		8.4.2		Growing	
		8.4.3		Structure Determination	
		8.4.4		X-ray Diffractometry	
		8.4.5		(RD/XRF Systems	
		8.4.6		tions of XRD	
	8.5	X-ray F			
	Suac			S	
		•	•		
Chapter 9	Mass	Spectro	metry		519
	9.1	Princip	oles of MS.		520
		9.1.1		ng Power and Resolution of a Mass Spectrometer	
	9.2	Instrur		J	
	A Bri			nits of Measure—Vacuum Systems	
		9.2.1		Input Systems	
			9.2.1.1	Gas Expansion	
			9.2.1.2	Direct Insertion and Direct Exposure Probes	
			9.2.1.3	Chromatography and Electrophoresis Systems	
		9.2.2	Ionizatio	on Sources	
			9.2.2.1	Electron Ionization (EI)	
			9.2.2.2	Chemical Ionization (CI)	
			9.2.2.3	Atmospheric Pressure Ionization (API) Sources	
			9.2.2.4	Desorption Ionization	
			9.2.2.5	Ionization Sources for Inorganic MS	
		9.2.3		nalyzers	
			9.2.3.1	Magnetic and Electric Sector Instruments	
			9.2.3.2	Time of Flight (TOF) Analyzer	
			9.2.3.3	Quadrupole Mass Analyzer	
			9.2.3.4	MS/MS and MS ⁿ Instruments	
			9.2.3.5	Quadrupole Ion Trap	
			9.2.3.6	Fourier Transform Ion-Cyclotron Resonance (FTICR)	
			9.2.3.7	The Orbitrap TM TMMS	
		9.2.4		rs	
		J.Z. 1	9.2.4.1	Electron Multiplier	
			9.2.4.2	Faraday Cup	
			9.2.4.3	Array Detectors	
	9.3	Ion Mo		ctrometry	
	7.5	9.3.1		ld DMS Juno® Chemical Trace Vapor Point Detector	
		9.3.2		ellims HPIMS-LC System	
		9.3.2		s Ion Mobility Spectrometer Engine	
		9.3.4		G2-S Multistage MS System Incorporating the Triwave Ion Mobility Stage	
	9.4			Aolecular MS	
	J. ⊤	9.4.1		solution Mass Spectrometry	
		2.1.1	9.4.1.1	Achieving Higher Mass Accuracy (but not Resolution) from Low Resolution	
			2.1.1.1	MS Instruments	570
				IVIO ILIOCIATTICITO	1 2

			9.4.1.2	Improving the Quantitation Accuracy of Isotope Ratios from Low Resolution	F70
		0.4.2	Ouantite	MS Instrument Data Files	
		9.4.2 9.4.3		ative Analysis of Compounds and Mixtures Sequencing Analysis (Proteomics)	
		9.4.3		llysis	
		9.4.5		mental Applications	
		9.4.6		pplications of Molecular MS	
		9.4.7		ons of Molecular MS	
	9.5				
		9.5.1		rely Coupled Plasma Mass Spectrometry (ICP-MS)	
		9.5.2		tions of Atomic MS	
			9.5.2.1	Geological and Materials Characterization Applications	
			9.5.2.2	Speciation by Coupled Chromatography-ICP-MS	587
			9.5.2.3	Applications in Food Chemistry, Environmental Chemistry, Biochemistry,	
				Clinical Chemistry, and Medicine	588
			9.5.2.4	Coupled Elemental Analysis-MS	590
		9.5.3	Interfere	ences in Atomic MS	
			9.5.3.1	Matrix Effects	
			9.5.3.2	Spectral (Isobaric) Interferences	
		9.5.4		ental Approaches to Eliminating Interferences	
			9.5.4.1	High-Resolution ICP-MS (HR-ICP-MS)	
			9.5.4.2	Collision and Reaction Cells	
			9.5.4.3	MS/MS Interference Removal	
		9.5.5		ons of Atomic MS	
	Б 11			Common Spurious Effects in Mass Spectrometry	
	DIDIIO	угарпу			600
Chapter 10	Princi	ples of C	Thromatoo	graphy	603
	10.1	Introdu	ction to (Chromatography	603
	10.2			omatographic Process?	
	10.3			y in More than One Dimension	
	10.4			he Chromatographic Process at the Molecular Level: Analogy to "People on a	
				eway"	608
	10.5			of Silicon-Oxygen Compounds In Chromatography	
	10.6	Basic E	quations I	Describing Chromatographic Separations	616
	10.7	How d	o Column	Nariables Affect Efficiency (Plate Height)?	619
	10.8	Practic	al Optimiz	zation of Chromatographic Separations	621
	10.9	Extra-0	Column Ba	and Broadening Effects	622
				matography: Analyte Identification	
	10.11			asurements in Chromatography	
				ea or Peak Height: What is Best for Quantitation?	
				ion with an External Standard	
				ion with an Internal Standard	
		•		omatographic Calculations	
				ample in Section 10.13, Tables 10.1 and 10.2	
	Biblio	graphy			631
Chapter 11	Gas C	Chromato	ography		633
	11.1			opment of GC: The First Chromatographic Instrumentation	
	11.2			Leading to Present-Day Instrumentation	
	11.3			Component Design (Injectors)	
		11.3.1		5	

		11.3.2	Autosamplers	
		11.3.3	Solid Phase Microextraction (SPME)	
		11.3.4	Split Injections	640
		11.3.5	Splitless Injections	641
	11.4	GC Instr	rument Component Design (The Column)	642
		11.4.1	Column Stationary Phase	642
		11.4.2	Selecting a Stationary Phase for an Application	645
		11.4.3	Effects of Mobile Phase Choice and Flow Parameters	
	11.5		rument Operation (Column Dimensions and Elution Values)	
	11.6		rument Operation (Column Temperature and Elution Values)	
	11.7		rument Component Design (Detectors)	
			Thermal Conductivity Detector (TCD)	
			Flame Ionization Detector (FID)	
		11.7.3	Electron Capture Detector (ECD)	
		11.7.4	Electrolytic Conductivity Detector (ELCD)	
		11.7.5	Sulfur–Phosphorus Flame Photometric Detector (SP-FPD)	
		11.7.6	Sulfur Chemiluminescence Detector (SCD)	
		11.7.7	Nitrogen-Phosphorus Detector (NPD)	
		11.7.8	Photoionization Detector (PID)	
			Helium Ionization Detector (HID)	
			Atomic Emission Detector (AED)	
	11.8		nated GC Techniques (GC-MS; GC-IR; GC-GC; 2D-GC)	
	11.0		Gas Chromatography-Mass Spectrometry (GC-MS)	
		11.8.2	Gas Chromatography-IR Spectrometry (GC-IR)	
	11.9		on Indices (a Generalization of Relative R _t Information)	
			ope of GC Analyses	
	11.10		Gc Behavior of Organic Compound Classes	
			Derivatization of Difficult Analytes to Improve GC Elution Behavior	
			Gas Analysis by GC	
			Limitations of Gas Chromatography	
	Droble		Limitations of Gas Chromatography	
	DIDIIO	grapny		002
Chapter 12	Chron		by with Liquid Mobile Phases	
	12.1	High-Pe	erformance Liquid Chromatography	683
		12.1.1	HPLC Column and Stationary Phases	684
			12.1.1.1 Support Particle Considerations	686
			12.1.1.2 Stationary Phase Considerations	689
			12.1.1.3 Chiral Phases for Separation of Enantiomers	
			12.1.1.4 New HPLC Phase Combinations for Assays of Very Polar Biomolecules	
		12.1.2	Effects on Separation of Composition of the Mobile Phase	
		12.1.3	Design and Operation of an HPLC Instrument	
		12.1.4	HPLC Detector Design and Operation	
			12.1.4.1 Refractive Index Detector	
			12.1.4.2 Aerosol Detectors: Evaporative Light Scattering Detector and Corona Charged	
			Aerosol Detector	698
			12.1.4.3 UV/VIS and IR Absorption Detectors	
			12.1.4.4 Fluorescence Detector	
			12.1.4.5 Electrochemical Detectors	
		12.1.5	Derivatization In HPLC	
		12.1.5	Hyphenated Techniques in HPLC	
		12.1.0	12.1.6.1 Interfacing HPLC to Mass Spectrometry	
		12.1.7	Applications of HPLC	
	12.2		atography of lons Dissolved in Liquids	
	12.2	CHIOHIC	Trography of 10113 Dissolved in Elquius	/ 13

		12.2.1	Ion Chromatography	722
			12.2.1.1 Single-Column IC	
			12.2.1.2 Indirect Detection in IC	
	12.3	Affinity	r Chromatography	
	12.4		clusion Chromatography (SEC)	
	12.5		ritical Fluid Chromatography	
		12.5.1	Operating Conditions	
		12.5.2	Effect of Pressure	
		12.5.3	Stationary and Mobile Phases	
		12.5.4	SFC Versus Other Column Methods	
		12.5.5	Applications	
		12.5.6	Ultra Performance Convergence Chromatography (UPCC or UPC ²) – A New Synthesis	
	12.6		phoresis	
	12.0	12.6.1	Capillary Zone Electrophoresis (CZE)	
		12.6.2	Sample Injection In CZE	
		12.6.3	Detection In CZE	
		12.6.4	Applications of CZE	
		12.6.5		
	127		Modes of CE	
	12.7		Chromatography And Planar Electrophoresis	
		12.7.1	Thin Layer Chromatography (TLC)	
	D 1.1		Planar Electrophoresis on Slab Gels	
			Exercises	
	RIDIIC	ograpny		749
Chapter 13	Elect		cal Chemistry	
	13.1		mentals of Electrochemistry	
	13.2		chemical Cells	
		13.2.1	Line Notation for Cells and Half-Cells	
		13.2.2	Standard Reduction Potentials: The Standard Hydrogen Electrode	756
		13.2.3	Sign Conventions	759
		13.2.4	Nernst Equation	759
		13.2.5	Activity Series	760
		13.2.6	Reference Electrodes	762
			13.2.6.1 Saturated Calomel Electrode	762
			13.2.6.2 Silver/Silver Chloride Electrode	763
		13.2.7	Electrical Double Layer	763
	13.3	Electro	analytical Methods	
		13.3.1	Potentiometry	
			13.3.1.1 Indicator Electrodes	
			13.3.1.2 Instrumentation for Measuring Potential	
			13.3.1.3 Analytical Applications of Potentiometry	
		13.3.2	Coulometry	
		. 5.5.2	13.3.2.1 Instrumentation for Electrogravimetry and Coulometry	
			13.3.2.2 Applied Potential	
			13.3.2.3 Electrogravimetry	
			13.3.2.4 Analytical Determinations Using Faraday's Law	
			13.3.2.5 Controlled Potential Coulometry	
			13.3.2.6 Coulometric Titrations	
		1222	Conductometric Analysis	
		13.3.3		
			13.3.3.1 Instrumentation for Conductivity Measurements	
		1224	13.3.3.2 Analytical Applications of Conductometric Measurements	
		13.3.4	Polarography	
			13.3.4.1 Classical or DC Polarography	
			13.3.4.2 Half-Wave Potential	807

xvi Contents

		13.3.4.3	Normal Pulse Polarography	807	
			Differential Pulse Polarography		
	13.3		etry		
			Instrumentation for Voltammetry		
			Cyclic Voltammetry		
			Stripping Voltammetry		
	13.4 Spe		emistry		
	•				
	Problems			822	
	Bibliograph	ny		823	
Chapter 14	Thermal Ar	nalysis		825	
	14.1 The	rmogravimetr	mogravimetry		
			umentation		
			Applications of Thermogravimetry		
			e Thermogravimetry		
	14.1		f Error in Thermogravimetry		
	14.2 Diffe		al Analysis		
	14.2		umentation		
	14.2	.2 Analytical	Applications of DTA	843	
			ing Calorimetry		
	14.3	.1 DSC Instru	umentation	845	
	14.3	.2 Application	ons of DSC	851	
		14.3.2.1	Pressure DSC	853	
			Modulated DSC		
			niques		
			ted Thermal Methods		
			as Analysis		
	14.5 The	rmometric Titr	rimetry	858	
	14.6 Dire	ct Injection Er	nthalpimetry	860	
	14.7 Micr				
	14.7		C Instrumentation		
			ons of Micro DSC		
			al Titration Calorimetry		
			Flow Calorimetry		
			Materials		
		•			
	Bibliograph	ny		872	
Index				875	

Abbreviations and Acronyms Index

Instrumentation for analytical chemistry gives rise to many abbreviations, some forming "acronyms." These are often more encountered than the terms they abbreviate, and they appear extensively in the text. A reader new to the field may become lost or disoriented in this thicket of initials. To aid the student in reading the text, the **abbreviation/acronym index** below translates these and indicates the chapter where they are best defined or characterized. These acronyms are frequently compounded, as in UV/VIS (ultraviolet/visible) or LC-CI-TOFMS (interfaced liquid chromatograph to time-of-flight mass spectrometer operating in chemical ionization mode). The components of such compounded abbreviations are listed individually in the index, but not all the possible combinations. All acronyms are abbreviations, but the reverse is not true. For example, CLIPS, DART, DRIFTS and COSY are acronyms because they form words or are pronounced as words; GFAAS, APCI, and FTIR are abbreviations.

Acronym	Chapter	Abbreviated Term	Acronym	Chapter	Abbreviated Term
AAS	6	Atomic absorption	ATP	5	Adenosine triphosphate
AC	12	spectrometry Alternating current (or	ATR BCA	4 3	Attenuated total reflectance Bicinchoninic acid
ACN	12	voltage) Acetonitrile	BID	11	(Dielectric) Barrier discharge detector (GC)
AED	11	Atomic emission detector	BTEX	11	Benzene, toluene,
AES	7	Atomic emission			ethylbenzene, xylenes
		spectroscopy	CAD	12	Corona charged aerosol
AFS	7	Atomic fluorescence			detector
		spectroscopy	CAT	8	Computed axial tomography
amu	9	Atomic mass unit	CCD	4	Charge coupled device (or
AOAC	1	Association of Official	CD-	1	detector)
AOCS	5	Analytical Chemists American Oil Chemists'	CDs CE	1 12	Compact disks Capillary electrophoresis
AUCS	3	Society	CE	13	Counter electrode (in
APCI	9	Atmospheric pressure	CL	13	electrochemistry)
7 C .		chemical ionization	CEC	13	Capillary
APDC	6	Ammonium pyrrolidine			electrochromatography
		dithiocarbamate	CEM	9	Channel electron multiplier
APHA	1	American Public Health	CFFAB	9	Continuous flow-FAB
		Association	CGE	12	Capillary gel electrophoresis
API	5	American Petroleum	CI	9	Chemical ionization
		Institute	CID	7	Charge injection device (or
APIs	5	Active pharmaceutical			detector)
4.001		ingredients	CID	12	Collision-induced
APPI	9	Atmospheric pressure	CIE	2	dissociation
APT	5	photoionization Attached proton test	CIE	3	Commission Internationale
APXS	8	Alpha particle X-ray	CIEF	13	de l'Eclairage Capillary isoelectric focusing
AFAS	O	spectrometer	CIMPS	14	Controlled intensity
ASBC	5	American Society of Brewing	Civil 5	11	modulated photocurrent
11000	J	Chemists			spectroscopy
ASE	1	Accelerated solvent	CL	1	Confidence level
		extraction	CLIP	7	Collection of Line Intensity
ASTM	1	American Society for Testing and Materials			Profiles

CLIPS	9	Calculated line intensity	DTGS	4	Deuterated triglycine sulfate
		profiles	EC	8	Electron capture (radioactive
CNES	7	Centre national d'études			decay mode)
		spatiales	EC	9	Electron capture (in MS)
cm	2	Centimeter (length)	ECD	11	Electron capture detector (in
CMC	12	Critical micelle concentration			GC)
COSY	5	Correlated spectroscopy	ECD	12	Electrochemical detector (in
CPC	4	Compound parabolic		0	HPLC)
CDCIA	0	concentrator	ED	8	Energy dispersive (with XRF)
CPSIA	8	Active pharmaceutical	EDL	6	Electrodeless discharge lamp
		ingredient (API) Consumer	EDS	8	Energy-dispersive
		Protection and Safety Improvement Act	EDTA	14	spectroscopy Ethylenediaminetetraacetic
CP-MAS	5	Cross-polarization-MAS	EDIA	14	acid
CRM	9	Certified reference material	EE+	9	Even electron (ion in MS)
CT	8	Computed tomography	EGA	14	Evolved gas analysis
CTD	7	Charge transfer device	EGD	14	Evolved gas detection
CTE	14	Coefficient of thermal	EI	9	Electron ionization
C.12		expansion	EIE	7	Easily ionized element
CV	13	Cyclic voltammetry	ELCD	11	Electrolytic conductivity
CVAAS	6	Cold vapor-AAS			detector
CW	5	Continuous wave	ELSD	12	Evaporative light scattering
CZE	12	Capillary zone			detector
		electrophoresis	EM	9	Electron multiplier
DAD	12	Diode array detector	EMA	8	Electron microprobe
DART	9	Direct analysis in real time			analyzer
DC	6	Direct current	EMEA	9	European Medicines Agency
DCP	7	Direct current plasma	emf	13	Electromotive force (voltage)
DDT	1	Dichlorodiphenyltrichloroethane	ENDOR	5	Electron nuclear double
DEPT	5	Distortionless enhancement			resonance
		by polarization transfer	EOF	12	Electroosmotic flow
DESI	9	Desorption electrospray	EPA	1	Environmental Protection
		ionization			Agency
DI	1	Deionized	ESA	9	Electrostatic analyzer
DI	9	Desorption ionization	ESI	9	Electrospray ionization
DID	12	Discharge ionization	ETA ETD	6 9	Electrothermal atomizer Electron transfer dissociation
DIE	14	detector Direct injection	ETV	9	Electrothermal vaporization
DIE	14	enthalpimetry	EU	3	European Union
DIN	7	Direct insertion nebulizer	EXAFS	8	Extended X-ray absorption
DL	6	Detection limit	EXAI 5	O	fine structure
DMD	12	Dispersive monochromator	FAAS	6	Flame-AAS
		detector	FAB	9	Fast atom bombardment
DME	13	Dropping mercury electrode	FAME	11	Fatty acid methyl ester
DMS	9	Differential (ion) mobility	FC	8	Flow proportional counter
		spectrometry	FET	8	Field effect transistor
DMSO	4	Dimethylsulfoxide	FFT	1	Fast Fourier transform
DNA	9	Deoxyribonucleic acid			(algorithm)
DR	4	Diffuse reflectance	FIA	6	Flow injection analysis
DRIFTS	4	Diffuse-reflectance-IR-FT-	FIAS	6	Flow injection atomic
		spectroscopy			spectroscopy
dsDNA	5	Double-stranded DNA	FID	5	Free induction decay (in
DSC	14	Differential scanning			NMR)
	4.4	calorimetry	FID	11	Flame ionization detector (in
DTA	14	Differential thermal analysis		4.4	GC)
DTG	14	Derivative thermogravimetry	FMC	14	Flow microliter calorimeter

FPA	4	Focal plane array	HR-CS	6	High resolution continuum
FPC	9	Focal plane camera	IIII-C5	O	source (AAS)
FPD	11	Flame photometric detector	HR-ICP-MS	9	High-resolution ICP-MS
FRPs	5	Fiber-reinforced plastics	HRT	9	High-resolution TOF
FT	1	Fourier transform	Hz	2	Hertz (frequency)
FT-MS	9	FT-ion cyclotron resonance	IC	12	Ion chromatography
		(MS)	ICDD	8	International Centre for
FTIR	4	Fourier transform IR	ico b	O	Diffraction Data
FT-ICR-MS	9	Fourier transform mass	ICP	7	Inductively coupled plasma
		spectrometry	ICP-SFMS	9	ICP-sector field MS
FT-NMR	5	Fourier transform-NMR	ICR	9	lon cyclotron resonance
FW	4	Formula weight	IDL	1	Instrument detection limit
FWHM	8	Full width at half maximum	IDMS	11	Isotope dilution mass
GC	11	Gas chromatography			spectrometry
GC × GC	11	2-D orthogonal GC–GC	IE	12	lon exchange
		coupling	IEC	7	Interelement correction
GD	7	Glow discharge	IEF	12	Isoelectric focusing
GDMS	9	Glow discharge MS	IMS	9	lon mobility spectrometry
GFAAS	6	Graphite furnace-AAS	INADEQUATE	5	Incredible natural-
GFC	12	Gel filtration	•		abundance double-
		chromatography			quantum transfer
GFs	7	Graphite furnaces	IPC	12	lon-pairing chromatography
GF-LEAFS	7	Graphite furnace laser-	IPCE	13	Incident photon conversion
		excited AFS			efficiency
GPC	12	Gel permeation	IR	4	Infrared
		chromatography	IRE	4	Internal reflection element
HCD	9	High-energy collisional	IR-SEC	13	Infrared-SEC
		dissociation	IS	10	Internal standard
HCL	6	Hollow cathode lamp	ISC	3	Intersystem crossing
HD	8	High density	ISE	13	Ion-selective electrode
HEPS	7	High energy prespark	ISFET	13	Ion-selective field-effect
HETCOR	5	Heteronuclear chemical shift			transistor
		correlation	ISO	5	International Standards
HETP	10	Height equivalent to a			Organization
		theoretical plate	ITC	14	Isothermal titration
HF	1	Hydrofluoric acid			calorimetry
HG	7	Hydride generation	ITO	13	Indium tin oxide
HGAAS	6	Hydride generation-AAS	IUPAC	3	International Union of Pure
HH XRF	8	Handheld XRF			and Applied Chemistry
HHPLC	12	Hyper-HPLC	JEOL	9	Japan Electron Optics
HID	11	Helium ionization detector			Laboratory
HILIC	12	Hydrophilic interaction liquid	KED	9	Kinetic energy discrimination
		chromatography			(ICP-MS)
HMDE	13	Hanging mercury drop	LAESI	9	Laser ablation electrospray
		electrode		_	ionization
HMF	3	Hydroxymethylfurfural	LANL	7	Los Alamos National
НМІ	9	High matrix introduction		_	Laboratory
	10	(ICP-MS)	LASS	7	Laser spark spectroscopy
HPAE	12	High performance anion	LC	10	Liquid chromatography
		exchange	LD	8	Low density
HPIMS™	9	high-performance ion	LED	3	Light emitting diode
LIDIC	10	mobility spectrometry	LIBS	7	Laser-induced breakdown
HPLC	12	High performance	LIMC	1	spectroscopy
		(or pressure) liquid	LIMS	1	Laboratory information
		chromatography			management system

LIPS	7	Laser-induced plasma	NP	12	Normal phase (LC)
		spectroscopy	NPD	11	Nitrogen-phosphorous
LOD	1	Limit of detection			detector
LOQ	1	Limit of quantitation	NRC	11	Nuclear Regulatory
L-PAD	7	Large format programmable			Commission
		array detector	NRCC	1	National Research Council of
LPDA	3	Linear photodiode array			Canada
LVDT	14	Linear variable displacement	NTP	12	Normal temperature and
		transducer			pressure
LVP	9	Large volume parenteral	ODS	12	Octadecylsilyl
LVR	14	Linear viscoelastic range	OE+•	9	Odd electron (ion in MS)
m	2	Meter (length)	OES	7	Optical emission
MALDI	9	Matrix-assisted laser-			spectroscopy
		desorption ionization	OEM	9	Original equipment
MAS	5	Magic angle spinning			manufacturer
MC	9	Multiple collector	OTE	13	Optically transparent
MCA	8	Multichannel analyzer			electrode
MCT	4	Mercury cadmium telluride	PAD	12	Pulsed amperometric
MDL	1	Method detection limit			detection (LC)
MDSC	14	Modulated DSC®	PAGE	12	Polyacrylamide gel
MEK	6	Methyl ethyl ketone			electrophoresis
MEKC	12	Micellar electrokinetic	PAHs	1	Polynuclear aromatic
MIDIC	1	chromatography	DDDE	0	hydrocarbons
MIBK	1	Methyl isobutyl ketone	PBDE	9	Polybrominated diphenyl
MIP	7 7	Microwave-induced plasma	DCA	4	ether
MIT	/	Massachusetts Institute of	PCA	4	Principal component
MOC	7	Technology Metal–oxide–semiconductor	РСВ	1	analysis
MOS MP	7		PCB PCDE	1 9	Polychlorinated biphenyl
MRI	5	Microwave plasma (source)	PCDE	9	Polychlorinated diphenyl ether
IVIKI	3	Magnetic resonance imaging	PCr	5	Phosphocreatine
MS	9	Mass spectrometry	PDA	3	Photodiode array
MSA	2	Method of standard	PDE	9	Permissible daily exposure
MISA	2	additions	PDMS	11	Polydimethylsiloxane
MSD	11	Mass selective detector	PEEK	12	Polyether ether ketone
MW	9	Molecular weight	PEG	5	Polyethylene glycol
NASA	7	National Aeronautics and	PET	14	Polyethylene terephthalate
		Space Administration	PFTBA	9	Perfluorotributylamine
NCE	13	Normal calomel electrode	PID	11	Photoionization detector
NICI	9	Negative ion chemical	PIN	8	(Silicon junction) p-i-n
		ionization			(diode)
NIEHS	5	National Institute of	PIXE	8	Particle-induced X-ray
		Environmental Health and			emission
		Safety	PLOT	11	Porous layer open tubular
NIR	4	Near infrared	PLS	4	Partial least squares
NIRIM	4	NIR-Raman imaging	PMI	8	Positive material
		microscope			identification
NIST	1	National Institute of	PMT	3	Photomultiplier tube
		Standards and Technology	POP	11	Persistent organic pollutant
nm	2	Nanometer (length)	ppb, ppt, ppq	1	Parts per billion (109), trillion
NMR	5	Nuclear magnetic resonance			(1012), quadrillion (1015)
NMRFAM	5	National Magnetic	PTFE	4	Polytetrafluoroethylene
		Resonance Facility at	PVC	14	Polyvinyl chloride
	_	Madison	Q	9	Quadrupole mass analyzer
NOE	5	Nuclear Overhauser effect	QC	3	Quality control
NOESY	5	NOE-spectroscopy	QD	12	Charge detector (IE-LC)

QID	9	Quadrupole ion deflector	SOPs	1	Standard operating
QIT	9	Quadrupole ion trap			procedures
QqQ	9	Triple quadrupole mass	SPADNS	5	See end of Table 3.7
		analyzer	SPE	1	Solid phase extraction
QQQ	9	Triple quadrupole mass analyzer	SP-FPD	11	Sulfur–phosphorous flame photometric detector
QTH	4	Quartz tungsten halogen	SPME	1	Solid phase microextraction
QIII	4	(lamp)	SRM	9	Standard reference material
QuEChERS	1	Quick, easy, cheap, effective,	STA	14	Simultaneous thermal
QUECHENS	1	safe	JIA	14	analysis
RE	2	Relative error	STP	9	Standard temperature and
REE	9	Rare earth elements			pressure
REF	13	Reference electrode	STPF	6	Stabilized temperature
RF	5	Radiofrequency			platform furnace
RGA	9	Residual gas analyzer	SWIFT	5	Sweep imaging with Fourier
RI	11	Retention index (in GC)		_	transform
RI	12	Refractive index (as in LC	TA	1	Thermal analysis
D114	0	detector)	TBAH	13	Tetrabutylammonium
RNA	9	Ribonucleic acid	TCD	11	hydroxide
RoHS	7	Restriction of the use of hazardous substances	TCD	11	Thermal conductivity detector
RP	12	Reverse phase	TDS	13	Total dissolved solids
RRF	10	Relative response factor	TEAP	13	Tetraethylammonium
RRT	10	Relative retention time			perchlorate
RSD	1	(%) Relative standard	TEEM	9	Tunable-energy electron
		deviation			monochromator (beam)
RT	13	Room temperature	TFME	13	Thin film mercury electrode
RU	7	Raies ultimes	TG	14	Thermogravimetry
SBSE	1	Stirbar sorptive extraction	TGA	14	Thermogravimetric analysis
SBW	2	Spectral bandwidth	THF	1	Tetrahydrofuran
SC	8	Scintillation counter	TIC	11	Total ion chromatogram
SCD	7	Segmented charge detector	TISAB	13	Total ionic strength adjusting
SCD	11	Sulfur chemiluminescence			buffer
		detector	TLC	12	Thin layer chromatography
SCE	13	Saturated calomel electrode	TMAH	15	Tetramethylammonium
SCF	12	Supercritical fluid		_	hydroxide
SDD	8	Silicon drift detector	TMS	5	Tetramethylsilane
SDS	12	Sodium dodecyl sulfate	TNT	9	Trinitrotoluene
SEC	12	Size exclusion	TOF	9	Time of flight (in mass
CEC.	10	chromatography	TT	1.4	spectrometry) Thermometric titration
SEC SEM	13	Spectroelectrochemistry Scanning electron	TT TXRF	14 8	Total reflection XRF
SEIVI	8	microscope	UHPLC	10	Ultra-high-performance
SEM	9	Secondary electron	OHFEC	10	liquid chromatography
JLIVI)	multiplier	μm	2	Micrometer (length)
SERS	4	Surface-enhanced Raman	UPC2	12	Ultra performance
JENS	'	spectroscopy	01 62	12	convergence
SFC	12	Supercritical fluid			chromatography
		chromatography	URL	12	Uniform resource locator
SFE	1	Supercritical fluid extraction	USN	7	Ultrasonic nebulizer
SHE	13	Standard hydrogen	USP	9	United States Pharmacopeia
		electrode	UV	3	Ultraviolet
SI	1	Système International	VIS	3	Visible (light wavelength
		d'Unités			range)
SIM	11	Selected ion monitoring	WD	8	Wavelength dispersive (with
S/N	1	Signal to noise (ratio)			XRF)

xxii Abbreviations and Acronyms Index

WDXRF	8	Energy-dispersive XRF	XRA	8	X-ray absorption
		(EDXRF) wavelength-	XRD	8	X-ray diffraction
		dispersive XRF	XRF	8	X-ray fluorescence
WE	13	Working electrode	XRT	8	X-ray transmission
WEEE	7	Waste electrical and	YAG	3	yttrium aluminum garnet
		electronic equipment	ZPD	4	Zero path difference
XIC	11	Extracted ion chromatogram	% RE	2	Percent relative error

Preface

Analytical chemistry today is almost entirely instrumental analytical chemistry and it is performed by many scientists and engineers who are not chemists. Analytical instrumentation is crucial to research in molecular biology, medicine, geology, food science, materials science, and many other fields. While it is true that it is no longer necessary to have almost artistic skills to obtain accurate and precise analytical results using instrumentation, the instruments should not be considered "black boxes" by those using them. The well-known phrase "garbage in, garbage out" holds true for analytical instrumentation as well as computers. We hope this book serves to provide users of analytical instrumentation with an understanding of their instruments.

This textbook is a concise and updated version of our *Undergraduate Instrumental Analysis Textbook*, designed for teaching undergraduates and those working in chemical fields outside analytical chemistry how modern analytical instrumentation works and what the uses and limitations of analytical instrumentation are.

Mathematics is kept to a minimum. No background in calculus, physics, or physical chemistry is required. The major fields of modern instrumentation are covered, including applications of each type of instrumental technique. Each chapter includes a discussion of the fundamental principles underlying each technique, detailed descriptions of the instrumentation, and a large number of applications. Each chapter includes an updated bibliography and problems, and most chapters have suggested experiments appropriate to the technique.

While the authors are extremely grateful to the many experts listed in the acknowledgments, who have provided graphics, technical advice, rewrites, and reviews of various sections, any errors that are present are entirely the responsibility of the authors.

James W. Robinson Eileen M. Skelly Frame George M. Frame II



Authors



James W. Robinson earned his BS (Hons), PhD, and DSc from the University of Birmingham, England. He is professor emeritus of chemistry, Louisiana State University, Baton Rouge, Louisiana. A fellow of the Royal Society of Chemistry, he is the author of 250 professional papers, book chapters, and several books including *Atomic Absorption*

Spectroscopy and Atomic Spectroscopy, first and second editions. He was editor in chief of Spectroscopy Letters and the Journal of Environmental Science and Health (both Marcel Dekker, Inc.); executive editor of Handbook of Spectroscopy Vol. 1 (1974), Vol. 2 (1974), Vol. 3 (1981); and Practical Handbook of Spectroscopy (1991) (all CRC Press). He served on the National University Accreditation Committee from 1970–1971. He was a visiting distinguished professor at University of Colorado in 1972 and University of Sydney, Australia in 1975. He served as the Gordon Conference Chairman in Analytical Chemistry in 1974. Professor Emeritus James W. Robinson passed away in November, 2018, at 95 years of age.

Eileen M. Skelly Frame was adjunct professor, Department of Chemistry and Chemical Biology, Rensselaer Polytechnic Institute (RPI), Troy, NY, and head of Full Spectrum Analytical Consultants. Dr. Skelly Frame was the first woman commissioned from the Drexel University Army ROTC program. She graduated from Drexel *summa cum laude* in chemistry. She served as medical service corps officer in the U.S. Army from 1975 to 1986, rising to the rank of Captain. For the first

five years of her military career, Eileen was stationed at the 10th Medical Laboratory at the U.S. Army Hospital in Landstuhl Germany. Thereafter, she was selected to attend a three-year PhD program in chemistry at Louisiana State University. She received her doctorate in 1982 and became the first female chemistry professor at the U.S. Military Academy at West Point. Following her military service, she joined the General Electric Corporation (now GE Global Research) and supervised the atomic spectroscopy laboratory. In addition to her duties at RPI, she was clinical and adjunct professor of chemistry at Union College in Schenectady, NY. She was well known for her expertise in in the use of instrumental analysis to characterize a wide variety of substances, from biological samples and cosmetics to high-temperature superconductors, polymers, metals, and alloys. She was an active member of the American Chemical Society for 45 years, and a member of several ASTM committees. Dr. Skelly Frame passed away in January of 2020, shortly after completion of this book.

George M. Frame II is a retired scientific director, Chemical Biomonitoring Section of the Wadsworth Laboratory, New York State Department of Health, Albany. He has a wide range of experience in analytical chemistry and has worked at the GE Corporate R&D Center (now GE Global Research), Pfizer Central Research, the U.S. Coast Guard R&D Center, the Maine Medical Center, and in the U.S. Air Force Biomedical Sciences Corps. He is a member of the American Chemical Society. Dr. Frame earned his AB in chemistry from Harvard College, Cambridge, Massachusetts, and his PhD in analytical chemistry from Rutgers University, New Brunswick, New Jersey.



Acknowledgments

The following people are gratefully acknowledged for their assistance in the successful contribution to this textbook or our Undergraduate Instrumental Analysis textbook, Seventh Edition. They provided diagrams, photographs, application notes, spectra, chromatograms, and many helpful comments, revisions, and suggestions.

Thanks are due, in no specific order,

- Active Spectrum, Inc., Dr. James R. White, Christopher J. White, and Colin T. Elliott
- Agilent Technologies, Gwen Boone, Doug Shrader, Ed McCurdy, Pat Grant, Laima Baltusis, Dan Steele, Jim Simon, Paul Canavan, Amy Herlihy, Eric Endicott, Valerie Lopez, William Champion, and Matt Nikow, Doug Shrader, and Ed McCurdy
- Albany Advanced Imaging, Herk Alberry, Mike Farrell, and Danny Dirico
- Alfred-Wegner-Institute for Polar and Marine Research, Bremerhaven, Germany, Dr. Christian Bock
- **Allen Design**, Mary Allen
- Anasazi Instruments, Inc., Donald Bouchard
- Applied Photonics Ltd., Dr. Andrew Whitehouse
- Applied Rigaku Technologies, Inc., Robert Bartek
- **Applied Separations, Inc.**, Rolf Schlake
- **ASTM International**, Jamie Huffnagle, Len Morrisey, and Brent Cleveland
- **AstraNet Systems Ltd**., Ray Wood
- Avantor Performance Materials, Inc., Paul Smaltz and Anne Logan
- **BaySpec, Inc.**, Steve Pullins and Eric Bergles
- Bio-Rad Informatics Division, Marie Scandone, Wes Rawlins, Cindy Addenbrook, Sean Battles, Dean Llanas, Chris Wozniak, and Chris Lein
- **Bruker AXS,** Dr. Alexander Seyfarth
- Bruker BioSpin, Pat Wilkinson, James Beier and Dr. Ralph Weber
- Bruker Corporation, Dr. Thorsten Thiel, Kodi Morton, Catherine Fisk, Andrew Hess, Armin Gross, Sarah Nelson, and Jerry Sooter
- Bruker Optics, Inc., Dr. Z. Harry Xie and Amy Herlihy
- **B BÜCHI Labortechnik AG**, Birke Götz
- **Buchi Corporation**, William Ickes
- BURLE Electro-Optics, Inc., Dr. Ronald Starcher

- **C Technologies**, Eric Shih and Mark Salerno
- **CambridgeSoft Corporation**, Irwin Schreiman
- **Carpenter Technologies**, Dr. Tom Dulski
- **CEM Corporation**, Dr. Mike Collins
- Centers for Disease Control, Atlanta, Georgia, Dr. Robert Kobelski
- **CERNO, Inc.**, Yongdong Wang and Ming Gu
- **CETAC Technologies**, Todd Maxwell
- Chemring, Inc., Jeff Okamitsu
- **Enwave Optronics, Inc.**, Dawn Nguyen
- **Excellims**, Carol Morloff
- **Gamry Instruments, Inc.**, Dr. Chris Beasley and Burak Uglut
- GE Healthcare Life Sciences, Mary Jo Wojtusik and Michele Giordiano
- Glass Expansion, Inc., Ryan Brennan
- Hellma USA, Inc., Evan Friedmann
- **Hitachi High Technologies America**, Mike Hurt and Luis Moreno
- HORIBA Scientific, Dr. A. Horiba, Atsuro Okada, Juichiro Ukon, Mike Pohl, Philippe Hunault, Patrick Chapon, Phil Shymanski, Diane Surine, Joanne Lowy, Andrew Whiteley, Christophe Morin, and David Tuschel
- **Teledyne Leeman Labs, Inc.**, Peter Brown, Dave Pfeil, and Dr. Manuel Almeida
- **Implen, Inc.**, Heather Grael
- International Crystal Manufacturing, Inc., Mark Handley
- **IonSense, Inc.**, Mike Festa
- **JEOL, Inc.**, Michael Fry, Dr. Chip Cody, Pam Mansfield, Masaaki Ubukata, and Patricia Corkum
- **LECO Corporation**, Pat Palumbo, Bill Strzynski, Lorne M. Fell, and Veronica Jackson
- NIST, Dr. Cedric Powell
- Lehigh University, Dr. James Roberts
- **LSU**, Professor Emeritus Robert Gale
- **Mettler Toledo, Inc.**, Steve Sauerbrunn
- Microspectral Analysis, LLC, Monique Claverie, Dr. Joseph E. Johnson, and Dr. David Wooton
- **Milestone, Inc.**, Merrill Loechner
- NETZSCH Instruments North America, LLC, Dr. Gilles Widawski and Fumi Akimaru
- **NETZSCH-Gerätebau GmbH**, Dr. Thomas Rampke and Stephan Knappe
- **Newport Corporation**, Nancy Fernandes

- NIST Mass Spec Data Center, Dr. S.E. Stein and Anzor I. Mikaia
- **NITON Corp**., Volker Thomsen
- Norton Scientific, Inc., Bryan C. Webb
- Olympus NDT, Eoin Vincent, Samuel Machado, and John Nikitas
- Pacific University, Professor Ronald Bailey, Dr.
 O. David Sparkman
- **Palisade**, Stanton Loh
- **PANalytical, Inc.**, David Coler
- PerkinElmer, Inc., Andy Rodman, Giulia Orsanigo, Christopher Tessier, Sarah Salbu, and Danielle Hawthorne
- Pfizer Central Research and Development, Dr. Alex Medek
- Phenomenex, Inc., Michael Garriques and Karen Anspach
- **Photonis**, Margaret M. Cooley
- Physical Electronics USA, Inc., Dr. John F. Moulder
- picoSpin, LLC, John Price, Dean Antic, and Chuck Miller
- PIKE Technologies, Jenni L. Briggs and Z. Stanek
- Process NMR Associates, LLC, Dr. John C. Edwards
- **Prosolia**, Joseph H. Kennedy
- Rensselaer Polytechnic Institute, Dr. Christin Choma, Professor Ronald Bailey and Professor Peter Griffiths
- Restek, Dr. Frank Dorman, Dr. Jack Cochran and Pam Decker
- **Rigaku Corporation**, Michael Nelson
- Rigaku Raman Technologies, Inc., Alicia Kimsey and Claire Dentinger
- Scripps Research Institute Center for Mass Spectrometry, Professor Gary Siudzak
- **SGE**, A. Audino and Kerry Scoggins
- Shimadzu Scientific Instruments, Inc., Keith Long, Mark Talbott, Mark Taylor, and Kevin McLaughlin
- **Sigma-Aldrich,** Wes Rawlins, Cindy Addenbrook, Sean Battles, Dean Llanas, Chris Wozniak, and Chris Lein
- SPECTRO Analytical Instruments, Alan Merrick
- **SPEX CertiPrep, Inc.**, Ralph Obenauf

- Starna Scientific, Inc., John Hammond, Rosemary Huett, and Keith Hulme
- State University of New York College of Environmental Science and Forestry, Professor F. X. Webster
- **Supelco**, Jill Thomas and Michael Monko
- Supercritical Fluid Technologies, Inc. Kenneth Krewson
- **AMETEK**, Jim McKinley, Dale Edcke and Bob Anderhalt
- **TA Instruments** team with special thanks to Roger Blaine, Fred Wiebke, Charles Potter and Terry Allen
- Thermo Fisher Scientific, Mark Mabry, Bob Coel, Ed Oliver, Lara Pryde, Jim Ferrara, John Flavell, Chuck Douthitt, Keith Bisogno, Mary Meegan-Litteer, Jackie Lathos-Markham, Todd Strother, Joseph Dorsheimer, Marty Palkovic, Dr. Julian Phillips, Wendy Weise, Carl Millholland, Michael Bradley, Janine O'Rourke, Eric Francis, Art Fitchett, Dr. Stephan Lowry, Timothy O. Deschaines, Fergus Keenan, Simon Nunn, Ryan Kershner, Elizabeth Guiney, Russell Diemer, Michael W. Allen, Bill Sgammato, Dr. John Wolstenholme, Dr. Joachim Hinrichs, Carolyn Carter, Kathy Callaghan, Allen Pierce, Arthur Fitchitt, Fraser McLeod, Frank Hoefler, and Todd Strother
- Toshiba America Medical Systems, Vielen Dank and Julie Powers
- **TSI, Inc.**, Steve Buckley and Edwin Pickins
- University of Cincinnati, the late Professor Milton
- University of Idaho, Professor Peter Griffiths
- **University of Massachusetts, Amherst**. Dr. Elizabeth Williams and Professor Julian Tyson
- University of Melbourne, Australia, Professor Stephen P. Best
- University of Wisconsin, NMRFAM, Madison (nmrfam.wisc.edu), Dr. Anne Lynn Gillian-Daniel
- **US Army Research Laboratory**, Dr. Andrzej Miziolekand and Dr. Andrew Whitehouse
- **Vanderbilt University**, Professor David Hercules
- Waters Corp., Brian J. Murphy and Dave DePasquale
- WITec GmbH, Harald Fischer
- ZAHNER-Elektrik GbmH & Co.KG, Dr. Hans Joachim Schaefer and C.-A. Schiller

Concepts of Instrumental Analytical Chemistry

1.1 INTRODUCTION: WHAT IS INSTRUMENTAL

ANALYTICAL CHEMISTRY?

Perhaps the most functional definition of analytical chemistry is that it is "the qualitative and quantitative characterization of matter". The word characterization is used in a very broad sense. It may mean the identification of the chemical compounds or elements present in a sample to answer questions such as "Is there any vitamin E in this shampoo as indicated on the label"? or "Is this white tablet an aspirin tablet"? or "Is this piece of metal iron or nickel"? This type of characterization, to tell us what is present is called qualitative analysis. Qualitative analysis is the identification of one or more chemical species present in a material. Characterization may also mean the determination of how much of a particular compound or element is present in a sample, to answer questions such as "How much acetylsalicylic acid is in this aspirin tablet"? or "How much nickel is in this steel"? This determination of how much of a species is present in a sample is called quantitative analysis. Quantitative analysis is the determination of the amount of a chemical species present in a sample. The chemical species may be an element, compound, or ion. The compound may be organic or inorganic. Characterization can refer to the entire sample (bulk analysis), such as the elemental composition of a piece of steel, or to the surface of a sample (surface analysis), such as the identification of the composition and thickness of the oxide layer that forms on the surface of most metals exposed to air and water. The characterization of a material may go beyond chemical analysis to include structural determination of materials, the measurement of physical properties of a material, and the measurement of physical chemistry parameters like reaction kinetics. Examples of such measurements are the degree to which a polymer is crystalline as opposed to amorphous, the temperature at which a material loses its water of hydration, how long it takes for antacid "Brand A" to neutralize stomach acid, and how fast a pesticide degrades in sunlight. These diverse applications make analytical chemistry one of the broadest in scope of all scientific disciplines. Analytical chemistry is critical to our understanding of biochemistry, medicinal chemistry, geochemistry, environmental science, forensic science, atmospheric chemistry, polymer chemistry, metallurgy, and many other scientific disciplines.

For many years, analytical chemistry relied on chemical reactions to identify and determine the components present in a sample. These types of classical methods, often called "wet chemical methods", usually required that a part of the sample be taken, dissolved in a suitable solvent if necessary, and the desired reaction carried out. The most important analytical fields based on this approach were volumetric and gravimetric analyses. Acid-base titrations, oxidation-reduction titrations, and gravimetric determinations, such as the determination of silver by precipitation as silver chloride are all examples of wet chemical analyses. These types of analyses require a high degree of skill and attention to detail on the part of the analyst if accurate and precise results are to be obtained. They are also time-consuming and the demands of today's high-throughput pharmaceutical development labs, forensic labs, commercial environmental labs, and industrial quality control labs often do not permit the use of such time-consuming methods for routine analysis. In addition, it may be necessary to analyze samples without destroying them. Examples include evaluation of valuable artwork to determine if a painting is really by a famous "Old Master" or is a modern forgery, as

1

well as in forensic analysis, where the evidence may need to be preserved. For these types of analyses, **non-destructive analysis** methods are needed. Wet chemical analysis is still used in specialized areas of analysis, but many of the volumetric methods have been transferred to automated instruments. Classical analysis and instrumental analysis are similar in many respects, such as in the need for proper sampling, sample preparation, assessment of accuracy and precision, and proper record-keeping. Some of the topics discussed briefly in this chapter are covered at greater length in more general texts on analytical chemistry and quantitative analysis. Several of these types of texts are listed in the bibliography.

Most analyses today are carried out by **instrumental analytical chemistry**, using specially designed electronic instruments controlled by computers. These instruments make use of the interaction of electromagnetic radiation and matter, or of some physical property of matter, to characterize the sample being analyzed. Often these instruments have automated sample introduction, automated data processing, and even automated sample preparation. To understand how instrumentation operates and what information it provides requires knowledge of chemistry, physics, mathematics, and engineering. The fundamentals of common analytical instruments and how measurements are performed with these instruments are the subjects of the following chapters on specific instrumental techniques.

The field of analytical chemistry is advancing rapidly. To keep up with the advances, the analytical chemist must understand the fundamentals of common instrumental analytical techniques, their capabilities, and their shortcomings. The analytical chemist must understand the problem to be solved, select the appropriate techniques to use, design the analytical experiment to provide relevant data, and ensure that the data obtained is valid. Merely providing data to other scientists is not enough; the analytical chemist must be able to interpret the data, and communicate the meaning of the results, together with the accuracy and precision (the reliability) of the data, to scientists in other fields who will use the data. This means that the analytical chemist will need to be conversant with materials science, metallurgy, biology, pharmacology, agricultural science, food science, geology, and so on. In addition to understanding the scientific problem, the modern analytical chemist often must also consider factors such as time limitations and cost limitations in providing an analysis. Whether one is working for a government regulatory agency, a hospital, a private company, or a university, analytical data must be legally defensible. It must be of known, documented quality. Record-keeping, especially computer record keeping using Laboratory Information Management Systems (LIMS), Electronic Laboratory Notebooks (ELNs), and modern "cloudbased" information storage systems, assessing accuracy and precision, statistical handling of data, documenting, and ensuring that the data meet the applicable technical standards are especially critical aspects of the job of modern analytical chemists.

Analytical chemistry uses many specialized terms that may be new to you. The definitions of the terms, usually shown in boldface, must be learned. The units used in this text are, for the most part, the units of the Système International d'Unités (SI system). The SI system is used around the world by scientists and engineers. The tables (Appendix 1.B. on the book's website) give the primary units of measurement in the SI system. A comprehensive list of SI units, SI derived units and definitions, as well as non-SI units may be found at the US National Institute of Standards and Technology website at http://physics.nist.gov.

1.2 ANALYTICAL APPROACH

A major personal care products manufacturer receives a phone call from an outraged customer whose hair has turned green after using their "new, improved shampoo". The US Coast Guard arrives at the scene of an oil spill in a harbor and finds two ship captains blaming each other for the spill. A plastics company that sells bottles to a water company bottling "pure crystal-clear spring water" discovers that the 100,000 new empty bottles it is ready to ship are slightly yellow in color instead of crystal clear. A new, contagious disease breaks out and people are dying of flu-like symptoms. What caused the problem? How can it be prevented in the future? Who is at fault? Can a vaccine or drug treatment be developed quickly? These sorts of problems and many more occur daily around the world, in industry, in medicine, and

in the environment. A key figure in the solution of these types of problems is the analytical chemist. The analytical chemist is first and foremost a problem-solver and to do that, must understand the analytical approach, the fundamentals of common instrumental analytical techniques, their uses, and their limitations.

The approach used by analytical chemists to solve problems may include the following steps:

- 1. Defining the problem and designing the analytical method
- 2. Sampling and sample storage
- 3. Sample preparation
- 4. Performing the measurement
- 5. Assessing the data
- 6. Method validation
- 7. Documentation

General sample preparation will be discussed in this chapter, but instrument-specific sample preparation is included in the appropriate chapter on each technique. Data assessment, method validation, and documentation will not be covered as the focus of this text is on instrumentation. The text by Christian cited in the bibliography has an excellent introduction to analytical data handling, validation and documentation for the interested student.

1.2.1 DEFINING THE PROBLEM

The analytical chemist must find out what information needs to be known about the sample, material, or process being studied, how accurate and precise the analytical information must be, how much material or sample is available for study, and if the sample must be analyzed without destroying it. Is the sample organic or inorganic? Is it a pure material or a mixture? Does the customer want a bulk analysis or information about a particular fraction of the sample, such as the surface? Does the customer need to know if the sample is homogeneous or heterogeneous with respect to a given analyte? Does the customer need elemental information or information about the chemical species (ionic or molecular, particular oxidation states) present in the sample? The answers to such questions will guide the analyst in choosing the analytical method. If the sample is an unknown material, the analyst must find out if it is organic or inorganic, pure or a mixture, as part of solving the problem. The analyte is the substance to be measured; everything else in the sample is called the **matrix**. There may be more than one analyte in a given sample. The terms analysis and analyze are applied to the sample under study, as in "this water was analyzed for nitrate ion" or "an analysis of the contaminated soil was performed". Water and soil are the samples being analyzed. The terms determine and determinations are applied to the measurement of the analyte in the sample, as in "nitrate ion was determined in the water sample", "a determination of lead in blood was made because the symptoms indicated lead poisoning", or "an analysis of the soil was performed and cyanide levels were determined". Nitrate ion, lead, and cyanide are the analytes being determined; water, blood, and soil are the samples. Other components in the sample matrix may interfere with the measurement of the analyte; such components are called **interferences**.

A sample may be **homogeneous**, that is, it has the same chemical composition everywhere within the sample. Pure table salt, a pure milk chocolate bar, and pure water are examples of homogeneous materials. Many samples are **heterogeneous**; the composition *varies* from region to region within the sample. Vanilla pudding with raisins in it and a chocolate bar with whole almonds in it are heterogeneous; you can see the composition difference. In most real samples, the heterogeneity may not be visible to the human eye. The variation in composition can be *random* or it can be *segregated* into regions of distinctly different compositions.

A significant part of defining the problem is the decision between performing a qualitative analysis and a quantitative analysis. Often the problem is first tackled with a qualitative analysis, followed by a quantitative analysis for specific analytes. The analyst needs to

communicate with the customer who is requesting the analysis. Two-way communication is important, to be certain that the problem to be solved is understood and to be sure that the customer understands the capabilities and limitations of the analysis.

1.2.1.1 QUALITATIVE ANALYSIS

Qualitative analysis is the branch of analytical chemistry that is concerned with questions such as "What makes this water smell bad"? "Is there gold in this rock sample"? "Is this sparkling stone a diamond or cubic zirconia"? "Is this plastic item made of polyvinyl chloride, polyethylene, or polycarbonate"? or "What is this white powder"?

Some methods for qualitative analysis are non-destructive. They provide information about what is in the sample without destroying the sample. These are often the best techniques to begin with, because the sample can be used for subsequent analyses. To identify what elements are present in a sample nondestructively, a qualitative elemental analysis method such as X-ray fluorescence spectroscopy (XRF) can be used. Modern XRF instruments, discussed in Chapter 8, can identify all elements from sodium to uranium, and some instruments can measure elements from beryllium to uranium. The sample is usually not harmed by XRF analysis. For example, XRF could easily distinguish a diamond from cubic zirconia. Diamond is a crystalline form of carbon; most XRF instruments would see no elemental signal from the carbon in a diamond but would see a strong signal from the element zirconium in cubic zirconia, a crystalline compound of zirconium and oxygen. Qualitative molecular analysis will tell us what molecules are present in a material. The nondestructive identification of molecular compounds present in a sample can often be accomplished by the use of nuclear magnetic resonance (NMR) spectroscopy, discussed in Chapter 5, or by infrared (IR) spectroscopy, discussed in Chapter 4. IR spectroscopy can provide information about organic functional groups present in samples, such as alcohols, ketones, carboxylic acids, amines, thioethers, and many others. If the sample is a pure compound such as acetylsalicylic acid (the active ingredient in aspirin), the IR spectrum may be able to identify the compound exactly, because the IR spectrum for a compound is unique, like a fingerprint. Qualitative identification of polymers for recycling can be done using IR spectroscopy, for example. NMR gives us detailed information about the types of protons, carbon, and other atoms in organic compounds and how the atoms are connected. NMR can provide the chemical structure of a compound without destroying it.

Many methods used for qualitative analysis are destructive; either the sample is consumed during the analysis or must be chemically altered in order to be analyzed. The most sensitive and comprehensive elemental analysis methods for inorganic analysis are inductively coupled plasma atomic emission spectrometry (ICP-OES or ICP-AES), discussed in Chapter 7 and ICP-MS, discussed in Chapter 9. These techniques can identify almost all the elements in the periodic table, even when only trace amounts are present, but often require that the sample be in the form of a solution. If the sample is a rock or a piece of glass or a piece of biological tissue, the sample usually must be dissolved in some way to provide a solution for analysis. The analyst can determine accurately what elements are present, but information about the oxidation states and molecules in the sample is lost in the sample preparation process. The advantage of ICP-OES and ICP-MS is that they are very sensitive; concentrations at or below 1 ppb of most elements can be detected using these methods.

If the sample is organic, that is, composed primarily of carbon and hydrogen, qualitative analysis can provide chemical and structural information to permit identification of the compound. Use of IR, NMR, and MS, combined with quantitative elemental analysis to accurately determine the percentage of carbon, hydrogen, oxygen, and other elements, is the usual process by which analytical chemists identify organic compounds. This approach is required to identify new compounds synthesized by pharmaceutical chemists, for example. In a simple example, elemental analysis of an unknown organic compound might provide an **empirical formula** of C_2H_5 . An empirical formula is the simplest whole number ratio of the atoms of each element present in a molecule. For any given compound, the empirical formula may or may not coincide with the **molecular formula**. A molecular formula contains the total number of atoms of each element in a single molecule of the compound. The results

from IR, NMR, and MS might lead the analytical chemist to the molecular formula C_4H_{10} , and would indicate which of the two different structures shown below our sample was.

$$\begin{array}{cccc} & & & H \\ | & & | \\ CH_3-CH_2-CH_2-CH_3 & & H_3C-C-CH_3 \\ & & | & \\ & & CH_3 \\ & & &$$

These two structures are two different compounds with the same molecular formula. They are called **isomers.** Elemental analysis cannot distinguish between these isomers, but NMR and MS usually can distinguish isomers. Another example of a more difficult qualitative analysis problem is the case of the simple sugar, erythrose. The empirical formula determined by elemental analysis is CH_2O . The molecular formula, $C_4H_8O_4$, and some of the structure can be obtained from IR, NMR, and MS, but we cannot tell from these techniques which of the two possible isomers shown in Figure 1.1 is our sample.

These two erythrose molecules are **chiral**, that is, they are nonsuperimposable mirrorimage isomers, called **enantiomers**. Imagine sliding the molecule on the left in the plane of the paper, through the "mirror plane" indicated by the arrow, over the molecule on the right. The OH groups will not be on top of each other. Imagine turning the left molecule in the plane of the paper upside down and then sliding it to the right; now the OH groups are lined up, but the CHO and CH₂OH groups are not. That is what is meant by nonsuperimposable. You can do whatever you like to the two molecules except remove them from the plane of paper; no matter how you move them, they will not be superimposable. They have the same molecular formula, C₄H₈O₄, the same IR spectrum, the same mass spectrum, and the same NMR spectrum, and many of the same physical properties such as boiling point and refractive index. Such chiral compounds can be distinguished from each other by interaction with something else that possesses chirality or by interaction with plane-polarized light. Chiral compounds will interact differently with other chiral molecules, and this interaction forms the basis of chiral chromatography. Chiral chromatography (Chapter 12) can be used to separate the two erythrose compounds shown. Chiral compounds also differ in their behavior toward plane-polarized light, and the technique of polarimetry can be used to distinguish them. One of the erythrose enantiomers rotates plane-polarized light to the right (clockwise); this compound is dextrorotatory, and is given the symbol (+) as part of its name. The other enantiomer rotates the plane of polarization to the left (counterclockwise); this compound is *levorotatory*, and is given the symbol (-) in its name. Such compounds are said to be optically active. Chiral compounds are very important because biochemical reactions are selective for only one of the two structures and only one of the two enantiomers is biologically active. Biochemists, pharmaceutical chemists, and medicinal chemists are very interested in the identification, synthesis, and separation of only the biologically active compound. The letters D and L in the name of the sugar refer to the position of the alcohol group on the carbon closest to the bottom primary alcohol. There is no relationship between the D and L configuration and the direction of rotation of plane polarized light. The simplest sugar, glyceraldehyde, has two enantiomers, one D and one L, but the D enantiomer of glyceraldehyde rotates light in the opposite direction from D-erythrose.

If organic compounds occur in mixtures, separation of the mixture often must be done before the individual components can be identified. Techniques such as gas chromatography, liquid chromatography, and capillary electrophoresis are often used to separate mixtures of organic compounds prior to identification of the components. These methods are discussed in Chapters 10-12.

Table 1.1 lists some common commercially available instrumental methods of analysis and summarizes their usefulness for qualitative elemental or molecular analysis. Appendix 1.A (book website) gives a very brief summary of the use of the methods. Analyte concentrations that can be determined by common methods of instrumental analysis are presented in

$$\begin{array}{cccc} & & & & & \\ & & & \downarrow & \\ & \downarrow & \\$$

FIGURE 1.1 Isomers of erythrose.

	Quali	tative	Quantitative		
Method	Elemental	Molecular	Elemental	Molecular	
Atomic absorption spectrometry	No	No	Yes	No	
Atomic emission spectrometry	Yes	No	Yes	No	
Capillary electrophoresis	Yes	Yes	Yes	Yes	
Electrochemistry	Yes	Yes	Yes	Yes	
Gas chromatography	No	Yes	No	Yes	
ICP-mass spectrometry	Yes	No	Yes	No	
Infrared spectroscopy	No	Yes	No	Yes	
Ion chromatography	Yes	Yes	Yes	Yes	
Liquid chromatography	No	Yes	No	Yes	
Mass spectrometry	Yes	Yes	Yes	Yes	
Nuclear magnetic resonance	No	Yes	No	Yes	
Raman spectroscopy	No	Yes	No	Yes	
Thermal analysis	No	Yes	No	Yes	
UV/VIS spectrophotometry	Yes	Yes	Yes	Yes	
UV absorption	No	Yes	No	Yes	
UV fluorescence	No	Yes	No	Yes	
X-ray absorption	Yes	No	Yes	No	
X-ray diffraction	No	Yes	No	Yes	
X-ray fluorescence	Yes	No	Yes	No	

Table 1.2. The concentration of analyte that can be determined in real samples will depend on the sample and on the instrument, but Table 1.2 gives some indication of the sensitivity and working range of methods.

1,2,1,2 QUANTITATIVE ANALYSIS

When qualitative analysis is completed, the next question is often "How much of each or any component is present"? or "Exactly how much gold is this rock"? or "How much of the organochlorine pesticide dieldrin is in this drinking water"? The determination of how much is quantitative analysis. Analytical chemists express *how much* in a variety of ways, but often in terms of *concentration*, the amount of the measured substance (analyte) in a given amount of sample. Commonly used concentration units include molarity (moles of substance per liter of solution), weight percent (grams of substance per gram of sample × 100 %), and units for trace levels of substances. One *part per million* (ppm) by mass is one microgram of analyte in a gram of sample, that is, 1×10^{-6} g analyte/g sample. One *part per billion* (ppb) by mass is one nanogram of analyte in a gram of sample or 1×10^{-9} g analyte/g sample. Concentration is an expression of the quantity of analyte in a given volume or mass of sample. For dilute aqueous solutions, one milliliter of solution has a mass of one gram (because the density of water is 1 g/mL), so solution concentrations are often expressed in terms of volume. A part per million of analyte in dilute aqueous solution is equal to one microgram per milliliter of solution (μ g/mL), for example.

For many elements, the technique known as inductively coupled plasma mass spectrometry (ICP-MS) can detect *parts per trillion* of the element, that is, picograms of element per gram of sample (1×10^{-12} g analyte/g sample). To give you a feeling for these quantities, a million seconds is ~12 days (11.57 days, to be exact). One part per million in units of seconds would be one second in 12 days. A part per billion in units of seconds would be 1 s in ~32 years, and one part per trillion is one second in 32,000 years. Today, lawmakers set environmental levels of allowed chemicals in air and water based on measurements of

TABLE 1.2 Analytical Concentration Ranges for Common Instrumental Methods

Technique	Destructive	Ultratrace <1 ppm	Trace 1ppm–0.1 %	Minor 0.1–10 %	Major >10 %
X-ray diffraction	No	No	No	Yes	Yes
Nuclear magnetic resonance	No	No	Yes	Yes	Yes
X-ray fluorescence	No	No	Yes	Yes	Yes
Infrared spectroscopy	No	No	Yes	Yes	Yes
Raman spectroscopy	No	No	Yes	Yes	Yes
UV/VIS spectrometry	No	No	Yes	Yes	Yes
Colorimetry	No	Yes	Yes	Yes	No
Molecular fluorescence Spectrometry	Maybe	Yes	Yes	Yes	Yes
Atomic absorption	Yes	Yes	Yes	Yes	No
Spectrometry Atomic emission	Yes	Yes	Yes	Yes	Yes
Spectrometry					
Atomic fluorescence	Yes	Yes	Yes	No	No
Spectrometry					
ICP-mass spectrometry	Yes	Yes	Yes	Yes	No
Organic mass spectrometry	Yes	Yes	Yes	Yes	Yes
GC-MS	Yes	Yes	Yes	Yes	Yes
LC-MS	Yes	Yes	Yes	Yes	Yes
Potentiometry	No	Yes	Yes	Yes	Yes
Voltammetry	No	Yes	Yes	Yes	Yes
Gas chromatography	May be	Yes	Yes	Yes	Yes
High performance	May be	Yes	Yes	Yes	Yes
Liquid chromatography					
Ion chromatography	May be	Yes	Yes	Yes	Yes
Capillary electrophoresis	No	Yes	Yes	Yes	Yes
Thermal analysis	May Be	No	No	Yes	Yes

Note: The destructive nature of the instrumental method is characterized. A sample may be destroyed by a nondestructive instrumental method, depending on the sample preparation required. The chromatographic techniques may be destructive or nondestructive, depending on the type of detector employed. The nondestructive detectors generally limit sensitivity to "trace". Molecular fluorescence is not destructive if the molecule is inherently fluorescent. It may be if the molecule requires derivatization. A method with "yes" for ultratrace and "no" for major concentrations reflects linear working range. Such methods can measure "majors" if the sample is diluted sufficiently.

compounds and elements at part per trillion levels because instrumental methods can detect part per trillion levels of analytes. It is the analytical chemist who is responsible for generating the data that these lawmakers rely on. A table of commonly encountered constants, multiplication factors, and their prefixes is found on the book website. The student should become familiar with these prefixes, since they will be used throughout the text.

The first quantitative analytical fields to be developed were for quantitative elemental analysis, which revealed how much of each element was present in a sample. These early techniques were not instrumental methods, for the most part, but relied on chemical reactions, physical separations, and weighing of products (gravimetry), titrations (titrimetry or volumetric analysis), or production of colored products with visual estimation of the amount of color produced (colorimetry). Using these methods, it was found, for example, that dry sodium chloride, NaCl, always contained 39.33 %Na and 60.67 %Cl. The atomic theory was founded on early quantitative results such as this, as were the concept of valence and the determination of atomic weights. Today, quantitative inorganic elemental analysis

is performed by atomic absorption spectrometry (AAS), atomic emission spectrometry of many sorts, inorganic mass spectrometry such as ICP-MS, XRF, ion chromatography, and other techniques discussed in detail in later chapters.

In a similar fashion, quantitative elemental analysis for carbon, hydrogen, nitrogen, and oxygen enabled the chemist to determine the empirical formulas of organic compounds. For any given compound, the empirical formula may or may not coincide with the molecular formula. A molecular formula contains the total number of atoms of each element in a single molecule of the compound. For example, ethylene and cyclohexane have the same empirical formula, CH₂, but molecular formulas of C_2H_4 and C_6H_{12} , respectively. The empirical formula of many sugars is CH_2O_6 , but the molecular formulas differ greatly. The molecular formula of glucose is $C_6H_{12}O_6$, fructose is $C_6H_{12}O_6$, erythrose is $C_4H_8O_4$, and glyceraldehyde is $C_3H_6O_3$. An example of a molecule whose empirical formula is the same as the molecular formula is tetrahydrofuran (THF), an important organic solvent. The molecular formula for THF is C_4H_8O ; there is only one oxygen atom, so there can be no smaller whole number ratio of the atoms. Therefore, C_4H_8O is also the empirical formula of THF.

Empirical formulas of organic compounds were derived mainly from combustion analysis, where the organic compound is heated in oxygen to convert all of the carbon to CO₂ and all of the hydrogen to H₂O. The CO₂ and H₂O were collected and weighed or the volume of the gas was determined by displacement of liquid in a measuring device. To distinguish between butane, C₄H₁₀, which contains 82.76 %C and 17.24 %H, and pentane, C₅H₁₂, which contains 83.33 %C and 16.66 %H required great skill using manual combustion analysis. Today, automated analyzers based on combustion are used for quantitative elemental analysis for C, H, N, O, S, and the halogens in organic compounds. These analyzers measure the evolved species by gas chromatography (GC), IR, or other techniques. These automated analyzers require only microgram amounts of sample and a few minutes to provide data and empirical formulas that used to take hours of skilled analytical work. Quantitative elemental analysis cannot distinguish between isomers. Glucose and fructose have the same molecular formula, but glucose is a sugar with an aldehyde group in its structure, while fructose is a sugar with a ketone group in its structure. They cannot be distinguished by elemental analysis, but are easily distinguished by their IR and NMR spectra.

Quantitative molecular analysis has become increasingly important as the fields of environmental science, polymer chemistry, biochemistry, pharmaceutical chemistry, natural products chemistry, and medicinal chemistry have grown. Techniques such as GC, liquid chromatography or high-performance liquid chromatography (LC, HPLC), capillary electrophoresis (CE), MS, fluorescence spectrometry, IR, and X-ray diffraction (XRD) are used to determine the amounts of specific compounds, either pure or in mixtures. These techniques have become highly automated and extremely sensitive, so that only micrograms or milligrams of sample are needed in most cases. The chromatography techniques, which can separate mixtures, have been "coupled" to techniques like MS, which can identify and quantitatively measure the components in a mixture. Such techniques, like GC-MS and LC-MS, are called hyphenated techniques. Many hyphenated instruments are commercially available. These types of instruments for use in the pharmaceutical industry have been designed to process samples in very large batches in a completely automated fashion. The instruments will analyze the samples, store the data in computer files, "pattern-match" the spectra to identify the compounds, and calculate the concentrations of the compounds in the samples.

Instrumental methods differ in their ability to do quantitative analysis; some methods are more *sensitive* than others. That is, some methods can detect smaller amounts of a given analyte than other methods. Some methods are useful for wide ranges of analyte concentrations; other methods have very limited ranges. We will discuss the reasons for this in the chapters on the individual techniques, but Table 1.2 shows the approximate useful concentration ranges for common instrumental techniques. Table 1.2 is meant to serve as a guide; the actual sensitivity and useful concentration range (also called the working range) of a technique for a specific analysis will depend on many factors.

1.2.2 DESIGNING THE ANALYTICAL METHOD

Once the problem has been defined, an analytical procedure, or method, must be designed to solve the problem. The analytical chemist may have to design the method to meet certain goals, such as achieving a specified accuracy and precision, using only a limited amount of sample, or performing the analysis within a given cost limit or "turnaround time". Turnaround time is the time elapsed from receipt of a sample in the lab to delivery of the results to the person who requested the analysis. This length of time may need to be very short for clinical chemistry laboratories providing support to hospital emergency rooms, for example. A common goal for modern analytical procedures is that they are "green chemistry" processes, that is, the solvents used are of low toxicity or biodegradable, that waste is minimized, and that chemicals used in the analysis are recycled when possible.

Designing a good analytical method requires knowing how to obtain a *representative sample* of the material to be analyzed, how to store or preserve the sample until analysis, and how to prepare the sample for analysis. The analyst must also know how to evaluate possible *interferences* and *errors* in the analysis and how to assess the accuracy and precision of the analysis.

There are many analytical procedures and methods that have been developed and published for a wide variety of analytes in many different matrices. These methods may be found in the chemical literature, in journals such as Analytical Chemistry, The Analyst, Analytical and Bioanalytical Chemistry (formerly Fresenius' Journal of Analytical Chemistry), Talanta, and in journals which focus on specific analytical techniques, such as Applied Spectroscopy, Journal of Separation Science (formerly Journal of High-Resolution Chromatography), Journal of the American Society for Mass Spectrometry, Thermochimica Acta, and many others. Compilations of "standard" methods or "official" methods have been published by government agencies such as the US Environmental Protection Agency (EPA) and private standards organizations such as the American Association of Official Analytical Chemists (AOAC), ASTM International (formerly the American Society for Testing and Materials)), and the American Public Health Association (APHA), among others. Similar organizations and official methods exist in many other countries. These standard methods are methods that have been tested by many laboratories and have been found to be reproducible, with known accuracy and precision. The bibliography lists several of these books on analytical methods. It is always a good idea to check the chemical literature first, so that you don't waste time designing a procedure that already exists.

If there are no methods available, then the analytical chemist must develop a method to perform the analysis. For very challenging problems, this may mean inventing entirely new analytical instruments or modifying existing instruments to handle the task.

The design of the method also requires the analyst to consider how the method will be shown to be accurate and precise (validation). This requires knowledge of how we assess accuracy and precision. The evaluation of accuracy, precision, error analysis, and similar data handling calculations involve mathematical probability and statistics. A brief introduction to these topics is found in Section 1.4. The analyst must evaluate interferences. Interference is anything that (1) gives a response other than the analyte itself or (2) that changes the response of the analyte. Interferences may be other compounds or elements present in the sample, or that form on degradation of the sample. Interfering compounds or elements may respond directly in the instrumental measurement to give a false analyte signal, or they may affect the response of the analyte indirectly by enhancing or suppressing the analyte signal. Examples will be given in the chapters for each instrumental technique. The analyst must demonstrate that the method is reliable and *robust*.

There are some fundamental features that should be a part of every good analytical method. The method should require that a **blank** be prepared and analyzed. A blank is used to ascertain and correct for certain interferences in the analysis. In many cases, more than one type of blank is needed. One type of blank solution may be just the pure solvent used for the sample solutions. This will ensure that no analyte is present in the solvent and allows the analyst to set the baseline or the "zero point" in many analyses. A **reagent blank** may

be needed; this blank contains all of the reagents used to prepare the sample and is carried through the sample preparation steps but does not contain the sample itself. Again, this assures the analyst that the sample preparation does not contribute analyte to the final reported value of analyte in the sample. Sometimes, a **matrix blank** is needed; this is a blank that is similar in chemical composition to the sample but without the analyte. It may be necessary to use such a blank to correct for an overlapping spectral line from the matrix in atomic emission spectrometry, for example.

All instrumental analytical methods except coulometry (Chapter 14) require calibration standards, which have known concentrations of the analyte present in them. These calibration standards are used to establish the relationship between the analytical signal being measured by the instrument and the concentration of the analyte. Once this relationship is established, unknown samples can be measured and the analyte concentrations determined. Analytical methods should require some sort of reference standard. This is also a standard of known composition with a known concentration of the analyte. This reference standard is not one of the calibration standards and should be from a different lot of material than the calibration standards. It is run as a sample to confirm that the calibration is correct and to assess the accuracy and precision of the analysis. Reference standard materials are available from government and private sources in many countries. Examples of government sources are the National Institute of Standards and Technology (NIST) in the US, the National Research Council of Canada (NRCC), and the LGC (formerly Laboratory of the Government Chemist) in the UK.

1.2.3 SAMPLING

The most important single step in an analysis is collecting the sample of the material to be analyzed. Real materials are usually not homogeneous, so the sample must be chosen carefully to be **representative** of the real material. A representative sample is one that reflects the true value and distribution of the analyte in the original material. If the sample is not taken properly, no matter how excellent the analytical method or how expert the analyst, the result obtained will not provide a reliable characterization of the material. Other scientists, law enforcement officials, and medical professionals often collect samples for analysis, sometimes with no training in how to take a proper sample. The analytical chemist ideally would be a part of the team that discusses collection of samples before they are taken, but in reality, samples often "show up" in the lab. It is important that the analyst talks with the sample collector before doing any analyses; if the sample has been contaminated or improperly stored, the analysis will be not only a waste of time, but can also lead to erroneous conclusions. In clinical chemistry analysis, this could lead to a misdiagnosis of a disease condition; in forensic analysis, this could lead to a serious miscarriage of justice.

The amount of sample taken must be sufficient for all analyses to be carried out in duplicate or triplicate, if possible. Of course, if only a small quantity of sample is available, as may be the case for forensic samples from a crime scene or rocks brought back from the moon, the analyst must do the best job possible with what is provided.

A good example of the problems encountered in sampling real materials is collecting a sample of a metal or metal alloy. When a molten metal solidifies, the first portion of solid to form tends to be the most pure (remember freezing point depression from your general chemistry class?). The last portion to solidify is the most impure and is generally located in the center or *core* of the solidified metal. It is important to bear this in mind when sampling solid metals. A sample is often ground from a representative cross-section of the solid, or a hole is drilled through a suitable location and the drillings mixed and used as the sample.

Samples have to be collected using some type of collection tool and put into some type of container. These tools and containers can often contaminate the sample. For example, stainless steel needles can add traces of metals to blood or serum samples. Metal spatulas, scissors and drill bits, glass pipettes, filter paper, and plastic and rubber tubing can add unwanted inorganic and organic contaminants to samples. To avoid iron, nickel, and chromium contamination from steel, some implements like tongs and tweezers can be purchased with platinum or gold tips.




FIGURE 1.2 The cone and quarter method of sampling bulk materials.

The discussion of sampling which follows refers to the traditional process of collecting a sample at one location (often called "collection in the field") and transporting the sample to the laboratory at a different location. Today, it is often possible to analyze samples *in situ* or during the production of the material (on-line or process analysis) with suitable instrumental probes, completely eliminating the need for "collecting" a sample. Examples of *in situ* and on-line analysis and field portable instruments will be discussed in later chapters.

The process of sampling requires several steps, especially when sampling bulk materials such as coal, metal ore, soil, grain, and tank cars of oil or chemicals. First, a *gross representative sample* is gathered from the *lot*. The lot is the total amount of material available. Portions of the gross sample should be taken from various locations within the lot, to ensure that the gross sample is representative. The *cone and quarter* method may be used to collect a gross sample of solid materials. The sample is made into a circular pile and mixed well. It is then separated into quadrants. A second pile is made up of two opposite quadrants, and the remainder of the first pile discarded. This process is shown in Figure 1.2. This process can be repeated until a sample of a suitable size for analysis is obtained. This sample can still be very large. Ferroalloys, for example, are highly segregated (i.e., inhomogeneous) materials; it is not uncommon for the amount required for a representative sample of alloy in pieces about 2 inches in diameter to be one ton (0.9 Mg) of material from the lot of alloy.

A computer program that generates random numbers can choose the sampling locations and is very useful for environmental and agricultural sampling. If the lot is a field of corn, for example, the field can be divided into a grid, with each grid division given a number. The computer program can pick the random grid divisions to be sampled. Then, a smaller, homogeneous laboratory sample is prepared from the gross composite sample. If the sample is segregated (i.e., highly inhomogeneous), the representative sample must be a composite sample that reflects each region and its relative amount. This is often not known, resulting in the requirement for very large samples. The smaller laboratory sample may be obtained by several methods, but must be representative of the lot and large enough to provide sufficient material for all the necessary analyses. After the laboratory sample is selected, it is usually split into even smaller test portions. Multiple small test portions of the laboratory sample are often taken for replicate analyses and for analysis by more than one technique. The term **aliquot** is used to refer to a quantitative amount of a *dissolved* test portion; for example, a 0.100 g test portion of sodium chloride may be dissolved in water in a volumetric flask to form 100.0 mL of test solution. Three 10.0 mL aliquots may be taken with a volumetric pipette for triplicate analysis for chloride using an ion selective electrode, for example.

As the total amount of the sample is reduced, it should be broken down to successively smaller pieces by grinding, milling, chopping, or cutting. The one-ton sample of ferroal-loy, for example, must be crushed, ground, and sieved many times. During the process, the sample size is reduced using a sample splitter called a riffle. After all this and then a final drying step, a one-lb (454 g) sample remains. The sample must be mixed well during this entire process to ensure that it remains representative of the original. The grinding equipment used must not contaminate the sample. For example, boron carbide and tungsten carbide are often used in grinding samples because they are very hard materials, harder than most samples. They can contribute boron or tungsten to the ground sample, so they would not be used if boron or tungsten must be measured at low concentrations. Zirconium oxide ball mills can contribute Zr and Hf to a sample. Stainless steel grinders are a source of Fe, Cr,




FIGURE 1.3 Sampling of a segregated material with a problematic component like gold. (Extracted, with permission, from Dulski, T.R., ASTM International, 100 Barr Harbor Drive, West Conshohocken, PA 19428.)

and Ni. Some cutting devices use organic fluids as lubricants; these must be removed from the sample before analysis.

It is also possible for the grinding or milling step to cause erroneously low results for some analytes. Malleable metals like gold may adhere to the grinding or milling surface and be removed from the sample in the process, leading to erroneously low results. An example of sampling a segregated material with a problematic component like gold is illustrated in Figure 1.3. The rectangular piece at the top is a hypothetical piece of gold-bearing quartz. The gold is represented as the dark flecks. You can see that the gold appears in bands within the quartz, separated by bands of pure quartz (the white area). If the rock is crushed to Size I, the gold particles have not been liberated from the quartz; some pieces have gold flecks and many large pieces are pure quartz. At this size, it is difficult to remove a sample of the rock pieces and expect it to be representative. If the rock is crushed to a smaller size, Size II, it is evident that a representative small sample can be obtained. If the rock is crushed to Size III, the gold particles are freed from the quartz matrix. If this sample could be mixed perfectly, a smaller sample could be taken to represent the whole than the sample needed at Size II. (Why would this be desirable? The smaller the analytical sample, the less gold is used up by analysis. This is an important consideration with valuable analytes and valuable samples.) But the gold particles and the quartz particles have different densities, different shapes, and will be difficult to mix well. As mentioned, gold is soft and malleable. If it is broken out of the quartz, it may become embedded in the grinder or smeared onto surfaces in the grinding equipment, so some gold may actually be lost from the sample particles ground to Size III. Size II will give a more representative sample than either of the other sizes.

Sampling procedures for industrial materials, environmental samples, and biological samples are often agreed upon, or *standardized*, by industry, government, and professional societies. Standard sampling procedures help to ensure that the samples analyzed are representative and are not contaminated or changed during the sampling process. Standard sampling procedures for many materials can be found in the Annual Book of ASTM Standards, for example. Sampling procedures for soil, water, and air are established by the US EPA in the United States, and similar government organizations in other countries. Procedures for sampling of water and wastewater can be found in Standards Methods for the Analysis of Water and Wastewater; the AOAC publishes procedures for food products. The bibliography provides some examples of these publications. A good analytical chemist will consult the literature before sampling an unfamiliar material. Some general guidelines for sampling different classes of materials are discussed here.

1.2.3.1 GAS SAMPLES

Gas samples are generally considered homogeneous, but gas mixtures may separate into layers of differing density. Samples that have been collected and allowed to settle will need to be stirred before a portion is taken for analysis. Gas samples can be taken at a single point in time (called a **grab** sample) or can be collected over a period of time or from different locations to provide an *average* or **composite** sample. Gas samples can be collected using gas-tight syringes, balloons, plastic bags, or containers made of metal or glass that can be evacuated. Sampling of toxic, flammable, or corrosive gases should be done with great care using appropriate safety equipment.

The containers used to collect the samples must not contaminate the sample with analyte. Plastic bags and balloons may leach volatile organic compounds into the gas sample, while glass may adsorb components of the sample onto the surface of the glass.

Certain components of gas samples, such as organic vapors in air, may be collected by pulling the air through activated charcoal. The organic gases are adsorbed onto the charcoal, while the majority of the air (oxygen, nitrogen, etc.) passes through. This has the advantage of *pre-concentrating* the analytes of interest and reducing the physical size of the sample. Many liters of air can be pulled through an activated charcoal bed that is no bigger than a ballpoint pen. It is much easier to transport the analytes trapped on the charcoal to the laboratory than to transport hundreds of liters of air. The process of trapping an analyte out of the gas phase is called "scrubbing". Scrubbing a gas sample can also be done by bubbling the gas through a liquid that will absorb the analytes of interest.

Gas samples may contain particles of solid material that need to be removed by filtration. The filter material must be chosen so that it does not adsorb analytes or add contaminants to the gas. Filters are available which will remove particles as small as $0.2~\mu m$ in diameter from a gas stream.

1.2.3.2 LIOUID SAMPLES

Liquid samples can also be collected as grab samples or as composite samples. Sampling liquids can be quite difficult; it is not always as straightforward as "pouring some" out of a bottle or dipping a bucket into a fluid. Only a few comments with respect to general sampling of liquids can be made here. It is usual to stir liquid samples adequately to obtain a representative sample; however, there may be occasions when stirring is not desired. If the analyst is only interested in identifying an oily layer floating on water, stirring the sample is not needed; the oily layer may be pulled off with a pipette or an eyedropper, for example. Samples must be collected at locations remote from sources of contamination if a representative sample is desired. For example, if a sample of "normal" river water is desired, the sample should be collected away from riverbanks, floating froth, oil, and discharges from industrial and municipal waste treatment sites. Sampling of rivers, lakes, and similar bodies of water may require samples from different depths or different distances from shore. Such samples may be analyzed individually or blended to obtain an average composition.

Liquid samples may contain particles of solid material that need to be removed by filtration or centrifugation. The filter material must be chosen so that it does not adsorb analytes or contaminate the liquid. Some samples that are mostly liquid contain suspended solid material; orange juice and liquid antacids are examples. In these types of samples, the liquid and its associated solids may need to be sampled for analysis without removing the solids. It may be difficult to obtain a representative sample from these suspensions; a standard sampling procedure is needed to ensure that results can be compared from one day to the next. Liquid samples may consist of more than one layer because they contain two or more **immiscible** liquids. Examples include samples of oil and water from an oil spill at sea, oil and vinegar salad dressing, or cream at the top of a bottle of milk. The layers may need to be *emulsified* to provide a representative sample, but there may be reasons to sample each layer separately.

Sampling of hot molten materials such as metals, alloys, and glasses is a form of liquid sampling, but one requiring very specialized equipment and techniques which will not be covered here.

1.2.3.3 SOLID SAMPLES

Solid samples are often the most difficult to sample because they are usually less homogeneous than gases or liquids. Large amounts of solid sample cannot be conveniently "stirred up". Moreover, unlike the situation with fluids, there are no diffusion or convection currents in solids to ensure mixing. Solids must often be ground or drilled or crushed into smaller particles to homogenize the sample. There are many types of manual and automated grinders and crushers available; the choice depends on the hardness of the material to be ground. Soft materials also pose a challenge in grinding because they often just deform instead of being reduced in size. Polymer pellets may be ground in an electric coffee grinder with a small amount of liquid nitrogen added to the grinder (called cryogrinding). The liquid nitrogen freezes the polymer, making the pellets brittle and capable of being easily powdered. Other soft solids such as foods can be handled the same way. Commercial cryomills that prevent the user from coming into contact with liquid nitrogen are available. Many solid materials must be oven-dried before sampling to remove adsorbed water in order to obtain a representative sample. There are numerous published standard methods for sampling solid materials such as cement, textiles, food, soil, ceramics, and other materials. Examples of the wide variety of analytical pulverizing, grinding, and blending equipment available can be found at the following websites: SpexCertiprep (www.spexcsp.com), Retsch (www.retsch.com) and Netzsch (www.netzsch.com), among others.

1.2.4 STORAGE OF SAMPLES

When samples cannot be analyzed immediately, they must be stored. The composition of a sample may change during storage because of reactions with air, light, or interaction with the container material. The container used for collection and storage of the sample and the storage conditions must be chosen to minimize changes in the sample.

Plastic containers may leach organic components such as plasticizers and monomers into a sample. Plastic containers may also introduce trace metal impurities such as Cu, Mn, or Pt from the catalysts used to make the polymer or elements such as Si, Ti, Sb, Br, and P from inorganic fillers and flame-retardants. Glass surfaces both adsorb and release trace levels of ionic species, which can dramatically change the trace element and trace ion concentrations in solutions. It has been observed that trace metals will "plate out" of solution along strain lines in glass. Such strain lines are not reproducible from one container to another; therefore, the loss of trace metals cannot be estimated accurately for one container by measuring the loss in a similar but different container. All containers require appropriate cleaning before use. Containers for organic samples are usually washed in solvent, while containers for samples for trace metals analysis are soaked in acid and then in deionized water.

Precautions such as freezing biological and environmental samples or displacing the air in a container by an inert gas will often extend the storage life of a sample. Samples should not be stored any longer than is absolutely necessary prior to analysis and should not be stored under conditions of high heat or high humidity. Some samples require storage in the dark to avoid photolytic (light-induced) changes in composition; water samples to be analyzed for silver are a good example. Such samples must be stored in dark plastic bottles to avoid the photolytic formation of colloidal silver, which will precipitate out of the sample. Many samples for environmental analysis require the addition of preservatives or adjustment of pH to prevent the sample from deteriorating. Water samples for trace metals determinations must be acidified with high purity nitric acid to keep the trace metals in solution, for example. Blood samples often require collection in tubes containing an anticoagulant to keep the blood sample fluid, but the anticoagulant must not interfere in the analysis. For example, a sample collected to measure a patient's sodium level cannot be collected in a tube that contains the sodium salt of ethylenediaminetetraacetic acid (EDTA) as the anticoagulant. Other biological samples may need to be collected in sterile containers.

Sample containers must be labeled accurately and in such a way that the label does not deteriorate on storage; do not use water-soluble marking pen on samples to be put in a

freezer, for example. The label should clearly identify the sample and any hazards associated with the sample. Many analytical laboratories have computer-based sample tracking systems that generate adhesive barcoded labels for samples, exactly like the barcodes used on retail items in stores. These computer-based systems, like Laboratory Information Management Systems (LIMS), catalog and track not only the samples but also the analytical data generated on the samples.

As a student, you should get into the habit of labeling all your containers in the laboratory with your name, date, and the contents. There is nothing worse than finding four beakers of colorless liquid on the lab bench and not knowing which one is yours or what is in the other beakers! That situation would be a serious safety violation in an industrial laboratory. Academic labs in the US are now required to follow the same safety regulations followed in industry and something as simple as beakers with "stuff" in them but no proper labels can result in large monetary fines for your school. The cost of chemical waste disposal is very high and it is not legal to dispose of unidentified chemicals, so unlabeled containers are a very expensive problem. The material must be analyzed to identify it just so that it can be disposed of properly.

1.3 SAMPLE PREPARATION

The aim of all sample preparation is to provide the analyte of interest in the physical form required by the instrument, free of interfering substances, and in the concentration range required by the instrument. For many instruments, a solution of analyte in organic solvent or water is required.

If the physical form of the sample is different from the physical form required by the analytical instrument, sample preparation is required. Samples may need to be dissolved to form a solution or pressed into pellets or cast into thin films or cut and polished smooth. The type of sample preparation needed depends on the nature of the sample, the analytical technique chosen, the analyte to be measured, and the problem to be solved. Most samples are not homogeneous. Many samples contain components that interfere with the determination of the analyte. A wide variety of approaches to sample preparation are available to deal with these problems in real samples. Only a brief overview of some of the more common sample preparation techniques is presented. More details are found in the chapters on each instrumental method.

Note: None of the sample preparation methods described here should be attempted without approval, written instructions, and close supervision by your professor or laboratory instructor. The methods described present many potential hazards. Many methods use concentrated acids, flammable solvents, and/or high temperatures and high pressures. Reactions can generate harmful gases. The potential for "runaway reactions" and even explosions exists with preparation of real samples. Sample preparation should be performed in a laboratory fume hood for safety. Goggles, lab coats or aprons, closed-toe shoes, and gloves resistant to the chemicals in use should be worn at all times in the laboratory.

1.3.1 ACID DISSOLUTION AND DIGESTION

Metals, alloys, ores, geological samples, ceramics, and glass react with concentrated acids and this approach is commonly used for dissolving such samples. Organic materials can be decomposed (digested or "wet ashed") using concentrated acids to remove the carbonaceous material and solubilize the trace elements in samples such as biological tissues, foods, and plastics. A sample is generally weighed into an open beaker, concentrated acid is added, and the beaker heated on a hot plate until the solid material dissolves. Dissolution often is much faster if the sample can be heated at pressures greater than atmospheric pressure. The boiling point of the solvent is raised at elevated pressure in a closed system, allowing the sample and solvent to be heated to higher temperatures than can be attained at atmospheric pressure. This can be done in a sealed vessel, which also has the advantage of not allowing

volatile elements to escape from the sample. Special stainless steel high-pressure vessels, called "bombs", are available for acid dissolution and for the combustion of organic samples under oxygen. While these vessels do speed up the dissolution, they operate at pressures of hundreds of atmospheres and can be very dangerous if not operated properly. Another sealed vessel digestion technique uses microwave digestion. This technique uses sealed sample vessels made of polymer, which are heated in a specially designed laboratory microwave oven. (NEVER use a kitchen-type microwave oven for sample preparations. Samples may boil over or explode. The electronics in kitchen-type units are not protected from corrosive fumes, arcing can occur, and the microwave source, the magnetron, can easily overheat and burn out.) The sealed vessel microwave digestion approach keeps volatile elements in solution, prevents external contaminants from falling into the sample, and is much faster than digestion on a hot plate in an open beaker. Microwave energy efficiently heats solutions of polar molecules (such as water), ions (aqueous mineral acids) and samples that contain polar molecules and/or ions. In addition, the sealed vessel results in increased pressure and increased boiling point. Commercial analytical microwave digestion systems for sealed vessel digestions are shown in Figure 1.4.

The acids commonly used to dissolve or digest samples are hydrochloric acid (HCl), nitric acid (HNO₃), and sulfuric acid (H₂SO₄). These acids may be used alone or in combination. The choice of acid or acid-mix depends on the sample to be dissolved and the analytes to be measured. The purity of the acid must be chosen to match the level of analyte to be determined. Very high-purity acids for work at ppb or lower levels of elements are commercially available, but are much more expensive than standard reagent-grade acid. For special applications, perchloric acid (HClO₄) or hydrofluoric acid (HF) may be required. A student should never use HClO₄ or HF without specific training from an experienced analytical chemist and only then under close supervision. While a mixture of HNO₃ and HClO₄ is extremely efficient for wet ashing organic materials, HClO₄ presents a very serious explosion hazard. Specially designed fume hoods are required to prevent HClO₄ vapors from forming explosive metal perchlorate salts in the hood ducts, and reactions of hot HClO₄ with organic compounds can result in violent explosive decompositions. A blast shield should be used and the organic sample must first be heated with HNO₃ alone to destroy easily oxidized material before the HClO₄ is added. Concentrated HF is used for dissolving silica-based glass and many refractory metals such as tungsten, but it is extremely dangerous to work with. It causes severe and extremely painful deep tissue burns that do not hurt immediately upon exposure. Delay in treatment for HF burns can result in serious medical problems and even death from contact with relatively small amounts of acid.

HCl is the most commonly used non-oxidizing acid for dissolving metals, alloys, and many inorganic materials. HCl dissolves many materials by forming stable chloride complexes with the dissolving cations. There are two major limitations to the universal use of HCl for dissolution. Some elements may be lost as volatile chlorides; examples of volatile chlorides include arsenic, antimony, selenium, and germanium. Some chlorides are not soluble in water; the most common insoluble chloride is silver chloride, but mercurous chloride, cuprous chloride, BiOCl, and AuCl₃ are not soluble, while PbCl₂ and TlCl are only partially soluble. A 3:1 mixture of HCl and HNO₃ is called *aqua regia*, and has the ability to dissolve gold, platinum, and palladium. The mixture is also very useful for stainless steels and many specialty alloys.

 HNO_3 is an oxidizing acid; it has the ability to convert the solutes to higher oxidation states. It can be used alone for dissolving a number of elements, including nickel, copper, silver, and zinc. The problem with the use of HNO_3 by itself is that it often forms an insoluble oxide layer on the surface of the sample that prevents continued dissolution. For this reason, it is often used in combination with HCl, H_2SO_4 , or HF. A mixture of HNO_3 and H_2SO_4 or HNO_3 and $HClO_4$ can be used to destroy the organic material in an organic sample, by converting the carbon and hydrogen to CO_2 and H_2O when the sample is heated in the acid mixture. The trace metals in the sample are left in solution. H_2SO_4 is a strong oxidizing acid and is very useful in the digestion of organic samples. Its main drawback is that it forms a number of insoluble or sparingly soluble sulfate salts.



(a)



(b)

FIGURE 1.4 (a) and **(b)** Commercial analytical microwave digestion systems for sealed vessel digestions. (Courtesy of CEM Corporation, Matthews, NC [www.cem.com].)

TABLE 1.3 Common Acid Dissolutions of Metals, Alloys, and Materials for Inorganic Compositional Analysis

	Total Volume of	
Material ^a	Reagent (mL)	Reagent (vol:vol)
Elements		
Copper metal	20	1:1 HNO ₃ /H ₂ O
Gold metal	30	3:1 HCI/HNO ₃
Iron metal	20	1:1 HCI/H ₂ O
Titanium metal	20	H_2SO_4 , 3–5 drops HNO_3
Zinc metal	20	HCI
Zirconium metal	15	HF
Alloys		
Copper alloys	30	1:1 HNO ₃ /H ₂ O
Low alloy steels	20	3:1 HCI/HNO ₃
Stainless steels	30	1:1 HNO ₃ /HCl
Titanium alloys	100	1:1 HCI/ H_2O , 3–5 drops HNO ₃
Zinc alloys	30	1:1 HCI/H ₂ O, dropwise HNO ₃
Zirconium alloys	40	1:1 H_2SO_4/H_2O , 2 mL HF dropwise
Other materials		
Borosilicate glass	12	10 mL HF + 2 mL 1:1 H_2SO_4/H_2O
Dolomite	40	1:1 HCI/H ₂ O
Gypsum	50	1:1 HCI/H ₂ O
Portland cement	20	HCl + 3 g NH ₄ Cl
Silicate minerals	30	$10 \mathrm{mL} \mathrm{HF} + 20 \mathrm{mL} \mathrm{HNO}_3$
Titanium dioxide	15	HF
Zinc oxide	15	1:1 HCI/H ₂ O

Source: Extracted, with permission, from Dulski, T.R. Copyright ASTM International, 100 Barr Harbor Drive, West Conshohocken, PA 19428.

Note: "Dropwise" means add drop-by-drop until dissolution is complete.

HF is a non-oxidizing, complexing acid like HCl. Its most important attribute is that it dissolves silica-based substances like glass and many minerals. All or most of the silicon is volatized on heating with sufficient HF. Glass beakers and flasks cannot be used to hold or store even dilute HF. Teflon or other polymer labware and bottles are required. Commercial "heatable" Teflon beakers with graphite bottoms are available for use on hot plates. HF is used in acid mixtures to dissolve many refractory elements and minerals by forming fluoride complexes; such elements include tungsten, titanium, niobium and tantalum. Some elements can be lost as volatile fluorides (e.g., Si, B, As, Ge, and Se). There are a number of insoluble fluoride compounds, including most of the alkaline earth elements (Ca, Mg, Ba, and Sr) and the rare earth elements (lanthanides). Table 1.3 gives examples of some typical acid digestions.

Some bases, such as sodium hydroxide and tetramethylammonium hydroxide, are used for sample dissolution, as are some reagents that are not acids or bases, like hydrogen peroxide. The chemical literature contains sample dissolution procedures for virtually every type of material known and should be consulted. For elements and inorganic compounds, the CRC Handbook of Chemistry and Physics gives guidelines for dissolution in the tables of physical properties of inorganic compounds.

1.3.2 FUSIONS

Heating a finely powdered solid sample with a finely powdered salt at high temperatures until the mixture melts is called a fusion or molten salt fusion. The reacted and cooled melt

^a 1 g test portion is used; warm to complete reaction.

is leached with water or dilute acid to dissolve the analytes for determination of elements by atomic spectroscopy or ICP-MS. Often, the molten fusion mixture is poured into a flatbottomed mold and allowed to cool. The resulting glassy disk is used for quantitative XRF measurements. Molten salt fusions are useful for the dissolution of silica-containing minerals, glass, ceramics, ores, human bone, and many difficultly soluble materials like carbides and borides. The salts used (called "fluxes") include sodium carbonate (Na₂CO₃), borax (sodium tetraborate, Na₂[B₄O₅(OH)₄]·8H₂O), lithium metaborate (LiBO₂), and sodium peroxide (Na₂O₂). The fusions can be carried out over a burner or in a muffle furnace in crucibles of the appropriate material. Depending on the flux used and the analytes to be measured, crucibles may be made of platinum, nickel, zirconium, porcelain, quartz, or glassy carbon. Automated "fluxers" or fusion machines, either gas or electric, are available that will fuse multiple samples at once and pour the melts into XRF molds or into beakers, for laboratories that perform large numbers of fusions. The website at xrfscientific.com has videos of fusions, both electric and gas automated fusion machines and other useful information on sample preparation. Figure 1.5(a) shows typical platinum crucibles and molds, along with cooled glassy disks such as would be used for XRF analyses. Figure 1.5(b) shows a commercial gas fusion machine automatically pouring the molten samples into platinum molds.





FIGURE 1.5 (a) Platinum crucibles and molds used for fusion, along with some finished glassy sample disks, used for XRF analyses. (b) An automated fusion machine pouring multiple molten samples into platinum molds. (Courtesy of XRF Scientific, Perth, Australia, www.xrfscientific.com. Used with permission.)

TABLE 1.4 Molten Salt Fusions of Materials

Material ^a	Dissolution Procedure
Bauxite	2 g Na ₂ CO ₃ ; Pt c&1
Corundum	3 g Na ₂ CO ₃ + 1 g H ₃ BO ₃ ; Pt c&1
Iron Ores	$5 \text{ g Na}_2\text{O}_2 + 5 \text{ g Na}_2\text{CO}_3$; Zr c&1
Niobium alloys	10 g K ₂ S ₂ O ₇ ; SiO2;c&l
Silicate minerals	10 g 1:1 Na ₂ CO ₃ :Na ₂ B ₄ O ₇ ; Pt c&
Tin ores	10 g $Na_2O_2 + 5$ g $NaOH$; Zr c&1
Titanium ores	7 g NaOH + 3 g Na ₂ O ₂ ; Zr c&1
Tungsten ores	8 g 1:1 Na ₂ CO ₂ /K ₂ CO ₂ ; Pt c&1

Source: Extracted from Dulski, T.R. A Manual for the Chemical Analysis of Metals, ASTM International, West Conshohocken, PA, 1996. With permission. Copyright 1996 ASTM International.

Note: c&1 = crucible and lid.
a 1 g test portion is used.

The drawback of fusion is that the salts used as fluxes can introduce many trace element contaminants into the sample, the crucible material itself may contaminate the sample, and the elements present in the flux cannot be analytes in the sample. Fusion cannot be used for boron determinations if the flux is borax or lithium metaborate, for example. Platinum crucibles cannot be used if trace levels of platinum catalyst are to be determined. Table 1.4 gives examples of typical fusions employed for materials.

1.3.3 DRY ASHING AND COMBUSTION

To analyze organic compounds or substances for the inorganic elements present, it is often necessary to remove the organic material. Wet ashing with concentrated acids is one approach. The other approach is "dry ashing", that is, ignition of the organic material in air or oxygen. The organic components react to form gaseous carbon dioxide and water vapor, leaving the inorganic components behind as solid oxides. Ashing is often done in a crucible or evaporating dish of platinum or fused silica in a muffle furnace. Volatile elements will be lost even at relatively low temperatures; dry ashing cannot be used for the determination of mercury, arsenic, cadmium, and a number of other metals of environmental and biological interest for this reason. Oxygen bomb combustions can be performed in a high-pressure steel vessel very similar to a bomb calorimeter. One gram or less of organic material is ignited electrically in a pure oxygen atmosphere with a small amount of absorbing solution such as water or dilute acid. The organic components form carbon dioxide and water and the elements of interest dissolve in the absorbing solution. Combustion in oxygen at atmospheric pressure can be done in a glass apparatus called a Schöniger flask. The limitation to this technique is sample size; no more than 10 mg of sample can be burned. However, the technique is used to obtain aqueous solutions of sulfur, phosphorus, and the halogens from organic compounds containing these heteroatoms. These elements can then be determined by ion selective potentiometry, ion chromatography, or other methods.

1.3.4 EXTRACTION

The sample preparation techniques previously discussed are used for inorganic samples or for the determination of inorganic components in organic materials by removing the organic matrix. Obviously, they cannot be used to determine organic analytes. The most common approach for organic analytes is to extract the analytes out of the sample matrix using a

suitable solvent. Solvents are chosen with the polarity of the analyte in mind, since "like dissolves like". That is, polar solvents dissolve polar compounds, while nonpolar solvents dissolve nonpolar compounds. Common extraction solvents include hexane, methylene chloride, methyl isobutyl ketone (MIBK), and xylene.

1.3.4.1 SOLVENT EXTRACTION

Solvent extraction is based on preferential solubility of an analyte in one of two immiscible phases. There are two common situations that are encountered in analysis: extraction of an organic analyte from a solid phase, such as soil, into an organic solvent for subsequent analysis, and extraction of an analyte from one liquid phase into a second immiscible liquid phase, such as extraction of polychlorinated biphenyls from water into an organic solvent for subsequent analysis.

Liquid-liquid extraction is similar to what happens when you shake oil and vinegar together for salad dressing. If you pour the oil and vinegar into a bottle carefully, you will have two separate layers because the oil and vinegar are not soluble in each other (they are *immiscible*). You shake the bottle of oil and vinegar vigorously and the "liquid" gets cloudy and you no longer see the two separate phases. On standing, the two immiscible phases separate again. Our two immiscible solvents will be called solvent 1 and solvent 2. The analyte, which is a solute in solvent 2, will distribute itself between the two phases on vigorous shaking. After allowing the phases to separate, the ratio of the concentration of analyte in the two phases is approximately a constant, K_D :

(1.1)
$$K_{\rm D} = \frac{[A]_1}{[A]_2}$$

 $K_{\rm D}$ is called the distribution coefficient and the concentrations of A, the analyte, are shown in solvent 1 and solvent 2. A large value of $K_{\rm D}$ means that the analyte will be more soluble in solvent 1 than in solvent 2. If the distribution coefficient is large enough, most of the analyte can be extracted quantitatively out of solvent 2 into solvent 1. In manual solvent extraction, the liquid containing the analyte and the extracting solvent are placed into a separatory funnel, shaken, and the desired liquid phase drawn off into a separate container. The advantages of solvent extraction are to remove the analyte from a more complex matrix, to extract the analyte into a solvent more compatible with the analytical instrument to be used, and to preconcentrate the analyte. For example, organic analytes can be extracted from water using solvents such as hexane. Typically, 1 L of water is extracted with 10–50 mL of hexane. Not only is the analyte extracted, but it is also now more concentrated in the hexane than it was in the water.

The analyte % extracted from solvent 2 into solvent 1 can be expressed as:

(1.2)
$$\%E = \frac{[A]_1 V_1}{[A]_2 V_2 + [A]_1 V_1} \times 100$$

where %E is the percent of analyte extracted into solvent 1, the concentration of analyte in each solvent is expressed in molarity; V_1 and V_2 are the volumes of solvents 1 and 2, respectively. The percent extracted is also related to K_D :

(1.3)
$$\%E = \frac{100K_{\rm D}}{K_{\rm D} + (V_2 / V_1)}$$

The percent extracted can be increased by increasing the volume of solvent 1, but it is more common to use a relatively small volume of extracting solvent and repeat the extraction more than once. The multiple volumes of solvent 1 are combined for analysis. Multiple small extractions are more efficient than one large extraction.

Liquid-liquid extraction is used extensively in environmental analysis to extract and concentrate organic compounds from aqueous samples. Examples include the extraction of pesticides, PCBs, and petroleum hydrocarbons from water samples. Extraction is also used in the determination of fat in milk. Liquid-liquid extraction can be used to separate organometallic complexes from the matrix in clinical chemistry samples such as urine. For example, heavy metals in urine can be extracted as organometallic complexes for determination of the metals by flame AAS. The chelating agent and a solvent such as MIBK are added to a pH-adjusted urine sample in a separatory flask. After shaking and being allowed to stand, the organic solvent layer now contains the heavy metals, which have been separated from the salts, proteins, and other components of the urine matrix. In addition to now having a "clean" sample, the metals have been extracted into a smaller volume of solvent, increasing the sensitivity of the analysis. An added benefit is that the use of the organic solvent itself further increases the sensitivity of flame AAS measurement (as discussed in Chapter 6).

Extraction of organic analytes such as pesticides, PCBs, and fats from solid samples such as food, soil, plants, and similar materials can be done using a Soxhlet extractor. A Soxhlet extractor consists of a round bottom flask fitted with a glass sample/siphon chamber in the neck of the flask. On top of the sample chamber is a standard water-cooled condenser. The solid sample is placed in a cellulose or fiberglass porous holder, called a thimble; the solvent is placed in the round bottom flask. Using a heating mantle around the flask, the solvent is vaporized, condensed, and drips or washes back down over the sample. Soluble analytes are extracted and then siphoned back into the round bottom flask. This is a continuous extraction process as long as heat is applied. The extracted analyte concentrates in the round bottom flask. An unfavorable aspect of extractions such as those with the Soxlet apparatus is that large volumes of solvent are used that must eventually be disposed of properly.

Performing these extractions manually is time consuming and can be hard work (try shaking a 1 L separatory funnel full of liquid for 20 min and imagine having to do this all day!). In addition, a lot of bench space is needed for racks of 1 L flasks or multiple heating mantles. Fortunately, there are several instrumental advances in solvent extraction that have made extraction a more efficient process. These advances generally use sealed vessels under elevated pressure to improve extraction efficiency and are classified as pressurized fluid (or pressurized solvent) extraction methods. One approach is the Accelerated Solvent Extraction system, ASE, from Thermo Fisher Scientific (www.thermoscientific.com). This technique is used for extracting solid and semi-solid samples, such as food, with liquid solvents. The technique is shown schematically in Figure 1.6. ASE uses conventional solvents and mixtures of




FIGURE 1.6 Accelerated solvent extraction technique. (© Thermo Fisher Scientific (www.thermofisher.com). Used with permission.)

TABLE 1.5 Comparison of Soxhlet Extraction with Accelerated Solvent Extraction

Extraction Method	Average Solvent Used per Sample (mL)	Average Extraction Time per Sample	Average Cost Per Sample (US \$)
Manual Soxhlet	200-500	4–48 h	27
Automated Soxhlet	50-100	1–4 h	16
Accelerated solvent extraction	15–40	12–18 min	14

Source: © Thermo Fisher Scientific (www.thermofisher.com). Used with permission.

solvents at elevated temperature and pressure to increase the efficiency of the extraction process. Increased temperature, up to 200 °C compared with the 70-80 °C normal boiling points of common solvents, accelerates the extraction rate while elevated pressure keeps the solvents liquid at temperatures above their normal boiling points, enabling safe and rapid extractions. Extraction times for many samples can be cut from hours to minutes, and the amount of solvent used is greatly reduced. Table 1.5 presents a comparison of the use of a commercial ASE system with conventional Soxhlet extraction. Dozens of application examples, ranging from fat in chocolate through environmental and industrial applications can be found at the Thermo website. The SpeedExtractor from Büchi Corporation also has applications available at www.mybuchi.com. The US EPA has recognized ASE and other instruments that use pressure and temperature to accelerate extraction of samples for environmental analysis by issuing US EPA Method 3545A (SW-846 series) for Pressurized Fluid Extraction of samples. The method can be found at www.usepa.gov.

A second approach also using high pressure and temperature is that of microwave assisted extraction. The sample is heated with the extraction solvent in a sealed vessel by microwave energy, as was described for microwave digestion. The temperature can be raised to about 150 °C with the already described advantages of high temperature and high pressure. One limitation of microwave assisted extraction is that some solvents are "transparent" to microwave radiation and do not heat; pure nonpolar solvents such as the normal alkanes are examples of such transparent solvents. Several instrument companies manufacture microwave extraction systems. Milestone Inc. (www.milestonesci.com) and CEM (www.cem.com), among others, have numerous applications on their websites as well as videos of microwave extraction, ashing, and digestion. An example of improved performance from a microwave extraction system vs. conventional extraction is shown in Table 1.6.

The third instrumental approach is the use of supercritical fluid extraction (SFE). A **supercritical fluid** is a substance at a temperature and pressure above the critical point for the substance. You may want to review phase diagrams and the critical point on the phase diagram in your general chemistry text or see the Applied Separations, Inc. website at www. appliedseparations.com. Supercritical fluids are more dense and viscous than the gas phase

TABLE 1.6 Comparison of Microwave Assisted
Extraction with Conventional Solvent
Extraction for Herbicides in Soil Samples

	Volume of			
Extraction Method	Time (min)	Solvent (mL)	% Recovery	
Separatory funnel	15	25	42-47	
Soxhlet	90	40	51-52	
Microwave extraction	10 (90 °C)	20	66-78	

Source: Data in table courtesy of Milestone Inc. (www.milestonesci.com).




FIGURE 1.7 Phase diagram for carbon dioxide.

of the substance but not as dense and viscous as the liquid phase. The relatively high density (compared with the gas phase) of a supercritical fluid allows these fluids to dissolve non-volatile organic molecules. Carbon dioxide, CO_2 , has a critical temperature of 31.3 °C and a critical pressure of 72.9 atm (Figure 1.7); this temperature and pressure are readily attainable, making supercritical CO_2 easy to form.

Supercritical CO_2 dissolves many organic compounds, so it can replace a variety of common solvents; supercritical CO_2 is used widely as a solvent for extraction. The advantages of using supercritical CO_2 include its low toxicity, low cost, nonflammability, and ease of disposal. Once the extraction is complete and the pressure returns to atmospheric pressure, the carbon dioxide immediately changes to a gas and escapes from the opened extraction vessel. The pure extracted analytes are left behind. Automated SFE instruments can extract multiple samples at once at temperatures up to 150 °C and pressures up to 10,000 psi (psi, pounds per square inch, is not an SI unit; 14.70 psi = 1 atm). SFE instrument descriptions and applications can be found at a number of company websites: Jasco, Inc. (www.jascoinc.com); Supercritical Fluid Technologies, Inc.(www.supercriticalfluids.com); Büchi Corporation (www.mybuchi.com); Newport Scientific, Inc. (www.newport-scientific.com). SFE methods have been developed for extraction of analytes from environmental, agricultural, food and beverage, polymer and pharmaceutical samples, among other matrices.

1.3.4.2 SOLID PHASE EXTRACTION (SPE)

In **solid phase extraction** (SPE), the "extractant" is not an organic liquid, but a solid phase material. Organic compounds are chemically bonded to a solid substrate such as silica beads or polymer beads. The bonded organic layer interacts with organic analytes in the sample solution and extracts them from the sample solution as it is poured through a bed or disk of the solid extractant. The excess solution is allowed to drain away, and interfering compounds are washed off the extractant bed with a solution that does not remove the target analytes. The extracted organic analytes are then **eluted** from the solid phase extractant by passing a suitable organic solvent through the bed. The interactions that cause the analytes to be extracted are those intermolecular attractive forces you learned about in general chemistry: van der Waals attractions, dipole-dipole interactions, and electrostatic attractions.

The types of organic compounds that can be bonded to a solid substrate vary widely. They can be hydrophobic nonpolar molecules such as C_8 and C_{18} hydrocarbon chains, chains with highly polar functional groups such as cyano ($-C\equiv N$), amine ($-NH_2$), and hydroxyl




FIGURE 1.8 (a) Commercial plastic syringe-type cartridges and **(b)** Schematic of sorbent packing. (Permission to reprint from Avantor Performance Materials, Inc., Center Valley, PA. www.avantormaterials.com.)

(—OH) groups, and with ionizable groups like sulfonic acid anions (— SO_3^-) and carboxylic acid anions (— CO_2^-), to extract a wide variety of analytes. The term **sorbent** is used for the solid phase extractant. Commercial SPE cartridges have the sorbent packed into a polymer syringe body or disposable polymer pipette tip. Figure 1.8(a) shows commercial plastic syringe-type cartridges with a variety of sorbents, including several of those just mentioned, while Figure 1.8(b) shows a schematic of how the sorbent is packed and held in the cartridge. These are used only once, preventing cross-contamination of samples and allowing the cleanup of extremely small sample volumes (down to 1 μ L), such as those encountered in clinical chemistry samples. Specialized sorbents have been developed for the preparation of urine, blood, and plasma samples for drugs of abuse, for example. Automated SPE systems that can process hundreds of samples simultaneously are now in use in the pharmaceutical and biotechnology industries.

SPE is used widely for the cleanup and concentration of analytes for analysis using LC, HPLC, and LC-MS, discussed in Chapter 12. As you will see, the phases used in HPLC for the separation of compounds are in many cases identical to the bonded solid phase extractants described here. Detailed examples and applications notes are available from a number of SPE equipment suppliers: Avantor Performance Materials, Inc. (www.avantormaterials.com), Sigma-Aldrich Co. (www.sigmaaldrich.com), Phenomenex (www.phenomenex.com) and Büchi Corporation (www.mybuchi.com) are a few of the companies that supply these products.

The SPE field is still developing, with the introduction of an automated SPE instrument from Thermo Fisher Scientific designed to be used with large volume samples (20~mL-4~L) for the isolation of trace organics in water and other aqueous matrices.

1.3.4.3 QuEChERS

A very important analytical method is the determination of pesticide residues in fruits, vegetables, and processed foods such as cereal. The method used to require complex extraction and cleanup of samples prior to HPLC and MS analysis. In 2003, US Department of Agriculture scientists (Anastassiades et al.) developed a simplified method for food samples, called QuEChERS (pronounced "ketchers" or "catchers"), which stands for Quick, Easy, Cheap, Effective, Rugged, and Safe. QuEChERS has now been applied to food samples, dietary supplements, and other matrices for pesticides, veterinary drugs, and other compounds and is recognized as a sample preparation method in AOAC and European

standards. QuEChERS uses a simple two-step approach, an extraction step followed by dispersive SPE. First, the sample is homogenized, weighed into a 50 mL centrifuge tube and appropriate organic solvent and salts are added. The salts may include magnesium sulfate and sodium acetate for drying and buffering the sample. The sample is shaken and centrifuged. The supernatant is further extracted and cleaned using dispersive SPE. In dispersive SPE, the SPE sorbent(s) is (are) in a centrifuge tube along with a small amount of MgSO₄. An aliquot of the supernatant from step 1 is added, the tube is shaken and centrifuged, and the sorbent removes interfering matrix materials from the sample. Sorbents include primary and secondary amine exchange materials (PSA), to remove sugars, fatty acids, organic acids, and some pigments; C18 (a common octadecyl-substituted hydrophobic LC material) used to remove lipids and nonpolar interferences and GBC (graphitized carbon black) to remove pigments and sterols. Multiple companies now market packaged QuEChERS kits that meet regulatory standards in the US and Europe. The websites www.quechers.com, www.restek. com, www.gerstel.com/en/applications.htm and www.agilent.com/chem/Quechers offer a variety of tutorials, applications notes, audio slide shows, webinars, and video demonstrations of the QuEChERS process.

A recent environmental application of the QuEChERS method was demonstrated by researchers from Gerstel, Inc. and the Arkansas Public Health Laboratory to deal with the huge 2010 oil well spill in the Gulf of Mexico (Whitecavage et al.). Estimates of the number of samples to be analyzed for petroleum hydrocarbons such as polyaromatic hydrocarbons (PAH) in seafood ran as high as 10,000 samples per month. Standard regulatory assays took one week to analyze 14-25 samples. Using Gerstel's TwisterTM Stir Bar Sorptive Extraction (SBSE), sample throughput for PAHs in seafood could be increased to 40 samples/day. The TwisterTM is a glass coated magnetic stir bar with an external layer of polydimethylsiloxane (PDMS). The stir bar is added to an aliquot of the supernatant from the QuEChERS step, and while stirring the solution, organic compounds are extracted into the PDMS phase. The Twister is removed from the sample, rinsed with DI water, dried with a lint-free cloth and placed in a thermal desorption tube for automated direct thermal desorption into a GC/MS system. The SBSE step provides a concentration of the analytes as well as an additional cleanup of the supernatant, resulting in limits of detection 10-50 limes lower than the regulatory assay while using significantly less solvent.

1.3.4.4 SOLID PHASE MICROEXTRACTION (SPME)

Solid phase microextraction (SPME, pronounced "spee-mee" by some users) is a sampling technique developed first for analysis by GC; the use of SPME for GC and related applications is discussed in greater detail in Chapter 11, Section 11.3. The solid phase in this case is a coated fiber of fused silica. The coatings used may be liquid polymers like poly(dimethylsiloxane) (PDMS), which is a silicone polymer. Solid sorbents or combinations of both solid and liquid polymers are also used. Figure 1.9(a) shows a commercial SPME unit with the coated fiber inserted into a sample vial: the coated fiber tip is shown in Figure 1.9(b). The size of the probe is shown in Figure 1.9(c). No extracting solvent is used when the sample is analyzed by GC. The coated fiber is exposed to a liquid or gas sample or to the vapor over a liquid or solid sample in a sealed vial (this is called sampling the **headspace**) for a period of time. Analyte is adsorbed by the solid coating or absorbed by the liquid coating on the fiber and then thermally desorbed by insertion into the heated injection port of the gas chromatograph. The process is shown schematically in Figure 1.10.

Unlike solvent extraction, the entire amount of analyte is not extracted. The amount of analyte extracted by the coated fiber is proportional to the concentration of analyte in the sample. This will be true if equilibrium between the fiber and the sample is achieved or before equilibrium is achieved if the sampling conditions are controlled carefully. SPME sampling and desorption can be used for qualitative and quantitative analyses. Quantitative analysis using external calibration, internal standard calibration, and the method of standard additions are all possible with SPME.

SPME sampling is used for a wide variety of analytes, including environmental pollutants, volatiles from botanical samples (e.g., used to identify tobacco species), explosives, and



FIGURE 1.9 (a) Commercial SPME unit with the coated fiber (b) Inserted into a sample vial. (c) An SPME probe the size of a ballpoint pen. (Used with permission from Sigma-Aldrich, a part of MilliporeSigma. www.sigmaaldritch.Com. Copyright 2020 Sigma-Aldrich Co. LLC. All rights reserved.)




FIGURE 1.10 Schematic of the SPME process. (Used with permission from Sigma-Aldrich, a part of MilliporeSigma. www.sigmaaldritch.com. Copyright 2020 Sigma-Aldrich Co. LLC. All rights reserved.)

chemical agent residues. Gasoline and other accelerants in the headspace over fire debris can be sampled with SPME to determine whether arson may have caused the fire. As little as 0.01 μ L of gasoline can be detected. Gas samples such as indoor air and breath have been sampled using SPME. Liquid samples analyzed by either immersion of the fiber into the sample or sampling of the headspace vapor include water, wine, fruit juice, blood, milk, coffee, urine, and saliva. Headspace samplings of the vapors from solids include cheese, plants, fruits, polymers, pharmaceuticals, and biological tissue. These examples and many other applications examples are available in pdf format and on CD from Sigma-Aldrich at www.sigmaaldrich.com/supelco. SPME probes that are ballpoint pen-sized are available for field sampling (see www.fieldforensics.com or www.sigmaaldrich.com/supelco). These can be capped and taken to an on-site mobile lab or transported back to a conventional laboratory for analysis.

While SPME started as a solvent-free extraction system for GC analysis, it can now also be used to introduce samples into an HPLC apparatus. A SPME-HPLC interface, Figure 1.11, allows the use of an SPME fiber to sample nonvolatile analytes such as nonionic surfactants in water, and elute the analyte into the solvent mobile phase used for the HPLC analysis. The sampling process and elution are shown schematically in Figure 1.10. HPLC and its applications are covered in Chapter 12.




FIGURE 1.11 A SPME-HPLC interface. (Used with permission from Sigma-Aldrich, a part of MilliporeSigma. www.sigmaaldritch.Com. Copyright 2020 Sigma-Aldrich Co. LLC. All rights reserved.)

1.4 BASIC STATISTICS AND DATA HANDLING

In order to design the correct experiment to answer the analytical question being asked, statistical methods are needed to select the size of the sample required, the number of samples to be analyzed, and the number of measurements that must be performed to obtain the needed accuracy and precision in the results generated by the experiment. Statistical analysis of data is also used to express the uncertainty in measured values, so that the users of the data understand the limitations associated with results. Every measured result has uncertainty associated with it; it is part of the analyst's job to express that uncertainty in a way that defines the range of values that are reasonable for the measured quantity. Uncertainty, properly evaluated and reported with the measured value, indicates the level of confidence (CL) that the value actually lies within the range reported.

1.4.1 ACCURACY AND PRECISION

It is very important to understand the definitions of accuracy and precision and to recognize the difference between them. *Accuracy* is a measure of how close a measured analytical result is to the true answer. For most analytical work, the "true answer" is not usually known. We often work with an "accepted" true value or "accepted reference value". Accuracy is evaluated by analyzing known, standard samples. The US NIST in Gaithersburg, MD has well-characterized **standard reference materials (SRMs)** of many types that can serve as the known sample. Similar **certified reference materials (CRMs)** are available from government standards agencies in Canada, the UK, Europe, and other countries, as well as from a wide variety of commercial standards suppliers. A brief discussion of these materials is provided in Chapter 14 on Thermal Methods. Another way of assessing accuracy is to *spike* a sample with a known amount of the pure analyte. The sample is analyzed and the amount of added analyte *recovered* is reported. A spike recovery of 100 % would indicate that all of the added analyte was measured by the analytical method, for example. Accuracy is documented by reporting the difference between the measured value and the true value with the appropriate **confidence level**, or by reporting the spike recovery as a percentage of added analyte.

Precision is a measure of how close replicate results on the same sample are to each other. A common analogy used to envision the difference between accuracy and precision is to imagine a bull's-eye target used by an archer. If all the arrows hit in the bull's-eye, the archer is both accurate (has hit the center) and precise (all the arrows are close together). If the archer puts all the arrows into the target close together (a "tight shot group") but to the upper left of the bull's-eye, the archer is precise but not accurate. If the arrows hit the target in many locations—top, bottom, center, left, and right of the center—the archer is neither precise nor accurate. The difference between precision and accuracy is illustrated in Table 1.7. There are several ways to express precision mathematically; Table 1.7 uses standard deviation (to be defined shortly) as a measure of precision. A superficial examination of the results provided by Analyst 2 could be misleading. It is very easy to be deceived by the closeness of the answers into believing that the results are accurate. The closeness, expressed as the standard deviation, shows that the results of Analyst 2 are *precise*, and not that the analysis will result in obtaining the true answer. The latter must be discovered by an independent method, such as having Analyst 2 analyze a sample of known composition. The accepted true value for the determination is 10.1 ± 0.2 % according to the table footnote, so the determination by Analyst 2 is not accurate. Analyst 3 is both inaccurate and imprecise. It is very unlikely that an imprecise determination will be accurate. Precision is required for accuracy, but does not guarantee accuracy.

It is important for students to realize that the inability to obtain the correct answer does not necessarily mean that the analyst uses poor laboratory techniques or is a poor chemist. Many causes contribute to poor accuracy and precision, some of which we will discuss in this chapter as well as in later chapters. Careful documentation of analytical procedures, instrument operating conditions, calculations, and final results are crucial in helping the analyst recognize and eliminate errors in analysis.

TABLE 1.7 Replicate Determinations of Analyte in a Sample^a

	% Analyte			
	Analyst 1 ^b	Analyst 2°	Analyst 3d	
	10.0	8.1	13.0	
	10.2	8.0	10.2	
	10.0	8.3	10.3	
	10.2	8.2	11.1	
	10.1	8.0	13.1	
	10.1	8.0	9.3	
Average (%)	10.1	8.1	11.2	
Absolute error ^e	0.0	2.0	1.1	
Standard deviation	0.09	0.13	1.57	

- ^a Accepted true answer is 10.1 ± 0.2 % (obtained independently).
- ^b Results are precise and accurate.
- ^c Results are precise but inaccurate.
- d Results are imprecise and inaccurate.
- e Absolute error = |true value -measured value|.

The quantitative analysis of any particular sample should generate results that are precise and accurate. The results should be reproducible, reliable, and truly representative of the sample. Some degree of error is always involved in analytical determinations, as discussed in Section 1.4.2. We note that the presence of uncertainty in a measurement is not necessarily a downside or disadvantage. A measured result is useless unless the uncertainty is known and quantified.

For analytical results to be most useful, it is important to be aware of the reliability of the results. To do this, it is necessary to understand the sources of error and to be able to recognize when they can be eliminated and when they cannot. Error is the difference between the true result (or accepted true result) and the measured result. If the error in an analysis is large, serious consequences may result. A patient may undergo expensive and even dangerous medical treatment based on an incorrect laboratory result or an industrial company may implement costly and incorrect modifications to a plant or process because of an analytical error. There are numerous sources of error and several types of errors, some of which are described here.

1.4.2 TYPES OF ERRORS

There are two principal types of error in analysis: **determinate** or **systematic** error and **indeterminate** or **random** error.

1.4.2.1 DETERMINATE ERROR

Broadly speaking, **determinate errors** are caused by faults in the analytical procedure or the instruments used in the analysis. The name determinate error implies that the cause of this type of error may be found out and then either avoided or corrected. Determinate errors are *systematic errors*; that is, they are not random. A particular determinate error may cause the analytical results produced by the method to be always too high; another determinate error may render all results too low. Sometimes the error is *constant*; all answers are too high (or too low) by the same amount. If the true results for three samples are 25, 20, and 30 mg/L of analyte, but the measured (or determined) results are 35, 30, and 40 mg/L, respectively, the analysis has a *constant error* of 10 mg/L. Since these results are all too high, the constant error is positive. Sometimes the determinate error is proportional

to the true result, giving rise to *proportional errors*. For example, if the measured results for the same three earlier samples are 27.5, 22.0, and 33.0 mg/L analyte, respectively, the measured results are too high by 10 % of the true answer. This error varies in proportion to the true value. Other determinate errors may be variable in both sign and magnitude, such as the change in the volume of a solution as the temperature changes. Although this variation can be positive or negative, it can be identified and accounted for. Determinate errors can be additive or they can be multiplicative. It depends on the error and how it enters into the calculation of the final result.

If you look again at the results in Table 1.7 for Analyst 2, the results produced by this analyst for the repetitive analysis of a single sample agree closely with each other, indicating high precision. However, the results are all too low (and therefore inaccurate), given that the true value of the sample is 10.1 ± 0.2 % analyte. There is a negative determinate error in the results from Analyst 2. This determinate error could be the result of an incorrectly calibrated balance. If the balance is set so that the zero point is actually 0.5 g too high, all masses determined with this balance will be 0.5 g too high. If this balance was used to weigh out the potassium chloride used to make the potassium standard solution used in the clinical laboratory, the standard concentration will be erroneously high, and all of the results obtained using this standard will be erroneously low. The error is reported as the absolute error, the absolute value of the difference between the true and measured values. However, there is not enough information provided to know if this is a constant or a proportional error. It can be seen that close agreement between results does not rule out the presence of a determinate error.

Determinate errors arise from some faulty step in the analytical process. The faulty step is repeated every time the determination is performed. Whether a sample is analyzed 5 times or 50 times, the results may all agree with each other (good precision) but differ widely from the true answer (poor accuracy).

If a faulty analytical procedure is used to analyze five different patients' serum samples and the results shown in Table 1.8 are obtained, it can be seen that in all cases the error is +1.2 mmol/L. This indicates a constant, positive determinate error. If the normal range for K in serum is 3.5-5.3 mmol/L, this faulty procedure would result in one patient being misdiagnosed with a false high serum K level and a patient with a truly low serum K level being misdiagnosed as "normal".

Systematic error is under the control of the analyst. It is the analyst's responsibility to recognize and correct for these *systematic errors* that cause results to be *biased*, that is, offset in the average measured value from the true value. How are determinate errors identified and corrected? Two methods are commonly used to identify the existence of systematic errors. One is to analyze the sample by a completely different analytical procedure that is known to involve no systematic errors. Such methods are often called "standard methods"; they have been evaluated extensively by many laboratories and shown to be accurate and precise. If the results from the two analytical methods agree, it is reasonable to assume that both analytical procedures are free of determinate errors. The second method is to run several analyses of a reference material of known, accepted concentration of analyte. The difference between the known (true) concentration and that measured by analysis should reveal the error. If

TABLE 1.8 Potassium Concentrations in Patients' Serum

Measured Value ^a	True Value
(mmol/L)	(mmol/L)
5.3	4.1
4.8	3.6
6.3	5.1
5.0	3.8
4.1	2.9
	(mmol/L) 5.3 4.8 6.3 5.0

^a Constant error of +1.2 mmol/L.

the results of analysis of a known reference standard are too high (or too low), then a determinate error is present in the method. The cause of the error must be identified and either eliminated or controlled if the analytical procedure is to give accurate results. In the earlier example of potassium in serum, standard serum samples with certified concentrations of potassium are available for clinical laboratories. Many clinical and analytical laboratories participate in proficiency testing programs, where "unknown" standard samples are sent to the laboratory on a regular basis. The results of these samples are sent to the government or professional agency running the program. The unknowns are of course known to the agency that sent the test samples; the laboratory receives a report on the accuracy and precision of its performance.

Determinate errors can arise from uncalibrated balances, improperly calibrated volumetric flasks or pipettes, malfunctioning instrumentation, impure chemicals, incorrect analytical procedures or techniques, and analyst error.

Analyst error. The person performing the analysis causes these errors. They may be the result of inexperience, insufficient training, or being "in a hurry". An analyst may use the instrument incorrectly, perhaps by placing the sample in the instrument incorrectly each time or setting the instrument to the wrong conditions for analysis. Consistently misreading a meniscus in a volumetric flask as high (or low) and improper use of pipettes, such as "blowing out" the liquid from a volumetric pipette, are possible analyst errors. Some other analyst-related errors are (1) *carelessness*, which is not as common as is generally believed; (2) *transcription errors*, that is, copying the wrong information into a lab notebook or spreadsheet or onto a label; and (3) *calculation errors*. Proper training, experience, and attention to detail on the part of the analyst can correct these types of errors.

Reagents and instrumentation. Contaminated or decomposed reagents can cause determinate errors. Impurities in the reagents may interfere with the determination of the analyte, especially at the ppm level or below. Prepared reagents may also be improperly labeled. The suspect reagent may be tested for purity using a known procedure or the analysis should be redone using a different set of reagents and the results compared.

Numerous errors involving instrumentation are possible, including incorrect instrument settings and use of the wrong instrument program in computer-based instruments. Any variation in proper instrument settings can lead to errors. These problems can be eliminated by a systematic procedure to check the instrument settings and operation before use. Such procedures are called standard operating procedures (SOPs) in many labs. There should be a written SOP for each instrument and each analytical method used in the laboratory.

In instrumental analysis, electrical line voltage fluctuations are a particular problem. This is especially true for automated instruments running unattended overnight. Instruments are often calibrated during the day, when electrical power is in high demand. At night, when power demand is lower, line voltage may increase substantially, completely changing the relationship between concentration of analyte and measured signal. Regulated power supplies are highly recommended for analytical instruments. The procedure for unattended analysis should include sufficient calibration checks during the analytical run to identify such problems. Many instruments are now equipped with software that can check the measured value of a standard and automatically recalibrate the instrument if that standard falls outside specified limits.

Analytical method. The most serious errors are those in the method itself. Examples of method errors include: (1) incomplete reaction for chemical methods, (2) unexpected interferences from the sample itself or reagents used, (3) having the analyte in the wrong oxidation state for the measurement, (4) loss of analyte during sample preparation by volatilization or precipitation, and (5) an error in calculation based on incorrect assumptions in the procedure (errors can arise from assignment of an incorrect formula or molecular weight to the sample). Most analytical chemists developing a method check all the compounds likely to be present in the sample to see if they interfere with the determination of the analyte; unlikely interferences may not have been checked. Once a valid method is developed, an SOP for the method should be written so that it is performed the same way every time it is run.

Contamination. Contamination of samples by external sources can be a serious source of error and may be extremely variable. An excellent example of how serious this can be has

been documented in the analysis of samples for polychlorinated biphenyls (PCBs). PCBs are synthetic mixtures of organochlorine compounds that were first manufactured in 1929 and have become of concern as significant environmental pollutants. It has been demonstrated that samples archived since 1914, before PCBs were manufactured, picked up measurable amounts of PCBs in a few hours just sitting in a modern laboratory (Erickson). Aluminum levels in the dust in a normal laboratory are so high that dust prohibits the determination of low ppb levels of aluminum in samples. A special dust-free "clean lab" or "clean bench" with a filter to remove small dust particles may be required, similar to the clean rooms needed in the semiconductor industry, for determination of traces of aluminum, silicon, and other common elements such as iron. When **trace** (<ppm level) or **ultratrace** (<ppb level) organic and inorganic analysis is required, the laboratory environment can be a significant source of contamination.

Another major source of contamination in an analysis can be the analyst. It depends on what kind of analytes are being measured, but when trace or ultratrace levels of elements or molecules are being determined, the analyst can be a part of the analytical problem. Many personal care items, such as hand creams, shampoos, powders, and cosmetics, contain significant amounts of chemicals that may be analytes. The problem can be severe for volatile organic compounds in aftershave, perfume, and many other scented products and for silicone polymers, used in many health and beauty products. Powdered gloves may contain a variety of trace elements and should not be used by analysts performing trace element determinations. Hair, skin, and clothing can shed cells or fibers that can contaminate a sample.

Having detected the presence of a determinate error, the next step is to find its source. Practical experience of the analytical method or first-hand observation of the analyst using the procedure is invaluable. Much time can be wasted in an office guessing at the source of the trouble. Unexpected errors can be discovered only in the laboratory. A little data is worth a lot of discussion (Robinson's Law).

1.4.2.2 INDETERMINATE ERROR

After all the determinate errors of an analytical procedure have been detected and eliminated, the analytical method is still subject to random or indeterminate error arising from inherent limitations in making physical measurements. Each error may be positive or negative, and the magnitude of each error will vary. Indeterminate errors are not constant or biased. They are random in nature and are the cause of slight variations in results of replicate samples made by the same analyst under the same conditions.

Indeterminate errors arise from sources that cannot be corrected, avoided, or even identified, in some cases. All analytical procedures are subject to indeterminate error. However, because indeterminate error is random, the errors will follow a random distribution. This distribution can be understood using the laws of probability and basic statistics. The extent of indeterminate error can be calculated mathematically.

Let us suppose that an analytical procedure has been developed in which there is no determinate error. If an infinite number of analyses of a single sample were carried out using this procedure, the distribution of numerical results would be shaped like a symmetrical bell (Figure 1.12). This bell-shaped curve is called the **normal** or **Gaussian distribution**. This is a graphical representation of the frequency of occurrence of any given measured value when only indeterminate error occurs.

If only indeterminate errors were involved, the most frequently occurring result would be the true result; the result at the maximum of the curve would be the true answer. In practice, it is not possible to make an infinite number of analyses of a single sample. At best, only a few analyses can be carried out and frequently only one analysis of a particular sample is possible. We can, however, use our knowledge of statistics to determine how reliable these results are. The basis of statistical calculations is outlined below. Statisticians differentiate between the values obtained from a finite number of measurements, N, and the values obtained from an infinite number of measurements, so we need to define these statistical terms.




FIGURE 1.12 A normal or Gaussian distribution of results when only indeterminate error is present. The value that occurs with most frequency is the true value (T) or mean value, while the spread of the distribution is expressed in units of standard deviation from the mean, symbolized by σ the larger the random error, the broader the distribution will be.

1.4.3 DEFINITIONS FOR STATISTICS

True value T: the true or accepted value; also symbolized by x_t . **Observed value** x_i : a single value measured by experiment.

Sample mean \overline{x} : the arithmetic mean of a finite number of observations, that is,

(1.4)
$$\overline{x} = \frac{\sum_{i=1}^{N} x_i}{N} = \frac{(x_1 + x_2 + x_3 + \dots + x_N)}{N}$$

Where *N* is the number of observations and $\sum x_i$ is the sum of all the individual values x_i . **Population mean** μ : the limit as *N* approaches infinity of the sample mean, that is,

$$\mu = \lim_{N \to \infty} \sum_{i=1}^{N} \frac{x_i}{N}$$

In the absence of systematic error, the population mean μ equals the true value T of the quantity being measured.

Error *E*: the difference between the true value T and either a single observed value x_i or the sample mean of the observed values, \overline{x} ; error may be positive or negative,

$$E = x_i - T \quad \text{or} \quad \overline{x} - x_t \tag{1.6}$$

The total error is the sum of all the systematic and random errors.

Absolute error: the absolute value of *E*, and can be defined for a single value or for the sample mean,

(1.7)
$$E_{\text{abs}} = |x_i - T| \text{ or } |\overline{x} - x_t|$$

Relative error: the absolute error divided by the true value; it is often expressed as a percent by multiplying by 100,

(1.8)
$$E_{\text{rel}} = \frac{E_{\text{abs}}}{x_{\text{t}}} \text{ or } \%E_{\text{rel}} = \frac{E_{\text{abs}}}{x_{\text{t}}} \times 100$$

Absolute deviation d_i : the absolute value of the difference between the observed value x_i and the sample mean \overline{x} ,

$$(1.9) d_i = |x_i - \overline{x}|$$

Relative deviation *D*: the absolute deviation d_i divided by the mean \overline{x} ,

$$(1.10) D = \frac{d_i}{\overline{x}}$$

Percent relative deviation: the relative deviation multiplied by 100,

(1.11)
$$D(\%) = \frac{d_i \times 100\%}{\overline{x}} = D \times 100$$

Sample standard deviation *s*: for a finite number of observations *N*, the sample standard deviation is defined as

(1.12)
$$s = \sqrt{\frac{\sum_{i=1}^{N} d_i^2}{N-1}} = \sqrt{\frac{\sum_{i=1}^{N} (x_i - \overline{x})^2}{N-1}}$$

Standard deviation of the mean s_m : the standard deviation associated with the mean of a data set consisting of N measurements,

$$(1.13) s_m = \frac{s}{\sqrt{N}}$$

Population standard deviation σ : for an infinite number of measurements,

(1.14)
$$\sigma = \sqrt{\lim_{N \to \infty} \frac{\sum_{i=1}^{N} (x_i - \mu)^2}{N}}$$

Percent relative standard deviation %RSD,

$$\%RSD = \frac{s}{\overline{x}} \times 100$$

Variance σ^2 or s^2 : the square of the population standard deviation σ or the sample standard deviation s.

1.4.4 QUANTIFYING RANDOM ERROR

If the systematic errors have been eliminated, the measured value will still be distributed about the true value owing to random error. For a given set of measurements, how close is the average value of our measurements to the true value? This is where the Gaussian distribution and statistics are used.

The Gaussian distribution curve assumes that an infinite number of measurements of x_i have been made. The maximum of the Gaussian curve occurs at $x = \mu$, the true value of the parameter we are measuring. So, for an infinite number of measurements, the population

mean is the true value x_t . We assume that any measurements we make are a subset of the Gaussian distribution. As the number of measurements, N, increases, the difference between \overline{x} and μ tends toward zero. For N greater than 20, the sample mean rapidly approaches the population mean. For 25 or more replicate measurements, the true value is approximated very well by the experimental mean value. Unfortunately, even 20 measurements of a real sample are not usually possible. Statistics allows us to express the random error associated with the difference between the population mean μ and the mean of a small subset of the population, \overline{x} . The random error for the mean of a small subset is equal to $\overline{x} - \mu$.

The area under any portion of the Gaussian distribution, for example, between a value x_1 and a value x_2 , corresponds to the fraction of the measurements which will yield a measured value of x between and including these two values. The spread of the Gaussian distribution, that is, the width of the bell-shaped curve, is expressed in terms of the population standard deviation σ . The standard deviation σ coincides with the point of inflection of the curve as can be seen in Figure 1.12. The curve is symmetrical, so we have two inflection points, one on each side of the maximum. The x-axis relates the area under the curve to the standard deviation. For $\pm \sigma$ on either side of the maximum, 68.3 % of the area under the curve lies in this range of x. This means that 68.3 % of all measurements of x_i will fall within the range $x = \mu \pm \sigma$. About 95.5 % of the area under the curve lies between $x = \mu \pm 2\sigma$ and 99.7 % of the area lies between $x = \mu \pm 3\sigma$.

The precision of analytical results is usually stated in terms of the standard deviation σ . As just explained, in the absence of determinate error, 68.3 % of all results can be expected to fall within $\pm \sigma$ of the true value, 95.5 % of the results will fall within $\pm 2 \sigma$ of the true answer, and 99.7 % of our results will fall within $\pm 3\sigma$ of the true value if we perform enough measurements (more than 20 or so replicates). It is common practice to report analytical results with the mean value and the standard deviation expressed, thereby giving an indication of the precision of the results.

Let us suppose that we know by previous extensive testing that the standard deviation σ of a given analytical procedure for the determination of Si in an aluminum alloy is 0.1 %w/w. This is the standard deviation in concentration units (0.1 g Si/100 g Al alloy), not the relative standard deviation. We know that there are no determinate errors in the analysis. Also, when we analyze a particular sample using this method, and perform sufficient replicate analyses, we obtain an average result of 19.6 % Si by weight. We can now report that the analytical result is 19.6 ± 0.1 % Si with the understanding that 68.3 % of all results will fall in this range. We could also report that the result is 19.6 ± 0.2 % (where 0.2 % = 2σ). A report stating that an analysis of a sample indicated 19.6 % Si and that 2σ for the method is 0.2 % means that we are 95.5 % certain that the true answer is 19.6 ± 0.2 %Si. We say that the confidence level (CL) of the measurement is 95.5 %, with the understanding that there are no determinate errors and that we have performed a sufficient number of replicates to know both μ and σ . Notice that the more certain we are that the answer falls within the range given, the bigger the range actually is. It is important when reporting data with both mean and precision information that the analyst tells the customer what precision is reported. If Analyst A reported 19.6 ± 0.1 %Si and Analyst B reported 19.6 ± 0.2 %Si, without telling the customer what the 0.1 and 0.2 % mean, the customer might think incorrectly that Analyst A is more precise than Analyst B.

We are usually dealing with a small, finite subset of measurements, not 20 or more; in this case, the standard deviation that should be reported is the sample standard deviation s. For a small finite data set, the sample standard deviation s differs from σ in two respects. Look at the equations given in the definitions. The equation for sample standard deviation s contains the sample mean, not the population mean, and uses N-1 measurements instead of N, the total number of measurements. The term N-1 is called the **degrees of freedom**.

Let us go through an example of calculating some of these statistical parameters. The equations are simple enough that the values can be calculated manually, although the calculations can be tedious for large values of N. Most scientific handheld calculators have programs that calculate mean, sample standard deviation s (sometimes marked σ_{N-1} on a calculator button), and σ (sometimes marked σ_N on a button). You should learn how to use

these programs on your calculator. In addition, the calculations can be set up in a spread-sheet in programs like Microsoft Excel®.

You have measured mercury in eight representative samples of biological tissue from herons (which eat fish that may be contaminated with mercury) using cold vapor AAS (discussed in Chapter 6). The values in column 2 of the table below were obtained.

Sample	Hg Content (ppb)	$(x_i - \overline{x})^2$
1	5.34	0.010
2	5.37	0.005
3	5.44	0.000
4	5.22	0.048
5	5.84	0.160
6	5.67	0.053
7	5.27	0.029
8	5.33	0.012

The mean is calculated using Eq. (1.4):

$$\overline{x} = \frac{5.34 + 5.37 + 5.44 + 5.22 + 5.84 + 5.67 + 5.27 + 5.33}{8}$$

$$= \frac{43.48}{8} = 5.44 \text{ ppb Hg}$$

Since we have only eight measurements, we will calculate s, the sample standard deviation, using Eq. (1.12). The standard deviation s is calculated manually in steps, with the intermediate values for $(x_i - \overline{x})^2$ shown in the table in the third column. The sum of the $(x_i - \overline{x})^2$ values = 0.317, therefore:

$$s = \sqrt{\frac{0.317}{8 - 1}} = 0.213$$

You could report the average concentration of Hg in the heron tissue as 5.44 ± 0.21 ppb Hg and indicate in your report that 0.21 equals 1s. The Hg concentration can be reported in terms of 2s, 3s, and so on, just as for the population standard deviation. Analytical results published without such precision data lose much of their meaning. They indicate only the result obtained and not the reliability of the answer.

Software programs called spreadsheets are extremely useful for performing the repetitive calculations used by analysts, displaying each step in the calculation, tabulating data, and presenting data graphically. A variety of commercial software programs are available. The example given here uses the spreadsheet program Microsoft Excel®. The other commercial programs have similar capabilities but the instructions will differ for each. The following example assumes some familiarity with using Microsoft programs. If more fundamental directions are needed, the texts by Christian, Harris, Billo or Diamond and Hanratty listed in the bibliography have excellent instructions and examples.

When an Excel spreadsheet is opened, the page consists of blank boxes, called cells, arranged in rows and columns. Each cell is identified by its column letter and row number. The individual mercury concentrations from the earlier example can be typed into separate cells, as can text such as column headings. In the sample spreadsheet page shown, text is typed into cells A1, B1, A12, and A13, while the sample numbers and data are put in as shown. The data points are in cells B3 through B10. The width of the columns can be varied to fit the contents.

	Α	В	c	D
1	Sample	Hg cone. (ppb)		
2				
3	1	5.34		
4	2	5.37		
5	3	5.44		
6	4	5.22		
7	5	5.84		
8	6	5.67		
9	7	5.27		
10	8	5.33		
11				
12	Mean			
13	Std. Dev.			

It is possible to write mathematical formulas and insert them into the spreadsheet to perform calculations, but Excel has many functions already built into the program. By clicking on an empty cell and then on f_x on the toolbar, these functions can be accessed. This opens the Paste Function window. Select *Statistical* in the *Function category* on the left side of the window and a list of *Function names* appears on the right side of the window. Click on the cell B12, then select AVERAGE from the Function name list. Click OK, and type in (B3:B10) in the active box. The average (mean) will appear in cell B12. Alternatively, in cell B12, you can type = AVERAGE(B3:B10) and the mean will be calculated. The standard deviation can be calculated by selecting STDEV from the Function name list and clicking on cell B13 or by typing = STDEV(B3:B10) into cell B13.

	Α	В	c	D
1	Sample	Hg conc. (ppb)		
2				
3	1	5.34		
4	2	5.37		
5	3	5.44		
6	4	5.22		
7	5	5.84		
8	6	5.67		
9	7	5.27		
10	8	5.33		
11				
12	Mean	5.435		
13	Std. Dev.	0.212804		
14				

The values calculated by Excel are shown in cells B12 and B13. Of course, they must be rounded off to the correct number of significant figures, but are the same as the results obtained manually. Learning to use spreadsheets can save time and permit the data to be stored, processed, and presented in a variety of formats. The spreadsheets can be made part of the electronic lab notebooks that are common in industry and government laboratories as well as in many college laboratories. In addition, most computer-based analytical instruments will calculate mean, standard deviation, and the entire set of parameters associated with the calibration curve, discussed below.

The value obtained for σ is an estimate of the precision of the method. If an analyst sets up a new analytical procedure and carries out 20 determinations of a standard sample, the precision obtained is called the **short-term precision** of the method. This is the optimum value of

 σ because it was obtained from analyses run at the same time by the same analyst, using the same instrumentation and the same chemicals and reagents. In practice, the short-term precision data may be too optimistic. Routine analyses may be carried out for many years in a lab, such as the determination of Na and K in serum in a hospital laboratory. Different analysts, different chemicals and reagents, and even different instrumentation may be used. The analysis of a standard sample should be carried out on a regular basis (daily, weekly, etc.) and these results compiled on a regular basis. Over several months or a year, the **long-term precision** of the method can be calculated from these compiled results. This is a more realistic measure of the reliability of the analytical results obtained on a continuing basis from that laboratory.

There are a variety of terms used to discuss analytical methods that are related to the precision of the method. The **repeatability** of the method is the short-term precision of the method under the same operating conditions. **Reproducibility** refers to the ability of multiple laboratories to obtain the same results on a given sample and is determined from collaborative studies. **Ruggedness** is the degree of reproducibility of the results obtained by one laboratory under a variety of conditions (similar to the long-term precision). Repeatability, reproducibility, and ruggedness are all expressed in terms of the standard deviation (or relative standard deviation) obtained experimentally. **Robustness** is another term for the **reliability** of the method, that is, its accuracy and precision, under small changes in conditions. These changes can be in operating conditions such as laboratory room temperature, sample variables such as concentration and pH, reagent and standard stability, and so on.

1.4.4.1 CONFIDENCE LIMITS

It is impossible to determine μ and σ from a limited set of measurements. We can use statistics to express the probability that the true value μ lies within a certain range of the measured average mean \overline{x} . That probability is called a **confidence limit** (CL) and is usually expressed as a percentage (e.g., the CL is 95 %). The term confidence limit refers to the extremes of the *confidence interval* (the range) about \overline{x} within which μ is expected to fall at a given CL.

When s is a good approximation for σ , we can state a CL for our results based on the Gaussian distribution. The CL is a statement of how close the sample mean lies to the population mean. For a single measurement we let $s = \sigma$. The CL is then the certainty that $\mu = x \pm z\sigma$. For example, if z = 1, we are 68.3 % confident that x lies within $\pm \sigma$ of the true value; if we set z = 2, we are 95.5 % confident that x lies within $\pm 2\sigma$ of the true value. For N measurements, the CL for $\mu = \overline{x} \pm zs_m$.

In most cases, s is not a good estimate of σ because we have not made enough replicate analyses. In this case, the CL is calculated using a statistical probability parameter, *Student's t*. The parameter t is defined as $t = (x - \mu)/s$ and the CL for $\mu = \overline{x} \pm ts/\sqrt{N}$. An abbreviated set of t values is given in Table 1.9; complete tables can be found in mathematics handbooks or statistics books.

As an example of how to use Table 1.9 and CLs, assume that we have made five replicate determinations of the pesticide DDT in a water sample using GC. The five results are given in the spreadsheet below, along with the mean and standard deviation. How do we report our results so that we are 95 % confident that we have reported the true value?

Α	В	c	D
Replicate sample	DDT conc. (ppb)		
1	1.3		
2	1.5		
3	1.4		
4	1.4		
5	1.3		
Mean	1.4		
Std. Dev.	0.08		
	1 2 3 4 5	1 1.3 2 1.5 3 1.4 4 1.4 5 1.3 Mean 1.4	1 1.3 2 1.5 3 1.4 4 1.4 5 1.3 Mean 1.4

	Stud		

Degrees of Freedom	t Value for Confidence Limit				
(<i>N</i> – 1)	90 %	95 %	99 %		
1	6.31	12.7	63.7		
2	2.92	4.30	9.92		
3	2.35	3.18	5.84		
4	2.13	2.78	4.60		
5	2.02	2.57	4.03		
6	1.94	2.45	3.71		
7	1.90	2.36	3.50		
8	1.86	2.31	3.36		
9	1.83	2.26	3.25		
10	1.81	2.23	3.17		
∞	1.64	1.96	2.58		

The number of determinations is five, so there are four degrees of freedom. The t value for the 95 %CL with N - 1 = 4 is 2.78, according to Table 1.9. Therefore:

95 %CL =
$$\overline{x} \pm \frac{ts}{\sqrt{N}}$$
 = 1.4 ± $\frac{2.78 \times 0.08}{5^{1/2}}$ = 1.4 ± 0.1

We are 95 % confident that the true value of the DDT concentration in the water sample is 1.4 ± 0.1 ppb, assuming no determinate error is present.

The Student's *t* value can be used to test for systematic error (bias) by comparing means of different determinations. The CL equation is re-written as:

$$\pm t = (\overline{x} - \mu) \frac{\sqrt{N}}{s}$$

By using a known, valid method, μ is determined for a known sample, such as a certified reference material. The values of \overline{x} and s are determined for the known sample using the new method (new instrument, new analyst, etc.). A value of t is calculated for a given CL and the appropriate degrees of freedom. If the calculated t value exceeds the value of t given in Table 1.9 for that CL and degrees of freedom, then a significant difference exists between the results obtained by the two methods, indicating a systematic error. Using the DDT data above, assume that we know that the true value of the DDT concentration is 1.38 ppb. A new analyst runs the five determinations and obtains a mean of 1.20 ppb and a standard deviation of 0.13. If we calculate t using Equation (1.16), we get t = (1.20 – 1.38)(5)t = -3.09. At 95 %CL, the absolute value of this calculated t is larger than the tabulated t for 4 degrees of freedom found in Table 1.9; i.e., 3.09 > 2.78. Therefore, a determinate error exists in the procedure as performed by the new analyst.

1.4.4.2 VARIANCE

Variance is defined as the square of the standard deviation, σ^2 . Variance is often preferred as a measure of precision because variances from m independent sources of random error are additive. The standard deviations themselves are not additive. The use of variance allows us to calculate the random error in the answer from mathematical calculations involving several numbers, each of which has its own associated random error. The total variance is the sum of the individual variances:

(1.17)
$$\sigma_{\text{tot}}^2 = \sum_{i=1}^m \sigma_i^2$$

TARIF 1.10 F Val	+ OF 0/ CI

$(N-1)_2$	$(N-1)_1$						
	2	4	6	8	10	20	
2	19.0	19.2	19.3	19.4	19.4	19.4	
4	6.94	6.39	6.16	6.04	5.96	5.80	
6	5.14	4.53	4.28	4.15	4.06	3.87	
8	4.46	3.84	3.58	3.44	3.35	3.15	
10	4.10	3.48	3.22	3.07	2.98	2.77	
20	3.49	2.87	2.60	2.45	2.35	2.12	

For addition and subtraction, the absolute variance, σ^2 , is additive. For multiplication and division, the relative variances are additive, where the relative variance is just the square of the standard deviation divided by the mean, $\sigma_{\text{rel}}^2 = (\sigma / \overline{x})^2$.

The square of the standard deviation, σ^2 , can also be used to determine if sets of data from two methods (analysts, instruments, etc.) are statistically significantly different from each other in terms of their precision. In this test, the variances of two sets of results are compared. The variance σ_2^2 of one set of results is calculated and compared with the variance σ_1^2 of earlier results, or the variance of a new method is compared with that of a standard method. The test is called the *F-test*. The ratio of the variances of the two sets of numbers is called the *F-function*:

$$(1.18) F = \frac{\sigma_1^2}{\sigma_2^2}$$

where $\sigma_1^2 > \sigma_2^2$ (i.e., the ratio should be greater than 1). Each variance has its associated degrees of freedom, $(N-1)_1$ and $(N-1)_2$. Tables of F values are found in mathematics handbooks or statistics books. An abbreviated table for the 95 %CL is given in Table 1.10. If the calculated value of F is larger than the tabulated value of F for the appropriate degrees of freedom and CL, then there is a significant difference between the two sets of data.

1.4.5 REJECTION OF RESULTS

When a set of replicate results is obtained, it may be the case that one of the results appears to be "out of line"; such a result is called an **outlier**. While it is tempting to discard data that does not "look good" in order to make the analysis seem more precise, it is never a good practice unless there is justification for discarding the result. If it is known that an error was made, such as spillage of the sample, use of the wrong size pipette, incorrect dilution, or allowing the sample to boil to dryness when it should not have been done so, the result should be rejected and not used in any compilation of results. In practice, if something of this sort is suspected, a good analyst will discard the sample and start over.

There are a variety of statistical tests that have been used to decide if a data point is an outlier, as well as some "rules of thumb". The range chosen to guide the decision will limit all of these tests and guidelines. A large range will retain possibly erroneous results, while a very small range will reject valid data points. It is important to note that the outlier must be either the highest value in the set of data or the lowest value in the set. A value in the middle of a data set cannot be discarded unless the analyst knows that an error was made.

One rule of thumb is that if the outlier value is greater than $\pm 4\sigma$ from the mean, it should be approached with caution. When calculating the mean and standard deviation, an outlier result should *not be* included in the calculation. After the calculation, the suspected result should be examined to see if it is more than 4σ from the mean. If it is outside this limit, it should be ignored under this rule; if it is within this limit, the value for σ should be recalculated with this result included in the calculation. It is not permissible to reject more

than one result on this basis. A suspected result should not be included in calculating σ . If it is included, it will automatically fall within 4σ because such a calculation includes this number. Other reference sources recommend an even smaller range for rejection, such as a 2.5σ limit.

A statistical test called the Q-test can be used effectively for small data sets (see the reference by Rorabacher). The Q-test at the 90 %CL is typically used. The data is arranged in order of increasing value. The range of the data is calculated, that is, the lowest value is subtracted from the highest value. The range is $x_n - x_1$. Then the "gap" is calculated, where the gap is defined as the difference between the suspect value and the nearest value, $x_n - x_{n-1}$. The Q ratio is defined as Q = gap/range. Using a table of Q values, if Q observed >Q tabulated, the suspect value is discarded. The Q-test cannot be used if all but one data point is the same in a set. For example, if triplicate results are 1.5, 1.5, and 3.0, you cannot discard the 3.0 value using statistics. It ultimately falls to the analyst to make the decision about rejecting data, but it should not be done lightly. Additional discussion on outlier determination can be found in the book by Bruno and Svoronos.

1.5 PERFORMING THE MEASUREMENT

To determine an analyte using an instrumental method of analysis, we must establish the relationship between the magnitude of the physical parameter being measured and the amount of analyte present in the sample undergoing the measurement. In most analyses, the measurement is made and then a calculation is performed to convert the result of the measurement into the amount of analyte present in the original sample. The calculation accounts for the amount of sample taken and dilutions required in the process of sample preparation and measurement.

In an instrumental method of analysis, a **detector** is a device that records a change in the system that is related to the magnitude of the physical parameter being measured. We say that the detector records a **signal**. If the detector is properly designed and operated, the signal from the detector can be related to the amount of analyte present in the sample through a process called **calibration**. Before we discuss calibration, we need to understand a little about what the detector is recording. A detector can measure physical, chemical, or electrical changes or signals, depending on its design. A **transducer** is a detector that converts nonelectrical signals to electrical signals (and vice versa). There are transducers used in spectroscopic instruments that convert photons of light into an electrical current, for example. Another term used in place of detector or transducer is **sensor**. The operation of specific detectors is covered in the chapters on the different instrumental methods.

1.5.1 SIGNALS AND NOISE

Instrumental analysis uses electronic equipment to provide chemical information about the sample. Modern instruments use semiconductor technology and computers to control the instrument, collect signals, process and report data. Fundamentals of modern instrument electronics are covered in the text by Malmstadt et al. listed in the bibliography.

All instruments measure some chemical or physical characteristic of the sample, such as how much light is absorbed by the sample at a given wavelength, the mass-to-charge ratio of an ion produced from the sample, or the change in conductivity of a wire as the sample passes over it. A detector of some type makes the measurement and the detector response is converted to an electrical signal. The electrical signal should be related directly to the chemical or physical property being measured and that should be related to the amount of analyte present. Ideally, the signal would represent only information related to the analyte. When no analyte is present, there should be no signal. For example, in Figure 1.13, we are looking at signals from a spectrometer that is measuring the amount of light emitted by a sample at a given wavelength. The three traces in Figure 1.13 show a **peak**, which is the signal at the emission wavelength. The response on either side of the peak is called the **baseline**.




FIGURE 1.13 Signal vs. Wavelength with different noise levels: **(a)** No detectable noise, **(b)** Moderate noise, and **(c)** High noise.

An ideal signal for intensity of light emitted by the analyte vs. wavelength would be a smooth baseline when no light is emitted and a smooth peak at the emission wavelength, as shown in Figure 1.13(A). In this case, when the instrument does not detect the analyte, there is no signal, represented by the flat baseline. The signal increases when the instrument detects the analyte. The signal decreases back to the baseline when the instrument no longer detects the analyte. In this case the entire signal (the peak) is attributed to the analyte. In practice, however, the recorded signal and baseline are seldom smooth, but include random signals called **noise**. All measured signals contain the desired information about the analyte and undesirable information, including noise. Noise can originate from small fluctuations of various types in the instrumentation, in the power provided to the instrument, from external sources such as TV and radio stations, other instruments nearby, building vibrations, electrical motors and similar sources, and even from fundamental quantum effects that cannot be eliminated. Provided that the signal is sufficiently greater than the noise, it is not difficult to make a reliable measurement of the desired analyte signal. The **signal-to-noise ratio**, *S/N*, is a useful quantity for comparing analytical methods or instruments.

In Figure 1.13(b), the noise level is increased over that in Figure 1.13(a) and is superimposed on the signal. The value of the signal is less certain as a result of the noise. The measurement is less precise, but the signal is clearly discernible. In Figure 1.13(c), the noise level is as great as the signal, and it is virtually impossible to make a meaningful measurement of the latter. It is very important to be able to separate data-containing signals from noise. When the signal is very weak, as it might be for trace amounts of analyte, the noise must be reduced or the signal enhanced. Noise is random in nature; it can be either positive or negative at any given point, as can be seen in Figure 1.13(b) and (c). Because noise is random, it can be treated statistically.

If we consider the signal S to be our measured value, then the noise N is the variation in the measured value when repeat measurements of the same sample are made. That is, the noise can be defined as the standard deviation s of repeat measurements; the signal S is then the average value of the measurement, \overline{x} . Making the repeat measurements at the peak maximum would provide the best estimate of the signal-to-noise ratio at the exact point we want to measure, but there are some difficulties associated with this approach. One is that the noise measured at the peak maximum may be hard to detect, as a small variation in a large signal is more difficult to measure than a large variation in a small signal. A second problem is that the signal-to-noise ratio will be dependent on the size of the signal if measured at the peak maximum. In practice, the noise is often measured along the baseline where the signal

should be zero, not at the peak maximum. The effect of noise on the relative error of the measurement decreases as the signal increases.

$$\frac{S}{N} = \frac{\overline{x}}{s} = \frac{\text{mean}}{\text{std. dev.}}$$

There are several types of noise encountered in instrumental measurements. The first is **white noise**, the random noise seen in Figure 1.13(b) and (c). White noise can be due to the random motions of charge carriers such as electrons; the random motion results in voltage fluctuations. This type of white noise is called *thermal noise*. Cooling the detector and other components in an instrument can reduce thermal noise. A second type of white noise is *shot noise*, which occurs when charge carriers cross a junction in an electric circuit. **Drift** or **flicker noise** is the second major type of instrumental noise. It is inversely proportional to the frequency of the signal being measured and is most significant for low frequencies. The origin of drift or flicker noise is not well understood. The third type of instrumental noise is that due to the surroundings of the instrument, such as the line noise due to the power lines to the instrument or building vibrations. Some of this type of noise is frequency dependent and may occur at discrete frequencies.

Improvement in *S/N* requires that the signal be different from the noise in some way. Most differences can be expressed in terms of time correlation or frequency. To increase *S/N*, either the noise must be reduced or the signal enhanced, or both must occur. There are a variety of hardware and software approaches to reduce noise in instruments. External sources of noise can be eliminated or reduced by proper grounding and shielding of instrument circuits and placement of instruments away from drafts, other instruments, and sources of vibration. The intrinsic noise can be reduced using a variety of electronic hardware such as lock-in amplifiers, filters, and signal modulators. Signals can be enhanced by a variety of computer software programs to perform signal averaging, Fourier transformation, filtering, and smoothing. Many of these software manipulations are applied after the data has been collected. Many of the hardware methods for reducing noise have been replaced by computer software methods, since even simple instruments now put out data in digital form. The discussion of analog to digital conversion and details of methods for *S/N* enhancement are beyond the scope of the text; the references by Enke or Malmstadt et al. can be consulted for details.

Signal averaging is one way to improve S/N; repetitive measurements are made and averaged. In this instance, advantage is taken of the fact that noise is random but the signal is additive. If a signal, such as that shown in Figure 1.13(b), is measured twice and the results added together, the signal will be twice as intense as the first measurement of the signal. If n measurements are made and added together, the signal will be n times as intense as the first signal. Because noise is random, it may be positive or negative at any point. If n measurements are added together, the noise increases only as the square root of n, or $n^{1/2}$. Since S increases by a factor of n, and N increases by $n^{1/2}$, S/N increases by $n/n^{1/2} = n^{1/2}$. Averaging multiple signal measurements will improve the signal-to-noise ratio by a factor of $n^{1/2}$ as shown in Figure 1.14. To improve the S/N ratio by 10, about 100 measurements must be made and averaged. The disadvantage to signal averaging is the time required to make many measurements. Some instrumental methods lend themselves to rapid scanning, but others such as chromatography do not.

Instruments that use Fourier transform (FT) spectroscopy, introduced in Chapter 2, collect the entire signal, an interferogram, in a second or two. Hundreds of measurements can be made, stored by a computer and averaged by an FT instrument very quickly, greatly improving the signal-to-noise ratio using this approach. The FT approach discriminates signal from noise based on frequency. An FT is a mathematical transformation that converts a variable measured as a function of time, f(t), into a function of reciprocal time, f(1/t). A function of reciprocal time is also a function of frequency. The FT permits the removal of noise that differs in frequency from the signal and also permits enhancement of frequencies associated with the signal. FT and a related algorithm, the fast Fourier transform (FFT) are now available as part of many data handling software packages. (FFT is an algorithm for efficiently computing FT.)




FIGURE 1.14 Improvement in the signal-to-noise ratio by averaging multiple signal measurements.

The use of FT is required to process data from experiments based on interferometry, such as FT-IR spectroscopy (Chapter 4), from pulsed NMR experiments (FT-NMR, Chapter 5), and the signal pulses from cyclotron resonance MS experiments (FT-MS, Chapter 9).

The signal-to-noise ratio is a limiting factor in making analytical measurements. It is theoretically possible to measure any signal in any noise level, provided the measurements are taken over a long enough period of time or repeated enough times to accumulate the signal. In practice, there is usually a limitation on the number of measurements that can be made, owing to factors such as time, cost, amount of sample, and the inherent limitations of the instrument. If many measurements are made over too long a period of time, other sources of error may occur in the measurement and these types of errors may not be random.

1.6 METHODS OF CALIBRATION

Calibration is the process of establishing the relationship between the signals measured and known concentrations of analyte. Once this relationship is established, it is possible to calculate the concentration of the analyte in an unknown sample by measuring its signal. The calibration methods discussed subsequently are applicable to most of the analytical instrumental methods discussed in this text. Modern instruments have software packages that fit the data points to the best-fit line or curve statistically, display the results on the computer screen and send them to the printer. Computerized data collection and processing greatly reduces *transcription error*, the copying of the wrong figures into a notebook. The use of linear regression and other curve-fitting approaches provides greater accuracy and precision in the calibration equation and in sample results calculated from the equation. The calibration methods discussed subsequently are used in chromatography, spectroscopy, mass spectrometry, and electroanalytical chemistry as appropriate.

1.6.1 PLOTTING CALIBRATION CURVES

For many techniques, calibration standards with a range of known concentrations are prepared and a signal is measured for each concentration. The magnitude of the signal for each standard is plotted against the concentration of the analyte in the standard and the equation that relates the signal and the concentration is determined. Once this relationship, called a **calibration equation or calibration curve**, is established, it is possible to calculate the concentration of the analyte in an unknown sample by measuring its signal and using the

equation that has been determined. The calibration curve is a plot of the sets of data points (x_i, y_i) , where x is the concentration or amount of analyte in the standards and y is the signal for each standard. Many calibration curves are straight-line relationships or have a linear region, where the concentration of analyte is related to the signal according to the equation y = mx + b. The slope of the line is m and the intercept of the line with the y-axis is b. Determining the proper calibration curve is critical to obtaining accurate results. We have already learned that all measurements have uncertainty associated with them. The calibration curve also has uncertainty associated with it. The most accurate way to determine the calibration curve is to use the statistical programs on a calculator, in a spreadsheet, or in an instrument's computer data system to plot calibration curves and determine the equation that best fits the data. The use of graphing calculators, computerized data handling, and spreadsheets also permits the fitting of nonlinear responses to higher order equations accurately.

We will assume that the errors in the measured signal, y, are significantly greater than any errors in the known concentration, x. In this case, the best-fit straight line is the one that minimizes vertical deviations from the line. This is the line for which the sum of the squares of the deviations of the points from the line is the minimum. This fitting technique is called the **method of least squares**. For a given x_i , y_i , and the line y = mx + b, the vertical deviation of y_i from $y = (y_i - y)$. Each point has a similar deviation, so the sum of the squares of the deviations is:

(1.20)
$$D = \sum (y_i - y)^2 = \sum [y_i - (mx_i + b)]^2$$

To obtain the slope m and the intercept b of the best-fit line requires the use of calculus and the details will not be covered in this text. The results obtained are:

(1.21)
$$m = \frac{n \sum x_i y_i - \sum x_i \sum y_i}{n \sum x_i^2 - (\sum x_i)^2}$$

$$(1.22) b = \overline{y} - m\overline{x}$$

Expressions for the uncertainty in the measured value, *y*, in the slope, and in the intercept are similar to the expressions for the standard deviation [Eq. (1.12)]. Two degrees of freedom are lost in the expression for the uncertainty in *y*, because both the slope and intercept have been defined.

(1.23)
$$s_{y} = \sqrt{\frac{\sum_{i=1}^{N} d^{2}}{N-2}} = \sqrt{\frac{\sum_{i=1}^{N} (y_{i} - mx + b)^{2}}{N-2}}$$

$$(1.24) s_m = \sqrt{\frac{s_y^2}{\sum (\overline{x} - x_i)^2}}$$

(1.25)
$$s_b = s_y \sqrt{\frac{1}{N - (\sum x_i)^2 / \sum x_i^2}}$$

Equation (1.23) defines the uncertainty in y, s_y ; Eq. (1.24) gives the uncertainty in the slope, s_m , and Eq. (1.24) gives the uncertainty in the intercept, s_b . The uncertainty in x_i is calculated using all the associated variances, as has been discussed in Section 1.4.4. The use of a spreadsheet program such as Microsoft Excel® to plot a calibration curve eliminates the need to do manual calculations for least squares and the associated statistics. The Excel program permits the calculation of the best-fit equation using linear least squares regression (as well as many nonlinear curve fitting routines). The program also calculates the **correlation coefficient**, r, for the line. A correlation coefficient with a value of 1 means that there is a direct

relationship between x and y; the fit of the data to a straight line is perfect. A correlation coefficient of 0 means that x and y are completely independent. The range of the correlation coefficient is from 1 to -1. Most linear calibration curves should have a correlation coefficient of 0.99 or greater. Statistics programs usually calculate the square of the correlation coefficient, r^2 , which is a more realistic measure of the goodness-of-fit of the data. It is always a good idea to plot the data graphically so that it can be looked at, to ensure that the statistical calculations are not misleading about the goodness-of-fit.

Modern computerized analytical instruments have quantitative analysis programs that allow the analyst to specify the calibration standard concentrations, select the curve-fitting mode, and calculate the results of the samples from the calibration curve equation. Many of these programs will rerun outlier standards and samples automatically, flag suspect data, compute precision and recovery of spikes, track reference standards for quality control, and perform many other functions that used to be done manually by the analyst.

1.6.2 CALIBRATION WITH EXTERNAL STANDARDS

The relationship between the signal from the detector (absorbance, peak height, peak area, current, etc.) and the concentration of the analyte must be established. Solutions containing known concentrations of analyte are called **standard solutions** or more simply, **standards**. For some types of analyses, the standards may be in the form of solids or gases.

Standards must be prepared accurately from high purity materials so that the concentration of analyte is known as accurately as possible. A series of standards covering an appropriate concentration range is prepared. The standards should include one solution with no added analyte; the concentration of analyte in this standard is zero. This solution is called the reagent blank and accounts for absorbance due to impurities in the solvent and other reagents used to prepare the samples. It also accounts for the instrumental baseline. The signals from the reagent blank and each standard are measured. The signal of the reagent blank is subtracted from the signals of the other standards before any calculations are performed. In many instruments, the blank value is automatically set to zero. The signals from which the blank has been subtracted are called "corrected signals". A plot is made of corrected signal on the *y*-axis vs. the known concentration of the standard on the *x*-axis by the instrument software. Preparing a calibration curve by making a series of standards of known concentrations of analyte, is called external calibration or calibration with external standards.

A typical calibration curve of this type is shown in Figure 1.15. This calibration curve shows the relationship between the absorbance of n-hexadecane, $CH_3(CH_2)_{14}CH_3$, a hydrocarbon found in petroleum, at 3.41 μ m in the IR region and concentration of solutions of




FIGURE 1.15 A typical external calibration curve for quantitative absorption spectrometry. The relationship between concentration and absorbance is linear.

TABLE 1.11 Calibration Data for Measurement of Petroleum Hydrocarbons by IR Absorption Spectrometry

Concentration of <i>n</i> -Hexadecane (mg/100 mL solution)	Absorbance at 3.41 μm	Corrected Absorbance
(mg/ roo me solution)	Absorbance at 5.41 µm	Corrected Absorbance
0.0	0.002	0.000
4.0	0.103	0.101
8.0	0.199	0.197
16.0	0.400	0.398
32.0	0.804	0.802

n-hexadecane in tetrachloroethylene, C_2Cl_4 . This measurement of the absorbance of solutions of n-hexadecane at 3.41 μm is a method used for determining petroleum contamination in water, soil, and other environmental samples, because most hydrocarbons absorb at this wavelength. It is an official method, Method 8440, developed by the US EPA (www.epa. gov) and relies on a linear relationship between absorbance and concentration (Beer's Law, discussed in Chp. 2) to permit the measurement of petroleum hydrocarbons in unknown samples. It is used to measure environmental contamination from oil spills, illegal dumping of oil, and leaking underground oil storage tanks.

Table 1.11 gives the values of the concentration and the measured and corrected absorbance for each standard. It is clear from Figure 1.15 that the relationship between absorbance and concentration for this measurement results in a straight line (y = mx + b, where y is the absorbance and x is the concentration). Once the points have been plotted, the best straight line is fitted through the data points by linear regression (linear least squares) using a statistical program on your calculator or using a computer spread-sheet program such as Excel.

Performing a linear regression on the data in Table 1.11 provides us with the exact relationship for this method: A = 0.0250x - 0.001, where x is the concentration of n-hexadecane in mg/100 mL. From the equation for the calibration curve, the concentration can be determined for any measured absorbance. For example, an unknown sample of contaminated soil is prepared according to US EPA Method 8440, and the absorbance of the sample solution is measured. The measured absorbance is 0.302, so the corrected absorbance would be 0.302 - 0.002 = 0.300. From our calibration curve, we can see visually that this corresponds to a concentration of ~12.0 mg n-hexadecane/100 mL. The exact concentration can be calculated from the linear regression equation, and is found to be 11.96 mg/100 mL or 12.0 mg/100 mL rounded to three significant figures.

Suppose that, in addition to the standards listed in Table 1.11, we also prepared n-hexadecane standards containing 60.0 mg n-hexadecane/100 mL solution and 100.0 mg n-hexadecane/100 mL solution. If we measure the absorbances for these standards, we obtain the data shown in Table 1.12. The additional points, shown as open circles, are plotted along with the original

TABLE 1.12 Calibration Data for Measurement of Petroleum
Hydrocarbons by IR Absorption Spectrometry (Higher
Concentration Standards Added)

Concentration of <i>n</i> -hexadecane		
mg/100 mL Solution)	Absorbance at 3.41 μ m	Corrected Absorbance
0.0	0.002	0.000
4.0	0.103	0.101
8.0	0.199	0.197
16.0	0.400	0.398
32.0	0.804	0.802
60.0	1.302	1.300
100.0	1.802	1.800




FIGURE 1.16 A calibration curve showing deviation from linearity at high concentrations (high absorbance values). The open circles are the measured absorbance values for the standards and clearly deviate from linearity above a = 0.8. The black squares show the expected absorbance values if all standards followed the equation calculated from table 1.11. The higher points were obtained by extrapolation of the linear portion of the Table 1.11 curve.

standards in Figure 1.16. Clearly, we now see a deviation from linearity at these high concentrations. The measured absorbances are lower than they should be. This shows why it is never a good idea to extrapolate (extend) a calibration curve beyond the range of the measured standards. If we had a sample with an absorbance of 1.30 (just like our 60.0 mg/100 mL standard) and had used our original calibration curve extrapolated to higher absorbances as shown by the black squares in Figure 1.16, we would calculate a concentration of 51.9 mg/100 mL for the unknown, which would be erroneously low. What should you do if you have absorbances that are above the absorbance of the highest linear standard (in this case, above A = 0.802)? The best approach is to dilute the samples. Dilute the 60.0 mg/100 mL standard by a factor of 10, by taking 10.0 mL of the solution and diluting it with pure solvent to a total volume of 100 mL in a volumetric flask. Measuring the absorbance of the diluted solution, you find that the corrected absorbance = 0.153. The corresponding concentration is determined to be 6.07 mg/100 mL. Multiplied by 10 to account for the dilution, the original solution is calculated to contain 60.7 mg/100 mL, and you know that this is a reasonably accurate answer because you made up the standard to contain 60.0 mg/100 mL. So, if you take the unknown sample solution with an absorbance of 1.30, dilute it by a factor of 10, and measure the absorbance of the diluted solution, you should get an accurate result for the sample as well.

1.6.3 METHOD OF STANDARD ADDITIONS

An alternate method of calibration is the Method of Standard Additions (MSA) calibration. This calibration method requires that known amounts of the analyte be added directly to the sample, which contains an unknown amount of analyte. The increase in signal due to the added analyte (e.g., absorbance, emission intensity, peak height or area, etc.) permits us to calculate the amount of analyte in the unknown. For this method of calibration to work, there must be a linear relationship between the concentration of analyte and the signal.

MSA is often used if no suitable external calibration curve has been prepared. There may be no time to prepare calibration standards. It may not be possible to prepare a valid set of calibration standards because of the complexity of the sample matrix or due to lack of sufficient information about the sample. Industries often require the analysis of "mystery" samples when something goes wrong in a process. MSA calibration is very useful when certain

types of interferences are present in the sample matrix. "Matrix effects" cause reductions or enhancements of the signal from the analyte due to other components in the sample. The MSA method was developed in 1955 to overcome matrix effects in the determination of Sr in seawater. MSA permits us to obtain accurate results without removing the interferences by performing the calibration in the presence of the interferences. It is often used when only one sample must be analyzed, and the preparation of external standards would be inefficient. It can be used in a wide variety of techniques, such as spectroscopy, mass spectrometry and chromatography.

A typical example of the use of MSA is the determination of sodium by atomic emission spectrometry in an industrial plant stream of unknown composition. A representative sample of the plant stream is taken and spilt into four aliquots of 100 mL each. The first aliquot is left untreated; this is called the "no add" or "zero add" sample. To the second aliquot, 100 μg Na is added to the 100 mL sample in such a way as to not change the volume significantly. This can be done by adding a 10 μL volume of a 10,000 ppm Na solution to the sample. A 10,000 ppm Na solution contains 10,000 μg Na/mL, so a 10 μL portion contains 100 μg Na as shown:

$$\left(\frac{10,000 \text{ } \mu\text{gNa}}{\text{mLsolution}}\right)\left(\frac{1 \text{ } mL}{1000 \text{ } \mu\text{L}}\right) \times 10 \text{ } \mu\text{L} = 100 \text{ } \mu\text{g Na}$$

The second sample aliquot now contains an additional 1.0 ppm Na, since 100 µg Na/100 mL equals 1.0 ppm Na. To the third aliquot, we add 0.020 mL of the 10,000 ppm Na solution; the third aliquot now contains an additional 2.0 ppm Na. To the fourth aliquot, an addition of 0.030 mL of the 10,000 ppm Na solution results in an additional 3.0 ppm Na in the sample aliquot. The maximum change in volume caused by the addition of Na solution is only 0.03 %, an insignificant amount. It is important not to change the volume of the aliquots because a change in volume will cause a change in the concentration-signal relationship. All of the aliquots, untreated and the ones to which additions have been made, must have the same composition or MSA calibration will not produce accurate results. The concentrations of Na added and the sample aliquot numbers are listed in Table 1.13. The emission intensity for each of the four sample aliquots is measured at the 589.0 nm sodium emission line, using flame atomic emission spectrometry. The intensities measured are also listed in Table 1.13. In addition, the emission intensity from the flame is measured with no sample present. This measures the "background emission"—a positive signal from the flame not due to the sample. The background emission signal must be subtracted from the sample intensities, just as a reagent blank is subtracted as we discussed earlier, to obtain the corrected intensities shown in Table 1.13. We will learn more about background emission from flames in Chapter 6 and 7.

The corrected emission intensity is plotted vs. added Na concentration. The quantity $(\Delta I_{\rm emission}/\Delta \ {\rm ppm}\ {\rm Na}\ {\rm added})$ is the **slope** of the addition calibration line and is obtained by a linear regression calculation. In this case,

$$\frac{\Delta I_{\text{emission}}}{\Delta \text{ ppm Na added}} = \frac{1.3}{1.0 \text{ ppm Na}}$$

TABLE 1.13	MSA Calibration		
Sample Aliquot	Emission Intensity (Intensity Units)	Corrected Intensity (Intensity Units)	ppm Na Added
1	2.9	2.4	0.0
2	4.2	3.7	1.0
3	5.5	5.0	2.0
4	6.8	6.3	3.0
Background	0.5	0.0	




FIGURE 1.17 Determination of the concentration of analyte by extrapolation of the MSA curve to the negative *x* intercept. The *y*-axis shows corrected emission intensity.

The emission intensity increases by 1.3 units for every 1.0 ppm Na present. Therefore, the concentration of Na in the untreated sample is calculated from the following equation:

ppm Na_{sample} =
$$\frac{R}{\text{slope}}$$
 = $R(\text{slope})^{-1}$

where R = the corrected intensity measurement for sample aliquot 1, and the slope = $(\Delta I_{emission}/\Delta \text{ ppm Na added})$. For our example, the Na concentration in the plant stream is:

$$ppm \, Na_{sample} = 2.4 \, \, intensity \, units \times \frac{1.0 \, pm \, Na}{1.3 \, \, intensity \, units}$$

$$ppm \, Na_{sample} = 1.85 \, ppm$$

Alternatively, the addition calibration curve may be extrapolated to the intercept on the negative x-axis using the linear regression equation determined. The concentration of sodium in the sample is equal to the absolute value of the negative x intercept. The extrapolation is shown in Figure 1.17. The -x intercept occurs at -1.85, therefore the concentration of Na in the sample is |-1.85 ppm |=1.85 ppm Na.

The MSA is a very powerful tool for obtaining accurate analytical results when it is not possible to prepare an external calibration curve. In some cases, it permits accurate results to be obtained even in the presence of interfering substances. MSA will not correct for background emission or background absorption, or other **spectral interferences**. These interferences and methods for correcting for background will be discussed in the appropriate later chapters.

While the use of a one-point addition may be required if sample is limited, it is generally a good practice to make at least two additions whenever possible, to confirm that the additions are within the linear range of the analysis method.

1.6.4 INTERNAL STANDARD CALIBRATION

An **internal standard** is a known amount of a non-analyte element or compound that is added to all samples, blanks, and standard solutions. Calibration with internal standardization is a technique that uses the signal from the internal standard element or compound to

correct for interferences in an analysis. Calibration with internal standardization improves the accuracy and precision of an analysis by compensating for several sources of error.

For determination of analyte A, an internal standard S, which must not be present in the samples, is selected. The same concentration of S is added to all samples, standard solutions, and blanks. The signals due to both A and S are measured. The ratio of the signal due to the analyte A to the signal due to the internal standard S is calculated. The signal ratio, signal_A/ signal_S, is plotted against the concentration ratio of A/S in the standards. The equation of the calibration curve, which should be linear for best results, is obtained by linear regression. The equation permits the calculation of the concentration ratio A/S in any unknown samples by measuring the signal of A and S in the sample.

The relationship between concentration and signal may be expressed as follows:

 $\frac{\text{Concentration ratio (A/S) in sample}}{\text{Concentration ratio (A/S) in standard}} = \frac{\text{signal ratio (A/S) in sample}}{\text{signal ratio (A/S) in standard}}$

The method of internal standardization is widely used in spectroscopy, chromatography, MS, and other instrumental methods. The use of internal standards can correct for losses of analyte during sample preparation, for mechanical or electrical "drift" in the instrument during analysis, for volume change due to evaporation and other types of interferences. The internal standard must be chosen carefully, usually so that the chemical and physical behavior of the internal standard is similar to that of the analyte. The internal standard must not interact chemically or physically with the analyte. Whatever affects the signal from the analyte should affect the signal from the internal standard in the same way. The ratio of the two signals will stay constant, even if the absolute signals change; this provides more accuracy and precision than if no internal standard is used.

The determination of lead in drinking water by ICP-MS demonstrates how an internal standard can correct for a problem such as "instrumental drift", that is, a change in the signal over a period of time. The signal for the Pb-208 isotope (208Pb) is monitored to determine lead. Two lead calibration standards are prepared, each containing 10.0 ppb Pb. One standard also contains 20.0 ppb bismuth as an internal standard. The Bi signal is measured at the Bi-209 isotope, along with the Pb-208 signal. Both standards are measured several times during the day and the resulting signals are listed in Table 1.14. The signals for both Pb and Bi fluctuate during the day; such fluctuations could be due to changes in electrical line voltage to the instrument, for example. However, as the last column shows, the ratio of the analyte signal to the internal standard signal stays constant throughout the day. If the ICP-MS were calibrated without using an internal standard at 8 AM, samples run at 1 PM would give erroneously high Pb concentrations, because the signal for a given amount of lead has increased by a factor of 2.5. At 3 PM, samples would be approximately 30 % higher than the true value. If 20.0 ppb Bi had been added to all the standards and samples, the ratio of the Pb signal/Bi signal would have remained constant and an accurate lead concentration would be determined.

Two drinking water samples, one with no internal standard and one to which 20.0 ppb Bi has been added as internal standard, are measured throughout the day. The signals obtained

TABLE 1.14	Use of In	ternal Stand	lard in Ca	ilibration
-------------------	-----------	--------------	------------	------------

	Signal Counts ^a 10 ppb	Signal Counts 20 ppb	
Time of Measurement	Pb, $m/e = 208$	Bi, $m/e = 209$	Ratio of Counts Pb/Bi
8 AM	12,050	60,000	0.2008
10 AM	12,100	60,080	0.2013
1 PM	30,000	149,200	0.2010
3 PM	15,750	78,400	0.2009

^a Both standards give the same signal for Pb, so only one column is shown. The counts for bismuth are from the second standard only.

	TABLE 1.15	ter with and without Internal Standard	ł
--	-------------------	--	---

Time of Measurement	Pb Counts, m/e = 208	ppb Pb, no Internal standard	Pb Counts, m/e = 208	Bi Counts, m/e = 209	Ratio of Counts: Pb/Bi	ppb Pb, with Internal Standard
8 AM	6,028	5.00	6,028	60,010	0.1004	5.00
10 AM	6,063	5.03	6,063	60,075	0.1009	5.02
1 PM	15,010	12.5	15,010	149,206	0.1006	5.01
3 PM	7,789	6.46	7,789	78,398	0.0994	4.95
Mean		7.25				4.99
SD		3.57				0.03
%RSD		49.2				0.60
True value		5.00				5.00
%Error		45.0				-0.2

Note: SD = standard deviation, % RSD = % relative standard deviation = $(SD/\text{mean}) \times 100$.

are given in Table 1.15. At 8 AM, the Pb signal is equal to 6028 counts, so the concentration of Pb in the water may be calculated from our calibration factor for lead with no internal standard from Table 1.14:

ppb Pb in sample =
$$(6028 \text{ counts}) \frac{10.0 \text{ ppb Pb}}{12,050 \text{ counts}}$$

ppb Pb in sample = 5.00 ppb Pb

This is the true value for lead in the water sample. The rest of the concentrations using the lead signal only are calculated the same way and the results are shown in the third column of Table 1.15. Due to the instrument "drift", the results obtained at 1 PM and 3 PM are clearly in error. The 1 PM sample has a signal equal to 15,010 counts for Pb. The concentration is calculated using the lead calibration factor:

ppb Pb in sample =
$$(15,010 \text{ counts}) \frac{10.0 \text{ ppb Pb}}{12,050 \text{ counts}}$$

ppb Pb in sample = 12.5 ppb Pb

The percent error in this result due to instrumental drift is calculated:

% Error =
$$\frac{\text{measured value - true value}}{\text{true value}} \times 100$$
% Error =
$$\frac{12.5 - 5.00}{5.00} \times 100$$
% Error = +150

If the Bi internal standard signal is used and the ratio of the Pb signal to the Bi signal is calculated, the internal standard calibration factor is obtained:

10.0 ppb Pb =
$$\frac{12,050 \text{ counts Pb}}{60,000 \text{ counts Bi}} = 0.2008$$

The sample run at 8 AM also contained Bi as an internal standard and the counts for Pb and Bi are shown in Table 1.15. The ratio of the sample Pb counts to the sample Bi counts is

6028 counts Pb/60,010 counts Bi = 0.1004. The Pb concentration in the sample is obtained as follows:

ppb Pb in sample =
$$(0.1004)$$
 $\frac{10.0 \text{ ppb Pb}}{0.2008}$
ppb Pb in sample = 5.00 ppb Pb

This is the same result obtained without in internal standard. If the internal standard ratio is used for all of the samples run during the day, the instrument "drift" is taken into account and the correct results are obtained. For example, at 1 PM, the sample Pb counts are 15,010 and the sample Bi counts are 149,206. These are clearly much higher than the counts obtained at 8 AM, but the ratio of Pb counts to Bi counts is 15,010/149,206 = 0.1006, and the calculated Pb concentration in the 1 PM sample is:

ppb Pb in sample =
$$(0.1006)$$
 $\frac{10.0 \text{ ppb Pb}}{0.2008}$
ppb Pb in sample = 5.01 ppb Pb

The percent error in this result is

$$\% Error = \frac{5.01 - 5.00}{5.00} \times 100$$

$$\% Error = 0.2$$

An error of 0.2 % is well within the expected accuracy for an instrumental method.

Compare this correct result to the 12.5 ppb Pb result at 1 PM calculated with no internal standard correction and the importance of using an internal standard when possible is clear.

1.7 ASSESSING THE DATA

A good analytical method should be both precise and accurate; that is, it should be reliable or robust. A robust analytical method is one that gives precise and accurate results even if small changes are made in the method parameters. The robustness of a method is assessed by varying the parameters in the analysis such as temperature, pH, reaction time, and so on, and observing the effect of these changes on the results obtained. The specificity of a method refers to the ability of the method to determine the analyte accurately in the presence of interferences. Method development should include checking the response of the method to other chemicals known to be in the sample, to possible degradation products, and to closely related compounds or elements. Ideally, the analytical method would be specific for only the analyte of interest. It is possible that analytical methods published in the literature may appear to be valid by a compensation of errors; that is, although the results appear accurate, the method may have involved errors that balanced each other out. When the method is used in another laboratory, the errors may differ and not compensate for each other. A net error in the procedure may result. This is an example of a method that is not reliable or robust. It is always prudent to run known reference samples when employing a method from the literature to evaluate its reliability.

The **sensitivity** of an analytical method can be defined as the slope of the calibration curve, the ratio of change in the instrument response with a change in the analyte concentration. Other definitions are also used. In AAS, sensitivity is defined as the concentration of analyte that produces an absorbance of 0.0044 (an absorption of 1 %), for example. When the term sensitivity is used, it should be defined.

Once the relationship between the signal and analyte concentration (i.e., the calibration curve) has been established, the linear working range of the method can be determined. The range is that interval between (and including) the lowest and highest analyte concentrations that have been demonstrated to be determined with the accuracy, precision, and linearity of the method. Linear working ranges vary greatly among instrumental methods, and may depend on the instrument design and the detector used, among other factors. Some instruments, such as a gas chromatograph with an electron capture detector or an atomic absorption spectrometer, have short linear ranges of one to two orders of magnitude. Other instruments, like ICP atomic emission spectrometers, may have linear ranges of five orders of magnitude, while mass spectrometers may be linear over nine orders of magnitude. All results should fall within the linear range of the method. This may require dilution of samples with analyte concentrations that are higher than the highest calibration standard in order to bring the signal into the known linear response region. Extrapolating beyond the highest standard analyzed is very dangerous because many signal-concentration relationships become nonlinear at high levels of analyte. Extrapolating below the lowest standard analyzed is also very dangerous because of the risk of falling below the limit of quantitation. If samples fall below the lowest calibration standard, they may need to be concentrated to bring them into the working range.

1.7.1 LIMIT OF DETECTION

All measurements have noise; the magnitude of the noise limits the amount of analyte that can be detected and measured. As the concentration of analyte decreases, the signal decreases. At some point, the signal can no longer be distinguished from the noise, so the analyte can no longer be "detected". Because of noise, it is not possible to say that there is no analyte present; it is only possible to establish a **detection limit**. Detection is the ability to discern a weak signal in the presence of background noise, so reducing the noise will permit the detection of smaller concentrations of analyte. The **limit of detection** (LOD) is the lowest concentration of analyte that can be detected. Detected does not mean that this concentration can be measured quantitatively; it only specifies whether an analyte is above or below a certain value, the LOD. One common approach to establishing the LOD is to measure a suitable number of replicates (8-10 replicates is common) of an appropriate blank or low concentration standard and determine the standard deviation of the blank signal. The blank measures only the background or baseline noise. The LOD is then considered to be the concentration of analyte that gives a signal that is equal to three times the standard deviation of the blank. This is equivalent to defining the LOD as that concentration at which the S/N ratio = 3 at 99 %CL.

(1.26)
$$LOD = \overline{x}_{blank} \pm 3\sigma_{blank}$$

The use of 3σ is now common and often specified by regulatory methods such as those of the US EPA; it results in an LOD with a 99 %CL. Other multiples of σ may be used as required, with a consequent change in the LOD.

There are other approaches used for calculating LODs; it is important to specify exactly how an LOD has been determined. A LOD can be defined by the instrument (using pure water for example); this would be the instrument detection limit (IDL). One can be defined for an entire analytical method including sample preparation. This would be the method detection limit (MDL). The MDL is in general not as low as an IDL, so it is important to know how the LOD has been defined. The calculated LOD should be validated by analyzing standards whose concentrations are below, at, and above the LOD. Any results from samples that fall below the established detection limit for the method are reported as "not detected" or as "<LOD". They should not be reported as numerical values except as "<the numerical value of the LOD"; for example, <0.5 ppb if the LOD is 0.5 ppb for this analysis.

1.7.2 LIMIT OF QUANTITATION

The precision of an analysis at or near the detection limit is usually poor compared with the precision at higher concentrations. This makes the uncertainty in the detection limit and in concentrations slightly above the detection limit also high. For this reason, many regulatory agencies define another limit, the **limit of quantitation** (LOQ), which is higher than the LOD and should have better precision.

The LOQ is the lowest concentration of analyte in a sample that can be determined quantitatively with a given accuracy and precision using the stated method. The LOQ is usually defined as that concentration equivalent to a signal-to-noise ratio of 10/1. The LOQ can also be determined from the standard deviation of the blank; the LOQ is 10× the standard deviation of the blank, expressed in concentration units. The LOQ is stated with the appropriate accuracy and precision and should be validated by running standards at concentrations that can confirm the ability of the method to determine analyte with the required accuracy and precision at the LOQ.

Analytical results that fall between the LOD and the LOQ should be reported as "detected but not quantifiable". These results are only estimates of the amount of analyte present since by definition they cannot be determined quantitatively.

PROBLEMS

- 1.1 a. Define determinate error and give two examples of determinate errors.
 - b. In preparing a sample solution for analysis, the pipette used actually delivered 4.92 mL instead of the 5.00 mL it was supposed to deliver. Would this cause determinate or indeterminate error in the analysis of this sample?
- 1.2 a. Define precision.
 - b. Do determinate errors affect precision?
- 1.3 a. Define accuracy.
 - b. How can the accuracy of an analytical procedure be determined?
- 1.4 a. What is the statistical definition of sigma (σ)?
 - b. What percentage of measurements should fall within $\pm 2\sigma$ of the true value for a data set with no determinate error, assuming a Gaussian distribution of random error?
- 1.5 Calculate the standard deviation of the following set of measured values: 3.15, 3.21, 3.18, 3.30, 3.25, 3.13, 3.24, 3.41, 3.13, 3.42, 3.19
- 1.6 The true mass of a glass bead is 0.1026 g. A student takes four measurements of the mass of the bead on an analytical balance and obtains the following results: 0.1021 g, 0.1025 g, 0.1019 g, and 0.1023 g. Calculate the mean, the average deviation, the standard deviation, the percentage relative standard deviation, the absolute error of the mean, and the relative error of the mean.
- 1.7 The following data set represents the results of replicate measurements of lead, expressed as ppm Pb. What are (a) the arithmetic mean, (b) the standard deviation, and (c) the 95 % confidence limits of the data?
 - 2.13, 2.51, 2.15, 2.17, 2.09, 2.12, 2.17, 2.09, 2.11, 2.12
 - (d) Do any of the data points seem "out of line" with the rest of the data? Are any point(s) outside the 4σ "rule of thumb" for rejecting suspect data? Should the suspect data be ignored in the calculation?
- 1.8 a. Explain the importance of good sampling.
 - b. Give three examples of precautions that should be taken in sample storage.
- 1.9 a. Illustrate the difference between precision and accuracy.
 - b. Do indeterminate errors affect precision or accuracy?
- 1.10 The results in Problem 1.7 were obtained for the lead content of a food sample. The recommended upper limit for lead in this food is 2.5 ppm Pb. (a) Are the results greater than 2.5 ppm Pb with 95 % confidence? (b) If the regulatory level is decreased

- to allow no more than 2.00 ppm Pb, is the Pb content of the food greater than 2.00 ppm with 95 % confidence?
- 1.11 The determination of Cu in human serum is a useful diagnostic test for several medical conditions. One such condition is Wilson's disease, in which the serum Cu concentration is lowered from normal levels and urine Cu concentration is elevated. The result of a single copper determination on a patient's serum was 0.58 ppm. The standard deviation σ for the method is 0.09 ppm. If the serum copper level is less than 0.70 ppm Cu, treatment should be started. Based on this one result, should the doctor begin treatment of the patient for low serum copper? Support your answer statistically. If the doctor were unsure of the significance of the analytical result, how would the doctor obtain further information?
- 1.12 With what confidence can an analytical chemist report data using σ as the degree of uncertainty?
- 1.13 The mean of eight replicate blood glucose determinations is 74.4 mg glucose/100 mL blood. The sample standard deviation is 1.8 mg glucose/100 mL blood. Calculate the 95 % and the 99 % confidence limits for the glucose concentration.
- 1.14 An analysis was reported as 10.0 with $\sigma = 0.1$. What is the probability of a result occurring within (a) ± 0.3 or (b) ± 0.2 of 10.0?
- 1.15 Name the types of noise that are frequency dependent. Which types of noise can be reduced by decreasing the temperature of the measurement?
- 1.16 The following measurements were obtained on a noisy instrument:1.22, 1.43, 1.57, 1.11, 1.89, 1.02, 1.53, 1.74, 1.83, 1.62(a) What is the signal-to-noise ratio, assuming that the noise is random? (b) How many measurements must be averaged to increase the *S/N* to 100?
- 1.17 Estimate the *S/N* ratio in Figure 1.13(b) and (c). What is the improvement in *S/N* from c to b? If the *S/N* value in c is the result of one measurement, how many measurements must be made and averaged to achieve the *S/N* value in b?
- 1.18 The tungsten content of a reference ore sample was measured both by X-ray fluorescence (XRF) spectrometry, the standard method, and by inductively coupled plasma-atomic emission spectrometry (ICP). The results as weight percent tungsten are given in the following table. Are the results of the two methods significantly different at the 95 % confidence level? Is there any bias in the ICP method? (*Hint*: The standard method can be considered to have a mean = μ .)

Replicate number	XRF	ICP
1	3.07	2.92
2	2.98	2.94
3	2.99	3.02
4	3.05	3.00
5	3.01	2.99
6	3.01	2.97

- Assuming that the results of many analyses of the same sample present a Gaussian distribution, what part of the curve defines the standard deviation σ ?
- 1.20 A liquid sample is stored in a clear glass bottle for the determination of trace metals at the ppm level. What factors can cause the results to be (a) too low or (b) too high?
- 1.21 Nitrate ion in potable water can be determined by measuring the absorbance of the water at 220 nm in a UV/VIS spectrometer. The absorbance is proportional to the concentration of nitrate ion. The method is described in Standard Methods for Analysis of Water and Wastewater listed in the bibliography. Calibrations standards were prepared and their absorbances measured. The results are given in the following table. (*Note*: the absorbance of the blank, the 0.0 mg nitrate/L "standard" was set to

0.000 in this experiment. A nonzero blank value is subtracted from all the standards before the calibration curve is plotted and the equation calculated.)

Nitrate ion (mg/L)	Absorbance
0.00	0.000
1.00	0.042
2.00	0.080
5.00	0.198
7.00	0.281

- (a) Make an x-y graph showing the experimental data with absorbance plotted on the y-axis. (b) Determine the equation of the least squares line through the data points, with y as absorbance and x as nitrate ion concentration. (c) Calculate the uncertainty in the slope and intercept. (d) If you have done this using a statistics program or spreadsheet, what is the value of the correlation coefficient for the line?
- 1.22 a. Name the instrumental methods that can be used for elemental qualitative analysis.
 - b. Name the instrumental methods that are used for elemental quantitative analysis.
- 1.23 a. Name the instrumental methods that can be used for molecular organic functional group identification.
 - b. What instrumental methods provide molecular structural information, that is, indicate which functional groups are next to each other in an organic molecule?
- 1.24 What instrumental methods are best for quantitative analysis of (a) complex mixtures, (b) simple mixtures, or (c) pure compounds?
- 1.25 What instrumental methods can provide measurements of the molecular weight of a molecule?
- 1.26 What is the purpose of a blank in an analysis? What is the purpose of a reference material or reference standard in an analysis?
- 1.27 Equation (1.25) shows how to calculate the LOD of a method at both the 95 % and 99 % confidence levels. You have measured the blank for a determination of arsenic in food samples by hydride-generation atomic fluorescence spectrometry. The blank values are:
 - $0.23~\rm ppb,\,0.14~\rm ppb,\,0.16~\rm ppb,\,0.28~\rm ppb,\,0.18~\rm ppb,\,0.09~\rm ppb,\,0.10~\rm ppb,\,0.20~\rm ppb,\,0.15~\rm ppb,\,and\,0.21~\rm ppb~As$
 - What is the LOD at (a) 95 %CL and (b) 99 %CL?
- 1.28 Based on your answer to problem 1.30, what are the respective method LOQs for As at the two confidence levels?
- 1.29 Describe the standard addition method for measuring concentration of an unknown. What are the advantages of this method of calibration?
- 1.30 Describe the use of an internal standard for calibration. What characteristics must a species possess to serve as an internal standard? What are the advantages of the internal standard method?
- 1.31 Describe what you would do for samples whose absorbances fell above the absorbance of your highest calibration standard.

BIBLIOGRAPHY

American Society for Testing and Materials 2003 Annual Book of ASTM Standards; ASTM International: West Conshohocken, PA, 2003.

Anastassiades, M.; Lehotay, S.J.; Stajnbaher, D.; Schenck, F.J., *Journal of AOAC International (JAOAC)*, 86, p. 412–413, 2003.

APHA, AWWA, WPCF, Standard Methods for the Examination of Water and Wastewater, 18th ed.; Greenberg, A.E., Clesceri, L.S., and Eaton, A.D., Eds.; American Public Health Association: Washington, D.C., 1992.

Bruno, T.J.; Svoronos, P.D.N. CRC Handbook of Basic Tables for Chemical Analysis – Data Driven Methods and Interpretation; CRC Press: Boca Raton, FL, 2021.

Christian, G.D. Analytical Chemistry, 6th; John Wiley and Sons, Inc: Hoboken, NJ, 2004.

CRC Standard Math Tables; CRC Press: Boca Raton, FL (any edition).

Diamond, D.; Hanratty, V. Spreadsheet Applications in Chemistry Using Microsoft Excel; John Wiley and Sons, Inc.: New York, 1997.

Dulski, T.R. *A Manual for the Chemical Analysis of Metals*; ASTM International: West Conshohocken, PA, 1996.

Enke, C.G. The Art and Science of Chemical Analysis; John Wiley and Sons, Inc.: New York, 2001.

Erickson, M.D. Analytical Chemistry of PCBs, 2nd; CRC Press: Boca Raton, FL, 1997.

Harris, D.C. Quantitative Chemical Analysis, 5th; W.H. Freeman and Company: New York, 1999.

Horwitz, W., Ed. *OFficial Methods of Analysis of the Association of Official Analytical Chemists*, 13th; Association of Official Analytical Chemists: Washington, D.C, 1980.

Keith, L.H., Ed. Principles of Environmental Sampling; American Chemical Society: Washington, D.C., 1988.

Malmstadt, H.V.; Enke, C.G.; Crouch, S.R. *Microcomputers and Electronic Instrumentation: Making the Right Connections*; American Chemical Society: Washington, D.C., 1994.

Mark, H.; Workman, J. Statistics in Spectroscopy; Academic Press, Inc.: San Diego, CA, 1991.

Rorabacher, D.B. Anal. Chem. 1991, 63, 139.

Simpson, N.J.K., Ed. Solid-Phase Extraction: Principles, Techniques and Applications; CRC Press: Boca Raton, 2000.

Skoog, D.A.; Holler, J.A.; Nieman, T.A. *Principles of Instrumental Analysis*, 5th; Saunders College Publishing; Harcourt, Brace and Company: Orlando, FL, 1998.

Tyson, J. Analysis. What Analytical Chemists Do; Royal Society of Chemistry: London, 1988.

US Environmental Protection Agency. *Methods for the Chemical Analysis of Water and Wastes*, EPA-600/4-79-020, Environmental Monitoring and Support Laboratory: Cincinnati, OH, March 1983.

US Environmental Protection Agency. *Test Methods for Evaluating Solid Waste-Physical/Chemical Methods*, 3rd ed.; SW-846; Office of Solid Waste and Emergency Response: Washington, D.C., 1986. (most recent version available at www.epa.gov).

Wercinski, S.A.S., Ed. *Solid Phase Microextraction: A Practical Guide*; CRC Press: Boca Raton, 1999. Whitecavage, J.; Stuff, J.R.; Pfannkoch, E.A.; Moran, J.H., High Throughput Method for the Determination of PAHs in Seafood by QuEChERS-SBSE-GC-MS. Application Notes 2010/6a and 2010/6b. http://www.gerstel.com/en/applications.htm.



Introduction to Spectroscopy

2

2.1 THE INTERACTION BETWEEN ELECTROMAGNETIC RADIATION AND MATTER

We know from our observation of rainbows that *visible light* (white light) is composed of a **continuum** of colors from violet to red. If a beam of white light is passed through a beaker of water, it remains white. If potassium permanganate is added to the water, the white light appears purple after it passes through the solution. The permanganate solution allows the red and blue components of white light to pass through but absorbs the other colors from the original beam of light. This is one example of the interaction of **electromagnetic radiation**, or light, with *matter*. In this case, the electromagnetic radiation is visible light and we can see the effect of absorption of some of the light with our eyes. However, interactions between electromagnetic radiation and matter take place in many ways and over a wide range of *radiant energies*. Most of these interactions are not visible to the human eye, but can be measured with suitable instruments.

Interaction of electromagnetic radiation and matter is not haphazard, but follows well-documented rules with respect to the wavelengths of light absorbed or emitted and the extent of absorption or emission. The subject of **spectroscopy** is the study of the interaction of electromagnetic radiation and matter.

2.1.1 WHAT IS ELECTROMAGNETIC RADIATION?

The nature of electromagnetic radiation baffled scientists for many years. At times, light appears to behave like a wave; at other times, it behaves as though it were composed of small particles. While we now understand the "wave-particle duality" of all matter, including electromagnetic radiation, in terms of quantum mechanics, it is still convenient to consider electromagnetic radiation as having the properties of waves in many cases.

Light waves can be represented as oscillating perpendicular electric and magnetic fields. The fields are at right angles to each other and to the direction of propagation of the light. The oscillations are sinusoidal in shape, as shown in Figure 2.1(a). We can easily and accurately measure the wavelength λ , defined as the crest-to-crest distance between two successive maxima. The standard unit of wavelength is the SI unit of length, the meter (m), but smaller units such as the centimeter (cm), micrometer (μ m), and nanometer (nm) are commonly used. The amplitude of the wave is defined as the maximum of the vector from the origin to a point displacement of the oscillation. An example of the electric field portion of a light wave propagating along only one axis is shown in Figure 2.1(b). Such a wave, confined to one plane, is called plane-polarized light. The wave shown represents only a single wavelength, λ Light of only one wavelength is called monochromatic light. Light that consists of more than one wavelength is called polychromatic light. White light is an example of polychromatic light.

The **frequency** v of a wave is the number of crests passing a fixed point per second. One crest-to-crest oscillation of a wave is called a cycle. The common unit of frequency is the hertz (Hz) or inverse second (s⁻¹); an older term for frequency is the cycles per second (cps). One hertz equals one cycle per second.




FIGURE 2.1 (a) A plane-polarized light wave in the *x*-direction, showing the mutually perpendicular electric and magnetic field components. (b) The wavelength and amplitude of a wave.

The wavelength of light, λ , is related to its frequency, ν , by the equation:

$$(2.1) c = \lambda v$$

where c is the speed of light in a vacuum, 2.997×10^8 m/s, v is the frequency of the light in inverse seconds (Hz), and λ is the wavelength in meters. In a vacuum, the speed of light is maximum and does not depend on the wavelength. The frequency of light is determined by the source and does not vary. When light passes through material other than a vacuum, its speed is decreased. Because the frequency cannot change, the wavelength must decrease. If we calculate the speed of light in air, it only differs by a very small amount from the speed of light in vacuum. In general, we use 3.00×10^8 m/s (to three significant figures) for the speed of light in air or vacuum.

In some cases, it is more convenient to consider light as a stream of particles. Particles of light are called **photons**. Photons are characterized by their energy, *E*. The energy of a photon is related to the frequency of light by the equation:

$$(2.2) E = hv$$

where *E* is the energy in joules (J), *h* is Planck's constant, 6.626×10^{-34} J s, and v is the frequency in inverse seconds (Hz). From Eqs. (2.1) and (2.2), we can deduce that:

$$(2.3) E = \frac{hc}{\lambda}$$

Therefore, the energy of electromagnetic radiation is directly proportional to its frequency and inversely proportional to its wavelength. Electromagnetic radiation ranges from very low energy (long wavelength, low frequency) radiation, like radio waves and microwaves, to very high energy (short wavelength, high frequency) radiation, like X-rays. The major regions of the electromagnetic spectrum of interest to us as analytical chemists are shown in Figure 2.2.




FIGURE 2.2 The electromagnetic spectrum. The visible light region is expanded to show the colors associated with wavelength ranges.

TABLE 2.1 Common Wavelength Symbols and Units for Electromagnetic Radiation

Unit	Symbol	Length (m)	Type of Radiation
Angstrom	Å	10 ⁻¹⁰	X-ray
Nanometer	Nm	10 ⁻⁹	UV, visible
Micrometer	μ m	10 ⁻⁶	IR
Millimeter	Mm	10 ⁻³	IR
Centimeter	Cm	10 ⁻²	Microwave
Meter	M	1	Radio

Visible light, the portion of the electromagnetic spectrum to which the human eye responds, is only a very small portion of all radiant energy. Table 2.1 presents some common units and symbols for various types of electromagnetic radiation.

2.1.2 HOW DOES ELECTROMAGNETIC RADIATION INTERACT WITH MATTER?

We know from quantum mechanics that energy is just a form of matter, and that all matter exhibits the properties of both waves and particles. However, matter composed of molecules, atoms, or ions, which exists as solid or liquid or gas, exhibits primarily the properties of particles. Spectroscopy studies the interaction of light with matter defined as materials composed of molecules or atoms or ions.

In a gas, atoms or molecules are widely separated from each other; in liquids and solids, the atoms or molecules are closely associated. In solids, the atoms or molecules may be arranged in a highly ordered array, called a **crystal**, as they are in many minerals, or they may be randomly arranged, or **amorphous**, as they are in many plastics. Atoms, molecules, and ions are in constant motion whatever their physical state or arrangement. For molecules, many types of motion are involved. Molecules can rotate, vibrate, and translate (move from place to place in space). Interaction with radiant energy can affect these molecular motions. Molecules that absorb IR radiation vibrate with greater amplitude; interaction with UV or

TABLE 2.2	Some Typ	es of Transitic	ons Studied b	y Spectroscopy
------------------	----------	-----------------	---------------	----------------

Type of Transition	Spectroscopic Method	Wavelength Range
Spin of nuclei in a magnetic field	NMR spectroscopy	0.5-10 m
Rotations of molecules	Microwave	4–25 mm
Vibration of molecules	Raman and IR spectroscopy	$0.8-300~\mu m$
Bonding electron energy, valence electron energy	UV/VIS spectroscopy	180-800 nm
Core electron energy	X-ray spectroscopy	0.1-100 Å

Note: This is a very limited list of the types of transitions and spectroscopic methods in current use.

visible light can move bonding electrons to higher energy levels in molecules. A change in any form of motion or electron energy level involves a change in the energy of the molecule. Such a change in energy is called a **transition**; we have the possibility of vibrational, rotational, and electronic transitions in molecules. We have some of the same kinds of motion in atoms and ions. Atoms can move in space, and their electrons can move between energy levels, but atoms and monoatomic ions cannot rotate or vibrate. The chemical nature of matter (its composition), its physical state, and the arrangement of the atoms or molecules in the physical state with respect to each other affect the way in which any given material interacts with electromagnetic radiation. Table 2.2 lists some of the important types of transitions studied by spectroscopy. We will cover these techniques in detail in later chapters. There are many types of transitions and types of spectroscopy used to investigate matter. Only the most common types of analytical spectroscopy will be covered in this book.

When light strikes a sample of matter, the light may be absorbed by the sample, transmitted through the sample, reflected off the surface of the sample, or scattered by the sample. Samples can also emit light after absorbing incident light; such a process is called **luminescence**. There are different kinds of luminescence, called **fluorescence** or **phosphorescence**, depending on the specific process that occurs; these are discussed in detail in Chapter 3. Emission of light may also be caused by processes other than absorption of light. There are spectroscopic methods based on all of these interactions. Table 2.3 summarizes the major types of interaction of light with matter and gives examples of the common spectroscopic techniques based on these interactions. For the moment, we will focus on the absorption, transmission, and emission of light by matter.

TABLE 2.3 Some Interactions of Light and Matter

Interaction	Radiation Measured	Spectroscopic Method
Absorption and transmission	Incident light, I ₀	Atomic absorption
	Transmitted light, I	Molecular absorption
Absorption then emission	Emitted light, I'	Atomic fluorescence
		Molecular fluorescence
		Molecular phosphorescence
Scattering	Scattered light, $I_{\rm S}$	Turbidimetry
		Nephelometry
		Raman
Reflection	Reflected light, $I_{\rm R}$	Diffuse reflection IR (the term reflectance
	or relative	is also used for these methods)
	reflected I_R	Attenuated total reflection
Attenuated Reflection	Reflected Evanescent	
	Light, I _R	
Emission	Emitted light, I _e	Atomic emission
		Molecular emission
		Chemiluminescence

If we pass white light through blue glass, the emerging light is blue. The glass has absorbed the other colors, such as red and yellow. We can confirm this absorption by shining red light through the blue glass. If the absorption is strong enough, all of the red light is absorbed; no light emerges from the glass and it appears black. How can this be explained?

The interaction of electromagnetic radiation and matter conforms to well-established quantum mechanical laws. Atoms, ions, and molecules exist only in certain discrete states with specific energies. The same quantum mechanical laws dictate that a change in state requires the absorption or emission of energy, ΔE , exactly equal to the difference in energy between the initial and final states. We say that the energy states are quantized. A change in state (change in energy) can be expressed as:

(2.4)
$$\Delta E = E_{\text{final}} - E_{\text{initial}} = h v$$

Since we know that $c = \lambda v$, then:

(2.5)
$$\Delta E = h\mathbf{v} = \frac{hc}{\lambda}$$

These equations tell us that matter can absorb or emit radiation when a transition between two states occurs, but it can absorb or emit only the specific frequencies or wavelengths that correspond to the exact difference in energy between two states in which the matter can exist. Absorption of radiation increases the energy of the absorbing species ($E_{\rm final} > E_{\rm initial}$). Emission of radiation decreases the energy of the emitting species ($E_{\rm final} < E_{\rm initial}$). So, the quantity ΔE can have either a positive sign or a negative sign, but when using ΔE to find the wavelength or the frequency of the radiation involved in a transition, only the absolute value of ΔE is used. Wavelength, frequency, and the speed of light are always positive in sign.

A specific molecule, such as hexane, or a specific atom, such as mercury, can absorb or emit only certain frequencies of radiation. All hexane molecules will absorb light with the same frequencies, but these frequencies will differ from those absorbed by a different molecule, such as benzene. All mercury atoms will absorb the same frequencies of incident light, but these will differ from the frequencies of light absorbed by atoms of lead or copper. Not only are the frequencies unique, but also the degree to which the frequency is absorbed, the **intensity**, is unique to a species. The uniqueness of the frequencies and amount of each frequency absorbed and emitted by a given chemical species are the basis for the use of spectroscopy for identification of chemicals. We call the set of frequencies and the associated intensities at which a species absorbs its **spectrum**. **In some cases, species will also emit radiation; we will encounter many such examples when we discuss fluorescence spectroscopy.**

The lowest energy state of a molecule or atom is called the **ground state**. All higher energy states are called **excited states**. At room temperature, molecules and atoms exist mainly in the ground state.

If we think about our example of the blue glass, and its ability to absorb red and yellow light, we can deduce a simple picture of the energy states in the blue glass. We will assume that the glass is in its ground state before we shine any light through it since we have performed this experiment at room temperature. We will call the ground state energy E_1 . If the glass is capable of absorbing red light, there must be an excited state such that the difference in energy between the ground state and this excited state is equivalent to the energy of a wavelength of red light. If we look at Figure 2.2, we can choose a representative wavelength in the red region of the visible spectrum, such as 653 nm. If a wavelength $\lambda = 653$ nm is absorbed by the glass, we can calculate the frequency of this light by rearranging Eq. (2.1):

$$v = \frac{c}{\lambda} = \frac{2.997 \times 10^8 \text{ m/s}}{(653 \text{ nm})(10^{-9} \text{ m/nm})}$$
$$v = 4.59 \times 10^{14} \text{ s}^{-1}$$

From the frequency, we are able to calculate the difference in energy between the ground state and this excited state, which we will call E_2 :

$$\Delta E = E_2 - E_1 = hv$$

 $\Delta E = (6.626 \times 10^{-34} \text{ J s})(4.59 \times 10^{14} \text{ s}^{-1})$
 $\Delta E = 3.05 \times 10^{-19} \text{ J}$

So, there is one excited state with an energy that is 3.05×10^{-19} J higher than the ground state in the glass. We do not know the exact energy of the ground state itself. The glass also absorbs yellow light, so we can pick a representative wavelength of yellow light, such as 575 nm, and repeat the preceding calculation. The frequency of light corresponding to a wavelength of 575 nm is 5.21×10^{14} Hz, so there must be an excited state E_3 such that:

$$\Delta E = E_3 - E_1 = hv$$

 $\Delta E = (6.626 \times 10^{-34} \text{ J s})(5.21 \times 10^{14} \text{ s}^{-1})$
 $\Delta E = 3.45 \times 10^{-19} \text{ J}$

We can now construct a simplified energy diagram for the blue glass, such as the one shown in Figure 2.3.

Because the glass does not absorb blue light, there would be no energy states with a difference in energy equal to any frequency of blue light. This diagram is very oversimplified. "Red", "yellow", and "blue" light span a range of wavelengths. There are many different energy levels associated with the transitions occurring in glass. Absorption of red light occurs from 620 to 750 nm, yellow light from 550 to 595 nm, and so on. What is the molecular reason for this "broadband" absorption observed in spectroscopic experiments with visible light? The absorption of visible light by glass is due to electronic transitions, excitation of bonding electrons in the molecules. Electronic transitions require more energy than rotational or vibrational transitions. For a molecule, the relative energy of transitions is rotational < vibrational < electronic. A more realistic energy level diagram for glass (and for molecules in general) is presented in Figure 2.4. For every electronic state E_n , there are many associated rotational and vibrational sublevels. Each sublevel has a slightly different energy, with the result that a transition from one energy level E_n to a higher energy level is not a single energy but a range of closely spaced energies, because the electron can end up in any one of the many sublevels. For this reason, absorption of red light by molecules occurs over a range of wavelengths, not at a single discrete wavelength.

Excited states are energetically unfavorable; the molecule or atom wants to return to the lowest energy ground state by giving up energy, often by emitting light. Because they are energetically unfavorable, excited states are usually short-lived, on the order of 10^{-9} – 10^{-6} s. Emission of light therefore occurs rapidly following excitation. One notable exception is the




FIGURE 2.3 Simplified energy diagram for the absorption of visible light by blue glass. Two possible excited energy states area shown, one corresponding to the absorption of 653 nm (red) light and a higher state corresponding to the absorption of 575 nm (yellow) light. If the ground state energy is defined as E=0, the relative energies of the excited states can be determined.




FIGURE 2.4 Schematic energy level diagram for molecules. Each electronic energy level, $E_{0,1,2,...}$ has associated vibrational sublevels $V_{1,2,3,...}$ and rotational sublevels $J_{1,2,3,...}$.

process of phosphorescence, described in Chapter 3; for this process, the excited state lifetime can be as long as tens of seconds.

Absorption spectra are obtained when a molecule or atom absorbs radiant energy that satisfies the equation $\Delta E = hv = hc/\lambda$. The **absorption spectrum** for a substance shows us the energies (frequencies or wavelengths) of light absorbed as well as how much light is absorbed at each frequency or wavelength. A graph of the intensity of light amplitude change on the *y*-axis vs. the frequency or wavelength on the *x*-axis is constructed. This graph of intensity vs. energy is called a spectrum. The IR absorption spectrum for polystyrene is shown in Figure 4.1 in Chapter 4.

Emission spectra are obtained when an atom or molecule in an excited state returns the ground state by emitting radiant energy. An emission spectrum can result from many different ways of forming an excited state. Atoms and molecules can be excited not only by absorption of electromagnetic radiation, but also by transfer of energy due to collisions between atoms and molecules, by addition of thermal energy, and by addition of energy from electrical discharges. Different excitation methods are used in several types of emission spectroscopy and will be discussed in later chapters. A special term is used for the emission of electromagnetic radiation by either atoms or molecules following excitation by absorption of electromagnetic radiation, **luminescence**. If light is used as the source of excitation energy, the emission of light is called luminescence; if other excitation sources are used, the emission of light is called simply emission.

2.2 ATOMS AND ATOMIC SPECTROSCOPY

An atom consists of a nucleus surrounded by electrons. Every element has a unique number of electrons equal to its atomic number for a neutral atom of that element. The electrons are located in atomic orbitals of various types and energies and the electronic energy states of atoms are quantized. The lowest energy, most stable electron configuration of an element is




FIGURE 2.5 Energy transitions in atoms. Atoms may absorb energy and move a ground state valence electron to higher energy excited states. The excited atom may relax back to the ground state by emitting light of a wavelength equal to the difference in energy between the states. Three such emissions are shown. (©1993-2020 PerkinElmer, Inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

its ground state. The ground state is the normal electron configuration predicted from the "rules" for filling a many-electron atom, which you learned in general chemistry. These rules are based on the location of the atom in the periodic table, the aufbau principle, the Pauli exclusion principle, and Hund's rule. (You may want to review your general chemistry text on the structure of the atom.) For example, the ground state electron configuration for sodium, atomic number 11, is 1s²2s²2p⁶3s¹ based on its position in the third row, first group of the periodic table, and the requirement to account for 11 electrons. The ground state electronic configuration for potassium is 1s²2s²2p⁶3s²3p⁶4s¹, vanadium is 1s²2s²2p⁶3s²3p⁶4s²3d³, and so on. If energy of the right magnitude is provided to an atom, the energy may be absorbed and an outer (valence) electron promoted from the ground state orbital to a higher energy orbital. The atom is now in a higher energy, less stable, excited state. Because the excited state is less stable than the ground state, the electron will return spontaneously to the ground state. In the process, the atom will emit energy; this energy will be equivalent in magnitude to the difference in energy levels between the ground and excited states (and equivalent to the energy absorbed initially). The process is shown schematically in Figure 2.5. Eqs. (2.4) and (2.5) directly relate the wavelength of radiation absorbed or emitted to the electronic transition that has occurred:

(2.6)
$$\Delta E = E_{\text{final}} - E_{\text{initial}} = h\mathbf{v} = \frac{hc}{\lambda}$$

Each element has a unique set of permitted electronic energy levels because of its unique electronic structure. The wavelengths of light absorbed or emitted by atoms of an element are characteristic of that element. The absorption of radiant energy by atoms forms the basis of AAS, discussed in Chapter 6. The absorption of energy and the subsequent emission of radiant energy by excited atoms form the basis of atomic emission spectroscopy and atomic fluorescence spectroscopy, discussed in Chapter 7.

In practice, the actual energy level diagram for an atom is derived from the emission spectrum of the excited atom. Figure 2.6 shows an energy level diagram for mercury atoms. Note that a free gas phase atom has no rotational or vibrational energy associated with it. When an electron is promoted to a higher atomic excited state, the change in energy is very well defined and the wavelength absorbed (or emitted on **relaxation** to the ground state) can be considered monochromatic. The wavelengths of light involved in valence electronic transitions in atoms fall in the visible and ultraviolet regions of the spectrum. This region is often called the UV/VIS region for short. The energy level diagrams for all elements have been determined, and tables of wavelengths absorbed and emitted by atoms are available. Appendix 6.1 (book website) lists the absorption wavelengths used to measure elements by AAS (Chapter 6).




FIGURE 2.6 Energy levels in mercury atoms (units of energy are electron volts, eV).

Knowing what wavelengths of light are absorbed or emitted by a sample permits qualitative identification of the elements present in the sample. Measuring the intensity of light absorbed or emitted at a given wavelength provides quantitative elemental analysis. All of the atomic spectroscopy methods—absorption, fluorescence, and emission—are extremely sensitive. As little as 10^{-12} – 10^{-15} g of an element may be detected using atomic spectroscopy.

It is possible for atoms to absorb higher energy radiation, in the X-ray region; such absorption may result in the inner shell (core) electrons being promoted to an excited state, with the subsequent emission of X-ray radiation. This process forms the basis for qualitative and quantitative elemental analysis by XRF spectroscopy, as well as other X-ray techniques, discussed in Chapter 8.

2.3 MOLECULES AND MOLECULAR SPECTROSCOPY

The energy states associated with molecules, like those of atoms, are also quantized. There are very powerful spectroscopic methods for studying transitions between permitted states in molecules using radiation from the radio wave region to the UV region. These methods provide qualitative and quantitative information about molecules, including detailed information about molecular structure.

2.3.1 ROTATIONAL TRANSITIONS IN MOLECULES

The ability of a molecule to rotate in space has associated rotational energy. Molecules may exist in only quantized rotational energy states. Absorption of the appropriate energy causes transitions from lower energy rotational states to higher energy rotational states, in which the molecule rotates faster. This process gives rise to rotational absorption spectra. The rotational energy of a molecule depends on its angular velocity, which is variable. Rotational energy also depends on the molecule's shape and weight distribution, which change as bond angles change. While a change in shape is restricted in diatomic molecules such as O_2 , molecules with more than two atoms, such as hexane, C_6H_{14} , have many possible shapes and therefore many possible rotational energy levels. Furthermore, the presence of more than one natural isotope of an atom in a molecule generates new sets of rotational energy levels. Such is the case with carbon, where a small percentage of the carbon atoms in a carbon-containing molecule are ^{13}C instead of ^{12}C . Consequently, even simple molecules have complex rotational absorption spectra. The energies involved in rotational changes are very small, on the order of 10^{-24} J per molecule. The radiation absorbed is therefore in the radiofrequency and microwave regions of the spectrum. Microwave spectroscopy has been largely unexploited in




FIGURE 2.7 Some possible vibrations of bonded atoms in a molecule.

analytical chemistry because of the experimental difficulties involved and the complexity of the spectra produced. The technique is limited to the gas phase and has been used by radio astronomers to detect the chemical species in interstellar clouds.

2.3.2 VIBRATIONAL TRANSITIONS IN MOLECULES

For the purposes of basic understanding of this branch of optical spectroscopy, molecules can be visualized as a set of weights (the atoms) joined together by springs (the chemical bonds). The atoms can vibrate toward and away from each other or they may bend at various angles to each other as shown in Figure 2.7. Each such vibration has characteristic energy associated with it. The vibrational energy states associated with molecular vibration are quantized. Changes in the vibrational energy of a molecule are associated with absorption of radiant energy in the IR region of the spectrum. While absorption of IR radiation causes changes in the vibrations of the absorbing molecule, the increase in vibrational energy is also usually accompanied by increased molecular rotation, since rotational energy levels are sublevels of the vibrational energy levels. Absorption of IR radiation corresponds to a combination of changes in rotational and vibrational energies in the molecule. Because a molecule with more than two atoms has many possible vibrational states, IR absorption spectra are complex, consisting of multiple absorption bands. Absorption of IR radiation by molecules is one of the most important techniques in spectroscopy. Through IR absorption spectroscopy, the structure of molecules can be deduced, and both qualitative identification of molecules and quantitative analysis of the molecular composition of samples can be performed. IR spectroscopy is discussed in Chapter 4.

2.3.3 ELECTRONIC TRANSITIONS IN MOLECULES

When atoms combine to form molecules, the individual atomic orbitals combine to form a new set of molecular orbitals. Molecular orbitals with electron density in the plane of the bonded nuclei, along the axis connecting the bonded nuclei, are called sigma (σ) orbitals. Those molecular orbitals with electron density above and below the plane of the bonded nuclei are called pi (π) orbitals. Sigma and pi orbitals may be of two types: bonding orbitals or antibonding orbitals. Bonding orbitals are lower in energy than the corresponding antibonding orbitals. When assigning electrons in molecules to orbitals, the lowest energy bonding orbitals are filled first. For a review of molecular orbital theory, see your general chemistry text.

Under normal conditions of temperature and pressure, the electrons in the molecule are in the ground state configuration, filling the lowest energy molecular orbitals available. Absorption of the appropriate radiant energy may cause an outer electron to be promoted to a higher energy excited state. The radiant energy required to cause electronic transitions

in molecules lies in the visible and UV regions. As with atoms, the excited state of a molecule is less stable than the ground state. The molecule will spontaneously revert (relax) to the ground state emitting UV or visible radiant energy. Unlike atoms, the energy states in molecules have rotational and vibrational sub-levels, so when a molecule is excited electronically, there is often a simultaneous change in the vibrational and rotational energies. The total energy change is the sum of the electronic, rotational, and vibrational energy changes. Because molecules possess many possible rotational and vibrational states, absorption of UV or visible radiation by a large population of molecules, each in a slightly different state of rotation and vibration, results in absorption over a wide range of wavelengths, called an absorption band. The UV/VIS absorption spectra of molecules usually have a few broad absorption bands and are usually very simple in comparison with IR spectra. While molecular absorption spectroscopy can be used for qualitative identification of chemical species, it has been replaced by the more powerful and now commonly available techniques of NMR, IR spectroscopy, and MS. UV/VIS molecular absorption spectroscopy is most often used for quantitative analysis of the composition of samples. Molecular fluorescence spectroscopy is an extremely high sensitivity method, with the ability to detect single molecules. We will learn the laws governing absorption, which permit quantitative analysis by UV/VIS spectroscopy, in this chapter. The use of UV/VIS molecular spectroscopy will be discussed at greater length in Chapter 3.

2.4 ABSORPTION LAWS

The **radiant power** *P* of a beam of light is defined as the energy of the beam per second per unit area. A related quantity is the **intensity**, *I*—the power per unit solid angle. Both power and intensity are related to the square of the amplitude of the light wave, and the absorption laws can be written in terms of either power or intensity. We will use intensity *I* but you may see the same laws written with a *P* for power in other literature.

When light passes through an absorbing sample, the intensity of the light emerging from the sample is decreased. Assume the intensity of a beam of monochromatic (i.e., single wavelength) radiation is I_0 . This beam is passed through a sample that can absorb radiation of this wavelength, as shown in Figure 2.8. The emerging light beam has an intensity equal to I, where $I_0 \ge I$. If no radiation is absorbed by the sample, $I = I_0$. If any amount of radiation is absorbed, $I < I_0$. The **transmittance** T is defined as the ratio of I to I_0 :

$$(2.7) T = \frac{I}{I_0}$$

The transmittance is the fraction of the original light that passes through the sample. Therefore, the range of allowed values for T is from 0 to 1. The ratio I/I_0 remains relatively constant even if I_0 changes; hence, T is independent of the actual intensity I_0 . To study the quantitative absorption of radiation by samples, it is useful to define another quantity, the **absorbance** A, where:

(2.8)
$$A = \log\left(\frac{I_0}{I}\right) = \log\left(\frac{1}{T}\right) = -\log T$$

When no light is absorbed, $I = I_0$ and A = 0. Two related quantities are also used in spectroscopy: the **percent transmittance**, %T, which equals $T \times 100$, and the **percent absorption**, %A, which is equal to 100 - %T.




FIGURE 2.8 Absorption of radiation by a sample.




FIGURE 2.9 Absorption of radiation by two identical sample cells.

Suppose we have a sample of an aqueous solution of an absorbing substance in a rectangular glass sample holder with a length of 1.0 cm, as shown in Figure 2.9. Such a sample holder is called a **sample cell**, or **cuvette**, and the length of the cell is called the **path length** b. The incident light has intensity, I_0 , equal to 100 intensity units. If 50 % of the light passing through the sample is absorbed, then 50 % of the light is transmitted. The emerging light beam has an intensity denoted as $I_1 = 50$ intensity units. So %T = 50, and therefore:

$$T = \frac{\%T}{100} = \frac{I_1}{I_0}$$
$$T = \frac{50}{100} = 0.50$$

From *T*, we calculate that absorbance equals:

$$A = -\log T = -\log(0.50) = 0.30$$

If a second identical cell with the same solution is placed in the path of beam I_1 , 50 % of the incident radiation, I_1 , will be absorbed and we have a new emerging beam, I_2 . The intensity of I_1 is 50 intensity units and therefore I_2 must be 25 intensity units. So, the transmittance for the second cell is:

$$T = \frac{I_2}{I_1} = \frac{25}{50} = 0.50$$

The absorbance for just the second cell is $A = -\log 0.50 = 0.30$. The two cells are identical in their absorbance of light. Identical or "optically-matched" cells are required for accurate quantitative analysis using spectroscopy in many cases.

Now suppose we put the two cells back-to-back and consider them together. Assume that these will behave as if there were no glass walls between the two cells; we have one "cell" that is 2.0 cm long. The path length for this experiment is now 2.0 cm. The incident light beam has intensity I_0 , with $I_0 = 100$ intensity units. We know from passing light through the two cells that the emerging light beam has intensity I = 25 intensity units. So, for a path length of 2.0 cm, T now equals 25/100 or 0.25 and $A = -\log 0.25 = 0.60$. If we put three cells in line (path length = 3.0 cm), the emerging beam has I = 12.5, T = 0.125, and A = 0.90. Four cells in line will give I = 6.25, T = 0.063, and A = 1.20. If we plot intensity I vs. the number of cells (i.e., the path length in cm) as shown in Figure 2.10(a), it is clear that I decreases exponentially with increasing path length. If we plot absorbance A vs. path length, shown in Figure 2.10(b), absorbance increases linearly with increasing path length. As analytical chemists, we find it better to work with linear equations rather than with exponential equations, because it is easier to interpolate and read data from a linear plot. A linear plot has a constant slope that greatly simplifies calculations. That is why the absorbance is such a useful quantity—it results in a linear relationship with quantities important to analytical chemists. This proportional relationship between sample thickness (the path length) and absorbance at constant concentration was discovered by P. Bouguer in 1729 and J. Lambert in 1760.

If we perform a similar experiment keeping the path length constant by using only one cell but change the **concentration** of the absorbing species, we find the same relationship




FIGURE 2.10 (a) Exponential relationship between intensity (or transmittance) and increasing number of cells (increasing path length). (b) Linear relationship between absorbance and increasing number of cells (increasing path length). $I_0 = 100$ for both plots.

between I, A, and concentration as we found for path length. A linear relationship exists between the absorbance A and the concentration c of the absorbing species in the sample, a very important quantity! Because A is linear with respect to path length b and concentration c, we can write the following equation:

$$(2.9) A = abc$$

The term "a" is a proportionality constant called the **absorptivity**. The absorptivity is a measure of the ability of the absorbing species in the sample to absorb light at the particular wavelength used. Absorptivity is a constant for a given chemical species at a specific wavelength. If the concentration is expressed in molarity (mol/L or M), then the absorptivity is called the **molar absorptivity**, and is given the symbol ε . The usual unit for path length is centimeters, cm, so if the concentration is in molarity, M, the unit for molar absorptivity is M^{-1} cm⁻¹. The units for absorptivity a when concentration is expressed in any units other than molarity (for example, ppm, mg/100 mL, etc.) must be such that A, the absorbance, is dimensionless. August Beer discovered the proportional relationship between concentration and absorbance at constant path length in 1852, while Bouguer and Lambert discovered the relationship between absorbance and path length much earlier.

Equation (2.9), which summarizes the relationship between absorbance, concentration of the species measured, sample path length, and the absorptivity of the species is known as the **Beer-Lambert-Bouguer Law** or, more commonly, as **Beer's Law**.

Since $A = -\log T$, we have the following equivalent expressions for Beer's Law:

$$(2.10) abc = -\log T$$

$$-\log\left(\frac{I}{I_0}\right) = abc$$

$$\log\left(\frac{I_0}{I}\right) = abc$$

(2.13)
$$\frac{I_0}{I} = 10^{abc}$$

(2.14)
$$\frac{I}{I_0} = 10^{-abc}$$

where a, the absorptivity, is equal to ε , the molar absorptivity, in all of the equations if c, the concentration of the absorbing species, is expressed as molarity.

Beer's Law shows mathematically, based on observed experimental facts, that there is a linear relationship between *A* and the concentration of an absorbing species if the path length and the wavelength of incident radiation are kept constant. This is an extremely important relationship in analytical spectroscopy. It forms the basis for the quantitative measurement of the concentration of an analyte in samples by quantitative measurement of the amount of absorbed radiation. The *quantitative* measurement of radiation intensity is called **spectrometry**. Beer's Law is used in all quantitative optical absorption spectrometry.

2.4.1 DEVIATIONS FROM BEER'S LAW

Beer's Law is usually followed at low concentrations of analyte for homogeneous samples. Absorbance is directly proportional to concentration for most absorbing substances when the concentration is less than about 0.01 M.

Deviations from linearity are common at high concentrations of analyte. There are several possible reasons for deviation from linearity at high concentrations. At low concentrations in a solution, the analyte would be considered the **solute**. As the solute concentration increases, the analyte molecules may begin to interact with each other, through intermolecular attractive forces such as hydrogen bonding and other van der Waals forces. Such interactions may change the absorptivity of the analyte, resulting in a nonlinear response as concentration increases. At extremely high concentrations, the solute may actually become the **solvent**, changing the nature of the solution. If the analyte species is in chemical equilibrium with other species, as is the case with weak acids or weak bases in solution, changes in concentration of the analyte may shift the equilibrium (Le Chatelier's Principle). This may be reflected in apparent deviations from Beer's Law as the solution is diluted or concentrated.

Another source of deviation from Beer's Law may occur if the sample scatters the incident radiation. Solutions must be free of floating solid particles and are often filtered before measurement. The most common reason for nonlinearity at high analyte concentrations is that too little light is available to be absorbed. At low levels of analyte, doubling the concentration doubles the amount of light absorbed, say from 25 % to 50 %. If 99 % of the light has already been absorbed, doubling the concentration still doubles the amount of remaining light absorbed, but the change is only from 99 % to 99.5 %. This results in the curve becoming flat at high absorbance (see Chapter 1).

It can be seen from Eq. (2.8) that $A = \log(I_0/I)$. If $I_0 = 100$ and A = 1.0, then I = 10. Only 10 % of the initial radiation intensity is transmitted. The other 90 % of the intensity is absorbed by the sample. If A = 2.0, I = 1.0, indicating that 99 % of the incident light is absorbed by the sample. If A = 3.0, 99.9 % of the incident light intensity is absorbed. The error in the measurement

of *A* increases as *A* increases (or as *I* decreases). Beer's Law is obeyed for absorbance values less than or equal to 1.0 in older instruments; modern instruments can be linear up to 2.0.

2.4.2 ERRORS ASSOCIATED WITH BEER'S LAW RELATIONSHIPS

All spectrometric measurements are subject to indeterminate (random) error, which will affect the accuracy and precision of the concentrations determined using spectrometric methods. Because these errors are random, they cannot be eliminated. Errors in measurement of radiation intensity lead directly to errors in measurement of concentration when using calibration curves and Beer's Law.

We can evaluate the impact of indeterminate error due to instrumental noise on the information obtained from transmittance measurements. The following discussion applies to UV/VIS spectrometers operated in regions where the light source intensity is low or the detector sensitivity is low and to IR spectrometers where noise in the thermal detector is significant.

From Beer's Law, it can be shown that:

(2.15)
$$\Delta c/c = \frac{0.434\Delta T}{T \log T}$$

where $\Delta c/c$ is the relative error in concentration and ΔT is the error in measurement of the transmittance. The value of ΔT can be estimated from a large number (n>20) of replicate measurements of the same solution. If we assume that we have a constant error of 1 % in the measurement of T, or $\Delta T=0.01$, the relative error in concentration can be calculated using Eq. (2.15). Table 2.4 presents the relative error in concentration for a wide range of transmittance measurements when a constant error of 1 % T is assumed. It can be seen from Table 2.4 that the relative error in concentration is high when T is very low or very high; significant errors result when using Beer's Law at very low concentrations of analyte (high %T) and at very high concentrations of analyte (low %T).

We can plot the relative error data in Table 2.4 as a function of transmittance. The resulting plot is shown in Figure 2.11. It can be seen from this plot that the minimum relative error occurs at T = 0.37 (37 %T), although satisfactory results can be obtained over the range of 15–65 %T. This range corresponds to an absorbance range of 0.82–0.19. For the greatest accuracy in quantitative absorption measurements, it is advisable to determine concentration from samples with absorbances between 0.82 and 0.19. Samples that are too concentrated (A > 0.82) should be diluted to bring their absorbance values below 0.8. Samples that are too dilute (A < 0.19) should be concentrated by evaporation or solvent extraction. If it is not possible to alter the sample solution, the analyst must be aware that the relative error

TABLE 2.4 Relative Concentration Error from 1 % Spectrometric Error

Transmittance (T)	Relative Error in Concentration $(\Delta c/c) \times 100$ (%)
0.02	12.8
0.08	4.9
0.15	3.5
0.30	2.8
0.37	2.7
0.45	2.8
0.65	3.6
0.80	5.6
0.97	33.8

Note: $\Delta T = 0.01$; $\Delta c/c = (0.434 \Delta T)/(T \log T)$




FIGURE 2.11 Relative uncertainty in measured concentration due to random error in spectrometric measurements due to some types of instrument noise. The data shown are for a constant 1 % error in transmittance. The curve will have the same shape for other values of error in *T*, but the magnitude of the uncertainty will change.

will be large for very dilute or very concentrated samples when using an instrument with the limitations described. A more detailed table of relative uncertainty can be found in the book by Bruno and Svoronos.

Modern UV/VIS spectrometers are generally limited by "shot noise" in the photon detector as electrons cross a junction. In this case, the plot of relative uncertainty due to indeterminate instrument error looks very different from Figure 2.11. For good quality shot-noise-limited instruments, the relative error is high for very low values of A (high %T), but absorbance values from 0.2 to above 2.0 have approximately the same low (< 1 %) relative uncertainty. Modern spectrometers are much more accurate and precise than older ones because of improvements in instrument components.

Another way of plotting spectrometric data is to use the Ringbom method in which the quantity (100-%T) is plotted against the logarithm of the concentration. The resulting S-shaped curve is called a Ringbom plot. A Ringbom plot for absorption by Mn as permanganate ion is shown in Figure 2.12. The Ringbom plot shows the concentration range where the analysis error is minimal; this is the steep portion of the curve where the slope is nearly linear. The plot also permits the evaluation of the accuracy at any concentration level. From Beer's Law, it can be shown that the percent relative analysis error for a 1 % transmittance error is given by:

(2.16)
$$\frac{\text{% relative analysis error}}{1\text{% transmittance error}} = \frac{100\Delta c/c}{1} = \frac{230}{1\Delta T/\Delta \log c}$$

Because the quantity ($\Delta T/\Delta \log c$) is the slope of the curve, the relative analysis error per 1% transmittance error at any point on the curve is equal to 230 divided by the slope at that




FIGURE 2.12 Ringbom plot of permanganate solution measured at 526 nm in a 1.00 cm cell. %RE = percent relative error in concentration for a 1 % error in transmittance. The magnitude of %RE is shown for three ranges of Mn concentration. Mn concentration is in units of ppm Mn in solution (1 ppm = 1 μ g Mn/mL solution).

point. The slope can be determined by constructing a tangent to the curve at the desired concentration. The difference in y for a 10-fold difference in x is calculated. This value, divided into 230, is the percent relative analysis error per 1 % transmittance error. For example, the slope between the two points labeled A in Figure 2.12 is determined by drawing a tangent which extends through the concentrations 2 and 20 ppm (a 10-fold change) as shown. The values of y from the plot are 9 % at 2 ppm and 90 % at 20 ppm. The difference in y values is 90-9=81; therefore 230/81=2.8. The relative analysis error is 2.8 % over this range. Other ranges and their respective errors are shown in Figure 2.12 in the inset box at the top left. Of course, this calculation can be done more accurately using a computer than by manually drawing tangent lines.

A practical application of the Ringbom plot is the determination of the concentration range over which the percent relative analysis error will not exceed a specified value. This sort of limit is often set for industrial analyses, where specifications for "good" product are established for upper and lower limits of product composition based on spectrometric measurements. A product falling outside of these specifications would be rejected as being not in compliance.

Interpretation of the Ringbom plot leads to the same conclusions we deduced from Figure 2.11. The error is lowest at approximately 100 - %T = 63, or 37 %T. The relative analysis error per 1 % transmittance is about 2.8 %. The error is not significantly greater over the range (100 - %T) of 40 - 80 %T, or between 20 % and 60 %T; this is the steep, nearly linear portion of the Ringbom plot. At very low and very high values of 100 - %T, the slope of the Ringbom plot approaches zero and therefore the percent relative analysis error approaches infinity for spectrometers with the limitations noted above.

TABLE 2.5 Nomenciature and Demintions for Spectroscopy		
Term	Symbol	Definition
Transmittance	T , where $T = I/I_0$	Ratio of light intensity after passing through sample, $\it l_0$ light intensity before passing through sample, $\it l_0$
Absorbance	Α	$-\log T = abc$
Absorptivity	а	The proportionality constant a in Beer's Law, $A = abc$ where A is absorbance, c is concentration, and b is path length
Molar absorptivity	ε	The proportionality constant ε in Beer's Law, $A = \varepsilon bc$, where A is absorbance, b is path length, and c is concentration of the absorbing solution in molarity (M)
Path length	Ь	Optical path length through the sample
Sample concentration	С	Amount of sample (usually in terms of the absorbing species) per unit volume or mass. Typical units are g/mL, mol/L, ppm, ppb, %
Absorption maximum	λ_{max}	Wavelength at which greatest absorption occurs
Wavelength	λ	Distance between consecutive wave crests
Frequency	ν	Number of oscillations of a wave per second; the number of wave crests passing a given point per second
Wavenumber	$\overline{ u}$	$1/\lambda$ or the number of waves per centimeter

TABLE 2.5 Nomenclature and Definitions for Spectroscopy

Table 2.5 provides a summary of the nomenclature, symbols, and definitions commonly used in spectroscopy. We will use these symbols throughout many of the later chapters.

2.5 OPTICAL SYSTEMS USED IN SPECTROSCOPY

In optical analytical spectroscopy, the absorption or emission of radiation by a sample is measured. The instrumentation designed to measure absorption or emission of radiation must provide information about the wavelengths that are absorbed or emitted and the intensity (*I*) or absorbance (*A*) at each wavelength. The instrumentation for spectroscopic studies from the UV through the infrared regions of the spectrum is very similar in its fundamental components. For the moment, the term **spectrometer** will be used to mean an instrument used for optical spectroscopy.

Instruments for analytical spectroscopy require a radiation source, a wavelength selection device such as a monochromator, a sample holder transparent to the radiation range being studied, a detector to measure the intensity of the radiation and convert it to a signal, and some means of displaying and processing the signal from the detector. FT spectrometers, discussed subsequently, do not require a wavelength selection device. If emitted radiation is being measured, the sample, excited by some means, is the radiation source. If absorption, fluorescence, phosphorescence, or scattering of light is measured, an external radiation source is required. The specific arrangement of these components is referred to as the **optics** or **optical configuration** or **optical layout** of the instrument. The optical layout of a simple single-beam absorption spectrometer is shown schematically in Figure 2.13. The




FIGURE 2.13 Schematic diagram of a single-beam absorption spectrometer.

placement of the sample holder and the wavelength selector may be inverted; in UV/VIS absorption spectrometry, the sample holder is usually placed after the wavelength selector, so that monochromatic light falls on the sample. For atomic absorption, IR, and fluorescence spectroscopy, the sample is usually placed in front of the wavelength selector.

2.5.1 RADIATION SOURCES

An ideal radiation source for spectroscopy should have the following characteristics:

- 1. The source must emit radiation over the entire wavelength range to be studied.
- 2. The intensity of radiation over the entire wavelength range must be high enough so that extensive amplification of the signal from the detector can be avoided.
- 3. The intensity of the source should not vary significantly at different wavelengths.
- 4. The intensity of the source should not fluctuate over long time intervals.
- 5. The intensity of the source should not fluctuate over short time intervals. Short time fluctuation in source intensity is called "flicker".

The design of the radiation source varies with the wavelength range for which it is used (e.g., IR, UV, visible) and details of specific sources will be discussed in the appropriate instrumentation chapter. Most sources will have their intensities change exponentially with changes in voltage, so in all cases a reliable, steady power supply to the radiation source is required. Voltage regulators (line conditioners) are available to compensate for variations in incoming voltage. A double-beam optical configuration may also be used to compensate for variations in source stability, as described in Section 2.5.5.

There are two major types of radiation sources used in analytical spectroscopy: **continuum sources** and **line sources**. Continuum sources emit radiation over a wide range of wavelengths and the intensity of emission varies slowly as a function of wavelength. Typical continuum sources include the tungsten filament lamp which produces visible radiation, light-emitting diodes (LEDs) for the visible region, the deuterium lamp for the UV region, high-pressure mercury or xenon arc lamps for the UV region, and heated solid ceramics or heated wires for the IR region of the spectrum. Continuum sources are used for most molecular absorption and fluorescence spectrometric instruments. Line sources, in contrast, emit only a few discrete wavelengths of light, and the intensity is a strong function of the wavelength. Typical line sources include hollow cathode lamps and electrodeless discharge lamps, used in the UV and visible regions for AAS and atomic fluorescence spectrometry, sodium or mercury vapor lamps (similar to the lamps used in street lamps) for lines in the UV and visible regions, and lasers. Lasers are high-intensity **coherent** line sources; lasers are available with emission lines in the UV, visible, and IR regions. They are used as sources in Raman spectroscopy, molecular, and atomic fluorescence spectroscopy.

2.5.2 WAVELENGTH SELECTION DEVICES

2.5.2.1 FILTERS

The simplest and most inexpensive way to select certain portions of the electromagnetic spectrum is with a filter. There are two major types: absorption filters and interference filters. Absorption filters can be as simple as a piece of colored glass. In Section 2.1, we discussed how blue glass transmits blue wavelengths of the visible spectrum but absorbs red and yellow wavelengths. This is an example of an absorption filter for isolating the blue region of the visible spectrum. Colored glass absorption filters that isolate various ranges of visible light are stable, simple, and cheap, so they are excellent for use in portable spectrometers designed to be carried into the field. The biggest limitation is that the range of wavelengths transmitted is broad. The transmission range may be 50–300 nm for typical absorption filters. Absorption filters are limited to the visible region of the spectrum and the X-ray region.

The second type of filter is the interference filter, constructed of multiple layers of different materials. The filter operates on the principle of constructive interference to transmit selected wavelength ranges. The wavelengths transmitted are controlled by the thickness and refractive index of the center layer of material. Interference filters can be constructed for transmission of light in the IR, visible, and UV regions of the spectrum. The wavelength ranges transmitted are much smaller than for absorption filters, generally 1–10 nm, and the amount of light transmitted is generally higher than for absorption filters.

2.5.2.2 MONOCHROMATOR

A **monochromator** consists of a dispersion element, an entrance slit and an exit slit, plus lenses and mirrors for collimating and focusing the beam of radiation. The function of the dispersion element is to spread out in space or *disperse*, the radiation falling on it according to wavelength. The two most common types of dispersion elements are prisms and gratings. You are probably already familiar with the ability of a glass prism to disperse white light into a rainbow of its component colors.

The entrance slit allows light from the source to fall on the dispersion element. The dispersed light falls on the exit slit of the monochromator. The function of the exit slit is to permit only a very narrow band of light to pass through to the sample and detector. One way to accomplish this is to rotate the dispersion element to allow dispersed light of different wavelengths to fall on the exit slit in sequence. For example, a white light source is dispersed into violet through red light by a prism or grating. The dispersion element is rotated slowly, allowing first violet light through the exit slit, then blue light, and so on all the way to red light. In this way, the monochromator sorts polychromatic radiation from a source into nearly monochromatic radiation leaving the exit slit.

Prisms. Prisms are used to disperse IR, visible, and UV radiation. The most common prisms are constructed of quartz for the UV region, silicate glass for the visible and near-IR region, and NaCl or KBr for the IR region. Prisms are shaped like bars with triangular cross-sections. Polychromatic light passing through the entrance slit is focused on a face of the prism such that *refraction*, or bending, of the incident light occurs. Different wavelengths of light are refracted to different degrees, and the spatial separation of wavelengths is therefore possible. The refractive index of prism materials varies with wavelength. A quartz prism has a higher index of refraction for short wavelength radiation than for long wavelength radiation; therefore, short wavelength radiation is bent more than long wavelength radiation. In the visible region of the spectrum, red light would be bent less than blue light on passing through such a prism, as shown in Figure 2.14. Prisms were historically the most used dispersion devices in monochromators, but they have been replaced by diffraction gratings or by Fourier Transform (FT) systems.

Diffraction Gratings. UV, visible, and IR radiation can be dispersed by a diffraction grating. A diffraction grating consists of a series of closely spaced parallel grooves cut (or *ruled*) into a hard glass, metallic, or ceramic surface (Figure 2.15). The surface may be flat or concave, and is usually coated on the ruled surface with a reflective coating. A grating for use in the UV






FIGURE 2.14 Dispersion of visible light by a prism.





Enlarged side view

FIGURE 2.15 Highly magnified schematic view of a diffraction grating.

and visible regions will contain between 500 and 5000 grooves/mm, while a grating for the IR region will have between 50 and 200 grooves/mm. Traditionally, the grooves in a grating were cut mechanically with a diamond-tipped tool, a time-consuming and expensive operation. This master grating is used for casting replica gratings out of polymer resin. The replica gratings duplicate the grooves in the master and are coated with a reflective coating, such as aluminum, for use. Most gratings are now produced by a holographic technique. The grating is made by coating the grating substrate with an optically flat photosensitive polymer film. The film is exposed to the interference pattern from laser beams and the interference pattern is "burned" into the film. The grooves from the interference pattern are then etched into the substrate to make the master grating, using chemical or ion etching to shape the grooves to the desired shape. The use of a laser interference pattern to form the grooves results in more perfect gratings at lower cost than mechanically ruled master gratings. These holographic gratings can be used in instruments directly or can serve as master gratings for the manufacture of replica holographic gratings. Holographic gratings can be made in many shapes other than the traditional plane or concave shape and the grooves may be uniform or nonuniform in spacing, depending on the application. The size of a typical diffraction grating varies from about 25×25 to 110×110 mm.

Dispersion of light at the surface of a grating occurs by diffraction. Diffraction of light occurs because of constructive interference between reflected light waves. The path of one wave is shown in Figure 2.16. Parallel waves can be envisioned on adjacent grooves. Constructive interference or diffraction of light occurs when

$$(2.17) n\lambda = d(\sin i \pm \sin \theta)$$




FIGURE 2.16 Cross-section diagram of a diffraction grating showing diffraction of a single beam of light. Symbols: i = angle of incidence, $\theta =$ angle of diffraction (or reflectance), $\beta =$ blaze angle of the grating, d = grating spacing. (Modified from Dean and Rains, used with permission.)




FIGURE 2.17 The angle of diffraction of light from a grating depends not only on the wavelength but also on the *order of diffraction, n*. Wavelengths of 200, 300, and 600 nm are diffracted at different angles in first order (n = 1), but 200 nm light in third order (n = 3) and 300 nm light in second order (n = 2) diffract at the same angle as 600 nm light in first order. The three wavelengths overlap.

where n is the order of diffraction (must be an integer: 1, 2, 3...); λ , the wavelength of the radiation; d, the distance between grooves; i, the angle of incidence of the beam of light; and θ , the angle of dispersion of light of wavelength λ .

The angle of incidence i and the angle of dispersion θ are both measured from the normal to the grating. For a given value of n, but different values of λ , the angle of dispersion θ is different. Separation of light occurs because light of different wavelengths is dispersed (diffracted) at different angles.

One problem with gratings is that light with several different wavelengths may leave the grating at the same angle of dispersion. For example, suppose that a beam of radiation falls on a grating at an angle i. From Eq. (2.17), for a given angle of dispersion θ , the product $n\lambda$ is a constant. Any combination of n and λ that equals this constant will satisfy the equation. Assume $\lambda = 600$ nm and n = 1 gives an angle of dispersion $= \theta$; then, if $\lambda = 200$ nm and n = 13, the angle is also θ , and so on. Radiation with each of these wavelengths is dispersed at an angle θ and travels down the same light path, as illustrated in Figure 2.17. Wavelengths of light that are related in this way are said to be different orders of diffracted radiation. They are not separated by gratings. The wavelengths of radiation traveling the same path after dispersion are related by the number *n*, which may take the value of any whole number. On highquality spectrometers, different orders are separated by using a small prism or a filter system as an order sorter in conjunction with the grating (Figures 2.18 and 2.19). It is common for IR instruments to use filters as order sorters. As the grating rotates to different wavelength ranges, the filters rotate to prevent order overlap, and only one wavelength reaches the detector. Excellent tutorials on diffraction gratings and the optics of spectroscopy are available on the Internet from the instrument company Horiba Scientific (www.horiba.com) by typing "optics of spectroscopy tutorial" into the search box on the home page.




FIGURE 2.18 Prism used as an order sorter for a grating monochromator.




FIGURE 2.19 A filter is used as an order sorter to prevent higher-order wavelengths from reaching the grating.

2.5.2.3 RESOLUTION REQUIRED TO SEPARATE TWO LINES OF DIFFERENT WAVELENGTH

Monochromator Wavelength Accuracy. Before discussing the ability of a system to separate two wavelengths, it is important that the wavelength scale of the system be assessed. For the UV/VIS region of the spectrum, this can be done by scanning either a holmium or didymium glass or commercially available sealed quartz cuvettes filled with a stable solution of holmium perchlorate or didymium perchlorate. One source of such wavelength reference standards is Starna Cells, Inc. (www.starnacells.com). These compounds give a series of sharp peaks throughout the UV/VIS region, as seen in Figure 2.20, and should be run on a regular basis to ensure that the wavelength reading from the monochromator system is accurate. Similar types of standards are available to check wavelength accuracy in the far UV and NIR regions.

Resolution of a Monochromator. The ability to disperse radiation is called *resolving power*. Alternative designations include *dispersive power* and *resolution*. For example, in order to observe an absorption band at 599.9 nm without interference from an absorption band at 600.1 nm, we must be able to resolve, or separate, the two bands.




FIGURE 2.20 Didymium oxide UV/VIS wavelength reference spectra, from a sealed quartz cell containing didymium oxide in perchloric acid solution. (Courtesy of Starna Cells, Inc., Atascadero, CA [www.starnacells.com].)

The resolving power R of a monochromator is equal to $\lambda/\delta\lambda$, where λ is the average of the wavelengths of the two lines to be resolved and $\delta\lambda$ is the difference in wavelength between these lines. In the present example, the required resolution is:

(2.18)
$$R = \frac{\lambda}{\delta \lambda}$$

$$R = \frac{\text{average of 599.9 and 600.1}}{\text{absolute difference between 599.9 and 600.1}} = \frac{600}{0.2} = 3000$$

Resolution of a Prism. The resolving power *R* of a prism is given by:

$$(2.19) R = t \frac{\mathrm{d}\eta}{\mathrm{d}\lambda}$$

where t is the thickness of the base of the prism and $d\eta/d\lambda$ is the rate of change of dispersive power (or refractive index) η of the material of the prism with wavelength. For the resolution of two beams at two wavelengths λ_1 and λ_2 , it is necessary that the refractive index of the prism be different at these wavelengths. If it is constant, no resolution occurs. The resolving power of a prism increases with the thickness of the prism. Resolution can be maximized for a given wavelength region by choosing the prism material to maximize $d\eta/d\lambda$. For example, glass prisms disperse visible light better than quartz prisms. For maximum dispersion, a prism is most effective at wavelengths close to the wavelengths at which it ceases to be transparent.

Resolution of a Grating. The resolving power of a grating is given by:

$$(2.20) R = nN$$

where n is the order and N is the total number of grooves in the grating that are illuminated by light from the entrance slit. Therefore, longer gratings, smaller groove spacing, and the use of higher orders (n > 1) result in increased resolution. Suppose that we can obtain a grating with 500 grooves/cm. How long a grating would be required to separate the sodium D lines at 589.5 and 589.0 nm in first order?

We know from Eq. (2.18) that the required resolution R is given by:

$$R = \frac{589.25}{0.5} = 1178.5$$

The resolution of the grating must therefore be at least 1179 (to four significant figures). R = nN; therefore, 1179 = nN. In first order, n = 1; hence N, the total number of grooves required, is 1179. The grating contains 500 grooves/cm. It must be (1179/500) cm long, or 2.358 cm. This assumes that the entire grating surface is illuminated during use.

In a separate example, we may ask how many grooves per centimeter must be cut on a grating 3.00 cm long to resolve the same sodium D lines, again assuming that the entire grating is illuminated. The required resolution is 1179, and for first order, nN = N = 1179 total grooves are required. Therefore, the number of grooves needed per cm is:

$$N/cm = 1179/3.00 cm = 393 lines/cm$$

It is not possible to cut a fraction of a groove or to illuminate a fraction of a groove; hence *N* must be a whole number in all calculations. This may require rounding off a calculated answer to the nearest whole number.

In practice, the resolution of a grating monochromator system in the UV is usually assessed by measuring benzene vapor, which gives rise to a number of close but sharp absorption lines. Sealed quartz cells containing benzene vapor are commercially available for performing this assessment, which is normally done at several bandwidths, as shown in Figure 2.21.




FIGURE 2.21 (a) Spectrum of benzene vapor. (b) Spectra of benzene vapor taken at two different bandwidths for testing resolution of a grating-based instrument. (Courtesy of Starna Cells, Inc. Atascadero, CA [www.starnacells.com].)

Dispersion of a Grating Monochromator. The resolution of a monochromator measures its ability to separate adjacent wavelengths from each other. Resolution is related to a useful quantity called the reciprocal dispersion, or reciprocal linear dispersion, D^{-1} .

where the reciprocal dispersion equals the change in wavelength, $d\lambda$, divided by dy, the corresponding change in y, the distance separating the wavelengths along the dispersion axis.




FIGURE 2.22 Spectral bandwidth measurements using a sealed cell containing 0.02 % toluene in hexane and a hexane blank cell. (Courtesy of Starna Cells, Inc. Atascadero, CA [www.starnacells.com].)

Units for D^{-1} are usually nm/mm. The reason D^{-1} is useful is that the **spectral bandpass** or **spectral bandwidth** of the light exiting a monochromator is directly related to D^{-1} and the slit width of the monochromator.

$$(2.22) Spectral bandwidth = sD^{-1}$$

where *s* is the slit width of the monochromator. The spectral bandwidth represents the width of the wavelength range of 75 % of the light exiting the monochromator. For a monochromator that uses a grating as the dispersion device, the reciprocal linear dispersion is:

$$(2.23) D^{-1} = \frac{d}{nF}$$

SBW

where d is the distance between two adjacent grooves on the grating, n is the diffraction order, and F is the focal length of the monochromator system. The reciprocal dispersion for a grating-based system is therefore essentially constant with respect to wavelength. Spectral bandwidth (SBW) in the UV region can be determined by measuring a solution of 0.02 % toluene in hexane using a matched hexane reference cell. The absorbance is measured at both 268.7 nm and 267.0 nm (Figure 2.22). The ratio of absorbances ($A_{268.7}/A_{267.0}$) is calculated and is directly related to the SBW, as shown in Table 2.6.

The dispersion of a prism-based monochromator is a more complex calculation and will not be covered due to the predominance of gratings in even inexpensive modern instruments.

Echelle Monochromator. From Figures 2.15 and 2.16, you can see that the cuts shown on the surface of the gratings are not symmetrical v-shapes. Each cut has a short face and a long face. This type of grating is known as a blazed grating. The conventional blazed diffraction grating uses the long face of the groove, as seen in Figure 2.16, and the angle of the cut, called the blaze angle β , is generally optimized for first order diffraction. It is possible to rule a grating with a much higher blaze angle and to use the short side of the groove for diffraction; this type of grating is called an **echelle** grating. The angle of dispersion θ is much higher from an echelle grating than from a conventional grating. The echelle system improves dispersion by

TABLE 2.6	Bandw	h Ratios			
Ratio:	2.5	2.1	1.6	1.4	1.0

20

3.0

Source: Courtesy of Starna Cells, Inc. Atascadero, CA (www.starnacells.com).




FIGURE 2.23 An echelle spectrometer optical layout. The echelle grating disperses the light to a second wavelength selector, called a cross-disperser. (©1997-2020 PerkinElmer, Inc. All rights reserved. Printed with permission. www.perkinelmer.com.)

this increase in θ and by the use of higher orders (larger values of n). The result is a ten-fold improvement in resolution over a conventional grating monochromator of the same focal length. Because of the multiple high orders diffracted, it is necessary to use a second dispersing element to sort the overlapping orders. The second dispersing element, called a cross-disperser, is arranged to sort the light at right angles to the grating, so a two-dimensional (2D) spectrum results. An echelle optical layout for ICP-OES is shown in Figure 2.23. An example of the 2D output, with wavelength plotted on the y-axis and diffraction order on the x-axis, is shown in Figure 2.24. Commercial echelle spectrometers will be discussed in Chapter 7.




FIGURE 2.24 Illustration of the two-dimensional (2D) array of dispersed light produced by an echelle spectrometer. (©1997-2020 PerkinElmer, Inc. All rights reserved. Printed with permission. www.perkinelmer.com.)

2.5.3 OPTICAL SLITS

A system of slits (Figure 2.13) is used to select radiation from the light beam both before and after it has been dispersed by the wavelength selector. The jaws of the slit are made of metal and are usually shaped like two knife edges. They can be moved relative to each other to change the mechanical width of the slit as desired. For the sake of simplicity, Figure 2.13 does not show the system of lenses or mirrors used in a monochromator to focus and collimate the light as needed.

The *entrance slit* permits passage of a beam of light from the source. Radiation from the light source is focused on the entrance slit. Stray radiation is excluded. After being passed through the entrance slit, the radiation is collimated into a parallel beam of light, which falls onto and completely illuminates one side of the prism or the entire grating. The prism or grating disperses the light in different directions according to wavelength. At the setting selected for the dispersion device, one wavelength is refocused onto the exit slit. The emerging light is redirected and focused onto the detector for intensity measurement.

Lenses or front-faced mirrors are used for focusing and collimating the light. In the IR, front-faced mirrors are always more efficient than lenses and do not absorb the radiation. They are also easily scratched, since the reflecting surface is on the front and not protected by glass, as is the case with conventional mirrors. Back-faced mirrors are not used because the covering material (e.g., glass) may absorb the radiation. One type of monochromator system using mirrors for focusing, collimation and a grating for dispersion is presented in Figure 2.25, with the entrance and exit slits shown.

The physical distance between the jaws of the slit is called the *mechanical slit width*. Modern computer-controlled instruments set and read the slit width through software that controls a stepper motor operating the slit mechanism. In UV absorption spectroscopy, mechanical slit widths are of the order of 0.3–4 μ m. In IR spectroscopy, slit widths between 0.1 and 2.0 mm are common for dispersive instruments. There are no slits in FTIR spectrometers.

The wavelength range of the radiation that passes through the exit slit is called the *spectral bandpass* or *spectral bandwidth* or *spectral slit width*. As noted above, this bandpass can be measured by using the absorption spectrum of toluene in hexane. It can also be




FIGURE 2.25 A grating monochromator showing the optical slits. The entrance slit is on the right and the exit slit on the left. (Dean, J.A. and Rains, T.C., Eds., *Flame Emission and Absorption Spectrometry*, Vol. 2, Marcel Dekker, Inc., New York, 1971. Used with permission.)

measured by passing an emission line of very narrow width through the slits to the detector. By rotating the dispersion element, we can record the wavelength range over which response occurs. After correcting for the actual width of the emission line, we can calculate the spectral bandpass. For example, to measure the spectral bandpass for a monochromator system used as an AAS, we can use a cadmium hollow cathode lamp, which produces very narrow atomic emission lines from cadmium. One of those lines occurs at 228.8 mm. We move our dispersion device and monitor the signal at the detector. The emission line from cadmium gave a signal at all wavelengths from 228.2 to 229.4 nm. This means that the cadmium emission line reached the detector over a wavelength range that was 1.2 nm wide. In this example, no correction was made for the actual width of the cadmium 228.8 nm line, which is negligible. The signal that is measured in the above experiment has a Gaussian peak shape. The spectral bandwidth in this type of measurement is usually defined as the width of the signal peak at one-half of the maximum peak height, called the full width at half maximum (FWHM). Spectral bandpasses are normally on the order of 0.3-4 nm. Note that the spectral bandwidth is three orders of magnitude smaller than the physical slit width, nm vs. µm.

If the mechanical slit width were made wider, the spectral bandpass would simultaneously increase and vice versa. The spectral bandpass is one of the components of the spectrometer that affects resolution. For example, with the mechanical slit settings described in the AAS example, it would not be possible to resolve an emission line at 229.0 nm from the 228.8 nm Cd line, because both would pass through the slits. In practice, the slits are kept as narrow as possible to ensure optimum resolution; however, they must be wide enough to admit sufficient light to be measured by the detector. The final choice of slit width is determined by the analyst based on the particular sample at hand. A good rule of thumb is to keep the slits as narrow as possible without impairing the functioning of the detector or the ability to detect a specified amount of analyte.

By rotating the grating, the wavelength range passing through the exit slit can be changed. By rotating the dispersion element from one extreme to another, the complete spectrum can be scanned.

2.5.4 DETECTORS

The detector is used to measure the intensity of the radiation that falls on it. It does this by converting the radiation energy into electrical energy. The amount of energy produced is usually low and must be amplified. The signal from the detector must be steady and representative of the intensity of radiation falling on it. Amplifying the signal from the detector increases its response. In practice, the response can be increased until the noise level of the signal becomes too great; at this point, the amplification is decreased until the noise level becomes acceptable.

There are a number of different types of photon detectors, including the photomultiplier tube, the silicon photodiode, the photovoltaic cell, and a class of multichannel detectors called charge transfer devices. Charge transfer detectors include photodiode arrays, charge-coupled devices (CCDs), and charge-injection devices (CIDs). These detectors are used in the UV/VIS and IR regions for both atomic and molecular spectroscopy.

In addition to photon detectors, there are several important detectors that measure heat. These heat detectors or thermal detectors are particularly useful in the IR region, where the energy of photons is very low. The detectors will be discussed at length in the following chapters on specific techniques.

2.5.5 SINGLE-BEAM AND DOUBLE-BEAM OPTICS

Single-beam optics, shown schematically in Figure 2.13, are used for all spectroscopic *emission* methods. In emission procedures, the sample is put where the source is located in Figure 2.13.




FIGURE 2.26 Error caused by baseline drift in a spectroscopic measurement.

In spectroscopic *absorption* studies, the intensity of radiation before and after passing through the sample must be measured. When single-beam optics are used, any variation in the intensity of the source while measurements are being made may lead to analytical errors. Slow variation in the average signal with time is called *drift*, displayed in Figure 2.26. Drift can cause a direct error in the results obtained. As shown in Figure 2.26, a signal has been set to zero at Time 0 with no analyte present. As time increases toward Time 1, the signal with no analyte present (called the baseline signal) increases due to drift. At Time 1, a sample is measured and gives an increased signal due to analyte present (the peak shown above the baseline). The total signal, sample plus baseline, at Time 1 is 5 units. The baseline continues to drift upwards and at Time 2, the sample is measured again. As can be seen in the figure, the peak for sample above the baseline is the same height as the peak at Time 1, but the total signal (peak plus baseline) is now 10 units. If the baseline drift were not accounted for, the analyst would conclude that the sample at Time 2 has twice as much analyte as the sample at Time 1—a direct error.

There are numerous sources of drift. The *radiation source* intensity may change because of line voltage changes, the source warming up after being recently turned on, or the source deteriorating with time. The *monochromator* may shift position as a result of vibration or heating and cooling causing expansion and contraction. The line voltage to the *detector* may change, or the detector may deteriorate with time and cause a change in response. Errors caused by drift lead to an error in the measurement of the emission signal or the absorption signal compared with the standards used in calibration. The problem can be reduced by constantly checking the light intensity or by using a standard solution measured at frequent intervals during the analysis. Single-beam optics are particularly subject to errors caused by drift. The problems associated with drift can be greatly decreased by using a double-beam system.

The double-beam system is used extensively for spectroscopic absorption studies. The individual components of the system have the same function as in the single-beam system, with one very important difference. The radiation from the source is *split* into two beams of approximately equal intensity using a *beam splitter*, shown in Figure 2.27. One beam is termed the *reference beam*; the second beam, which passes through the sample, is called the *sample beam*. The two beams are then recombined and pass through the monochromator and slit systems to the detector. In Figure 2.27, there is a cell in the reference beam that




FIGURE 2.27 Schematic diagram of a double-beam optical system.

would be identical to the cell used to hold the sample. The reference cell may be empty or it may contain the solvent used to dilute the sample, for example. This particular arrangement showing the monochromator after the sample is typical of a dispersive IR double-beam spectrophotometer. There are many commercial variations in the optical layout of double-beam systems.

As shown in Figure 2.28(a), the beam splitter may be a simple mirror plate into which a number of holes are drilled. Light is reflected by the mirror plate and passes down the sample beam path. An equal portion of light passes through the holes in the plate and forms the reference beam. Another convenient beam splitter is a disk with opposite quadrants removed (Figure 2.28(b)). The disk rotates in front of the radiation beam and the mirrored surface reflects light into the sample path. The missing quadrants permit radiation to pass down the reference path. Each beam of light is intermittent and arrives at the detector in the form of an alternating signal. When no radiation is absorbed by the sample, the two beams are equal and recombine and form a steady beam of light. However, when radiation is absorbed by the sample, the two beams are not equal, and an alternating signal arrives at the detector (Figure 2.29).

Using the double-beam system, the *ratio* of the reference beam intensity to the sample beam intensity is measured. Because the ratio is used, any variation in the intensity of radiation from the source during measurement does not introduce analytical error. This advantage revolutionized absorption spectroscopy. Drift in the signal affects the sample and reference beams equally. Absorption measurements made using a double-beam system are virtually independent of drift and therefore more accurate.




FIGURE 2.28 (a) Plate beam splitter. (b) Rotating disk beam splitter (or *chopper*).




FIGURE 2.29 Radiation intensity reaching the detector using double-beam optics and a rotating disk beam splitter. (a) No absorption by the sample; (b) 50 % absorption by the sample.

2.5.6 DISPERSIVE OPTICAL LAYOUTS

Configurations of the common components of dispersive spectroscopy systems are shown below for the most used types of spectroscopy. Arrows show the light path in each layout. In layouts 1 and 3, an external source of radiation is required, but for 3, the source is generally oriented at right angles to the sample. Emission, layout 2, does not require an external radiation source; the excited sample is the source. For absorption, fluorescence, phosphorescence, and scattering, the source radiation passes through the dispersive device, which selects the wavelength, and into the sample. The selected wavelength passes through the sample and reaches the detector, where the intensity of the signal is converted to an electrical signal. In emission, the radiation that emanates from the sample passes through the dispersive device, which selects one wavelength at a time to reach the detector. The detector signal in all types of spectroscopy is processed (amplified, smoothed, derivatized, or otherwise transformed) and an output is obtained. The output may be graphical (e.g., a plot of intensity vs. wavelength or what we call a *spectrum*), tabular, or both. In some absorption spectrometers, the position of the sample and the dispersive device may be reversed. In AAS, for example, the sample is positioned between the source and the dispersive device for reasons discussed in Chapter 6.

```
    Absorption spectroscopy:
        Source → Dispersive device → Sample → Detector → Data output
    Emission spectroscopy:
        Sample → Dispersive device → Detector → Data output
    Fluorescence, phosphorescence, and scattering spectroscopy:
        Sample → Dispersive device → Detector → Data output
        ↑
        Dispersive device
        ↑
        Source
```

The dispersive spectroscopy systems discussed above are *sequential systems*: they separate light into its component wavelengths and spread them into a spectrum. The intensity

can be measured at each point along a path where wavelength is proportional to position. Alternatively, a *simultaneous system* can measure all wavelength regions simultaneously with an *array detector*. Simultaneous systems acquire more information in less time. In the UV/VIS region, one-dimensional (1D) photodiode arrays or 2D CCDs, similar to those found in modern digital cameras, are employed. These will be discussed in Chapter 3.

Detectors for the less energetic IR wavelengths cannot be as easily miniaturized, so dispersive IR operates with the slow scanning approach. To obtain high wavelength resolution with scanning instruments requires restricting the wavelength region reaching the detector to a very narrow window. This in turn requires scanning the spectrum slowly to achieve a desired sensitivity.

2.5.7 FOURIER TRANSFORM SPECTROMETERS

Fourier Transform spectrometers take a very different approach to acquiring a spectrum than that used in dispersive systems. It would be ideal to measure the light at all wavelengths simultaneously in a manner that will permit reconstruction of the intensity vs. wavelength curve (the spectrum). If the wavelength information is encoded in a well-defined manner, such as by modulation of the light intensity using an interferometer, mathematical methods allow the information to be interpreted and presented as the same type of spectrum obtained from a dispersive instrument. An instrument that does this without a dispersive device is called a multiplex instrument. If all of the wavelengths of interest are collected at the same time without dispersion, the wavelengths and their corresponding intensities will overlap. The resulting overlapping information has to be sorted out in order to plot a spectrum. A common method of sorting or "deconvoluting" overlapping signals of varying frequency (or wavelength) is a mathematical procedure called Fourier analysis. The example presented here is of IR spectroscopy, its first application in instrumental analytical chemistry, but the principle is also employed with other techniques in which analytical data is displayed as a spectrum of response vs. frequency, for example, NMR and ion cyclotron resonance MS.

Fourier analysis permits any continuous curve, such as a complex spectrum of intensity peaks and valleys as a function of wavelength or frequency, to be expressed as a sum of sine or cosine waves varying with time. Conversely, if the data can be *acquired* as the equivalent sum of these sine and cosine waves, it can be *Fourier transformed* into the spectrum curve. This requires data acquisition in digital form, substantial computing power, and efficient software algorithms, all now readily available in personal computers, laptops, and hand-held devices. The computerized instruments employing this approach are called FT spectrometers—FTIR, FTNMR, and FTMS instruments, for example.

FT optical spectroscopy uses an **interferometer** similar in design to that of the Michelson interferometer shown schematically in Figure 2.30. To simplify the discussion, we will initially consider a source that produces monochromatic radiation of wavelength λ . The source radiation strikes the beam splitter, which transmits half of the light to the fixed mirror and reflects the rest to a mobile mirror. The mobile mirror can be programmed to move at a precisely controlled constant velocity along the path of the beam. The beams are reflected from the mirrors back to the beam splitter. Half of each ray is directed through the sample holder to the detector. The other halves travel back in the direction of the source and do not need to be considered further. If the fixed and mobile mirrors are at exactly equal distances from the beam splitter, the two half beams will combine in phase. The combined wave will have twice the amplitude of each half and the detector signal will be at its maximum. If the mobile mirror then moves a distance equal to $\lambda/4$, the two half beams will combine 180° (i.e., $\lambda/2$) out of phase. The beams interfere destructively and the detector registers no signal. For all other values of path difference between the mirrors, partial destructive interference occurs. As the mobile mirror moves at constant speed, the signal reaching the detector cycles regularly through this repetitive pattern of constructive and destructive interference. It maximizes when the path difference δ is an integral multiple of λ and goes to zero when δ is a half-integral multiple of λ . In FTIR, δ is called the *retardation*.




FIGURE 2.30 Schematic of a Michelson interferometer-based FTIR spectrometer.

A plot of the signal (power, intensity) vs. δ is called an **interferogram**; for monochromatic light, it has the form of a simple pure cosine curve:

(2.24)
$$P(\delta) = B(\overline{u})\cos(2\pi\delta\overline{u})$$

where $P(\delta)$ is the amplitude of the signal reaching the detector, $B(\overline{u})$ is a frequency-dependent constant that accounts for instrumental variables such as detector response, the amount of light transmitted or reflected by the beam splitter, and the source intensity. The wavenumber \overline{u} is equal to $1/\lambda$. The interferogram is the record of the interference signal reaching the detector. It is actually a "time-domain" spectrum; it records how the detector response changes with time. If the sample absorbs light at a specific frequency, the amplitude of that frequency changes. For a continuum source (a source with a continuously variable output of all wavelengths over the region of interest), the interferogram is a complex curve that can be represented as the sum of an infinite number of cosine waves and different amplitudes that reflect absorption of light by the sample. Although complex, if the interferogram is sampled at a sufficient number of points, modern computers using fast Fourier transformation (FFT) can process the interferogram and identify enough of the cosine waves to permit deconvolution of the data into the IR spectrum plot of intensity vs. wavelength.

FT spectrometers have a number of advantages over dispersive systems.

Compared with dispersive systems, FT spectrometers produce better S/N ratios. This results from several factors. FT instruments have fewer optical elements and no slits, so the intensity of the radiation reaching the detector is much higher than in dispersive instruments. The increase in signal increases the S/N ratio. This is called the *throughput* advantage or Jacquinot advantage. All available wavelengths are measured simultaneously, so the time needed to collect all the data to form a spectrum is drastically reduced. An entire IR spectrum can be collected in less than 1 s. This makes practical the collection and signal averaging of hundreds of repetitions of the spectrum measurement. The theoretical improvement in S/N from signal averaging is proportional to the square root of the number of spectra averaged, $(n)^{1/2}$. This advantage is called the *multiplex* or Fellgett's advantage.

FT spectrometers have high wavelength reproducibility. In an FTIR spectrometer, the position of the mobile mirror during its motion is continuously calibrated with extreme precision by parallel interferometry through the optical system using highly monochromatic light from a visible range laser, seen in Figure 2.30. This accurate position measurement translates into accurate and reproducible analytical wavelength measurements after Fourier transformation of the interferogram and permits the precise addition of multiple spectra to achieve the multiplex advantage.

It should be noted that FT spectrometers are single-beam instruments. The background must be collected separately from the sample spectrum. The ratio of the two spectra results in a background-corrected spectra, similar to that obtained from a double-beam instrument. While the sample and background spectra are not collected at exactly the same time, because the spectra can be collected rapidly and processed rapidly, background spectra can be collected regularly to avoid the problems encountered with a single-beam dispersive instrument.

2.6 SPECTROSCOPIC TECHNIQUE AND INSTRUMENT NOMENCLATURE

Spectroscopy and spectroscopic instrumentation have evolved over many years. It is not surprising that the terminology used has also evolved and is constantly evolving. Scientific terms are often defined by professional organizations and sometimes these organizations do not agree on the definitions, leading to the use of the same term to mean different things. Scientists (and students) have to keep up-to-date on the meaning of terms in order to communicate effectively but must also know the older usage of terms in order to understand the literature. The term **spectroscopy** means the study of the interaction of electromagnetic radiation and matter. The term **spectrometry** is used for quantitative measurement of the intensity of one or more wavelengths of electromagnetic radiation. **Spectrophotometry** is a term reserved for absorption measurements, where the ratio of two intensities (sample and reference) must be measured, either simultaneously in a double-beam system or sequentially in a single-beam system. The term is gradually being replaced by spectrometry; for example, *atomic absorption spectrometry* is now more common than *atomic absorption spectrophotometry*.

The terms used for instruments generally distinguish how wavelengths are selected or the type of detector used. An optical spectrometer is an instrument that consists of a dispersion device, slits, and a photoelectric detector to measure transmittance or absorbance. However, the term spectrometer is also applied to IR interferometer-based FT systems that are non-dispersive and have no slits. Spectrophotometer used to mean a double-beam spectrometer; however, the term is now used for both single-beam and double-beam dispersive spectrometers used for absorption measurements. A **photometer** is a spectroscopic instrument that uses a filter to select the wavelength instead of a dispersive device. A **spectrograph** is an instrument with a dispersive device that has a large aperture instead of a tiny exit slit and uses a solid-state imaging detector.

SUGGESTED EXPERIMENTS

- 2.1 You will need a UV/VIS spectrophotometer for this experiment and plastic or glass sample holders, either cuvettes or test tubes, depending on your instrument.
 - a. Prepare suitable standard solutions of (1) 0.1 g KMnO $_4$ per liter of water, (2) 1.0 g K $_2$ Cr $_2$ O $_7$ per liter of water, and (3) water-soluble red ink diluted 50 % with water.
 - b. Measure the absorption from 700 to 350 nm and determine the wavelength of maximum absorption for each solution.
 - c. Measure the transmittance I/I_0 at the wavelength of maximum absorption determined for each solution.

- 2.2 a. Choose one of the standard solutions prepared in Experiment 2.1(a) and measure the transmittance at the wavelength where maximum absorption occurs. Take 50 mL of this solution (solution A) and transfer it to a 100 mL volumetric flask; make up to volume with deionized water. This is solution B. Measure and record the transmittance of solution B. Dilute solution B by 50 % to obtain solution C. Measure the transmittance of solution C. Repeat this process to produce solutions D. E. and F.
 - b. Prepare a graph correlating transmittance *T* and the concentrations of solutions A, B, C, D, E, and F. *Note*: You can use most commercial spreadsheet programs (e.g., Excel) or the software package on many spectrophotometers to do the curvefitting and graph.
 - c. From the data obtained in step (a), calculate *A*, the absorbance of each solution. Prepare a graph correlating *A*, the absorbance, with the concentrations of solutions A, B, C, D, E, and F.
 - d. Is one graph preferred over the other for use in obtaining information about concentrations of unknown samples? Why or why not?
- 2.3 a. Add 10.0 mL of the $K_2Cr_2O_7$ solution prepared in Experiment 2.1 to 10.0 mL of the KMnO₄ solution prepared in Experiment 2.1. Mix well and measure the absorption spectrum.
 - b. Add 10.0 mL of the $K_2Cr_2O_7$ solution prepared in Experiment 2.1 to 10.0 mL deionized water. Mix well and measure the absorption spectrum.
 - c. Add 10.0 mL of the KMnO₄ solution prepared in Experiment 2.1 to 10.0 mL of deionized water. Mix well and measure the absorption spectrum. Using the wavelength of maximum absorption for each compound, answer the following questions. Is there a change in the absorbance at the wavelengths of maximum absorption for the solution containing both compounds compared with the solutions containing a single compound? Is the total amount of light absorbed by the single solutions equal to the amount absorbed by the mixture? Would this change in absorbance (if any) be a source of error? Is the error positive or negative? Can you think of ways to correct for this error if you have to measure a mixture of potassium permanganate and potassium dichromate?
- 2.4 Measure the absorbance of a freshly prepared aqueous solution of KMnO₄ at its wavelength of maximum absorption. The concentration of the solution should be such that the absorbance is about 0.6–0.8. Make the solution in a volumetric flask and make your first measurement by pouring the solution into the sample holder directly from the flask. Now, pour the solution from the flask into a beaker or wide-mouth jar (you want to maximize the surface area). Leave the container open to the atmosphere for 5 min and then measure the absorbance of the solution again. Repeat measurements at 5 min intervals. (If no change is seen, cap the sample and shake it well, then uncap and allow it to sit in the air.) Plot the measured absorbance against the time exposed to the air. The change is caused by the chemical instability of the KMnO₄ (it reacts with the air). If it were being used as a standard solution for calibration, this change would be a source of error. Many solutions are subject to this sort of error to a greater or lesser extent, and precautions must be taken to prevent this source of trouble. Suggest two ways to avoid this problem with KMnO₄.

PROBLEMS

- A molecule absorbs radiation of frequency 3.00×10^{14} Hz. What is the energy difference between the molecular energy states involved?
- 2.2 What frequency of radiation has a wavelength of 500.0 nm?
- 2.3 Describe the transition that occurs when an atom absorbs UV radiation.
- 2.4 Arrange the following types of radiation in order of increasing wavelength: IR, radio waves, X-rays, UV, and visible light.
- 2.5 For a given transition, does the degree of absorption by a population of atoms or molecules depend on the number in the ground state or the excited state? Explain.

- 2.6 For a given transition, does the intensity of emission by a population of atoms or molecules depend on the number in the ground state or the excited state? Explain.
- 2.7 Briefly describe three types of transitions that occur in most molecules, including the type of radiation involved in the transition.
- 2.8 State the mathematical formulation of the Beer–Lambert–Bouguer Law and explain the meaning of each symbol in the equation.
- 2.9 a. Define transmittance and absorbance.
 - b. What is the relationship between concentration and (1) transmittance, (2) absorbance?
- 2.10 Using Figure 2.12, calculate the slope of the tangent drawn through the lower point marked B by extending the line to cover a ten-fold difference in concentration. Confirm that the range shown for B–B for 1 %R.E. is correct by finding where on the upper portion of the curve you have a slope equal to the one you just calculated. Repeat the calculation for point C and confirm the C–C range.
- 2.11 The following data were obtained in an external standard calibration for the determination of iron by measuring the transmittance, at 510 nm and 1.00 cm optical path, of solutions of Fe^{2+} reacted with 1, 10-phenanthroline to give a red-colored complex.

Fe Conc. (ppm)	%Т	Fe Conc. (ppm)	%Т
0.20	90.0	3.00	26.3
0.40	82.5	4.00	17.0
0.60	76.0	5.00	10.9
0.80	69.5	6.00	7.0
2.00	41.0	7.00	4.5

- a. Calculate *A*, the absorbance, for each solution and plot *A* against concentration of iron. (You can do this using a spreadsheet program very easily.) Does the system conform to Beer's Law over the entire concentration range?
- b. Calculate the average molar absorptivity of iron when it is determined by this method.
- c. Plot (100 %T) against log concentration (Ringbom method). (1) What are the optimum concentration range and the maximum accuracy (percent relative error per 1 % transmittance error) in this range? (2) Over what concentration range will the relative analysis error per 1 % transmittance error not exceed 5 %?
- 2.12 The following data were obtained in a standard calibration for the determination of copper, as $Cu(NH_3)_4^{2+}$, by measuring the transmittance using a filter photometer.

Cu Conc. (ppm)	% T	Cu Conc. (ppm)	%T
0.020	96.0	0.800	27.8
0.050	90.6	1.00	23.2
0.080	84.7	1.40	17.2
0.100	81.4	2.00	12.9
0.200	66.7	3.00	9.7
0.400	47.3	4.00	8.1
0.600	35.8		

Calculate *A*, The absorbance, for each solution and plot *A* against concentration of copper. (You can do this using a spreadsheet program very easily.) Does the system, measured under these conditions, conform to Beer's Law over the entire concentration range? Is any deviation from the law of small or of large magnitude? Suggest a plausible cause for any deviation.

- 2.13 An amount of 0.200 g of copper is dissolved in nitric acid. Excess ammonia is added to form $\text{Cu}(\text{NH}_3)_4^{2^+}$ and the solution is made up to 1 L. The following aliquots of the solution are taken and diluted to 10.0 mL: 10.0, 8.0, 5.0, 4.0, 3.0, 2.0, and 1.0 mL. The absorbances of the diluted solution were 0.500, 0.400, 0.250, 0.200, 0.150, 0.100, and 0.050, respectively. A series of samples was analyzed for copper concentration by forming the $\text{Cu}(\text{NH}_3)_4^{2^+}$, complex and measuring the absorbance. The absorbances were (a) 0.450, (b) 0.300, and (c) 0.200. What were the respective concentrations in the three copper solutions? If these three samples were obtained by weighing out separately (a) 1.000 g, (b) 2.000 g, and (c) 3.000 g of sample, dissolving and diluting to 10.0 mL, what was the original concentration of copper in each sample?
- 2.14 What range of % transmittance results in the smallest relative error for an instrument limited by (a) noise in the thermal detector of an IR spectrometer? (b) shot-noise?
- 2.15 What is *A* if the percentage of light absorbed is (a) 90 %, (b) 99 %, (c) 99.9 %, and (d) 99.99 %.
- 2.16 What is the purpose of having and measuring a reagent blank?
- 2.17 An optical cell containing a solution was placed in a beam of light. The original intensity of the light was 100 units. After being passed through the solution, its intensity was 80 units. A second similar cell containing more of the same solution was also placed in the light beam behind the first cell. Calculate the intensity of radiation emerging from the second cell.
- 2.18 The transmittance of a solution of unknown concentration in a 1.00 cm cell is 0.700. The transmittance of a standard solution of the same material is also 0.700. The concentration of the standard solution is 100.0 ppm; the cell length of the standard is 4.00 cm. What is the concentration of the unknown solution?
- 2.19 A solution contains $1.0 \,\mathrm{mg}$ of KMnO₄/L. When measured in a $1.00 \,\mathrm{cm}$ cell at 525 nm, the transmittance was 0.300. When measured under similar conditions at 500 nm, the transmittance was 0.350. (a) Calculate the absorbance A at each wavelength. (b) Calculate the molar absorptivity at each wavelength. (c) What would T be if the cell length were in each case 2.00 cm? (d) Calculate the absorptivity if concentration is in mg/L for the solution at each wavelength.
- 2.20 A series of standard ammoniacal copper solutions was prepared and the transmittance measured. The following data were obtained:

Cu Concentration	Transmittance	Sample	Transmittance
0.20	0.900	1	0.840
0.40	0.825	2	0.470
0.60	0.760	3	0.710
0.80	0.695	4	0.130
1.00	0.635		
2.00	0.410		
3.00	0.263		
4.00	0.170		
5.00	0.109		
6.00	0.070		

Plot the concentration against absorbance (use your spreadsheet program). The transmittance of solutions of copper of unknown concentrations was also measured in the same way and the sample data in the above table were obtained. Calculate the concentration of each solution. What is missing from this experiment? List two things a good analytical chemist should have done to be certain that the results are accurate and precise.

2.21 List the components of a single-beam optical system for absorption spectroscopy. List the components of single-beam optical system for emission spectroscopy.

- 2.22 Describe the components in a grating monochromator. Briefly discuss the role of each component.
- 2.23 State the equation for the resolution of a grating.
- 2.24 a. Define mechanical slit width.
 - b. Define spectral bandpass or bandwidth.
- 2.25 What is the effect of mechanical slit width on resolution?
- 2.26 Write the expression for resolution of a grating ruled to be most efficient in second order. To resolve a given pair of wavelengths, will you need more or fewer grooves if the grating were ruled in first order?
- 2.27 What resolution is required to separate two lines λ_1 and λ_2 ?
- 2.28 What resolution is required to resolve the Na D lines at 589.0 and 589.5 nm in first order?
- 2.29 How many grooves must be illuminated on a grating to separate the Na D lines in second order?
- 2.30 A grating contains 1000 grooves. Will it resolve two lines of λ 500.0 and 499.8 nm in first order if all 1000 grooves are illuminated?
- 2.31 What are the components of a double-beam system? Describe two types of beam splitters.
- 2.32 How does a double-beam system correct for drift? Draw the alternating signal output from a double-beam system for a sample that absorbs 25 % of the incident light.
- 2.33 Give an example of an absorption filter. Over what wavelength range do absorption filters function as wavelength selectors?
- 2.34 What are the advantages of absorption filters as wavelength selectors compared with gratings? What are the disadvantages?
- 2.35 Light of 300.0 nm is diffracted from a grating in first order at an angle of incidence normal to the grating (i.e., $i = 0^{\circ}$). The grating contains 1180 grooves/mm. Calculate the angle of diffraction, θ , for this wavelength.
- 2.36 If an emission line for magnesium appears at 285.2 nm in first order, where will it appear in second order? Where will it appear in third order? If you needed to measure a first order iron emission line at 570 nm, will the presence of magnesium in the sample cause a problem? What can you do to solve the problem if one exists?
- 2.37 What are the major differences between an FT system and a dispersive system for spectroscopy?
- 2.38 Define the throughput advantage. How does it arise?
- 2.39 Define the multiplex advantage. How does it arise?
- 2.40 Draw two cosine waves of the same amplitude in phase. Draw the resulting wave if the two waves are combined. Draw two cosine waves 180° out of phase. Draw the resulting wave if these two waves are combined.
- 2.41 What is the difference between a spectrometer and a photometer? What is the difference between a spectrometer and a spectrograph?

BIBLIOGRAPHY

Ayres, G.H. Quantitative Chemical Analysis, 2nd edn; Harper and Row: New York, 1968.

Beaty, R.D.; Kerber, J.D. Concepts, Instrumentation and Techniques in Atomic Absorption Spectrophotometry; PerkinElmer, Inc.: Norwalk, CT, 1993.

Boss, C.B.; Fredeen, K.J. Concepts, Instrumentation and Techniques in Inductively Coupled Plasma Optical Emission Spectrometry, 2nd edn; PerkinElmer, Inc: Norwalk, CT, 1997.

Bruno, T.J.; Svoronos, P.D.N. CRC Handbook of Basic Tables for Chemical Analysis – Data Driven Methods and Interpretation; CRC Press: Boca Raton, FL, 2021.

Dean, J.A.; Rains, T.C., Eds. *Flame Emission and Absorption Spectrometry*; Marcel Dekker, Inc.: New York, 1971; Vol. 2.

Harris, D.C. *Quantitative Chemical Analysis*, 5th edn; W.H. Freeman and Company: New York, 1999. Hollas, J.M. *Modern Spectroscopy*; John Wiley and Sons, Ltd.: Chichester, 1996.

Ingle, J.D.; Crouch, S.R. Spectrochemical Analysis; Prentice-Hall, Inc.: Englewood Cliffs, NJ, 1988. Koenig, J.L. Anal. Chem. 1994, 66 (9), 515A.

- Meehan, E.J. Optical Methods of Analysis. Treatise on Analytical Chemistry, 2nd edn; John Wiley and Sons, Ltd: Chichester, 1981.
- Settle, F.A., Ed. *Handbook of Instrumental Techniques for Analytical Chemistry*; Prentice-Hall PTR: Upper Saddle River, NJ, 1997.
- Skoog, D.A.; Holler, F.J.; Nieman, T.A. *Principles of Instrumental Analysis*, 5th edn; Harcourt, Brace and Company: Orlando, FL, 1998.
- Willard, H.H.; Merrit, L.L.; Dean, J.A.; Settle, F.A. *Instrumental Methods of Analysis*, 7th edn; Van Nostrand: New York, NY, 1988.
- Zumdahl, S.S.; Zumdahl, S.A. Chemistry, 5th edn; Houghton Mifflin: Boston, MA, 2000.

Visible and Ultraviolet Molecular Spectroscopy

3.1 INTRODUCTION

One of the first physical methods used in analytical chemistry was based on the quality of the color in colored solutions. The first things we observe regarding colored solutions are their *hue*, or color, and the color's *depth*, or *intensity*. These observations led to the technique historically called *colorimetry*; the color of a solution could identify species (qualitative analysis) while the intensity of the color could identify the concentration of the species present (quantitative analysis). This technique was the first use of what we now understand to be absorption spectroscopy for chemical analysis. For a long time, experimental work made use of the human eye as the detector to measure the hue and intensity of colors in solutions. However, even the best analyst can have difficulty comparing the intensity of two colors with slightly different hues, and there are of course people who are color-blind and cannot see certain colors. Instruments have been developed to perform these measurements more accurately and reliably than the human eye. While the human eye can only detect visible light, this chapter will focus on both the ultraviolet (UV) and the visible (VIS) portions of the spectrum.

The wavelength range of UV radiation starts at the blue end of visible light (about 400 nm) and ends at approximately 200 nm for spectrometers operated in air. The radiation has sufficient energy to excite valence electrons in many atoms and molecules; consequently, UV radiation is involved with electronic excitation. Visible light, considered to be light with wavelengths from 800 to 400 nm, acts in the same way as UV light. It is also considered part of the electronic excitation region. For this reason, we find commercial spectroscopic instrumentation often operates with wavelengths between 800 and 200 nm. Spectrometers of this type are called UV/Visible (or UV/VIS) spectrometers. The vacuum UV region of the spectrum extends below 200 nm to the X-ray region of the spectrum at ~100 Å. It is called the vacuum UV region because oxygen, water vapor, and other molecules in air absorb UV radiation below 200 nm, so the spectrometer light path must be free of air to observe wavelengths <200 nm. The instrument light path must be kept under vacuum or purged with an appropriate non-UV absorbing gas such as argon for this region to be used. Vacuum UV radiation is also involved in electronic excitation but the spectrometers are specialized and not commonly found in undergraduate analytical laboratories. For our purposes, the term UV will mean radiation between 200 and 400 nm, unless stated otherwise. The major types of analytical spectroscopy operating within this wavelength range are listed in Table 3.1. This chapter will focus on molecular spectroscopy—the absorption and emission of UV and visible radiation by molecules and polyatomic species. We will also look at the use of scattering of visible light to provide information about macromolecules and particles. Atomic absorption spectroscopy is covered in Chapter 6 and atomic emission spectroscopy in Chapter 7.

The interaction of UV and visible radiation with matter can provide qualitative identification of molecules and polyatomic species, including ions and complexes. Structural information about molecules and polyatomic species, especially organic molecules, can be acquired. This qualitative information is usually obtained by observing the UV/VIS spectrum. Typical UV absorption spectra of some organic compounds are shown in Figure 3.1(a-c). The spectrum may be plotted as wavelength vs. absorbance, transmittance, or molar absorptivity, ϵ . The molar absorptivity is defined subsequently. In Figure 3.1(a), the absorption spectrum of

TABLE 3.1 Spectroscopy Using UV and Visible Light

Function	Analytical Field	Analytical Application
Atomic Spectroscopy		
Absorption of UV/VIS radiation	Atomic absorption spectrometry	Quantitative elemental analysis
Emission of UV/VIS radiation	Flame photometry, atomic emission spectrometry	Qualitative and quantitative multielement analysis
Emission of UV/VIS radiation	Atomic fluorescence spectrometry	Quantitative elemental analysis of ultratrace concentrations (sub-ppb)
Molecular Spectroscopy		
Absorption of UV/VIS radiation	UV/VIS Molecular absorption spectroscopy, spectrophotometry	Qualitative and quantitative determinations of aromatic and unsaturated organic compounds, including natural products; direct and indirect quantitative determination of inorganic ions, organic molecules, and biochemicals
Emission of UV/VIS radiation	Molecular fluorescence, Molecular phosphorescence	Detection of small quantities (<ng) of<br="">certain aromatic compounds and natural products; analysis of gels and glasses; determination of organic and inorganic species by "tagging"</ng)>




FIGURE 3.1 Typical UV absorption spectra for several organic molecules in solution. **(a)** the spectrum is that of pyridine dissolved in 95 % ethanol. The absorption wavelength is plotted on the *x*-axis and the logarithm of the molar absorptivity is plotted on the *y*-axis. (From Jaffé and Orchin. Reprinted with the permission of the late professor M. Orchin.) **(b)** a UV spectrum of naphthacene dissolved in cyclohexane. **(c)** the UV spectrum of benzonitrile dissolved in methanol. **(b)** and **(c)** (Copyright Bio-Rad laboratories, Informatics Division, Sadtler Software and Databases 2020. All rights reserved.)

602 UV



BENZONITRILE

IR 2255

Mol. Form. Mol. Wt.

Source

C₇H₅N 103.12

B. P. 188-189°C

The Matheson Co., Inc., E. Rutherford, N. J.

			A	В	С	D	E
	Conc.	g/L	0.140	0.140	0.140	0.0380	0.0380
Methano1	Cell	mm	5	5	5	2	2
	am		932	1010	804	9100	10600
	λ Max.	mll	277	269.5	263	230	222

	Conc. g/L			
Methano1	Cell mm			
КОН	a _m	Charled -	no change	
	λ Max. mu	onecked =	no change	

	Conc. g/L	
Methano1	Cell mm	
HC1	a _m	Cl. 1 - 1 h
	λ Max. mμ	Checked - no change




FIGURE 3.1 (Continued)

pyridine dissolved in ethanol is plotted as log ϵ vs. wavelength in ångstroms (Å). Figure 3.1(b) and c are plotted as absorbance vs. wavelength in nm. The older wavelength unit seen in these spectra was μ m; this unit has been replaced by the S.I. unit nm. Note the need for dilution in Figure 3.1(b) and (c). In (b), the solution was diluted 1:10 to bring the peak at 275 nm on scale. In (c), the absorbance peaks at 230 and 222 nm are off scale at a concentration of 0.140 g/L; the solution was diluted to a concentration of 0.038 g/L and run in a smaller pathlength cell.

Quantitative information can also be obtained by studying the absorption or emission of UV and visible radiation by molecules or polyatomic species. As a very simple example, we can look at the absorption spectrum of a red solution such as red ink in water (Figure 3.2). It can be seen that with a colorless sample of pure water, shown as the dotted line, all wavelengths




FIGURE 3.2 Visible absorption spectra of a colorless sample of pure water (dotted line), a pale red solution of red ink in water, and a dark red solution of red ink in water. Note that none of the samples absorbs red light.

of white light, including all of the red wavelengths, are transmitted through the sample. If we add one drop of red ink to water, to make a solution that appears pale red, the spectrum shows that some of the blue and yellow wavelengths have been absorbed, but all of the red light has been transmitted. If we add more red ink to the water to make a dark red solution, most of the blue and yellow light has been absorbed, but again all of the red light has been transmitted. The amount of red light falling on the eye or the detector is the same in each case; the amount of ink in the solution is related to the blue and yellow light absorbed, not to the color transmitted. We could construct a series of known amounts of red ink in water and quantitatively measure other ink solutions by measuring the amount of light absorbed at, for example, 450 nm. Concentrations of species in samples, especially solutions, are often measured using UV/VIS absorption spectrometry or fluorescence spectrometry. The measurement of concentrations or changes in concentrations can be used to calculate equilibrium constants, reaction kinetics, and stoichiometry for chemical systems. Quantitative measurements by UV/VIS spectrometry are important in environmental monitoring, industrial process control including food and beverage manufacturing, pharmaceutical quality control, and clinical chemistry, to name a just a few areas. The emission of radiation by molecules may occur in several ways following excitation of the molecule; two processes are fluorescence and phosphorescence. These processes will be discussed in Section 3.5.

3.1.1 ELECTRONIC EXCITATION IN MOLECULES

Molecules are composed of atoms that are held together by sharing electrons to form chemical bonds. Electrons in molecules move in molecular orbitals at discrete energy levels as defined by quantum theory. When the energy of the electrons is at a minimum, the molecules are in the lowest energy state, or ground state. The molecules can absorb radiation and move to a higher energy state, or *excited state*. When the molecule becomes excited, an outer shell (valence) electron moves to an orbital of higher energy. The process of moving electrons to higher energy states is called *electronic excitation*. For radiation to cause electronic excitation, it must be in the visible or UV region of the electromagnetic spectrum.

The frequency absorbed or emitted by a molecule and the energy of radiation are related by $\Delta E = hv$. The actual amount of energy required depends on the difference in energy between the ground state E_0 and the excited state E_1 of the electrons. The relationship is described by

$$\Delta E = E_1 - E_0 = h\nu$$

where E_1 is the energy of the excited state and E_0 is the energy of the ground state.

You may want to review the topics of bonding, molecular orbitals, Lewis structures, and organic chemistry in your general chemistry textbook or in the texts by Chang or Zumdahl listed in the bibliography to help you understand the material discussed subsequently. The discussion will focus on organic molecules, as the bonding is relatively easy to understand. Inorganic molecules also undergo absorption and emission of UV and visible radiation, as do complexes of organic molecules with metal ions, but the bonding in inorganic molecules and complexes of the transition metals and heavier elements is complicated due to electrons in the d and f orbitals.

Three distinct types of electrons are involved in valence electron transitions in molecules. First are the electrons involved in single bonds, such as those between carbon and hydrogen in alkanes. These bonds are called sigma (σ) bonds. The amount of energy required to excite electrons in σ bonds is usually more than UV photons of wavelengths >200 nm possess. For this reason, alkanes and other saturated compounds (compounds with only single bonds) do not absorb UV radiation and are therefore frequently very useful as transparent solvents for the study of other molecules. An example of such a non-absorbing compound is the alkane hexane, C_6H_{14} .

Next, we have the electrons involved in double and triple (unsaturated) bonds. These bonds involve a pi (π) bond. Typical examples of compounds with π bonds are alkenes, alkynes, conjugated olefins, and aromatic compounds (Figure 3.3). Electrons in π bonds are excited relatively easily; these compounds commonly absorb in the UV or visible region.

Electrons that are not involved in bonding between atoms are the third type of electrons in molecules. These are called n electrons, for nonbonding electrons. In saturated hydrocarbons, the outer shell electrons of carbon and hydrogen are all involved in bonding; hence, these compounds do not have any n electrons. Organic compounds containing nitrogen,

FIGURE 3.3 Examples of organic molecules containing π bonds. Note that benzene rings can be drawn showing three π bonds (the Kekulé structure) or with a circle inside the ring, as has been done for ethylbenzene, to more accurately depict the delocalized nature of the π electrons in aromatic compounds.

FIGURE 3.4 Examples of organic molecules with nonbonding electrons. The n electrons are represented as pairs of dots around the atom on which they are located. For the carbonyl compound, if R = H, the compound is an aldehyde; If R = A organic group, the compound is a ketone.




FIGURE 3.5 Schematic energy diagram of two s orbitals on adjacent atoms forming a σ bonding orbital and a σ^* antibonding orbital.

oxygen, sulfur, or halogens, however, frequently contain electrons that are nonbonding (Figure 3.4). Because n electrons are usually excited by UV or visible radiation, many compounds that contain n electrons absorb UV/VIS radiation.

A schematic energy diagram of two s electrons in atomic orbitals on adjacent atoms combining to form a σ bond is shown in Figure 3.5. Orbitals are conserved; therefore, two molecular orbitals are formed—a sigma bonding orbital and a higher energy sigma antibonding orbital. The antibonding orbital is denoted σ^* (called a sigma star orbital). The energy difference between σ and σ^* is equal to ΔE , shown by the large arrow. Remember that each atom has three 2p atomic orbitals. One of those p orbitals can overlap with a p orbital on an adjacent atom to form a second set of sigma orbitals. Sideways overlap of the other two p orbitals is possible, resulting in pi bonding and antibonding orbitals. The schematic energy diagram for the formation of one set of π orbitals is shown in Figure 3.6, and the energy difference between the π orbital and the antibonding π^* (pi star) orbital is shown by the large arrow. If a p orbital is filled with a pair of electrons, it will have no tendency to form a bond. Figure 3.7 shows that a filled atomic p orbital (in the atom on the right) may form a nonbonding n orbital that is not shifted in energy from the atomic orbital, while the partially filled p orbitals on each atom overlap to form a pair of pi bonding and antibonding orbitals.

A relative energy diagram of σ , π , and n electrons is shown in Figure 3.8, although there are exceptions to this general order. It can be seen that the energy required to excite an electron from a σ to a σ * orbital is considerably greater than that required to






FIGURE 3.6 Schematic energy diagram of two p orbitals on adjacent atoms forming a π bonding orbital and a π * antibonding orbital.




FIGURE 3.7 The relative energy levels of the π , π^* , and nonbonding (n) orbitals formed from p orbitals on adjacent atoms.




FIGURE 3.8 The relative energy levels of a set of σ , π , and n orbitals and the associated antibonding orbitals.

excite an electron from a π to a π° orbital or an n electron to either a σ° or a π° orbital. As a consequence, the energy necessary to excite σ electrons to σ° orbitals is greater than that available in the UV region. UV radiation is sufficient to excite electrons in π orbitals to π° orbitals or n electrons to π° or σ° orbitals.

3.1.2 ABSORPTION BY MOLECULES

Quantum mechanics provides a theoretical basis for understanding the relative energy levels of molecular orbitals and how they vary with structure. Quantum mechanics also generates a set of "selection rules" to predict what transitions occur in molecules. The transitions that occur in molecules are governed by these quantum mechanical selection rules. Some transitions are "allowed" by the selection rules, while others are "forbidden". The selection rules are beyond the scope of this text, but may be found in most physical chemistry texts or in the text by Ingle and Crouch listed in the bibliography. As is often the case with rules, there are exceptions, and many forbidden transitions do occur and can be seen in UV/VIS spectra.

When molecules are electronically excited, an electron moves from the highest occupied molecular orbital to the lowest unoccupied orbital, which is usually an antibonding orbital. Electrons in π bonds are excited to antibonding π^* orbitals, and n electrons are excited to either σ^* or π^* orbitals.

Both organic and inorganic molecules may exhibit absorption and emission of UV/VIS radiation. Molecular groups that absorb visible or UV light are called *chromophores*, from the Greek word *chroma*, color. For example, for a $\pi \to \pi^*$ transition to occur, a molecule must possess a chromophore with an unsaturated bond, such as C=C, C=O, C=N, and so on. Compounds with these types of chromophores include alkenes, amides, ketones, carboxylic acids, and oximes, among others. The other transition that commonly occurs in the UV/VIS region is the n $\to \pi^*$ transition, so organic molecules that contain atoms with nonbonded electrons should be able to absorb UV/VIS radiation. Such atoms include nitrogen, oxygen, sulfur, and the halogen atoms, especially Br and I. Table 3.2 presents some typical organic functional groups that serve as chromophores. Table 3.3 lists types of organic compounds and the wavelengths of their absorption maximum, that is, the wavelength at which the most light is absorbed. Some compounds have more than one absorption peak, so several "maxima" are listed. Compounds such as alkanes (also called paraffins) contain only σ bonds, which do not absorb radiation in the visible or UV region.

A comprehensive listing of absorbances and absorbance shifts can be found in the book by Bruno and Svoronos.

Transition metal compounds are often colored, indicating that they absorb light in the visible portion of the spectrum. This is due to the presence of unfilled d orbitals. The exact wavelength of the absorption band maximum depends on the number of d electrons, the geometry of the compound, and the atoms coordinated to the transition metal.

TABLE 3.2 Organic Functional Groups That Can Absorb UV/VIS
Radiation

Functional Group	Chemical Structure	Electronic Transitions
Acetylenic	—C=C—	$\pi \to \pi^{^*}$
Amide	—CONH ₂	$\pi \mathop{\rightarrow} \pi^{\scriptscriptstyle *} \text{, } \cap \mathop{\rightarrow} \pi^{\scriptscriptstyle *}$
Carbonyl	>C=O	$\pi \mathop{ ightarrow} \pi^*$, $\mathop{ ightarrow} \pi^*$
Carboxylic acid	—COOH	$\pi \mathop{ ightarrow} \pi^*$, $\mathop{ ightarrow} \pi^*$
Ester	—COOR	$\pi \mathop{ ightarrow} \pi^*$, $\mathop{ ightarrow} \pi^*$
Nitro	NO ₂	$\pi \mathop{ ightarrow} \pi^*$, $\mathop{ ightarrow} \pi^*$
Olefin	>C=C<	$\pi \mathop{\rightarrow} \pi^{\scriptscriptstyle *}$
Organoiodide	R—I	$n \rightarrow \sigma^*$
Thiol	R—SH	$n \rightarrow \sigma^*$

Note: $R = \text{any organic group (e.g., CH}_3, C_2H_5, C_6H_5, \text{ etc.)}.$

TABLE 3.3	Absorption Wavelengths of Typical Organic Functional
	Groups

Chromophore	System	Wavelength of Absorption Maximum, λ_{\max} (nm)
Amine	-NH ₂	195
Bromide	—Br	208
lodide	—	260
Thioketone	>C=S	460
Thiol	—SH	220
Ester	—COOR	205
Aldehyde	—CHO	210
Carboxylic acid	—COOH	200–210
Nitro	-NO ₂	210-270
Nitrile	—C=N	<160
Azo	N=N	285-400
Conjugated olefins	(—HC=CH—) ₂	210–230
	(—HC=CH—) ₃	260
	(—HC=CH—) ₅	330
	(—HC=CH—) ₁₀	460
Benzene		198
		255
Naphthalene		210
		220
		275

3.1.3 MOLAR ABSORPTIVITY

Beer's Law, which relates absorbance of a sample to the path length and concentration of absorbing species, was covered in Chapter 2. The proportionality constant, *a*, in Beer's Law is the absorptivity of the absorbing species.

The *absorptivity*, a, of a molecule defines how much radiation will be absorbed by that molecule at a given concentration and at a given wavelength. If the concentration is expressed in molarity (mol/L, M), the absorptivity is defined as the *molar absorptivity*, ϵ . The absorptivity can be calculated directly from the measured absorbance using Beer's Law:

$$(3.2) A = abc = \varepsilon bc$$

where A is the absorbance; b, the path length; and c, the concentration of the absorbing species.

If b is in units of cm and c has units of molarity, then the proportionality constant is the molar absorptivity and is given the symbol ϵ , with units of M–¹cm–¹. Commonly $\epsilon \approx 10^4$ – 10^5 M–¹cm–¹ for an allowed transition and is on the order of 10–100 for a forbidden transition. The magnitude of the absorptivity is an indication of the probability of the electronic transition. High values of ϵ give rise to strong absorption of light at the specified wavelength; low values of ϵ result in weak absorption of light. Both a and ϵ are constants for a given wavelength and are physical properties of the molecule. The molar absorptivity may be specified for any wavelength, but is usually tabulated for the wavelength at which maximum absorption of light occurs for a molecule. The wavelength of maximum absorption is symbolized by $\lambda_{\rm max}$ and the associated ϵ is symbolized as $\epsilon_{\rm max}$. Table 3.4 presents typical values for $\lambda_{\rm max}$ and $\epsilon_{\rm max}$ for some common organic molecules.

A comprehensive listing of absorbances and absorbance shifts can be found in the book by Bruno and Svoronos.

 1.0×10^{5}

 9.0×10^{3}

290

<10

Com	imon Chromophores		
Chromophore	Compound	λ_{max} (nm)	$\epsilon_{ m max}$ (M $^{-1}$ cm $^{-1}$)
>C=CC=C<	$H_2C=C-C=CH_2$	210	2.5×10^{4}
NO ₂	CH ₃ NO ₂	210	1.0×10^{4}
		280	10
N=N	CH ₃ N=NCH ₃	<250	$>1.0 \times 10^5$
—Br	CH₃Br	205	1.8×10^{3}
—SH	C_2H_5SH	230	160
Aromatic ring	Benzene (C ₆ H ₆)	198	8.0×10^{3}
		255	200

221

285 300

460

TABLE 3.4 Typical Absorption Maxima and Molar Absorptivities for Common Chromophores

Naphthalene

 $(CH_3)_3C=S$

The absorptivity is not a direct measure of the probability that a given electronic transition will occur. This is because absorbance is measured over a wavelength range that is much smaller than the width of the absorption band. The absorptivity will differ at different wavelengths over the band profile. There are several fundamental quantities that are directly related to the transition probability; these include Einstein coefficients and the oscillator strength, f. The text by Ingle and Crouch presents the derivation of these quantities for the interested student.

3.1.4 THE SHAPE OF UV ABSORPTION CURVES

>C=S

Figure 3.1 shows "typical" UV absorption spectra for several organic molecules in solution. Each spectrum appears to be very simple, with a broad absorption "band" over a wide wavelength range instead of the numerous, narrower absorptions seen in IR spectra (Chapter 4). The absorption bands are broad because each electronic energy level has multiple vibrational and rotational energy levels associated with it. Excitation from the ground electronic state can occur to more than one vibrational level and to more than one rotational level. A schematic representation of an electronic transition with vibrational and rotational sublevels is shown in Figure 3.9. In the ground state, only the lowest vibrational level is shown, with four rotational sublevels. At room temperature, most molecules are in the ground state in the lowest vibrational state. In the excited state, four vibrational sublevels are shown, slightly separated, with four rotational sublevels in each. Only four of the many possible transitions are shown; each arrow represents an absorption wavelength. The electronic transition consists of a large number of wavelengths that overlap to give the "continuous" absorption band observed. Even though each separate transition is quantized, the close energy spacing of the vibrational levels and the even more closely spaced rotational sublevels cause the electronic transition to appear as a broad band. This is shown schematically in Figure 3.10.

An absorption band is characterized by its width and intensity, its "shape". The shape of the band is determined primarily by the vibrational energy level spacing and the intensity of each vibrational transition. The transition probabilities can be determined using the Franck-Condon principle. The texts by Hollas and Lambert et al. may be consulted for details. Suffice it to say that if we have a million molecules, even if they are mostly in the ground vibrational state before excitation, they may be in various vibrational states after excitation. The radiant energy required to cause electronic excitation to each vibrational energy level is slightly different and is further modified by rotational energy changes. For this reason, when UV




FIGURE 3.9 An electronic transition occurs over a band of energy due to the multiple vibrational and rotational sublevels associated with each electronic state. This schematic depicts four of the many possible transitions that occur. The length of the arrow is proportional to the energy required for the transition, so a molecular electronic transition consists of many closely spaced transitions, resulting in a band of energy absorbed rather than discrete line absorption.

radiation falls on the million molecules, it is absorbed at numerous wavelengths. The effect of the rotational energy of the molecule is to add even more absorption lines to the single band. The increased number of absorption lines makes the lines even closer together, but it does not appreciably increase the total range of the band because the energy involved in rotation is very small compared to vibrational energy and extremely small compared to electronic excitation energy. UV radiation is therefore absorbed in *absorption bands* that may stretch over 100 nm rather than at discrete wavelengths.

In some cases, the UV/VIS spectra will show the different energies associated with the vibrational sublevels. For example, simple molecules in the gas phase often show the vibrational levels superimposed on the electronic transitions, as seen in Figure 3.11, the gas phase spectrum for benzene. The sharp peaks on top of the broad bands are called vibrational "fine structure". Molecules in solution usually do not exhibit vibrational structure due to interactions between the solvent and the solute molecules. Compare the gas phase spectrum of benzene (Figure 3.11) to the solution spectrum for benzene (Figure 3.12) and note the loss of much of the fine structure in solution. Fine structure due to rotational sublevels is never observed in routine UV/VIS spectra; the resolution of commercial instrumentation is not high enough to separate these lines.




FIGURE 3.10 Illustration of a UV absorption band greatly expanded.




FIGURE 3.11 Gas phase absorption spectrum of benzene. (From Jaffé and Orchin. Reprinted with the permission of the late professor M. Orchin.)




FIGURE 3.12 Absorption spectrum of benzene in solution. The solvent is cyclohexane. Note the loss of fine structure when compared to Figure 5.11. (From Jaffé and M. Orchin. Reprinted with the permission of the late professor M. Orchin.)

3.1.5 SOLVENTS FOR UV/VIS SPECTROSCOPY

Many spectra are collected with the absorbing molecule dissolved in a solvent. The solute must be soluble in the solvent and the solvent must be transparent over the wavelength range of interest. A molecule will dissolve in a solvent if the formation of a solution leads to a lower energy system. The intermolecular attractive forces between the solute and solvent must be

TABLE 3.5 Common UV Solvents and Their Lower Wavelength Cutoffs

Solvent	Lower Wavelength Cutoff (nm)
Acetone	330
Pyridine	306
Toluene	285
Xylene	280
Carbon tetrachloride	265
Chloroform	245
Diethyl ether	215
Methanol	205
Cyclohexane	205
95 % Ethanol	204
Hexane	200
Isooctane	195
Water	195
Acetonitrile	190

greater than solute-solute and solvent-solvent attractive forces. The forces involved in solution formation are dipole-dipole attraction, hydrogen bonding, and van der Waals forces. Polarity plays a major role, and gives rise to the "like dissolves like" rule. Polar substances dissolve more readily in polar solvents than in nonpolar solvents. It is important for the solute to be dissolved completely; undissolved particles can scatter light from the light source. This can result in serious errors in qualitative and quantitative analyses.

The solvent may affect the appearance of the spectrum, sometimes dramatically. Polar solvents generally wipe out the vibrational fine structure in a spectrum. Solvents may also shift the position of the absorption band, as will be discussed. For the visible region of the spectrum, any colorless solvent can be used in which the sample is soluble.

The common solvents used in UV/VIS spectroscopy are listed in Table 3.5, along with their low wavelength cutoff. At wavelengths shorter than the cutoff wavelength, the solvent absorbs too strongly to be used in a standard 1 cm sample cell. The cutoff is affected by the purity of the solvent. For spectroscopy, the solvents should be of spectral or spectrochemical grade, conforming to purity requirements set by the American Chemical Society or similar standards agencies.

A comprehensive listing of absorbances of solvents can be found in the book by Bruno and Svoronos.

3.2 INSTRUMENTATION

3.2.1 OPTICAL SYSTEM

Spectrometers are instruments that provide information about the intensity of light absorbed or transmitted as a function of wavelength. Both single-beam and double-beam optical systems are used in molecular absorption spectroscopy. Schematics and advantages/disadvantages of these systems are discussed in Chapter 2.

Commercial UV/VIS spectrometers are designed to operate with air in the light path over the range of 200–800 nm. Purging the spectrometer with dry nitrogen may permit wavelengths as low as 175 nm to be observed. For lower wavelengths, the spectrometer must be put under vacuum or purged with a non-absorbing gas. Analytically, the vacuum UV region has been of minor importance for routine analysis because of the difficulties and expense inherent in instrumentation requiring a vacuum.

All spectrometers for absorption measurements require a light source, a wavelength selection device, a sample holder, and a detector. Complete UV/VIS and UV/VIS-NIR systems are available from many commercial instrument companies, including Agilent Technologies,

PerkinElmer, Shimadzu Scientific Instruments, and Thermo Fisher Scientific. These large companies each offer from 5-8 versions of their systems with varied capabilities. Their websites offer applications, videos on using the instruments, tutorials and a host of other useful information.

3.2.2 RADIATION SOURCES

Radiation sources for molecular absorption measurements must produce light over a continuum of wavelengths. Ideally, the intensity of the source would be constant over all wavelengths emitted. Traditionally, the two most common radiation sources for UV/VIS spectroscopy were the tungsten lamp and the deuterium discharge lamp. The tungsten lamp is similar in functioning to an ordinary incandescent light bulb. It contains a tungsten filament heated electrically to white heat and generates a continuum spectrum. It has two shortcomings: the intensity of radiation at short wavelengths (<350 nm) is low; furthermore, to maintain a constant intensity, the electrical current to the lamp must be carefully controlled. However, the lamps are generally stable, robust, and easy to use. Typically, the emission intensity varies with wavelength as shown in Figure 3.13. The shape of these curves is typical of the continuum output of a solid heated to incandescence. An incandescent solid that produces a curve of this type is called a blackbody radiator. The continuum emission is due to thermally excited transitions in the solid tungsten filament. The intensity vs. wavelength plot for a blackbody radiator is dependent on the temperature of the emitting material, not on its chemical composition. Because the W lamp is used only in the visible region, the bulb or lamp envelope can be made of glass instead of quartz. Quartz is required for the transmission of UV light. The tungsten-halogen lamp, similar to the lamp in modern auto headlights, has replaced the older tungsten lamp. The tungsten-halogen lamp has a quartz bulb, primarily to withstand the high operating temperatures of the lamp. This lamp is much more efficient than a W lamp and has a significantly longer lifetime. The wavelength/intensity output of a tungsten halogen lamp is presented in Figure 3.14.

The *deuterium arc lamp* consists of deuterium gas (D_2) in a quartz bulb through which there is an electrical discharge. The molecules are excited electrically and the excited deuterium molecules dissociate, emitting UV radiation. The dissociation of the deuterium molecule into atoms results in UV photon emission over a continuous range of energies. The lamp




FIGURE 3.13 Emission intensity of blackbody radiation at various temperatures as a function of wavelength: 3000 K is equivalent to a tungsten filament lamp (an incandescent lamp); 6000 K is equivalent to a xenon arc lamp.




FIGURE 3.14 (a) Emission spectrum of a commercial tungsten-halogen lamp. (b) Emission spectrum of a commercial deuterium arc lamp. (© 2020 Agilent Technologies, Inc. [www.agilent.com]).

emits a continuum (broadband) UV spectrum over the range of 160-400 nm rather than a narrow line atomic emission spectrum. The lamps are stable, robust, and widely used. The use of deuterium (D_2) instead of hydrogen gas results in an increase in the emission intensity by as much as a factor of three at the short-wavelength end of the UV range. Deuterium is more expensive than hydrogen, but is used to achieve the high intensity required of the source. Figure 3.14(b) presents the emission spectrum of a deuterium arc lamp.

Xenon arc lamps operate in a manner similar to deuterium lamps. A passage of current through xenon gas produces intense radiation over the 200–1000 nm range. They provide very high radiation intensity and are widely used in modern UV/VIS instruments because they require no warm-up period. This lamp is used in fluorescence spectrometry and the lamp schematic and spectrum are shown in Section 3.9.2. Many UV/VIS spectrometers today use xenon flash lamps, which only flash when a reading is taken. They require no warm-up time and use very little electrical energy. Photodegradation is eliminated with this type of lamp, as the sample is not exposed to high amounts of radiation or heat.

Important recently introduced light sources are light-emitting diodes (LEDs). An LED consists of a chip of semiconducting material doped with impurities to create a p-n junction (Figure 3.21). Current flows from the p side (the anode) to the n-side (the cathode). The charge carriers, electrons, and holes, flow into the junction from electrodes with different voltages. When an electron meets a hole, it falls into a lower energy level and emits a photon. The wavelength of light emitted (its color) depends on the band gap energy (Figure 3.15(a) and 3.20) of the materials forming the p-n junction. An LED schematic is shown in Figure 3.15(b).




FIGURE 3.15 (a) Light production by recombination of an electron and hole in an LED. (b) Schematic of an LED.

Commercial LEDs are now available in a variety of visible colors as well as IR and UV-emitting LEDs. UV-emitting LEDs are often made of boron nitride (BN), aluminum nitride (AlN), aluminum gallium nitride (AlGaN), and aluminum gallium indium nitride (AlGaInN). To create a white light source for visible spectroscopy, two approaches are used. One is to use a combination of red, green, and blue LEDs mixed to create white light. Red LEDs, the first practical LED and the first to be commercialized, are made from gallium phosphide (GaP), gallium arsenide phosphide (GaAsP), aluminum gallium arsenide (AlGaAs), and aluminum gallium indium phosphide (AlGaInP). Green LEDs are based on indium gallium nitride (InGaN), aluminum gallium phosphide (AlGaP), and similar materials. Blue LEDs are made from indium gallium nitride (InGaN), zinc selenide (ZnSe), and other materials (note that some of these materials are highly toxic and handling should be done with care). The second approach, made practical after the development of high-intensity blue LEDs, is to use a blue LED and a phosphor coating based on materials like yttrium aluminum oxide (also called yttrium aluminum garnet or YAG). The phosphor produces a yellow light which appears white when combined with blue light. This is similar to the way a standard fluorescent light bulb works.

3.2.3 MONOCHROMATORS

The purpose of the monochromator is to disperse the radiation according to wavelength and allow selected wavelengths to illuminate the sample. Diffraction gratings are used to disperse light in modern instruments (Chapter 2). The monochromators in modern systems can scan at rates up to 2000–3000 nm/min, with slew rates (the time to move between wavelengths without taking measurements) as high as 16,000 nm/min to accommodate the high throughput measurements needed in pharmaceutical and biotechnology laboratories.

Diffraction grating technology permits measurements that were impossible just 40 years ago. Diffraction gratings manufactured by ion beam or laser beam photolithography can produce stray light (light at unwanted wavelengths) due to the surface roughness of the surface. Proprietary manufacturing methods developed for optimizing the etching process used with holographic technology result in greatly improved diffraction gratings, such as the "Lo-Ray-Ligh" gratings from Shimadzu Scientific Instruments (www.ssi.shimadzu.com). The Lo-Ray-Ligh gratings have ultralow stray light values of as little as 0.00005 %, permitting absorbance measurements at up to 8.5 absorbance units with complete linearity. Figure 5.16(a) compares the absorbance spectra obtained on a UV-2700 with a Lo-Ray-Ligh grating with those obtained on a conventional spectrometer. Figure 5.16(b) demonstrates the linearity over 8.5 absorbance units. This allows the measurement of highly absorbing materials, such as sunglass polarizers and welding facemasks. Some examples will be given in Section 3.3.

3.2.4 DETECTORS

The earliest detector used for visible light spectroscopy was the human eye. There are still *spectroscopes* and *color comparators* designed for visual observation of color and intensity.

Most modern instruments rely on **photoelectric transducers**, detection devices that convert photons into an electrical signal. Photoelectric transducers have a surface that can absorb radiant energy. The absorbed energy either causes the emission of electrons, resulting in a photocurrent, or moves electrons into the conduction band of a solid semiconductor, resulting in an increase in conductivity. There are several common forms of these detectors including barrier layer cells, photomultiplier tubes, and semiconductor detectors.

3.2.4.1 BARRIER LAYER CELL

In a barrier layer cell, also called a photovoltaic cell, a current is generated at the interface of a metal and a semiconductor when radiation is absorbed. For example, silver is coated onto a semiconductor such as selenium (see Figure 3.17) that is joined to a strong metal base, such




FIGURE 3.16 (a) Left: Spectra obtained on a UV-2700 spectrometer equipped with a Lo-Ray-Ligh grating; right: the same spectra collected on a conventional spectrometer. Note that the signals on the conventional system go over the operating range. (b) Calibration curve from the UV-2700 showing linearity up to absorbance = 8.5. (© 2020 Shimadzu Scientific Instruments, [www.ssi.shimadzu.com]. Used with permission.)




FIGURE 3.17 Barrier layer cell.

as iron. To manufacture these cells, the selenium is placed in a container and the air pressure reduced to a vacuum. Silver is heated electrically, and its surface becomes so hot that it melts and vaporizes. The silver vapor coats the selenium surface, forming a very thin but evenly distributed layer of silver atoms. Any radiation falling on the surface generates electrons and holes at the selenium-silver interface. A barrier seems to exist between the selenium and the iron that prevents electrons from flowing into the iron; the electrons flow to the silver layer and the holes to the iron. The electrons are collected by the silver. These collected electrons migrate through an external circuit toward the holes. The photocurrent generated in this manner is proportional to the number of photons striking the cell.

Barrier layer cells are used as light meters in cameras and in low cost, portable instruments. The response range of these cells is 350–750 nm. These detectors have two main disadvantages: they are not sensitive at low light levels and they show *fatigue*, that is, the current drops gradually under constant exposure to light. On the plus side, they require no external electrical power and they are very rugged.

3.2.4.2 PHOTOMULTIPLIER TUBE

A very common detector is the photomultiplier tube (PMT). A PMT is a sealed, evacuated transparent envelope (quartz or glass) containing a photoemissive cathode, an anode, and several additional electrodes called dynodes. The photoemissive cathode is a metal coated with an alkali metal or a mixture of elements (e.g., Na/K/Cs/Sb or Ga/As) that emits electrons when struck by photons. The PMT is a more sophisticated version of a vacuum phototube, Figure 3.18(a), which contained only a photoemissive cathode and an anode; the photocurrent was limited to the electrons ejected from the cathode. In the PMT, Figure 3.18(b), the additional dynodes "multiply" the available electrons. The ejected electrons are attracted to a dynode that is maintained at a positive voltage with respect to the cathode. Upon arrival at the dynode, each electron strikes the dynode's surface and causes several more electrons to be emitted from the surface. These emitted electrons are in turn attracted to a second dynode, where similar electron emission and more multiplication occur. The process is repeated several times until a shower of electrons arrives at the anode, which is the collector. The number of electrons falling on the collector is a measure of the intensity of light falling on the detector. In the process, a single photon may generate many electrons and give a high signal. The dynodes are therefore operated at an optimum voltage that gives a steady signal. A commercial photomultiplier tube may have nine or more dynodes. The gain may be as high as 109 electrons per photon. The noise level of the detector system ultimately limits the gain. For example, increasing the voltage between dynodes increases the signal, but if the voltage is made too high, the signal from the detector becomes erratic or noisy. In practice, lower gains and lower noise levels may be preferable for accuracy.




FIGURE 3.18 (a) A vacuum phototube. (b) Schematic of a PMT, looking down through the tube. Impinging photons pass through the quartz envelope and liberate electrons from the light-sensitive cathode. The electrons are accelerated to the first dynode, where each electron liberates several electrons on impact. The process is repeated at the other dynodes, resulting in a cascade of electrons for every photon hitting the PMT.




FIGURE 3.19 Response curves for various commercial PMTs. Note the variable response among different models and the sharp drop-off in response outside the useable range.

PMTs are extremely sensitive to UV and visible radiation. In fact, they are so sensitive that care must be taken not to expose PMTs to bright light, to avoid damage. There are a wide variety of photoemissive surfaces available, which respond to different wavelength ranges. A plot of detector signal vs. wavelength is called a *response curve*. Figure 3.19 displays some response curves for commercial PMTs. The PMT detector should be chosen so that it has maximum response to the wavelength range of interest. For example, the IP28 is not useful at 800 nm, but the R136 and Ga/As PMT detectors respond in this range. PMTs have very fast response times, but they are limited in sensitivity by their *dark current*. Dark current is a small, constant signal from the detector when no radiation is falling on it. Dark current can be minimized or eliminated by cooling the detector housing.

3.2.4.3 SEMICONDUCTOR DETECTORS: DIODES AND DIODE ARRAY SYSTEMS

Solid semiconducting materials are extremely important in electronics and instrumentation, including their use as radiation detectors. To understand the behavior of a semiconductor, it is necessary to briefly describe the bonding in these materials.

When a large number of atoms bond to form a solid, such as solid silicon, the discrete energy levels that existed in the individual atoms spread into *energy bands* in the solid. The valence electrons are no longer localized in space at a given atom. The width of the energy bands increases as the interatomic spacing in the solid decreases. The highest band that is at least partially occupied by electrons is called the *valence band*; the energy band immediately above the valence band is called the *conduction band*. The valence and conduction bands are separated by a forbidden energy range (forbidden by quantum mechanics); the magnitude of this separation is called the *band gap*, $E_{\rm g}$. A set of energy bands and the band gap are shown schematically in Figure 3.20. If the valence band of a solid is completely filled at a temperature of 0 K, the material is a **semiconductor** or an **insulator**. The difference between a semiconductor and an insulator is defined by the size of the band gap. If $E_{\rm g} \le 2.5$ eV, the material




FIGURE 3.20 Schematic of energy bands in a solid material separated by a band gap of energy E_{α} .

is a semiconductor; if $E_g > 2.5$ eV, the material is an insulator. The third type of material, a **conductor**, has a partially filled valence band at 0 K.

The two elements most used for semiconductor devices are silicon and germanium; both are covalently bonded in the solid state and both belong to group 4A of the periodic table. [This group is also called group 14 in the new International Union of Pure and Applied Chemistry (IUPAC) nomenclature and group IVA in some texts.] Other semiconductors include GaAs, CdTe, InP, and other inorganic and organic compounds. Most semiconductors are covalently bonded solids. Band gap energies for semiconductors are tabulated in the CRC Handbook of Chemistry and Physics.

Silicon has the valence electronic structure $3s^23p^2$. The partially filled p orbitals might lead one to suppose that silicon has a partially filled valence band and would therefore be an electrical conductor. Because silicon is covalently bonded, the two 3s electrons and the two 3p electrons occupy sp^3 hybrid orbitals. This results in a solid with two electron energy bands, each with four closely spaced sublevels, one for each electron in the valence shell of Si. The four electrons occupy and fill the valence band at 0 K and are therefore nonconducting. However, at temperatures above 0 K, a few electrons can be thermally promoted from the valence band into the conduction band; there they become conductors of electricity. When an electron leaves the valence band, it leaves behind a positive hole that is also mobile, thus producing an electron-hole pair. Both the electron and the hole are charge carriers in a semiconductor. Semiconductors such as Si and Ge are called intrinsic semiconductors; their behavior is a result of the band gap and band structure of the pure material.

The conductivity can be increased by doping either one of these elements with a group 5A element, such as arsenic or antimony, or a group 3A element, such as indium or gallium. Doping means to add another species to the *host* material; the added species is referred to as the dopant. The electrons associated with the dopant atom do not have the same energy levels as the host and may lie at energies forbidden to the host. Conductivity caused by addition of a dopant is called extrinsic conduction. A group 5A element has an extra electron (or extra negative charge). This electron is not held as tightly as the covalently bonded electrons of the host and requires less energy to move it into the conduction band. This is an n-type semiconductor. Similarly, adding a group 3A element leads to "missing" electrons; this can be considered to be the generation of extra positive holes. These positive holes from the dopant atom can accept electrons from the valence band. The energy needed to move an electron into an acceptor hole is less than the energy needed to move an electron into the conduction band. This is a p-type semiconductor. In an n-type semiconductor, the electron is mobile, and in the p-type, the positive hole is mobile. In an intrinsic semiconductor, two charge carriers are formed for every excitation event. In extrinsic semiconductors, either n- or p-type, only one charge carrier is formed per excitation event.

Semiconductors can be used as detectors for electromagnetic radiation. A photon of light with $E > E_{\rm g}$ is sufficient to create additional charge carriers in a semiconductor. Additional charge carriers increase the conductivity of the semiconductor. By measuring the conductivity, the intensity of the light can be calculated. Selection of a material with the appropriate band gap can produce light detectors in the UV, visible, and IR regions of the spectrum.




FIGURE 3.21 A p-n junction with no applied electrical potential.




FIGURE 3.22 A p-n junction under forward bias. The positive battery terminal is connected to the p side.

3.2.4.4 DIODES

A diode or rectifier is an electronic device that permits current to flow in only one direction. If we put together a p-type semiconductor and an n-type semiconductor, the junction between the two types is a p-n junction (Figure 3.21). It is formed from a single piece of semiconductor by doping one side to be a p-type and the other side to be an n-type semiconductor. The junction is formed where the two types meet. Before any potential is applied to the device, holes will be the major charge carriers on the p side and electrons will be the major charge carriers on the n side. If we apply a positive potential to the p-type side and a negative potential to the n-type side, as shown in Figure 3.22, positive charges (holes) flow from the p region to the junction and negative charges flow from the n region to the junction. At or near the junction, the holes and electrons recombine and are annihilated. This is called a *forward bias*, and under these conditions, current flows easily across the semiconductor. The annihilation of the electron-hole pair produces energy. If this energy is in the form of light, we have the LED, discussed above.

However, if the applied voltage were in the reverse direction, the flow of carriers would be in the opposite direction, as shown in Figure 3.23(a). These are the conditions of *reverse bias*. The junction region is depleted of mobile charge carriers, recombination cannot occur,




FIGURE 3.23 (a) A p-n junction under reverse bias. The positive battery terminal is connected to the n side. A depletion layer forms along the junction. (b) Diagram of a photodiode showing light incident upon the depletion layer. (From Brown, used with permission.)

and no significant flow of current occurs. There is always a small flow of current due to the intrinsic conductivity. In short, the p-n junction acts as a rectifier and permits significant current flow only under forward bias.

If a diode is held under reverse bias, and photons of energy greater than the band gap energy fall on the diode junction as shown in Figure 3.23(b), electron-hole pairs are formed in the depleted region. These carriers will move through the diode, producing a current that is proportional to the intensity of the light falling on the diode. These detectors cover spectral ranges from the UV (about 190 nm) into the NIR (about 1000 nm), but are not as sensitive as PMTs. They have limited dynamic range compared to PMTs and when they deviate from linearity, they do so precipitously.

3.2.4.5 DIODE ARRAYS

In UV/VIS spectroscopy, a complete absorption spectrum can be obtained by scanning through the entire wavelength range and recording the spectrum with a PMT, one wavelength at a time. This takes time using a conventional scanning monochromator system, although modern instruments can be very fast. The absorption at one wavelength is measured at a different time from that at another wavelength.

There are two conditions under which scanning optical systems do not work very well. The first is when there is a rapid chemical reaction taking place and conventional scanning is too slow to follow the reaction. The second is when the sample is available only for a limited time and complete scanning is not possible. Examples of the latter include the eluent from a liquid chromatographic separation, the flowing stream in a flow injection system, or a process stream in a chemical or pharmaceutical production plant. In cases like this, many wavelengths need to be monitored simultaneously. Ideally, intensity over the entire spectral range of interest should be measured at the same instant. Today, a third condition often pushes the need for fast analysis—the need for high sample throughput in many industries—often 24/7 unattended operation of instruments, which improves analytical "turnaround" time and impacts costs.

The linear photodiode array (LPDA) is a transducer developed to enable simultaneous measurement of light intensity at many wavelengths. The diode array consists of a number of semiconductors embedded in a single crystal in a one-dimensional linear array. A common procedure is to use a single crystal of doped silicon that is an n-type semiconductor. A small excess of a group 3A element, such as arsenic, is embedded into the surface at regular intervals. This creates local p-type semiconductors. The semiconductor device ideally has a cross-section such as that shown in Figure 3.24. The surface contains a linear series or array of p-n junctions, each of which is a photodiode. The individual diodes are called *elements*, *channels*, or *pixels*.

The PDA is arranged as part of a circuit. A reverse bias is created across the p-n junction by charging a capacitor in the circuit. Radiation falling on the array creates charge carriers in both p and n regions. The electrons will then flow to the nearest p-type semiconductor and the holes are collected in the p-type region. The current flow partially discharges the




FIGURE 3.24 A photodiode array. The top view shows the face that the light would fall on. The side view shows that the p-type elements are embedded in a continuous layer of n-type semiconductor. (From Brown, used with permission.)




FIGURE 3.25 Optical diagram of a diode array spectrophotometer, showing both UV and visible light sources and a 1024 element PDA detector. (© 2020 Agilent Technologies, Inc. [www.agilent.com]).

capacitor. At the end of the measurement cycle, the capacitor is recharged; the charging current results in a voltage that is directly related to the light intensity. The number of charge carriers formed in a particular element depends on the light intensity falling on the array in the immediate vicinity of that particular element. By measuring the charges on each individual element, it is possible to get an instantaneous measurement of light intensity vs. wavelength of the whole spectral range, but in discrete elements. This is tantamount to a digital UV absorption spectrum.

The optical layout of a commercial multichannel instrument is shown schematically in Figure 3.25. In this system, radiation from a source, which may be a deuterium lamp or other UV/VIS light source, passes through the sample to a holographic grating, where the radiation is separated by wavelengths and directed to the diode array detector. No exit slit is used. The entire spectral region is measured in much less than 1 s. In practice, the spectrum is usually acquired for more than 1 s, and stored by the computer. This practice improves the signal-to-noise ratio for the measurement. By acquiring multiple measurements, the signal can be accumulated and sensitivity considerably increased.

PDAs are available to cover the wavelength range between 190 and 1100 nm. Simultaneous use of the entire wavelength range provides the multiplex advantage and improves the resolution of the system. The resolution of the system is limited by the number of diode elements involved. Typical diode spacing is 0.025 mm. Each one can be thought of as covering a finite spectral range. Detectors have been developed with as many as 4096 elements in the array, although 1024 is probably the most common number.

The most important applications for diode array systems are in molecular spectroscopy, since in general they do not have the resolution necessary for atomic spectroscopy. In molecular spectroscopy, the most useful areas of application are for (1) scanning fast reactions to determine kinetics, (2) applications involving low light levels because spectra can be stored and added to each other, increasing the intensity, and (3) detectors for HPLC and capillary electrophoresis (CE), discussed in Chapter 13.

3.2.5 SAMPLE HOLDERS

Samples for UV/VIS spectroscopy can be solids, liquids, or gases. Different types of holders have been designed for these sample types.

3.2.5.1 LIQUID AND GAS CELLS

The cells or *cuvettes* (also spelled *cuvets*) used in UV absorption or emission spectroscopy must be transparent to UV radiation. The most common materials used are quartz and fused silica. Quartz and fused silica are also chemically inert to most solvents, which make them

sturdy and dependable in use. (*Note*: solutions containing hydrofluoric acid or very strong bases, such as concentrated NaOH should never be used in these cells. Such solutions will etch the cell surfaces, making them useless for quantitative work.) Quartz and fused silica cells are also transparent in the visible and into the NIR region, so these could be used for all work in the UV and visible regions. These are also the most expensive cells, so if only the visible portion of the spectrum is to be used, there are cheaper cell materials available, such as Pyrex. The website of Starna Cells, Inc. (www.starna.com) has detailed information about the types of cells available, tolerances, material characteristics, and much more.

Some typical cell types are shown in Figure 3.26. Cells are available in many sizes. The standard size for spectrophotometry had long been the 1 cm path length rectangular cell, which holds about 3.5 mL of solution, shown in the upper left of Figure 3.26. There are microvolume cells (second from the left in the top row of Figure 3.26) with volumes as small as 40 µL, flow-through cells for process streams or the routine analysis of large numbers of samples, microflow cells for chromatographic systems, and larger path length/volume cells for gases and highly dilute solutions. Two flow-through cells are shown in the middle of the bottom row in Figure 3.26. In general, gas cells are long path cells, similar to the one shown on the upper right of Figure 3.26 and must be able to be closed once filled with a gas sample. New innovations in cell technology include the development of nanovolume (i.e., sub-μL volume) cells, such as the Starna Cells, Inc. Demountable Micro-Volume (DMV)-Bio Cell, an ultralow volume cell for use in most UV/VIS spectrometers. The DMV-Bio is available in 0.5, 0.2, and 0.125 mm pathlengths, with nominal sample volumes of 2.5, 1.0, and 0.6 μL respectively. Another nanovolume cell is the TrayCell, from Hellma Analytics (www.hellmausa. com), with pathlengths of 0.2 or 1.0 mm, allowing volumes as low as 0.5 µl to be measured and recovered (Figure 3.31).




FIGURE 3.26 Cells for liquid samples, showing just a few of the wide variety of types and sizes available. From left to right, top row: standard 1 cm spectrophotometer cuvet with two optical faces and two frosted faces; semimicro 0.7 mL cuvet; 10 μ L submicro cell; constant temperature cell with a jacket for circulating a temperature-controlling fluid. From left to right, bottom row: 5 mm fluorometer cuvet (all four faces are optically clear); in-line continuous flow cell for process monitoring (sample flow is from bottom to top); 10 mm flow cell; cylindrical cell. (Courtesy of Starna Cells, Inc., [www.starna.com]).




FIGURE 3.27 Transparencies of materials used to make sample cells for UV/VIS spectroscopy.

For spectrophotometric analysis in the visible region of the spectrum, glass or disposable plastic cells may be used. These are less expensive than quartz or fused silica but cannot be used at short UV wavelengths. Polystyrene is often used for visible range cuvettes (340–800 nm), while acrylic polymer cuvettes can be used down to 285 nm. Plastic cells cannot be used with any organic solvent in which the plastic is soluble. Disposable plastic cells are not suitable for accurate quantitative work. Price differences are significant between the materials. For example, a high-quality 1 cm quartz cuvette for use in the UV costs about \$200, while a matched set of quartz cells costs \$600-800; the same size glass cuvette for use in the visible region costs about \$100 and a 1 cm plastic disposable cuvette costs about 40 cents. Microvolume cells, flow cells, and other specialty cells are expensive. Some spectrometers are designed to use ordinary glass test tubes as the "cells". These test tube "cells" should not be used for accurate quantitative work. Transparencies of some typical cell materials are presented in Figure 3.27.

It is important that cells be treated correctly in order to achieve best results and to prolong their lifetime. To that end, the analyst should (1) always choose the correct cell for the analysis; (2) keep the cell clean, check for stains, etch marks, or scratches that change the transparency of the cell; (3) hold cells on the nontransparent surfaces if provided; (4) clean cells thoroughly before use and wash out the cell with a small amount of the sample solution before filling and taking a measurement; (5) not put strongly basic solutions or HF solutions into glass, quartz, or fused silica cells; (6) check for solvent compatibility with disposable plastic cells before putting them into the spectrometer; (7) for nondisposable cells, always dry carefully and return to their proper storage case; and (8) never wipe the optical surfaces with paper products, only lens cleaning paper or cloth material recommended by the manufacturer. At all times when not in use, cells should be kept clean and dry, and stored so that the optical surfaces will not become scratched. The use of a vacuum-operated cuvette washer is convenient and effective in the cleaning of cuvettes, for both the inside and the outside.

3.2.5.2 MATCHED CELLS

When double-beam instrumentation is used, two cells are needed: one for the reference and one for the sample. It is normal for absorption by these cells to differ slightly. This causes a small error in the measurement of the sample absorption and can lead to analytical error. For most accurate quantitative work, *optically matched cells* are used. These are cells in which the absorption of each one is equal to or very nearly equal to the absorption of the other. Large numbers of cells are manufactured at one time and their respective absorptivities measured.

Those with very similar absorptivities are designated as optically matched cells. Tolerances for new matched cells measured at a suitable wavelength for the cell material are on the order of 1 %. Matched cells are usually etched near the top with an identification mark and must be kept together. It is important for the analyst to understand that even closely matched cells will show small differences in absorption due to differences in raw material characteristics. The transmission of matched cells will also change due to normal use, so a new cell of the same "match code" will not necessarily match an older, used cell. Less commonly used cells (other than the 1 cm type) can be supplied in matched sets of two or four cells. The proper use of matched cells is to fill both the sample and the reference cells with the solvent and run a baseline spectrum, which is stored by the instrument computer system. The sample cell is then cleaned and sample solution put into it, while the reference cell and its solvent are left in place. After measuring the sample spectrum, the baseline is subtracted from the sample spectrum by the computer. This approach will correct for small differences in the cells. It is also important that the sample cell be reinserted into the spectrometer facing in the same direction it was facing when the background was obtained. The etch mark on the top of the cell helps to facilitate this.

Modern cell manufacturing practices have improved greatly, and high-quality cell manufacturers such as Starna Cells, Inc. are now producing cells with tolerances for window flatness, parallelism of windows, polish, and path length precision better than older "matched" cells. These modern cells are in effect optically matched by the nature of the manufacturing process and standard cells like the 1 cm cell are available in large quantities. Tolerances for modern cells can be found on the Starna website (www.starna.com). It is still necessary for the analyst to check the cells on a routine basis by measuring a dilute solution of an absorbing material in all cells. This will identify any possible problems with microscopic scratches, residual film, or deposits on the windows, and so on. Matched cells are not needed for qualitative analysis, such as obtaining the spectrum of a compound to help identify its structure. For rough or survey work, disposable cuvettes are available.

3.2.5.3 FLOW-THROUGH SAMPLERS

For routine analysis of large numbers of samples, the filling, cleaning, and emptying of large numbers of cells is time-consuming. A flow cell and a peristaltic pump can be used to measure sample solutions directly from their original containers. Flow cells for sample volumes as small as 80 µL are available. This eliminates the need for sample handling and can minimize errors from sample handling, as well as eliminating the need to wash many cuvettes. Flow-through samplers for routine analysis are commercially available. Dedicated flow-injection systems and segmented flow systems are available for specific routine analyses, such as nitrate, sulfate, and fluoride in drinking water using methods specified by regulatory agencies around the world. See Standard Methods for the Examination of Water and Wastewater, listed in the bibliography, for example. These systems are automated to take the sample, add and mix the reagents, and send the absorbing solution through a fixed wavelength spectrometer for completely unattended quantitative analysis. One such stand-alone system is the OI Analytical Flow Solution™ FS 3700 (www.oico.com, www.xylem.com).

Also available from multiple instrument companies are stopped-flow cell accessories for mixing reagents and measuring the kinetics of short-lived reactions. A stop-flow rapid kinetics accessory from Agilent Technologies, Inc. has an empirical dead-time of less than 8 ms, and can monitor reaction rates up to $100~\text{s}^{-1}$ when used with their Cary spectrophotometers, using as little as $350~\mu\text{L}$ per reagent. Similar rapid mixing accessories are available from other instrument companies. The Rapid Mix accessory from Thermo Fisher Scientific mixes two reactants and fills cells using as little as $120~\mu\text{L}$ of reactant, with a dead-time of 8 ms. The flow circuit and drive syringes can be water thermostatted for temperature control. Sample surfaces are chemically inert and biocompatible. Reactant ratios are changed by changing the syringe diameters. The pneumatic drive mechanism and software triggering allows precise zero-time measurement and can measure reaction rates from millisecond to minutes (Figure 3.29(a)).




FIGURE 3.28 Gel holder for UV/VIS absorption spectroscopy of electrophoresis gels. (© 2020 Agilent Technologies, Inc. [www.agilent.com]).

3.2.5.4 SOLID SAMPLE HOLDERS

The absorption spectrum of thin films of transparent solid materials, such as polymers, can be obtained by using a film holder. The simplest type of holder can be a paper slide mount with the sample taped to the slide mount. However, producers of films, gels, and other sheet materials are often interested in the homogeneity of the film or sheet. The film holder accessory for the Cary line of spectrometers (Agilent Technologies, Inc.) allows samples up to 160 mm in length to be mounted. The absorption spectrum can be collected and then the sample moved automatically to produce a plot of absorption vs. position along the sample length.

Gel electrophoresis is an important technique for separating high molecular weight biological molecules, such as DNA, lipoproteins, immunoglobulins, and enzyme complexes. The classic method for visualizing the separated molecules is to stain them with colored dyes. Slices of electrophoresis gels can be mounted in a holder (Figure 3.28) and the absorption spectrum collected as a function of distance along the gel using the same device used to move film samples. The holder can be moved in increments of 0.25 mm and gels up to 100 mm long can be analyzed in this fashion.

As described in Chapter 4 for FTIR and NIR, solid samples can be measured by diffuse reflectance or specular reflectance with the appropriate accessories. Solid and powder samples as small as 3 mm can be measured over the entire wavelength range of the spectrometer using a diffuse reflectance device called the Praying Mantis™ (Harrick Scientific Products, www.harricksci.com). It consists of two large hemispherical mirrors which collect the light from very small samples, eliminating the need for solvent dissolution. For materials science and nanomaterials, a 1-2 mm thickness and 3 mm diameter sample of powder is placed in the purgeable chamber, so oxygen and water-sensitive materials can be studied. Diffuse reflectance measurements can be obtained at varying conditions: temperatures from −150 to 600 °C and pressures from 10⁻⁶ torr to 3 atm.

3.2.5.5 FIBER OPTIC PROBES

In all the cells described earlier, the sample had to be brought to the spectrometer and placed in the light path (or pumped into the light path). Modern fiber optic probes enable the spectrometer to be brought to the sample. Using a fiber optic probe such as the one shown in Figure 3.29(b), the absorption spectrum can be collected from a very small sample volume in a microcentrifuge tube. The microprobe can be put in a stand, so that samples can be brought up to it for rapid throughput. These probes can cover the range from 200–1100 nm and operate at temperatures up to 150 °C. Fiber optic probes can be used to collect a spectrum from inside almost any container—an open beverage can, a 55-gallon drum of material, a tanker truck, or railroad car full of liquid. Probes are made in various path lengths, just as cells are, but eliminate the need to collect a sample and put it into a cell for measurement. This is especially useful for unknown and possibly hazardous samples. Fiber optic reflectance and fixed angle specular reflectance probes are available for remote measurement of solid samples. They are generally made from 316 stainless steel (AISI designation) for ease of cleaning, corrosion resistance and relative inertness.






FIGURE 3.29 (a) The evolution 300 with the rapid mixing accessory for fast kinetic studies in the UV/VIS region. (b) A fiber optic microprobe for UV/VIS determinations, shown in a PCR tube; 125 μ L of sample can be measured. (©Thermo fisher scientific inc., [www.thermofisher.com]. Used with permission.)

3.2.6 MICROVOLUME, NANOVOLUME AND HAND-HELD UV/VIS SPECTROMETERS

The intense interest in recent years in determining DNA, RNA, proteins, and the like in limited amounts of biological samples, as well as the incentive in chemical laboratories to reduce sample and reagent volumes, thereby reducing waste, and the "need for speed" in many laboratories has led to the development of a variety of microvolume UV/VIS instruments, many of which do not require a sample cell and some of which permit recovery of almost all of the sample. In addition, handheld devices have now appeared, permitting analyses in the field or manufacturing plant. Examples of some of these instruments are presented, and while not comprehensive, attention has been paid to demonstrating the wide variety of innovation in these products. The instruments themselves will be described in this section, while applications will be discussed in Section 3.3.

The advantages of directly measuring small volume samples include no dilution errors, no contamination, no or decreased sample preparation time, and an increase in sample throughput, especially if no cuvettes are required. As the pathlength decreases, the measured absorbance decreases (Beer's Law); decreasing the pathlength is therefore equivalent to dilution of the sample—a "virtual dilution". By using very short pathlengths, highly absorbing samples can be measured directly without dilution. Many of these instruments permit recovery of the sample if desired.

The NanoPhotometer $^{\text{\tiny MS}}$ Pearl (from Implen, GmbH; www.implen.com) is a compact dual-channel Czerny Turner grating spectrometer with a 1024-pixel CCD array detector and xenon flash lamp source (Figure 3.30).



FIGURE 3.30 The NanoPhotometer[™] Pearl. (© Implen GmbH [www.implen.com]. Used with permission.)

Its wavelength range is 190–1100 nm with the ability to scan from 200–950 nm in 3.5 seconds. The instrument needs no warm-up time and with sealed optics and no moving parts, the need for recalibration is eliminated. Up to 81 methods can be stored in the system and methods for nucleic acids (DNA, RNA), protein quantification, cell density, and others are predefined and come with the system. The instrument can use cuvettes, but also permits cuvette-less measurement of sample volumes as small as 0.3 μ L. This is accomplished by Sample Compression Technology[™] (www.implen.com/nanophotometer/how-it-works.php). A sample as small as 0.3 μ L is pipetted directly onto the spectrometer window and a cap is placed over the drop. The cap squeezes the sample to an exactly defined pathlength which is independent of surface tension and prevents evaporation, shown in Figure 3.31.




FIGURE 3.31 Left: sample is pipetted onto the cell window. Right: the cap compresses the sample into a fixed pathlength. (Graphic courtesy of Hellma Analytics [www.hellmausa.com].)





FIGURE 3.32 Two views of the Thermo Scientific NanoDrop™2000c. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

Five different "virtual dilution" lids are available to provide exact pathlengths corresponding to dilutions of 1/5, 1/10, 1/50, 1/100, and 1/250. Using fiber optics, the light source is directed up through the sample, and reflected from the mirror in the cap to the detector. After measurement, the sample can be retrieved with a micropipette or the sample is simply wiped off the mirror and window. Videos of the complete operation of the instrument can be seen at www.implen.de by clicking on applications under the instrument tab. (Note: The cell patent is jointly held by Implen and Hellma Analytics. Only Implen offers the 0.3 μ L option and the five virtual dilution lids. Hellma Analytics, the manufacturer of these cells, offers a two-fold virtual dilution version, the TrayCell, which is available directly from Hellma and also from a number of instrument companies, although often under different names.)

Thermo Fisher Scientific has a family of nanovolume spectrometers, the Thermo Scientific NanoDrop™ series (Figure 3.32).

The NanoDropTM 2000c is a compact (14x20 cm) spectrometer with a range of 190-840 nm, <5 sec measurement time for absorbance at a single wavelength, cuvette capability, as well as heating and stirring capability for kinetics and cell cultures. 1-2 μ L of sample can be measured over the full spectral range. It also permits cuvetteless measurement of as little as 0.5 μ L sample volumes. The sample is pipetted directly onto the measurement surface of the NanoDropTM, the cover is closed and a "column" is formed by the sample's surface tension (Figure 3.33) between the upper and lower pedestals. The exact volume is not critical, only that a column forms. The sample is pipetted, the absorbance read and the surfaces wiped clean in 15 seconds. A video of the operation is available at http://www.nanodrop.com/nd-1000-video.html and nanodrop.com/HowItWorks.aspx.

An eight-sample version is available for high throughput laboratories [Figures 3.33(a), (b), (c)] using 96 well plates. Using an eight-channel pipette as shown, 96 samples can be run in about six minutes. A new palm-sized version, the NanoDrop™ Lite was introduced in 2012 for dedicated nucleic acid applications by measuring absorbance at 260 and 280 nm. (The method will be discussed in Section 3.3). Most of the systems have built-in methods for the life sciences, including nucleic acids, protein, and colorimetric protein assays like the Bradford and Lowry assays.






FIGURE 3.33 (a) 0.5 μL sample pipetted onto the measurement surface of the NanoDrop™ 2000c. (b) Cuvette-less sample column formed between the pedestals by closing the cover. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

The AstraGene iCF UV/VIS spectrophotometer (AstraNet Systems, Ltd., www.astranet-systems.com; www.norsci.ca) is a CCD array spectrophotometer with a xenon light source and fiber optic coupling of the source and detector through the sample holder, which is a micropipette tip (Figure 3.34). 2 μ L of sample is taken up in a UV transparent, disposable pipette tip. The polymer pipette tips transmit UV light down to 230 nm and have a fixed 1 mm pathlength. The absorbance measurement is made through the pipette tip, the sample returned to the vial and the tip disposed of. The advantages of this "through-the-tip" system include easy sample handling, no sample carryover or contamination, no cleaning of the optics, and complete recovery of the sample. The system is designed for routine analysis of nucleic acids and protein using the absorbance measured at 260 and 280 nm, but the system can be used as a scanning UV/VIS spectrophotometer or in microarray mode to measure



(c)






FIGURE 3.33 (Continued) (c) NanoDrop 8000 with 8-channel pipette. (d) Sample pipetted onto the eight measuring surfaces. (e) Eight sample columns formed simultaneously (Thermo Fisher Scientific, used with permission).

absorbance, concentration and ratio at two selected wavelengths. Measurement for nucleic acids or proteins takes approximately two seconds.

The i-LAB® Visible Hand-Held Analyzing Spectrometer from Microspectral Analysis, LLC (www.microspectralanalysis.com) is a portable, miniaturized spectrometer powered by 3 AA batteries which covers the 400-700 nm region and weighs only 200 g. [Figure 3.35(a)]. The instrument has a bandwidth of 4–7 nm, spectral resolution of 1.4 nm, and no moving parts.








FIGURE 3.34 (a) The AstraGene iCF UV/Vis spectrophotometer with the pipette being placed in the stand. (b) The pipette containing the sample in place for measurement. (c) Schematic of the "through the tip" technology. (©AstraNet systems, ltd., www.astranetsystems.com, www.norsci.ca. Used with permission.)






FIGURE 3.35 (a) The i-LAB® visible hand held analyzing spectrometer measuring a solid sample. (b) Schematic of the i-LAB® liquid sample measurement technique. (Courtesy of Microspectral Analysis, LLC, Wilton, ME [www.microspectralanalysis.com]. All rights reserved.)

The i-LAB* uses spectrally balanced LEDs to provide a uniform white light source, with a linearized photodiode array detector. The source light reflects directly from a solid sample [Figure 3.35 (a)] or passes through a liquid sample and reflects back [Figure 3.35(b)] and onto a linear variable filter attached to a multiple diode array detector. A spectrum is recorded and automatically saved. The data can be transformed to provide quantitative concentration using a Beer's law calculation, absorption, transmission, area under the curve, peak maximum, peak ratios, spectral matching, and color measurement using the L*, a*, b*, or RGB systems.

The system is available with a variety of sample adaptors, including a cuvette holder, a round vial holder, and custom vials for liquids and a surface reader for solids. The software allows users to create and transfer customized measurement methods to the i-LAB. Applications will be discussed in Section 3.3.

3.3 ANALYTICAL APPLICATIONS

3.3.1 QUALITATIVE STRUCTURAL ANALYSIS

As described at the beginning of the chapter, the types of compounds that absorb UV radiation are those with nonbonded electrons (n electrons) and conjugated double bond systems (π electrons) such as aromatic compounds and conjugated olefins. Unfortunately, such compounds absorb over similar wavelength ranges, and the absorption spectra overlap considerably. As a first step in qualitative analysis, it is necessary to purify the sample to eliminate absorption bands due to impurities. Even when pure, however, the spectra are often broad and frequently without fine structure. For these reasons, UV absorption is much less useful for the qualitative identification of functional groups or particular molecules than analytical methods such as MS, IR, and NMR. While a brief introduction to the use of UV absorption for structural identification is found in Appendix 3 on the website, UV absorption is rarely used for organic structural elucidation today because of the ease of use and power of NMR (Chapter 5), IR and Raman (Chapter 4), and MS (Chapter 9).

UV spectra can be used to confirm qualitative identification of a compound determined using IR, NMR and so on, by comparing the unknown compound's absorption spectrum with the spectrum of the known compound. Compilations of UV absorption spectra in electronic formats can be found from commercial sources such as the Informatics Division, Bio-Rad Laboratories (www.bio-rad.com), or the American Petroleum Institute (API) indices. Computer searching and pattern matching are the ways spectra are compared and unknowns identified in modern laboratories. Some academic libraries still maintain the printed spectra collections, which must be searched manually.

One area where qualitative UV/VIS spectroscopy is still very useful is in the rapid screening of samples for UV absorbing compounds. In a high throughput environmental lab, UV absorption can be used qualitatively to screen for samples that may have high levels of organic compounds, to avoid contaminating a sensitive instrument, or to evaluate dilution factors needed for quantitative analysis. In today's very high throughput pharmaceutical laboratories, UV absorption spectra can provide a quick survey of synthesized compounds, to screen out those that do not have the expected absorbance and therefore probably do not have the desired structure.

Another approach that can be taken is the use of derivative spectra, i.e., plotting the first, second, or even higher derivatives of the absorbance spectra. Derivative spectra can enhance the differences among spectra, resolve overlapping bands, and reduce the effects of interference from other absorbing compounds. The number of bands increases with higher orders of the derivative. The increased complexity of the derivative spectrum may aid in compound identification. For example, the absorbance spectrum of testosterone shows a single broad peak centered around 330 nm; the second derivative spectrum has six distinct peaks (Owen).

3.3.2 QUANTITATIVE ANALYSIS

UV and visible absorption spectrometry is a powerful tool for quantitative analysis. It is used in chemical research, biochemistry, chemical analysis, and industrial processing. Quantitative analysis is based on the relationship between the degree of absorption and the concentration of the absorbing material. Mathematically, it is described for many chemical systems by Beer's Law. The term applied to quantitative absorption spectrometry by measuring intensity ratios is **spectrophotometry**. The use of spectrophotometry in the visible region of the spectrum used to be referred to as *colorimetry*. (The term colorimetry appears in much of the older literature, but the term is also used for an unrelated measurement, the specification of color in samples using, for example, the Commission Internationale de l'Eclairage (CIE) L*a*b* system.) To avoid confusion, the term spectrophotometry should be used for both UV and visible regions when quantitative determination of an analyte species is meant. Quantitative UV/VIS spectrophotometry is useful for determination of organic molecules, inorganic molecules, metal and nonmetal ions, and organometallic complexes.

Some typical applications of UV absorption spectroscopy include the determination of the concentrations of phenol, nonionic surfactants, sulfate, sulfide, phosphates, fluoride, nitrate, a variety of metal ions, and other chemicals in drinking water in environmental testing, analysis of natural products, such as steroids or chlorophyll, dyestuff materials, vitamins, proteins, DNA, and enzymes in biochemistry.

Quantitative UV/VIS spectrophotometry has been used for the determination of impurities in organic samples, such as in industrial plant streams using flow-through cells. For example, it can be used to determine traces of conjugated olefins in simple olefins or aromatic impurities in pure hexane or similar paraffins. It has also been used in the detection of possible carcinogenic materials in foods, beverages, cigarette smoke, and air. In the field of agriculture, UV/VIS spectrophotometry is used for the determination of fertilizers containing nitrogen and phosphorus. In the medical field, it is used for the determination of enzymes, vitamins, hormones, steroids, alkaloids, and barbiturates. These measurements are used in the diagnosis of diabetes, kidney damage, and myocardial infarction, among other ailments. In the pharmaceutical industry, it can be used to measure the purity of drugs during manufacture and the purity of the final product. For example, aspirin, ibuprofen, and caffeine—common ingredients in pain relief tablets—all absorb in the UV and can be determined easily by spectrophotometry. Methods for many pharmaceuticals can be found in the United States Pharmacopeia and are called USP methods.

For example, the purity of acetaminophen, $C_8H_9NO_2$, can be determined by measuring the absorbance of an aqueous solution of the drug at 244 nm and comparing it to a solution of acetaminophen of known purity and concentration. See the suggested experiments at the end of the chapter for details.

Foods and beverages are often analyzed by UV/VIS spectrophotometry both to ensure quality and to determine impurities. An example of such an analysis is the determination of hydroxymethylfurfural (HMF) in honey. The method is described in the reference by Keppy et al. and the reference by White. HMF is an aldehyde that is generated by the decomposition of fructose in acidic conditions; it has a chromophore that absorbs at 284 nm. While HMF occurs naturally over time in most honeys, high levels of HMF may indicate poor storage conditions, adulteration with sugar additives or high heat. Levels in honey are regulated by the European Union and the Korean Food Code.

Olive oil is a major agricultural product for many countries. It is more valuable than other vegetable oils, especially high grades such as extra virgin olive oil (EVOO), but in the past 20 years, numerous cases around the world have found EVOO to be adulterated with cheaper oils, such as sunflower, canola, and soybean oil (Claverie and Johnson and references therein). The standard method for evaluating olive oil is a titration of the acidity using phenolphthalein. It is a slow method and can give "passing" results to adulterated samples. A rapid, accurate test for EVOO was clearly needed. Olive oil comes in a range of green-gold colors, due to the pigments found in olives, primarily chlorophylls and carotenoids. Using a hand held i-LAB visible spectrometer, Claverie and Johnson measured 12 cooking oils using a 5 cm cuvette over the range 400-700 nm. The EVOO samples were found to have major absorption peaks at 417 nm, 455 nm, 478 nm, and 667 nm (Figure 3.36) while the canola and blended oils had no such absorbance peaks. Three of the four spectra with absorbance less than 0.45 at 400 nm in Figure 3.36 are the known non-EVOO samples. However, one of the four spectra, clearly not containing the characteristic absorption peaks, was from a sample labeled as EVOO. The visible spectra, as can be seen, provide a clear and quick ID of olive oil in about ten seconds.

UV spectrophotometric determination of nucleic acids and proteins is a major application and systems are now able to perform this determination on sample volumes of 0.3-2 μL , often non-destructively. This is critical for DNA microarrays, polymerase chain reaction (PCR), and forensic DNA measurements. The nitrogenous bases, purines and pyrimidines, in nucleotides absorb at a λ_{max} of 260 nm. Using known extinction coefficients, concentrations of double-stranded DNA (dsDNA), single stranded DNA and RNA can be determined. Using the microvolume systems described above, dsDNA can be measured over a range of approximately 2-18,000 ng/ μ L. Proteins and peptides absorb strongly at 280 nm, due to the aromatic amino acids tryptophan, tyrosine, and phenylalanine and, to a smaller extent,




FIGURE 3.36 Absorbance spectra for a variety of vegetable oils using the i-LAB visible spectrometer. Extra virgin olive oil is clearly differentiated from other vegetable oils by the strong absorption peaks in the 400–480 nm region and the peak at 667 nm. (From Claverie and Johnson, courtesy of Microspectral Analysis, LLC. Wilton, ME, www.microspectralanalysis.com. Used with permission.)

disulfide bonds. The absorbance of a DNA sample at 280 nm gives an estimate of the protein concentration of the sample, and the ratio of the absorbance at 260 nm to the absorbance at 280 nm is a measure of the purity of the DNA sample. The ratio should be between 1.65 and 1.85. The measurement of proteins and peptides at 280 nm is an important application in itself, given the increasing use of these as therapeutic agents for the treatment of diseases. Extinction coefficient assays, the determination of the extinction coefficient over the linear working range, can be used to identify proteins and peptides. There are also a number of classic spectrophotometric protein assays based on the formation of a complex between a dye and proteins in solution. The named assays are referenced in the bibliography. The Bradford assay is based on the shift of Coomassie Brilliant Blue G-250 from 465–595 nm. This shift is due to the stabilization of the anionic form of the dye upon binding to protein. The bicinchoninic acid (BCA) assay (Smith et al.), is based on the reaction of proteins and alkaline copper ion with BCA to form a purple complex with an absorbance maximum at 562 nm.

Many clinical chemistry assays are based on UV/VIS spectrophotometry, often by reaction of the chemical of interest, such as glucose, with an enzyme and dye to create a colored complex. A novel method for determining the age of dried bloodstains at a crime scene has been developed by researchers at the National Center for Forensic Science at the University

of Central Florida using the Implen NanoPhotometer Pearl (Hanson and Ballantyne). The researchers discovered a previously unidentified hypsochromic shift (a blue shift to shorter wavelengths) in the Soret band of hemoglobin ($\lambda_{max} = 412$ nm) that had a high correlation to the time since deposition of dried bloodstains. The extent of the shift made it possible to distinguish among bloodstains that were deposited minutes, hours, days, and weeks prior to recovery and analysis. The test can be made on bloodstains as small as 1 μ L and the spot can be confirmed as blood by collecting the hemoglobin UV/VIS spectrum.

Spectrophotometry is used routinely to determine the concentrations of metal and nonmetal ions in a wide variety of samples, although many of the classic spectrophotometric measurements are being replaced by instrumental methods such as ion chromatography (Chapter 13), atomic spectroscopy (Chapters 6 and 7), and inorganic mass spectrometry (Chapter 9). Spectrophotometry in the UV region of the spectrum is used for the direct measurement of many organic compounds, especially those with aromatic rings and conjugated multiple bonds. There are also colorless inorganic species that absorb in the UV. A good example is the nitrate ion, NO₃. A rapid screening method for nitrate in drinking water is performed by measuring the absorbance of the water at 220 nm and at 275 nm. Nitrate ion absorbs at 220 nm but not at 275 nm; the measurement at 275 nm is to check for interfering organic compounds that may be present. Spectrophotometric analysis in the visible region can be used whenever the sample is colored. Many materials are inherently colored without chemical reaction (e.g., inorganic ions such as dichromate, permanganate, cupric ion, and ferric ion) and need no further chemical reaction to form colored compounds. Colored organic compounds, such as dyestuffs, are also naturally colored. Solutions of such materials can be analyzed directly. The majority of metal and nonmetal ions, however, are colorless. The presence of these ions in a sample solution can be determined by reacting the ion with an organic reagent to form a strongly absorbing species. If the product of the reaction is colored, absorbance can be measured in the visible region; alternatively, the product formed may be colorless but absorb in the UV. The majority of spectrophotometric determinations result in an increase in absorbance (darker color if visible) as the concentration of the analyte increases. However, there are analyses that cause a bleaching of color (decrease in absorbance) with increasing concentration of analyte.

As was mentioned in the introduction, the color we observe in a colored solution is the color that is transmitted by the solution. The color absorbed is the complementary color. The relationship between the color of light absorbed and the color observed is given in Table 3.6.

There are thousands of possible compounds and complexes that can be formed by reacting analyte species with organic reagents. Ideally, the reagent chosen should be selective; that is, it should react with only one ion or molecule under the conditions present. Second, the reagent should cause an abrupt color change or absorbance change when mixed with the analyte. This imparts high sensitivity to the method. Third, this intensity of color or UV absorbance should be related to the concentration of analyte in the sample. Spectrophotometric reagents have been developed for almost all metal and nonmetal ions and for many molecules or classes of molecule (i.e., for functional groups). Many of these reactions are both sensitive and selective. Several examples of these reagents and their uses are given in Table 3.7.

TABLE 3.6 A	Absorbed	and Observed	Colors
-------------	----------	--------------	--------

Color Absorbed	Color Observed
Red	Blue-green
Orange	Green-blue
Yellow	Blue
Yellow-green	Violet
Green	Violet-red
Blue-green	Red
Green-blue	Orange
Blue	Yellow
Violet	Yellow-green

TABLE 3.7 Typical Reagents Used in Spectrophotometry

Aluminon (also called ammonium aurintricarboxylate)

4-Aminophenazone (also called 4-aminoantipyrine)

$$CH_3 - N \xrightarrow{N} C = O$$

$$CH_3 - C \xrightarrow{} C - NH_2$$

Thiourea

H₂NCSNH₂

Chloranilic acid

Quinalizarin

Curcumin

SPADNS [also known as 4, 5-dihydroxy-3-(2-hydroxy-5-sulfophenylazo)-2, 7-naphthalenedisulfonic acid]

This compound reacts with aluminium in a slightly acid solution (pH 4–5) to form an intense red color in solution. It detects $0.04-0.4\,\mu g/mL$ (ppm) of Al. Other elements, such as Be, Cr, Fe, Zr, and Ti, also react with aluminon. These elements must be removed if a sample is being analyzed for Al. The absorbance of the red solution is measured at 525 nm. The red color is the result of formation of a metal–dye complex called a "lake".

This compound reacts with a variety of phenols to give intensely colored compounds and will detect 0.02–6.4 ppm of phenol in water. Drinking water is steam-distilled to separate the volatile phenols from interfering compounds. The distillate is treated with the reagent, and the colored complex is extracted into CHCl₃. The absorbance of the chloroform solution is measured at 460 nm. The reagent does not react with some para-substituted phenols, such as paracresol. This reaction is an example of the determination of organic compounds by spectrophotometric analysis following reaction with a color-producing reagent.

Thiourea will react with osmium, a very toxic element, in sulfuric acid solution to form a colored product. The absorbance is measured at 460 nm with a detection range of 8–40 ppm Os. The only interferences are Pd and Ru. Compared with the other reagents in this table, the sensitivity of the reagent is low. Interestingly, under different analytical conditions (different acid, pH) thiourea reacts with Bi. The absorbance of this product is measured at 322 nm, and detects 0.06–0.6 ppm of Bi. A number of elements such as Ag, Cu, Hg, and Pb interfere. This is an example of a reagent that works under different chemical conditions to produce a low-sensitivity determination for one element and a high-sensitivity determination for another.

Chloranilic acid forms solutions that are intensely red. The addition of calcium to the solution precipitates the chloranilic acid and the intensity of the red diminishes. The change (loss) in color is a measure of the quantity of calcium added. Numerous other elements interfere with the procedure. This is an example of spectrophotometric analysis by loss of color after addition of the sample.

This reagent gives intensely colored solutions in aqueous solutions. In 93 % w/w H_2SO_4/H_2O , the color is red. The presence of borate causes the color to become blue. Numerous other ions, such as Mg^{2+} , Al^{3+} , and Be^{3+} , also react with quinalizarin. This is an example of a change of color of the reagent after reaction with the sample.

Curcumin is a sensitive reagent for boron, detecting 0.01–0.1 ppm of B by absorbance at 555 nm. Fluoride, nitrate and nitrite interfere, but can be eliminated by separating the boron from the sample by distillation of B as a methyl borate ester.

SPADNS (pronounced "spadins") is used to determine fluoride ion in drinking water. The SPADNS dye reacts with zirconium to form a dark red Zr–dye "lake". The F^- ion reacts to dissociate the Zr–dye complex and form (ZrF_6^{2-}), which is colorless. The color of the solution decreases with increasing fluoride ion concentration. The absorbance is measured at 570 nm, with range of 0.2–1.40 ppm F^- . There are both positive and negative interferences from chlorine, chloride, phosphate, sulfate, and other species in drinking water. This is another example of a reaction where the color is "bleached" with increasing concentration of analyte.

Source: Examples were extracted from Standard Methods for the Examination of Water and Wastewater, and the references by Dean and Dulski.

The books by Boltz and by Sandell and Onishi listed in the bibliography are classic reference sources. The analytical literature contains thousands of direct and indirect methods for quantitative analysis of metals and nonmetals. A good summary of methods with literature references for most metal and nonmetal ions may be found in the handbook by Dean listed in the bibliography.

Quantitative analysis by absorption spectrophotometry requires that the samples be free from particulates, that is, free from **turbidity**. The reason for this is that particles can scatter light. If light is scattered by the sample away from the detector, it is interpreted as an absorbance. The absorbance will be erroneously high if the sample is turbid. We can make use of the scattering of light to characterize samples as discussed in Section 3.4, but particulates must be avoided for accurate absorbance measurements.

Quantitative analysis by spectrophotometry generally requires the preparation of a calibration curve, using the same conditions of pH, reagents added, and so on for all of the standards, samples, and blanks. It is critical to have a reagent blank that contains everything that has been added to the samples (except the analyte). The absorbance is measured for all blanks, standards, and samples. The absorbance of the blank is subtracted from all other absorbances and a calibration curve is constructed from the standards. The concentrations of analyte in the samples are determined from the calibration curve. The highest accuracy results from working in the linear region of the calibration curve. These quantitative methods can be quite complicated in the chemistry involved, the number of steps required: extraction, back-extraction, pH-adjustment, precipitation, masking, and many other types of operations may be involved in a method. The analyst must pay attention to all the details to achieve accurate and precise results. Both science and art are involved in performing many of these analyses. Many standard or regulatory methods (e.g., from Standard Methods for the Examination of Water and Wastewater, ASTM, EPA, etc.) have published precision and accuracy data in the methods. These are the precisions and accuracies that can be achieved by an experienced analyst.

There are three major factors that affect the accuracy and precision of quantitative absorption measurements: the instrument, the skill of the analyst, and the method variables. Instruments vary in the quality of their optical, mechanical, and electrical systems and also in their data processing. Each instrument has fixed limitations; these must be understood by the analyst and optimized when possible. Wavelength calibration must be checked routinely using recognized wavelength standards and other instrument parameters should be checked regularly. Method variables include the quality of the reagents used, pH, temperature control, color stability, reaction kinetics, and stoichiometry. It may be necessary to remove interferences, to buffer the sample, to control exposure to air and light, and perform other chemical manipulations to achieve accurate results. The analyst must be trained to operate the instrument and to perform all the chemical manipulations required. Attention to detail, accurate recordkeeping, routine use of replicates, spiked samples, or reference materials, and the preparation and measurement of appropriate blanks and standards are the analyst's responsibility.

Spectrophotometric analyses are capable of being performed with relative standard deviations as low as 0.5 %. Detection limits depend on the molar absorptivity of the transition being measured, but are often sub-ppm for many analytes. The linear working range for spectrophotometry used to be only one to two orders of magnitude but new systems are capable of much higher linear working ranges.

3.3.3 MULTICOMPONENT DETERMINATIONS

It has been seen that UV/VIS absorption peaks are generally broad, so if there are two compounds, X and Y, in solution, it is likely that they will not be completely resolved from each other. That is, both X and Y contribute to the absorbance at most wavelengths. It is possible to calculate the concentrations of X and Y from a series of measurements. Measurements must be made at a number of wavelengths equal to the number of components in the mixture. In this case, there are two components, so two wavelengths are needed. Caveats for this

approach are that the two components each follow Beer's Law and that the two components must not interact in solution; their absorbances must be additive.

Four calibration curves need to be prepared: X at λ_1 , X at λ_2 , Y at λ_1 , and Y at λ_2 . All calibration curves should be blank corrected to pass through the origin. The absorbance of the sample mixture is measured at λ_1 and at λ_2 .

Two equations can be written:

(5.3)
$$A_1 = C_X S_{X1} + C_Y S_{Y1}$$
$$A_2 = C_X S_{X2} + C_Y S_{Y2}$$

where A_1 is the absorbance of the unknown at λ_1 ; A_2 , the absorbance of the unknown at λ_2 ; C_X , the concentration of X in the unknown; C_X , the concentration of Y in the unknown; S_{X1} , the slope of the calibration curve for X at λ_1 ; S_{X2} , the slope of the calibration curve for X at λ_2 ; S_{Y1} , the slope of the calibration curve for Y at λ_1 ; and S_{Y2} , the slope of the calibration curve for Y at λ_2 .

The absorbances and slopes are known; this leaves us with two equations and two unknowns, C_X and C_Y . The equations can be solved for the concentrations of X and Y in the unknown mixture. Dulski gives an example of this approach with a method for the simultaneous determination of niobium and titanium by reaction with hydroquinone and measurement at 400 and 500 nm. Another example is the analysis of a common nasal spray which contains L-phenylephrine (PEH) and chlorpheniramine maleate (PAM). Each compound in aqueous solution gives a broad absorption peak in the UV. Choose two wavelengths; preferably the λ_{max} for each, if possible. The amounts of the two ingredients in the nasal spray can be found by preparing a calibration curve of each compound, obtaining the slopes of the lines at two wavelengths, for example, at 266 nm and 272 nm. This gives the four S terms as shown above. Then, the sample is measured at the two wavelengths, giving the A terms. The experiment is outlined in the suggested experiments at the end of the chapter.

This same approach can be used for a mixture of three components. More complex mixtures can be unraveled through computer software that uses an iterative process at multiple wavelengths to calculate the concentrations. Mathematical approaches used include partial least squares, multiple least squares, principle component regression, and other statistical methods. Multicomponent analysis using UV absorption has been used to determine how many and what type of aromatic amino acids are present in a protein and to quantify five different hemoglobins in blood.

3.3.4 OTHER APPLICATIONS

3.3.4.1 REACTION KINETICS

In common with other spectroscopic techniques, UV spectroscopy can be used to measure the kinetics of chemical reactions, including biochemical reactions catalyzed by enzymes. For example, suppose that two compounds A and B react to form a third compound C. If the third compound absorbs UV radiation, its concentration can be measured continuously. The original concentrations of A and B can be measured at the start of the experiment. By measuring the concentration of C at different time intervals, the kinetics of the reaction $A + B \rightarrow C$ can be calculated. Enzyme reactions are important biochemically and also analytically; an enzyme is very selective, even specific, for a given compound. The compound with which the enzyme reacts is called the substrate. If the enzyme assay is correctly designed, any change in absorbance of the sample will result only from reaction of the substrate with the enzyme. The rate of an enzyme reaction depends on temperature, pH, enzyme concentration and activity, and substrate concentration. If conditions are selected such that all of the substrate is converted to product in a short period of time, the amount of substrate can be calculated from the difference between the initial absorbance of the solution and the final absorbance. This approach is called an end point assay. Alternatively, in a rate assay, the other experimental




FIGURE 3.37 Measurement of the fast and slow steps in the oxidation of dichromate ion by spectroscopy using a rapid mix accessory. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

variables are controlled so that the rate of the enzyme reaction is directly proportional to substrate concentration.

From a practical point of view, many reactions occur so rapidly that manual mixing of reagents is not practical. Mixing dead time must be small compared to the reaction half-life. Temperature must be accurately controlled, since reaction rates are temperature dependent. For accurate determination of start times, electronic triggering is necessary. Sophisticated accessories are available with most major instruments. The example used here is from Dr. Michael Allen, Thermo Fisher Scientific, using the Rapid Mixing accessory described earlier.

The dichromate ion, $Cr_2O_7^{2-}$, contains the toxic Cr(VI) ion and is usually removed from chemical waste by oxidation to Cr(III). The oxidation of dichromate with hydroxide ion proceeds in two steps, the first step slow and the second fast:

$$Cr_2O_7^{2-} + OH^- \to HCrO_4^- + CrO_4^{2-}$$
 slow
 $CrO_4^- + OH^- \to CrO_4^{2-} + H_2O$ fast

At low hydroxide concentration, both the fast and slow steps can be measured (Figure 3.37).

3.3.4.2 SPECTROPHOTOMETRIC TITRATIONS

Many titration procedures in volumetric analysis use an indicator that changes color to signal the endpoint of the titration. For example, acid-base titrations are often performed with indicators such as phenolphthalein. Figure 3.38 shows the structure of phenolphthalein in an acid solution and in a basic solution. As can be seen, the loss of protons results in a change in the structure of the molecule. As we know, this should result in a change in the energy levels in the molecule. In phenolphthalein, the energy level difference gives rise to the absorption of visible radiation when it is in an alkaline solution, but not in an acid solution. Phenolphthalein appears red in basic solution but colorless in acidic solution. Such structure changes and energy level changes are the basis of many acid-base indicators. Use of the human eye to detect the color change at the end of a titration is subject to the problems described at the beginning of the chapter. Each analyst may "see" the endpoint slightly differently from other analysts, leading to poor precision and possible errors. The use of a spectrophotometer to detect the color change is more accurate and reproducible. Use of the spectrophotometer also permits any change in absorbance in the UV or visible region by the titrant, analyte, or

FIGURE 3.38 The structure of phenolphthalein in acidic solution and basic solution. The change in structure results in a change in the light absorbed by the molecule.

product to be used to determine the endpoint of the titration, so the method is not limited to reactions that use a colored indicator.

Spectrophotometric titrations have been used for redox titrations, acid-base titrations, and complexation titrations. The spectrophotometer can be used in a light scattering mode to measure the endpoint for a precipitation titration by turbidimetry. Spectrophotometric titrations can be easily automated.

3.3.4.3 SPECTROELECTROCHEMISTRY

Oxidation-reduction reactions of inorganic and organic compounds can be studied by using a combination of electrochemistry (Chapter 14) and spectroscopy. Diode array systems are usefully employed when transparent thin electrodes are used to study these reaction mechanisms. By taking the absorption spectra in rapid succession and accumulating the data, it is possible to detect and measure intermediates formed in complex reactions. This is much more reliable than using absorption at a single wavelength to measure the reactions, since the choice of the single wavelength is often made with the assumption that the intermediates and end products are well known and suitable absorption wavelengths are therefore easily chosen. This is often not the case. Using the diode array system, the complete UV absorption spectra can be obtained, and much more information on the identity and concentration of species is therefore available.

3.3.4.4 ANALYSIS OF SOLIDS

Solids can be measured in transmission or reflection (reflectance) modes. Both specular reflection and diffuse reflection are used. Diffuse reflection accessories include the Praying Mantis™ from Harrick Scientific Products, Inc. and a variety of integrating spheres available from most major instrument companies. Specular reflection is used for highly reflective materials; diffuse reflectance for powders and rough surfaced solids. Materials characterization relies heavily on techniques like these.

The Praying Mantis[™] and its high temperature reaction chamber have been used for studying temperature-induced wavelength changes in Thermal Liquid Crystal Paint, analyzing gas-solid reactions such as heterogeneous catalysis, and routine analysis of powders and solids. Application notes can be found at www.harricksci.com.

Using the Shimadzu ISR-2600Plus integrating sphere on their UV-2600 spectrophotometer, it is possible to make transmission measurements of solids such as polycrystalline silicon.

3.3.5 MEASUREMENT OF COLOR

Color is a very important parameter for many manufactured products including paint, cosmetics, foods, beverages, pharmaceutical liquids and tablets, textiles, and so on. If the

calcium supplements in a bottle are supposed to be pink, all the tablets in the bottle should be the same color. All of the bottles in a lot should be the same color. If they are not, consumers may think there is something wrong with the tablets. Both the generation and sensation of color are complex and depend on factors such as the spectrum of the illuminant and the surface structure of solid samples, for example. The most widely used international scale for color is the CIE L*a*b* color space introduced in 1976. CIE stands for *Commission internationale de l'eclairage*, French for International Commission on Illumination. The CIE L*a*b* color space describes all colors visible to the human eye and is device independent. Most spectrophotometers, equipped with the appropriate software, can be used to measure color.

The three coordinates, L*, a*, and b* are organized like the x, y, and z axes in a cube or sphere; they are orthogonal to each other. The L* axis runs from top to bottom (like the z axis) and represents the lightness of the color. $L^* = 0$ represents pure black; $L^* = 100$ is pure diffuse white. The a* axis represents the color position between green and red, with negative a* values indicating greener colors; positive a* indicating redder colors. The b* axis is the blue-yellow axis, with negative b* values on the blue end and positive b* values toward yellow. Because there are three coordinates, this is also called a tristimulus color system. Delta values associated with each coordinate indicate how much a standard and sample differ from each other, and are often used for quality control or formula adjustment. An overall measure of color difference is ΔE^* . ΔE^* is equal to the square root of the sum of the squares of the ΔL^* , Δa^* and Δb^* values. The values for the coordinates are calculated from a mathematical combination of visible absorbance spectra combined with standard functions for the observation angle and illumination source. Assuming that our spectrophotometer has the appropriate software, we'll look at some examples of how colors of products are measured. We note that other color spaces are used in films, scanner/printer/projector technology, etc. An example is the familiar RGB (red-green-blue) color space. Quantitative measurements require a color space that is perceptually linear, that is, the vector lengths correspond to differences in what an observer would perceive. L*a*b* color space fulfills this need.

Earlier, we discussed the use of visible absorbance spectra to compare olive oils and to detect non-olive oil vegetable oils. Using the same instrument, the i-LAB (Claverie and Johnson), the L*a*b* values were also calculated, using as the illumination source the CIE D65 function, which represents standard daylight. The observer function was the CIE 10° standard angle. For all the oils measured, the L* value correlated well with visual lightness observations. Olive oils have very definite colors ranging from light yellow or green to darker green and golden colors. Most of the oils had a* values of -2 to -14 (light green to dark green) and b* values > +7, indicating light yellow to golden yellow. All of the EVOOs had L* < 92.3, a* > (-10) and b*> 50; the canola oils had L* values > 94, meaning they were lighter than the EVOOs, with a* values in the -2 to -4 range and b* values < 10. All measurements were made in less than ten seconds. The tristimulus values can easily be used to check batch to batch variability of vegetable oils.

The color of beer is often the first thing people notice about it (Johnson et al.). Beer color ranges from pale yellow for a wheat beer to opaque black for stout. The white paper by Johnson et al. is highly recommended reading, for both a history of color measurement using spectrophotometry, but also for the color graphics. The i-LAB visible spectrometer was used to measure the color of beer according to the American Society of Brewing Chemists (ASBC) protocol, but can also calculate the tristimulus values as noted above and the European Brewing Convention color, which uses a slightly different protocol. The ASBC color measurement defines beer color as ten times the absorbance at 430 nm for a calculated 0.5 inch pathlength of decarbonated beer samples. Typical absorbance curves for four beers are shown in Figure 3.39.

Several important measures of wine quality can be evaluated by mathematical combination of absorbance values at multiple wavelengths (Bain). Wine *color intens*ity, a measure of how dark the wine is, is calculated from the sum of the absorbances at 420nm, 520nm, and 620 nm. The wine *hue* is a measure of the appearance of the wine and is calculated from the ratio of absorbance at 420 nm to absorbance at 520 nm. The Thermo Fisher Scientific software on the Evolution Array UV/VIS spectrophotometer can calculate the intensity, hue and the CIE $L^*a^*b^*$ values, as well as the color difference values (the delta values) compared to a standard.




FIGURE 3.39 Visible absorbance spectra of selected beers from 400 nm to 700 nm. The lowest curve is the Old Milwaukee, then Molson Canadian, Allagash Black, and Baxter being the most absorbing as run. The Allagash Black was diluted 1:10 and the Baxter 1:2 with distilled water. (From Johnson et al., Copyright, Microspectral Analysis LLC. www.microspectralanalysis.com used with permission.)

TABLE 3.8 Color and Color Differences in	Wines
---	-------

Wine	L*	a*	b*	Δ L*	Δ a*	$\Delta \mathbf{b}^{ullet}$	CIE ∆E*
Standard	99.9702	-0.0047	-0.074				
Red 1	56.392	36.660	27.775	-43.578	36.664	27.849	63.394
Red 2	65.478	31.896	17.716	-34.492	31.901	17.790	50.238
Red 3	70.463	27.620	12.179	-29.508	27.625	12.253	42.237
Red 4	75.233	25.744	9.695	-24.737	25.749	9.769	37.018
Red 5	74.303	23.064	15.526	-25.667	23.068	15.600	37.873
White 1	100.185	-0.144	0.819	0.215	-0.479	0.893	1.037
White 2	99.258	-0.099	1.621	-0.713	-0.095	1.695	1.842

Source: Table modified from Bain. Application note and data © 2018 Thermo Fisher Scientific, www.thermofisher.com. Used with permission.

Red wines exhibit an absorbance between 400 and 650 nm, centered at about 500 nm, due to the presence of anthocyanin. No such peak appears in the spectra of white wines. The CIE color measurements are carried out in transmittance mode. Table 3.8 shows results for the color and color difference measurements.

You can see from the L* values that the white wines are lighter than the reds; in fact, one of the white wines has an L* value >100. The L*=100 value is for diffuse white; samples that give specular reflection may be higher than 100. You can also see that the a* values for the red wines are positive, as would be expected, while the white wines are negative (more greenish than red in color).

3.4 NEPHELOMETRY AND TURBIDIMETRY

Much of the theory and equipment used in spectrophotometry applies with little modification to **nephelometry** and **turbidimetry**. These fields involve the **scattering** of light by nontransparent particles suspended in a liquid; examples of such particles include fine precipitates and colloidal suspensions. In *nephelometry*, we measure the amount of radiation




FIGURE 3.40 Schematic optical system for nephelometry.

scattered by the particles; in *turbidimetry*, we measure the amount of light *not scattered* by the particles. These processes are illustrated in Figures 3.40 and 3.41. The applications of nephelometry include the estimation of the clarity of drinking water, beverages, liquid pharmaceuticals, and other products where the transparency is important. Nephelometry is used in the determination of species that can be precipitated, such as calcium or barium by precipitation as the phosphate or sulfate insoluble salt. The quantity of calcium or barium present is measured by the amount of radiation scattered by the precipitated compound. From the intensity of scattered radiation, the original concentration of calcium or barium can be determined. Conversely, sulfate and phosphate can be determined by precipitation as the barium compound. Process analyzers using nephelometry or turbidimetry can be used to monitor the clarity of a plant stream or water treatment facility stream on a continuous basis.

When using nephelometry or turbidimetry for quantitative analysis, standard suspensions or standard turbid solutions are required for calibration. The precipitate or suspension standards must be prepared under rigidly controlled conditions. This is essential because the scattering of light depends on the *size*, *shape*, and *refractive index* of the *particles* involved, as well as on the concentration of particles. Some particles also absorb light, which will cause an error in the turbidity measurement. It is necessary for a given solution to produce the same number of particles of the same size and other properties listed for the degree of light scattering to be meaningful. Interferences include dirty sample cells, and any absorbing species that will remove light from the light path. Any absorbance of light will result in an erroneously high turbidity, just as turbidity results in an erroneously high absorbance.

The wavelength of the light scattered most efficiently depends on the physical size of the scattering particles. From this, it can be reasoned that the size of the scattering particle may be determined if the wavelength of scattered light is accurately known. This type of light scattering forms the basis for the measurement of polymer molecular weights from the size of polymer molecules.

For water analysis, the formulation of turbid standards is very difficult, so most water laboratories use a synthetic polymer suspension as a standard. The formazin polymer suspension is easy to make and more stable and reproducible than adding clay or other particles to water to prepare standards. Alternatively, suspensions of polymer beads of the appropriate size can be used as scattering standards. (See Standard Methods for the Examination of Water and Wastewater for details.)

In the determination of a given species by a precipitation reaction, it is critical to control the experimental conditions. Two identical samples of equal concentration of analyte will scatter light equally only if they form the same number and size distribution of particles when they are precipitated. This depends on many experimental conditions, including the




FIGURE 3.41 Schematic optical system for turbidimetry.

sample temperature, the rate at which the precipitant and the sample are mixed, the degree of agitation or stirring, and the length of time the precipitates are allowed to stand before measurement. Procedures usually call for the use of a stopwatch to make all measurements at the same point in time, such as 60 s after the reagent was added. Interferences include other particles and absorbing species. Sulfate in drinking water can be determined turbidimetrically by precipitation as barium sulfate over the range of 1-40 mg/L sulfate, with a precision of about 2 %RSD and accuracy, estimated by recovery of spiked samples, of about 90 %.

Other working definitions of turbidity can be used. We discussed measuring the color of beer above, using the ASBC protocol. Turbidity in beer is defined by them as a function of the difference in the absorbances of decarbonated beer at 700 nm and at 430 nm (Johnson et al.). If the absorbance at 700 nm for a calculated 0.5 inch pathlength is less than or equal to 0.039 times the absorbance for the same pathlength at 430 nm, the beer is said to be free of turbidity. If the value at 700 nm is > 0.039 x Abs_{430 nm}, the beer is turbid and would need to be clarified by centrifugation or filtration in order to get a true color measurement.

3.5 MOLECULAR EMISSION SPECTROMETRY

3.5.1 FLUORESCENCE AND PHOSPHORESCENCE

If "black light" (UV light) illuminates certain paints or certain minerals in the dark, they give off visible light. These paints and minerals are said to *fluoresce*. An energy diagram of this phenomenon is shown in Figure 3.42. For fluorescence to occur, a molecule must absorb a photon and be promoted from its ground state to an excited vibrational state in a higher electronic state. There are actually *two* possible electronic transitions. Electrons possess the property of spin; we can think of this simplistically as the electron rotating either clockwise or counterclockwise. For two electrons to occupy the same orbital, their spins must be opposite to each other; we say that the spins are paired. If one electron is raised to the excited level without changing its spin, the electron in the excited level is still opposite in spin to the electron left behind in the valence level. This excited state of the molecule in which electron spins are paired is called a *singlet* state. If the electron spins are parallel (both spinning in the same direction as a result of the excited electron reversing its spin), the excited state is called a *triplet* state. Each "excited state" has both a singlet and corresponding triplet state. Singlet state energy levels are higher than the corresponding triplet state energies. Singlet states are designated S₁, S₂, S₃, and so on; triplet states are designated T₁, T₂, T₃, and so on. The ground




FIGURE 3.42 Schematic diagram of the ground state, excited singlet state, and excited triplet state, of a molecule. The wavy line denotes a radiation-less transition from a higher vibrational level in the excited singlet state to the lowest vibrational level in the excited singlet state. The dotted arrow marked ISC shows the radiation-less *intersystem crossing* from the excited singlet state to the excited triplet state. The length of the solid arrows denotes the relative energy of the transitions: absorption > fluorescence > phosphorescence. This results in $\lambda_{\text{phosphorescence}} > \lambda_{\text{fluorescence}} > \lambda_{\text{absorption}}$.

state is a singlet state, S_0 . Figure 3.42 shows a ground state with the first excited singlet and triplet states. Some vibrational sublevels of the excited states are also shown.

The molecule absorbs energy and an electron is promoted to one of the higher vibrational levels in the singlet state; this is a vibrationally excited electronic state. The vibrationally excited molecule will rapidly "relax" to the lowest vibrational level of the electronic excited state S_1 . This relaxation or loss of energy is a radiation-less process, shown by the wavy arrow. Energy decreases but no light is emitted. Now the molecule can return to the ground state by emitting a photon equal to the energy difference between the two levels. This is the process of *fluorescence*: excitation by photon absorption to a vibrationally excited state followed by a rapid transition between two levels with the same spin state (singlet to singlet, in this case) that results in the emission of a photon. The emitted photon is of lower energy (longer wavelength) than the absorbed photon. The wavelength difference is due to the radiation-less loss of vibrational energy, depicted by the wavy line in Figure 3.42. This type of fluorescence, emission of a longer wavelength than was absorbed, is what is usually seen in solutions; it is called Stokes fluorescence. The lifetime of the excited state is very short, on the order of 1-20 ns, so fluorescence is a virtually instantaneous emission of light following excitation. However, the lifetime of the fluorescent state is long enough that time-resolved spectra can be obtained with modern instrumentation. A molecule that exhibits fluorescence is called a fluorophore.

The transition from the singlet ground state to a triplet state is a forbidden transition. However, an excited singlet state can undergo a radiation-less transition to the triplet state by reversing the spin of the excited electron. This is an energetically favorable process since the triplet state is at a lower energy level than the singlet state. This radiation-less transition, shown schematically in Figure 3.42 and 3.43, is called *intersystem crossing (ISC)*. The molecule can relax to the ground state from the triplet state by emission of a photon. This is the process of *phosphorescence*: excitation by absorption of light to an excited singlet state, then an ISC to the triplet state, followed by emission of a photon due to a triplet-singlet transition. The photon associated with phosphorescence is even lower energy (longer wavelength) than the fluorescence photon, as seen from the relative energy levels in Figures 3.42 and 3.43. Because the triplet-singlet transition is forbidden, the lifetime of the triplet excited state is long, up to 10 s in some cases. The sample will "glow" for some time after the excitation light source is removed. "Glow in the dark" paint is an example of phosphorescent material.

Fluorescence and phosphorescence are both types of luminescence. They are, specifically, types of *photoluminescence*, meaning that the excitation is achieved by absorption of light. There are other types of luminescence. If the excitation of a molecule and emission of light occurs as a result of chemical energy from a chemical reaction, the luminescence is called *chemiluminescence*. The "glow sticks" popular at rock concerts and Halloween are an example of chemiluminescence. The light emitted by a firefly is an example of *bioluminescence*. *Electroluminescence* is induced by current. Both photoluminescence and electroluminescence




FIGURE 3.43 Processes by which an excited molecule can relax to the ground state. The short-dotted arrow shows the radiation-less *intersystem crossing* from the excited singlet state to the excited triplet state. (Adapted from Guilbault, used with permission.)

are exhibited by semiconductor quantum dots, solid state sources of single photons, made from materials such as InAs.

As shown in Figure 3.43, there are other ways for molecules to return to the ground state. Excited molecules may collide with other molecules; it is possible for energy to be transferred during this collision. The molecule returns to the ground state but does not emit radiation. This is called collisional deactivation or quenching. Quenching occurs in solution by collision of the excited analyte molecule with the more numerous solvent molecules. Quenching in fluorescence is often a serious problem, but with care it can be minimized. Quenching by collision with the solvent molecules can be reduced by decreasing the temperature, thus reducing the number of collisions per unit time. The same result can be achieved by increasing the viscosity—for example, by adding glycerine. Dissolved oxygen is a strong quenching agent. It can be removed by bubbling nitrogen through the sample. Phosphorescence is very susceptible to quenching; the molecule in a triplet state has an extended lifetime in the excited state, so it is quite likely that it will collide with some other molecule and lose its energy of excitation without emitting a photon. Phosphorescence is almost never seen in solution at room temperature because of collisional deactivation. Low temperatures must be used and the analyte must be constrained from collision. This can be done for fluorescence and phosphorescence by converting the sample into a gel (highly viscous state), glass, or by adsorption of the analyte onto a solid substrate. "Organized" solvents such as surfactant micelles have been used successfully to observe room temperature phosphorescence and to greatly enhance fluorescence by reducing or eliminating collisional deactivation. Even with the appropriate experimental care, only a small fraction of available analyte molecules will actually fluoresce or phosphoresce, since radiation-less transitions are very probable.

3.5.2 RELATIONSHIP BETWEEN FLUORESCENCE INTENSITY AND CONCENTRATION

The intensity of fluorescence *F* is proportional to the amount of light absorbed by the analyte molecule. We know from Beer's Law that:

(3.4)
$$\frac{I_1}{I_0} = e^{-abc}$$

so, subtracting each side of the equation from 1 gives:

$$(3.5) 1 - \frac{I_1}{I_2} = 1 - e^{-abc}$$

We multiply each side by I_0 :

$$(3.6) I_0 - I_1 = I_0 (1 - e^{-abc})$$

Since $I_0 - I_1 =$ amount of light absorbed, the fluorescence intensity, F, may be defined as:

(3.7)
$$F = (I_0 - I_1)\Phi$$

where Φ is the quantum efficiency or quantum yield. The quantum yield, Φ , is the fraction of excited molecules that relax to the ground state by fluorescence. The higher the value of Φ , the higher the fluorescence intensity observed from a molecule. A nonfluorescent molecule has $\Phi = 0$.

Therefore, fluorescence intensity is equal to:

(3.8)
$$F = I_0 (1 - e^{-abc}) \Phi$$

From Equation 3.8, it can be seen that fluorescence intensity is related to the concentration of the analyte, the quantum efficiency, the intensity of the incident (source) radiation, and the absorptivity of the analyte. Φ is a property of the molecule, as is the absorptivity, a. A table

Compound	Solvent	Φ
9-Aminoacridine	Ethanol	0.99
Anthracene	Hexane	0.33
9,10-Dichloroanthracene	Hexane	0.54
Fluorene	Ethanol	0.53
Fluorescein	0.1 N NaOH	0.92
Naphthalene	Hexane	0.10
1-Dimethylaminonaphthalene-4-sulfonate	Water	0.48
Phenol	Water	0.22
Rhodamine B	Ethanol	0.97
Sodium salicylate	Water	0.28
Sodium sulfanilate	Water	0.07
Uranyl acetate	Water	0.04

of typical values of Φ for fluorescent molecules is given in Table 3.9. The absorptivity of the compound is related to the fluorescence intensity. Molecules like saturated hydrocarbons that do not absorb in the UV/VIS region do not fluoresce.

The fluorescence intensity is directly proportional to the intensity of the source radiation, I_0 . In theory, the fluorescence intensity will increase as the light source intensity increases, so very intense light sources such as lasers, mercury arc lamps, or xenon arc lamps are frequently used. There is a practical limit to the intensity of the source because some organic molecules are susceptible to photodecomposition.

When the term abc is <0.05, which can be achieved at low concentrations of analyte, the fluorescence intensity can be expressed as:

$$(3.9) F = I_0 abc \Phi$$

That is, F, total fluorescence, = kI_0c , where k is a proportionality constant. At low concentrations, a plot of F vs. concentration should be linear. But, only a portion of the total fluorescence is monitored or measured; therefore:

$$(3.10) F' = Fk'$$

where F' is the measured fluorescence and

$$(3.11) F' = k'I_0c$$

where k' is another proportionality constant.

A plot of *F* vs. *c* is shown in Figure 3.44. It is linear at low concentrations. The linear working range for fluorescence is about five orders of magnitude, from 10^{-9} to 10^{-4} M.

At higher concentrations, the relationship between F and c deviates from linearity. The plot of F vs. c rolls over as seen in Figure 3.45. It can be seen that at higher concentrations the fluorescence intensity actually decreases because the molecules in the outer part of the sample absorb the fluorescence generated by those in the inner part of the sample. This is called the "inner cell" effect or self-quenching. In practice, it is necessary to recognize and correct for this effect. It is impossible to tell directly if the fluorescence measured corresponds to concentration A or concentration B as shown in Figure 3.45. Both concentrations would give the same fluorescence intensity. Diluting the sample slightly can solve the dilemma. If the original concentration were A, then the fluorescence intensity would sharply decrease on dilution. On the other hand, if the concentration were B, then the fluorescence should increase on slight dilution of the sample.




FIGURE 3.44 Dependence of fluorescence on the concentration of the fluorescing molecule. (From Guilbault, used with permission.)




FIGURE 3.45 Fluorescence intensity at high concentrations of analyte. Note the reversal of fluorescence at high concentration. Concentrations a and b give the same fluorescence intensity and could not be distinguished by a single measurement.

3.6 INSTRUMENTATION FOR LUMINESCENCE MEASUREMENTS

A schematic diagram of a spectrofluorometer is shown in Figure 3.46. Spectrometer systems for luminescence measurements are available from the major instrument companies, including Agilent, Horiba, PerkinElmer, Shimadzu, Thermo Fisher Scientific, and others. Only a few examples will be discussed; the company websites provide information, applications notes, and photos of their instrumentation. Luminescence spectrometers range from highend research instruments to dedicated application instruments.

3.6.1 WAVELENGTH SELECTION DEVICES

Two monochromators are used, the primary or excitation monochromator, and the secondary or fluorescence monochromator. These are generally grating monochromators, although filters can be used for specific analyses. The excitation monochromator selects the desired




FIGURE 3.46 Block diagram of the optical components of a typical fluorometer. (From Guilbault, used with permission.)




FIGURE 3.47 Front surface fluorescence geometry for a solid sample. (From Froelich and Guilbault, used with permission.)

narrow band of wavelengths that can be absorbed by the sample. The sample emits light in all directions. The second monochromator is placed at 90° to the incident light beam. The second monochromator is set to pass the fluorescence wavelength to the detector. The 90° orientation of the second monochromator is required to avoid the detector "seeing" the intense incident light, thus eliminating the background caused by the light source. Unlike absorption spectrophotometry, the measurement is not of the small difference between two signals, but of a signal with essentially no background. This is one reason for the high sensitivity and high linearity of fluorescence. Most fluorescence instruments are single beam instruments. This means that changes in the source intensity will result in changes in the fluorescence intensity. To compensate for changes in the source intensity, some instruments split off part of the source output, attenuate it, and send it to a second detector. The signals from the two detectors are used to correct for drift or fluctuations in the source.

The 90° geometry is the most common orientation for measuring fluorescence and works very well for solution samples that do not absorb strongly. Other angles are used in specific applications. For strongly absorbing solutions or for solid samples such as thin layer chromatography plates, fluorescence is measured from the same face of the sample illuminated by the source. This is called front-surface geometry. It is shown schematically for a solid sample in Figure 3.47.

3.6.2 RADIATION SOURCES

The fluorescence intensity is directly proportional to the intensity of the light source. Therefore, intense sources are preferred. Excitation wavelengths are in the UV and visible regions of the spectrum, so some of the same sources used in UV/VIS absorption spectrometry are used for fluorescence. The optical materials will of course be the same—quartz for the UV, glass for the visible region.

Mercury or xenon arc lamps are used. A schematic of a xenon arc lamp is given in Figure 3.48. The quartz envelope is filled with xenon gas, and an electrical discharge through the gas causes excitation and emission of light. This lamp emits a continuum from 200 nm into the IR. The emission spectrum of a xenon arc lamp is shown in Figure 3.49. Current fluorescence spectrometers use xenon flash lamps. Mercury lamps under high pressure can be used to provide a continuum, but low-pressure Hg lamps, which emit a line spectrum, are often used with filter fluorometers. The spectrum of a low-pressure Hg lamp is presented in Figure 3.50.



FIGURE 3.48 Compact xenon arc lamp used in fluorometers. The quartz envelope is filled with xenon gas. The lamp is ignited by a 10-20 kV pulse across the electrodes. (From Froelich and Guilbault, used with permission.)




FIGURE 3.49 Spectral output of a compact xenon arc lamp. (From Froelich and Guilbault, used with permission.)

Because of their high intensity, laser light sources are ideal sources for fluorescence. The laser must exhibit a wide range of emission wavelengths, so tunable dye lasers have been the only choice until recently. The dye lasers are generally pumped by a neodymium yttrium aluminum garnet (Nd:YAG) laser. These pumped dye laser systems are very expensive and complicated to operate. They have much greater intensity output than lamps and so enable lower detection limits to be achieved. Recent advances in solid-state lasers have made small, less expensive visible wavelength lasers available. Solid-state UV lasers are available, but do not have the required intensity for use as a fluorescence source.

3.6.3 DETECTORS

The most common detector is the PMT. The operation of a PMT was described earlier in this chapter. Because the signal is small due to the low concentrations of analyte used, the PMT is often cooled to sub-ambient temperature to reduce noise. The limitation of the PMT is that it is a single wavelength detector. This requires that the spectrum be scanned. As we have discussed, scanning takes time and is not suitable for transient signals such as those from a




FIGURE 3.50 Spectral output of a mercury arc lamp, used as a source in fluorometers. (From Froelich and Guilbault, used with permission.)

chromatographic column. Diode array detectors are now available to collect the entire spectrum at once instead of scanning. The CCD, a 2D array detector, is another alternative to scanning in fluorescence spectrometry. Both PDA and CCD detectors can be used with liquid chromatography (LC) or capillary electrophoresis (CE) systems for separation and detection of fluorescent compounds or fluorescent-labeled ("tagged") compounds in mixtures. LC and CE are discussed in Chapter 13.

3.6.4 SAMPLE CELLS

The most common cell for solutions is a 1 cm rectangular quartz or glass cuvette with **four** optical windows. For extremely small volumes, fiber optic probes, microvolume cells, and flow cells are available. Gas cells and special sample compartments for solid samples are commercially available. Microplate readers are available for most instruments, permitting analysis of large numbers of samples.

3.7 ANALYTICAL APPLICATIONS OF LUMINESCENCE

Fluorescence occurs in molecules that have low energy $\pi \to \pi^*$ transitions; such molecules are primarily aromatic hydrocarbons and polycyclic aromatic compounds. Examples include those in Table 3.9, as well as compounds like indole and quinoline. Molecules with rigid structures exhibit fluorescence; the rigidity evidently decreases the probability of a radiation-less deactivation. Some organic molecules increase their fluorescence intensity on complexation with a metal ion. The resulting complex structure is more rigid than the isolated organic molecule in solution. Molecules that fluoresce can be measured directly; the number of such molecules is estimated from the published literature to be between 2000 and 3000. There are several compounds that exhibit strong fluorescence; these can be used to derivatize, complex, or "tag" nonfluorescent species, thereby extending the range of fluorescence measurements considerably. Other analytes are very efficient at quenching the fluorescence of a fluorophore; there are quantitative methods based on fluorescence quenching.

A fluorometric analysis results in the collection of two spectra, the excitation spectrum and the emission spectrum. The excitation spectrum should be the same as the absorption spectrum obtained spectrophotometrically. Differences may be seen due to instrumental factors, but these are normally small, as seen in Figure 3.51, which shows the absorption and excitation spectra for Alizarin garnet R, a fluorometric reagent for aluminum ion and fluoride ion. The longest wavelength absorption maximum in the excitation spectrum is chosen as the excitation wavelength; this is where the first monochromator is set to excite the sample. It would seem reasonable to choose the wavelength that provides the most intense fluorescence as the excitation wavelength, but often short wavelengths from the high-intensity sources used can cause a compound to decompose. The emission spectrum is collected by the second monochromator. The emission or fluorescence spectrum for Alizarin garnet R is shown in Figure 3.51. Similar excitation and emission spectra are shown in Figure 3.52 for quinine and anthracene. Note, especially for anthracene, that the fluorescence (emission) spectrum is almost a mirror image of the excitation spectrum. The shape of the emission spectrum and wavelength of the fluorescence maximum do not depend on the excitation wavelength. The same fluorescence spectrum is obtained for any wavelength the compound can absorb. However, the intensity of the fluorescence is a function of the excitation wavelength.

Fluorometry is used in the analysis of clinical samples, pharmaceuticals, natural products, and environmental samples. There are fluorescence methods for steroids, lipids, proteins, amino acids, enzymes, drugs, inorganic electrolytes, chlorophylls, natural and synthetic pigments, vitamins, and many other types of analytes. The detection limits in fluorometry are very low. Detection limits of 10^{-9} M and lower can be obtained. Single molecule detection has been demonstrated under *extremely* well controlled conditions. This makes fluorometry one of the most sensitive analytical methods available. Therefore, the technique is widely used in quantitative trace analysis. For example, Table 3.7 indicated that Al^3 + could be detected




FIGURE 3.51 Absorption and fluorescence spectra of the aluminum complex with acid alizarin garnet R (0.008 %): curve a, the absorption spectrum; curve b, the fluorescence excitation spectrum; curve c, the fluorescence emission spectrum. (From Guilbault, used with permission.)

spectrophotometrically using Aluminon at about 0.04 ppm in solution and fluoride could be detected at 0.2 ppm with SPADNS. Using fluorometry and Alizarin garnet R (Figure 3.53), Al^3+ can be determined at 0.007 ppm and F^- at 0.001 ppm. The strongly fluorescent compounds like fluorescein can be detected at part per trillion levels (ng/mL in solution), so use of such a compound as a "tag" can result in a very sensitive analytical method for many analytes.

The analysis of solid samples, especially using fiber-optic probes, has opened up new applications for fluorescence spectroscopy. Some of these include the examination of rocks and




FIGURE 3.52 Excitation and fluorescence spectra of anthracene and quinine: curve a, anthracene excitation; curve b, quinine excitation; curve c, anthracene fluorescence; curve d, quinine fluorescence. (From Guilbault, used with permission.)

HO N = N
$$= N$$
 SO₃Na **FIGURE 3.53** Structure of alizarin garnet R.

minerals to identify the presence of oil in shale, evaluation of gemstone quality and origin and the identification of minerals at potential mining sites. Materials characterization of solar cell materials, semiconductors, organic LEDs, and polymers by fluorescence is another emerging area of study. Solid samples give much sharper fluorescence peaks than liquid samples due to the elimination of nonradiative relaxation paths. Therefore, high-resolution spectrometers are needed. Solar cell researchers need the ability to adjust the position of the sample in the excitation beam to mimic the movement of the sun and fiber optic probes eliminate the need to cut up large samples to fit into sample compartments. For example, stalactites often fluoresce due to the presence of humic and fulvic acids that precipitate along with the calcite. Use of a fiber optic probe allows for non-destructive analysis of such samples in order to understand the environmental conditions under which they formed (McGarry and Baker).

Many materials benefit from analysis at cryogenic temperatures. At 77K, enhanced fluorescence and phosphorescence are seen, and low temperature studies are used for elucidation of the mechanisms of photochemical reactions, characterizing band gap changes in semiconductors and other applications.

An interesting application of the use of chemiluminescence is the measurement of a ruthenium complex upon reaction with codeine (Purcell and Barnett). A 1mM solution of tris(2,2'-bipyridyl)ruthenium(II) in 0.05 M $\rm H_2SO_4$ was oxidized to the 3+ state, then mixed with 1mM codeine. The codeine is oxidized and the Ru reduced to the 2+ state, producing an excited state intermediate which returns to the ground state by emission of a photon centered at about 610 nm. In this case the excited state is produced by a chemical reaction; the emission of light is due to chemiluminescence. No light source was required for excitation. The same $\rm Ru^2+$ complex can also be excited using an external light source; the same emission spectrum results, but this would be due to phosphorescence (Girardi et al.)

3.7.1 ADVANTAGES OF FLUORESCENCE AND PHOSPHORESCENCE

The advantages of fluorescence and phosphorescence for analyses of molecules include extremely high sensitivity, high specificity, and a large linear dynamic range. The sensitivity is a result of the direct measurement of the fluorescence or phosphorescence signal against a zero-background signal, as described. Specificity is a result of two factors: first, not all molecules fluoresce; therefore, many molecules are eliminated from consideration; and second, two wavelengths, excitation and emission, are used in fluorometry instead of one in spectrophotometry. It is not likely that two different compounds will emit at the same wavelength, even if they absorb the same wavelength and vice versa. If the fluorescing compounds have more than one excitation or fluorescent wavelength, the difference in either the emission spectrum or the excitation spectrum can be used to measure mixtures of compounds in the same solution. In Figure 3.52, for example, the excitation spectra of quinine and anthracene overlap, but they do not emit at the same wavelengths, so the two compounds could be measured in a mixture. The linear dynamic range in fluorometry is six to seven orders of magnitude, better than for spectrophotometry.

3.7.2 DISADVANTAGES OF FLUORESCENCE AND PHOSPHORESCENCE

Other compounds that fluoresce may need to be removed from the system if the spectra overlap. This can be done, for example, by column chromatography. Peaks may appear in the

fluorescence spectrum due to other emission and scattering processes. Rayleigh, Tyndall, and Raman scattering may be seen because of the high intensity of the light source used. Peaks due to fluorescent impurities may occur.

Reversal of fluorescence intensity or self-quenching at high concentrations is a problem in quantitative analysis but can be eliminated by successive dilutions. Quenching by impurities can also occur and can cause significant problems in analysis. Changes in pH can frequently change structure, as we saw with phenolphthalein, and thereby change fluorescence intensity; pH must therefore be controlled. Temperature and viscosity need to be controlled as well for reproducible results.

Photochemical decomposition or photochemical reaction may be induced by the intense light sources used. In general, the approach of using the longest excitation wavelength possible and the shortest measurement time possible will minimize this problem.

SUGGESTED EXPERIMENTS

- 3.1 Add a drop of toluene to a UV absorption cell and cap or seal the cell. Record the absorption spectrum of toluene vapor over the UV range (220–280 nm) several times, varying the slit widths but keeping the scan speed constant. For example, slit widths of 0.1, 0.5, 1, and 5 nm can be used. Explain what happens to the spectral resolution as the slit width is changed.
- 3.2 Record the absorption spectrum of a solution of pure octane. Record the absorption spectrum of a 0.02 % v/v toluene in octane solution from 220 to 280 nm. For a double-beam spectrometer, pure octane can be put into the reference cell. Compare with Experiment 3.1. Explain your observations. Change the slit width as in Experiment 3.1 and observe what happens to the resolution.
- 3.3 Record the absorption spectrum between 400 and 200 nm of (a) 1-octene, (b) 1,3-butadiene, and (c) a nonconjugated diolefin (e.g., 1, 4-pentadiene). What is the effect of a conjugated system on the absorption spectrum? What does the spectrum tell you about the relative energy of the molecular orbitals in each compound?
- 3.4 Record the absorption spectrum of a polynuclear aromatic compound such as anthracene and of a quinonoid such as benzoquinone. How does the structure of the compound affect the spectrum?
- 3.5 From Experiment 3.2, choose a suitable absorbance wavelength (or wavelengths) for toluene. Based on the maximum absorbance for your 0.02 % solution, prepare a series of toluene in octane solutions of higher and lower concentrations. (For example, 0.1%, 0.05 %, 0.01 % v/v toluene in octane might be suitable.) Measure the absorbance of each solution (using octane as the reference) at your chosen wavelength.
- 3.6 Using the absorbance data obtained from Experiment 3.5, plot the relationship between the absorbance *A* and concentration *c* of toluene at each wavelength chosen. Indicate the useful analytical range for each wavelength.
- 3.7 Prepare a standard solution of quinine by dissolving a suitable quantity of quinine in water. Record the UV absorption spectrum of the solution between 500 and 200 nm. Record the absorption spectra of several commercial brands of quinine water (after allowing the bubbling to subside). Which brand contained the most quinine? (Tonic water contains quinine.)
- 3.8 Prepare ammonium acetate buffer by dissolving 250 g of ammonium acetate in 150 mL of deionized water and then adding 700 mL of glacial acetic acid. Prepare a 1,10-phenanthroline solution by dissolving 100 mg 1,10-phenanthroline monohydrate in 100 mL deionized water to which two drops of conc. HCl have been added. 1 mL of this reagent will react with no more than 100 μ g of ferrous ion, Fe²+. Prepare a stock ferrous iron solution containing 1 g/L of ferrous sulfate. By taking aliquots of the stock solution and diluting, prepare four standard solutions and a blank in 100 mL volumetric flasks as follows: Pipet 0, 100, 200, 300, and 400 μ g of Fe²+ into 100 mL flasks, then add 2 mL conc. HCl to each flask. Add 10 mL of ammonium acetate buffer solution and 4 mL of 1,10-phenanthroline solution. Dilute to the mark with deionized water. Mix completely and allow to stand for 15 min for color development. Measure

the absorbance at 510 nm. Correlate the absorbance with the concentration of iron in the solutions (remember to subtract the blank) and prepare a calibration curve. *Note*: all reagents used should be low in iron or trace metal grade. The use of this method for determining total iron, ferric iron, and ferrous iron in water may be found in Standard Methods for the Examination of Water and Wastewater. Sample preparation is required for real water samples, as the reagent only reacts with ferrous ion.

3.9 Prepare a concentrated stock solution of acetaminophen by dissolving 20 mg, accurately weighed, of dried acetaminophen in 2 mL methanol. Bring this solution to a total volume of 100 mL with deionized (DI) water in a volumetric flask. Dilute 3 mL of the stock standard to 100 mL with DI water in a second flask to prepare the working standard. Make a test sample of acetaminophen in exactly the same way. Measure the absorbance of the working standard and the test sample at 244 nm, using a 1 cm quartz cuvette. Measure the absorbance of the DI water as a blank and subtract as needed.

Quantity of acetaminophen in the test sample = standard sample wt(mg)X(Abs₂₄₄ test sample / Abs₂₄₄ standard)

% purity = $100 \,\mathrm{X}$ (calculated wt of test sample) / actual weight of test sample)

The nasal spray Dristan® used to contain L-phenylephrine (PEH) and chlorpheniramine maleate (PAM). (Current formulation may differ; in that case, your instructor can make up a 'synthetic unknown' mixture of the two.) Prepare the following solutions: 1 L of 0.10 M HCl; 1 L PEH stock solution containing 200 (+/- 10) mg of PEH in 0.010 M HCl and record the actual concentration; 1 L PAM stock solution containing 80 (+/- 5) mg PAM in 0.010 M HCl and record the concentration. Record the UV spectrum of each stock solution from 230-300 nm. Chose the best wavelength for PEH and the best wavelength for PAM. Using the PEH stock solution and 10 mL volumetric flasks, make up 6 standard solutions covering the Abs range from 0-1 by diluting your stock solution. Each solution should be 0.010 M in HCl. So what is your blank? Record the concentration of each standard solution. Do the same for your PAM stock solution. Record absorbance measurements on all solutions (blank and 6 standards for each compound) at the two wavelengths you have chosen. Use a graphing program (or graph paper) to obtain Beer's Law plots for PEH and PAM at both wavelengths. Are they linear? Using a least squares program, obtain the slopes, intercepts, and correlation coefficients for the Beer's Law plots. Next, prepare three solutions containing both PEH and PAM. Record the absorbance at both wavelengths. Are the absorbance values additive? If you have the nasal spray product, dilute it 1 in 200 using 0.010 M HCl by weighing 0.5 g Dristan on an analytical balance. The easiest way to do this is to squirt the spray into a tared 10 mL beaker on the balance. Pour the sample into a 100 mL volumetric and then rinse the beaker multiple times with 0.010 M HCl, adding the washings to the volumetric and making it up to the mark. This should be done in triplicate. Record the absorbance of the three samples at the two wavelengths. Set up and solve the simultaneous equations. Calculate the average %PEH and PAM in Dristan from the diluted samples. Determine the standard deviation. Report results to the correct number of significant figures. (The experiment is courtesy of Prof. T. C. Werner, Dept. of Chemistry, Union College, Schenectady, NY.)

PROBLEMS

- 3.1 What types of molecules are excited by UV radiation? Why?
- 3.2 Indicate which of the following molecules absorb UV radiation and explain why: (a) heptane, (b) benzene, (c) 1,3-butadiene, (d) water, (e) 1-heptene, (f) 1-chlorohexane, (g) ethanol, (h) ammonia, and (i) *n*-butylamine.
- 3.3 Draw a schematic diagram of a double-beam spectrophotometer. Briefly explain the function of each major component.

- 3.4 List the principal light sources used in UV/VIS spectrometry.
- Radiation with a wavelength of 640 nm is dispersed by a simple grating monochromator at an angle of 20°. What are the other wavelengths of radiation that are dispersed at the same angle by this grating (lowest wavelength 200 nm)?
- 3.6 Explain the operating principle of the photomultiplier tube.
- 3.7 What are the limitations of UV absorption spectroscopy as a tool for qualitative analysis?
- 3.8 a. Plot a calibration curve for the determination of monochlorobenzene from the data listed below.
 - b. Three samples of monochlorobenzene were brought in for analysis. The samples transmitted (1) 90 %, (2) 85 %, and (3) 80 % of the light under the conditions of the calibration curve just prepared. What was the concentration of monochlorobenzene in each sample?

Absorbance
0.24
0.50
0.71
0.97
1.38
1.82

3.9 Several samples of monochlorobenzene were brought to the laboratory for analysis using the calibration curve in Problem 5.8. The absorbance of each sample is listed below.

Sample	Absorbance
A	0.400
В	0.685
C	0.120
D	0.160
Е	3.0

- a. What are the respective concentrations of monochlorobenzene in samples A–D?
- b. What is the problem with Sample E? How could the analysis of sample E be obtained?
- 3.10 Which of the following absorb in the UV region? (a) N_2 , (b) O_2 , (c) O_3 , (d) CO_2 , (e) CH_4 , (f) C_2H_4 , (g) I_2 , (h) CI_2 , (i) Cyclohexane, and (j) C_3H_6 .
- 3.11 Why does phenolphthalein change color when going from an acid to a basic solution?
- 3.12 Why do UV absorption spectra appear as broad bands?
- 3.13 Why do D_2 lamps emit a continuum and not line spectra?
- 3.14 How does a pn diode work?
- 3.15 Describe a diode array.
- 3.16 Describe the processes of UV molecular fluorescence and phosphorescence.
- 3.17 What is the relationship between fluorescence and excitation light intensity *I*₀?
- 3.18 Explain the reversal of fluorescence intensity with increase in analyte concentration. How is this source of error corrected?
- 3.19 Draw a schematic diagram of the instrumentation used for measuring UV fluorescence intensity.
- 3.20 a. What interferences are encountered in UV fluorescence?
 - b. Why is phosphorescence not used as extensively as fluorescence for analytical measurements?

- 3.21 From the emission spectra of quinine and anthracene (Figure 3.52), pick a wavelength that will permit you to determine quinine in a mixture of quinine and anthracene. Do the same for anthracene. Can you use the excitation spectra to distinguish between the two compounds? Explain.
- 3.22 If a solution appears blue when a white light is passed through it, what color(s) has the solution absorbed?
- 3.23 State Beer's Law. What conditions must be met for Beer's Law to apply? Complete the following table:

Absorption (%)	Т	Α	Concentration (ppm)
1			1
13			6
30			15
55			34
80			69
	1 13 30 55	1 13 30 55	1 13 30 55


3.24 Assuming the data obtained in Problem 3.23 were for a calibration curve and the same cell was used for all measurements, complete the following table:

Solution	Absorption (%)	T	Concentration (ppm)
А	30		
В	3		
C	10		
D	50		
Е	70		

What is the relationship between the absorption cell length b and the absorbance A? Complete the following table (the concentration c was equal in all cases):

Sample	Path length b (cm)	Α
1	0.1	0.01
2	0.5	
3	1.0	
4	2.0	
5	5.0	


- 3.26 Name three reagents used for quantitative UV/VIS spectrometric analysis and the elements they are used to determine.
- 3.27 Name two fluorometric reagents. What are the structural characteristics that make a molecule fluoresce?
- 3.28 Below are the absorption spectra of naphthalene and anthracene (from Jaffé and Orchin, with permission). Their structures are shown on the spectra. These molecules are polycyclic aromatic hydrocarbons, formed by fusing together benzene rings.



(a) Tabulate the wavelengths for the absorption maxima for these two compounds and in the spectrum of benzene (Figure 3.12 in the text). What trend do you observe? (b) What transition is causing the peaks observed in these compounds? (c) Explain the trend you observe in the absorption maxima. (d) The next larger molecule in this family is naphthacene, a four-ring compound, with the structure shown here:

Predict where the absorption maxima will occur for naphthacene. Explain your prediction.

3.29 The UV/VIS absorption spectrum shown here is the spectrum of holmium oxide glass (from Starna Cells, Inc., www.starna.com, with permission). It is a rare earth oxide glass and is available in high purity.



(a) Qualitatively, what differences do you see between this spectrum and the spectrum of an organic molecule such as pyridine (Figure 3.1a)? Why do you think they are different in appearance? (b) Consider the spectrum. Think of how you might use holmium oxide to check on the operation of your UV/VIS spectrometer. What could you check?

BIBLIOGRAPHY

Agilent Technologies, Fundamentals of Modern UV-Visible Spectroscopy, Publication Number 5980-1397E and the companion Fundamentals of Modern UV-Visible Spectroscopy Workbook, Publication 5980-1398E, Agilent Technologies, 2000 (Both publications may be accessed as pdf files at www.chem.agilent.com).

Bain, G. Wine Color Analysis using the Evolution Array UV/VISible Spectrophotometer, Thermo Fisher Scientific Application Note 51852, www.thermoscientific.com © 2013 Thermo Fisher Scientific, Inc.

Boltz, D.F., Ed. *Colorimetric Determination of Nonmetals*; Interscience Publishers: New York, 1958. Bradford, M.M. *Anal. Biochem.* **1976**, 72, 248.

Brown, C. Analytical Instrumentation Handbook, 2nd Ed.; Ewing, G.W., Ed.; Marcel Dekker, Inc.: New York, 1997.

Bruno, T.J.; Svoronos, P.D.N. CRC Handbook of Basic Tables for Chemical Analysis – Data Driven Methods and Interpretation; CRC Press: Boca Raton, FL, 2021.

Burgess, C.; Knowles, A., Eds. *Techniques in Visible and Ultraviolet Spectrometry*; Chapman and Hall: Londo, 1981.

Callister, W.D. Jr. *Materials Science and Engineering: An Introduction*, 5th; John Wiley and Sons: New York, 2000.

Chang, R. Essential Chemistry, 2nd; McGraw-Hill Companies, Inc: New York, 2000.

Claverie, M.; Johnson, J.E. The Determination of Extra Virgin Olive Oil from other Oils by Visible Spectroscopy. White Paper, © Microspectral Analysis, LLC, 2011. www.microspectralanalysis.com.

Creswell, C.J.; Runquist, O. Spectral Analysis of Organic Compounds; Burgess: Minneapolis, MN, 1970.

Dean, J.A. Analytical Chemistry Handbook; McGraw-Hill, Inc.: New York, 1995.

Dulski, T.R. A Manual for the Chemical Analysis of Metals; American Society for Testing and Materials: West Conshohocken, PA, 1996.

Ewing, G.W., Ed. Analytical Instrumentation Handbook, 2nd; Marcel Dekker, Inc: New York, 1997.

Froelich, P.M.; Guilbault, G.G. In *Practical Fluorescence*, 2nd Ed.; Guilbault, G.G., Ed.; Marcel Dekker, Inc.: New York, 1990.

Gerardi, D.; Barnett, N.W.; Lewis, S.W. Anal. Chim. Acta, 1999, 378, 1.

Guilbault, G.G., Ed. Practical Fluorescence, 2nd; Marcel Dekker, Inc: New York, 1990.

Handbook, 61st; CRC Press: Boca Raton, FL, 1980.

Hanson, E.K.; Ballantyne, J. PLoS One 2010, 5 (9), e12830. www.plosone.org.

Hollas, J.M. Modern Spectroscopy, 3rd; John Wiley and Sons, Ltd: England, 1996.

Huber, L.; George, S.A., Eds. *Diode Array Detection in HPLC*; Marcel Dekker, Inc.: New York, 1993.

Ingle, J.D. Jr.; Crouch, S.R. Spectrochemical Analysis; Prentice-Hall, Inc.: Englewood Cliffs, NJ, 1988.

Jaffé, H.H.; Orchin, M. *Theory and Applications of Ultraviolet Spectroscopy*; John Wiley and Sons: New York, 1962.

Johnson, J.E.; Claverie, M.; Wooton, D. The Color and Turbidity of Beer. White Paper, © Microspectral Analysis, LLC, 2011. www.microspectralanalysis.com.

Keppy, N.K.; Allen, M.W. The Determination of HMF in Honey with an Evolution Array UV/VISible Spectrophotometer, Thermo Fisher Scientific Application Note 51864, www.thermoscientific.com © 2013 Thermo Fisher Scientific, Inc.

Lambert, J.B.; Shurvell, H.F.; Lightner, D.; Cooks, R.G. *Introduction to Organic Spectroscopy*; Macmillan Publishing Company: New York, 1987.

Lowry, O.H. et al. J. Biol. Chem. 1951, 193, 265.

McGarry, S.F.; Baker, A. Quat. Sci. Rev., 2000, 19, 1087.

Meehan, E.J. Optical methods of analysis. In *Treatise on Analytical Chemistry*; Elving, P.J.; Meehan, E.; Kolthoff, I.M., Eds.; John Wiley and Sons: New York, 1981, Vol. 7.

Owen, A. Tutorial on UV/VISible Spectroscopy, www.chem.agilent.com. ©Agilent Technologies 2013 Pavia, D.L.; Lampman, G.M.; Kriz, G.S. Introduction to Spectroscopy: A Guide for Students of Organic Chemistry, 3rd; Harcourt College Publishers: Fort Worth, 2001.

Pisez, M.; Bartos, J. Colorimetric and Fluorometric Analysis of Organic Compounds and Drugs; Marcel Dekker, Inc.: New York, 1974.

Purcell, S.; Barnett, N. Using the Agilent Cary Eclipse to measure the chemicluminescence of a ruthenium complex. Application Note, www.chem.agilent.com.

Robinson, J.W.; Skelly Frame, E.M.; Frame, G.M. *Undergraduate Instrumental Analysis*, ^{7th}; CRC Press: Boca Raton, Fl, 2014.

Sandell, E.B.; Onishi, H. *Colorimetric Determination of Traces of Metals*, 4th; Interscience: New York, 1978.

Settle, F.A., Ed. *Handbook of Instrumental Techniques for Analytical Chemistry*; Prentice Hall, Inc.: Upper Saddle River, NJ, 1997.

Schaffer, J.P.; Saxena, A.; Antolovich, S.D.; Sanders, T.H. Jr.; Warner, S.B. *The Science and Design of Engineering Materials*, 2nd; WCB/McGraw-Hill: Boston, MA, 1999.

Scott, A.I. Interpretation of the Ultraviolet Spectra of Natural Products; Pergamon: Oxford, 1964. Shackelford, J.F. Introduction to Materials Science for Engineers, 4th; Prentice Hall, Inc. Upper Saddle River, NJ, 1996.

Silverstein, R.M.; Bassler, G.C.; Morrill, T.C. Spectrometric Identification of Organic Compounds, 5th Ed.; John Wiley and Sons: New York, 1991. [Note: The most recent edition of this text (Silverstein, R.M.: Webster, F.X., 6th ed., John Wiley and Sons: New York, 1998) has eliminated entirely the topic of UV spectroscopy.]

Smith, P.K. et al. Anal. Biochem. 1985, 150, 76.

Standard, 18th; American Public Health Association: Washington, DC, 1992.

United States Pharmacopeia and National Formulary, Rockville, MD 2006

White, J.W. Journal of the Association of Official Analytical Chemists 1979, 62 (3), 509-514.

Zumdahl, S.S.; Zumdahl, S.A. Chemistry, 5th; Houghton Mifflin Co: Boston, MA, 2000.

Infrared, Near-Infrared, and Raman Spectroscopy

4

Infrared (IR) radiation was first discovered in 1800 by Sir William Herschel, who used a glass prism with blackened thermometers as detectors to measure the heating effect of sunlight within and beyond the boundaries of the visible spectrum. Coblentz laid the groundwork for IR spectroscopy with a systematic study of organic and inorganic absorption spectra. Experimental difficulties were immense. Since each point in the spectrum had to be measured separately, it could take 4 hours to record the full spectrum. But from this work came the realization that each compound had its own unique IR absorption pattern and that certain functional groups absorbed at about the same wavelength even in different molecules. The IR absorption spectrum provides a "fingerprint" of a molecule with covalent bonds. This can be used to identify the molecule. Qualitative identification of organic and inorganic compounds is a primary use of IR spectroscopy. In addition, the spectrum provides a quick way to check for the presence of a given functional group such as a carbonyl group in a molecule. IR spectroscopy and spectrometry as used by analytical and organic chemists is primarily absorption spectroscopy. IR absorption can also be used to provide quantitative measurements of compounds.

IR spectroscopy became widely used after the development of commercial spectrometers in the 1940s. Double-beam monochromator instruments were developed, better detectors were designed, and better dispersion elements, including gratings, were incorporated. These conventional spectrometer systems have been replaced by FTIR instrumentation. This chapter will focus on FTIR instrumentation and applications of IR spectroscopy. In addition, the related techniques of near-IR (NIR) spectroscopy and Raman spectroscopy will be covered, as well as the use of IR and Raman microscopy.

The wavelengths of IR radiation of interest to chemists trying to identify or study organic molecules fall between 2 and 20 μm . These wavelengths are longer than those in the red end of the visible region, which is generally considered to end at about 0.75 μm . IR radiation therefore is of lower energy than visible radiation, but of higher energy than radiowaves. The entire IR region can be divided into the *near-IR*, from 0.75 to 2.5 μm , the *mid-IR*, from about 2.5 to 20 μm , and the *far-IR*, from 20 to 200 μm . Visible radiation (red light) marks the upper energy end or minimum wavelength end of the IR region; the maximum wavelength end is defined somewhat arbitrarily; some texts consider the far-IR to extend to 1000 μm . The IR wavelength range tells us the IR frequency range from the equation (introduced in Chapter 2)

$$v = \frac{c}{\lambda}$$

where v is the frequency, c is the speed of light, and λ is the wavelength. We also know that $\Delta E = hv$. When the frequency is high, λ is short and the energy of the radiation is high.

It is common to use *wavenumber*, symbolized by either \tilde{v} or \overline{v} , with units of cm⁻¹, in describing IR spectra. The first symbol is called "nu tilde"; the second symbol is called "nu bar"; both symbols are used in the literature. The unit cm⁻¹ is called a *reciprocal centimeter*. The wavenumber is the reciprocal of the wavelength. Wavenumber is the number of waves of radiation per centimeter, $1/\lambda$; frequency is the number of waves per second, c/λ . Wavelength and wavenumber are related by:

(4.2) wavelength (
$$\mu$$
m)× wavenumber (cm⁻¹)=10,000 = 1×10⁴

Both wavenumbers and wavelengths will be used throughout the chapter, so it is important to be able to convert between these units. Old IR literature used the term *micron* and the symbol μ for wavelength in micrometers (μ m).

4.1 ABSORPTION OF IR RADIATION BY MOLECULES

Molecules with covalent bonds may absorb IR radiation. This absorption is quantized, so only certain frequencies of IR radiation are absorbed. When radiation, (i.e., energy) is absorbed, the molecule moves to a higher energy state. The energy associated with IR radiation is sufficient to cause molecules to rotate (if possible) and to vibrate. If the IR wavelengths are longer than 100 µm, absorption will cause excitation to higher rotational states in the gas phase. If the wavelengths absorbed are between 1 and 100 µm, the molecule will be excited to higher vibrational states. Because the energy required to cause a change in rotational level is small compared to the energy required to cause a vibrational level change, each vibrational change has multiple rotational changes associated with it. Gas phase IR spectra therefore consist of a series of discrete lines. Free rotation does not occur in condensed phases. Instead of a narrow line spectrum of individual vibrational absorption lines, the IR absorption spectrum for a liquid or solid is composed of broad vibrational absorption **bands**. A typical IR spectrum for a condensed phase (liquid or solid) is shown in Figure 4.1. This is the spectrum of a thin film of polystyrene; note that the absorption band at about 2950 cm⁻¹ is more than 100 cm⁻¹ wide at the top. The individual vibration-rotation lines can be seen in gas phase IR spectra. These narrow lines are clearly seen in Figure 4.2, the gas phase spectrum of hydrogen chloride, HCl.

Molecules absorb radiation when a bond in the molecule vibrates at the same frequency as the incident radiant energy. After absorbing radiation, the molecules have more energy and vibrate at increased amplitude. The frequency absorbed depends on the masses of the atoms in the bond, the geometry of the molecule, the strength of the bond, and several other factors. Not all molecules can absorb IR radiation. The molecule must have a change in **dipole moment** during vibration in order to absorb IR radiation.

4.1.1 DIPOLE MOMENTS IN MOLECULES

When two atoms with different electronegativities form a bond, the electron density in the bond is not equally distributed. For example, in the molecule hydrogen fluoride, HF, the electron density in the bond shifts away from the H atom toward the more electronegative




FIGURE 4.1 Fourier transform IR spectrum of a thin film of polystyrene. The *y* axis unit is %T, the *x* axis is in wavenumbers (cm⁻¹). Collected on a ThermoScientific 6700 FTIR spectrometer with a DTGS detector. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)




FIGURE 4.2 Vapor-phase FTIR spectrum of hydrogen chloride, HCl. Spectrum was collected in a 10 cm gas cell with NaCl windows on a paragon 1000 FTIR spectrometer. (©2020 PerkinElmer, inc. All rights reserved. Printed with permission.)

fluorine atom. This results in a partial negative charge on F and a partial positive charge on H. The bond is said to be **polar** when such charge separation exists. The charge separation can be shown as

$$\overset{\delta^+}{H} \overset{\delta^-}{F}$$

where δ indicates a partial charge. The dipole in the bond is indicated by a crossed arrow placed with the point on the more negative end of the bond as shown:




The HF molecule is a linear diatomic molecule with one polar bond; therefore, the molecule is polar and has a dipole moment. The dipole moment μ is the product of the charge Q and the distance between the charges, r:

$$\mu = Q \times r$$

The partial positive and negative charges in HF must be equal in magnitude but opposite in sign to maintain electrical neutrality. We can imagine that the HF molecule vibrates by having the bond stretch and compress over and over, just as a spring can be stretched and compressed by first pulling and then squeezing the spring. On vibration of the HF bond, the dipole moment changes because the distance between the charges changes. Because the dipole moment changes in a repetitive manner as the molecule vibrates, it is possible for HF to absorb IR radiation. It follows that diatomic molecules containing atoms of the same element such as H_2 , N_2 , O_2 , and Cl_2 have no charge separation because the electronegativity of each atom in the bond is the same. Therefore, they do not have dipole moments. Since a change in dipole moment with time is necessary for a molecule to absorb IR radiation, symmetrical diatomic molecules do not absorb IR radiation. Diatomic molecules made up of different atoms such as HCl and CO do have dipole moments. They would be expected to absorb IR radiation or to be "IR-active".

Molecules with more than two atoms may or may not have permanent dipole moments. It depends on the geometry of the molecule. Carbon dioxide has two equal C=O bond dipoles but because the molecule is linear the bond dipoles cancel and the molecule has no net dipole moment:

Water, H_2O , has two equal H—O bond dipoles. Water has a bent geometry and the vector sum of the bond dipoles does not cancel. The water molecule has a permanent net dipole moment.



Bond dipoles in water Net dipole in water

Predicting the IR absorption behavior of molecules with more than two atoms is not as simple as looking at diatomic molecules. It is not the net dipole moment of the molecule that is important, but any change in the dipole moment on vibration. We need to understand how molecules vibrate. This is relatively simple for diatomic and triatomic molecules. Large molecules cannot be evaluated simply, because of their large number of vibrations and interactions between vibrating atoms. It can be said that most molecules do absorb IR radiation, which is the reason this technique is so useful.

4.1.2 TYPES OF VIBRATIONS IN MOLECULES

The common molecular vibrations that are excited by IR radiation are **stretching** vibrations and bending vibrations. These are called modes of vibration. Stretching involves a change in bond lengths resulting in a change in interatomic distance. Bending involves a change in bond angle or a change in the position of a group of atoms with respect to the rest of the molecule. For a group of three or more atoms, at least two of which are the same type of atom, there are two stretching modes: symmetrical stretching and asymmetrical stretching. These two modes of stretching are shown, respectively, in Figure 4.3 for a CH₂ group. In Figure 4.3(a), the two H atoms both move away from the C atom—a symmetrical stretch. In Figure 4.3(b), one H atom moves away from the C atom and one moves toward the C atom—an asymmetrical stretch. Bending modes are shown in Figure 4.3(c)-(f). Scissoring and rocking are in-plane bending modes—the H atoms remain in the same plane as the C atom (i.e., in the plane of the page). Wagging and twisting are out-of-plane (oop) bending modes—the H atoms are moving out of the plane containing the C atom. The + sign in the circle indicates movement above the plane of the page toward the reader, while the – sign in the circle indicates movement below the plane of the page away from the reader. Bends are also called deformations and the term antisymmetric is used in place of asymmetric in various texts.

For the CO_2 molecule, we can draw a symmetric stretch, an asymmetric stretch, and a bending vibration, as shown:

The CO₂ molecule on the left is undergoing a symmetric stretch, the one in the middle an asymmetric stretch and the one on the right an in-plane bend. The symmetric stretching




FIGURE 4.3 Principal modes of vibration between carbon and hydrogen in an alkane: **(a)** symmetrical stretching, **(b)** asymmetrical stretching and the bending vibrations, **(c)** scissoring, **(d)** rocking, **(e)** wagging, and **(f)** twisting.

vibration does *not* change the dipole moment of the molecule. This vibrational mode does not absorb IR radiation—it is said to be *IR-inactive*. However, the other two modes of vibration do change the dipole moment—they are *IR-active*. The asymmetric stretching frequency occurs at 2350 cm⁻¹ and the bending vibration occurs at 666 cm⁻¹.

For diatomic and triatomic molecules, it is possible to work out the number and kind of vibrations that occur. To locate a point in three-dimensional space requires three coordinates. To locate a molecule containing N atoms in three dimensions, 3N coordinates are required. The molecule is said to have 3N degrees of freedom. To describe the motion of such a molecule, translational, rotational, and vibrational motions must be considered. Three coordinates or degrees of freedom are required to describe translational motion and three degrees of freedom are required to describe rotational motion about the molecule's center of gravity. This leaves 3N-6 degrees of freedom to describe vibrational motion. There are 3N-6 possible normal modes of vibration in a molecule of N atoms. For example, the water molecule contains 3 atoms, so it has $3 \times 3 = 9$ degrees of freedom and $(3 \times 3) - 6 = 3$ normal modes of vibration. For the water molecule, these normal modes of vibration are a symmetric stretch, an asymmetric stretch, and a scissoring (bending) mode. Linear molecules cannot rotate about the bond axis. As a result, only two degrees of freedom are needed to describe rotation, so linear molecules have 3N-5 normal modes of vibration. If we look at CO₂ above, three modes of vibration are shown, but 3N - 5 = 4 normal modes of vibration, so one is missing. The fourth is a bending mode equivalent to that shown, but oop:

$$\overset{+}{O} = \overline{C} = \overset{+}{O}$$

where + indicates movement toward the reader and – indicates movement away from the reader. The oop bending mode and the in-plane bending mode already shown both occur at 666 cm⁻¹. They are said to be *degenerate*. Both are IR-active, but only one absorption band is seen since they both occur at the same frequency.

For simple molecules, this approach predicts the number of fundamental vibrations that exist. Use of the dipole moment rule indicates which vibrations are IR-active, but the IR spectrum of a molecule rarely shows the number of absorption bands calculated. Fewer peaks than expected are seen due to IR-inactive vibrations, degenerate vibrations, and very weak vibrations. More often, additional peaks are seen in the spectrum due to overtones and other bands.

The excitation from the ground state V_0 to the first excited state V_1 is called the *fundamental transition*. It is the most likely transition to occur. Fundamental absorption bands are

strong compared with other bands that may appear in the spectrum due to overtone, combination, and difference bands. *Overtone* bands result from excitation from the ground state to higher energy states V_2 , V_3 , and so on. These absorptions occur at approximately integral multiples of the frequency of the fundamental absorption. If the fundamental absorption occurs at frequency v, the overtones will appear at about 2v, 3v, and so on. Overtones are weak bands and may not be observed under real experimental conditions. Vibrating atoms may interact with each other. The interaction between vibrational modes is called *coupling*. Two vibrational frequencies may couple to produce a new frequency $v_3 = v_1 + v_2$. The band at v_3 is called a *combination* band. If two frequencies couple such that $v_3 = v_1 - v_2$, the band is called a *difference* band. Not all possible combinations and differences occur; the rules for predicting coupling are beyond the scope of this text.

The requirements for the absorption of IR radiation by molecules can be summarized as follows:

- 1. The natural frequency of vibration of the molecule must equal the frequency of the incident radiation.
- 2. The frequency of the radiation must satisfy $\Delta E = hv$, where ΔE is the energy difference between the vibrational states involved.
- 3. The vibration must cause a change in the dipole moment of the molecule.
- 4. The amount of radiation absorbed is proportional to the square of the rate of change of the dipole during the vibration.
- 5. The energy difference between the vibrational energy levels is modified by coupling to rotational energy levels and coupling between vibrations.

4.1.3 VIBRATIONAL MOTION

A molecule is made up of two or more atoms joined by chemical bonds. Such atoms vibrate about each other. A simple model of vibration in a molecule can be made by considering the bond to be a spring with a weight on each end of the spring (Figure 4.4). The stretching of such a spring along its axis in a regular fashion results in simple harmonic motion. Hooke's Law states that two masses joined by a spring will vibrate such that:

$$v = \frac{1}{2\pi} \sqrt{\frac{f}{\mu}}$$

(a)

where ν is the frequency of vibration; f, the force constant of the spring (a measure of the stiffness of the spring); and μ , the reduced mass. The reduced mass is calculated from the masses of the two weights joined by the spring.

$$\mu = \frac{M_1 M_2}{M_1 + M_2}$$

$$H \longrightarrow C \longrightarrow H \qquad M_2 \bigcirc 00000 \bigcirc M_2$$

$$M_1 \longrightarrow M_2 \bigcirc 00000 \bigcirc M_2$$

FIGURE 4.4 (a) The atoms and chemical bonds in methane, CH₄, presented as (b) a system of masses and springs.

(b)

TABLE 4.1 Average Values for Bond Force Constant

Bond Order	Average Force Constant f (N/m)
1 (single bond)	500
2 (double bond)	1000
3 (triple bond)	1500

^a N/m is the SI unit; dyn/cm is the cgs unit. The single bond force constant in dyn/cm is about 5×10^5 .

where M_1 is the mass of one vibrating body and M_2 the mass of the other. From Equation (4.4), it can be seen that the natural frequency of vibration of the harmonic oscillator depends on the force constant of the spring and the masses attached to it, but is independent of the amount of energy absorbed. Absorption of energy changes the amplitude of vibration, not the frequency. The frequency ν is given in hertz (Hz) or cycles per second (cps). If one divides ν in cps by c, the speed of light in cm/s, the result is the number of cycles per cm. This is $\overline{\nu}$, the wavenumber:

$$\overline{\nu} = \frac{\mathbf{v}}{c}$$

Dividing both sides of Equation (4.4) by c, we get:

$$\overline{\nu} = \frac{1}{2\pi c} \sqrt{\frac{f}{\mu}}$$

where $\overline{\nu}$ is the wavenumber of the absorption maximum in cm⁻¹; c, the speed of light in cm/s; f, the force constant of the bond in dyn/cm; and µ, the reduced mass in g. The term frequency of vibration is often used when the vibration is expressed in wavenumbers, but it must be remembered that wavenumber is directly proportional to the frequency v, not identical to it. Equation (4.7) tells us the frequency of vibration of two atoms joined by a chemical bond, where the force constant f is a measure of the *strength* of the chemical bond and μ is the reduced mass of the vibrating atoms. The term f varies with bond strength; a simple but useful approximation is that a triple bond between two atoms is 3× as strong as a single bond between the same two atoms, so f would be $3\times$ as large for the triple bond. The force constant f is directly proportional to the bond order, and depends on the electronegativity of the vibrating atoms and the mean distance between them. These are all physical constants and properties of the molecule. Since f and μ are constant for any given set of atoms and chemical bonds, the frequency of vibration ν is also constant. The radiation absorbed by the system has the same frequency and is constant for a given set of atoms and chemical bonds, that is, for a given molecule. The absorption spectrum is therefore a physical property of the molecule. Average values of the force constant for single, double, and triple bonds are given in Table 4.1. Using these values of f and the masses of given atoms, it is possible to estimate the wavenumber for fundamental stretching vibrations of given bonds as discussed. Table 4.2 presents frequencies for common vibrations.

From Equation (4.7), we can deduce that a C—C bond vibrates at a lower wavenumber than a C=C bond, because the force constant for the C—C bond is smaller than that for C=C. For example, C—C vibrates at 1200 cm⁻¹ and C=C vibrates at 1650 cm⁻¹. In general, force constants for bending vibrations are lower than stretching vibrations. Resonance and hybridization in molecules also affect the force constant for a given bond.

4.2 IR INSTRUMENTATION


Until the early 1980s, most mid-IR spectrometer systems were double-beam dispersive grating spectrometers, similar in operation to the double-beam system for UV/VIS spectroscopy described in Chapter 2. These instruments have been replaced by FTIR spectrometers

TABLE 4.2 Molecular Vibrations and Approximate Absorption Frequencies in Wavenumbers (Cm⁻¹)

	olecular Vibrations					
Molecular Group	Structu	re		ching	Bend	ing
C—H bonds			C → F	1	C↓H	700 760
Methylene (alkane)	H R - C - R H		2929, 2850		1460	780–760
Methyl (alkane)	H 		2960, 2870		1450	1375
Alkene (terminal)	R-C=C		3080, 2990		1410	890
Aromatic			3050		1200	680–900
Aldehyde	R-C O		2820, 2710		1390	
Alkyne (terminal)	R—C≡CH		3300		615–680	
Nitrogen bonds	R-N H	C→N	$N \rightarrow H$		N↓H	
Primary amine		1065	3390, 3330		1610	
Secondary amine	R ₁ NH	1150, 850	3330		1610	
Tertiary amine	$\begin{array}{c} R_1 \\ R_2 \\ R_3 \end{array} N$	780				
Oxygen bonds Primary alcohol	H	O → H 3635	C ⇒ 0	C → O 1050, 850		C—O↓H1300
Secondary alcohol	R H C OH	3625		1100, 830		1300
Oxygen bonds		$O \rightarrow H$	$C \Rightarrow 0$	$C \rightarrow O$		C—O↓H
Tertiary alcohol	R_1 R_2 C	3615		1150, 780		1300
Phenol	ОН ОН	3600		1220		1360

(continued)

TABLE 4.2 (continued)



Note: A single arrow (\rightarrow) denotes a single bond stretching vibration; a double arrow (\Rightarrow) denotes a double bond stretching vibration and so on. A vertical arrow (\downarrow) denotes a bending vibration.

because of the advantages in speed, signal-to-noise ratio, and precision in determining spectral frequency that can be obtained from a modern multiplex instrument. There are NIR instruments that are part of double-beam dispersive UV/VIS/NIR systems, but many NIR instruments are stand-alone grating instruments.

The first requirement for material used in an IR spectrometer is that the material must be transparent to IR radiation. This requirement eliminates common materials such as glass and quartz for use in mid-IR instruments because glass and quartz are not transparent to IR radiation at wavelengths longer than 3.5 μ m. Second, the materials used must be strong enough to be shaped and polished for windows, samples cells, and the like. Common materials used are ionic salts, such as potassium bromide, calcium fluoride, sodium chloride (rock salt), and zinc selenide. The final choice among the compounds is determined by the wavelength range to be examined. The wavelength ranges of some materials used for IR optics and sample holders are given in Table 4.3.

The major problem with the use of NaCl, KBr, and similar ionic salts is that they are very soluble in water. Any moisture, even atmospheric moisture, can dissolve the surface of a polished salt crystal, causing the material to become opaque and scatter light. Optics and sample containers made of salts must be kept desiccated. This limitation is one of the reasons salt prisms are no longer used in dispersive IR spectrometers.

TABLE 4.3 Typical Materials Used in Mid-IR Optics

Material	Transmission Range (μm)	Solubility (g/100g Water)	Refractive Index	Comments
Sodium chloride (NaCl)	0.25–16	36	1.49	Most widely used; reasonable range and low cost
Potassium chloride (KCI)	0.30–20	35	1.46	Wider range than NaCl; used as a laser window
Potassium bromide (KBr)	0.25-26	65	1.52	Extensively used; wide spectral range
Barium fluoride (BaF ₂)	0.2–11	0.1	1.39	Extremely brittle
Cesium iodide (CsI)	0.3-60	160	1.74	Transmits to 60 μ m
Cesium bromide (CsBr)	0.3-45	125	1.66	
Thallium bromide/iodide eutectic (KRS-5)	0.6–40	<0.05	2.4	For internal reflection in the far IR when moisture is a problem
Strontium fluoride (SrF ₂)	0.13-11	1.7×10^{-3}		Resistant to thermal shock
Silver chloride (AgCl)	0.4-25	1.5×10^{-4}	2.0	Darkens under UV light
Silver bromide (AgBr)	0.5-35	1.2×10^{-5}	2.2	Darkens under UV light
Germanium	2–11	Insoluble	4.00	
Fused silica	0.2-4.5	Insoluble	1.5 at 1 μm	Most useful for NIR
Magnesium fluoride (MgF ₂)	0.5–9	Insoluble	1.34 at 5 μm	This and the next five materials are known commercially at Irtran® 1through 6
Zinc sulfide (ZnS)	0.4-14.5	Insoluble	2.2	
Calcium fluoride (CaF ₂)	0.4-11.5	Insoluble	1.3	
Zinc selenide (ZnSe)	0.5-22	Insoluble	2.4	
Magnesium oxide (MgO)	0.4-9.5	Insoluble	1.6 at 5 μm	
Cadmium telluride (CdTe)	0.9–31	Insoluble	2.7	

4.2.1 RADIATION SOURCES

A radiation source for IR spectroscopy should fulfill the requirements of an ideal radiation source, namely, that the intensity of radiation (1) be continuous over the wavelength range used, (2) cover a wide wavelength range, and (3) be constant over long periods of time. The most common sources of IR radiation for the mid-IR region are *Nernst glowers*, *Globars*, and *heated wires*. All of these heated sources emit continuous radiation, with a spectral output very similar to that of a blackbody radiation source. Spectral curves for blackbody radiators at several temperatures are shown in Figure 4.5. The normal operating temperatures for IR sources are between 1100 and 1500 K. The range of light put out by mid-IR sources extends into both the NIR and far-IR regions, but intensity is at a maximum in the mid-IR region from 4000 to 400 cm⁻¹.




FIGURE 4.5 Radiant energy distribution curves for a blackbody source operated at various temperatures. (From Coates, used with permission.)

4.2.1.1 MID-IR SOURCES

The two main types of sources for mid-IR radiation are electrically heated rigid ceramic rods and coiled wires.

The Nernst glower is a cylindrical bar composed of zirconium oxide, cerium oxide, and thorium oxide that is heated electrically to a temperature between 1500 and 2000 K. The source is generally about 20 mm long and 2 mm in diameter. The rare earth oxide ceramic is an electrical resistor; passing current through it causes it to heat and glow, giving off continuous IR radiation. The Nernst glower requires an external preheater because of the negative coefficient of electrical resistance; it only conducts at elevated temperature. In addition, the Nernst glower can easily overheat and burn out because its resistance decreases as the temperature increases. The circuitry must be designed to control the current accurately. A related source, the Opperman, consists of a bar of rare earth ceramic material with a Pt or other wire running coaxially through the center of the ceramic. Electrical current through the wire heats the wire, and that heats the ceramic, providing a source similar to the Nernst glower without the preheating requirement. The Globar is a bar of sintered silicon carbide, which is heated electrically to emit continuous IR radiation. The Globar is a more intense source than the Nernst glower. These rigid cylinders were designed so that their shape matched the shape of the slit on a classical dispersive spectrometer. Modern FTIRs do not have slits, so the geometry of the source can now be made more compact. Commercial ceramic IR sources are available in a variety of sizes and shapes, as seen in Figure 4.6. Typical spectral outputs from these commercial ceramic sources are compared with a blackbody radiator in Figure 4.7.




FIGURE 4.6 Commercial IR radiation sources. (Top) a variety of designs. Dimensions given are in inches and (mm). Courtesy of Newport corporation, Irvine, CA (www.newport.com). (Bottom) FTIR source element used in the PerkinElmer spectrum one instrument. It is made of a proprietary ceramic/metallic composite and is designed to minimize hot spots to the end of the element. Only the last 5 mm on the end lights up. (©2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.Com].)




FIGURE 4.7 Spectral output of a variety of commercial IR radiation sources, including a silicon carbide source (dashed line marked SiC) and an NIR quartz tungsten-halogen lamp (the dotted line marked QTH). A blackbody curve at 1273 K is included for comparison. (Courtesy of Newport corporation, Irvine, CA [www.newport.com].)


Electrically heated wire coils, similar in shape to incandescent light bulb filaments, have also been used successfully as a light source. Nichrome wire is commonly used, although other metals such as rhodium are used as well. These wires are heated electrically in air to a temperature of $\sim 1100\,^{\circ}$ C. The main problem with these wire coils is "sagging" and embrittlement due to ageing, resulting in fracture of the filament, exactly the way a light bulb filament "burns out". Some coiled wire sources are wound around a ceramic rod for support; this results in a more uniform light output over time than that from an unsupported coil.

Modern sources for the mid-IR region are variants of the incandescent wire source or the Globar, but generally in a compact geometry. Commercial furnace ignitors and diesel engine heaters such as the silicon carbide tipped "glo-plug" have been adapted for use as IR sources because of their robustness, low operating voltage, and low current requirements.

Sources are often surrounded by a thermally insulated enclosure to reduce noise caused by refractive index gradients between the hot air near the source and cooler air in the light path. Short-term fluctuations in spectral output are usually due to voltage fluctuations and can be overcome by use of a stabilized power supply. Long-term changes occur as result of changes in the source material due to oxidation or other high temperature reactions. These types of changes may be seen as hot or cold "spots" in the source, and usually require replacement of the source.

4.2.1.2 NIR SOURCES

As can be seen in Figure 4.5, operating a mid-IR source at higher temperatures (>2000 K) increases the intensity of NIR light from the source. Operation at very high temperatures is usually not practical, due to the excessive heat generated in the instrument and premature burn-out of the source. For work in the NIR region, a quartz halogen lamp is used as the source. A quartz halogen lamp contains a tungsten wire filament and iodine vapor sealed in a quartz envelope or bulb. In a standard tungsten filament lamp, the tungsten evaporates from the filament and deposits on the lamp wall. This process reduces the light output as a result of the black deposit on the wall and the thinner filament. The halogen gas in a tungsten-halogen lamp removes the evaporated tungsten and redeposits it on the filament, increasing the light output and source stability. The intensity of this source is very high compared to a standard tungsten filament incandescent lamp. The range of light put out by this source is from 25,000 to 2000 cm $^{-1}$. Figure 4.8 shows typical commercial quartz tungsten-halogen lamps and a plot of the spectral output of such a source.






FIGURE 4.8 (a) Commercial quartz tungsten-halogen lamps for use in the NIR region. The lamps are constructed of a doped tungsten coiled filament inside a quartz envelope. The envelope is filled with a rare gas and a small amount of halogen. (b) The spectral output of a model 6315 1000 W quartz tungsten-halogen lamp. The location and height of the peak depend on the model of lamp and the operating conditions. (Courtesy of Newport Corporation, Irvine, CA [www.newport.com].)

4.2.1.3 FAR-IR SOURCES

While some of the mid-IR sources emit light below 400 cm⁻¹, the intensity drops off. A more useful source for the far-IR region is the high-pressure mercury discharge lamp. This lamp is constructed of a quartz bulb containing elemental Hg, a small amount of inert gas, and two electrodes. When current passes through the lamp, mercury is vaporized, excited, and ionized, forming a plasma discharge at high pressure (>1 atm). In the UV and visible regions, this lamp emits atomic Hg emission lines that are very narrow and discrete, but it emits an intense continuum in the far-IR region.

4.2.1.4 IR LASER SOURCES

A laser is a light source that emits very intense monochromatic radiation. Some lasers, called tunable lasers, emit more than one wavelength of light, but each wavelength emitted is monochromatic. The combination of high intensity and narrow linewidth makes lasers ideal light sources for some applications. Two types of IR lasers are available: gas phase and solid-state. The tunable carbon dioxide laser is an example of a gas phase laser. It emits discrete lines in the 1100-900 cm⁻¹ range. Some of these lines coincide with the narrow vibrational-rotational lines of gas phase analytes. This makes the laser an excellent source for measuring gases in the atmosphere or gases in a production process. Open path environmental measurements of atmospheric hydrogen sulfide, nitrogen dioxide, chlorinated hydrocarbons, and other pollutants can be made using a carbon dioxide laser.

Tunable gas phase lasers are expensive. Less expensive solid-state diode lasers with wavelengths in the NIR are available. Commercial instruments using multiple diode lasers are available for NIR analyses of food and fuels. Because of the narrow emission lines from a laser system, laser sources are often used in dedicated applications for specific analytes. They can be ideal for process analysis and product quality control, for example, but are not as flexible in their applications as a continuous source or a tunable laser.

4.2.2 MONOCHROMATORS AND INTERFEROMETERS

The radiation emitted by the source covers a wide frequency range. However, the sample absorbs only at certain characteristic frequencies. In practice, it is important to know what these frequencies are. To obtain this information, we must be able to select radiation of any




FIGURE 4.9 Wave interactions. (Top) Constructive interference occurs when both waves are in phase. (Bottom) Destructive interference occurs when both waves are out of phase. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)


desired frequency from our source and eliminate that at other frequencies. This can be done by a *dispersive* spectrophotometer (Chapter 2). Double-beam spectrophotometers were routinely used because both CO₂ and H₂O present in air absorb IR radiation. While this type of spectrometer is still used for the NIR, especially in combined UV/VIS/NIR systems, optics for the mid-IR had to be transparent to mid-IR radiation. These optics had to be ionic salts or metal. It was estimated (Coates, 1997) that no more than 5 % of the IR spectrometers in use in 1997 were dispersive instruments and that figure has undoubtedly dropped. Therefore, the discussion of mid-IR instruments will focus on the FTIR based on a Michelson interferometer.

4.2.2.1 FT SPECTROMETERS

If two beams of light of the same wavelength are brought together in phase, the beams reinforce each other and continue down the light path. However, if the two beams are out of phase, destructive interference takes place. This interference is at a maximum when the two beams of light are 180° out of phase (Figure 4.9). Advantage is taken of this fact in the FT instrument. The FT instrument is based on a Michelson interferometer; a schematic is shown in Figure 4.10. The system consists of four optical arms, usually at right angles to each other, with a *beam splitter* at their point of intersection. Radiation passes down the first arm and is separated by a beam splitter into two perpendicular beams of approximately equal intensity. These beams pass down into other arms of the spectrometer. At the ends of these arms, the two beams are reflected by mirrors back to the beam splitter, where they recombine and are reflected together onto the detector. One of the mirrors is fixed in position; the other mirror can move toward or away from the beam splitter, changing the path length of that arm.

It is easiest to discuss what happens in the interferometer if we assume that the source is monochromatic, emitting only a single wavelength of light. If the side arm paths are equal in length there is no difference in path length. This position is shown in Figure 4.10 as the zero-path length difference (ZPD) point. For ZPD, when the two beams are recombined, they will be in phase, reinforcing each other. The maximum signal will be obtained by the detector. If the moving mirror is moved from ZPD by 1/8 of a wavelength, the total path difference on recombination is $[2 \times (1/8)\lambda]$ or $(1/4)\lambda$ and partial interference will occur. If the moving mirror is moved from ZPD by 1/4 of a wavelength, then the beams will be one-half of a wavelength out of phase with each other; that is, they will destructively interfere with each other such that a minimum signal reaches the detector. Figure 4.11 shows the signal at the detector as a function of path length difference for monochromatic light. In practice, the mirror in one arm is kept stationary and that in the second arm is moved slowly. As the moving mirror moves, the net signal falling on the detector is a cosine wave with the usual maxima and minima when plotted against the travel of the mirror. The frequency of the cosine signal is equal to:

$$(4.8) f = \frac{2}{\lambda}(\nu)$$







FIGURE 4.10 (Top) Schematic diagram of a Michelson interferometer. ZPD stands for zero path-length difference (i.e., the fixed mirror and moving mirror are equidistant from the beam splitter). (From Coates, used with permission). (Bottom) A simple commercial FTIR spectrometer layout showing the He-Ne laser, optics, the source, interferometer, sample, and detector. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

where f is the frequency; ν , the velocity of the moving mirror; and λ , the wavelength of radiation. (Note: ν is an italic "v", not the Greek letter "nu", ν).

The frequency of modulation is therefore proportional to the velocity of the mirror and inversely proportional to wavelength of the incident radiation. The frequency is therefore also proportional to the wavenumber of the incident radiation.

Real IR sources are polychromatic. Radiation of all wavelengths generated from the source travels down the arms of the interferometer. Each wavelength will generate a unique cosine wave; the signal at the detector is a result of the summation of all these cosine waves. An idealized interferogram from a polychromatic source is shown in Figure 4.12. The "centerburst" is located in the center of the interferogram because modern FTIR systems scan the moving mirror symmetrically around ZPD. The interferogram holds the spectral information from the source (or sample) in a *time domain*, a record of intensity vs. time based on the speed of the moving mirror. The spectral information about the sample is obtained from the wings of the interferogram.






FIGURE 4.11 (Top) A simplified schematic showing the generation of an interferogram from monochromatic light by displacement of the moving mirror. (Modified from Coates, used with permission). (Bottom) An enlarged view of the signal at the detector as a function of path difference between the moving and fixed mirrors for monochromatic light of wavelength λ . (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

If the unique cosine waves can be extracted from the interferogram, the contribution from each wavelength can be obtained. These individual wavelength contributions can be reconstructed to give the spectrum in the frequency domain, that is, the usual spectrum obtained from a dispersive spectrometer. A Fourier transform is used to convert the time-domain spectrum into a frequency-domain spectrum. Hence the term Fourier Transform infrared spectrometer for this type of system.

It is mechanically difficult to move the reflecting mirror at a controlled, known, steady velocity, and position variations due to temperature changes, vibrations, and other environmental effects must be corrected for. The position of the moving mirror must be known




FIGURE 4.12 An idealized interferogram. (From Coates, used with permission.)

Sampling the interferogram




FIGURE 4.13 Schematic diagram showing how the interferogram is digitized by sampling it at discrete points based on the He-Ne laser signal, shown at the bottom. Each vertical line represents a sampling point. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

accurately. The position and the velocity are controlled by using a helium-neon (He-Ne) laser beam that is directed down the light path producing an interference pattern with itself. (Note: This laser is <u>not</u> the spectrometer radiation source.) The cosine curve of the interference pattern of the laser is used to adjust the moving mirror in real time in many spectrometers. The He-Ne laser is also used to identify the points at which the interferogram is sampled for the Fourier transform, as shown schematically in Figure 4.13.

There are a number of advantages to the use of FTIR over dispersive IR. Because the sample is exposed to all source wavelengths at once, all wavelengths are measured simultaneously in less than 1 s. This is known as the *multiplex* or *Fellgett's advantage*, and it greatly increases the sensitivity and accuracy in measuring the wavelengths of absorption maxima. This multiplex advantage permits collection of many spectra from the same sample in a very short time. Many spectra can be averaged, resulting in improved signal-to-noise ratio. An FTIR is considerably more accurate and precise than a monochromator (*Connes' advantage*). Another advantage is that the intensity of the radiation falling on the detector is much greater because there are no slits; large beam apertures are used, resulting in higher energy throughput to the detector. This is called the *throughput* or *Jacquinot's advantage*. Resolution is dependent on the linear movement of the mirror. As the total distance traveled increases, the resolution improves. It is not difficult to obtain a resolution of 0.5 cm⁻¹. A comparison between FTIR and dispersive IR is given in Table 4.4.

The signal-to-noise improvement in FTIR comes about as a result of the multiplex and throughput advantages. These permit a rapid spectrum collection rate. A sample spectrum can be scanned and rescanned many times in a few seconds and the spectra added and averaged electronically. The IR signal (S) accumulated is additive, but the noise level (N) in the signal is random. The S/N ratio therefore increases with the square root of the number of scans (i.e., if 64 scans are accumulated, the S/N ratio increases 8×). FTIR has the potential to be many orders of magnitude more sensitive than dispersive IR. However, in practice, the sheer number of scans necessary to continue to improve the sensitivity limits the improvement. For example, 64 scans improve sensitivity 8×. It would require 4096 scans to increase the S/N 64-fold. A practical limit of one to two orders of magnitude sensitivity increase is therefore normal unless circumstances merit the additional time. Of course, the ability to process many spectra rapidly is a result of the improvement in computer hardware and software that has occurred over the past decade. Inexpensive powerful computers and commercially available user-friendly software allow this technology to be used in undergraduate laboratories as well as in industrial and academic research labs.

4.2.2.2 INTERFEROMETER COMPONENTS

The schematic interferometer diagrams given do not show most of the optics, such as beam collimators and focusing mirrors. Mirrors in an FTIR are generally made of metal. The mirrors are polished on the front surface and may be gold-coated to improve corrosion

TABLE 4.4 Comparison of Dispersive IR and FTIR Instruments

Dispersive IR **FTIR** Many moving parts results in mechanical slippage Only mirror moves during an experiment Calibration against reference spectra required to Use of laser provides high frequency precision (to 0.01 cm⁻¹) (Connes' advantage) measure frequency Stray light within instrument causes spurious readings Stray light does not affect detector, since all signals are modulated In order to improve resolution, only small amount of IR Much larger beam aperture used; higher energy throughput (Throughput or Jacquinot's advantage) beam is allowed to pass through the slits Only narrow-frequency radiation falls on the detector All frequencies of radiation fall on detector simultaneously; at any one time improved S/N ratio obtained quickly (Multiplex or Fellgett's advantaae) Slow scan speeds make dispersive instruments too Rapid scan speeds permit monitoring samples undergoing slow for monitoring systems undergoing rapid rapid change change (e.g., GC effluents) Sample subject to thermal effects from the source due Short scan times, hence sample is not subject to thermal to length of scan time Any emission of IR radiation by sample will fall on Any emission of IR radiation by sample will not be detected detector due to the conventional positioning of the sample before the monochromator Double-beam optics permit continuous real-time Single-beam optics; background spectrum collected background subtraction separately in time from sample spectrum. Can result in error if background spectra not collected frequently

resistance. Commercial FTIRs use a variety of flat and curved mirrors to move light within the spectrometer, to focus the source onto the beam splitter, and to focus light from the sample onto the detector.

The beam splitter can be constructed of a material such as Si or Ge deposited in a thin coating onto an IR-transparent substrate. The germanium or silicon is coated onto the highly polished substrate by vapor deposition. A common beam splitter material for the mid-IR region is germanium and the most common substrate for this region is KBr. Both the substrate and the coating must be optically flat. KBr is an excellent substrate for the mid-IR region because of its transparency and its ability to be polished flat. Its major drawback is that it is hygroscopic; this limits the use of KBr as a substrate for field or process control instruments, where environmental conditions are not as well controlled as laboratory conditions. Germanium on KBr is also used for the long wavelength end of the NIR region, while Si coated on quartz can be used for the short wavelength end of the NIR region. A thin film of Mylar is used as a beam splitter for the far-IR region. Other combinations of coatings and substrates are available, including complex multilayer materials, especially for applications where moisture may limit the use of KBr.

Ideally, the beam splitter should split all wavelengths equally, with 50 % of the beam being transmitted and 50 % reflected. This would result in equal intensity at both the fixed and moving mirrors. Real beam splitters deviate from ideality.

 CO_2 and H_2O absorb IR radiation (Figure 4.14). To reduce the spectral background from CO_2 and H_2O and increase the light intensity in the regions where these gases absorb, many spectrometers have sealed and desiccated optical systems. Only a small air path in the sample compartment remains. Alternately, some spectrometers allow the optics and the sample path to be purged with dry nitrogen or other dry gas, decreasing the H_2O and CO_2 in the light path.

IR spectrometers must be calibrated for wavelength accuracy. FTIRs are usually calibrated by the manufacturer and checked on installation. Wavelength calibration can be checked by the analyst by taking a spectrum of a thin film of polystyrene, which has well-defined absorption bands across the entire mid-IR region, as seen in Figure 4.1. Polystyrene calibration standard films are generally supplied with an IR instrument or can be purchased from any




FIGURE 4.14 A background spectrum of air, showing the absorption bands due to water vapor and carbon dioxide. (Collected on a paragon 1000 FTIR spectrometer, ©2020 PerkinElmer, inc. All rights reserved. Printed with permission.)

instrument manufacturer. Recalibration of the spectrometer should be left to the instrument service engineer if required.

4.2.3 DETECTORS

Detectors for IR radiation fall into two classes: thermal detectors and photon-sensitive detectors. Thermal detectors include *bolometers* and *pyroelectric* devices. Thermal detectors tend to be slower in response than photon-sensitive semiconductors. Faster detectors are required for FTIR. FTIR relies on pyroelectric and photon-sensitive semiconducting detectors. Table 4.5 summarizes the wavenumber ranges covered by commonly used detectors.

TABLE 4.5 Detectors for	or IR Spectroscopy	
Near-IR (12,000–3800 cm ⁻¹ ; 0.8 μm)	Mid-IR (4000–400 cm ⁻¹ ; 2.5–25 μm)	Far-IR (400–20 cm ⁻¹ ; 25–500 μm)
InGaAs (12,000–6,000 cm ⁻¹)		
PbSe (11,000–2,000 cm ⁻¹)		
InSb (11,500–1,850 cm ⁻¹)		
MCT (11,700-400 cm ⁻¹)	MCT (11,700-400 cm ⁻¹)	
DTGS/KBr (12,000-350 cm ⁻¹)	DTGS/KBr (12,000-350 cm ⁻¹)	
	Photoacoustic(10,000–400 cm ⁻¹)	
	DTGS/CsI (6,400-200 cm ⁻¹)	
		DTGS/PE (700-50 cm ⁻¹)
		Si bolometer (600–20 cm ⁻¹)

Source: © Thermo Fisher Scientific (www.thermofisher.com). Used with permission.

Note: KBr, Csl, and PE (polyethylene) are the window materials for the DTGS detectors. The MCT detector can vary in its spectral range depending on the stoichiometry of the material.

4.2.3.1 BOLOMETER

A bolometer is a very sensitive electrical resistance thermometer that is used to detect and measure weak thermal radiation. Consequently, it is especially well suited as an IR detector. The bolometer used in dispersive instruments consisted of a thin metal conductor, such as platinum wire. Incident IR radiation heats up this conductor, which causes its electrical resistance to change. The degree of change of the conductor's resistance is a measure of the amount of radiation that has fallen on the detector. This response is too slow for use in FTIR.

Modern bolometers are micro-machined from silicon. This type of bolometer is only a few micrometers in diameter and is usually placed in one arm of a Wheatstone bridge for measurements. The modern micro-bolometer has a fast response time and is particularly useful for detecting far-IR radiation (600-20 cm⁻¹).

4.2.3.2 PYROELECTRIC DETECTORS

Pyroelectric materials change their electric polarization as a function of temperature. These materials may be insulators (dielectrics), ferroelectric materials, or semiconductors. A dielectric placed in an electrostatic field becomes polarized with the magnitude of the induced polarization depending on the dielectric constant. The induced polarization generally disappears when the field is removed. Pyroelectric materials, however, stay polarized and the polarization is temperature dependent.

A pyroelectric detector consists of a thin single crystal of pyroelectric material placed between two electrodes. It acts as a temperature-dependent capacitor. Upon exposure to IR radiation, the temperature and the polarization of the crystal change. The change in polarization is detected as a current in the circuit connecting the electrodes. The signal depends on the rate of change of polarization with temperature and the surface area of the crystal. These crystals are small; they vary in size from about 0.25 to 12.0 mm².

The most common pyroelectric material in use as an IR detector is deuterated triglycine sulfate (DTGS). The formula for triglycine sulfate is $(NH_2CH_2COOH)_3 \cdot H_2SO_4$; replacement of hydrogen with deuterium gives DTGS. DTGS with a cesium iodide window covers the 6400-200 cm⁻¹ range, which includes part of the NIR, all of the mid-IR, and some of the far-IR regions. With the use of a polyethylene window, a DTGS detector can be used as a far-IR detector (700-50 cm⁻¹). Other pyroelectric detectors for the mid-IR region include lithium tantalate, LiTaO₃, and strontium barium niobate.

Pyroelectric materials lose their polarization above a temperature called their Curie point. For DTGS, this temperature is low. DTGS detectors are cooled by thermoelectric cooling to between 20 °C and 30 °C to prevent loss of polarization. Lithium tantalate has a much higher Curie temperature and does not require cooling, but is less sensitive than DTGS by about an order of magnitude. Lithium tantalate has a high linear response range, unlike DTGS. DTGS does not respond linearly over the IR frequency range. Its response is inversely proportional to the modulation frequency of the source, resulting in lower sensitivity at the high frequency end of the spectral range than at the low frequency end.

4.2.3.3 PHOTON DETECTORS

Semiconductors are materials that are insulators when no radiation falls on them but become conductors when radiation falls on them. Exposure to radiation causes a very rapid change in their electrical resistance and therefore a very rapid response to the IR signal. The response time of a semiconductor detector is the time required to change the semiconductor from an insulator to a conductor, which is frequently as short as 1 ns. The basic concept behind this detector is that absorption of an IR photon raises an electron in the detector material from the valence band of the semiconductor across a band gap into the conduction band, changing its conductivity greatly. In order to do this, the photon must have sufficient energy to displace the electron. IR photons have less energy than UV or visible photons. The semiconductors chosen as IR detectors must have band gaps of the appropriate energy. The band gap of the detector material determines the longest wavelength (lowest wavenumber) that can be detected.




FIGURE 4.15 Spectral response of various semiconductor detectors. The operating temperature in kelvin is given next to the material.

Materials such as lead selenide (PbSe), indium antimonide (InSb), indium gallium arsenide (InGaAs), and mercury cadmium telluride (HgCdTe, also called MCT) are intrinsic semiconductors commonly used as detectors in the NIR and mid-IR regions. Cooling of these detectors is required for operation. MCT requires operation at 77 K and must be cooled with liquid nitrogen; other detectors such as InGaAs can operate without cooling, but show improved S/N if cooled to -30 °C or so with thermoelectric cooling. For the far-IR region, extrinsic semiconductors such as Si and Ge doped with low levels of copper, mercury, or other dopants are used. The dopants provide the electrons for conductivity and control the response range of the detector. These doped germanium or silicon detectors must be cooled in liquid helium, but are sensitive to radiation with wavelengths as long as 200 μ m. The spectral response curves of some semiconductor detectors are shown in Figure 4.15. The MCT material used is nonstoichiometric, and can be represented as Hg_(1-x)Cd_xTe. The actual spectral range of an MCT detector can be varied by varying the Hg/Cd ratio.

Semiconductor detectors are very sensitive and very fast. The fast response time has permitted rapid-scan IR to become a reality, as is needed in FT spectrometers and coupled techniques such as GC-IR that generate transient peaks. The sensitivity of these detectors has opened up the field of microsampling, IR microscopy, and on-line IR systems for process control.

4.2.4 DETECTOR RESPONSE TIME

The length of time that a detector takes to reach a steady signal when radiation falls on it is called its *response time*. This varies greatly with the type of detector used and has a significant influence on the design of the IR instrument. Thermal detectors have very slow response times, on the order of seconds, because their temperature has to change as a result of radiation falling on the detector.

Semiconductors operate on a different principle. When radiation falls on them, they change from a nonconductor to a conductor. No temperature change is involved in the process; only the change in electrical resistance is important. This takes place over an extremely short period of time. Response times of the order of nanoseconds are common. This enables instruments to be designed with very short scanning times. These kinds of instruments are

very valuable when put onto the end of a GC and used to obtain the IR spectra of the effluents. Such scans must be made in a few seconds and be completely recorded before the next component emerges from the GC column.

Response time is not the only detector characteristic that must be considered. Linearity is very important in the mid-IR region where wide variations in light intensity occur as a result of absorption by a sample. The ability of the detector to handle high light levels without saturating is also important. The MCT detectors saturate easily and should not be used for high-intensity applications; DTGS, on the other hand, while not as sensitive as MCT, does not saturate as readily.

4.3 SAMPLING TECHNIQUES

IR spectroscopy is one of the few analytical techniques that can be used for the characterization of solid, liquid, and gas samples. The choice of sampling technique depends upon the goal of the analysis, qualitative identification or quantitative measurement of specific analytes, upon the sample size available, and upon sample composition. Water content of the sample is a major concern, since the most common IR-transparent materials are soluble in water. Samples in different phases must be treated differently. Sampling techniques are available for transmission (absorption) measurements and for several types of reflectance (reflection) measurements. The common reflectance measurements are attenuated total reflectance (ATR), diffuse reflectance or diffuse reflectance infrared Fourier transform spectroscopy (DRIFTS), and specular reflectance. The term reflection may be used in place of reflectance and may be more accurate; specular reflection is actually what occurs in that measurement, for example. However, the term reflectance is widely used in the literature and will be used here.

4.3.1 TECHNIQUES FOR TRANSMISSION (ABSORPTION) MEASUREMENTS

These are the oldest and most basic sampling techniques for IR spectroscopy. Transmission analysis can handle a wide range of sample types and can provide both qualitative and quantitative measurements. Transmission analysis provides maximum sensitivity and high sample throughput at relatively low cost. Substantial sample preparation may be required.

The sample or the material used to contain the sample must be transparent to IR radiation to obtain an absorption or transmission spectrum. This limits the selection of container materials to certain salts, such as NaCl or KBr, and some simple polymers. A final choice of the material used depends on the wavelength range to be examined. A list of commonly used materials is given in Table 4.3. If the sample itself is opaque, it may be possible to dissolve it or dilute it with an IR-transparent material to obtain a transmission spectrum. Other approaches are to obtain IR reflectance spectra or emission spectra from opaque materials. The Specac website, www.specac.com, has pictures and details of the IR hydraulic presses, sampling accessories and sample holders discussed in the next sections.

4.3.1.1 SOLID SAMPLES

Three traditional techniques are available for preparing solid samples for collection of transmission IR spectra: mulling, pelleting, and thin film deposition. First, the sample may be ground to a powder with particle diameters less than 2 μ m. The small particle size is necessary to avoid scatter of radiation. A small amount of the powder, 2-4 mg, can be made into a thick slurry, or *mull*, by grinding it with a few drops of a greasy, viscous liquid, such as Nujol (a paraffin oil) or chlorofluorocarbon greases. The mull is then pressed between two salt plates to form a thin film. This method is good for qualitative studies, but not for quantitative analysis. To cover the complete mid-IR region, it is often necessary to use two different






FIGURE 4.16 (a) Schematic drawing of a typical IR pellet die showing the arrangement of the major components. (Reprinted from Aikens et al. By permission from Waveland Press, Inc. Long Grove, IL, 1984. All rights reserved.) (b) Evacuable pellet dies for hydraulic press. (Courtesy of Specac, Inc., Ft. Washington, PA. www.specac.com. Used with permission.)

mulling agents, since the mulling agents have absorption bands in different regions of the spectrum. The spectrum of the mulling agents alone should be obtained for comparison with the sample spectrum.

The second technique is the KBr pellet method, which involves mixing about 1 mg of a finely ground (<2 µm diameter) solid sample with about 100-200 mg powdered dry potassium bromide. The mixture is compressed under very high pressure (>50,000 psi) in a vacuum to form a small disk about 10 mm in diameter. Hydraulic presses, both manual and automated, can apply 15-40 tons of pressure. An evacuable die is designed for use in a hydraulic press. A die consists of a body and two anvils that will compress the powdered mixture. The faces of the anvils are highly polished to give a pressed pellet with smooth surfaces. Evacuable dies are shown in Figure 4.16. When done correctly, the KBr pellet looks like glass. The disk is transparent to IR radiation and may be analyzed directly by placing it in a standard pellet holder. Commercial dies are available to form pellets from 5-40 mm in diameter, with 8-13 mm common for IR. The larger pellets are used for XRF (Chapter 8). There are small, handoperated presses available for making KBr pellets, but the quality of the pellet obtained will not be as good as that obtained with an evacuable die. The pellet often will contain more water, which absorbs in the IR region and may interfere with the sample spectrum. There are several types of handheld presses available. A common design consists of two bolts with polished ends that thread into a metal die (Figure 4.17). The die serves as the body of the press and also as the sample holder. One bolt is threaded into place. The KBr/sample mix is added into the open hole in the die so that the face of the inserted bolt is covered with powdered mix.



FIGURE 4.17 Hand-held IR pellet press. (Courtesy of Specac, Inc., Ft. Washington, PA. www.specac.com. Used with permission.)

The second bolt is inserted into the die. Pressure is applied using two wrenches, one on each bolt. The bolts are then removed; the KBr pellet is left in the die and the die is placed in the light path of the spectrometer. The pellet should appear clear; if it is very cloudy, light scattering will result, giving a poor spectrum. The pellet is removed by washing it out of the die with water. One disadvantage of this type of die is that the pellet usually cannot be removed intact; if pellets need to be saved for possible reanalysis, a standard die and hydraulic press should be used. Micropellet dies are available that produce KBr pellets on the order of 1 mm in diameter and permit spectra to be obtained on a few micrograms of sample. A beam condenser is used to reduce the size of the IR source beam at the sampling point.

It is critical that the KBr be dry; even then bands from water may appear in the spectrum because KBr is so hygroscopic. The KBr used should have its IR spectrum collected as a blank pellet; reagent grade KBr sometimes contains nitrate, which has IR absorption bands. IR-grade KBr should be used when possible. The quality of the spectrum depends on having small particle size and complete mixing. A mortar and pestle can be used for mixing, but better results are obtained with a vibrating ball mill such as the Wig-L-Bug* (International Crystal Laboratories, www.internationalcrystal.net). It is also very important that the polished faces of the anvils not be scratched. The anvils should never have pressure applied to them unless powdered sample is present to avoid scratching the polished faces.

In the third method, the solid sample is deposited on the surface of a KBr or NaCl plate or onto a disposable "card" by evaporating a solution of the solid to dryness or allowing a thin film of molten sample to solidify. IR radiation is then passed through the thin layer deposited. It is difficult to carry out quantitative analysis with this method, but it is useful for rapid qualitative analysis. The thin film approach works well for polymers, for example. It is important to remove all traces of solvent before acquiring the spectrum. Disposable salt "cards" are available for acquiring the IR spectrum of a thin film of solid deposited by evaporation. These cards have an extremely thin KBr or NaCl window mounted in a cardboard holder, but are manufactured so that atmospheric moisture does not pose a storage problem (Real CrystalTM IR cards, International Crystal Laboratories, Garfield, NJ, www.internationalcrystal.net). Water can even be used as the solvent for casting films of polar organic molecules on these cards.

A newer approach to collecting transmission spectra of solids is the use of a *diamond* anvil cell. Diamond is transparent through most of the mid-IR region, with the exception of

a broad absorption around 2000 cm⁻¹. A solid sample is pressed between two small parallel diamond "anvils" or windows to create a thin film of sample. A beam condenser is required because of the small cell size. Very high pressures can be used to compress solid samples because diamonds are very hard materials. As a result, the diamond anvil cell permits transmission IR spectra to be collected of thin films of very hard materials. Hard materials cannot be compressed between salt windows because the salt crystals are brittle and crack easily.

In general, spectra from solid samples are used for qualitative identification of the sample, not for quantitative analysis. The spectrum of a solid sample is generally collected when the sample is not soluble in a suitable IR-transparent solvent. There are some problems that can occur with spectra from solid samples. Many organic solids are crystalline materials. The mull and pellet approaches result in random orientation of the finely ground crystals; deposition of thin films by evaporation may result in a specific crystal orientation with respect to the light beam. Hence, thin film spectra may look different from the spectrum of the same material collected as a mull or a pellet. When possible, spectra of known materials obtained by the same sample preparation method should be compared when trying to identify an unknown. Use of a high-pressure hydraulic press for KBr pellets may cause crystal structure changes in some materials; again, standards and samples should have the same sample preparation method used if spectra are to be compared.

4.3.1.2 LIQUID SAMPLES

The easiest samples to handle are liquid samples. Many liquids may be analyzed "neat", that is, with no sample preparation. Neat liquids that are not volatile are analyzed by pressing a drop of the liquid between two flat salt plates to form a very thin film. The salt plates are held together by capillary action or may be clamped together. NaCl, KBr, AgCl, and similar salts are used as the plates. Volatile liquids may be analyzed neat by using a pair of salt plates with a thin spacer in a sealed cell. The path length of these cells depends on the spacer thickness. For neat liquids very small path lengths, less than 0.05 mm, must be used to avoid complete absorption of the source beam. Sample sizes used for the collection of neat spectra are on the order of a few milligrams of material.

The use of dilute solutions of material for IR analysis is the preferred choice for several reasons. Solutions give more reproducible spectra, and dilution in an IR-transparent solvent eliminates the problem of total absorption by the strong bands in a neat sample. Solvents commonly used for IR spectroscopy include carbon tetrachloride, carbon disulfide, methylene chloride, and some alkanes such as hexane. No one solvent is transparent over the entire mid-IR region, so the analyst must choose a solvent that is transparent in the region of interest. Figure 4.18 shows the IR-transparent regions for some common




FIGURE 4.18 IR absorption characteristics of some common solvents. Regions of strong IR absorbance in 0.1 mm cells (except water, 0.01 mm cell) are shown as shaded areas. Longer cell paths will broaden the regions of absorption and in some cases introduce new regions where absorption is significant. (Reprinted from Aikens et al. By permission from Waveland Press, Inc. Long Grove, IL, 1984. All rights reserved.)




FIGURE 4.19 (a) Standard demountable cell for liquid samples, shown in an "exploded" view. The spacer is of Teflon or metal. The width of the spacer used determines the pathlength of the assembled cell. The nuts screw onto the four threaded posts to seal the assembled cell. Once the cell is assembled, it is filled via syringe. The inlet port on the back plate is equipped with a fitting for a syringe (not shown); The outlet port is the hole in the back plate opposite the inlet hole. Sample is injected until the liquid appears at the top of the outlet port. Plugs are put into both inlet and outlet ports to seal the cell. © 2020 PerkinElmer, inc. All rights reserved. Printed with permission. (b) and (c) show the absorbance spectra for two commercial disposable IR cards with polymer film windows. The choice of polymer depends on the region of the spectrum to be studied. PTFE (c) would be used if the c—h stretch region needs to be measured, while clearly polyethylene (b) is not suited for that use. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

solvents. Liquid cells for solutions are sealed cells, generally with a path length of 0.1-1 mm and two salt windows. The path length is fixed by a spacer placed between the two salt windows. Some cells come with a single fixed path length; other cells can be purchased with a variety of spacers. These cells can be disassembled and the path length changed by inserting a different spacer [Figure 4.19(a)]. The windows and spacer are clamped into a metal frame that has two ports: one inlet and one outlet port. The cell is filled by injecting sample solution with a syringe into one port and allowing it to flow until the solution exits the other port. Solution concentrations of 1-10 % sample are used for most quantitative work. In the single-beam FTIR, solvent absorption bands are corrected for by obtaining a blank spectrum of the solvent and subtracting the blank spectrum from the sample solution spectrum, just as the background is subtracted. The same cell is used for both the blank spectrum and the sample spectrum.

Most IR cells must be protected from water, because the salt plates are water soluble and hygroscopic. Organic liquid samples should be dried over an appropriate drying agent before being poured into the cells; otherwise, the cell surfaces become opaque and uneven. Such etching of the internal window surfaces is frequently a serious problem, particularly when

quantitative analyses are to be performed. Light scattering will occur, the path length within the cell becomes uneven and erroneous quantitative results may be obtained.

It will be remembered that Beer's Law indicates that the absorbance = abc, where b is the path length through the sample, or in this case the width of the empty cell. In order for quantitative data to be reliable, b must be a constant, or at least measurable and correctable. A measurement of b may be performed by using a procedure based on interference fringes. An empty and dry cell is put into the light path, and the interferogram collected. Partial reflection of the light takes place at the inner surfaces, forming two beams. The first beam passes directly through the sample cell, and the second beam is reflected twice by the inner surfaces before proceeding to the detector. The second beam therefore travels an extra distance 2b compared with the first beam. If this distance is a whole number of wavelengths $(n\lambda)$, then the two emerging beams remain in phase and no interference is experienced. However, if $2b = (n + 1/2)\lambda$, interference is experienced and the signal reaching the detector is diminished. The interference signal generated is a sine wave, and each wave indicates an interference fringe. The path length of the sample holder can be measured by using the formula:

$$b (\mu m) = \frac{n}{2\eta} \left(\frac{\lambda_1 \lambda_2}{\lambda_2 - \lambda_1} \right)$$

where n is the number of fringes; η , the refractive index of the sample (or air, if empty light path); and λ_1 and λ_2 , the wavelengths between which the number of fringes is measured.

If λ is measured in μ m, b also has units of μ m. For example, if n=14, $\lambda_1=2$ μ m, and $\lambda_2=20$ μ m, b can be calculated as:

$$b = \frac{14}{2} \left(\frac{2 \times 20}{20 - 2} \right) = 15.5 \,\mu\text{m}$$
 (assuming that $\eta = 1$)

For quantitative analysis, it is necessary to measure the path length in order to use calibration curves obtained with the same cell but at different times. If the cell becomes badly etched, the interference pattern becomes noisy and the cell windows have to be removed and repolished.

IR spectra of samples containing water can be accomplished using special cells with windows of barium fluoride, silver chloride or KRS-5. These materials are not very water-soluble (see Table 4.3). However, a more useful technique is to measure attenuated total reflection (Section 4.3.3.1).

Disposable IR cards with a thin polymer film window are available for the qualitative analysis of liquids; they are available from International Crystal Laboratories, Garfield, NJ, and other suppliers. Two polymer substrates are available: polytetrafluoroethylene for the 4000-1300 wavenumber region and polyethylene for the lower wavenumber region. The absorption spectra for these two materials are displayed in Figure 4.19(b) and (c). A thin film can be deposited onto the polymer window by evaporation from solution or by smearing the liquid onto the polymer. A major advantage of these cards is that the polymer films do not dissolve in water; therefore, samples containing water can be analyzed. Absorption bands from the polymer substrate are subtracted from the sample spectra by running a blank card spectrum.

Microcells are available for the analysis of as little as $0.5\,\mu L$ of liquid sample. These microcells also require a beam condenser as described for solid microsamples.

4.3.1.3 GAS SAMPLES

Gas sample cells have windows of KBr and cell bodies made of glass or metal, along with two ports with valves for evacuating the cell and filling the cell from an external gas source. Gases are much more dilute than liquids or solids; a gas has many fewer molecules per unit volume than does a condensed phase. To compensate for the small concentration of sample molecules




FIGURE 4.20 Schematic gas absorption cell. Reflection of the light beam through the cell makes the effective path length longer than the cell length.

in a gas (the c term in Beer's Law), the gas cells have longer path lengths (b is increased). The sample cavity of an IR spectrometer is generally about 10 cm long. There are gas cells with a single-pass 10 cm path length, but most gas cells make use of multiple reflections to increase the effective path length. Commercial gas cells with effective path lengths of 2, 10, 20, 40, and up to 120 m are available. The IR beam is reflected multiple times from internal mirrors in the cell. Such a cell is shown schematically in Figure 4.20, where the multiple reflections make the effective path length $5\times$ longer than the actual physical length of the cell. A single-pass 10 cm cell requires about 50 torr of sample pressure to obtain a good IR spectrum. However, multiple reflection cells with long path lengths permit the analysis of ppm concentrations of gases. Gas cells are also used to obtain the vapor-phase spectrum of highly volatile liquids. A drop or two of liquid is placed in the cell, the valves are closed, and the sample is allowed to come to equilibrium. The vapor phase spectrum of HCl (Figure 4.2) was collected by placing a few drops of concentrated hydrochloric acid in a 10 cm gas cell with a glass body and KBr windows. The gas sample must not react with the cell windows or surfaces. Temperature and pressure must also be controlled if quantitative measurements are being made.

A second type of gas sampling FTIR is the open path instrumentation used for analysis of ambient air for environmental monitoring, chemical agent, and toxic vapor detection. These open path systems are specifically designed for use in the field and are "hardened" against mechanical shock, vibration, temperature, and humidity changes. These systems use interferometry and either a passive mid-IR detector which measures infrared signatures naturally emitted by chemicals or an active detector measuring absorption signatures using transmitted light from an active IR source. The systems can measure chemical agents and pollutants at distances of from one mile to several kilometers. They are used for smoke stack emission measurements, air pollution measurements, emissions from waste disposal sites, chemical accidents, or toxic agents deliberately released into the air. The Bruker website, www.bruker. com, has pictures and technical details of its HAWK First Responder and EM27 Open Path FTIR instruments, for example.

4.3.2 BACKGROUND CORRECTION IN TRANSMISSION MEASUREMENTS

The two main sources of background absorption (i.e., absorption from material other than the sample) are the solvent used for liquid solutions and the air in the optical light path. FTIR is a single-beam system and both air and solvent contribute to the signal, so corrections must be made in several steps.

4.3.2.1 SOLVENT ABSORPTION

The solvent absorption spectrum is measured by putting pure solvent in the liquid sample cell and recording its spectrum. This spectrum is stored by the computer under an assigned file name (e.g., Spectrum A). The cell is then filled with the sample solution in that solvent, its spectrum taken, recorded, and stored under a file name (e.g., Spectrum B). Spectrum A is then subtracted from Spectrum B by the computer software, giving the net spectrum of the sample. Of course, in this approach for liquid sample solutions, any absorption by the air is

also measured in both Spectrum A and Spectrum B, so the absorption by air is also corrected for. Ideally, if the solvent and the sample can be measured without removing the cell from the instrument, artifacts can be minimized.

4.3.2.2 AIR ABSORPTION

Gaseous CO₂ and H₂O vapor are both strong IR absorbers. Both occur in air in the optical light path and contribute to any IR absorption signal measured. First, the air spectrum is recorded with no sample present. This constitutes the "blank" spectrum and is stored as a file (usually called BLANK). Samples of any type—mulls, pellets, or neat liquids—may be run and their total spectrum (air + sample) recorded and stored. The blank (air) spectrum is then subtracted by the computer, leaving the net sample spectrum. This is an easy and rapid measurement for an FTIR, and in routine analysis, the background spectrum should be collected and the file updated on a regular basis.

A typical background spectrum of air taken by an FTIR spectrometer is shown in Figure 4.14. The bands above $3000~\rm cm^{-1}$ and between $1400~\rm and~1700~\rm cm^{-1}$ are due to water; the main $\rm CO_2$ band is the band at about $2350~\rm cm^{-1}$. This spectrum is stored for subtraction from all subsequent sample spectra. However, the absorption of the source intensity by carbon dioxide and water reduces the energy available in the regions where they absorb. To reduce the spectral background from carbon dioxide and water and increase the light intensity in these regions, many spectrometers have sealed and desiccated optical systems or a means of purging the optical path to remove the air. Purging the optical path is done with dry nitrogen or argon.

4.3.3 TECHNIQUES FOR REFLECTANCE AND EMISSION MEASUREMENTS

The sample techniques just described are designed for collection of transmission (absorption) spectra. This had been the most common type of IR spectroscopy, but it was limited in its applications. There are many types of samples that are not suited to the conventional sample cells and techniques just discussed. Thick, opaque solid samples, paints, coatings, fibers, polymers, aqueous solutions, samples that cannot be destroyed such as artwork or forensic evidence samples, hot gases from smokestacks—these materials posed problems for the analytical chemist who wanted to obtain an IR absorption spectrum. The use of reflectance techniques provides a nondestructive method for obtaining IR spectral information from materials that are opaque, insoluble, or cannot be placed into conventional sample cells. In addition, IR emission from heated samples can be used to characterize certain types of samples and even measure remote sources such as smokestacks. In reflectance and emission, the FTIR spectrometer system is the same as that for transmission. For reflectance, the sampling accessories are different and in some specialized cases contain an integral detector. The heated sample itself provides the light for emission measurements; therefore, there is no need for an IR source. There may be a heated sample holder for laboratory emission measurements.

4.3.3.1 ATTENUATED TOTAL REFLECTANCE (ATR)

ATR or internal reflectance uses an optical element of high refractive index. This optical element is called the internal reflection element (IRE) or the ATR crystal. Light traveling in a high refractive index material is reflected when it encounters an interface with a material of a lower refractive index. The amount of light reflected depends upon the angle of incidence at the interface. When the angle of incidence is greater than the *critical angle*, which depends on the ratio of the two refractive indices, complete reflection of light occurs at the interface (i.e., total internal reflection). If a sample of material, such as a squishy polymer or rubber or a liquid is placed directly against the IRE, an interface is formed. The light beam traveling in the IRE will be completely reflected at the interface if the critical angle condition is met,




FIGURE 4.21 Schematic ATR sampling accessory. The internal reflection crystal permits multiple reflections. At each reflection, a small amount of IR energy penetrates the sample and absorption occurs at the vibrational frequencies for the sample. (Courtesy of Pattacini Associates, LLC, Danbury, CT.)

but the beam of light actually penetrates a very short distance (generally less than 2 μ m) into the lower refractive index material (in this case, the sample). This penetrating beam is called an **evanescent wave**. If the sample cannot absorb any of the light, all of the intensity is reflected. If the sample can absorb part of the light, the light beam is **attenuated**, that is, reduced in intensity, at the frequencies where the sample absorbs. This is the basis of the ATR sampling technique. A schematic representation of a multiple reflection ATR crystal is shown in Figure 4.21. The interaction of the evanescent wave with the sample essentially provides an IR absorption spectrum of the sample.

Selection of the ATR crystal material for a specific sample analysis depends on the crystal refractive index (RI), its spectral range, and its chemical and physical properties. The crystal should have a higher index of refraction than the sample. The majority of organic samples have RIs of approximately 1.5. ATR crystals span a range of 2.4-4.0 in refractive index. If the RI ratio is not appropriate, spectral features may be distorted, with diminished peak symmetries, sharp baseline/peak shoulder transitions, and derivative-like features in the spectrum.

Typical ATR crystal materials are listed in Table 4.6. Samples must be in actual intimate physical contact with the ATR crystal. The first ATR systems were designed to analyze solids that could be pressed against the surface of the crystal: polymers, films, moldable resins, textiles, canvas paintings, and the like. Little or no sample preparation is required. For example, the IR spectrum of a valuable painting could be obtained without destroying the painting. This is essential in examining artwork and in other applications such as forensic science, archaeology, and paleontology. Very hard materials such as minerals could not be pressed against traditional ATR crystals because the IRE would be damaged. Designs of ATR probes

TABLE 4.6	Common	ATD IDE	Matorials
IADLE 4.0	COIIIIIIOII	AIDINE	Materiais

Material	Spectral Range (cm ⁻¹)	Refractive Index	Penetration Depth ^a (μm)	Uses
Germanium	5,500–675	4	0.66	Good for most samples; strongly absorbing samples such as dark polymers
Silicon	8,900-1,500	3.4	0.85	Resistant to basic solutions
AMTIR ^b	11,000-725	2.5	1.77	Very resistant to acidic solutions
ZnSe	15,000-650	2.4	2.01	General use; not for acidic solutions
Diamond	30,000–200	2.4	2.01	Good for most samples, extremely caustic or hard samples

Source: © Thermo Fisher Scientific (www.thermofisher.com). Used with permission.

a Depth at 45° and 1000 cm⁻¹.

b AMTIR is an IR-transparent glass composed of Ge, As, and Se.

include cylindrical probes used for analysis of liquids and diamond ATR probes for hard materials. The diamond ATR probes permit analysis of hard, rigid samples and probes with inert diamond tips are available for direct insertion into process streams. The ATR crystal chosen must be chemically and physically compatible with the sample. Some crystal materials may react with certain samples, damaging the crystal and in some cases, producing dangerous side effects. For example, ZnSe cannot be used in acidic solutions, because solutions with pH<5 will etch the crystal and very strong acids will generate toxic hydrogen selenide. The crystal KRS-5 is not only soft but somewhat soluble in water and should be used only in the pH range of 5-8. Other crystals are susceptible to temperature and pressure changes.

ATR can be used to monitor organic reactions and processing of organic materials. For example, if an ATR probe is put into a mixture of reacting organic compounds, one particular wavelength can be monitored to indicate the disappearance of one of the reactants or the appearance of a product as the reaction proceeds. This eliminates the need to remove samples from the reaction vessel or process line in order to obtain an IR spectrum and permits continuous monitoring of the reaction without disturbing the system. ATR systems are also available with heaters to monitor processes at elevated temperatures and to study reaction kinetics and thermal degradation. Making quality chocolate is an example of a process that can be monitored by ATR at elevated temperature. ATR can be applied to the study of fossils. IR spectra can be obtained from the surface of fossilized plants or animals. The method is nondestructive, and the samples need not be removed from the fossil surface. The method is of particular interest to paleontologists and archeologists. Fossilized leaves, amber, bone, fish, trilobites, teeth, and many other sample types have been examined.

Remote mid-IR probes such as the PIKE FlexIRTM Hollow Waveguide Accessory (Pike Technologies, www.piketech.com) permit in vivo studies, such as investigations of chemical diffusion through the skin, residual chemicals on skin from personal care type products, analysis of large painted panels, and similar studies which could not be done in the sampling compartment of an FTIR. The hollow waveguide consists of hollow silica tubing coated on the inside with a highly reflective, smooth Ag/AgI dielectric layer and on the outside with a polymer coating for strength (Figure 4.22(a) and (b)). The spectral range spanned by hollow wave guides is from 11,000-400 cm⁻¹ and remote probes are available for ATR, specular reflectance and diffuse reflectance measurements. The ATR crystals available are ZnSe, Ge, and diamond/ZnSe composite. As an example, the FlexIRTM ZnSe ATR probe was used to study the effect of sunscreen on skin [Figure 4.22(c)]. Untreated skin measured directly with the probe showed the amide I and amide II bands at 1650 and 1550 cm⁻¹. Spectral subtraction of the untreated skin spectrum from sunscreen-treated skin permitted the residual chemicals from the sunscreen to be studied (Briggs; www.piketech.com).

4.3.3.2 SPECULAR REFLECTANCE

When light bounces off a smooth polished surface, specular reflection occurs. By specular reflection, we mean that the angle of reflected light is equal to the angle of incident light, just as happens with a mirror. Specular reflectance is a nondestructive way to study thin films on smooth, reflective surfaces. The measurement is a combination of absorption and reflection. The IR or NIR beam passes through the thin coating where absorption can occur. The beam is reflected from the polished surface below the coating and then passes through the coating again on its way out. Spectra can be obtained from inorganic and organic coatings from sub-micrometer to 100 micrometers in thickness. An angle of incidence of 45° from the normal is typically used for thin films. Ultrathin films, as thin as 20 Å, may be studied using a much larger angle of incidence, such as 80° from normal. This technique is called grazing angle analysis.

The thin films or coatings can be studied nondestructively, with no sample preparation other than deposition on a polished metal surface if necessary. Specular reflectance has been used to study lubricant films on computer disks, oxide layers on metal surfaces, paint curing as a function of time, and molecules adsorbed on surfaces. For example, the IR absorption spectrum of proteins adsorbed onto a polished gold surface can be studied. This spectrum from an adsorbed layer can form the basis of sensors for compounds that will bind to the






FIGURE 4.22 (a) Hollow wave guide schematic **(b)** Mid-IR FlexIR™ with remote probes **(c)** ATR spectra of human skin, skin treated with sunscreen and the result of spectral subtraction. (Courtesy of PIKE technologies, www.piketech.com. Used with permission.)

proteins and change the spectrum. Use of a polarizer in conjunction with grazing angle analysis can provide information about the orientation of molecules adsorbed onto surfaces.

4.3.3.3 DIFFUSE REFLECTANCE

Diffuse reflectance, also called DRIFTS, is a technique used to obtain an IR or NIR spectrum from a rough surface. The rough surface may be a continuous solid, such as a painted surface, fabric, an insect wing or a piece of wood, or it may be a powder that has just been dumped into a sample cup, not pressed into a glassy pellet. The incident light beam interacts with the sample in several modes. Specular reflectance from the surface can occur; this is not desired and samples may need some preparation or dilution with KBr to minimize the specular component. The desired diffuse reflectance occurs by interaction of the incident beam with the sample. Ideally, the beam should penetrate about 100 μm into the sample and the reflected light is scattered at many angles back out of the sample. A large collecting mirror or, for NIR, an integrating sphere, is used to collect the scattered radiation.

DRIFTS works very well for powdered samples. The sample powder is generally mixed with loose KBr powder at dilutions of 5-10 % and placed into an open sample cup. A commercial diffuse reflectance arrangement for the mid-IR region is shown in Figure 4.23(a) and (b). Other types of probes, including fiber optic probes are available for diffuse reflectance measurements in the NIR region. A commercial IR integrating sphere for NIR diffuse reflectance measurements is diagrammed in Figure 4.23(c).

The diffuse reflectance experiment requires that the incident beam penetrate into the sample, but the path length is not well defined. The path length varies inversely with the sample absorptivity. The resulting spectrum is distorted from a fixed path absorbance spectrum and is not useful for quantitative analysis. Application of the Kubelka-Munk equation is a common way of making the spectral response linear with concentration.




FIGURE 4.23 (a) Schematic diagram of diffuse reflectance from a powdered sample in a cup, showing the depth of penetration of the incident and reflected beams. Ideally, specular reflectance should be minimized to prevent distortion of the diffuse reflectance spectrum. (From Coates, used with permission.) (b) A DRIFTS sampling accessory with a compound parabolic concentrator (CPC) design. The CPC design minimizes specular reflection from the sample surface, reduces sample packing and height effects, and avoids damage to the optics from sample spills by placement of the sample below the optics. © Thermo Fisher Scientific (www.thermofisher.com). Used with permission. (c) Schematic diagram of an NIR integrating sphere for DR. The sphere is placed in the sample compartment of a dispersive UV/VIS/NIR spectrophotometer. The sphere design permits only diffuse reflectance to reach the detector; the specular component is reflected out through the same opening the light enters. (Courtesy of Hitachi High technologies America, inc., Pleasanton, CA [www.hitachi-hhta.com].)

The Kubelka-Munk relationship is:

(4.10)
$$f(R_{\infty}) = \frac{(1 - R_{\infty})^2}{2R_{\odot}} = K'C$$

where R_{∞} is the ratio of the sample reflectance spectrum at infinite sample depth to that of a non-absorbing matrix such as KBr, K' is a proportionality constant, and C is the concentration of absorbing species. The Kubelka-Munk equation gives absorbance-like results for diffuse reflectance measurements, as can be seen by comparing it to Beer's Law, A = abc = Kc for a fixed path length. In Beer's Law, K is a proportionality constant based on the absorption coefficient and the pathlength. K' is also a proportionality constant, but based on the ratio of absorption coefficient to scattering coefficient. The term $f(R_{\infty})$ can be considered a "pseudo-absorbance".

4.3.3.4 IR EMISSION

Some samples are not amenable to transmission/absorption or reflectance spectroscopy. Samples can be characterized by their IR emission spectrum under certain conditions. If the sample molecules are heated, many will occupy excited vibrational states and will emit radiation upon returning to the ground state. The radiation emitted is characteristic of the

vibrational levels of the molecule, that is, the IR spectrum, and can be used to identify the emitting sample. The IR emission from the sample is directed into the spectrometer in place of the usual IR light source. Very small samples can have their IR emission collected with an IR microscope, discussed later in this chapter. Large, physically remote samples can be imaged with a telescope arrangement and the emitted light directed into the spectrometer.

IR emission can be used in the laboratory to study heated samples. Most modern research grade instruments offer an emission sampling port as an option. One significant advantage of IR emission spectrometry is that the sample can be remote—such as the emission from a flame or smokestack. Some typical applications of IR emission include analysis of gases, remote flames and smokestacks or other hot discharges, process measurements, photochemical studies, and the analysis of thin films and coatings. IR emission measurements are nondestructive and do not suffer from atmospheric background problems, since the room temperature water and carbon dioxide in air do not emit radiation. The major limitation is that thick samples cannot be measured due to reabsorption of the emitted radiation by cool parts of the sample.

4.4 FTIR MICROSCOPY

FTIR instruments with sensitive MCT detectors have permitted the development of the IR microscope, which extends IR spectroscopy to the examination of very small samples with excellent detection limits. An IR microscope uses two light beams, one visible and the other IR, that travel through the microscope optics to the sample following identical paths, as shown in Figure 4.24. The sample is viewed optically and the exact region to be studied is centered and focused using the microscope controls. In some microscope designs, the visible beam is then moved out of the light path and the IR beam is moved in. Microscopes designed with dichroic optics allow both beams to reach the sample so that the analyst can view the sample while the IR spectrum is collected. It is possible to collect an IR spectrum, in either transmission or reflectance mode, from an area as small as $10~\mu m$ in diameter. The IR signal from the sample passes to a dedicated MCT detector designed for small samples.

To obtain a transmission spectrum, the sample must be prepared. A microtome is used for cutting a very thin slice of the sample through which radiation can penetrate. Sample thickness must be in the range of 15 μ m and the sample must be flat. The quality of the




FIGURE 4.24 IR microscope schematic with the detector integrated into the microscope. The microscope is usually coupled to a light port on the side of the FTIR spectrometer. The FTIR spectrometer supplies a modulated, collimated beam of light to the microscope. (© 2020 PerkinElmer, inc. All rights reserved. Printed with permission. www.perkinelmer.com.)




FIGURE 4.25 Micrograph of a polymer laminate, showing two broad layers and a narrow middle layer. The sample was mounted in a NaCl compression cell and spectra were collected automatically in 2 μ m steps along the line indicated. A Centaur μ s analytical FTIR microscope system was used for the automatic data collection and results. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

spectrum depends on the sample preparation. All of the reflectance modes are available for microscopy, including ATR and grazing angle analysis. These generally require little or no sample preparation. The sensitivity obtainable is subnanogram quantities of analyte.

Modern FTIR microscopes are available with computer-controlled microscope stages and video imaging systems that permit a 2D picture of the sample to be displayed, and areas containing a specified functional group to be highlighted using "false color" to show differences in composition with respect to position in the sample. Microscopes are available that allow the use of polarized light for imaging and that can obtain fluorescence images. These are useful to improve the contrast in samples that lack features under normal illumination.

A prime example of the use of FTIR microscopy is in the examination of polymers, a very important class of engineering materials. The physical properties of polymers are very dependent on their molecular structure. The presence of impurities, residual monomers, degree of crystallinity, size, and orientation of crystalline regions (the microstructure of a polymer) greatly affects their mechanical behavior. FTIR microscopy can identify polymers, additives, and determine the presence of impurities.

Food-packaging materials may be made up of several layers of different polymers, called a laminate, to provide a single plastic sheet with the desired properties. Typical layers are between 10 and 200 μ m thick. Using an automated FTIR microscope, it is possible to obtain acceptable spectra from each layer and identify the polymers involved. As an example, a cross-section of a polymer laminate, compressed between NaCl plates, is shown is shown in Figure 4.25. Three layers were seen under magnification. The sample was moved in a straight line, as shown, and IR spectra were collected every 2 μ m across the sample. The spectra collected from the laminate can be displayed in a variety of formats, such as the "waterfall display" presented in Figure 4.26. This display gives the analyst a very clear picture of the




FIGURE 4.26 The spectra collected from the polymer laminate are displayed as a function of position along the sample, in a "waterfall display". The chemical differences in the layers are clearly seen. For example, the top layer has a large broad peak at about 3400 cm⁻¹ (the peak on the far left); that peak disappears as the middle and bottom layers are scanned. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)





FIGURE 4.27 One spectrum from each layer is displayed. The spectrum from the top layer matches that of a polyamide; That on the bottom is the spectrum of polyethylene. The middle spectrum has not yet been identified. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

differences in the three layers. If we look at the band on the left, between 3200 and 3400 cm⁻¹, we see that it is high in the layer plotted at the front of the display, as we move back (along the sample), we reach the thin middle layer. Note the band is still there, but much less intense. Then, moving back into the third layer, the band disappears. The same thing happens to the intense band at about 1700 cm⁻¹. Three distinct IR spectra were obtained, one from each layer (Figure 4.27). The front layer was identified as a polyamide polymer by matching its spectrum to a known spectrum. The back layer is identified as polyethylene—note that this spectrum does not show the bands seen in the polyamide spectrum at 3400 and 1700 cm⁻¹. The middle layer was not immediately identified. A search of a computerized IR spectral library matched the spectrum of the middle layer to a urethane alkyd, as shown in Figure 4.28. Figure 4.28 shows what a spectral search routine does-it picks a series of possible "fits" to the unknown



	Index	Match	Compound Name	Library Name
1	175	77.00	Urethane alkyd	HR Hummel Polymer and Additives
2	1767	76.48	PENTAERYTHRITOL MONORICINOLEATE #2	HR Polymer Additives and Plasticizers -
3	1768	76.16	PENTAERYTHRITOL TETRARICINOLEATE	HR Polymer Additives and Plasticizers
4	1597	75.35	PROPYLENE GLYCOL MONOOLEATE	HR Polymer Additives and Plasticizers
5	1769	74.91	PROPYLENE GLYCOL MONORICINOLEATE	HR Polymer Additives and Plasticizers

FIGURE 4.28 The results of a library search of the spectrum from the middle layer of the laminate. The top spectrum is that collected from the sample; the bottom spectrum, urethane alkyd, is the best match found in the search of a polymer database. Other possible compounds are suggested by the search routine and listed in the box below the spectra. Note the match number—the higher the number, the better the agreement between the sample spectrum and the library spectrum. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

from its database and assigns a goodness-of-fit or match number. In this case, the urethane alkyd spectrum has the highest match number, 77, of the spectra in this database.

In forensic science, FTIR microscopy has been used extensively. Rapid chemical imaging of documents and paper currency allows an analyst to distinguish between various inks and the paper itself using ATR mode, which minimizes absorption from cellulose, enabling identification of counterfeit currency. In addition, modern currency often has small security fibers in the paper. These can be visually identified and chemically imaged to confirm authenticity. FTIR microscopy is used to examine paint chips from automobile accidents. An example of a paint chip spectrum is shown in Figure 4.29. The spectral region below 1000 cm⁻¹ is where pigments absorb. Hit-and-run drivers frequently leave traces of paint on cars, structures, and victims with which they collide. Identification of the paint can help to identify the car. Both transmission and ATR sampling can be used in conjunction with optical microscopy and FTIR imaging. A typical paint chip will have layers of coatings, base coat and binder, as well as possibly the substrate (plastic, fiberglass). In a real case, a jogger was intentionally struck by a car and killed. The driver of the car was convicted of murder based on the FTIR microscopy data from a tiny paint chip found on the victim's clothing. The tiny sample from




FIGURE 4.29 (a) Transmission spectrum of a blue paint chip from an American car measured using a miniature diamond anvil cell. (b) Comparison of microscopic paint chips taken from a crowbar and compared to paint from a window at the site of a Burglary. (© 2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

the victim and a sample of paint from the car were mounted in paraffin and cross-sectioned with a microtome. IR spectra were collected from five layers in each paint sample. Based on the data, the paints were shown to be identical.

Other uses of an IR microscope in forensic analysis include the examination of fibers, drugs, and traces of explosives. For example, oxidation of hair can occur chemically or by sunlight; oxidation of cystine to cysteic acid can be seen in hair fibers by FT-IR microscopy (Robotham and Izzia). Excellent examples in full color of FTIR imaging microscopy can be found on the websites of companies like PerkinElmer and Thermo Fisher Scientific. A novel IR microscope combined with atomic force microscopy, the nanoIR[™] platform from Anasys Instruments (www.anasysinstruments.com) permits nanoscale IR spectroscopy, AFM topography, nanoscale thermal analysis and mechanical testing.

IR microscopy is used in the characterization of pharmaceuticals, catalysts, minerals, gemstones, adhesives, composites, processed metal surfaces, semiconductor materials, fossils, and artwork. Biological samples such as plant leaves and stems, animal tissue, cells, and similar samples can be imaged. Frequently, such information cannot be obtained by any other means. A microscope that combines both IR and Raman measurements will be discussed in the section on Raman spectroscopy.

4.5 NONDISPERSIVE IR SYSTEMS

In industry, it is often necessary to monitor the quality of a product on a continuous basis to make certain the product meets its specifications. This on-line, real-time approach to analysis is called **process analysis**. IR spectroscopy is often the method of choice for process monitoring of organic chemical, polymer, and gas production. It is usually not feasible to use laboratory IR instruments under production conditions because they are too delicate, too big, and too expensive. Nondispersive systems have therefore been developed that are much sturdier and can be left running continuously. Many nondispersive systems have been designed for the NIR region. These will be discussed in Section 4.7. The mid-IR region is used mainly for monitoring gas streams.

Nondispersive IR spectrometers may use filters for analysis of gaseous substances. Each filter is designed to measure a specific compound. Figure 4.30(a) presents a commercial filter




FIGURE 4.30 (a) Schematic of a two-filter wheel, multiwavelength filter photometer. (From Coates, used with permission.) (b) Schematic of a positive-filter nondispersive IR system.

photometer for the mid-IR region with a filter wheel containing multiple narrow bandpass filters. The compound measured is selected by turning the wheel to put the proper filter in the light path. Other photometers have been designed for dedicated measurement of a single gaseous species. A schematic diagram of such a dedicated nondispersive IR instrument is shown in Figure 4.30(b). The system consists essentially of the radiation source and two mirrors that reflect two beams of light, which pass through the sample and reference cells, respectively, to two detectors. These detectors are transducers and each contains the gas phase of the compound being determined. The detector is therefore selective for the compound. For example, imagine that the two detectors are filled with gas phase carbon tetrachloride. If there is no carbon tetrachloride vapor in the sample cell, detectors A and B will absorb the IR radiation equally and consequently their temperatures will increase. The temperature difference between the two detectors is measured and is at a minimum when there is no sample in the light path. When carbon tetrachloride vapor is introduced into the sample cell, it absorbs radiation. The light falling on detector A is therefore decreased in intensity and the temperature of the detector decreases. The temperature difference $T_2 - T_1$ between the two detectors increases. As the concentration of sample increases, the temperature of detector A decreases and $T_2 - T_1$ increases. The relationship between $T_2 - T_1$ and sample concentration is positive in slope. The reference cell may be a sealed cell containing N2 gas, which does not absorb in the IR, or a flow-through cell that is purged with a non-absorbing gas. Clearly, the system can be made specific for any IR-absorbing gas by putting that vapor in the detectors. The response of the system is usually better if the light beams are chopped, and it is common to chop the light as it leaves the source so that the sample and reference beams are chopped equally. This provides an ac signal that helps correct for changes in room temperature during operation, instrument drift, and other types of noise in the system.

A problem may be encountered if an interfering material is present in the sample (that is, it absorption bands overlapping those of the sample). This will result in a direct interference in the measurement. The problem can be overcome by placing a cell containing a pure sample of the interfering material in the sample arm. In this fashion, all the absorbable radiation at a common wavelength is absorbed and this eliminates any variation in absorption due to the impurity in the sample because all the light at this wavelength has been removed.

Nondispersive IR systems are good for measuring concentrations of specific compounds under industrial and other similar circumstances. As can be readily understood, they are not generally used as research instruments and do not have scanning capabilities. However, they are robust and can be used for the continuous monitoring of specific compounds. Nondispersive systems are very common in NIR applications, as discussed in Section 4.7.

4.6 ANALYTICAL APPLICATIONS OF IR SPECTROSCOPY

The two most important analytical applications of IR spectroscopy are the qualitative and quantitative analyses of organic compounds and mixtures. We pointed out at the beginning of this chapter that the frequencies of radiation absorbed by a given molecule are characteristic of the molecule. Since different molecules have different IR spectra that depend on the structure and mass of the component atoms, it is possible, by matching the absorption spectra of unknown samples with the IR spectra of known compounds, to identify the unknown molecule. Moreover, functional groups, such as -CH₃, -C=O, -NH₂, and -OH, act almost as separate groups and have characteristic absorption frequencies relatively independent of the rest of the molecule they are part of. This enables us to identify many of the functional groups that are important in organic chemistry, and provides the basis for qualitative structural identification by IR spectroscopy. By examining the absorption spectra of an unknown sample and comparing the bands seen with the characteristic absorption frequencies of known functional groups, it is possible to classify the sample as, say, a ketone or a carboxylic acid very quickly, even if it is not possible to identify the compound exactly. In some cases, the structure of an unknown can be deduced from its IR spectrum, but this requires much practice and is not always possible, even for an expert. Computerized libraries of spectra are now commonly used to identify compounds from their IR spectra. In addition to identifying a molecule, or its functional groups, we can acquire information about structural and geometrical isomers from IR spectroscopy. IR spectroscopy has been coupled to chromatography to identify separated compounds and to thermogravimetric analyzers to identify compounds or degradation products that volatilize as a sample is heated.

We can measure the extent of absorption at a specific frequency for an analyte of known concentration. If now we were to measure the extent of absorption at the same frequency by a sample solution of unknown concentration, the results could be compared. We could determine the sample's concentration using Beer's Law. Thus, as a *quantitative tool*, IR spectroscopy enables us to measure the concentration of analytes in samples.

The introduction and widespread use of FTIR has resulted in considerable extension of the uses of IR in analytical chemistry. With regard to wavelength assignment, speed of analysis, and sensitivity, FTIR has opened new fields of endeavor. Some of these uses are described.

Typical analyses include the detection and determination of paraffins, aromatics, olefins, acetylenes, aldehydes, ketones, carboxylic acids, phenols, esters, ethers, amines, sulfur compounds, halides, and so on. From the IR spectrum, it is possible to distinguish one polymer from another, or determine the composition of mixed polymers, or identify the solvents in paints. Atmospheric pollutants can be identified while still in the atmosphere. Another interesting application is the examination of old paintings and artifacts. It is possible to identify the varnish used on the painting and the textile comprising the canvas, as well as the pigments in the paint. From this information, fake "masterpieces" can be detected. Modern paints and textiles use materials that were not available when many masterpieces were painted. The presence of modern paints or modern synthetic fabrics confirms that the painting must have been done recently. In a similar manner, real antiques can be distinguished from modern imitations.

Forensic science makes use of infrared spectroscopy and IR microscopy, not only for paint analysis but for analysis of controlled substances. IR can be used to detect the active compounds in hallucinogenic mushrooms, for example. IR is often used to confirm the identity of controlled substances such as cocaine. It has the advantage of being able to differentiate isomers that cannot be distinguished by mass spectrometry, e.g., ephedrine and pseudoephedrine.

In industry, IR spectroscopy has important uses. It is used to determine impurities in raw materials. This is necessary to ensure good products. It can be used for quality control by checking the composition of the product, either in batch mode or continuously (on-line or process analysis). On-line IR analyzers can be used to control the process in real time, a very cost-effective way of ensuring quality. IR spectroscopy is used in the identification of new materials made in industrial research laboratories and in the analysis of materials made or used by competitors (a process called "reverse engineering"). New hand-held portable FTIR systems are available, and can be used in manufacturing plants to identify incoming raw materials and finished products on site, to identify coatings (composition, thickness, homogeneity), in the field to identify minerals, to characterize materials, to evaluate surface cleanliness, and to determine cure times for polymer coatings in real time. A handheld instrument can evaluate pieces too large or too valuable to be analyzed in a laboratory setting. The hand-held instrument in Figure 4.31, Agilent Technologies, Inc. 4100 ExoScan FTIR, a Michelson interferometer system, weighs 7 lbs, is battery powered, has both diffuse reflectance and single-reflection diamond ATR sampling heads, a DTGS detector, covers the 4000-650 cm⁻¹ range, and is water resistant, shock and vibration resistant and can operate from 32-120 °F (0-50 °C).

4.6.1 QUALITATIVE ANALYSES AND STRUCTURAL DETERMINATION BY MID-IR ABSORPTION SPECTROSCOPY

Qualitative analysis of unknown samples is a major part of the work of an analytical chemist. Since it is better to give no answer than an incorrect answer, most analytical chemists perform qualitative analysis using an array of techniques that overlap and confirm each other, providing in the sum more information than could be obtained with the separate individual





FIGURE 4.31 The Agilent 4100 ExoScan FTIR, used **(a)** to characterize minerals in the field and **(b)** to evaluate rubber tire condition in real time. (©2018 Agilent Technologies, Inc., [www.agilent.com/chem. Used with permission.)

methods. For qualitative analysis of an unknown organic compound, the most commonly used spectroscopic methods are: IR spectroscopy to see which functional groups are present; NMR to indicate the relative positions of atoms in the molecule and the number of these atoms; and MS to provide the molecular weight of the unknown and additional structural information. UV spectroscopy was used in the past to study unsaturated or substituted compounds; it has been almost entirely replaced for qualitative structural information by NMR and MS, which are commonly available in undergraduate chemistry labs. Each technique provides an abundance of valuable information on molecular structure, but a combination of methods is used to ensure more reliable identification. In addition to spectroscopy, real

samples may be submitted to chromatography to determine if the unknown is a pure substance or a mixture, to determine the number of compounds present, and to separate and purify the compound of interest.

The value to qualitative analysis of prior knowledge about the sample cannot be overemphasized. Before trying to interpret an IR spectrum, it is important to find out as much as possible about the sample. For example, to identify the products of an organic reaction, it is very valuable to have information about the materials that were present before the reaction started, the compounds the reaction was expected to produce, the possible degradation products that may come about after the reaction, and so on. Armed with as much of this information as possible, we may be able to identify the molecules in the sample from their IR spectra.

The general technique for qualitative analysis is based on the characteristics of molecular structure and behavior mentioned at the beginning of the chapter. That is, the frequency of vibration of different parts of a molecule depends on the weight of the vibrating atoms (or groups) and the bond strength. Many groups can be treated as isolated harmonic oscillators and their vibrational frequencies calculated. More commonly, vibrational frequencies for functional groups are identified by the collection of spectra from hundreds of different compounds containing the desired functional group. These characteristic group vibrational frequencies are tabulated in correlation tables or correlation charts. Table 4.2 is a short list of functional groups and their relevant vibrational frequencies. A comprehensive collection of correlation charts and tables is provided in the book by Bruno and Svoronos. Since the absorption frequency is the same as the vibration frequency, the presence of absorption at a given frequency is an indication that the functional group may be present. Very detailed tables are found in the references listed in the bibliography by Silverstein and Webster, Pavia et al., Lambert et al., Colthup et al., Dean, Robinson, and in the CRC Handbook of Chemistry and Physics.

Qualitative analysis is carried out by matching the wavelengths of the absorption bands in the spectrum of the sample with the wavelengths of functional groups listed in a correlation table. Before a positive identification can be made, all the absorption bands typical of the functional group must be observed. More importantly, the lack of an absorption band where one should be can be used to rule out certain functional groups. For example, if there is no strong absorption at about 1700 cm^{-1} due to the C=O stretch in a pure unknown compound, we can state with certainty that the compound does not contain a C=O group and therefore is not a ketone, aldehyde, amide, ester, or carboxylic acid.

Because the IR spectrum of each compound is unique, matching the IR spectrum of an unknown peak for peak to a reference spectrum of a known material is a very good way to identify the unknown. This is often done with the aid of computerized spectral libraries and search routines, as we saw for the polymer laminate (Figure 4.28). A number of companies, instrument manufacturers, government agencies, and other sources publish collections of reference spectra in electronic format and in hardcopy. These spectral databases may contain spectra of more than 200,000 compounds, with subsets of the database available for specific fields of endeavor, such as environmental chemistry, pharmaceuticals, polymers, and forensic science. The unknown spectrum or some predetermined number of the strongest absorption bands from the unknown spectrum may be entered into a computerized search routine, which compares the unknown with stored spectra. It then retrieves all compounds from the database that may match the unknown spectrum, assigning a goodness-of-fit or probability to the suggested matches. The analyst then identifies the spectrum of the unknown based on spectral matching and chemical knowledge of the sample to rule out improbable compounds suggested by the search routine. A short list of reference spectra suppliers is given in Appendix 4. Most large spectral databases are expensive to buy. Many small companies or individuals can now access these by a "pay for what you use" approach. The KnowItAllTM system from the Informatics Division, Bio-Rad Laboratories (www.bio-rad.com) and the FTIR/ Raman system from Thermo Fisher Scientific (www.ftirsearch.com) are two examples of this very new and cost-effective approach to spectral matching. In addition, there are some free databases that allow the user to view spectra of known compounds. These sources include FTIR and FTNMR spectra from Sigma-Aldrich (www.sigma-aldrich.com), gas-phase IR

spectra from NIST in the US (www.nist.gov), and a comprehensive spectral database, including IR spectra, from the Japanese National Institute of Advanced Industrial Science and Technology (www.aist.go.jp/RIOBD/SDBS/menu-e.html). If a database or spectral library is not available or the spectra do not match exactly, the analyst must try to identify the compound from its spectrum. Even when electronic databases are available, it is useful for the analyst to understand how to look at and interpret an IR spectrum. For detailed basic IR spectral interpretation, the texts by Colthup et al., Pavia et al., Lambert et al., or Silverstein and Webster should be consulted.

Before trying to interpret an IR spectrum, there are some things the analyst should note. The method of collecting the spectrum should be stated—mull, thin film, KBr pellet, solution, and the solvent-because the appearance of the spectrum may change as has been discussed earlier. The analyst should compare reference spectra collected under the same conditions when possible. Older spectra were printed with the spectrum displayed linear in wavelength (on the x-axis); FTIR spectra are generally plotted linear in wavenumber. The two plots look very different for the same spectrum; for example, bands will appear to have expanded or contracted depending on their position in the spectrum. It is important that the analyst pay attention to the scale when comparing spectra from the older literature. It should also be noted that in grating IR spectra, the scaling changes at 5 μ m. The γ -axis units should also be noted. Until recently, the y-axis for IR absorption spectra was "Transmittance" or "% Transmittance", with 100 %T at the top of the spectrum. Transmittance is the ratio of radiant power transmitted by the sample to the radiant power incident on the sample, P/P_0 or I/I_0 . 100 %T is the transmittance multiplied by 100. Transmittance ranges from 0 to 1.0; %T ranges from 0 to 100. The absorption peaks therefore are pointing toward the bottom of the spectrum as printed. The y-axis could be given in Absorbance (A), where A is defined as = $-\log T$. If 0.00 Absorbance is at the top of the y-axis, the spectrum is similar to the standard %T plot, but the contrast between strong and weak bands is not as good because A ranges from infinity to 0. However, it is becoming more common to see IR spectra plotted with A on the y-axis and with 0.00 A at the bottom of the y-axis, resulting in the peaks pointing up to the top of the plot. This is the inverse of the traditional \(T \) spectrum. One reason for this is that Raman spectra are plotted with peak intensity increasing from bottom to top of the plot; having the complementary IR spectrum in the same format makes comparison easier.

It is highly unlikely that an analyst can identify a complete unknown by its IR spectrum alone without the help of a spectral library database and computerized search. For most molecules, not only the molecular weight obtained by mass spectrometry, but also the elemental composition (empirical formula) from combustion analysis and other classical analysis methods, the mass spectrum, proton and ¹³C NMR spectra, possibly heteroatom NMR spectra (P, Si, and F), the UV spectrum, and other pieces of information may be required for identification. From this data and calculations such as the unsaturation index, likely possible structures can be worked out.

An application of using FTIR to determine the source oil in biodiesel fuel is described from an application note from the PerkinElmer, Inc. website (www.perkinelmer.com). Biodiesel fuel is a renewable fuel produced from a wide range of naturally occurring fats and oils by a transesterification reaction in which the triglycerides are broken down and fatty acid methyl esters (FAMES) are formed. Biodiesel fuel is allowed in fossil fuel up to 5 % in the US and Europe without need for labeling. Concerns include oxidative stability of these fuels on long term storage. The fatty acid distribution in the original oil is retained in the biodiesel fuel, so the physical and chemical properties of the biodiesel fuel have some dependence on the feedstock. One important property particularly influenced by the feedstock is the cloud point, the temperature at which solid crystals start to form, creating a suspension that can block fuel filters. For operation in cool climates, a low cloud point is needed. A sample of palm oil biodiesel fuel may have a cloud point of 15 °C while rapeseed oil may be around –10 °C. FTIR spectra collected using a PerkinElmer*.

Spectrum[™] 100 FT-IR spectrometer with a diamond ATR accessory provided a rapid and simple way to check the provenance of a biodiesel fuel sample using the bands related to the alkene functional groups, e.g., the alkene C=C-H stretch, the C=C stretch, and the CH=CH oop band at about 1400 cm⁻¹. The intensity of the bands increases in the order:

TABLE 4.7 Typica	I Fatty	/ Acid	Distribution	in 3 Oils
------------------	---------	--------	--------------	-----------

Chain	Length	DB	Palm Oil % Chains	Soy % Chains	Rapeseed Oil % Chains
Caprylate	8	0	7	0	0
Caprate	10	0	5	0	0
Laurate	12	0	48	0	0
Myristate	14	0	15	0	1
Palmitate	16	0	7	6	4
Stearate	18	0	3	3	3
Arachidate	20	0	0	3	3
Bhenate	22	0	0	0	3
Lignocerate	24	0	0	0	3
Oleate	18	1	12	35	45
Erucate	22	1	0	0	20
Linoleate	18	2	3	50	15
Linolenate	18	3	0	3	3
Average chain length			13.28	17.94	19.04
Average DBs per chain			0.18	1.44	1.04
DB fraction			1.4 %	8.0 %	5.5 %

Source: ©2020 PerkinElmer, Inc. All rights reserved. Printed with permission. www. perkinelmer.com.

DB = double bond. Fatty acid distribution from www.accustandard.com. The bottom three rows are weighted averages over the distributions for each oil.

palm<rapeseed<soy. Palm oil is more than 60 % saturated, while the other two have high proportions of unsaturated fatty acid chains, as seen in Table 4.7. Consistent with the FTIR data, the ratio of double bonds (DB) to average chain length (a quantity approximately proportional to the volume density of double bonds) increases in the order: palm<rapeseed<soy. Acquiring the spectrum of a biodiesel fuel sample takes only a few seconds and contains readily accessible information about the extent of unsaturation in the fatty acid chains. This information is directly related to both the source oil used and to properties such as the cloud point.

FTIR spectroscopy, as well as Raman spectroscopy, can be used to great advantage in the analysis of gemstones, to detect treatment of gemstones, and to distinguish natural gemstones from synthetic stones. Emeralds are among the most valuable gemstones. They are a type of beryl, composed of aluminum and beryllium silicates with traces of chromium creating the color. There are a number of processes for creating synthetic emeralds, including the hydrothermal process and the flux process. The top spectrum in Figure 4.32 is of a natural emerald (green stone). The next lower spectrum is from a hydrothermally grown synthetic emerald and the library match between the two spectra is quite good. It is obvious from the rest of the spectra that the natural emerald can easily be distinguished from a flux grown synthetic emerald.

4.6.2 QUANTITATIVE ANALYSES BY IR SPECTROMETRY

The quantitative determination of various compounds by mid-IR absorption is based on the measurement of the concentration of one of the functional groups of the analyte compound. For example, if we have a mixture of hexane and hexanol, the hexanol may be determined by measuring the intensity of absorption that takes place near 3300 cm⁻¹ by the OH band. The spectrum of pure hexanol would be used to determine the exact wavenumber corresponding to the absorption maximum. Alternatively, the intensity of absorption due to the $C \rightarrow O$ at about 1100 cm⁻¹ could be used. From this, the concentration of alcohol can be calculated, once the intensity from a set of hexanol standards of known concentrations has been measured at the same wavenumber. Whenever possible, an absorption band unique to the sample




FIGURE 4.32 FTIR spectra of natural and synthetic gemstones. (From Lowry, © Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

molecule should be used for measuring purposes. This reduces the problem of overlapping bands, although there are mathematical approaches for deconvoluting overlapping peaks. The quantitative calculation is based on Beer's Law (Chapter 2).

The intensity of the peak being measured in each sample must be measured from the same baseline. Usually, a straight baseline is drawn from one side of the peak to the other, or across multiple peaks or a given wavenumber range, to correct for sloping background using the computer software. Quantitative measurements are generally made on samples in solution, because scattered radiation results in deviations from Beer's Law. KBr pellets have been used for quantitative work, but the linear working range may be small due to light scatter if the pellets are not well-made. A hydraulic press is recommended for preparation of pellets for quantitative analysis.

Calibration curves are constructed from measurements of intensity of absorption by solution standards at different known concentrations of the analyte (Chapter 1). Quantitative analysis using mid-IR absorption is not as accurate as that using UV or visible absorption. The sample cells for mid-IR absorption have much smaller path lengths than those for UV and must be made with material transparent to IR radiation, such as NaCl or KBr. These materials are very soft and easily etched by traces of water or distorted by clamping the cell together; as a result, the sample path length may vary from one sample to the next. Any change in b between samples or between samples and standards causes an error in the calculation of *c*, the concentration of the analyte. Nonlinear response is a problem, especially at high absorbance. Samples must often be diluted to keep the absorbance below 0.8 for quantitative measurements. FTIR instruments do not suffer from stray or external radiation and they do not have slits, so it might be expected that accurate absorbance measurements can be made on solutions with absorbance values greater than 1.0. However, the detector and the apodization function limit accuracy in FTIR instruments. It is still advisable to stay below 1.0 absorbance units for FTIR quantitative work. An external calibration curve covering the range of concentrations expected in the samples should be used for the best accuracy, instead of relying on a calculation of the proportionality factor from one standard. An example of quantitative analysis by ATR is the determination of water in a polyglycol. The wavelength measured, peak intensities, and Beer's Law plot are displayed in Figure 4.33.




FIGURE 4.33 (a) The IR spectra of a polyglycol with no water present and with 4 % water. The peak marked with an X is the O—H bend at 1640 cm⁻¹ that will be used for quantitation. **(b)** Standards of the polyglycol containing 0.5-8 % water were scanned and the spectra saved. The spectra of the standard solutions were collected from a horizontal attenuated total reflectance (HATR) liquid sample cell using a ZnSe crystal. All spectra were collected on a PerkinElmer paragon 1000 FTIR spectrometer at 8 cm⁻¹ resolution. **(c)** the data from **(b)** were input into the spectrum® Beer's Law quantitative analysis software. The calibration curve is shown. (Spectrum® is a registered trademark of PerkinElmer, inc. All rights reserved.). (Data and spectra courtesy of Pattacini Associates, LLC, Danbury, CT.)

Hydrocarbon contamination from oil, grease, and other sources in drinking water and wastewater is determined quantitatively by extraction of the hydrocarbons and measurement of the CH stretching band. The water is extracted with trichlorotrifluoroethane or other suitable solvent, the IR spectrum of the extracted solution is obtained and the absorbance is measured at 2920 cm⁻¹ after a baseline is drawn as described earlier. A series of standards of known oil diluted in the same solvent is prepared as the external calibration curve. The method can measure as little as 0.2 g oil/L of water, with a precision of about 10 %RSD.

Precisions of 5-10 %RSD are typical for IR measurements. The entire method can be found in Standard Methods for the Examination of Water and Wastewater, listed in the bibliography. A new, rapid solvent-free method for determining hydrocarbon contamination at the ppm to sub-ppm level in 10 mL of sample is ASTM D-7575, which uses an IR-transmitting solid phase membrane that extracts and holds the hydrocarbon as a known amount of water is passed through it. The ClearShot Extractor® from Orono Spectral Solutions, Inc., Bangor, ME, retains any oil and grease from a 10 mL water sample passed through it and then sits in a transmission sample holder in the IR spectrometer. The extractor is disposed of once a spectrum is taken. Calibration is performed using a set of solid-state Calibration Standard Devices (CSDs).

Quantitative analysis of multiple components in a mixture can be done by assuming that Beer's Law is additive for a mixture at a given frequency. For a mixture with two components, the total absorbance of the mixture at a given frequency is the sum of the absorbance of the two components, compound F and compound G, at that frequency.

$$A_{\text{total}} = A_{\text{F}} + A_{\text{G}} = a_{\text{F}}bc_{\text{F}} + a_{\text{G}}bc_{\text{G}}$$

The absorptivity of F, a_F , and the absorptivity of G, a_G , are determined at two different wavenumbers, \overline{v}_1 and \overline{v}_2 from a series of mixtures with known amounts of F and G. This results in four absorptivity values, a_{F1} , a_{F2} , a_{G1} , and a_{G2} ; the symbol for wavenumber is eliminated for simplicity. The concentrations of F and G in an unknown mixture can be calculated from two absorbance measurements at \overline{v}_1 and \overline{v}_2 . Two simultaneous linear equations with two unknowns are constructed and solved for c_F and c_G :

A at
$$\overline{v}_1 = a_{F1}bc_F + a_{G1}bc_G$$

A at $\overline{v}_2 = a_{F2}bc_F + a_{G2}bc_G$

This approach can be used for multicomponent mixtures by applying matrix algebra. This is generally done with a software program and even nonlinear calibrations can be handled with statistical regression methods.

In addition to the quantitative analysis of mixtures, measurement of the intensity of an IR band can be used to determine reaction rates of slow to moderate reactions. The reactant or product has to have a "clean" absorption band and the absorbance-concentration relationship must be determined from calibration standards. The reaction cannot be extremely fast because the band has to be scanned and even FTIR spectrometers are not instantaneous.

Many applications of FTIR spectroscopy and microscopy can be found by searching the websites of major instrument manufacturers.

4.7 NEAR-IR SPECTROSCOPY

The NIR region covers the range from $0.75~\mu m$ (750 nm or $13,000~cm^{-1}$) to about $2.5~\mu m$ (2500 nm or $4000~cm^{-1}$). This is the range from the long-wavelength end of visible light (red) to the short-wavelength side of the mid-IR region. The NIR region bridges the region between molecular vibrational spectroscopy and electronic spectroscopic transitions in the visible region. The bands that occur in this region are generally due to OH, NH, and CH bonds. The bands in this region are primarily overtone and combination bands; these are less intense than the fundamental bands in the mid-IR region. While weaker absorptions and limited functional group information might seem to limit the usefulness of the NIR region, there are some inherent advantages to working in the range. High-intensity sources such as tungstenhalogen lamps give strong, steady radiation over the entire range. Very sensitive detectors, such as lead sulfide photodetectors can be used. These detectors need not be operated in liquid N_2 . The third important advantage is that quartz and fused silica can be used both in optical systems and as sample containers. Fiber optic probes and long path length cells can be used to compensate for the weaker absorptions and can be used to advantage for process analysis applications. The NIR region is used primarily for quantitative analysis of solid and



FIGURE 4.34 Antaris II [™] FT-NIR analyzer, Thermo Scientific, equipped with a fiber optic probe for remote measurement, transmission, and integrating sphere and a tablet analyzer for direct analysis of pharmaceuticals. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

liquid samples for compounds containing OH, NH, and CH bonds, such as water, pharmaceutical compounds, and proteins. Correlation charts for the NIR region can be found in the book by Bruno and Svoronos.

Advantages of NIR include speed, little or no sample preparation, solvents and reagents are rarely needed, high dynamic concentration range and deep sample penetration. NIR obeys the same selection rules as mid-IR. Only molecules which exhibit a dipole moment will absorb NIR radiation.

4.7.1 INSTRUMENTATION

NIR instrumentation is very similar to UV/VIS instrumentation, discussed in Chapters 2 and 5. Quartz and fused silica optics and tungsten-halogen lamps identical to those used in UV/VIS systems may be used. Commercial research grade double-beam dispersive grating spectrometers are available that cover the optical range from the UV (180 or 200 nm) through the visible up to the NIR long wavelength limit of 2500 or 3000 nm. In addition, many customized portable filter-based NIR instruments, FT-NIR instruments, and other designs for dedicated applications are commercially available. Dispersive, non-scanning spectrographs are also used in NIR spectroscopy, with a silicon photodiode array detector. These are used for dedicated applications, such as moisture analyzers. Absorption, transmission, and reflection measurements are made in NIR spectrometry. A modern NIR analyzer with a variety of measurement modes is shown in Figure 4.34.

Quartz optical fibers are transparent to NIR radiation and are often used to interface the sample and spectrometer or spectrograph. The low OH-content quartz fiber used for many NIR applications is single filament, between 100 and 600 μm in diameter. Fibers can be bundled together when it is necessary to collect light over a large area. Fiber optic probes can be used for remote sampling and continuous monitoring of bulk flowing streams of commercial products as well as for simple "dip" probes. This greatly simplifies sample preparation and, in many cases, eliminates it completely. Dilute liquid solutions can be analyzed in the standard 1 cm quartz cuvets used for UV/VIS spectrometry.

4.7.2 NIR VIBRATIONAL BANDS

As seen in Figure 4.35 (a), an absorbance at 3000 cm^{-1} will produce overtone bands at 6000, 9000, and $12,000 \text{ cm}^{-1}$ as well as combination bands. The NIR absorptions are generally not as strong as the fundamental IR band. Figure 4.35(b) shows the IR and NIR spectra of the same compound for comparison.




FIGURE 4.35 (a) Schematic representation of the overtones and combinations from a 3000 cm⁻¹ fundamental band, together with the NIR spectrum. (b) NIR and IR spectra of the same compound with the bands marked. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

The primary absorption bands seen in the NIR region are:

C—H bands between 2100 and 2450 nm and between 1600 and 1800 nm

N—H bands between 1450 and 1550 nm and between 2800 and 3000 nm

O-H bands between 1390 and 1450 nm and between 2700 and 2900 nm

Bands for S—H, P—H, C \equiv N, and C=O also appear in the NIR region. Water has several distinct absorption peaks at 1400, 1890, 2700, and 2750 nm. These bands enable the determination of hydrocarbons, amines, polymers, fatty acids, proteins, water, and other compounds in a wide variety of materials.

There is some correlation between molecular structure and band position for certain bands, but because these are often overtone and combination bands, their positions are not as structure-dependent as the fundamental bands in the mid-IR. For example, primary amines, both aliphatic and aromatic, have two absorption bands, one at about 1500 nm and the second at about 1990 nm. Secondary amines have only one band at about 1500 nm. As expected, a tertiary amine has no NH band. Amides with an —NH₂ group can be distinguished from R—NH—R' amides by the number and position of the N—H bands. The reference by Goddu has a detailed table of NIR structure—wavelength correlations.

The molecular absorption coefficients (molar absorptivities) for NIR bands are up to three orders of magnitude lower than the fundamental bands in the mid-IR. This results in reduced sensitivity. Greater sample thickness can be used to compensate for this, giving more representative results with less interference from trace contaminants. Sample pathlengths of 0.1 mm-10 cm are common.

4.7.3 NIR CALIBRATION: CHEMOMETRICS

NIR analysts often use a statistical methodology called **chemometrics** to "calibrate" an NIR analysis. Chemometrics is a specialized branch of mathematical analysis that uses statistical algorithms to predict the identity and concentration of materials. Chemometrics is heavily used in NIR spectral analysis to provide quantitative and qualitative information about a variety of pure substances and mixtures. NIR spectra are often the result of complex, convoluted, and even unknown interactions of the different molecules and their environment. As a result, it is difficult to pick out a spectral peak or set of peaks that behave linearly with concentration or are definitive identifiable markers of particular chemical structures. Chemometrics uses statistical algorithms to pick out complex relationships between a set of spectra and the material's composition, and then uses the relationship to predict the composition of new materials. Essentially, the NIR system, computer, and associated software are "trained" to relate spectral variation to identity and then apply that training to new examples of the material.

This inherently requires a good training set of standards to ensure accurate prediction of the identity or concentrations of new examples of the material. An adequate training set that has enough examples and describes the variation expected from test samples is critical for effective chemometric modeling. The concentrations and identity of the standards must first be confirmed by some other primary means, such as chromatography, gravimetric analysis, titration, and so on. This information is entered as part of the training set for development of the chemometric model. For example, if an NIR method is being developed to measure primary amines, it may be necessary to actually measure the standards (or samples that will then be used as standards) by a method such as the Kjeldahl titration method. The quantitative nitrogen results from the titration method are used as the concentrations for the training set. Once the standards have been analyzed and the chemometric model developed, it can be employed to automatically predict the identity and composition of new samples. When a model has been completed and validated, it may be used for long periods of time and transferred to other NIR instruments.

There are a variety of chemometric models for both qualitative and quantitative analysis. A common quantitative model is called Partial Least Squares (or Projection to Latent Structure), PLS. PLS condenses the thousands of individual data points across the whole spectrum in all of the standards to a few sources of variation that contrast broad bands of frequencies. These condensed sources of variation are called **factors** and are selected as part of the model in order of importance in accounting for the variation. The first factor of a good model will account for a large part of the variation and subsequent factors will account for the remaining variation. In practice, only a limited number of factors is required to account for most of the variation.

A practical example of the chemometrics approach is described in the reference by Heil. In order to develop a PLS calibration model for moisture, oil, protein, and linolenic acid in soybeans, a total of 207 calibration and 50 validation samples were used to build and validate the calibration model described in Heil's paper. While this may seem like a lot of work,

64 co-averaged scans were collected using a Thermo Scientific AntarisTM II FT-NIR instrument in 30 seconds with a resolution of 8 cm⁻¹. No processing or grinding of the raw soybeans was required, and once the method is validated, no additional calibration is required. The wet chemical methods to measure these four parameters would require grinding, digestion, extraction, and multiple analytical techniques.

4.7.4 SAMPLING TECHNIQUES FOR NIR SPECTROSCOPY

NIR spectroscopy has a real advantage over many spectroscopic techniques in that many plastic and glass materials are transparent to NIR radiation at the common thicknesses encountered for films, packaging materials, and coatings. It is practical to take an NIR spectrum of a sample without even opening the sample container in many cases; the spectrum is collected through the plastic or glass bottle or through the plastic film on food or the plastic bubble packs used for pharmaceutical tablets. In many cases, no sample preparation is required at all. When diffuse reflectance measurements are made, not only is no sample preparation required, but the method is also nondestructive, as Figure 4.36 shows.




FIGURE 4.36 (a) NIR measurement directly through a plastic bag. (b) NIR measurement through a glass vial. Both require no sample preparation. Instrument shown is a Thermo Scientific AntarisTM II FT-NIR analyzer equipped with an integrating sphere and a remote NIR probe, shown on the side of the instrument. (c) The integrating sphere (schematic) the bag or glass vial is placed on top of the instrument (at the top of the schematic). (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

4.7.4.1 LIQUIDS AND SOLUTIONS

With a fiber optic dip probe, many liquids and solutions can be analyzed with no sample preparation. One such sampling accessory for most commercial spectrometers is the FlexIR NIR Fiber Optic accessory (Pike Technologies, www.piketech.com). The wand tip is inserted into the liquid sample and the spectrum collected. The FlexIR NIR probe is directly coupled to an integrated indium gallium arsenide (InGaAs) detector to eliminate energy loss due to transfer optics and beam divergence. The use of a dip probe for transmission measurements requires that the liquid or solution be free from small particles or turbidity. Suspended particles scatter light and reduce the sensitivity of the measurement. The already low absorptivity of NIR bands makes transmission measurements of limited use for liquid samples that are not clear.

There are a number of solvents that can be used to prepare solutions for NIR measurements. Carbon tetrachloride and carbon disulfide are transparent over the entire NIR range. Many other organic solvents are transparent up to 2200 nm, with only a short region between 1700 and 1800 nm obscured by the solvent. Solvents as varied as acetonitrile, hexane, dimethyl sulfoxide (DMSO), and dibutyl ether fit into this category. Methylene chloride and chloroform can be used up to 2600 nm, with short "gaps" at about 1700 and 2300 nm.

Liquids, gels, and solutions can be poured into cuvets for transmission measurements in either a scanning NIR instrument or an FT-NIR instrument. Modern FT-NIR transmission instruments permit the analysis of liquid samples in the cylindrical sample vials used for liquid chromatography (LC or HPLC, discussed in Chapter 13). For example, the 7 mm disposable glass vials used for LC can be used for transmission NIR measurements. Pharmaceutical laboratories often need to collect the NIR spectrum as well as performing HPLC or HPLC-MS on samples. The ability to fill one type of sample vial and use it for multiple measurements is very valuable. It increases sample throughput by eliminating transfer of samples to multiple sample holders and by eliminating washing of sample cells or cuvets. It also conserves sample, decreases waste, and saves money.

4.7.4.2 SOLIDS

For reflectance measurements, most solids require no sample preparation. Powders, tablets, textiles, solid "chunks" of material, food, and many other solids are analyzed "as is". Samples can be analyzed through plastic bags, glass vials, or in sample cups (see Figure 4.36). Examples will be discussed in the applications section. NIR reflectance spectra of solids are often plotted as the second derivative of the spectrum. This format shows small differences between samples more clearly and eliminates scatter and slope in the baseline. An example of this is seen is Figure 4.37.

Polymer films can be measured in either reflectance or transmission mode. For transmission, the film may be taped across an IR transmission card or cardboard slide mount.


Remote analysis of solids is possible through the use of fiber optic probes such as the FlexIR NIR fiber optic accessory described in the previous section. The probe tip is simple touched to the sample, in drums or through packaging, and the spectrum collected. This eliminates sample preparation, speeds up analyses and minimizes exposure of the analyst to large amounts of materials.


4.7.4.3 GASES

Gas samples are handled by filling the same type of gas cell used for mid-IR gas analysis, except that the cell windows are of quartz instead of salt.

4.7.5 APPLICATIONS OF NIR SPECTROSCOPY

The most important bands are overtones or combinations of the stretching modes of C—H, O—H, and N—H. These bands enable the quantitative characterization of polymers, chemicals, foods, and agricultural products for analytes such as water, fatty acids, proteins, and the like. In many cases, the use of NIR reflectance spectroscopy has been able to replace





-0.0025 -0.0030

(b)

FIGURE 4.37 (a) NIR spectra of 14 samples of nitrocellulose solutions differing in concentration, with the region around 5200 cm⁻¹ expanded in the inset (upper right) clearly showing the intensity difference due to compositional variation. **(b)** The derivative spectra of the 5200 cm⁻¹ region, showing an improvement in peak shape (more nearly gaussian) and elimination of the baseline shift on the low wavenumber side seen in the inset in **(a)**. **(c)** Comparison of the chemometrics-based calculated results versus the actual concentrations. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

time consuming, classical "wet" chemical analyses, such as the Kjeldahl method for protein nitrogen and the Karl Fischer titration for water content. The NIR region has been used for qualitative studies of hydrogen bonding, complexation in organometallic compounds, and solute-solvent interactions because the NIR absorptions are sensitive to intermolecular forces.

Polymer characterization is an important use of NIR spectrometry. Polymers can be made either from a single monomer, as is polyethylene, or from mixtures of monomers, as are styrene—butadiene rubber from styrene and butadiene and nylon 6-6, made from hexamethylenediamine and adipic acid. An important parameter of such copolymers is the relative amount of each present. This can be determined by NIR for polymers with the appropriate functional groups. Styrene content in a styrene-butadiene copolymer can be measured using the aromatic and aliphatic C—H bands. Nylon can be characterized by the NH band from the amine monomer and the C=O band from the carboxylic acid monomer. Nitrogencontaining polymers such as nylons, polyurethanes, and urea formaldehyde resins can be measured by using the NH bands. Block copolymers, which are typically made of a "soft block" of polyester and a "hard block" containing aromatics, as is polystyrene, have been analyzed by NIR. These analyses have utilized the C=O, aromatic and aliphatic C=O bands. NIR is used to measured hydroxyl content in polymers with alcohol functional groups (polyols), both in final product and online for process control.

Fibers and textiles are well suited to NIR reflectance analysis. Analyses include identifying the type of fiber, the uptake of dyes, the presence of processing oil in polyester yarns, and the presence of fabric "sizing" agents.

Proteins in foods can be measured by NIR reflectance spectrometry with no sample preparation. This has replaced the standard Kjeldahl protein nitrogen determination, which required extensive sample preparation to convert protein nitrogen to ammonia, distillation of the released ammonia, and subsequent titration of the ammonia. The replacement of the Kjeldahl method for routine analysis by NIR has permitted online measurement of protein in food and beverage products. The Kjeldahl method is required for assaying the materials used to calibrate the NIR and for method validation.

The determination of ppm amounts of water in many chemicals is critical. Organic solvents used for organic synthesis may have to be very dry so that traces of water do not interfere with the desired reaction, for example. The classic method for measuring water at low levels in organic solvents and other chemicals is the Karl Fischer titration, procedure requiring specialized reagents that are commercially available, and carful calibration. Using the O—H bands characteristic of water, NIR has been used to measure water quantitatively in materials from organic solvents to concentrated mineral acids.

The use of NIR for process analysis and real-time analysis of complex samples is impressive. Grains such as wheat and corn can be measured with no sample preparation for protein content, water content, starch, lipids, and other components. In the reference by Heil, whole soybean samples were analyzed for water, protein, fatty acid, and oil by placing whole beans in a 12 cm Sample Cup Spinner accessory (Thermo Scientific) combined with the integrating sphere in the FT-NIR for diffuse reflection measurements. Spinning the sample allows average, representative spectra to be collected from a bulk sample. Measurement of the four parameters permit NIR to perform multiple steps in the processing of soybeans, from grading of incoming soybeans, monitoring extraction efficiency, to ensuring the correct protein content of final product such as soy protein concentrate.

An NIR spectrometer is now commercially available on grain harvesting machines to measure protein, moisture, and oil as the grain is being harvested (von Rosenburg et al.). The analysis is performed in real-time, as the farmer is driving around the field harvesting the grain. The data is coupled with a global positioning unit on the harvester, resulting in a map of the farmer's field, showing the quality of the grain harvested from different points in the field. This gives the farmer important information about where more fertilizer or water is needed. The real-time field analyzer gives excellent accuracy and precision, as shown by comparison to standard laboratory analyses.

Pharmaceutical tablets packaged in plastic "blister packs" can be analyzed nondestructively by NIR spectrometry right through the package. In the quality control laboratory, this permits rapid verification of product quality without loss of product. In forensic analysis,

unknown white powders in plastic bags seized as evidence in a drug raid can be identified by obtaining the NIR spectrum nondestructively right through the bag, eliminating the need to open the bag. This avoids possible contamination or spillage of the evidence and eliminates exposure of the officer and analyst to possibly hazardous materials.

The cost savings provided by the use of NIR instead of titrations for water and protein are enormous, not just in labor cost savings but in the cost of buying and then properly disposing of expensive reagents. NIR permits increased efficiency and increased product quality by online and at-line rapid analysis in the agricultural, pharmaceutical, polymer, specialty chemicals, and textile industries, among others.

4.8 RAMAN SPECTROSCOPY

Raman spectroscopy is a powerful, non-invasive technique for studying molecular vibrations by light scattering. Raman spectroscopy complements IR absorption spectroscopy because some vibrations do not result in absorptions in the IR region. A vibration is only seen in the IR spectrum if there is a change in the dipole moment during the vibration. For a vibration to be seen in the Raman spectrum, a change in *polarizability* is necessary. That is, a distortion of the electron cloud around the vibrating atoms is required. Distortion becomes easier as a bond lengthens and harder as a bond shortens, so the polarizability changes as the bound atoms vibrate. Homonuclear diatomic molecules such as Cl_2 do not absorb IR radiation, because they have no dipole moment. The Cl—Cl stretching vibration is said to be *IR-inactive*. Homonuclear diatomic molecules do change polarizability when the bond stretches, so the Cl—Cl stretch is seen in Raman spectroscopy. The Cl—Cl stretching vibration is said to be *Raman-active*. Some molecular vibrations are active in IR and not in Raman, and vice versa; many modes in most molecules are active in both IR and Raman. Looking at CO_2 again, shown below, the mode on the left is the IR-inactive symmetric stretch, while the other two asymmetric vibrations are both IR-active. The symmetric stretch is Raman-active.

$$O = C = O$$
 $O = C = O$ $O = C = O$

In general, symmetric vibrations give rise to intense Raman lines; non-symmetric ones are usually weak and sometimes unobserved.

Raman spectroscopy offers some major advantages in comparison to other analytical techniques. Because it is a light scattering technique, there are few concerns with sample thickness and little interference from ambient atmosphere. Therefore, there is no need for high vacuum systems or instrument purge gas. Glass, water, and plastic packaging have weak Raman spectra, allowing samples to be measured directly inside a bottle or package, thereby minimizing sample contamination. Aqueous samples are readily analyzed. No two compounds give exactly the same Raman spectra and the intensity of the scattered light is proportional to the amount of material present. Raman spectroscopy is therefore a qualitative and quantitative technique.

4.8.1 PRINCIPLES OF RAMAN SCATTERING

When radiation from a source is passed through a sample, some of the radiation is scattered by the molecules present. For simplicity, it is best to use radiation of only one frequency and the sample should not absorb that frequency. The beam of radiation is merely dispersed in space. Three types of scattering occur: they are called *Rayleigh scattering, Stokes scattering*, and *anti-Stokes scattering*. Most of the scattered radiation has the same frequency as the source radiation. This is Rayleigh scattering, named after Lord Rayleigh, who spent many years studying light scattering. Rayleigh scattering occurs as a result of elastic collisions between the photons and the molecules in the sample; no energy is lost on collision. However, if the scattered radiation is studied closely, it can be observed that slight interaction of the incident beam with the molecules occurs. Some of the photons are scattered with

less energy after their interaction with molecules and some photons are scattered with more energy. These spectral lines are called *Raman lines*, after Sir C. V. Raman, who first observed them in 1928. Only about 1 photon in a million will scatter with a shift in wavelength. The Raman Stokes lines are from those photons scattered with less energy than the incident radiation; the Raman anti-Stokes lines are from the photons scattered with more energy. The slight shifts in energy and therefore slight shifts in the frequencies of these scattered photons are caused by inelastic collisions with molecules. The differences in the energies of the scattered photons from the incident photons have been found to correspond to vibrational transitions. Therefore, the molecules can be considered to have been excited to higher vibrational states, as in IR spectroscopy, but by a very different mechanism. Figure 4.38 shows a schematic diagram of the Rayleigh and Raman scattering processes and of the IR absorption process.

The energy of the source photons is given by the familiar expression E = hv. If a photon collides with a molecule, the molecule increases in energy by the amount hv. This process is not quantized, unlike absorption of a photon. The molecule can be thought of as existing in an imaginary state, called a virtual state, with an energy level between the ground state and the first excited electronic state. The energies of two of these virtual states are shown as dotted lines in Figure 4.38. The two leftmost arrows depict increases in energy through collision for a molecule in the ground state and a molecule in the 1st excited vibrational state, respectively. The arrows are of the same length, indicating that the interacting photons have the same energy. If the molecule releases the absorbed energy, the scattered photons have the same energy as the source photons. These are the Rayleigh scattered photons, shown by the two middle arrows. The molecules have returned to the same states they started from, one to the ground vibrational state and the other to the first excited vibrational state. The arrows are the same length; therefore, the scattered photons are of the same energy.

If the molecule begins to vibrate with more energy after interaction with the photon, that energy must come from the photon. Therefore, the scattered photon must decrease in energy by the amount equal to the vibrational energy gained by the molecule. That process is shown by the second arrow from the right. Instead of returning to the ground vibrational state, the




FIGURE 4.38 The process of Rayleigh and Raman scattering. Two virtual states are shown, one of higher energy. Rayleigh and Raman scattering are shown from each state. Normal IR absorption is shown by the small arrow on the far right marked ΔE , indicating a transition from the ground state vibrational level to the first excited vibrational level within the ground electronic state.

molecule is now in the first excited vibrational state. The energy of the scattered photon is $E-\Delta E$, where ΔE is the difference in energy between the ground and first excited vibrational states. This is Raman scattering, and the lower energy scattered photon gives rise to one of the Stokes lines. Note that ΔE is equal to the frequency of an IR vibration; if this vibration were IR-active, there would be a peak in the IR spectrum at a frequency equal to ΔE . In general, the Raman Stokes lines have energies equal to $E-\Delta E$, where ΔE represents the various possible vibrational energy changes of the molecule. This relationship can be expressed as:

$$(4.12) E - \Delta E = h(\nu - \nu_1)$$

where ν is the frequency of the incident photon and ν_1 is the *shift* in frequency due to an energy change ΔE . Several excited vibrational levels may be reached, resulting in several lines of energy $h(\nu - \nu_1)$, $h(\nu - \nu_2)$, $h(\nu - \nu_3)$, and so on. These lines are all shifted in frequency from the Rayleigh frequency. The Stokes lines, named after Sir George Gabriel Stokes, who observed a similar phenomenon in fluorescence, are shifted to lower frequencies than the Rayleigh frequency. The Raman shifts are completely independent of the wavelength of the excitation source. Sources with UV, visible, and NIR wavelengths are used, and the same Raman spectrum is normally obtained for a given molecule. There are exceptions due to instrumental variations and also if a resonance or near-resonance condition applies at certain wavelengths (Section 4.8.4).

Less commonly, the molecule *decreases* in vibrational energy after interacting with a photon. This might occur if the molecule is in an excited vibrational state to begin with and relaxes to the ground vibrational state. In this case, the molecule has given energy to the scattered photon. The photon is shifted to a frequency higher than the incident radiation. These higher frequency lines, the Raman anti-Stokes lines, are less important to analytical chemists than the Stokes lines because of their lower intensity. One exception to this is for samples that fluoresce strongly. Fluorescence interferes with the Stokes lines but to a much lesser extent with the anti-Stokes lines.

It is convenient to plot the Raman spectrum as intensity vs. shift in wavenumbers in cm⁻¹, because these can be related directly to IR spectra. The Raman shift in cm⁻¹ is identical to the IR absorption peak in cm⁻¹ for a given vibration, because both processes are exciting the same vibration. That is, if a vibration is both Raman and IR active, it will be seen at the same position in wavenumbers in both spectra, although with different intensity. The Raman spectra for benzene and ethanol are shown in Figure 4.39, along with the related IR transmission spectra.

4.8.2 RAMAN INSTRUMENTATION

A Raman spectrometer requires a light source, a sample holder or cell, a wavelength selector (or interferometer), and a detector, along with the usual signal processing and display equipment. Since Raman spectroscopy measures scattered radiation, the light source and sample cell are usually placed at 90° to the wavelength selector, as shown schematically in Figure 4.40. The radiation being measured in Raman spectroscopy is either visible or NIR; therefore, spectrometer optics, windows, sample cells, and so on can be made of glass or quartz. It is critical in Raman spectroscopy to completely exclude fluorescent room lights from the spectrometer optics. Fluorescent lights give rise to numerous spurious signals.

4.8.2.1 LIGHT SOURCES

Monochromatic light sources are required for Raman spectroscopy. The light sources used originally were simple UV light sources, such as Hg arc lamps; however, these were weak sources and only weak Raman signals were observed. The Raman signal is directly proportional to the power of the light source, which makes the laser, which is both monochromatic and very intense, a desirable light source. It was the development in the 1960s of lasers that made Raman spectroscopy a viable and useful analytical technique. Modern Raman instruments use a laser as the light source. The use of these intense light sources has greatly expanded the applications of Raman spectroscopy, because of the dramatically increased




FIGURE 4.39 (a) The IR spectrum and Raman spectrum of benzene. (b) The IR spectrum of ethanol. (c) The Raman spectrum of ethanol. (b) and (c) are not plotted on the same scale. (The ethanol spectra are courtesy of http://www.aist.go.jp/RIODB/SDBS.)

intensity of the signal and a simultaneous improvement in the signal-to-noise ratio. Lasers and excitation wavelengths commonly used for Raman instruments include visible wavelength helium/neon lasers and ion lasers such as the argon ion laser (488 nm) and the krypton ion laser (532 nm). The intensity of Raman scattering is proportional to the fourth power of the excitation frequency or to $1/\lambda^4$, so the shorter wavelength blue and green ion lasers have an advantage over the red helium/neon laser line at 633 nm. The disadvantage of the shorter wavelength lasers is that they can cause the sample to decompose on irradiation (photodecomposition) or fluoresce, an interference discussed subsequently. NIR lasers, such as neodymium/yttrium aluminum garnet, Nd/YAG, with an excitation line at 1064 nm, and the 785 nm NIR diode laser are used to advantage with some samples, such as biological tissue,




FIGURE 4.40 Idealized layout of a Raman spectrometer.

because they do not cause fluorescence or photodecomposition. However, longer integration time or a higher-powered laser may be needed to compensate for the decrease in scattering efficiency of NIR lasers. Because of the wavelength-dependent nature of fluorescence excitation, a Raman spectrometer that integrates multiple laser sources and makes changing lasers easy should be considered if a diverse sample load is expected.

4.8.2.2 DISPERSIVE SPECTROMETERS SYSTEMS

Traditional Raman spectrometers used a monochromator with two or even three gratings to eliminate the intense Rayleigh scattering. The optical layout is similar to that for the UV/VIS single grating monochromators discussed in Chapters 2 and 3. Holographic interference filters, called *super notch filters*, have been developed that dramatically reduce the amount of Rayleigh scattering reaching the detector. These filters can eliminate the need for a multiple grating instrument unless spectra must be collected within 150 cm⁻¹ of the source frequency. Dispersive systems generally use a visible laser as the source. The low-end cutoff of the Raman spectrum is determined by the ability of the filters to exclude Rayleigh scattering. Since inorganic compounds have Raman bands below 100 cm⁻¹, modern instruments should provide a 50 cm⁻¹ low end cutoff.

The traditional detector for these systems was a photomultiplier tube. Multichannel instruments with photodiode array (PDA), CID, or CCD detectors are commonly used today. All three detectors require cryogenic cooling. Room temperature InGaAs detectors are also available. The PDA has the advantage of having the fastest response but requires more complicated optics than the other detectors. The CID has the advantage over both the PDA and CCD of not "blooming". Blooming means having charge spill over onto adjacent pixels in the array, which would be read in error as a signal at a frequency where no signal exists. CCDs are the slowest of the three array detectors because they have to be read out by transferring the stored charge row by row, but they are also the least expensive of the detector arrays. Sensitivity is improved in newer CCD designs as well. A dispersive Raman spectrometer with a CCD detector is shown schematically in Figure 4.41.

As described in Chp.2, spectral resolution determines the amount of detail that can be seen in the spectrum. If the resolution is too low, it will be impossible to distinguish between spectra of closely related compounds; if the resolution is too high, noise increases without any increase in useful information. Spectral resolution is determined by the diffraction grating and by the optical design of the spectrometer. With a fixed detector size, there is a resolution beyond which not all of the Raman wavelengths fall on the detector in one exposure. Ideally, gratings should be matched specifically to each laser used. A dispersive Raman Echelle spectrometer from PerkinElmer (www.perkinelmer.com) covers the spectral range 3500-230 cm⁻¹ with a resolution better than 4 cm⁻¹.

CCDs used in modern instruments are generally Si-based 2D arrays of light-sensitive elements, called pixels. Each pixel, typically $< 30 \, \mu m$, acts as an individual detector. Each dispersed wavelength is detected by a different pixel. CCD detectors commonly respond over the 400 nm–1100 nm range, but specialized detectors can extend the range over 1100 nm




FIGURE 4.41 Schematic of a dispersive Raman spectrometer. (Reprinted from Weesner and Longmire, with permission from Advanstar Communications, Inc.)




FIGURE 4.42 Schematic of an FT-Raman spectrometer. (Reprinted from Weesner and Longmire, with permission from Advanstar Communications, Inc.)

and down into the UV range. The longest excitation wavelength that can be used with a silicon CCD detector is about 785 nm. Dispersive Raman, with its high sensitivity and high spatial resolution, is the best choice for small particle analysis and minor component analysis.

4.8.2.3 FT-RAMAN SPECTROMETERS

FT-Raman systems generally use an NIR laser source, such as the Nd/YAG laser, and a Michelson interferometer. A schematic FT-Raman spectrometer is shown in Figure 4.42. The NIR laser source line is at 1064 nm, so the Raman Stokes lines occur at longer wavelengths. This is beyond the detection range of the materials used in array detectors. The detector for an NIR-laser based FT-Raman system is a liquid nitrogen-cooled photoconductive detector such as Ge or InGaAs (indium gallium arsenide). InGaAs detectors that do not require cooling are also available.

FT-Raman has many of the advantages of FTIR. There is high light throughput, simultaneous measurement of all wavelengths (the multiplex advantage), increased signal-to-noise ratio by signal averaging, and high precision in wavelength due to the internal interferometer calibration provided by the built-in He-Ne laser. A major advantage is in the use of the NIR laser excitation source, which dramatically reduces fluorescence in samples. Fluorescence occurs when the virtual states populated by excitation overlap excited electronic states in the molecule. Then, the molecule can undergo a radiation-less transition to the lowest ground state of the excited electronic state before emitting a fluorescence photon on relaxation to the ground state. The fluorescence photon is of lower energy than the exciting radiation, and so fluorescence occurs at longer wavelengths, interfering with the Stokes scattering lines. The NIR laser is of low energy and does not populate virtual states that overlap the excited electronic states, as higher energy visible lasers can. As an example, the Raman spectrum of cocaine is shown in Figure 4.43. The spectrum in Figure 4.43(a) was collected with an FT-Raman spectrometer using an NIR laser, while that in Figure 4.43(b) was collected with a dispersive Raman system and a visible laser. Figure 4.43(b) shows a large fluorescence band that obscures most of the Raman spectrum below 2000 cm⁻¹. With appropriate mathematical "smoothing" algorithms and multipoint baseline correction, it is possible to extract a useable Raman spectrum from samples that exhibit strong fluorescence, as shown in Figure 4.44. One consideration in FT-Raman is that the laser line at 1064 nm is very close to a water absorption band. While this does not prevent aqueous solutions from being studied by FT-Raman, aqueous solutions cannot be studied as easily as they can with dispersive Raman. FT-Raman is the better choice for samples that fluoresce or contain impurities that fluoresce. FT-Raman is widely used in the analysis of illicit drugs and pharmaceuticals, as many of these compounds fluoresce strongly at visible wavelengths.




FIGURE 4.43 Analyses of crack cocaine using **(a)** FT-Raman and **(b)** 785 nm dispersive Raman. Note the lack of fluorescence in the FT-Raman spectrum (flat baseline vs. the big "hump" due to fluorescence in the lower spectrum) and the rich spectral information in the upper spectrum. This information is partially obscured by the fluorescence band in the dispersive spectrum. (Reprinted from Weesner and Longmire, with permission from Advanstar Communications, Inc.)

4.8.2.4 FIBER OPTIC-BASED MODULAR AND HANDHELD SYSTEMS

Low-resolution Raman systems based on fiber optics have been developed to provide miniaturized, low cost, rugged systems for lab, process, and field testing. This development has occurred in the last ten years, due to improved, low-cost semiconductor lasers, cheap and highly sensitive solid-state detectors, and cheaper, faster computer chips. Portable and handheld Raman systems are now available from several companies, including Rigaku Raman




FIGURE 4.44 It is possible to extract data from a Raman spectrum that exhibits fluorescence interference by the application of mathematical data treatments. The data treatments were applied sequentially to give the final spectrum shown in **(d)**. **(a)** is the raw spectrum of a weak scatterer with a fluorescence background, **(b)** is the spectrum after Savitzky-Golay smoothing, **(c)** after a multipoint baseline correction performed by the analyst, and **(d)** after a Fourier smoothing. (Reprinted from Kawai and Janni, with permission from Advanstar Communications, Inc.)

Technologies, Inc. (www.rigakuraman.com), BaySpec,Inc. (www.bayspec.com), Thermo Fisher Scientific (www.thermo.com), Enwave Optronics, Inc.(www.enwaveopt.com), B&W Tek, Inc. (www.bwtek.com), Ocean Optics (www.oceanoptics.com) and others for screening of incoming raw materials, hazardous materials, forensic applications, in-line pharmaceutical processing, gem and semiprecious stone quality, authentication and anti-counterfeiting and QC. These field and portable instruments weigh between 2 and 5 lbs. They can be configured with one or more lasers, and different detectors (Figure 4.45). The field portable EZRaman-I series instruments from Enwave Optronics, Inc., for example, are lithium battery-powered, compact instruments with built-in laptop, one of three lasers (or configured with two different lasers), a high-sensitivity CCD spectrograph, with the CCD thermoelectrically cooled to -50°C, spectral ranges from 100-3300 cm⁻¹ and average resolution of 6-7 cm⁻¹.

Hand-held and portable systems may have less resolution and spectral range than laboratory systems, but can be customized for specific applications with customized spectral libraries. Specialized applications for these instruments include measuring the "freshness" of fish by monitoring the concentration of dimethylamine, which is directly related to age and temperature of processed frozen fish (Herrero et al.). Fat concentration, composition, and saturation index allows a hand-held Raman instrument to determine in less than one minute if edible oils such as olive oil have been adulterated or if cheaper oil is being sold as more expensive olive oil.

Another critical food safety application is the determination of melamine in human and pet food. Melamine has been found in milk and pet food, deliberately added to watered-down or inferior products to boost the apparent protein concentration. The standard wet chemical method for "protein" in food is the Kjeldahl method, which actually measures nitrogen and is an indirect measure of protein. Melamine responds to the Kjeldahl method just like protein, but is not a protein and is toxic; it combines with uric acid to form kidney stones. Numerous pet deaths from ingestion of melamine-contaminated pet food have been reported. Using their portable Nunavut™ Raman System, BaySpec, Inc. scientists demonstrated the measurement of melamine at levels down to 3 ppm in the field; the analysis takes less than ten seconds, is accurate, repeatable and is non-destructive.

4.8.2.5 SAMPLES AND SAMPLE HOLDERS FOR RAMAN SPECTROSCOPY

Because the laser light source can be focused to a small spot, very small samples can be analyzed by Raman spectroscopy. Samples of a few microliters in volume or a few milligrams are sufficient in most cases. Liquid samples can be held in beakers, test tubes, glass capillary tubes, 96 well plates or NMR tubes. Aqueous solutions can be analyzed since water is a very weak Raman scatterer. This is a significant advantage for Raman spectroscopy over IR. Other solvents that can be used for Raman studies include chloroform, carbon tetrachloride, acetonitrile, and carbon disulfide. Solid powders can be packed into glass capillary tubes, NMR tubes, plastic bags, or glass vials for analysis. The spectra are obtained through the glass. Solid samples can also be mounted at the focal point of the laser beam and their spectra obtained "as is" or pressed into pellets. Gas samples do not scatter radiation efficiently, but can be analyzed by being placed into a multipath gas cell, with reflecting mirrors at each end. The body of the gas cell must be of glass to allow collection of the scattered light at 90°.

The sample must be placed at the focal point of an intense laser beam, and some samples may be subject to thermal decomposition or photodecomposition. Accessories that spin the sample tube or cup are available, to distribute the laser beam over the sample and reduce heating of the sample. Spinning or rotating the sample minimizes thermal decomposition, but does not stop photodecomposition. Sample spinning is required for *resonance Raman spectroscopy* (Section 4.8.4).

Raman spectroscopy does not suffer interference from atmospheric water vapor or carbon dioxide. Gases do not scatter well, so even though Raman-active bands occur for these gases, the contribution to the Raman signal from air in the optical path is insignificant. Materials in the optical path outside of the laser focus also have negligible scattering.





FIGURE 4.45 (a) Hand-held TruScan® Raman instrument collecting a spectrum from a powder sample directly through the plastic bag. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.) **(b)** Hazardous material identification by a first responder using the handheld FirstGuard™ 1064 nm advanced Raman system. (Used with permission of Rigaku Raman Technologies, Inc. [www.rigakuraman.Com].)

Sample cells have been designed for low and high temperature operation, well-plate accessories allow high-throughput analyses, and remote probes and user-friendly video stages are available for many systems.

4.8.3 APPLICATIONS OF RAMAN SPECTROSCOPY

Quantitative and qualitative analyses of inorganic and organic compounds can be performed by Raman spectroscopy. Raman spectroscopy is used for bulk material characterization, online process analysis, remote sensing, microscopic analysis, and chemical imaging of inorganic, organic and organometallic compounds, polymers, biological systems, art objects, carbon nanomaterials, and much more. Forensic science applications include identification of illicit drugs, explosives, and trace evidence like hair, fibers, and inks. Raman spectra have fewer lines and much sharper lines than the corresponding IR spectra, as seen in Figure 4.46. This makes quantitative analysis, especially of mixtures, much simpler by Raman spectroscopy than by IR spectroscopy.

Quantitative analysis had not been as common until recently, due to the high cost of Raman instruments. With prices for Raman systems dropping below \$40,000, and even as low as \$10,000, the use of Raman spectroscopy for quantitative analysis is increasing. Quantitative analysis requires measurement of the intensity of the Raman peaks and the use of a calibration curve to establish the concentration-intensity relationship. The intensity of a Raman peak is directly proportional to the concentration:






FIGURE 4.46 Raman spectra of common drugs of abuse, showing how sharp the Raman spectral lines are. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

where I is the intensity of Raman signal at frequency v; K, the proportionality constant including instrument parameters such as laser power; J, the scattering constant for the given Raman peak; v, the scattering frequency of the Raman peak; and c, concentration of analyte.

K, J, and ν are all constants for a given sample measurement. The frequency and intensity of the desired Raman lines are measured, and the intensity of an unknown compared to the calibration curve. It is common to use an internal standard (Chapter 1) for Raman analysis, because of the dependence of the signal on the laser power (in the K term). Without an internal standard, the laser power, sample alignment, and other experimental parameters must be carefully controlled. If an internal standard is used, the intensity of the internal standard peak is also measured, and the ratio of intensities plotted vs. concentration. Upon division, this reduces Equation 4.13 to:

$$\frac{I_{\text{unk}}}{I_{\text{std}}} = K'c$$

The use of the internal standard minimizes the effect of changes in instrumental parameters and can result in better accuracy and precision. Newer Raman systems such as the Thermo Scientific DXR series incorporate a laser power regulator which delivers reproducible laser power to the sample and compensates for laser aging and variability, minimizing the need for internal standards.

Two other major factors had impacted Raman spectroscopy for both qualitative and quantitative work. Older systems had problems with reproducibility due to wavelength dependence of the silicon CCD detector response and x-axis non-reproducibility, a result of inadequate spectrograph and laser calibration. Modern systems use automated, software-driven multipoint calibration of the laser and spectrograph and automatic intensity correction, dramatically improving reproducibility. Wavelength accuracy can be checked by using a high-purity mercury vapor or argon light source. Laser power output can be measured in a variety of ways, including the use of NIST Raman relative intensity standards, fluorescent glasses sensitive to specific laser wavelengths.

Quantitative analyses that can be done by Raman spectroscopy include organic pollutants in water, inorganic oxyanions and organometallic compounds in solution, aromatic/aliphatic hydrocarbon ratios in fuels, antifreeze concentration in fuel, and concentration of the active pharmaceutical ingredient in the presence of excipients such as microcrystalline cellulose. Other common applications include raw materials identification, forensic testing of illegal drugs, explosives and other hazardous materials, cancer screening and dialysis monitoring. Mixtures of compounds in pharmaceutical tablets can be determined quantitatively, without dissolving the tablets. Raman sensitivity varies greatly, depending on the sample and the equipment. In general, analyte concentrations of at least 0.1-0.5 M (or 0.1-1 %) are needed to obtain good signals.

Another use of Raman spectroscopy for quantitative analysis is the determination of percent crystallinity in polymers. Both the frequency and intensity of peaks can shift on going from the amorphous to the semicrystalline state for polymers. The percent crystallinity can be calculated with the help of chemometrics software.

Qualitative analysis by Raman spectroscopy is very complementary to IR spectroscopy and in some cases has an advantage over IR spectroscopy. The Raman spectrum is more sensitive to the organic framework or backbone of a molecule than to the functional groups, in contrast to the IR spectrum. IR correlation tables are useful for Raman spectra, because the Raman shift in wavenumbers is equal to the IR absorption in wavenumbers for the same vibration. Raman spectral libraries are available from commercial and government sources, as noted in the bibliography. These are not yet as extensive as those available for IR, but are growing rapidly. Table 4.8 gives common functional groups, vibration regions and compares the strength of the Raman and IR bands.

The same rules for number of bands in a spectrum apply to Raman spectra as well as IR spectra: 3N - 6 for nonlinear molecules and 3N - 5 for linear molecules. There may be fewer bands than theoretically predicted due to degeneracy and nonactive modes. Raman spectra do not usually show overtone or combination bands. A "rule of thumb" that is often true is

TABLE 4.8 Raman Band Frequencies

Functional Group/Vibration	Region	Raman	Infrared
Lattice vibrations in crystals, LA modes	10-200 cm ⁻¹	strong	strong
δ (CC) aliphatic chains	250-400 cm ⁻¹	strong	weak
v(Se-Se)	290-330 cm ⁻¹	strong	weak
v(S-S)	430-550 cm ⁻¹	strong	weak
v(Si-O-Si)	450-550 cm ⁻¹	strong	weak
ν(X-O)	150-450 cm ⁻¹	strong	med-weak
ν(C-I)	480-660 cm ⁻¹	strong	strong
ν(C-Br)	500-700 cm ⁻¹	strong	strong
u(C-Cl)	550-800 cm ⁻¹	strong	strong
u(C-S) aliphatic	630-790 cm ⁻¹	strong	medium
u(C-S) aromatic	1080-1100cm ⁻¹	strong	medium
v(O-O)	845-900 cm ⁻¹	strong	weak
v(C-O-C)	800-970 cm ⁻¹	medium	weak
u(C-O-C) asym	1060-1150 cm ⁻¹	weak	strong
u(CC) aliphatic chain vibrations	600-1300 cm ⁻¹	medium	Medium
ν (C=S)	1000-1250 cm ⁻¹	strong	weak
u(CC) aromatic ring chain vibrations	*1580, 1600 cm ⁻¹	strong	medium
	*1450, 1500 cm ⁻¹	medium	medium
	*1000 cm ⁻¹	strong/medium	weak
δ (CH3)	1380 cm ⁻¹	medium	strong
δ (CH2) δ (CH3) asym	1400–1470 cm ⁻¹	medium	medium
δ (CH2) δ (CH3) asym	1400–1470 cm ⁻¹	medium	medium
v(C-(NO2))	1340-1380 cm ⁻¹	strong	medium
u(C-(NO2)) asym	1530-1590 cm ⁻¹	medium	strong
v(N=N) aromatic	1410-1440 cm ⁻¹	medium	-
v(N=N) aliphatic	1550-1580 cm ⁻¹	medium	-
δ (H2O)	~1640 cm ⁻¹	weak broad	strong
ν (C=N)	1610–1680 cm ⁻¹	strong	medium
ν (C=C)	1500-1900 cm ⁻¹	strong	weak
ν (C=O)	1680-1820 cm ⁻¹	medium	strong
ν (C≡C)	2100-2250 cm ⁻¹	strong	weak
ν(C≡N)	2220-2255 cm ⁻¹	medium	strong
ν(-S-H)	2550-2600 cm ⁻¹	strong	weak
ν(C-H)	2800-3000 cm ⁻¹	strong	strong
ν(=(C-H))	3000-3100 cm ⁻¹	strong	medium
ν(≡(C-H))	3300 cm ⁻¹	weak	strong
v(N-H)	3300-3500 cm ⁻¹	medium	medium
ν(O-H)	3100-3650 cm ⁻¹	weak	strong

Source: Table reproduced courtesy of @HORIBA Scientific (www.horiba.com/scientific).

Notes: X = metal atom; asym = asymmetric

that a band that is strong in IR is weak in Raman and vice versa. A molecule with a center of symmetry, such as CO_2 , obeys another rule: if a band is present in the IR spectrum, it will not be present in the Raman spectrum. The reverse is also true. The detailed explanation for this is outside the scope of this text, but the rule "explains" why the symmetric stretch in carbon dioxide is seen in the Raman spectrum, but not in the IR spectrum, while the asymmetric stretch appears in the IR spectrum but not in the Raman spectrum.

Since the physical properties of the sample do not greatly impact the Raman spectrum, it is not able to differentiate between materials which differ only in physical form, e.g., powder versus tablet. This does have an advantage in that a Raman spectral library can be built using only a single reference for each substance. Raman is an excellent tool for substances

that differ chemically, even only a little. Raman can differentiate polymorphs, isomers, anhydrates from hydrates, monohydrates from polyhydrates, L and D forms, and other chemically similar forms. A good example is the ease of distinguishing between pseudoephedrine and ephedrine, diastereomers which differ only in the position of a hydroxyl group, or the ease of distinguishing between methamphetamine (N-methyl-1-phenylpropan-2-amine, a drug widely abused) and phentermine (a diet pill, 2-methyl-1-phenylpropan-2-amine). The two compounds have the same molecular weight and are very difficult to distinguish based on their mass spectra. The Raman spectra [Figure 4.47(a)] are clearly different; even without any knowledge of Raman spectroscopy one can see that these are not the same spectra. The sharpness of the Raman bands is the key to using this technique for identification.

Identification of an unknown is usually done by matching Raman spectra to spectral libraries of known compounds. Subtraction of known spectra from the spectrum of an unknown




FIGURE 4.47 (a) The Raman spectra of methamphetamine and phentermine. **(b)** The analysis of a common multicomponent pharmaceutical tablet by Raman spectroscopy with spectral subtraction. The top spectrum is the entire tablet. The spectra for acetylsalicylic acid and caffeine were subtracted, resulting in the spectrum of the third component, identified as 4-acetamidophenol. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)




FIGURE 4.48 (a) Raman spectra of an unknown material (top) and four related drug compounds. (b) The library search match numbers (second column) show that the unknown is very probably methamphetamine. Note that the entire analysis was performed in 30 seconds. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

mixture to identify the components of the mixture works better for Raman spectra than for IR spectra, because there are fewer Raman peaks, the peaks are sharp and their position and shape are not affected by hydrogen-bonding. For example, it is possible to identify the components of a commercial pain relief tablet by spectral subtraction from the Raman spectrum of the intact tablet [Figure 4.47(b)].

The sharpness of Raman spectra also makes library searching very reliable, as seen in Figure 4.48. The spectrum of an unknown white powder collected through an evidence bag, as in Figure 4.45, is compared to spectra of a variety of drugs. The match to methamphetamine is significantly better than the other possibilities (83 vs. 62-65 for the other compounds).

Raman spectroscopy is particularly useful for studying inorganic and organometallic species. Most inorganic, oxyanionic, and organometallic species have vibrations in the far-IR region of the spectrum, which is not easily accessible with commercial IR equipment. These metal-ligand and metal-oxygen bonds are Raman-active and are easily studied in aqueous solutions and in solids. Raman spectroscopy is used in geology and gemology for identification and analysis, and in art restoration and identification and verification of cultural objects.

As noted earlier, fused silica optical fiber is used for remote NIR measurements. The same type of fiber optic probe can be used for Raman spectroscopy, and enables remote measurement of samples and online process measurements. *In situ* reaction monitoring by Raman spectroscopy has been used to study catalytic hydrogenation, emulsion polymerization, and reaction mechanisms. It is a powerful tool for real-time reaction monitoring, allowing feedback for reaction control. Remote sensing of molecules in the atmosphere can be performed by Raman scattering measurements using pulsed lasers.

4.8.4 THE RESONANCE RAMAN EFFECT

When monochromatic light of a frequency that cannot be absorbed by the sample is used, the resulting Raman spectrum is the **normal** Raman spectrum. Normal Raman spectroscopy is an inefficient process resulting in relatively low sensitivity and it suffers from interfering




FIGURE 4.49 The resonance Raman process.

fluorescence in many samples. If a laser excitation wavelength is used that falls within an excited electronic state of the molecule, the intensity of some Raman lines increases by as much as 10^3-10^6 over the normal Raman intensity. This is known as the *resonance Raman effect*, and the technique is called resonance Raman spectroscopy. The molecule must possess a *chromophore* that can absorb visible or UV radiation (discussed in Chapter 5). The process that occurs is shown schematically in Figure 4.49. The resulting spectra are even simpler than normal Raman spectra, because only totally symmetric vibrations associated with the chromophore are enhanced in intensity. This makes resonance Raman a very selective probe for specific chromophores. Resonance Raman spectroscopy has been used to study low concentrations of biologically important molecules such as hemoglobin.

Lasers that have wavelengths in the UV and visible regions of the spectrum are used for resonance Raman spectroscopy. Tunable dye lasers are often used; these lasers can be set to a selected wavelength over the UV/VIS range of 200–800 nm. This permits maximum flexibility in the choice of excitation wavelength.

4.8.5 SURFACE-ENHANCED RAMAN SPECTROSCOPY (SERS)

Surface-enhanced Raman spectroscopy or surface-enhanced Raman scattering (SERS) is another technique for obtaining strong Raman signals from surfaces and interfaces, including species adsorbed onto surfaces. Fleischmann and coworkers developed SERS in 1974. The SERS technique requires adsorption of the species to be studied onto or in close proximity to a prepared "rough" metal or metal colloid surface, where the roughness is at the atomic level. The surface roughness features are much smaller than the wavelength of the laser. For example, roughness features or particle sizes in the 20–100 nm range are used for laser wavelengths in the 532–780 nm range. The Raman excitation laser produces *surface plasmons* (coherent electron oscillations) on the surface of the metal. These surface plasmons interact with the analyte to greatly enhance the Raman emission. The process is shown schematically in Figure 4.50.

Inorganic and organic species adsorbed onto such surfaces show enhancement of Raman signals by up to 10⁶ over normal Raman signals. The reasons for the enhancement are not yet well understood, although to achieve the most effective enhancement, there must be resonance between the laser and the metal. Correct pairing of substrate and laser is of critical importance. Metals used as surfaces include gold, silver, copper, platinum, and palladium. Metal electrodes, metal films, and metal colloids have been used. The adsorbed or deposited analyte molecule must be less than 50 Å from the surface for the enhancement to be observed. Samples have been deposited electrolytically onto electrode surfaces, or mixed




FIGURE 4.50 The SERS process using 532 nm excitation of a silver substrate with adsorbed species (the circles). Surface plasmons interact with the adsorbed species to enhance the Raman emission, shown on the right side of the diagram. (© Thermo Fisher Scientific [www.thermo-fisher.com]. Used with permission.)

with colloidal metal suspensions. Samples separated on thin layer chromatography (TLC) plates have been sprayed with metal colloid solution. One simple approach involves mixing a few microliters of a colloidal substrate (metal nanoparticles of from 20–100 nm dimensions suspended in solution) with an equal amount of the analyte. This is deposited onto a glass slide, allowed to dry and is then ready for analysis (Deschaines and Wieboldt, and references therein). It should be noted that preparing colloids is not simple; glassware must be extremely clean and ultrapure water must be used. Reaction conditions must be carefully controlled so that particles of the correct size and shape form.

Preparing metal surfaces requires expertise and can be expensive. Commercial sources for SERS substrates, colloids, and sample holders are available from companies such as Thermo Fisher Scientific, Renishaw and Real-Time Analyzers (www.rta.biz), which focuses on high throughput needs with SERS 96 well plates.

The enhancement leads to the ability to detect extremely small amounts of material, making SERS an effective tool for a variety of problems, including corrosion studies, detection of chemical warfare agents, bacteria on food, trace evidence in forensic science, blood glucose, research into infectious diseases and many more. Detection limits for SERS are in the nanogram range. SERS can be used to study the way in which an analyte interacts with or binds to a surface. SERS can be used to obtain information on very dilute solutions and small amounts of material that cannot be obtained by regular Raman spectroscopy. Current research in SERS includes practical biomedical applications such as the detecting disease states based on DNA signatures.

4.8.6 RAMAN MICROSCOPY

Raman spectroscopy coupled to a microscope permits the analysis of very small samples non-destructively. The use of Raman microscopy allows the characterization of specific domains or inclusions in heterogeneous samples with very high spatial resolution. With dispersive Raman microscopy, the spatial resolution is often better than 1 μ m. FT-Raman microscopy is limited to spot sizes of about 2-10 μ m, but with no interference from fluorescence. The use of a confocal microscope (Figure 4.51) allows only the light at the sample focus to pass into the detector; all other light is blocked. This permits nondestructive depth profiling of samples without the need for cross-sectioning of the sample. For example, confocal Raman microscopy can identify the polymers in complex layered structures, such as multilayer films used for food packaging. Characterization of heterogeneous materials includes inclusions in minerals, the pigments, and other components in cosmetics, and the study of pigments, resins, and dyes in art and archeological objects. Using Raman microscopy, it is possible to identify if a red pigment in a painting is expensive cinnabar (HgS), cheaper hematite (Fe₂O₃), a mixture of the two, or an organic dye. The article by Edwards provides a detailed table of Raman




FIGURE 4.51 A simplified illustration of confocal microscopy. A spectrum is collected only from the area of the sample denoted by the middle arrow; only that light exits the confocal aperture. Information from all other sample areas is blocked. Raising or lowering the sample will allow the detector to collect Raman scatter from levels in the sample lower or higher than the area in the middle. (Reprinted from Weesner and Longmire, with permission from Advanstar Communications, Inc.)

bands from common minerals used in art and an overview of the use of Raman microscopy for the study of art objects. Raman microscopy is particularly useful for art and archeological objects, because there is no sample preparation required and the natural water present in paintings, manuscripts, and ancient textiles does not interfere, as it does in IR spectroscopy.

Since spatial resolution is diffraction-limited, short wavelength lasers are optimal for analyzing small sample features. In order to achieve micron-level spatial resolution, the alignment of the Raman microscope is critical. The visual light path, the excitation laser beam path and the Raman scatter beam path from the sample to the detector must all be targeted precisely on the same spot.

Raman microscopes are available from a number of instrument companies including Bruker, HORIBA Scientific, Jasco, Thermo Fisher Scientific, WITec, and Renishaw plc, among others.

FTIR microscopy was discussed earlier in the chapter, and given the complementary nature of IR and Raman, it is reasonable that laboratories performing IR microscopy might well need Raman microscopy and vice versa. Two microscope systems were required and the sample had to be moved from one system to the other. The difficulty of relocating the exact spot to be sampled can be imagined. A combination dispersive Raman and FTIR microscopy system, the LabRAM-IR2 (HORIBA Scientific, Edison, NJ), allows both Raman and IR spectra to be collected at exactly the same location on the sample. The resolution depends on the wavelength observed, because resolution is limited by diffraction, but is <1 μ m for the Raman spectrum and 10–20 μ m for the IR spectrum. Examples of the type of data that can be obtained with this combination microscopy system are shown in Figures 4.52 and 4.53.

4.9 CHEMICAL IMAGING USING NIR, IR, AND RAMAN SPECTROSCOPY

The most recent breakthrough in the use of vibrational spectroscopy for chemical analysis is in the area of *chemical imaging*. Chemical imaging is the use of 2D or 3D detectors to collect spectral data from a large number of locations within a sample and then using the variations in the spectral data to map chemical differences within the sample. The chemical differences are often displayed as a false-color image of the sample, called a chemigram.




FIGURE 4.52 The Raman and FTIR spectra of a 10 μ m fiber of a nylon 6-polyethylene glycol block copolymer. Spectra were collected at exactly the same spot on the fiber. FTIR spectrum is at the top; Raman spectrum at the bottom. (Courtesy of ©HORIBA Scientific, www.horiba.com.)

FTIR imaging has been commercially available since 1996. The usual "detector" is an MCT array detector, called a focal plane array (FPA) detector, used in conjunction with an FTIR microscope. A 64×64 FPA detector has 4096 detector elements and allows 4096 interferograms to be collected simultaneously. Because each pixel in the detector array generates a spectrum, there are three dimensions in the data set. These data sets are often referred to as data cubes or image cubes. The x and y coordinates of the cube are the spatial positions while the z coordinate represents the wavelength. The data can be handled in many ways, including the use of library searching, principal component analysis and more, making this a powerful technique. Principal component analysis is a chemometric technique that sorts the image spectra into an independent set of subspectra (the principal components) from which the image spectra can be reconstructed. If there are five layers in a polymer laminate, for example, and there are 1000 image spectra, in theory, five subspectra would be sufficient




FIGURE 4.53 Raman and FTIR spectra of a gallstone. The spectra were recorded with the LabRAM-IR microscope using a 532 nm laser. The FTIR spectrum is more sensitive to the OH bands, while the Raman spectrum starts below 600 cm⁻¹ and shows details of the cholesteric species and the c=c bands. (Courtesy of ©HORIBA Scientific, www.horiba.com.)

to describe all 1000 image spectra. In practice, more than five subspectra are needed, due to variations in baseline, instrumental conditions, impurities, and so on. The amounts of the principal components in the original image are calculated at each pixel and the resulting scores are used to enhance the IR image contrast. See the reference by Sellors for more detail and color images, as well as the websites of the major instrument companies for application notes. Samples can be measured in reflectance mode or transmission mode. Solid samples such as biological tissues may need to be sliced into thin sections for transmission analysis. FTIR imaging can be performed on a wide variety of sample matrices, including polymers, pharmaceutical tablets, fibers, and coatings.

Commercial Raman and NIR imaging microscope systems are also available. Raman imaging of polymer blend surfaces, Raman and NIR imaging of silicon integrated circuits, of whole pharmaceutical tablets, of tooth enamel and counterfeit documents are just a few applications. The FALCONTM Raman Chemical Imaging Microscope (ChemIcon, Pittsburgh, PA, www.chemimage.com) can be equipped with fiber optic probes for remote monitoring and for high-temperature remote monitoring, such as in a heated process stream. 3D Confocal Raman Imaging is a powerful technique available from a number of companies, including Horiba Scientific and WITec GmbH. A confocal Raman microscope is a combination of a Raman spectrometer with a confocal microscope, so that the resolution of the optical microscope is combined with the analytical power of Raman spectroscopy. The sample is scanned point-by-point and line-by-line, and at every image pixel a complete Raman spectrum is taken. This process is also called hyperspectral imaging. These multi-spectrum files are then analyzed to display the distribution of chemical sample properties. By taking a stack of images with different focal positions, the geometry of samples can be reconstructed in 3D. Figure 4.54 shows such a 3D Raman image of a fluid inclusion in garnet (60x60x30 μm) with the fluid inclusion (water) displayed in blue and the garnet in red. Typical integration times in a confocal Raman microscope are between 700 μs and 100 ms per spectrum, so that a complete Raman image of 10,000 spectra takes between a few seconds and 20 minutes.

Some systems can do NIR absorption imaging as well as fluorescence and visible emission imaging. They can be used to show inhomogeneous distribution of active pharmaceutical




FIGURE 4.54 3D Confocal Raman image of a fluid inclusion in garnet ($60x60x30 \mu m$; Red: Garnet; Blue: Water; Green: Calcite; Turquoise: Mica). (Courtesy of WITec GmbH, Ulm, Germany. www.WITec.de. Used with permission.)




FIGURE 4.55 Raman image of a commercial painkiller tablet showing the inhomogeneous distribution of aspirin (red), caffeine (green) and paracetamol (blue). (Taken with a Horiba Scientific LabRAM HR. Used with permission.)

ingredients in tablets that were otherwise identical in bulk chemical composition and in their bulk spectra as shown in Figure 4.55. Such a difference can point to a problem in the manufacturing process or to the use of a different manufacturing process by a company making counterfeit tablets.

A fast near-IR and Raman imaging microscope system (NIRIM) is described by McLain and coauthors that uses a fiber optic bundle and CCD detector to collect a complete 3D Raman data cube from a sample in 1 s or less. The system has been used to image inorganic inclusions in crystals, mixtures of metal oxides, amino acid mixtures and to perform surface-enhanced Raman imaging of catalyst and nanoparticle surfaces, among other studies. An example is shown in Figure 4.56.

Silicon deposited on glass or silicon carbide is widely used in manufacturing photovoltaic cells.

It is critical to monitor both the proportion and distribution of amorphous and crystalline silicon in such materials. Raman microscopy is ideal for this application as the two forms are readily distinguishable and permit simple quantification using Beer's Law (Deschaines, Hodkiewicz, and Henson). Raman spectroscopy using a Thermo Scientific DXR Raman microscope with a 532 nm laser permitted the authors to quantify the relative amounts of amorphous and crystalline silicon in thin layer deposits (Figure 4.57).

A simple Beer's Law calculation based on the ratio of the respective peak heights permits quantitation. In addition, a two-dimensional map was collected, showing the distribution of the two forms of silicon. This can be used as a quality control check during manufacturing. A laser power regulator (present in the DXR Raman microscope) is needed because too high a laser power can convert amorphous Si to crystalline Si, which would result in an inaccurate analysis.

A second combination of two techniques provides a solution to the problem of obtaining the Raman spectrum from a rough surface. On rough or inclined samples, a high level of confocality can cause part of the scanned area to be out of focus. This is especially true for larger scans on the mm scale because it can become quite a challenge to achieve a flatness of only a few µm over such a large area. Decreasing the confocality and thus making the system less sensitive to variations due to a lower depth resolution is a solution if the topographic changes are small (i.e., $<10 \mu m$), but even in those cases, it is not desirable due to the loss in surface sensitivity. Especially when looking at intensity changes of peaks or when working with transparent samples, this option should be avoided. However, without such a compromise or if the topographic variation is too large, it is only possible to image a slice of the sample in one scan in conventional Confocal Raman Imaging systems (Figure 4.58, top). For samples with high optical density for the wavelength of choice (=low penetration depth) one could in this fashion acquire many slices and then reconstruct the surface, but this would be a very time-consuming procedure. In contrast, Confocal Raman Imaging in combination with True Surface Microscopy (WITec GmbH, www.witec.de) allows the user to remain in focus on the surface at every point and thus acquire the complete image in one scan (Figure 4.58, bottom).

True Surface Microscopy uses the principle of a confocal chromatic sensor as shown in Figure 4.59. A white-light point source is focused onto the sample with a hyperchromatic lens assembly, a lens system that has a good point mapping capability, but a strong linear




FIGURE 4.56 (a) Schematic of the NIRIM. (b) Imaging and identification of three different amino acid crystals in a mixture using the NIRIM system. (Both reprinted from McLain et al., with permission from Advanstar Communications, Inc.)

chromatic error. Every color has therefore a different focal distance. The light reflected from the sample is collected with the same lens and focused through a pinhole onto a spectrometer. As only one specific color is in focus at the sample surface, only this light can pass through the confocal pinhole. The detected wavelength is therefore related to the surface topography. Scanning the sample in the XY plane reveals a topographic map of the sample. Such a map can be followed in a subsequent confocal Raman image scan so that the Raman excitation is always kept in focus with the sample surface (or at any chosen distance below the surface).






FIGURE 4.57 Raman spectra of silicon samples ranging from pure crystalline to primarily amorphous silicon. The spectra show a sharp band at 521 cm⁻¹ from crystalline silicon and a much broader band centered at approximately 480 cm⁻¹ from amorphous silicon. (From Deschaines et al., © Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)





3

FIGURE 4.59 Schematic operation of a confocal chromatic sensor. White light (1) is focused through a hyperchromatic lens system (2) onto the sample (3) and only the light scattered in its focal plane reaches the spectrometer (4) with high intensity. (Courtesy of WITec GmbH, Ulm, Germany. www.witec.de. Used with permission.)

In order to illustrate the advantage of such a sensor a highly inclined and very rough geological sample was investigated with True Surface Microscopy. A photograph of the sample can be seen in Figure 4.60.

optical cross-section through the sample. If the sample is not transparent, only the intersection of focal plane and sample surface will give a Raman signal. Depending on the objective used, the focal plane might have a thickness of less than 1 μ m. Bottom: (2) The True Surface Microscopy option enables the precise tracing of the surface while acquiring Raman imaging

data, resulting in a true surface Raman image. (Courtesy of WITec GmbH, Ulm, Germany. www.

witec.de. Used with permission.)

The scanned area was 2x2 mm with a maximum topographic range in the scanned area of approximately 1.3mm. If such an area is scanned in confocal Raman imaging mode without correction of the topography only a very limited range can be recorded, which is illustrated in Figure 4.61(a). The same area was also scanned with the topographic data taken into account in order to adjust the Z-position at each image pixel such that the surface is in focus. The results [Figure 4.61(b)] clearly show much more detailed information of the sample surface. Quartz (blue), Kerogen (green) as well as Anatase (red) could be found in this sample. Areas marked in yellow indicate high levels of fluorescence. The corresponding Raman spectra of the minerals found are shown in Figure 4.62.



FIGURE 4.60 A 2×2 mm area at the indicated position was investigated on this inclined and rough rock sample while the sample was positioned under the microscope exactly as shown in the image. The height profile was measured by the integrated optical profilometer. (Courtesy of Frances Westall, CNRS Orleans, France and WITec GmbH, Ulm, Germany, www.WITec.de. Used with permission.)




FIGURE 4.61 (a) Field of view of a Confocal Raman Imaging measurement without correcting for the topography. (b) True Surface Raman image as a result of the height profile overlaid with the topography-traced confocal Raman image. (Courtesy of Frances Westall, CNRS Orleans, France and WITec GmbH, Ulm, Germany. www.WITec.de. Used with permission.)




FIGURE 4.62 Colors correspond to the image in Figure 4.61(b). Top spectrum: Quartz (blue areas), middle spectrum: Kerogen (green areas), bottom spectrum: Anatase (red areas). (Courtesy of Frances Westall, CNRS Orleans, France and WITec GmbH, Ulm, Germany. www.WITec.de. Used with permission.)

Chemical imaging provides a nondestructive and noninvasive way to map the chemical composition of a wide variety of samples very rapidly and at the microscopic level. Applications range from real-time process monitoring and biomonitoring to materials characterization, engineering materials fabrication, and failure analysis. Chemical imaging systems are now available for about \$150,000, making this technology feasible for even routine analysis.

SUGGESTED EXPERIMENTS

- 4.1 Record the IR absorption spectrum of hexane. Identify the absorption bands caused by the C—H stretching frequency, the C—H bending frequency, and the C—C stretching frequency.
- 4.2 Record the IR spectrum of heptane. Note the similarity with the spectrum obtained in Experiment 4.1. Would it be possible to distinguish between these compounds based on their IR spectra?
- 4.3 Record the IR spectrum of n-butanol. Note the O \rightarrow H stretching peak and the C \rightarrow OH peak. Repeat with iso-butanol and tert-butanol. Note any changes in the positions of these peaks. Is there a peak that can be used to distinguish among primary, secondary, and tertiary alcohols?
- 4.4 Record the IR spectrum of n-butylamine. Note the N \rightarrow H and C \rightarrow N stretching peaks. Repeat with sec-butylamine and tert-butylamine. Compare the spectra to what you expect from your reading.
- 4.5 Place a few drops of a volatile organic liquid (toluene, xylene, carbon tetrachloride, etc.) in a 10 cm gas cell and close the valves. Allow the cell to sit for several minutes. Record the gas phase spectrum of the compound. Compare the spectrum to the liquid phase spectrum and explain your observations.
- 4.6 Make up several different solutions of known concentrations of ethanol in carbon tetrachloride over the concentration range of 1–30 %. Measure the intensity of the C—OH absorption band. Plot the relationship between absorbance and the concentration of

- ethanol. (Alternatively, run the quantitative "oil and grease" method from Standard Methods for the Examination of Water and Wastewater, or the similar EPA method 1664.)
- 4.7 Repeat Experiment 4.6, using acetone as the sample. Note the sharp $C \Rightarrow O$ stretching band and use the absorbance of this band for quantitative studies as suggested in Experiment 4.6.
- 4.8 Take a sample of unsaturated cooking oil and record the IR absorption spectrum. Note the $C \Rightarrow C$ stretching frequency. Repeat with several brands of cooking oil. Based on the IR absorption spectrum, which brand was the most unsaturated?

PROBLEMS

- 4.1 What types of vibrations are encountered in organic molecules?
- 4.2 What materials are used for making the cell windows used in IR spectroscopy? Why must special precautions be taken to keep these materials dry?
- 4.3 Why do organic functional groups resonate at characteristic frequencies?
- 4.4 How can primary, secondary, and tertiary alcohols be distinguished by their IR absorption spectra?
- 4.5 Indicate which C—H and C—C stretching and bending vibrations can be detected in an IR absorption trace over the range of $2.5-16~\mu m$. What would be the frequency of each vibration?
- 4.6 In discussing quantitative analysis using the mid-IR region, it was suggested that either the OH stretching band or the C—O stretching band could be used to measure hexanol in a mixture of hexanol and hexane. Which band would you choose to give more accurate results? Why?
- 4.7 A solution is known to contain acetone and ethyl alcohol. Draw the expected IR absorption curve for each compound separately. Which absorption band could be used to identify the presence of acetone in the mixture?
- 4.8 What requirements must be met before a molecule will absorb IR radiation?
- 4.9 In preparing a calibration curve for the determination of methyl ethyl ketone (MEK), solutions with different concentrations of MEK were prepared in chloroform. The absorbance at the C=O stretching frequency was measured. The measured absorbance *A* for each solution is given. A blank (the pure solvent) had an absorbance = 0.00.

MEK concentration (%)	Absorbance
2	0.18
4	0.36
6	0.52
8	0.64
10	0.74

(a) Does the relationship between *A* and sample concentration deviate from Beer's Law? (b) Several unknown samples containing MEK were measured at the same wavelength as that used for the calibration curve. The results were as follows:

Sample	Absorbance
A	0.27
В	0.44
C	0.58
D	0.69

What were the concentrations of MEK in the solutions A-D?

- 4.10 Explain what is meant by the Fellgett advantage.
- 4.11 What are (a) fundamental and (b) overtone vibrational bands?

- 4.12 Is FTIR a single-beam or double-beam technique? How is background correction achieved?
- 4.13 How does a semiconductor detector such as an MCT detector compare to a thermocouple detector for use in IR spectroscopy?
- 4.14 Describe the components of an FTIR spectrometer. Which detectors are used for FTIR?
- 4.15 List the advantages of FTIR over dispersive IR spectroscopy.
- 4.16 Describe how attenuated total reflectance works to give an IR absorption spectrum.
- 4.17 Give two examples of the use of FTIR microscopy for chemical analysis.
- 4.18 What wavelength range is covered by NIR? What bands occur here?
- 4.19 What is the advantage of using NIR compared with mid-IR? What are the disadvantages?
- 4.20 What is meant by the term "virtual state"?
- 4.21 Diagram the processes that give rise to Rayleigh, Stokes, and anti-Stokes scattering.
- 4.22 What are the requirements for a molecule to be Raman-active?
- 4.23 Explain why fluorescence is a problem in normal Raman spectroscopy. Give two examples of how the fluorescence interference in Raman spectroscopy can be minimized or eliminated.
- 4.24 Describe the resonance Raman process and its advantages.

BIBLIOGRAPHY

Aikens, D.A.; Bailey, R.A.; Moore, J.A.; Giachino, G.G.; Tomkins, R.P.T. *Principles and Techniques for an Integrated Chemistry Laboratory*; Waveland Press, Inc.: Prospect Heights, IL, 1978. (Reissued 1984).

Asher, S.A. UV resonance Raman spectroscopy for analytical, physical and biophysical chemistry, pts.1 and 2. *Anal. Chem* 1993, 65 (2), 59A.66A and 201A–210A.

Briggs, J.L. Hollow waveguides: the next generation of mid-IR remote sampling accessories. FT-IR Technology for Today's Spectroscopists, August 2010, a supplement to Spectroscopy 2010.

Bruno, T.J.; Svoronos, P.D.N. CRC Handbook of Basic Tables for Chemical Analysis – Data Driven Methods and Interpretation; CRC Press: Boca Raton, FL, 2021.

Burns, D.R.; Ciurczak, E.W., Eds., *Handbook of Near Infrared Analysis*; Marcel Dekker, Inc.: New York,

Carroll, J.E.; He, H.; Landa, I. *The NIR Desk Reference*, LT Industries, Inc., Rockville, Maryland,1998. Coates, J. Vibrational spectroscopy. In *Analytical Instrumentation Handbook*, 2nd; Ewing, G.W., Ed.; Marcel Dekker, Inc: New York, 1997.

Colthup, N.B.; Daly, L.H.; Wiberley, S.E. *Introduction to Infrared and Raman Spectroscopy*, 3rd; Academic Press: New York, 1990.

Cooke, P.M. Chemical microscopy. Anal. Chem 1996, 68 (12), 339R.

De Blase, F.J.; Compton, S. IR emission spectroscopy: a theoretical and experimental review. *Appl. Spectrosc* 1991, 45 (4), 611.

Deschaines, T.O.; Hodkiewicz, J.; Henson, P. Characterization of amorphous and microcrystalline silicon using Raman spectroscopy. Technical Note 51735, Thermo Fisher Scientific, Inc., 2009.

Deschaines, T.O.; Wieboldt, D. Practical applications of surface-enhanced Raman scattering (SERS). Technical Note 51874, Thermo Fisher Scientific, Inc., 2010.

Dieing, T.; Hollricher, O.; Toporski, J., Eds.; *Confocal Raman Microscopy*, 1st Edition; Springer Verlag: Berlin Heidelberg, 2011, Vol. 158..

Edwards, H.G.M. Raman microscopy in art and archeology. Spectroscopy 2002, 17 (2), 16.

Ferraro, J.R.; Nakamoto, K. Introductory Raman Spectroscopy; Academic Press: New York, 1994.

Fleischmann, M.; Hendra, P.J.; McQuillan, A.J. Chem. Phys. Lett. 1974, 26, 163.

Garrell, R.L. Surface-enhanced Raman spectroscopy. Anal. Chem 1989, 61 (6), 401A.

Goddu, R.F. Near-infrared spectrophotometry. In *Advances in Analytical Chemistry and Instrumentation*; Reilly, C.N., Ed.; John Wiley and Sons, Inc. New York, 1960, Vol. 1.

Grasselli, J.G.; Bulkin, B.J., Eds. *Analytical Raman Spectroscopy*; John Wiley and Sons, Inc.: New York, 1991.

Grasselli, J.G.; Snavely, M.K.; Bulkin, B.J. Chemical Applications of Raman Spectroscopy; John Wiley and Sons, Inc.: New York, 1981.

Greenberg, A.E.; Clesceri, L.S.; Eaton, A.D., Eds. *Standard Methods for the Examination of Water and Wastewater*, 18th; American Public Health Association: Washington, DC, 1992.

- Gremlich, H.-U.; Yan, B., Eds., *Infrared and Raman Spectroscopy of Biological Materials*, Marcel Dekker, Inc., New York, 2001.
- Griffiths, P.R.; de Haseth, J.A. Fourier Transform Infrared Spectrometry. Chemical Analysis; Wiley-Interscience: New York, 1986; Vol. 83.
- Heil, C. Rapid, Multi-Component Analysis of Soybeans by FT-NIR Spectroscopy. Thermo Fisher Scientific application note, www.thermo.com, ©2010 Thermo Fisher Scientific (www.thermo-fisher.com).
- Herrero, A.M.; Carmona, P.; Careche, M.J. Agric. Food Chem 2004, 52 (8), 2147.
- Humecki, H.J., Ed. *Practical Guide to Infrared Microspectroscopy. Practical Spectroscopy Series*; Marcel Dekker, Inc.: New York, 1995; Vol. 19.
- Hsu, C.-P.S. Infrared spectroscopy. In *Handbook of Instrumental Techniques for Analytical Chemistry*, Settle, F.A., Ed.; Prentice Hall PTR: Upper Saddle River, NJ, 1997.
- Ingle, J.D. Jr.; Crouch, S.R. Spectrochemical Analysis; Prentice-Hall, Inc.: Englewood Cliffs, NJ, 1988.
- Kawai, N.; Janni, J.A. Chemical identification with a portable Raman analyzer and forensic spectral database. *Spectroscopy* 2000, 15 (10), 32.
- Kneipp, K.; Moskvits, M.; Kneipp, H., Eds. *Surface-Enhanced Raman Scattering: Physics and Applications*; Topics in Applied Physics 103, Springer: New York, 2006.
- Lambert, J.B.; Shurvell, H.F.; Lightner, D.; Cooks, R.G. *Introduction to Organic Spectroscopy*; Macmillan Publishing Company: New York, 1987.
- Lowry, S., Using FT-IR Spectroscopy to Analyze Gemstones, *Thermo Fisher Scientific*, Madison WI. Press release., 2014
- Marbach, R.; Kosehinsky, T.; Gries, F.A.; Heise, H.M. Noninvasive blood glucose assay by NIR diffuse reflectance spectroscopy of the human inner lip. *Appl. Spectrosc* 1983, 47 (7), 875.
- McLain, B.L.; Hedderich, H.G.; Gift, A.D.; Zhang, D.; Jallad, K.; Haber, K.S.; Ma, J.; Ben-Amotz, D. Fast chemical imaging. *Spectroscopy* 2000, 15 (9), 28.
- Metzel, D.L.; LeVine, S.M. In-situ FTIR microscopy and mapping of normal brain tissue. *Spectroscopy* 1993, 8 (4), 40.
- Mirabella, F.M., Ed. *Internal Reflection Spectroscopy: Theory and Applications. Practical Spectroscopy Series*; Marcel Dekker, Inc.: New York, 1992; Vol. 15.
- Morris, M.D., Ed. *Microscopic and Spectroscopic Imaging of the Chemical State*; Marcel Dekker: New York, 1993.
- Nakamoto, K. *Infrared and Raman Spectra of Inorganic and Coordination Compounds*, 5th; John Wiley and Sons, Inc: New York, 1996.
- Pattacini, S. Solving Analytical Problems Using Infrared Spectroscopy Internal Reflectance Sampling Techniques; Pattacini Associates, LLC: Danbury, CT., 1995
- Pavia, D.L.; Lampman, G.M.; Kriz, G.S. *Introduction to Spectroscopy*, 3rd; Harcourt College Publishers: New York, 2001.
- Raman, C.V. Indian J. Phys. 1928, 2, 387.
- Richard, S.; Tang, P.L. Identification and Evaluation of Coatings using Hand-held FTIR, Agilent Technologies, Inc., Publication number 5990-8075EN, 2011.
- Robinson, J.W., Ed., Handbook of Spectroscopy; CRC Press: Boca Raton, FL, 1974; Vol. II.
- Robinson, J.W., Practical Handbook of Spectroscopy; CRC Press: Boca Raton, FL, 1991.
- Robotham, C.; Izzia, F. FT-IR Microspectroscopy in Forensic and Crime Lab Analysis, Application Note 51517, Thermo Fisher Scientific, Inc., 2008.
- Schultz, C.P. Precision infrared spectroscopic imaging. Spectroscopy 2001, 16 (10), 24.
- Sellors, J. ATR imaging of laminates. Am. Lab 2008, 40 (8), 24.
- Silverstein, R.M.; Webster, F.X. Spectrometric Identification of Organic Compounds, 6th; John Wiley and Sons, Inc: New York, 1998.
- Smith, A.L. *Infrared Spectroscopy, Treatise on Analytical Chemistry*, Part 1; John Wiley and Sons, Inc.: New York, 1981; Vol. 7.
- Strommen, D.P. Raman spectroscopy. *In Handbook of Instrumental Techniques for Analytical Chemistry*; Settle, F.A., Ed.; Prentice Hall PTR: Upper Saddle River, NJ, 1997.
- von Rosenberg, C.W. Jr.; Abbate, A.; Drake, J.; Mayes, D.M. A rugged near-infrared spectrometer for the real-time measurement of grains during harvest. *Spectroscopy* 2000, 15 (6), 35.
- Weesner, F.; Longmire, M. Dispersive and Fourier transform Raman. Spectroscopy 2001, 16 (2), 68.



Magnetic Resonance Spectroscopy

5

5.1 NUCLEAR MAGNETIC RESONANCE SPECTROSCOPY: INTRODUCTION

NMR spectroscopy is one of the most powerful techniques available for studying the structure of molecules. The NMR technique has developed very rapidly since the first commercial instrument, a Varian HR-30, was installed in 1952 at the Humble Oil Company in Baytown, Texas. These early instruments with small magnets were useful for studying protons (1H) in organic compounds, but only neat liquids or solutions with a high concentration of analyte. That has now changed much more powerful magnets are available. NMR instruments and experimental methods are now available that permit the determination of the 3D structure of proteins as large as 900,000 Da. "Magic angle" NMR instruments are commercially available for studying solids such as polymers, and ¹³C, ¹⁹F, ³¹P, ²⁹Si, and other nuclei are measured routinely. NMR imaging techniques under the name magnetic resonance imaging (MRI) are in widespread use in noninvasive diagnosis of cancer and other medical problems. NMR instruments coupled to liquid chromatographs and mass spectrometers for separation and characterization of unknowns are commercially available. Resolution and sensitivity have both increased; detection and identification of ppm concentrations of substances with NMR is easily achieved in modern instruments and detection limits are approaching nanogram levels. NMR detection is being coupled with liquid chromatographic separation in HPLC-NMR instruments for identification of components of complex mixtures in the flowing eluant from the chromatograph, and NMR is now used as a nondestructive detector combined with mass spectrometry and chromatography in HPLC-NMR-MS instruments, an extremely powerful tool for organic compound separation and identification. In short, the field has broadened greatly in scope and gives every indication of continuing to advance for many years to come.

The NMR phenomenon is dependent upon the magnetic properties of the nucleus. Certain nuclei possess spin angular momentum which gives rise to different spin states in the presence of a magnetic field. Nuclei with I=0, where I is the spin quantum number, including all nuclei with both an even atomic number and an even mass number, such as ^{16}O and ^{12}C , do not have a magnetic moment and therefore do not exhibit the NMR phenomenon. In theory, all other nuclei with $I\neq 0$ can be observed by NMR.

NMR involves the absorption of radio waves by the nuclei of some combined atoms in a molecule that is located *in a magnetic field*. NMR can be considered a type of absorption spectroscopy, not unlike UV/VIS absorption spectroscopy. Radio waves are low-energy electromagnetic radiation with frequencies on the order of 10⁷ Hz. The SI unit of frequency, 1 Hz, is equal to the older frequency unit, 1 cycle per second (cps) and has the dimension of s⁻¹. The energy of *radiofrequency* (RF) radiation can therefore be calculated from:

$$E = hv$$

where Planck's constant h is 6.626×10^{-34} J s and v (the frequency) is between 4 and 1000 MHz (1 MHz = 10^6 Hz).

The quantity of energy involved in RF radiation is very small. It is too small to vibrate, rotate, or electronically excite an atom or molecule. It is great enough to affect the nuclear spin of atoms in a molecule. As a result, spinning nuclei of *some* atoms in a molecule *in a magnetic field* can absorb RF radiation and change the direction of the spinning axis. In principle, each chemically distinct atom in a molecule will have a different absorption frequency or **resonance** if its nucleus possesses a *magnetic moment*. The analytical field that

uses absorption of RF radiation by such nuclei in magnetic fields to provide information about a sample is NMR spectroscopy.

In analytical chemistry, NMR is a technique that enables us to study the shape and structure of molecules. In particular, it reveals the different chemical environments of the NMR-active nuclei present in a molecule, from which we can ascertain the structure of the molecule. NMR provides information on the spatial orientation of atoms in a molecule. If we already know what types of compounds are present, NMR can provide a means of determining how much of each is in the mixture. It is thus a method for both qualitative and quantitative analysis, particularly of organic compounds. In addition, NMR is used to study chemical equilibria, reaction kinetics, the motion of molecules, and intermolecular interactions.

Three Nobel Prizes have been awarded in the field of NMR. The first was in 1952 to the two physicists, E. Purcell and F. Bloch, who demonstrated the NMR effect in 1946. In 1991, R. Ernst and W. Anderson were awarded the Nobel Prize for developing pulsed FTNMR and 2D NMR methods between 1960 and 1980. FTNMR and 2D experiments form the basis of most NMR experiments run today, even in undergraduate instrumental analysis laboratories. We will use the acronym NMR to mean FTNMR, since this is the predominant type of NMR instrument currently produced. The 2002 Nobel Prize in Chemistry was shared by three scientists for developing methods to use NMR and MS (MS is discussed in Chapter 9) in the analysis of large biologically important molecules such as proteins. K. Wüthrich, a Swiss professor of molecular biophysics, received the prize for his work in determining the 3D structure of proteins using NMR (John B. Fenn and Koichi Tanaka shared the prize that year "for their development of soft desorption ionization methods for mass spectrometric analyses of biological macromolecules").

The theory, instrument design, and mathematics that make NMR so powerful are complex; a good understanding of quantum mechanics, physics, and electrical engineering is needed to understand modern NMR experiments. Fortunately, we do not need to completely understand the theory in order to make use of the technique. This chapter will address NMR in a simplified approach using a minimum of mathematics.

5.1.1 PROPERTIES OF NUCLEI

To understand the properties of certain nuclei in an NMR experiment, we must assume that nuclei rotate about an axis and therefore have a **nuclear spin**, represented as *I*, the spin quantum number. In addition, nuclei are charged. The spinning of a charged body produces a **magnetic moment** along the axis of rotation. For a nucleus to give a signal in an NMR experiment, it must have a nonzero spin quantum number and must have a magnetic dipole moment.

As a nucleus such as ¹H spins about its axis, it displays two forms of energy. Because the nucleus has a mass and because that mass is in motion (it is spinning), the nucleus has spin angular momentum and therefore mechanical energy. So, the first form of energy is *mechanical energy*. The formula for the mechanical energy of the hydrogen nucleus is:

(5.1) spin angular momentum =
$$\frac{h}{2\pi} \sqrt{I(I+1)}$$

where *I* is the spin quantum number. For example, I = 1/2 for 1 H.

The spin quantum number I is a physical property of the nucleus, which is made up of protons and neutrons. From observations of the nuclear spins of known nuclei, some empirical rules for predicting the spin quantum numbers can be tabulated. These rules are summarized in Table 5.1. For example, ^{12}C has atomic weight 12 and atomic number 6. Hence, it has 6 protons (atomic number = 6) and 6 neutrons (atomic weight – atomic number = No. of neutrons, so 12-6=6 neutrons). Since the mass and the number of protons are both even numbers, Table 5.1 predicts that the net spin quantum number of ^{12}C is zero, denoting no spin. Therefore, the spin angular momentum (Equation 3.1) is zero and ^{12}C does not possess a magnetic moment. Nuclei with I=0 do not absorb RF radiation when placed in a magnetic field and therefore do not give an NMR signal. NMR cannot measure ^{12}C , ^{16}O , or any other nucleus with both an even atomic mass and an even atomic number.

TABLE 5.1	Rules	Predicting	Spin	Number o	f Nuclei
IADEL J. I	Mules	i i caictilly	Join	IAMILINE! O	I ITUCIEI

Mass (P + N) (Atomic Weight)	Charge (P) (Atomic Number)	Spin Quantum Number (I)
Odd	Odd or even	1/2, 3/2, 5/2,
Even	Even	0
Even	Odd	1, 2, 3

For 13 C, on the other hand, the atomic weight is 13 (i.e., P+N=13), an odd number and the atomic number is 6, an even number. From Table 5.1, we predict that I for 13 C is therefore a half integer; like 1 H, 13 C has I=1/2. So, NMR can detect 13 C, and even though 13 C represents only 1.1 % of the total C present in an organic molecule, 13 C NMR spectra are very valuable in elucidating the structure of organic molecules.

The physical properties predict whether the spin number is equal to zero, a half integer, or a whole integer, but the actual spin number—for example, 1/2 or 3/2 or 1 or 2—must be determined experimentally. All elements in the first six rows of the periodic table have at least one stable isotope with a nonzero spin quantum number, except Ar, Tc, Ce, Pm, Bi, and Po. It can be seen from Table 5.1 and Appendix 9.1 that many of the most abundant isotopes of common elements in the periodic table cannot be measured by NMR, notably those of C, O, Si, and S, which are very important components of many organic molecules of interest in biology, the pharmaceutical industry, the polymer industry, and the chemical manufacturing industry. Some of the more important elements that can be determined by NMR and their spin quantum numbers are shown in Table 5.2. The two nuclei of most importance to organic chemists and biochemists, ¹³C and ¹H, both have a spin quantum number = 1/2.

The second form of nuclear energy is *magnetic*. It is attributable to the electrical charge of the nucleus. Any electrical charge in motion sets up a magnetic field. The nuclear magnetic moment μ expresses the magnitude of the magnetic dipole. The ratio of the nuclear magnetic moment to the spin quantum number is called the **magnetogyric** (or gyromagnetic) **ratio** and is given the symbol γ . Therefore $\gamma = (2\pi/h)(\mu/I)$. This ratio has a different value for each type of nucleus. The magnetic field of a nucleus that possesses a nuclear magnetic moment can and does interact with other local magnetic fields. The basis of NMR is the study of the response of such magnetically active nuclei to an external applied magnetic field.

5.1.2 QUANTIZATION OF ¹H NUCLEI IN A MAGNETIC FIELD

When a nucleus is placed in a very strong, uniform external magnetic field B_0 , the nucleus tends to become lined up in definite directions relative to the direction of the magnetic field. Each relative direction of alignment is associated with an energy level. Only certain well-defined energy levels are permitted; that is, the energy levels are **quantized**. Hence, the

TABLE 5.2 NMR-Active Nuclei and Their Quantum Numbers

Element Isotope	I	Element Isotope	I
¹³ C	1/2	35CI	3/2
¹⁷ O	5/2	³⁷ Cl	3/2
¹ H	1/2	⁷⁹ Br	3/2
² H (deuterium)	1	⁸¹ Br	3/2
³ H (tritium)	1/2	125	5/2
19 F	1/2	129	7/2
31 p	1/2	¹⁴ N	1
²⁹ Si	-1/2	15N	1/2
³³ S	3/2	10B	3
35S	3/2	¹¹ B	3/2




FIGURE 5.1 In the presence of an applied magnetic field, a nucleus with l=1/2 can exist in one of two discrete energy levels. The levels are separated by ΔE . The lower energy level (m=1/2) has the nuclear magnetic moment aligned with the field; in the higher energy state (m=-1/2), the nuclear magnetic moment is aligned against the field.

nucleus can become aligned only in well-defined directions relative to the magnetic field B_0 . (*Note*: The symbol B is the SI symbol for magnetic field; many texts still use the symbols H and H_0 for magnetic field.)

The *number of orientations* or number of magnetic quantum states is a function of the physical properties of the nucleus:


(5.2) Number of orientations =
$$2I + 1$$

In the case of ${}^{1}H$, I = 1/2; hence, the number of orientations is $2 \times (1/2) + 1 = 2$. The permitted values for the magnetic quantum states, symbolized by the magnetic quantum number, m, are I, I-1, I-2, ..., -I. Consequently, for ${}^{1}H$ only two energy levels are permitted, one with m = +1/2 and one with m = -1/2. The splitting of these energy levels in a magnetic field is called nuclear Zeeman splitting.

When a nucleus with I=1/2, such as 1 H, is placed in an external magnetic field, its magnetic moment lines up in one of two directions, with the applied field or against the applied field. This results in two discrete energy levels, one of higher energy than the other, as shown in Figure 5.1. The *lower* energy is that where the magnetic moment is aligned *with* the field. The lower energy state is energetically more favored than the higher energy state, so the population of nuclei in the lower energy state will be higher than the population in the higher energy state. The difference in energy between levels is proportional to the strength of the external magnetic field. The axis of rotation also rotates in a circular manner about the external magnetic field axis, like a spinning top, as shown in Figure 5.2. This rotation is called **precession**. The direction of precession is either *with* the applied field B_0 or *against* the applied field.

So, we have nuclei, in this case, protons, with two discrete energy levels. In a large sample of nuclei, more of the protons will be in the lower energy state. The basis of the NMR experiment is to cause a transition between these two states by absorption of radiation. It can be

FIGURE 5.2 In the presence of an applied magnetic field, B_0 , shown parallel to the +z-axis, a spinning nucleus precesses about the magnetic field axis in a circular manner. The nucleus is shown spinning counterclockwise arrow with white head. The bold arrow with the black head represents the axis of rotation which traces the circular path shown.



seen from Figure 5.1 that a transition between these two energy states can be brought about by absorption of radiation with a frequency that is equal to ΔE according to the relationship $\Delta E = h v$.

The difference in energy between the two quantum levels of a nucleus with I = 1/2 depends on the applied magnetic field B_0 and the magnetic moment μ of the nucleus. The relationship between these energy levels and the frequency ν of absorbed radiation is calculated as follows. E is the expression for a given nuclear energy level in a magnetic field:

(5.3)
$$E = -m\left(\frac{\mu}{I}\right)B_0 = -m\left(\gamma \frac{h}{2\pi}\right)B_0$$

where m is the magnetic quantum number; μ , the nuclear magnetic moment; B_0 , the applied magnetic field; I, the spin quantum number γ , the magnetogyric ratio; and h, Planck's constant.

Equation 5.3 is the general equation for a given energy level for all nuclei that respond in NMR. However, if we confine our discussion to the 1 H nucleus, then I = 1/2. Therefore, there are only two levels.

For two energy levels with m = +1/2 and -1/2, respectively,

(5.4)
$$\Delta E = E_{-1/2} - E_{+1/2} = h v$$

and

(5.5)
$$\Delta E = h v = \gamma \frac{h}{2\pi} B_0 = \frac{\mu}{I} B_0 = 2\mu B_0$$

Therefore, the absorption frequency that can result in a transition of ΔE is:

$$v = \gamma \frac{B_0}{2\pi}$$

Equation 5.6 can be written as

$$(5.7) \omega = \gamma B_0$$

where ω is the frequency in units of rad/s.

Equation 5.7 is the **Larmor equation**, which is fundamental to NMR. It indicates that for a given nucleus there is a direct relationship between the frequency ω of RF radiation absorbed by that nucleus and the applied magnetic field B_0 . This relationship is the basis of NMR.

The absorption process can be understood in terms of a classical approach to the behavior of a charged particle in a magnetic field. The spinning of the charged nucleus (Figure 5.2) produces an angular acceleration, causing the axis of rotation to move in a circular path with respect to the applied field, called precession. The frequency of precession can be calculated from classical mechanics to be $\omega = \gamma B_0$, the Larmor frequency. Both quantum mechanics and classical mechanics predict that the frequency of radiation that can be absorbed by a spinning charged nucleus in a magnetic field is the Larmor frequency.

As shown in Figure 5.2, the axis of rotation of the precessing hydrogen nucleus is at an angle θ to the applied magnetic field. The energy of the precessing nucleus is equal to $E = \mu B_0 \cos\theta$. When energy in the form of RF radiation is absorbed by the nucleus, the angle θ must change. For a proton, absorption involves "flipping" the magnetic moment from being aligned with the field to being aligned against the applied field. When the rate of precession equals the frequency of the RF radiation applied, absorption of RF radiation takes place. The nucleus then become aligned *opposed* to the magnetic field and is in an excited state. To measure organic compounds containing protons by NMR, the sample is first put into a magnetic field and then irradiated with RF radiation. When the frequency of the radiation satisfies Equation 5.7, the magnetic component of the radiant energy becomes absorbed. If the magnetic field B_0 is kept




FIGURE 5.3 60 MHz proton NMR spectrum of methyl iodide, CH₃I. (From the Sadtler Handbook of Proton NMR Spectra, W.W. Simons, ed., Sadtler Research Laboratories, Inc., Philadelphia, PA, 1978. Now Bio-Rad Laboratories, Inc., Informatics Division, Sadtler Software and Databases. Copyright Bio-Rad Laboratories, Informatics Division, Sadtler Software and Databases, 2020. All rights reserved.)

constant, we may plot the absorption against the frequency v of the RF radiation. The same experiment could be done by holding the RF frequency constant and varying B_0 . An actual NMR spectrum with absorption at a single frequency is shown in Figure 5.3. NMR spectra of the compound toluene are shown in Figure 5.4. Figure 5.4(b) is the 300 MHz proton spectrum; 5.4c is the 60MHz proton spectrum. Figure 5.4(a) is the ^{13}C spectrum.

When a nucleus absorbs energy, it becomes excited and reaches an excited state. It then loses energy and returns to the unexcited state. Then it reabsorbs radiant energy and again enters an excited state. The nucleus alternately becomes excited and unexcited and is said to be in a state of *resonance*. This is where the term resonance comes from in nuclear magnetic resonance spectroscopy.

Magnetic field strengths are given in units of tesla (T) or gauss (G). The relationship between the two units is 1 T = 10^4 G. If the applied magnetic field is 14,092 G (or 1.41 T), the frequency of radiation absorbed by a proton is 60 MHz. The nomenclature "60 MHz proton NMR" indicates the RF frequency for proton resonance and also defines the strength of the applied magnetic field if the nucleus being measured is specified. For example, the 13 C nucleus will also absorb 60 MHz RF radiation, but the magnetic field strength would need to be 56,000 G. Similarly, a 100 MHz proton NMR uses 100 MHz RF and a magnetic field of $14,092 \times 100/60 = 23,486$ G (2.35 T) for 1 H measurements. At that field strength, a 13 C nucleus would absorb at 25.1 MHz due to its very different magnetogyric ratio. If a frequency is specified for an NMR instrument without specifying the nucleus, the proton is assumed (e.g., a 500 MHz NMR would be assumed to refer to an instrument with a magnetic field strength such that a proton will absorb at 500 MHz).

5.1.2.1 SATURATION AND MAGNETIC FIELD STRENGTH

The energy difference ΔE between ground state and excited state nuclei is very small. The number of nuclei in the ground state is the number lined up with the magnetic field B_0 . The ratio of excited nuclei to unexcited nuclei is defined by the Boltzmann distribution:

(5.8)
$$\frac{N^*}{N_0} = e^{-\Delta E/kT} = e^{-\gamma h B_0/2\pi kT}$$




FIGURE 5.4 (a) The ¹³C NMR spectrum of toluene and (b) the 300 MHz proton NMR spectrum of toluene. Reprinted with permission of Aldrich Chemical Company, LLC. (c) The 60 MHz proton NMR spectrum of toluene. The structure of toluene is shown, with Me indicating a methyl group, —CH₃. Two groups of absorption peaks are seen, one due to the protons of the methyl group, and the other to the aromatic ring protons. ([Figure 5.4(c)] from the Sadtler Handbook of Proton NMR Spectra, W.W. Simons, ed., Sadtler Research Laboratories, Inc., Philadelphia, PA, 1978. Now Bio-Rad Laboratories, Inc., Informatics division, Sadtler Software and Databases. Copyright Bio-Rad Laboratories, Informatics Division, Sadtler Software and Databases, 2020. All rights reserved.)

where N is the number of excited nuclei and N_0 , the number of unexcited (ground state) nuclei. For a sample at 293 K in a 4.69 T magnetic field, the ratio $N/N_0=0.99997$. There are almost as many nuclei in the excited state as in the ground state because the difference between the two energy levels is very small. Typically, for every 100,000 nuclei in the excited state, there may be 100,003 in the ground state, as in this case. This is always the case in NMR; the Boltzmann ratio is always very close to 1.00. For this reason, NMR is inherently a low-sensitivity technique.

A system of molecules in the ground state may absorb energy and enter an excited state. A system of molecules in an excited state may emit energy and return to the ground state. A signal can be seen only if there is an excess of molecules in the ground state. If the number of molecules in the ground state is equal to the number in the excited state, the net signal observed is zero and no absorption is noted.

The excess of unexcited nuclei over excited nuclei is called the *Boltzmann excess*. When no radiation falls on the sample, the Boltzmann excess is maximum, N_x . When radiation falls on the sample, however, an increased number of ground-state nuclei become excited and a reduced number remain in the ground state. If the RF field is kept constant, a new equilibrium is reached and the Boltzmann excess decreases to N_s . When $N_s = N_x$, absorption is maximum. When $N_s = 0$, absorption is zero. The ratio N_s/N_x is called Z_0 , the **saturation factor**.

If the applied RF field is too intense, all the excess nuclei will be excited, $N_s \to 0$, and absorption $\to 0$. The sample is said to be **saturated**. The saturation factor Z_0 is:

(5.9)
$$Z_0 = (1 + \gamma^2 B_1^2 T_1 T_2)^{-1}$$

where γ is the magnetogyric ratio, B_1 is the intensity of RF field, and T_1 , T_2 are, respectively, the longitudinal and transverse relaxation times (discussed in Section 5.1.3.2).

As a consequence of this relationship, the RF field must not be very strong so as to avoid saturation. Under certain experimental conditions, however, saturation of a particular nucleus can provide important structural information (Section 5.3).

From Equation 5.8, we can derive the expression:

(5.10)
$$\frac{N^{*}}{N_{0}} = 1 - \frac{\gamma h B_{0}}{2\pi kT} = 1 - \frac{2\mu B_{0}}{kT}$$

which shows that the relative number of excess nuclei in the ground state is related to B_0 . As the magnetic field strength increases, the NMR signal intensity increases. This is the driving force behind the development of high field strength magnets for NMR.

5.1.3 WIDTH OF ABSORPTION LINES

The resolution or separation of two absorption lines depends on how close they are to each other and on the absorption linewidth. The width of the absorption line (i.e., the frequency range over which absorption takes place) is affected by a number of factors, only some of which we can control. These factors are discussed below.

5.1.3.1 THE HOMOGENEOUS FIELD

An important factor controlling the absorption linewidth is the applied magnetic field B_0 . It is very important that this field be constant over all parts of the sample, which may be 1-2 in. long. If the field is not homogenous, B_0 is different for different parts of the sample and therefore the frequency of the absorbed radiation will vary in different parts of the sample, as described by Equation 3.7. This variation results in a wide absorption line. For molecular structure determination, wide absorption lines are very undesirable, since we may get overlap between neighboring peaks and loss of structural information. The magnetic field must be constant within a few ppb over the entire sample and must be stable over the time required to collect the data. This time period is short for routine ^1H and ^{13}C measurements, on the order of 5-30 min, but may be hours or days for complex analyses. Most magnets used in NMR instruments do not possess this degree of stability. Several different experimental techniques are used to compensate for field inhomogeneity, such as spinning the sample holder in the magnetic field. Most instruments require magnetic field shimming to improve (or at least fine tune) the magnetic field homogeneity. This is done by use of multiple shim coils that are electronically energized to produce slight magnetic fields. These coils can be

controlled by the operator, manually, or by the console computer. In most cases, the analyst will allow the computer to take care of shimming automatically. Indeed, in a well-shimmed magnetic field, it may not be necessary (or desirable) to spin the sample.

5.1.3.2 RELAXATION TIME

Another important feature that influences the absorption linewidth is the length of time that an excited nucleus stays in the excited state. The **Heisenberg uncertainty principle** tells us that:

$$\Delta E \Delta t = \text{constant}$$

where ΔE is the uncertainty in the value of E and Δt is the length of time a nucleus spends in the excited state. Since $\Delta E \Delta t$ is a constant, when Δt is small, ΔE is large. But we know that $\Delta E = h v$ and that h is a constant. Therefore, any variation in E will result in a variation in E is not an exact number but varies over the range $E + \Delta E$, then E will not be exact but will vary over the corresponding range E and E are restated as:

(5.12)
$$E + \Delta E = h(v + \Delta v)$$

We can summarize this relationship by saying that when Δt is small, ΔE is large and therefore Δv is large. If Δv is large, then the frequency range over which absorption takes place is wide and a wide absorption line results.

The length of time the nucleus spends in the excited state is Δt . This lifetime is controlled by the rate at which the excited nucleus loses its energy of excitation and returns to the unexcited state. The process of losing energy is called **relaxation**, and the time spent in the excited state is the **relaxation time**. There are two principal modes of relaxation: longitudinal and transverse. **Longitudinal relaxation** is also called spin-lattice relaxation; **transverse relaxation** is called spin-spin relaxation.

Longitudinal relaxation T_1 . The entire sample in an NMR experiment, both absorbing and non-absorbing nuclei, is called the **lattice**. An excited state nucleus (said to be in a *high spin* state) can lose energy to the lattice. When the nucleus drops to a lower energy (low spin) state, its energy is absorbed by the lattice in the form of increased vibrational and rotational motion. A very small increase in sample temperature results in spin-lattice (longitudinal) relaxation. This process is quite fast when the lattice molecules are able to move quickly. This is the state of affairs in most liquid samples. The excitation energy becomes dispersed throughout the whole system of molecules in which the analyte finds itself. No radiant energy appears; no other nuclei become excited. Instead, as numerous nuclei lose their energy in this fashion, the temperature of the sample rises very slightly. Longitudinal relaxation has a relaxation time, T_1 , which depends on the magnetogyric ratio and the lattice mobility. In solids or viscous liquids, T_1 is large because the lattice mobility is low.

Transverse relaxation T_2 . An excited nucleus may transfer its energy to an unexcited nucleus nearby. In the process, a proton in the nearby unexcited molecule becomes excited and the previously excited proton becomes unexcited. There is no net change in energy of the system, but the length of time that one nucleus stays excited is shortened because of the interaction. The average excited state lifetime decreases and line broadening results. This type of relaxation is called transverse relaxation or spin-spin relaxation, with a lifetime T_2 .

It is found in practice that in liquid samples the net relaxation time is comparatively long and narrow absorption lines are observed as in Figure 5.4. In solid samples, however, the transverse relaxation time T_2 is very short. Consequently ΔE and therefore Δv are large. For this reason, solid samples generally give wide absorption lines. As we will see, solid samples require a different set of experimental conditions than liquids to give useful analytical information from their NMR spectra. One approach is to make the solid behave more like a liquid. For example, solid polymer samples normally give broad NMR spectra. But if they are "solvated", narrower lines are obtained and the spectra are more easily interpreted. A sample is "solvated" by dissolving a small amount of solvent into the polymer. The polymer swells

and becomes jelly-like but does not lose its chemical structure. The solvating process greatly slows down transverse relaxation and the *net* relaxation time is increased. The linewidth is decreased and resolution of the spectrum for structural information is better.

5.1.3.3 THE CHEMICAL SHIFT

The movement of electrons in the sample, close to the nucleus being excited, will produce small magnetic fields that will affect the field "felt" by that nucleus. These small magnetic fields will counteract the applied magnetic field of the instrument. This effect is called shielding. Because of this shielding, less energy is required to excite the nucleus from one spin state to another. Since this energy is proportional to the frequency, v, the absorption will be observed at a lower value of v. This change is called the chemical shift, and it is usually expressed as a difference with some reference molecule. For proton NMR, the typical reference is tetramethylsilane, or TMS. Since this concept is critical to structure determination, especially in organic molecules, you will have no doubt studied it in organic chemistry, and a review of that material might be helpful. Moreover, a more in-depth discussion of chemical shift is presented later in this chapter.

5.1.3.4 MAGIC ANGLE SPINNING

A problem with the examination of solids is that the nuclei can be considered to be frozen in space and cannot freely line up in the magnetic field. The NMR signals generated are dependent, among other things, on the orientation of the nuclei to the magnetic field. Since the orientation of nuclei in solids is fixed, each nucleus (even chemically identical nuclei) "sees" a different applied magnetic field, resulting in broad NMR spectra. The effective magnetic field seen by a nucleus depends on the chemical environment in which the nucleus finds itself; the position at which a given nucleus resonates is the chemical shift, **as discussed above**. The phenomenon in solids of nuclei having different chemical shifts **as a result of orientation in space** is called **chemical shift anisotropy**.

The chemical shift due to magnetic anisotropy is directly related to the angle between the sample and the applied magnetic field. It has been shown theoretically and experimentally that by spinning the sample at an angle of 54.76° to the magnetic field, the **magic angle**, rather than the usual 90° for liquid sample analysis, the chemical shift anisotropy is eliminated and narrow line spectra are obtained. This is called magic angle spinning (MAS). Figure 5.5 demonstrates the difference in ¹³C NMR spectra of a solid with and without magic angle spinning (MAS). The spectrum in Figure 5.5(a) was taken without spinning (i.e., static), on a crystalline powder sample of L-DOPA. The spectrum has broad, unresolved lines and does not provide much useful information. The same sample is then spun at 9.6 kHz at the magic angle, 54.76°. The spectrum obtained is shown in Figure 5.5(b). The linewidths are dramatically decreased and seven carbon peaks are resolved, providing significant structural information about the compound. The spinning is carried out at very high frequencies (5-15 kHz) for optimum performance. This spinning gives better resolution and improved measurement of chemical shift and spin-spin splitting. The functional groups and their positions relative to each other in the solid sample molecule can be determined, as will be discussed.

Special probes have been developed for solid-state NMR that automatically position the sample at the magic angle. Modern instruments with magic angle spinning (MAS) make the analysis of solid samples by NMR a routine analytical procedure. MAS, combined with two RF pulse techniques called cross-polarization and dipolar decoupling (discussed in Section 5.6.4), permits the use of the low abundance nuclei ¹³C and ²⁹Si to analyze insoluble materials by NMR, including highly cross-linked polymers, glasses, ceramics, and minerals.

5.1.3.5 OTHER SOURCES OF LINE BROADENING

Any process of *deactivating* or relaxing an excited molecule results in a decrease in the lifetime of the excited state. This in turn causes line broadening. Other causes of deactivation include: (1) the presence of ions—the large local charge deactivates the nucleus; (2) paramagnetic




FIGURE 5.5 (a) The ¹³C NMR spectrum of solid powdered L-DOPA obtained without spinning the sample. (b) The ¹³C spectrum of the same sample obtained with MAS at a frequency of 9.6 kHz. Note the dramatic decrease in linewidth and increase in resolution when using MAS to obtain the NMR spectrum of a solid sample. (Spectra provided courtesy of Dr. James Roberts, Department of Chemistry, Lehigh University, PA.)

molecules such as dissolved ${\rm O_2}$ —the magnetic moment of electrons is about 10^3 times as great as nuclear magnetic moments and this high local field causes line broadening; and (3) nuclei with quadrupole moments. Nuclei in which I>1/2 have quadrupole moments, which cause electronic interactions and line broadening; one important nucleus with a quadrupole field is $^{14}{\rm N}$, present in many organic compounds such as amines, amides, amino acids, and proteins.

5.2 THE FTNMR EXPERIMENT

The time required to record an NMR spectrum by scanning either frequency or magnetic field is Δ/R , where Δ is the spectral range scanned and R the resolution required. For 1H NMR, the time required is only a few minutes because the spectral range is small, but for ^{13}C NMR, the chemical shifts are much greater; consequently, the spectral range scanned is much greater and the time needed to scan is long. For example, if the range is 5 kHz and a resolution of 1 Hz is required, the time necessary would be (5000 s)/1 or 83 min, an unacceptably long time for routine analysis, and an impossible situation if rapid screening of thousands of compounds is needed, as it is in the development of pharmaceuticals.

This problem and quite a few other problems with the NMR experiment were overcome with the development of FTNMR. The fundamentals of FT spectroscopy and the advantages gained through the use of FT spectroscopy were discussed in Chapter 2 for optical spectroscopy. In FTNMR, the RF frequency is applied to the sample as a short, strong "pulse" of radiation. The experiment is shown schematically in Figure 5.6. Because there are slightly more nuclei lined up with the field, the excess nuclei in the ground state can be thought of as having a single magnetic moment lined up with the external field, B_0 . This net magnetization is shown in Figure 5.6(d) as M_z . The net magnetization behaves as a magnet. An electric current applied to a coil of wire surrounding a magnet will cause the magnet to rotate. An RF pulse through a coil of wire around the sample is used to generate a second magnetic field,




FIGURE 5.6 The pulsed NMR experiment. (a) NMR-active nuclei have magnetic dipole moments. **(b)** In the presence of an external static field, B_0 , the dipoles precess about the field axis, each with an average component either parallel or antiparallel to the field. (c) In this case, there are two spin populations precessing in opposite directions represented by the two cones. At equilibrium, the top cone (the dipoles with components parallel to the field) has a slightly greater population. (d) The difference between the two populations is represented by the net magnetization, M_2 . The NMR signal derives from M_2 , which can be observed by rotating it into the plane of an RF coil using a resonant RF field, B_1 . (e) B_1 is usually gated on just long enough to rotate M_z into the x-y plane. After B_1 is gated off, the net magnetization M_{xy} begins to rotate about the z-axis at a frequency equal to the difference in precession frequencies for the two populations. (f) This rotating M_{xy} induces an emf in the RF coil along the x-axis. The signal appears as a cosine wave decaying in time following the pulse, and is referred to as FID. (From Petersheim, M., Nuclear Magnetic Resonance, in Ewing, G.A., Ed., Analytical Instrumentation Handbook, 2nd edn., Marcel Dekker, Inc., New York, 1997. Used with permission.) (g) Free induction decay and resulting ¹³C frequency spectrum after Fourier transformation for an organic compound containing multiple absorption frequencies due to chemically different carbon nuclei. (From Williams, E.A., Polymer Molecular Structure Determination, in Lifshin, E., Ed., Characterization of Materials, Part I, VCH Publishers, Inc., New York, 1992. Copyright Wiley-Vch Verlag GmbH & Co. KGaA. Used with permission.)

 B_1 , at right angles to B_0 ; this provides the excitation step in the NMR experiment. In a modern NMR instrument, the field B_1 is applied as a **pulse** for a very short time, on the order of 10 µs, with a few seconds between pulses. The net magnetic moment of the sample nuclei is shifted out of alignment with B_0 by the pulse [Figure 5.6(e)]. Most often, a 90° pulse is used; the net magnetization vector is shifted 90° (from the z-axis to the y-axis). Such a 90° change gives the largest signal possible. The pulse is discontinued and the excited nuclei precess around the applied magnetic field at an angle to B_0 . This "rotating magnet" induces a current in the wire coil. This induced current is the NMR signal and is picked up by the coil very quickly after the B_1 pulse ends. The signal undergoes free induction decay (FID); the current decreases with time as the freely precessing nuclei relax back to the ground state, as shown in Figure 5.6(f). This FID signal is a time-domain signal and must be processed using a Fourier transform (or another mathematical transform) to produce the usual frequency-domain spectrum. Because all frequencies are excited simultaneously, the FID signal consists of one exponentially decaying cosine wave for each frequency component in the spectrum. This type of pattern for a ¹³C experiment is shown in Figure 5.6(g) as the dense black multiple line signal at the top of the diagram, along with the Fourier transformation of the FID, resulting in the frequency-domain ¹³C spectrum shown at the bottom of the diagram.

One advantage of the FTNMR experiment is that the entire spectrum is taken in a single pulse. This occurs because pulsing the RF field broadens the frequency distribution of the RF source. All resonances within several kHz of the source frequency are excited simultaneously. While the intensity of the FID signal is very low, the process may be repeated many times very rapidly, for example, 8192 times in 0.8 s. The signal increases linearly, but the noise increases only as the square root of the number of readings. The net effect is a significant improvement in the signal-to-noise ratio, as seen in Figure 5.7. This directly improves the




FIGURE 5.7 From top to bottom: **(a)** A 100.62 MHz ¹³C NMR FID obtained from a single pulse. **(b)** The resulting Fourier transform. **(c)** The resulting FID after adding together 200 FIDs. **(d)** The resulting Fourier transform of the sum of 200 FIDs, showing the improvement in signal [compare peak heights in (b) and (d)] and the reduction in noise [compare the baselines in (b) and (d)]. (From Akitt, J.W. and Mann, B.E., NMR and Chemistry, 4th edn., CRC/Taylor & Francis, Boca Raton, FL, 2000. With permission.)

sensitivity of the method. Signals can be obtained that are orders of magnitude more sensitive than those obtained with "continuous wave" NMR. FTNMR is now the major type of NMR instrumentation being manufactured; it is critical to obtaining ¹³C NMR spectra and in performing 2D NMR experiments.

5.3 CHEMICAL SHIFTS

From the Larmor equation, it would seem that all protons in a sample in a given applied magnetic field would absorb at exactly the same frequency. NMR would therefore tell us only that protons were present in a sample. The same would be true for ¹³C; NMR would tell us only that carbon was present. If NMR were suitable only for detecting and measuring the presence of hydrogen or carbon in organic compounds, it would be a technique with very limited usefulness. There are a number of other fast, inexpensive methods for detecting and measuring hydrogen and carbon in organic compounds. Fortunately, this is not the case. In the NMR experiment, protons in different chemical environments within a molecule absorb at slightly different frequencies. This variation in absorption frequency is caused by a slight difference in the electronic environment of the proton as a result of different chemical bonds and adjacent atoms. The absorption frequency for a given proton depends on the chemical structure of the molecule. This variation in absorption frequency, as we introduced earlier, is called the **chemical shift**. The same type of chemical shift occurs for carbon in different chemical environments within a molecule. The physical basis for the chemical shift is as follows.

Suppose that we take a molecule with several different "types" of hydrogen atoms, such as the molecule ethanol, CH_3CH_2OH . This molecule has hydrogen atoms in three different chemical (and therefore magnetic) environments: the three hydrogen atoms in the terminal CH_3 , the two hydrogen atoms in the CH_2 group, and the one in the OH group. Consider the nuclei of the different types of hydrogen. Each one is surrounded by orbiting electrons, but the orbitals may vary in shape and the bonds vary in electron density distribution. This changes the length of time the electrons spend near a given type of hydrogen nucleus. Let us suppose that we place this molecule in a strong magnetic field B_0 . The electrons associated with the nuclei will be rotated by the applied magnetic field B_0 . This rotation, or *drift*, generates a small magnetic field σB_0 , which opposes the much larger applied magnetic field B_0 . The nuclei are *shielded* slightly from the applied magnetic field by the orbiting electrons. The extent of the shielding depends on the movement of the electrons caused by the magnetic field (not by the simple orbiting of the electrons). If the extent of this shielding is σB_0 , then the nucleus is not exposed to the full field B_0 , but to an *effective* magnetic field at the nucleus, B_{eff} .

$$(5.13) B_{\text{eff}} = B_0 - \sigma B_0$$

where B_{eff} is the effective magnetic field at the nucleus; B_0 , the applied field; σB_0 , the shielding by the drift of local electrons and σ is the *screening constant* or *diamagnetic shielding constant*.

In the case of ethanol, σB_0 is different for each type of hydrogen; therefore, the effective field $B_{\rm eff}$ is different for each type of hydrogen. In order to get absorption at frequency v, we must compensate for this variation by varying B_0 . In other words, resonance of the hydrogen atoms in different chemical environments takes place at slightly different *applied* magnetic fields. Another way of expressing this relationship is that if the applied field is kept constant, the nuclei in different chemical environments resonate at slightly different frequencies. A shielded nucleus resonates or absorbs at a lower frequency than an unshielded nucleus. This change in frequency of absorption because of shielding is the chemical shift. Instead of one absorption signal for the protons in ethanol, we would predict three absorption signals at slightly different frequencies. Figure 5.8 is a schematic low-resolution proton NMR spectrum of ethanol; three absorption peaks are seen. Looking at the structure of ethanol, we can also predict what the 13 C NMR spectrum should look like. There are two chemically different C atoms in the molecule—the methyl carbon and the methylene carbon; two peaks should be seen in the 13 C NMR spectrum of ethanol. It is important to note that $B_{\rm eff}$ and the




FIGURE 5.8 Schematic low-resolution proton NMR absorption spectrum of ethanol, CH₃CH₂OH.

peak separations resulting from the chemical shift differences are directly proportional to the applied magnetic field strength. This is another reason for the development of high field strength magnets: better resolution and more structural information result.

The chemical shifts of nuclei are measured (and defined) relative to a standard nucleus. As mentioned earlier, a popular standard for proton NMR is tetramethylsilane (TMS), which has the chemical formula Si(CH₃)₄. In this compound, all 12 hydrogen nuclei are chemically (and magnetically) equivalent; that is, they are all exposed to the same shielding and give a single absorption peak. The chemical shift for other hydrogen nuclei is represented as follows:

(5.14) Chemical shift =
$$\frac{\mathbf{v}_S - \mathbf{v}_R}{\mathbf{v}_{\text{NMR}}}$$

where v_S is the resonant frequency of a specific nucleus; v_R , the resonant frequency of the reference nucleus; and v_{NMR} , the spectrometer frequency.

The chemical shift is the difference in the observed shift between the sample and the reference compound divided by the spectrometer frequency. It is a dimensionless number. Typical values for the frequency difference between a nucleus and the reference are in the Hz or kHz range; the spectrometer frequency is in the MHz range. In order to make these numbers easier to handle, they are usually multiplied by 10^6 and then expressed in ppm. (This unit should not be confused with the concentration expression ppm used in trace analyses.) The symbol for the chemical shift is δ . It is expressed as:

$$\delta = \frac{v_{S} - v_{R}}{v_{NMR}} \times 10^{6} \, \text{ppm}$$

Look at Figure 5.13(b). The x-axis has units of chemical shift in ppm. The TMS peak is the single peak located at 0.0 ppm, by definition. It is a convention that NMR spectra are presented with the magnetic field increasing from left to right along the x-axis. Diamagnetic shielding therefore also increases from left to right. A nucleus that absorbs to the right-hand side of the spectrum is said to be *more shielded* than a nucleus that absorbs to the left side of the spectrum. One reason TMS is used as the reference peak is that the protons in common organic compounds are generally de-shielded with respect to TMS; the TMS peak appears at the far right of the spectrum. Look at the proton spectra in Figure 5.4(b) and (c) again—the x axis is in ppm, although it is not marked as such in the 300 MHz spectrum, and both show the TMS peak at 0.0 ppm. The student should be able to recognize that this means that δ decreases from left to right along the x-axis in proton NMR spectra. This is not the way one normally plots numbers; they are usually plotted increasing from left to right. An alternative scale was developed, where the chemical shift was plotted as τ , with τ defined as:

(5.16)
$$\tau = 10.00 - \delta \text{ (ppm)}$$

This tau scale is no longer used, but can be found in the literature through the 1970s, as can the now unused terms up-field and downfield to refer to resonance positions. The terminology that should be used is de-shielded (higher δ) or shielded (lower δ). Shielding by the drifting electrons is modified by other nuclei in their vicinity. These in turn are affected by the chemistry, geometry, and electron density of the system. Consequently, some de-shielding takes place in most molecules; the end result is that chemically identical nuclei are shifted

from chemically different nuclei. De-shielded nuclei would be moved to the left on the NMR plot. As a result, we are able to distinguish different functional groups in a molecule, even ones that contain the same atoms; methyl groups are separated from methylene groups, as seen in the ethanol spectrum. Two examples of how shielding and de-shielding occur based on the geometry of the molecule are shown in Figure 5.9. Figure 5.9(a) and 5.9(b) show the molecule acetylene. When the long axis of the molecule is aligned with the external magnetic field, the circulation of the π electrons in the triple bond, shown by the partially shaded curved arrow in Figure 5.9(a), induces a magnetic field along the molecular axis that opposes the applied field. The induced magnetic field lines are shown in Figure 5.9(b). The arrows show the direction of the induced magnetic field lines at the positions of the hydrogen atoms. Both of the protons in acetylene are shielded from the applied magnetic field by the induced magnetic field. The field these protons experience is $B_0 - B_{local}$, which is smaller than B_0 . Therefore, a higher frequency is needed to attain resonance. Figure 5.9(c) and (d) show the molecule benzene, a planar molecule with one proton on each carbon atom. The protons are located on the outside of the carbon ring in the plane of the ring. Only two of the six protons attached to the ring are shown here. The delocalized π electrons are depicted as the circle inside the carbon hexagon. When the benzene ring is perpendicular to the applied magnetic field, the delocalized electrons circulate as shown by the partially shaded curved arrow in Figure 5.9(c) and generate an induced magnetic field as depicted in Figure 5.9(d). In this case, the induced magnetic field shown reinforces the applied magnetic field outside the ring; all of the protons on the benzene ring feel a stronger field than B_0 . They are de-shielded by the induced field caused by the ring current. The field these protons experience is $B_0 + B_{local}$, so a lower frequency needs to be applied for resonance to occur. The term anisotropic effect or chemical shift anisotropy means that different chemical shifts occur in different directions in a molecule.




FIGURE 5.9 (a) and (b) Circulation of the π electrons in the C=C bond in acetylene is shown by the partially shaded arrow in (a). The direction of the induced magnetic field, B_{local} , at the hydrogen atoms is shown by the arrows in (b). The direction of the applied field, B_0 , is shown. The two protons are shielded from the applied field by the induced local field. (c) and (d) Circulation of the π electrons in the benzene ring, shown by the partially shaded arrow in (c), induces the magnetic field, B_{local} , shown in (d). Arrows show the induced and the applied magnetic field directions. All six protons in the plane of the benzene ring are de-shielded by the induced local magnetic field. ((b) and (d) are from McClure, used with permission.)


It is the chemical shift that allows us to identify which functional groups are present in a molecule or a mixture. Chemical shift enables us to ascertain what types of hydrogen nuclei are present in a molecule by measuring the shift involved and comparing it with known compounds run under the same conditions. For example, it is easy to distinguish between aromatic and aliphatic hydrogen atoms, alkenes, alkynes, or hydrogen bonded to oxygen or nitrogen, hydrogen on a carbon adjacent to ketones, esters, etc. Examples of typical chemical shifts for protons are given in Table 5.3. More extensive tables of chemical shifts can be found in the references by Bruno and Svoronos, Silverstein and Webster, Pavia et al. and Lambert et al. listed in the bibliography.

TABLE 5.3 Approximate Chemical Shifts of Protons in Common Organic Compounds

		Chemical Shift (ppm)			
(a) Type of Hydrogen	a	b	c	d	
TMS		• 0			
CH ₃					
CH ₃ — Si — CH ₃					
CH ₃ CH ₂ CH ₂ CH ₃ a b b a	• 1.0	• 1.2			
$\begin{array}{c} \operatorname{CH_3(c)} \\ \\ \operatorname{CH_3CH_2} - \operatorname{C} - \operatorname{CH_2CH_3} \\ \operatorname{a \ b \ } \operatorname{b \ a} \\ \operatorname{CH_3(c)} \end{array}$	• 1.0	• 1.2	• 2.0		
CH ₃ CH ₂ Br a b	• 1.2	• 3.48			
CH ₃ CH ₂ I a b	• 1.8	• 3.2			
CH ₃ CH ₂ OH a b c	• 1.32	• 3.7	• 0.5–4.0		
CH ₃ C=O a OH (b)	• 2.1	• 11.4			
CH ₃ CH ₂ CH ₂ NH ₂ a b c d	• 0.92	• 1.5	• 2.7	• 1.1	
$CH_3CH_2CH = CH_2$ a b c d	• .9	• 2.0	• 5.8	• 4.9	
$CH_3CH_2CH = CHCH_2CH_3$ a b c c b a	• 1.0	• 1.3	• 5.4		
CH ₃ CH ₂ CH — CH ₃ a b c d NO ₂	• 1.0	• 1.9	• 4.2	• 1.5	
CH ₃ C—CH ₂ CH ₃ a b c O	• 2.1	• 2.5	• 1.1		
CH ₃ CH ₂ S—CH ₃ a b c	• 1.3	• 2.53	• 2.1		
CH ₃ CH ₂ C≡CH a b c	• 1.0	• 2.2	• 2.4		
H(d) CH ₃ CH ₂ CH ₂ C a b c	• 1.0	• 1.7	• 2.4	• 9.7	

(continued)

TABLE 5.3 (continued)



¹H/ppm

Source: (d) With kind permission from Springer Science+Business Media: Multinuclear NMR, 1987, Akitt, J.W., in Mason (ed.), Plenum Press, New York, 1987.

Notes: Chart of approximate ¹H chemical shift ranges of different types of protons in organic compounds. X = halogen; R = organic substituent; Ar = aryl substituent.

Figure 5.8 shows schematically the low-resolution spectrum of ethyl alcohol. This absorption spectrum, which is historically significant as one of the first NMR spectra to be recorded (Arnold et al., 1951), discloses that there are three types of hydrogen nuclei present in the ethanol molecule. Because NMR spectra provide valuable information about a molecule's structure, they are one of the most powerful tools available for characterizing unknown compounds or compounds for which we know the empirical formula but not the structure.

Most proton NMR spectra show more peaks than one would predict based on chemical equivalency. With improved instrumentation resulting in higher resolution, the absorption spectrum of ethyl alcohol has been found to be more complex than Figure 5.8 indicates. When examined under *high* resolution, each peak in the spectrum can be seen to be composed of several peaks. This **fine structure** is brought about by **spin-spin splitting** or **spin-spin coupling.**

5.4 SPIN-SPIN COUPLING

As we have already seen, the hydrogen nuclei of an organic molecule are spinning, and the axis of rotation may be with or against the applied magnetic field. Since the nucleus is magnetic, it exerts a slight magnetic field, which may be either with or against the applied magnetic field.

Suppose that we have a molecule such as the aldehyde shown, 1-butanal, also called butyraldehyde:

$$CH_3 - CH_2 - C - C = O$$

The low-resolution NMR spectrum for 1-butanal is shown in Figure 5.10. The protons on a given carbon atom are chemically equivalent to each other, but each group of protons is different from the rest. There are four chemically different groups of protons, labeled a-d in Figure 5.10. The low-resolution spectrum shows four peaks, as expected from the structure.

We will focus on the type c and type d protons first, and ignore the rest of the molecule for the moment. The type c protons are the two methylene protons adjacent to the aldehyde group; the type d proton is the single proton on the aldehyde carbon. The type d proton on the aldehyde group, represented as CHO, may be spinning either *with* or *against* the applied magnetic field. The spinning of the nucleus creates a small magnetic field, either with or against the applied magnetic field. This changes the effective field felt by the two protons of the adjacent CH_2 group. The CH_2 protons next to a CHO proton that is spinning *with* the field absorb at a slightly different frequency from that of the CH_2 protons next to a CHO proton spinning *against* the field. Statistically, a sample will contain as many protons spinning with the field as against it; so, both groups will be equally represented. The single spinning




FIGURE 5.10 Low-resolution proton NMR spectrum of 1-butanal, showing four absorption peaks. The *x*-axis is chemical shift in ppm; the *y*-axis is absorption. The four groups of chemically non-equivalent protons are labeled a-d on the chemical structure. The peak corresponding to each type of proton is marked with the corresponding letter. Table 5.3 (website) should be consulted to confirm the approximate chemical shifts for each type of proton.




FIGURE 5.11 A portion of the expected 1-butanal NMR spectrum showing spin-spin coupling between the aldehyde proton and the adjacent methylene group. The x-axis is chemical shift in ppm; The y-axis is absorption. Peaks (c) and (d) are shown, with peak (d) split into a triplet by the adjacent —CH₂— group and peak (c) split into a doublet by the aldehyde proton. (The rest of the molecule is ignored for the moment.)

proton of the CHO group splits the absorption peak (peak c in Figure 5.10) for the adjacent protons in the CH₂ group into two peaks absorbing at slightly different frequencies but of equal intensity (1:1 peak area ratio). The spin-spin splitting is shown schematically in Figure 5.11 (peak c). The two peaks are moved from the original frequency, one to a slightly higher frequency and one to a slightly lower frequency, but they are symmetrically located about the original frequency.

At the same time, the two protons of the CH_2 group are also spinning, and they affect the frequency at which the neighboring CHO proton absorbs. In this case, each of the protons of the CH_2 group can spin with or against the applied field. Several spin combinations are possible. These combinations may be depicted as in Figure 5.12, where the arrows indicate the directions of the magnetic fields created by the spinning nuclei. In a typical NMR sample, many billions of molecules are present, and each spin combination is represented equally by number. The three combinations (a), (b), and (c) in Figure 5.12 modify the applied field felt by the CHO to three different degrees, and absorptions occur at three frequencies for the CHO proton. It can be seen that there are two ways in which the combination of Figure 5.12(b) can exist, but only one way for the combination of Figure 5.12(a) or (c). There will therefore be twice as many nuclei with a magnetic field equal to the combination (b) as of either (a) or (c). As a result, the CH_2 group will cause the neighboring H of the CHO group to absorb at three slightly different frequencies with relative intensities in the ratio 1:2:1, as shown schematically in Figure 5.11 (peak d).

The relative peak intensities in a multiplet can be worked out from the possible combinations of spin states, as was done in Figure 5.12; the result is that the relative peak intensities

FIGURE 5.12 Possible alignments of the magnetic field of pairs of protons: (a) Both aligned with the applied field; B_0 appears to be increased in magnitude; (b) one aligned with the field and one against the field. There are two possible arrangements with equal probability. The net effect is that B_0 is unchanged; and (c) both aligned against the field; B_0 appears to be reduced in magnitude. (a)

(c)

in multiplets match the coefficients in the binomial expansion. Pascal's triangle can be used to rapidly assign peak intensities:

					1					
				1		1				
			1		2		1			
		1		3		3		1		
	1		4		6		4		1	
1		5		10		10		5		1

and so on. From the triangle relationship, it is seen that a quartet (fourth line from the top of the triangle) will have a 1:3:3:1 intensity ratio and a sextuplet (sixth line from the top) a 1:5:10:10:5:1 ratio.

The proton NMR spectrum of 1-butanal, $CH_3CH_2CH_2CHO$, is shown in Figure 5.13. Figure 5.13(a) is the predicted first order spectrum of 1-butanal, Figure 5.13(b) is a 60 MHz proton spectrum and Figure 5.13(c) is a 90 MHz proton spectrum. Looking at Figure 5.13(a), the aldehydic proton, peak d, appears as the 1:2:1 triplet just predicted, but peak c is not the 1:1 doublet predicted from the splitting by the aldehyde proton alone. We of course ignored for the simple argument above that the CH_2 group adjacent to the CHO group is also adjacent to another CH_2 group on the opposite side.

Spin-spin splitting or coupling is the transmission of spin state information between nuclei through chemical bonds. Spin-spin splitting is quite strong between protons on *adjacent* carbons, but is generally negligible between protons farther removed than this. It is important to remember that spin-spin splitting by a given nucleus causes a change in the fine structure of peaks for the *adjacent* protons in the molecule. For example, the CH₂ splits the H of the adjacent CHO group, and the H of the CHO group splits the adjacent CH₂, but the CH₂ *does not* split itself because that interaction is forbidden by quantum theory.

The number of peaks in the fine structure is termed the **multiplicity** of the peak. A multiplicity of two is called a doublet, a multiplicity of three, a triplet and so on. The multiplicity of proton peaks due to spin-spin splitting is

$$(5.17)$$
 $2nI + 1$

where n is the number of (magnetically) *equivalent hydrogen atoms* on the carbon atoms adjacent to the one whose proton peak is being examined and I is the spin quantum number. For hydrogen, I = 1/2 and Equation 5.17 simplifies to n + 1.

If two different adjacent groups cause splitting, the multiplicity is given by (2nI + 1)(2n'I + 1), where n and n' are the numbers of equivalent protons on each group.

Using Equation 5.17 and the structure of butanal, we can work out the splitting patterns expected. The predicted spectrum is Figure 5.13(a), which can be compared with the experimentally obtained spectra in Figure 5.13(b) and (c). We predicted that the aldehyde proton should be split into a triplet by the adjacent CH₂ protons; the peak at 9.7 ppm is a triplet. We predicted that the aldehyde proton would split the adjacent CH₂ group into a doublet, but we did not take into account the protons on the other side of this CH₂ group. There are two methylene protons (the "b" protons) next to the "c" methylene protons. This is a case of having two different groups, b and d, adjacent to the "c" protons we are interested in. The multiplicity is calculated from (2nI + 1)(2n'I + 1), so we have (2+1)(1+1) = 6. The multiplicity of the peak for the "c" protons should be 6. In Figure 5.13(b), the peak is found at 2.4 ppm and looks like a triplet with each triplet peak split into a doublet for a total of six peaks. The methyl protons (the "a" protons located at 1.0 ppm) are split into a triplet by the adjacent "b" methylene protons. The "b" methylene protons are split by both the methyl group (three equivalent protons) and the "c" methylene protons (two equivalent protons), so the multiplicity of the "b" proton peak should be (3+1)(2+1) = 12. While all 12 lines cannot be distinguished without expanding the scale around the peak at 1.7 ppm, it is clear, especially from the 90 MHz spectrum shown in Figure 5.13(c), that there are more than nine peaks present for the "b" peak. Spin-spin coupling allows one to predict splitting patterns for simple compounds.




FIGURE 5.13 (a) Predicted proton NMR spectrum for 1-butanal, showing spin-spin coupling. **(b)** 60 MHz proton NMR spectrum of 1-butanal. Note the peak for TMS and the presence of a small impurity peak at about 7 ppm; 60 MHz instruments required that chemical shifts greater than 8 ppm be plotted offset from the 0 to 8 ppm baseline. The aldehyde proton shift is plotted at the far left above the first baseline. **(c)** 90 MHz proton NMR spectrum of 0.04 mL 1-butanal dissolved in 0.5 mL CDCl₃. SDBS No. 1925HSP-04-071. (Courtesy of National Institute of Industrial Science and Technology, Japan, SDBSWeb: http://www.Aist.Go.jp/RIOBD/SDBS. Accessed December 13, 2002.)

The NMR spectrum of very dry ethanol is presented in Figure 5.14(a). The CH₃ protons are split by the CH₂ group into (2+1) = 3 peaks. The CH₂ is split by the OH proton and by the CH₃ protons, giving (3+1)(1+1) = 8 peaks. Finally, the OH proton is split into three peaks by the adjacent CH₂ group. The number of peaks due to spin–spin coupling equals (n + 1) only for nuclei where I = 1/2, which is the case for 1 H.




FIGURE 5.14 (a) The 300 MHz proton NMR spectrum of dry ethanol dissolved in deuterated dimethyl sulfoxide (DMSO). **(b)** Detailed splitting pattern of the methylene protons. The *J* value for the methyl-methylene coupling is 7 Hz, which splits the methylene protons into a quartet. The *J* coupling constant for the hydroxyl-methylene coupling is 5 Hz, so each peak in the quartet is split into a doublet. (From Silverstein and Webster; this material is used by permission of John Wiley and Sons, Inc.)

The magnitude of the separation between peaks in the fine structure is a measure of the strength of the magnetic interaction between the nuclei involved in the coupling. The magnitude of the separation is given the symbol *J*. The value of *J* is the **coupling constant** or **spin-spin coupling constant** between two nuclei, and is given the symbol J_{AB} , with A and B representing the coupled nuclei. The value of *J* is measured directly from the NMR spectrum by measuring the peak separation in the fine structure, and is usually expressed in Hz. Figure 5.14(a) is a proton spectrum collected at 300 MHz; the separation between the different peaks is improved over lower field instruments, but in order to see the splitting patterns the NMR spectroscopist must select and "expand" each peak. The expanded peak plots are shown either above the spectral peaks, or just off to the side of the peak. In very dry ethanol, the hydroxyl proton can be considered fixed on the oxygen atom. (This is not the case in "normal" ethanol, which contains water.) Therefore, the hydroxyl proton will be split by the adjacent methylene protons into a triplet, which appears at about 4.3 ppm. Looking at the expanded peak (inset above the hydroxyl peak), it can be seen that the triplet peaks occur at 1291, 1296, and 1301 Hz; that is, they are spaced 5 Hz apart. The J coupling constant between the methylene and hydroxyl protons, J_{AB} , is 5 Hz. The methyl group protons appear between 1.0 and 1.1 ppm; the peak is split into a triplet by the adjacent methylene protons. The J coupling constant between the methyl protons and the methylene protons is 7 Hz, as you can tell by measuring the distance in Hz between the peaks shown in the expanded inset just to the left of the methyl peak. Since we have used A for the hydroxyl proton, we would represent the methyl-methylene J as J_{BC} . We know that the methylene protons, at about 3.5 ppm, are split into eight peaks by the adjacent methyl and hydroxyl protons. Because the methyl-methylene constant, J_{BC} , is larger than the methylene–hydroxyl constant, J_{AB} , the methylene peak will be split first into a quartet, with each peak in the quartet separated by 7 Hz. Then each peak in the quartet will be split into a doublet, with a peak spacing of 5 Hz. The resulting pattern is shown in detail in Figure 5.14(b).

Measurement of the coupling constants by measuring the peak spacing tells us which protons are splitting each other; this helps in deducing the structure of an unknown from its NMR spectrum. J coupling constants provide valuable information to physical chemists and to organic chemists interested in molecular interactions. The magnitude of J does not change if the applied magnetic field changes, unlike the chemical shift.

The magnitude of the *J* coupling constant between protons on adjacent single-bonded carbons is between 6 and 8 Hz. The magnitude of *J* decreases rapidly as the protons move farther apart in a compound containing saturated C—C bonds. The introduction of multiple bonds or aromatic rings changes the value of *J* and also permits longer-range coupling. There is no coupling between protons on the same carbon. For example, in a compound such as butane,

$$\begin{array}{cccc} CH_3 - & CH_2 - & CH_2 - & CH_3 \\ A & B & C & D \end{array}$$

the coupling between the protons on carbon A is zero; the coupling between the protons on carbon A and those on carbon B is about 6–8 Hz ($J_{\rm AB}$ = 6–8). The coupling between the protons on carbon A and those on carbon C is never more than 1 Hz, that is, $J_{\rm AC}$ ≤ 1, and $J_{\rm AD}$ is very small and usually negligible. If one of the C—C bonds is replaced by a C=C, the adjacent protons on the carbon atoms would have a coupling constant of 7-10 Hz if the protons are on the same side of the double bond (cis); the coupling constant for trans protons is even larger, 12-19 Hz. The magnitude of the coupling constant therefore provides structural information about the compound.

The 13 C nucleus is also an I=1/2 nucleus; it would be expected that two adjacent 13 C nuclei would split the peak for each carbon into a doublet. Given that 13 C is only 1.1 % of naturally occurring carbon, the chance of finding more than one 13 C in a low molecular weight organic molecule is very small. The chance of finding two adjacent 13 C nuclei is even smaller. Consequently, C-C spin-spin coupling is not usually observed in carbon NMR spectra, unless special techniques or isotopically enriched molecules are studied. Values of J for carbon-carbon coupling have been measured using these special approaches and range from about 20 to 200 Hz.

Spin-spin interaction is also possible between 13 C and protons, and can be seen in both proton NMR and 13 C NMR spectra under the appropriate conditions. Owing to the low abundance of 13 C, the peaks due to 13 C– 1 H interactions are very small. In the proton spectrum of a neat liquid, they can be observed as weak satellite peaks, one on either side of the central proton peak.

Interpretation of NMR spectra can be very difficult if we consider all the multiplicities that are possible from the interactions of all the nuclei. If we confine ourselves to spectra in which the chemical shift between interacting groups is large compared with the value of *J*, the splitting patterns and the spectra are easier to interpret. This is called utilizing *first order spectra*.

The capital letters of the alphabet are used to define spin systems that have strong or weak coupling constants (actually large or small values of $\Delta \nu/J$ where $\Delta \nu$ is the difference in chemical shift between the nuclei, in Hz). For example, a system A_2B_3 indicates a system of two types of nuclei interacting strongly together of which there are two of type A and three of type B. For an AB system, the value of $\Delta \nu/J$ will be small; a value of 8 is an arbitrary limit. A break in the alphabetical lettering system indicates weak or no coupling, resulting in a large value for $\Delta \nu/J$. The system A_2X would indicate two protons of type A that weakly couple with one proton of type X. An AX spin system will give a first order splitting pattern. As the value of $\Delta \nu/J$ decreases, the splitting pattern becomes more complex.

The rules for interpreting first order proton spectra can be summarized as follows:

- 1. A proton spin-coupled to any equivalent protons will produce (n + 1) lines separated by J Hz, where J is the coupling constant. The relative intensities of the lines are given by the binomial expansion $(r + 1)^n$, where n is the number of equivalent protons. Splitting by one proton yields two lines of equal intensity; splitting by two protons yields three lines with a ratio of intensities 1:2:1. Three protons give four lines with a ratio of intensities 1:3:3:1. Four protons yield five lines with a ratio of intensities 1:4:6:4:1, and so on.
- 2. If a proton interacts with two different sets of equivalent protons, then the multiplicity will be the product of the two sets. For example, a proton split by both a methyl (CH₃) and a methylene (CH₂) group will be split into four lines by the methyl

- group. Each line will be split into three other lines by the methylene group. This will generate a total of 12 lines, some of which will probably overlap each other. The exact pattern (e.g., quartet of triplets vs. triplet of quartets) is determined by the magnitude of the coupling constants.
- 3. Equivalent protons do not split each other; the transition being forbidden. In practice, however, interactions do take place and can be seen in second order spectra.

It is not possible in this text to give complete instructions on the interpretation of NMR spectra, but it should be understood that NMR spectra give important and detailed structural information about molecules. The chemical shift indicates the functional groups that are present, such as aromatics, halides, ketones, amines, alcohols, and so on. Spin-spin splitting indicates which groups are coupled to each other and therefore close to each other in the molecular structure. The multiplicity indicates how many equivalent protons are in the adjacent functional groups. The peak area gives us relative numbers of each type of nucleus. The 3D geometry of even large, complex molecules can be determined. For students who have never taken a course in organic spectral interpretation and wish to learn more, the texts by Silverstein and Webster, Pavia et al. and Lambert et al. listed in the bibliography are recommended. Moreover, the compilation of correlation charts for many nuclei, and also many spin-spin coupling constants are provided by Bruno and Svoronos.

5.5 INSTRUMENTATION

Low-field (e.g., 60 MHz) NMR instruments use a fixed radiofrequency, a permanent magnet or electromagnet with a set of Helmholtz coils in the pole faces of the magnet, shown schematically in Figure 5.15(b). These coils are adjusted to vary the applied magnetic field slightly by passing a current through them, causing each chemically different nucleus to come into resonance sequentially. Such instruments are called *continuous wave* (CW) instruments. The sample holder was placed in the magnetic field. Two RF coils surround the sample so as to be orthogonal to each other and to the applied magnetic field. One coil applies a constant RF frequency; the second coil detects the RF emission from the excited nuclei as they relaxed. These systems are simple and rugged, but limited in resolution and capability. They are used for teaching and for simple NMR determinations. For complex organic structural determination, a high-resolution NMR is required. The increased sensitivity of FTNMR is so critical to the measurement of ¹³C and other less abundant nuclei as well as to increased proton sensitivity that all modern NMR spectrometers are Fourier Transform (FT) instruments. The term NMR spectrometer therefore is used in the remainder of the chapter to mean a pulsed FT system.

The most important parts of an FTNMR instrument are the magnet, the RF generator, and the probe, which houses the sample, the RF transmission and RF detection coils. Instruments require one or more pulse generators, an RF receiver, lots of electronics, and a computer for data processing. Block diagrams of NMRs are shown in Figure 5.15.

Modern commercial NMR systems are shown in Figure 5.16 and show the range of sizes and magnets available. NMR spectrometers cost from about \$20,000 for a miniature 45 MHz NMR to \$200,000 for a 300 MHz instrument to \$1,000,000 for a high field wide bore instrument for solids. Magnetic resonance imaging (MR) and NMR research imaging instruments cost over \$3 million dollars.

5.5.1 SAMPLE HOLDER

The sample holder in NMR is normally a cylindrical tube-shape. The tube must be transparent to RF radiation, durable, and chemically inert. Glass or Pyrex tubes are commonly used. These are sturdy, practical, and cheap. They are usually about 6-7 in. long and $\sim 1/8$ in. in diameter, with a plastic cap to contain the sample. This type of tube is used for obtaining spectra of bulk samples and solutions. For high-resolution NMR, it is critical that the sample




FIGURE 5.15 (a) Basic components of an NMR spectrometer (Williams, 1992. Copyright Wiley-Vch Verlag GmbH & Co. KGaA. Used with permission.). (b) Schematic diagram of a CW NMR spectrometer with a permanent magnet. (c) Schematic diagram of an FTNMR spectrometer, Akitt and Mann, Used with permission.). (d) Magnet and assembly for a modern NMR spectrometer. The superconducting coils (the primary solenoid and the shim coils, marked SC) are submerged in a liquid helium dewar (He) which is suspended in an evacuated chamber. A liquid nitrogen dewar (N₂) surrounds that to reduce the loss of the more expensive He. The levels of cryogenic fluids are measured with level sensors, marked LS. The room temperature shim coils (RS) and probe (P) are mounted in the bore of the magnet. A capped sample tube, shown inserted into the probe at the top, is introduced and removed pneumatically from the top of the bore. (e) A schematic probe assembly. A sample tube (uncapped, with a liquid sample as indicated by the meniscus) is shown inserted at the top of the probe. The RF coil for the observed nucleus (OC) is mounted on a glass insert closest to the sample volume. The RF coil for the lock signal (LC) is mounted on a larger glass insert. Variable capacitors (VC) are used to tune the appropriate circuit (lock, observe) to be in resonance with the appropriate RF. Only a small portion of the RF circuitry in the probe is shown. (From Petersheim, used with permission.)











FIGURE 5.16 (a) Two views of A 900 MHz NMR at the national magnetic resonance facility at Madison (NMRFAM), University of Wisconsin. (Photos by Robin Davies, MediaLab, University Of Wisconsin-Madison, used with permission.). **(b)** Benchtop NMR. **(c)** 300 MHz FT-NMR. **(d)** 1 GHz NMR (1000 MHz). (Photos (b-d) courtesy of Bruker-BioSpin. www.bruker.com.)

tube be of uniform wall thickness to avoid field distortions. Sample tubes range in size from this "standard" size down to tubes designed to hold 40 μ L of sample. Flow-through cells are used for hyphenated techniques such as HPLC-NMR and on-line analysis.

5.5.2 SAMPLE PROBE

The sample chamber into which the sample holder is placed is called the **probe** in an NMR spectrometer. The probe holds the sample fixed in the magnetic field, contains an air turbine to spin the sample holder while the spectrum is collected and houses the coil(s) for transmitting and detecting NMR signals. A schematic of a probe is presented in Figure 5.15(d).

The probe is the heart of the NMR system. The most essential component is the RF transmitting and receiving coil, which is arranged to surround the sample holder and is tuned to the precession frequency of the nucleus to be measured. Modern NMR probes use a single wire coil to both excite the sample and detect the signal. The coil transmits a strong RF pulse to the sample; the pulse is stopped and the same coil picks up the FID signal from the relaxing nuclei.

For maximum sensitivity, a fixed frequency probe is needed. This means that a separate probe is required for each nucleus to be studied: ¹H, ¹³C, ¹⁹F, and so on. A high-end probe costs on the order of \$120,000. Changing probes is a time consuming and delicate procedure. Each time a probe is changed, it must be retuned and shimmed. In most laboratories, a given probe is operated for an optimal period of time to complete as many measurements as possible. Then, if a probe change is needed, for example to accommodate another nuclei set, then the probe is changed and maintained in place for the duration of any measurements that might require it. In this way, probe change operations are minimized. Some variable frequency probe designs are available, but have decreased power, sensitivity, and spectral quality compared with fixed frequency probes. Probes for double resonance experiments require two concentric coils for the two RF sources. Triple resonance probes with many gradient options for liquids, solids, and flow experiments are available.

Probes usually have variable temperature control to run experiments at temperatures selected by the analyst. Cryogenically cooled probes can improve the resolution of a system, so that a 600 MHz spectrometer equipped with such a probe can provide resolution equivalent to a 700-800 MHz instrument. In some systems, samples can be heated up to 80 °C. New probe designs with flow-through sample holders are commercially available, for use in coupled HPLC-NMR instruments, HPLC-NMR-MS instruments and on-line process control analyzers. These hyphenated instruments and process instruments are discussed under applications.

The probe is installed in the spectrometer magnet so that the coils are centered in the magnet. The sample tube is inserted into the top of the probe and is moved by an air column through the magnet bore and centered among the probe coils. The tube exits the spectrometer at the top of the probe, again moved by an air column from the bore.

5.5.3 MAGNET

The magnet in an NMR spectrometer must be strong, stable, and produce a homogenous field. Homogenous in this context means that the field does not vary in strength or direction from point to point over the space occupied by the sample. The field must be homogenous to a few ppb within the sample area. It is common to express the magnetic field strength in terms of the equivalent proton frequency from the Larmor equation. A field strength of 1.4 T is equivalent to a proton frequency of 60 MHz. Commercial magnets range from 45 MHz to 1 GHz. Varian, Inc., the same company that introduced the first commercial NMR instrument in 1952, introduced a 900 MHz NMR instrument in 2001. Two views of this instrument are shown in Figure 5.16(a). The magnet is so large that this instrument comes with its own staircase so that the analyst can insert and remove the sample tube from the top of the probe. (Varian is now Agilent Technologies, Inc.) Other instrument companies have introduced

similar high frequency instruments, with the trend now heading to GHz instruments, as seen in Figure 5.16(d), also with a staircase.

Modern NMR spectrometers can use electromagnets or permanent magnets but most use superconducting solenoid magnets, as shown schematically in Figure 5.15. The magnet consists of a main field coil made of superconducting Nb/Sn or Nb/Ti wire with a dozen or more superconducting **shim coils** wound around the main coil to improve field homogeneity. The superconducting coils must be submerged in liquid helium. The magnet and liquid helium reservoir are encased in a liquid nitrogen reservoir to decrease the evaporative loss of the more expensive liquid helium. As can be seen in Figure 5.15, there is an open bore in the middle of the solenoid. The sample probe is mounted in the bore along with a set of room temperature shim coils. These coils are adjusted with every new sample placed in the probe to compensate for sample composition, volume, and temperature. Adjusting the field homogeneity, called "shimming", is usually performed automatically by computers with multivariate optimization procedures, although manual shimming is sometimes important. The magnetic field strength is held constant by a "frequency locking" circuit. The circuit monitors a given nucleus, such as deuterium used in the solvent for liquid samples, and adjusts the magnetic field strength to keep this nucleus at a constant resonant frequency.

The bore also contains air conduits for pneumatic sample changing and spinning of the sample holder in the magnetic field. The size of the bore determines how large a sample can be introduced into the magnetic field. Conventional analytical NMRs generally have bore diameters of 5-10 cm, with the larger diameters used for NMR of solids by MAS; the wider bore is needed to accommodate the instrumentation required. Field homogeneity is better in narrow bore magnets. A very large bore size is that used in human whole-body MRI systems, where the bore is large enough to accommodate a table and the patient.

To see how an NMR magnet is constructed, the interested student should visit the link on the JEOL website at www.jeolusa.com and look for NMR Magnet Destruction in the links under NMR. JEOL scientist Dr. Michael Frey cut open a 270 MHz magnet layer-by-layer. The pictures and commentary give a good appreciation for the complexity of the magnet construction. In this particular magnet, over 12 miles of superconducting wire were used for the main coil alone.

The cryogenic fluids must be replenished on a regular basis, usually weekly for the liquid nitrogen and every 1-6 months for the liquid helium. The superconducting coils must be kept cold; if permitted to warm up they stop functioning. The magnet is said to have "quenched". The magnetic field will be maintained by the low temperature, with no external power source. Indeed, if the laboratory or site power is cut, the magnetic field will be unaffected as long as the cryogenic fluid is present. In some instances, it might be necessary to manually quench the magnet. If the instrument is decommissioned or if it must be moved, for example, it must be quenched before moving. A magnet quench is typically accompanied by a rapid release of vaporized helium and nitrogen from the top of the magnet, and must be done safely because of the asphyxiation hazard posed by the oxygen displacement. The quench process is an impressive sight, and online videos show what occurs during this process (see, for example: https://www.youtube.com/watch?v=d-G3Kg-7n_M, accessed October, 2020). Once a magnet is quenched, in order to use it again it must be reenergized with a powerful power supply, usually by the manufacturer. Accidental quenching must be avoided since this is always considered the fault of the user and is not covered by service contracts.

The magnets used in NMR are very strong. It is common practice to rope off an area around the magnet where the field is about 5 gauss (0.0005T) and to stay outside of this area. It is very important to keep all metallic objects, like tools, as well as any magnetic records (including credit cards) away from the magnet. People with heart pacemakers should not go near the magnetic field. Modern actively shielded magnets are far less prone to field leakage; it is possible to place a credit card against a modern actively shielded magnet with no consequence. The use of steel tools near the magnet can be dangerous even with active shielding. In such magnets, there is still a powerful field below the magnet. Indeed, during probe change, a small wrench can be pulled from one's hand especially if it is accidentally placed near the bottom of the magnet. Tools flying across the room is not unheard of.




FIGURE 5.17 The power distribution for a 10 μ s rectangular pulse of 500 MHz RF radiation (a) distribution over a 400 kHz range. (b) The power level drops to 97 % of the maximum at 5 kHz (10 ppm) on both sides of the center of the spectrum. This can affect the accuracy of integrals for resonances in different regions of the spectrum. (From Petersheim, M., Nuclear Magnetic Resonance, in Ewing, G.A., Ed., Analytical Instrumentation Handbook, 2nd edn., Marcel Dekker, Inc., New York, 1997. Used with permission.)

5.5.4 RF GENERATION AND DETECTION

The RF radiation is generated by using an RF crystal oscillator. The output of the oscillator is amplified, mixed, and filtered to produce essentially monochromatic RF radiation for an NMR instrument. The RF radiation delivered to the sample is pulsed. A simple pulse might be a rectangular pulse of 500 MHz frequency for a 10 µs duration. The process of pulsing actually widens the RF band, providing a range of frequencies able to excite all nuclei whose resonances occur within the band of frequencies. All resonances within the band are excited simultaneously. An example of this is shown in Figure 5.17. A 10 µs, 500 MHz rectangular pulse leads to a power distribution around the 500 MHz frequency as shown. A proton spectrum occurs over a chemical shift range of \sim 10 ppm, which corresponds to \pm 2.5 kHz at 500 MHz. As seen in Figure 5.17, all of the protons in the sample would see 98-100 % of the power of the 500 MHz radiation delivered and all would be excited simultaneously. A pulse programmer is used to control the timing and shape of the RF pulses used to excite the sample. Square wave pulses are commonly used, but multipulse experiments and 2D NMR experiments with other pulse shapes are performed. There are hundreds of pulse sequences and 2D experiments that have been developed, with curious names like APT, DEPT, INEPT, INADEQUATE, and COSY (Sec. 5.6.4). Each pulse sequence provides specific and unique NMR responses that enable the analyst to sort out the NMR spectrum and deduce the chemical structure of a molecule.

All signals are collected simultaneously. The RF pulse delivered is generally on the order of watts while the NMR signal collected is on the order of microwatts. The FID signal in the time domain must be converted to a frequency domain spectrum by application of a Fourier transformation or other mathematical transformation. Commercial instruments generally use quadrature phase-sensitive detection to avoid spectrum artifacts resulting from the mathematical transformation. The operational details of the electronics required to provide the strong pulse and detect the very weak signals are complex and beyond the scope of this text. The interested student should consult the texts by Fukushima and Roeder, Akitt and Mann, or the references cited by Petersheim for more details.

5.5.5 SIGNAL INTEGRATOR AND COMPUTER

All NMR spectrometers are equipped with a signal integrator to measure the area of peaks. The area often appears on the NMR spectrum as a step function superimposed on the spectrum but is printed out in a data report as well.

All NMR spectrometers require a computer to process the data and much of the instrument is under computer control. Multitasking or networked computer workstations are normally used, so that data can be processed while long experiments are running on the instrument. A typical single NMR data file can be processed in less than 1 second. 2D and 3D NMR experiments generate megabytes to gigabytes of data that must be processed for each experiment. 2D NMR plot generation in the early 1980s required days of operator and computer time. The same 2D plots are now generated in minutes with today's improved software and faster computers.

Computer control of the room temperature shim currents that control the field homogeneity, of sample spinning rates, autosamplers, pulse sequences, and many other aspects of instrument operation is a necessity.

5.6 ANALYTICAL APPLICATIONS OF NMR

NMR spectroscopy is used for both qualitative and quantitative analyses. The applications of NMR are very diverse and only a very few examples can be given here. The student interested in applications of NMR is advised to look at journals such as Analytical Chemistry and the Journal of the American Chemical Society (JACS), published by the American Chemical Society, Applied Spectroscopy, published by the Society for Applied Spectroscopy, and Journal of Magnetic Resonance (Elsevier) for an overview of the wide range of uses for NMR. Particularly useful is the annual issue of Analytical Chemistry dedicated to Applications Reviews (odd-numbered years) or Fundamental Reviews (even-numbered years). A list of specialty NMR journals can be found at www.spincore.com/nmrinfo. Many of the instrument company websites listed, such as JEOL, Bruker, Agilent Technologies, Anasazi (www.aiinmr.com), Oxford instruments (www.oxinst.com) and Thermo Fisher Scientific (www.thermoscientific.com/picospin) have lots of applications notes available to the public.

5.6.1 SAMPLES AND SAMPLE PREPARATION FOR NMR

Liquid samples are the simplest samples to analyze by NMR. Neat non-viscous liquids are run "as is" by placing about 0.5 mL of the liquid in a glass NMR tube. Liquids can be mixed in a suitable solvent and run as solutions; the analyte concentration is generally about 2-10 %. For the examination of liquid samples, the sensitivity is sufficient to determine concentrations down to about 0.1 %. NMR has not been considered a "trace" analytical technique, but that is changing as instrumentation continues to improve. Cryogenic probes can offer an enhancement in signal to noise of approximately 5:1. Microtubes with as little as 1 μ g of sample in 100 μ L of solvent are now in use. Samples in solution and neat liquids are degassed to remove oxygen and filtered to remove iron particles: both O_2 and iron are paramagnetic and cause undesired line broadening.

Soluble solid samples are dissolved in a suitable solvent, usually deuterated, for analysis. A typical sample size is 2-3 mg dissolved in 0.5 mL of solvent. Some solid polymer samples may be run under "liquid" conditions, that is, without MAS, by soaking the solid in solvent and allowing it to "swell". This gives enough fluidity to the sample that it behaves as a liquid with respect to the NMR experiment. Other solid samples must be run in an instrument equipped with MAS, as has been discussed. Sample solutions are generally filtered through alumina to remove any particles.

NMR does not usually have sufficient sensitivity to analyze gas phase samples directly, although recent experiments have shown that one can in fact measure the vapor liquid equilibria of a sample (that is, the coexisting vapor and liquid concentrations) in selected cases. Gases can most easily be concentrated by being absorbed in a suitable solvent, condensed to the liquid phase, or adsorbed onto an appropriate solid phase. NMR tubes capable of containing elevated pressure are available for some gas analyses.

A suitable solvent for NMR should meet the following requirements: (1) be chemically inert toward the sample and the sample holder, (2) have no NMR absorption spectrum itself

or a very simple spectrum, and (3) be easily recovered, by distillation, for example, if the original sample is required for other testing. The best solvents for proton NMR contain no protons and therefore give no proton NMR signals. Carbon tetrachloride and carbon disulfide fall into this category. Replacing protons, 1H , with deuterium, 2H or D, will remove most of the proton signal for the solvent from the spectrum. Deuterated chloroform, CDCl₃, deuterated water, D_2O and many other deuterated solvents are commercially available for use. Deuterated solvents have two drawbacks; they are expensive and they generally contain a small amount of 1H , so some small signal from the solvent may be seen. A spectrum of the solvent (the blank spectrum) should be run regularly and whenever a new lot of solvent is used. Deuterated chloroform is the solvent used for most of the ^{13}C spectra shown in the chapter and the small signal from the coupling of D with ^{13}C in the sample is visible in these spectra.

5.6.2 QUALITATIVE ANALYSES: MOLECULAR STRUCTURE DETERMINATION

The primary use of NMR spectroscopy is for the determination of the molecular structure of compounds. These may be organic compounds synthesized or separated from natural products by organic chemists, pharmaceutical chemists, and polymer chemists, organic compounds isolated by biologists, biochemists, and medicinal chemists, and organometallic and inorganic compounds synthesized by chemists and materials scientists. The importance of NMR spectroscopy in deducing molecular structure cannot be overstated. A proton NMR spectrum should be examined for: (1) the number of proton resonances which tells you how many different types of protons are in the molecule; (2) the chemical shift of the resonances which identifies the adjacent equivalent protons; and (4) the intensity (area) of the resonances which tells you the relative number of each type of proton. Students needing more detailed spectral interpretation should consult the references by Silverstein and Webster, Pavia et al., or similar texts.

5.6.2.1 RELATIONSHIP BETWEEN THE AREA OF A PEAK AND MOLECULAR STRUCTURE

The multiplicity of a given peak tells us the number of adjacent equivalent protons. The multiplicity tells us nothing about the number of protons that give rise to the peak itself. That information comes from the peak area. The total area of an absorption peak is directly proportional to the number of protons that resonate at the frequency. By total area, we mean the area of all the peaks in the multiplet, if the peak is a multiplet, or the total area of the peak if the peak is a singlet.

In a sample of dry ethanol, Figure 5.14(a), the methyl group, CH_3 , is split by the methylene group to give three peaks. The area corresponding to the methyl group is the area enclosed by all three peaks of the triplet measured from a baseline. The two protons of the methylene group are split by the methyl group and by the proton of OH into a total of eight peaks. The area contributed by the methylene protons is that enclosed by all eight peaks measured from a baseline on the spectrum. The total area of the methyl group, CH_3 , will be equal to (3/2) x (the total area of the CH_2 group). The OH proton is split into a triplet by the methylene protons; the area corresponding to that proton is the entire area of its triplet measured from a baseline; the area corresponding to the hydroxyl proton should be 1/3 that of the methyl group.

The peak areas are measured by integrating the signal area automatically. The computer prints out the relative area, often shown as step function traces on the spectrum printout, as has been done for the spectrum in Figure 5.14(a); each peak has a line traced over it with a baseline at the bottom and at the top. The peak areas are **relative**; it is not possible to assign a molecular formula to an unknown from the NMR spectrum alone. For ethanol, the relative areas of the peaks should be 3:2:1 for the peaks as shown from right to left, that is, A:B:C. For ethanol, the relative area of the peaks is also the absolute area. We know this *only* because we know the sample is ethanol and we know the molecular formula for ethanol. From this relative area calculation, we can state that there are twice as many protons in the group giving rise to peak B as there are in the group giving rise to peak C and that there are $3 \times a$

many protons in the peak A group as in the peak C group. We *cannot* say that peak C is due to one proton and peak A to three protons without more information. The empirical formula can be determined if we have elemental analysis information and the molecular formula can be calculated if the molecular weight is known from another measurement such as mass spectrometry.

It is important to keep in mind that the smallest peak may be equal to more than one proton. You can deduce this if your ratios look like 1.9:1.5:1, for example. You cannot have a molecule with 1.5 protons on a carbon atom. Multiply everything through by the same common factor, until you get whole number values. Multipling 1.9, 1.5, and 1 by 2 gives 4, 3, and 2 protons, respectively, which is a reasonable set of whole numbers to work with in building a structure.

5.6.2.2 CHEMICAL EXCHANGE

In a solution of methanol and water, or ethanol and water, the hydrogen of the alcohol OH group physically exchanges with hydrogen in the water. Such a proton is said to be *labile*. If this physical exchange rate is greater than the change in resonance frequency for the nuclei involved, the nearby nuclei see only the average position of the nucleus, and spin-spin splitting due to the labile proton disappears. The exchange rate is affected by temperature, increasing with increased temperature. In addition, the proton on the OH group can participate in hydrogen bonding, which is also temperature dependent, concentration dependent, and very solvent dependent. The spectra of alcohols, and any molecules that hydrogen bond (-NH, -OH), are therefore affected by any traces of water in the sample, by temperature, by concentration, and by solvent polarity. Reagent-grade ethanol always contains water, so its spectrum looks very different than that for dry ethanol. The hydroxyl peak at 4.40 ppm appears as a singlet, not a triplet, because the exchange rate is so fast that the hydroxyl proton is not split by the methylene protons. For the same reason, the methylene protons are not split by the hydroxyl proton, only by the methyl protons. Therefore, the methylene peak at 3.58 ppm appears as a quartet in normal ethanol. The spacing between the peaks in the triplet and the peaks in the quartet should be equal since $J_{AB} = J_{BA}$. The student should find an NMR spectrum of reagent grade ethanol in the literature and confirm the differences between it and dry ethanol, Figure 5.14.

If the chemical exchange frequency is lower than the spectral frequency for the nuclei of interest, there will be a discrete set of resonances for each state. Processes with intermediate rates are studied by physical, organic, and inorganic chemists using NMR because the positions and shapes of the peaks can be used to estimate reaction kinetics and the lifetimes of reactants and products in a reaction.

Chemical exchange is not limited to the exchange of hydrogen-bonded protons in solution. Chemical exchange includes conformational changes as well as actual bond-breaking and bond-forming changes that result in new chemical shifts for the nuclei involved. Examples include dimer formation and tautomerism.

5.6.2.3 DOUBLE RESONANCE EXPERIMENTS

When we first examine an NMR spectrum of an unknown sample, it is often not easy to tell which nuclei are coupled, especially if the splitting patterns are complex. Double resonance experiments employ two different RF sources and a variety of pulse sequences to sort out complex splitting patterns. It was discussed in Section 5.1.2 that a system of protons could become saturated by applying a strong RF field to the sample. When saturation occurs, the saturated protons do not give an NMR signal and they do not couple with and split the peaks for adjacent protons. The saturated proton is said to have been "decoupled". Advantage is taken of this phenomenon to simplify complicated NMR spectra. In a double resonance **spin decoupling** experiment for proton NMR, one RF source is scanned as usual. The second RF source selectively saturates one resonance frequency (one group or type of protons). This causes the collapse of all the splitting patterns of nuclei to which that group is coupled. Irradiating each resonance frequency in turn and observing which peaks have their fine




FIGURE 5.18 Homonuclear decoupling experiment. A 250 MHz ¹H NMR of ethylbenzene in deuterated chloroform obtained **(a)** without decoupling, **(b)** with irradiation of the methyl resonance, and **(c)** with irradiation of the methylene resonance. (From Bruch and Dybowski, used with permission.)

structure disappear permits identification of all the coupled protons. For example, a peak that had been a triplet will collapse into a singlet if the methylene group that is causing the spin-spin splitting is saturated. A simple example of the use of spin decoupling by double resonance is shown in Figure 5.18. The proton spectrum of ethylbenzene is shown in Figure 5.18(a). If the methyl resonance is saturated, the NMR spectrum obtained is that shown in Figure 5.18(b). The signal for the methyl group at 1.2 ppm disappears and the methylene quartet at 2.6 ppm collapses into a singlet, because the methyl protons no longer split the methylene protons. If in a second experiment, the methylene resonance is saturated, the spectrum in Figure 5.18(c) is obtained. The methylene signal at 2.6 ppm disappears and the methyl triplet collapses into a singlet. From these two experiments, it can be deduced that the methyl and methylene groups are coupled and therefore are adjacent to each other.

A more complex spectrum and decoupling experiments are shown for sucrose in Figure 5.19. The structure of sucrose is shown. Ignoring the hydroxyl protons, each methine proton and methylene group is chemically different, giving rise to 11 resonance peaks in the spectrum. The fully coupled spectrum for sucrose dissolved in deuterated water, D_2O , is shown in (c) and the exchange rate is fast enough that no coupling is seen from the hydroxyl protons. Look at the top spectrum (a) and compare it with spectrum (c). Saturation of the triplet at 4.05 ppm, which is due to the proton marked (a) in the structure, causes the triplet to disappear from spectrum (a). It also collapses the doublet at 4.22 ppm, indicating that proton (a) is coupled to the proton causing the absorbance at 4.22 ppm. If we know that the peak at 4.05 is due to proton (a), it follows that the peak at 4.22 ppm must be from the proton marked (b). [Why? Why can it not be the proton on the carbon to the right of proton (a)? Hint: think about the splitting.] Now look at spectrum (b). Saturation of the doublet at 5.41 ppm, due to proton (c), causes the doublet to disappear from spectrum (b) and also collapses the doublet of doublets at 3.55 ppm, leaving a doublet. This tells us that the resonance at 3.55 ppm is due to proton (d).




FIGURE 5.19 Homonuclear decoupling experiments of the 300 MHz proton NMR spectrum of sucrose dissolved in D_2O . The fully coupled spectrum is shown in (c). **(a)** Selective saturation of the triplet at 4.05 ppm collapses the doublet at 4.22 ppm, showing the coupling between the positions of protons a and b marked on the sucrose structure. **(b)** Saturation of the doublet at 5.41 ppm collapses the doublet of doublets. The experiment shows the coupling between the protons marked c and d on the structure.

[Why does proton (d) appear as a doublet of doublets in the fully coupled spectrum?] The singlet peak at 4.8 ppm in each spectrum is due to residual HDO in the D_2O solvent.

By using double resonance experiments, one can greatly simplify the spectrum. Coupling between different types of nuclei is confirmed by both the disappearance of the peak for the saturated nuclei and the collapse of the fine structure of the coupled nuclei. Nuclei of the same type can be decoupled, as in the proton-proton example given; this is called **homonuclear decoupling**. It is possible to decouple unlike nuclei, such as ${}^{1}H_{-}^{-13}C$ decoupling; this is called **heteronuclear decoupling**. Both of these are examples of spin decoupling.

In modern instruments, it is not uncommon to use double and triple resonance experiments to simplify the spectrum sufficiently for interpretation. One interesting result of the

TABLE 5.4 Double Resonance, Multipulse, and 2D NMR Experiments

Acronym	Experiment Description
APT: attached proton test	Multipulse sequence used to distinguish even and odd numbers of protons coupled to ¹³ C through one bond. Even numbers of bound protons give positive peaks; odd numbers give negative peaks
DEPT: distortionless enhancement by polarization transfer	Multipulse; conditions are chosen so that only ¹³ C nuclei with the same number of bound protons have enhanced resonances. Four experiments must be performed, but DEPT is more definitive than APT
INADEQUATE: incredible natural abundance double quantum transfer	Multipulse; allows observation of natural abundance ¹³ C- ¹³ C coupling. Only 1 carbon atom in 10 ⁴ carbon atoms is a ¹³ C bonded to another ¹³ C, hence the name "incredible"
COSY: correlated spectroscopy	Homonuclear 2D experiment; plot of chemical shift vs. chemical shift identifies spin-coupled resonances. Many variations permit measurement of <i>J</i> coupling constants, long-range connectivity, suppression, and enhancement of selected resonances
shift correlated experiment NOESY: nuclear Overhauser effect spectroscopy	Heteronuclear 2D experiment; usually to connect ¹ H resonances with ¹³ C resonances or ¹ H-X, where X is another NMR-active nucleus. Plot is ¹³ C chemical shift (or X chemical shift) vs. ¹ H chemical shift ldentifies dipolar coupled nuclei within certain distances (e.g., within 0.4 nm for first order coupling) and identifies connectivities through cross-relaxation
a remader effect spectroscopy	is: instance coupling, and identifies confined vides a floagificious relaxation

Note: Table modified from Petersheim, used with permission.

use of double resonance, the **nuclear Overhauser effect** (NOE), is very important in ¹³C NMR and will be discussed in Section 5.6.3. Table 5.4 lists a few commonly used double resonance, multipulse, and 2D NMR experiments by name.

5.6.3 ¹³C NMR

Nuclei with an even mass and an even atomic weight have a zero spin number and therefore give no NMR signal. This includes ¹²C and ¹⁶O—two important nuclei in organic chemistry. Carbon is the underlying "backbone" of organic molecules and knowledge of carbon atom locations in molecules is crucial to structural determination.

Essentially all elements have at least one isotope that can be examined by NMR. Examples were given in Table 5.1 and some additional isotopes are listed in Table 5.5.

There has been great incentive to develop ^{13}C NMR because carbon is the central element in organic chemistry and biochemistry. Useful applications were not forthcoming until the 1970s because of the difficulties in developing instrumentation. There were two major problems. First, the ^{13}C signal was very weak because the natural abundance of ^{13}C is low, only 1.1 % of the total carbon present in a sample. Also, the ratio γ and the sensitivity are low compared to that for ^{1}H . The net result was a carbon NMR signal only 0.0002 as intense as a comparative ^{1}H signal. Second, the chemical shift range was up to 200 ppm using TMS as a standard. This increased range precluded a simple "add on" to the ^{1}H NMR instruments already commercially available. The introduction of FTNMR, which allowed the excitation of all ^{13}C nuclei simultaneously, made ^{13}C readily determinable by NMR. ^{13}C NMR is now a routine technique, providing important structural information about organic molecules.

There are several advantages to obtaining ¹³C NMR spectra for structural identification of organic molecules. First, the wide range over which chemical shift occurs, 200 ppm for carbon compared with only 10 ppm for protons, greatly diminishes overlap between carbons in different chemical environments. The spectra are less crowded and a peak is usually seen for each unique carbon nucleus. Second, adjacent ¹²C atoms do not induce spin-spin splitting, and the probability of two ¹³C atoms being adjacent to each other is very low. Therefore spin-spin coupling between ¹³C nuclei is not seen.

Nucleus	Natural Abundance (%)	Spin	Sensitivity Relative to ¹ H		
¹ H	99.98	1/2	1.0		
⁷ Li	92.6	3/2	0.3		
¹³ C	1.1	1/2	0.0002		
¹⁴ N	99.6	1	0.001		
¹⁷ O	0.037	5/2	0.03		
¹⁹ F	100	1/2	0.83		
²³ Na	15.9	3/2	0.09		
²⁵ Mg	10.1	5/2	0.003		
²⁷ Al	15.6	5/2	0.206		
²⁹ Si	4.7	1/2	0.008		
31 P	24.3	1/2	0.07		
³³ S	0.8	3/2	0.002		

TABLE 5.5 Natural Abundance, Spin, and Sensitivity of Selected NMR-Active Nuclei

Coupling between 13 C and 1 H nuclei does occur, but there are techniques available to decouple these nuclei. Consequently, the 13 C NMR spectra are very simple, with a singlet seen for each chemically distinct carbon atom. Comparison of 13 C and 1 H spectra lead to data that can be interpreted with a high degree of confidence, thereby elucidating the structure of even very complicated molecules. Coupling also occurs between 13 C and D, which can be seen when deuterated solvents are used. Look at the 13 C spectrum in Figures 5.4, acquired in CDCl₃. The triplet at 77 ppm is due to the natural 13 C in the solvent split by the D nucleus. The signal from the deuterated solvent, such as CDCl₃, is often used as the frequency-lock for the NMR. Since D is an I = 1 nucleus, the signal from the single C atom is split into a *triplet* by the single deuterium nucleus, because $2I+1 = [(2 \times 1) + 1] = 3$.

The chemical shift of a ¹³C nucleus is determined by its chemical environment (electronegativity and anisotropy) as for protons, but in a more complex manner. Chemical shifts for some ¹³C functional groups are shown in Figure 5.20. Using this information, you should




FIGURE 5.20 Chemical shifts for ¹³C using TMS as the 0.0 ppm reference. The abbreviation Hal stands for halogen, (i.e., CI, Br, or I.). From Leyden, D.E. and Cox, R.H. (Used with permission of John Wiley and Sons, Inc. See also Bruno, Svoronos for more extensive charts and tables.)




FIGURE 5.21 Heteronuclear decoupling of the 75 MHz ¹³C spectrum of sucrose. The fully coupled spectrum is at the top. The bottom spectrum is the broadband ¹H decoupled spectrum. The decoupled spectrum shows 12 single peaks, one for each nonequivalent C atom. (From Petersheim, used with permission.)

be able to interpret the ¹³C spectrum of toluene in Figure 5.4. More detailed chemical shift tables can be found in the references on spectral interpretation listed in the bibliography.

5.6.3.1 HETERONUCLEAR DECOUPLING

Coupling between ¹³C and ¹H occurs and results in complex spectra with overlapping multiplets, but in practice, it is eliminated by broad band decoupling. The sample is irradiated with a wide RF frequency range to decouple all the protons at once. Each chemically different carbon atom should then give a single NMR resonance peak. Figure 5.21 shows the ¹³C NMR spectrum of sucrose before proton decoupling (top) and after proton decoupling (bottom). As can be seen in the bottom spectrum, each of the 12 carbon atoms in sucrose gives rise to a single discrete absorption peak in the spectrum. Two of the resonances are fairly close (the ones at ~26.5 ppm) but they can be distinguished. The structure of sucrose is given in Figure 5.19; confirm for yourself that each carbon atom is chemically nonequivalent.

5.6.3.2 THE NUCLEAR OVERHAUSER EFFECT

When broad band decoupling is used to simplify the ¹³C spectrum, it is noted that peak areas increase more than is expected from elimination of the peak splitting. This is the nuclear Overhauser effect (NOE). Direct dipolar coupling between a saturated nucleus and an unsaturated nucleus results in a change in the ground state population of the unsaturated nucleus. This change in ground state population is a result of quantum transitions resulting in cross-relaxation between the nuclei; a transition in one nucleus induces a transition in the second nucleus. In ¹³C NMR, the result of the NOE is that the signal for the low abundance ¹³C nucleus is increased dramatically on proton decoupling. Under ideal conditions, the NOE can double the ¹³C peak intensity; this decreases the time needed to collect a spectrum by a factor of 4. The maximum NOE between two isotopes can be expressed as:

$$NOE = \frac{\gamma_{obs}}{2\gamma_{sat}} + 1$$




FIGURE 5.22 (a) 1 H and (b) 13 C NMR spectra of poly(1,4-phenylene ether sulfone) in deuterated dimethylsulfoxide, DMSO- d_6 . Spectrum (b) shows the NOE that occurs on proton decoupling of the 13 C spectrum. The peaks for the protonated carbon atoms 2 and 3 are enhanced by the NOE over the signals from the unprotonated carbon atoms 1 and 4. The peak in the proton spectrum at 3.3 ppm is due to water in the solvent; the peak at 40 ppm in the 13 C spectrum is due to natural 13 C in the solvent. (Williams, 1992. Copyright Wiley-Vch Verlag GmbH & Co. KGaA. Used with permission.)

where γ_{obs} is the magnetogyric ratio for the nucleus being measured and γ_{sat} is the magnetogyric ratio for the nucleus being saturated.

The major disadvantage of the NOE is that the relationship between peak area and number of carbon atoms giving rise to the peak is lost. An example of this is seen in Figure 5.22, where the peaks for the protonated aromatic carbons (peaks 2 and 3) are more than twice the height of the peaks for the unprotonated aromatic carbons (peaks 1 and 4), even though each peak is due to a single carbon atom. The NOE can be eliminated experimentally, which must be done if quantitative analysis of the carbon spectral data is required. The NOE is also seen in homonuclear spin decoupling and can be used to determine the distances between nuclei, providing more structural information about a molecule.

5.6.3.3 ¹³C NMR SPECTRA OF SOLIDS

Solid samples present a number of problems in ¹³C NMR. Line broadening arises from chemical shift anisotropy, because of the many orientations the different carbon atoms have in

a solid sample relative to the applied magnetic field. The chemical shift anisotropy can be eliminated by magic angle spinning (MAS). This technique increases the resolution observed in the spectrum for a solid by averaging the chemical shift anisotropies to their isotropic values. Figure 3.5 shows how dramatically the use of MAS reduces line broadening in a solid sample spectrum. Line broadening also occurs as a result of interaction between ¹³C and ¹H; decoupling of the dipolar interaction in a manner similar to spin decoupling also reduces the linewidth.

The spin-lattice relaxation time for ¹³C in solids is very long (several minutes). Since the nuclei have to relax before another excitation pulse can be sent, this requires hours of instrument time in order to collect a spectrum of reasonable intensity. A pulse technique called **cross-polarization** can be used to reduce this effect by having the protons interact with the carbon nuclei, causing them to relax more rapidly. FTNMR systems for solid samples include the hardware and software to produce narrow line spectra from solid samples in a reasonable amount of time using high-power dipolar decoupling, MAS, and cross-polarization.

5.6.4 2D NMR

High-resolution NMR spectra of organic compounds can be complex, with overlapping resonances and overlapping spin-spin couplings. The use of 2D NMR experiments and even 3D and 4D experiments extends the information obtained into a second (or third or fourth) frequency dimension. The spectrum becomes easier to interpret and much more structural information is usually provided. 2D and higher dimension experiments rely on the selective manipulation of specific nuclear spins, followed by interaction between nuclear spins. A series of such experiments can provide the entire molecular structure including the stereochemistry of the molecule.

A 2D experiment generally consists of the following: a pulse, followed by a time interval t_1 , then a second pulse, followed by a time interval t_2 . The first time interval t_1 is called the evolution period; t_2 is the acquisition period. It is during the evolution period that nuclear spins interact. A nucleus detected during the acquisition period has been frequency modulated by the nuclei it has interacted with during t_1 . By varying the evolution period, t_1 , in increments, and collecting the resulting FIDs, two frequencies are generated from a double Fourier transformation of the data. It is common to collect 1024 or more FIDs. Each one is Fourier transformed to give a frequency axis ω_2 ; a second FT is performed at right angles to the first one, resulting in a frequency axis ω_1 related to t_1 . One frequency axis is the nucleus detected during the acquisition period; the other axis can be the same nucleus (a homonuclear experiment such as COSY) or a different nucleus (a heteronuclear experiment such as HETCOR). The data are plotted as frequency vs. frequency, usually presented as a contour plot.

For example, a homonuclear COSY experiment (see Table 5.4) is used to map the protonproton I coupling in a molecule. Consider a simple system in which two protons are coupled to each other, CH—CH. The basic pulse sequence for a 2D COSY experiment consists of a relaxation or preparation period to establish spin equilibrium. A 90° pulse is applied and the spins precess at their characteristic frequencies during the evolution period, t₁. After the evolution period, a second 90° pulse, called the mixing pulse, is applied. This second pulse causes exchange of magnetization between J-coupled spins. The normal 1D proton spectrum is plotted on both the x-axis and the y-axis. For the simple system we are considering, the spectrum would show two doublets, one centered at a chemical shift of δ_A for proton A and one centered at a chemical shift of δ_x for proton X. The plot is shown schematically in Figure 5.23. If the magnetization undergoes identical modulation during t_1 and t_2 , the resulting frequencies will be the same. A plot of ω_1 vs. ω_2 , where the two frequencies are identical, results in a point along the diagonal of the x-y graph. The contour peaks (points in the schematic diagram) that appear along the diagonal are the resonances in the "normal" spectrum and provide no additional information. The four points labeled 1-4 on the diagonal are just the frequencies of the four peaks (i.e., the two doublets) in the 1D NMR spectrum. Peaks 5-8 are called autocorrelation peaks and will not be discussed. What we are interested in are those results where the magnetization exhibits one frequency during t_1 and a different frequency




FIGURE 5.23 A simulated AX proton–proton COSY plot. (Modified from Bruch, used with permission.)

during t_2 , that is, peaks that have been frequency-modulated by interaction. In this case, peaks appear *off* the diagonal in the x-y plot; such peaks are called cross-correlation peaks, or cross-peaks. It is the cross-peaks that provide the additional information we are looking for. In the homonuclear COSY experiment, the cross-peaks tell us which protons are coupled to each other. For this simple example, magnetization exchange results in eight peaks that appear as symmetric pairs off the diagonal. We can draw a connection between the two diagonal peaks from A and X and the symmetric pair of off-diagonal peaks, as shown in Figure 5.24, proving that protons A and X are coupled. Any pair of diagonal peaks that can be connected through symmetric pairs of off-diagonal peaks are spin-coupled; in this way,




FIGURE 5.24 The connection between the cross-peaks and the A and X peaks on the diagonal proves that A and X are spin-coupled and also provides a measurement of J_{AX} . (Modified from Bruch, used with permission.)




FIGURE 5.25 (a) Simulated ¹H–¹H COSY plot of an unknown compound. (b) Connecting lines indicate which protons are spin-coupled to each other. The COSY plot indicates that protons 5 and 6 are not coupled to any other protons. Any postulated structure for the unknown must be consistent with the coupling information from the COSY experiment.

the coupling throughout a complex spectrum can be traced. As shown on the figure, the fine structure or spacing between the peaks gives us $J_{\rm AX}$. A COSY spectrum usually looks more like the simulated example presented in Figure 5.25(a), where the peaks are represented as contour plots. In this simulated example, there are 6 protons shown along the diagonal. The connecting lines in Figure 5.25(b) indicate that protons 1 and 2 are spin-coupled, protons 3 and 4 are spin-coupled, but protons 5 and 6 are not spin-coupled to any other protons. It is this type of information that helps to deduce the structure of an unknown; for this molecule, protons 5 and 6 cannot be adjacent to methyl, methylene, or methine protons, for example. The COSY spectrum of sucrose is shown in Figure 5.26. The connecting lines in Figure 5.26




FIGURE 5.26 COSY profile and contour spectra of sucrose in D_2O . Note the strong contour connecting the diagonal peak for the proton at 5.41 ppm with the doublet of doublets at 3.35 ppm. In addition, the triplet at 4.05 ppm has strong off-diagonal contours indicating it is coupled to the doublet at 4.22 ppm. Compare with figures 5.19 and 5.21. (Modified from Petersheim, used with permission.)

confirm the couplings worked out earlier in the decoupling experiment (Figures 5.19, 5.21). COSY spectra for large molecules can be complex and difficult to interpret.

5.6.5 QUALITATIVE ANALYSES: OTHER APPLICATIONS

NMR spectra can be used to identify unknown compounds through spectral pattern-matching. A number of companies, instrument manufacturers, government agencies, and other sources publish collections of reference spectra in electronic format. These spectral databases may contain spectra of more than 200,000 compounds. The unknown spectrum or some pre-determined number of the strongest absorption bands from the unknown spectrum may be entered into a computerized search routine, which compares the unknown with stored spectra. It then retrieves all compounds from the database that may match the unknown spectrum, assigning a "goodness-of-fit" or probability to the suggested matches. The analyst then identifies the spectrum of the unknown based on spectral matching and chemical knowledge of the sample to rule out improbable compounds suggested by the search routine. A short list of reference spectra suppliers is located at the end of the bibliography. Most large spectral databases are expensive, but the amount of work required to compile these databases is considerable.

In addition to identification of unknowns, NMR can be used for conformational and stereochemical analyses. This includes the determination of *tacticity* in polymers, that is whether the side chains are arranged regularly (isotactic and syndiotactic) or randomly (atatic) along the polymer backbone. Fundamental studies of bond distances from dipolar coupling and molecular motion from relaxation time measurements are used by physical chemists and physical organic chemists. In biology and biochemistry, the use of isotopelabeled compounds and NMR can be used to study metabolism and understand metabolic pathways in living organisms. Chemical reaction rates can be measured and studied as a function of temperature directly in the NMR spectrometer.

Polymers of many chemical compositions are used to make materials and composites for use in appliances, electrical equipment, telecommunications equipment and fiber optics, computers, aircraft, aerospace, automobiles, food and beverage packaging, potable water delivery systems, and medical devices, to name a few applications. Adequate knowledge of the polymer structure and its relationship to the performance of these polymeric materials is crucial to their successful use. NMR is extremely useful in polymer characterization. ¹³C and ¹H are the elements most commonly examined, followed by ²⁹Si, ¹⁹F, ³¹P, and ¹⁵N. NMR can be used to determine the monomer sequence, branching, and end groups in polymers of many types. For example, Figure 5.27 shows the ²⁹Si NMR spectrum of a polydimethylsiloxane polymer with trimethylsilyl end groups. Polydimethylsiloxanes (PDMS) are a major class of silicone polymers, used in many products from silicone caulk to shampoo. The NMR spectrum enables the analyst to identify the trimethylsilyl end groups (peak A) and the repeat unit of the chain (Peak B), the dimethyl-substituted SiO unit shown in parentheses, from the chemical shifts. The degree of polymerization can be determined from the areas of the peaks; the integrations are shown as the stepped lines on the spectrum, so quantitative information about the polymer is also obtained in this case. More extensive information on ²⁹Si NMR spectra can be found in the book by Bruno and Svoronos.

Polymer composites or fiber-reinforced plastics (FRPs) have a wide range of applications in the aerospace and automotive industries. In these composite systems, fibers of carbon or silica are embedded in a polymer matrix to provide desirable physical properties, such as strength, while maintaining the low mass of a polymer. For example, polymer composite turbine blades are replacing heavier metal alloy blades in jet engines. Organic coupling agents are used to treat fiber surfaces to improve bonding between the fibers and the polymer matrix. High-resolution cross-polarization magic angle spinning (CP-MAS) NMR is used to observe structure, orientation, and interactions of coupling agents bound to surfaces.

Chemists and materials scientists are working to develop new materials with specific properties such as high strength and high modulus, resistance to temperature extremes, corrosion resistance, demanding optical or electrical properties, and the like. This requires




FIGURE 5.27 The use of ²⁹Si NMR to characterize a silicone polymer. The polymer endgroups can be identified as trimethylsilyl groups and the measurement of peak areas permits the calculation of the average degree of polymerization. (Williams, 1992. Copyright Wiley-Vch Verlag GmbH & Co. KGaA. Used with permission.)

detailed knowledge of composition of the material, orientation of molecules, crystalline state, homogeneity, and other parameters. NMR is one tool that can provide much of the structural information necessary and often in a nondestructive manner. NMR is useful for studying both amorphous and crystalline materials, unlike X-ray diffraction spectroscopy (Chapter 8), which requires a crystalline sample.

The chemical shift differences between reactants and products permits NMR to be used to follow the course of a reaction and to choose the optimum reaction conditions. 29 Si NMR spectra show that NMR can follow the process of making β -SiC, a refractory ceramic, from polymethylvinylsilane and silicon metal. All reactant and product signals are well separated in chemical shift, so any unreacted starting material can be measured in the product and the production process can be optimized (Figure 5.28).

Solid-state NMR is proving to be a powerful technique for the study of reactions at surfaces. For example, NMR has been used in catalysis studies for determining the structure of chemisorbed molecules and for monitoring changes occurring in those structures as a function of temperature.

The need to determine the structures of large biological molecules like proteins is driving a new revolution in NMR. Extremely fast multidimensional NMR and new mathematical approaches, such as G-matrix FTNMR, are being developed to rapidly collect and process 4D and 5D NMR experiments on biological macromolecules. Articles on these developments can be found in Chemical and Engineering News, December 23, 2002, p.7 and January 27, 2003, p.15.

5.6.6 QUANTITATIVE ANALYSES

Both high- and low-resolution NMR are used for quantitative analyses of mixtures, quality control of both incoming raw materials and finished products, determination of percent purity of pharmaceuticals and chemicals, quantitative determination of fat and water *in vivo* in animals, and many other applications.

A significant advantage of NMR is that data can be obtained under experimental conditions where the area under each resonance is directly proportional to the number of nuclei contributing to the signal. No response factors are necessary to obtain quantitative results. A universal reference standard can be used for the analyses of most materials because the NMR response can be made the same for all components. This is a significant advantage over




FIGURE 5.28 (a) The ²⁹Si NMR spectrum of the pyrolyzed product, β-SiC. (b) The ²⁹Si NMR spectrum of polymethylvinylsilane and elemental silicon, the precursors to silicon carbide. (From Apple, T. M., *Appl. Spectrosc.*, 49(6), 12A, 1995. Used with permission.)

other methods of analysis. In cases where proton decoupling is used, such as in the analyses of polymers and organic compounds containing ¹³C, ²⁹Si, ¹⁹F, and other spin 1/2 nuclei, the NOE must be eliminated to reestablish the relationship between peak area and number of nuclei. This is done by using gated decoupling (i.e., turning the decoupler off during the delay between RF pulses). This permits the return of normal equilibrium populations and results in the peak intensity (area) again relating to the number of nuclei giving rise to the resonance.

In polymers and ceramics, NMR can be used to determine quantitatively the amounts of amorphous and crystalline material in a sample. Molecules in amorphous regions "move" more than molecules in crystalline regions, so the relaxation times of molecules in these different environments are different. NMR can measure the difference in relaxation times and relate that to the percent crystallinity of the sample. Whether a sample is amorphous, crystalline, or a combination of both directly impacts the material's physical properties and behavior. It is an important piece of information for materials scientists and polymer chemists to know.

One type of organic compound can be determined quantitatively in the presence of a different type, such as the percentage of alcohols in alkanes, amines in alcohols, aromatics and aliphatics in petroleum, olefins in hydrocarbon mixtures, organic halides and organometallic compounds in other organic compounds, or the number of side chains in a hydrocarbon. The method is not limited in the number of components that can be identified as long as there is at least one peak in the spectrum that is unique to each component.

NMR can be used to provide determination of chemical purity and quantitative measurements of impurities in materials. The accuracy and precision of quantitative NMR measurements are comparable to other instrumental analyses methods. Major components can be accurately determined with precisions better than 1 %RSD while impurities in materials may be quantified at 0.1 % or lower (Maniara et al.). The most common nuclei used for quantitative

analyses are ¹H, ¹³C, and ³¹P. Quantitative ³¹P NMR has been used to determine phospholipids, inorganic phosphorus, and organophosphorus compounds, such as phosphorus-based insecticides (Maniara et al.).

As an example of a simple quantitative analysis, suppose that we have a mixture of n-octane and 1-octene. The structure of n-octane, C_8H_{18} , which contains 18 protons, is composed of methyl and methylene groups. All atoms are joined by single bonds:

$$CH_3 - CH_2 - CH_2 - CH_2 - CH_2 - CH_2 - CH_2 - CH_3$$

The structure of 1-octene, C₈H₁₆, which contains one terminal C=C bond, is:

$$CH_3 - CH_2 - CH_2 - CH_2 - CH_2 - CH_2 - CH_2 - CH_2$$

It can be seen that in 1-octene there are two protons on the *terminal* carbon that are ole-finic in nature. These olefinic protons will absorb at about 5.0 ppm (Table 5.3 on website). Quantitatively, they constitute 2 of 16 protons in 1-octene. If we measure the area of the peaks at 5.0 ppm (call it area *A*), then the total area in the whole spectrum due to the presence of 1-octene is equal to area *A* times 8:

Area due to
$$1$$
 – octene = Area $A \times 8$

and

Area due to octane = total area
$$-(1 - octene area)$$

However, one molecule of octane contains 18 protons and one molecule of 1-octene contains 16 protons. Hence, if these compounds were present in equimolar proportions, the ratio of the relative area of the NMR absorption curves would be 18:16. A correction must be made for this difference in the final calculation. The mole ratio of octane to 1-octene in the mixture would therefore be obtained as

area due to octane/18 area due to octene/16

that is, the mole ratio of octane/octene equals

$$\frac{[\text{total area} - (\text{area } A \times 8)]/18}{(\text{area } A \times 8)/16}$$

Sample calculation: In an actual experiment involving a mixture of octane and 1-octene, it was found that the total area of all peaks = 52 units. The area of peaks at 5.0 ppm (area A) = 2 units. From the data and the relationships previously set out, we find that the area due to 1-octene protons = $2 \times 8 = 16$ units. The area due to octane protons = 52-16 = 36 units

Ratio of octane to octene =
$$\frac{36/18}{16/16} = \frac{2}{1}$$

Therefore, the mole ratio of octane to 1-octene in this in this sample is 2:1. Similar calculations can be made for many other combinations of compounds.

NMR can be used to determine the composition of mixtures, polymers, and other materials as long as there is at least one peak representing each different component. For example, the degree of bromination of a brominated polymer can be determined from the ¹³C NMR spectrum. The degree of bromination can be calculated from a direct comparison of the integrated areas labeled g and h in Figure 5.29 which represent the unbrominated and brominated aromatic rings or by using peak d to represent the unbrominated ring and the sum of peaks e and f to represent the brominated ring.

The end groups in a polymer are extremely important to the chemical and mechanical behavior of the polymer, but they are present at only low concentrations compared with the




FIGURE 5.29 The 75 MHz ¹³C NMR spectrum of the aromatic region of a 57 mol % brominated poly(2,6-dimethyl-1,4-phenylene oxide) polymer. Assignments are shown for peaks used in determining the degree of bromination. (From Williams et al., used with permission.)

polymer chain repeat units. End groups may be less than 1 mol % of the total polymer. An example of end group identification in a silicone polymer was given earlier. In cases where the polymer end groups are hydrocarbons, the less sensitive ¹³C spectrum must often be used to identify the end groups because there is less likelihood of spectral overlap. The proton spectrum, with a chemical shift range of only 10 ppm, often has the proton signals overlapping and impossible to sort out for the low concentration of end groups in a large polymer. Under ideal conditions, ¹³C NMR may be used to determine end group concentrations as low as 0.01 mol %.

NMR can be used to determine rates of reaction and reaction kinetics. In a chemical reaction such as

$$C_8H_{18} \xrightarrow{Pd} C_8H_{16} + H_2$$

one type of proton (paraffinic) is consumed and another type (olefinic) is formed. The rate of disappearance or formation of the different types of protons can be measured. The results can be used to calculate the rate of the chemical reaction and the kinetics involved. With a modern FTNMR, many reactions can be monitored in the probe without the need for physically taking samples at intervals. Spectra are collected every few seconds, and the rate and order of the reaction are calculated after the data is processed.

5.7 HYPHENATED NMR TECHNIQUES

Many samples of interest to researchers in biochemistry, pharmaceutical chemistry, medical chemistry, forensic chemistry, and industrial chemistry are not pure compounds. It is often necessary to go through complex extraction and separation procedures to isolate the compounds of interest before they can be studied. These separation procedures can be time consuming and labor intensive. Costly high-purity solvents are used, which then must be disposed of (costing even more money). In the pharmaceutical industry, for example, *combinatorial chemistry* approaches are used to synthesize thousands of new compounds a day. These syntheses do not result in pure products; in fact, many products and unreacted starting materials may be present in the sample to be analyzed. Various types of instrumental **chromatography** have been developed to expedite the separation and detection of compounds in complex mixtures. These techniques are discussed in detail in Chapters 11-13. One of the most important types of chromatography, especially for pharmaceutical, biochemical, and clinical chemists, is HPLC, covered in Chapter 13. HPLC is used for the separation of

nonvolatile molecular compounds; there are methods available to separate compounds with low molecular weights, high molecular weights, low polarity, high polarity, and everything in between. Detectors for HPLC do not provide molecular structure or molecular weight, except for mass spectrometers.

It is possible to interface or "couple" an HPLC instrument with an NMR spectrometer. The HPLC performs the separation of a complex mixture and the NMR spectrometer takes a spectrum of each separated component to identify its structure. We now have a "new" instrument, an HPLC-NMR instrument. We call a coupled instrument like this a "hyphenated" instrument. The coupling of two instruments to make a new technique with more capabilities than either instrument alone provides results in a hyphenated technique or hybrid technique. HPLC-NMR is made possible with a specially designed flow probe instead of the standard static probe. For example, Bruker Instruments (www.brukerbiospin.com) has a flow probe for proton and 13 C NMR with a cell volume of $120~\mu$ L. Complex mixtures of unknown alkaloids extracted from plants have been separated and their structures completely characterized by HPLC-NMR using a variety of 2D NMR experiments (Bringmann et al.). Only a simple aqueous extraction of the plant leaves, lyophilization, and dissolution in D_2 O was required for injection into the HPLC-NMR, saving time and resources. HPLC-NMR has been used for the analyses of metabolites in body fluids; body fluid samples are very complex mixtures and are usually of limited volume (Lindon et al.).

HPLC-NMR and the more powerful hyphenated instrument HPLC-NMR-MS (the MS stands for mass spectrometry) are used in pharmaceutical research and development. These hyphenated techniques identify not only the structures of unknowns, but with the addition of MS, the molecular weight of unknown compounds. The HPLC-NMR-MS instrument separates the sample on the HPLC column, takes the NMR spectra as the separated components flow through the probe and then acquires the mass spectrum of each separated component to determine the molecular weight and additional structural information from the mass spectral fragmentation pattern. The MS must be placed after the NMR, since MS is a destructive technique. MS is covered in Chapter 9.

5.8 NMR IMAGING AND MRI

NMR is extensively used in imaging solid objects in a nondestructive, noninvasive manner. The most important application of this imaging is in medicine. NMR imaging and **magnetic resonance imaging** (MRI) are the same technique. The term "nuclear" was dropped from instrumentation used for medical imaging so that patients would not mistakenly think this was a procedure that involved radioactive materials or gamma rays (X-rays). We will use the term MRI for NMR imaging applications in general.

MRI has found valuable applications in medical imaging of the human body. In this technique, a highly uniform magnetic field is used, but a linear magnetic field gradient is superimposed in three orthogonal directions using auxiliary coils. ¹H nuclei therefore respond at different frequencies at different physical locations, thus locating the physical position of the nuclei in three dimensions. By observing the NMR signal from numerous different angles simultaneously, the physical outline of the various body tissue components can be revealed. Abnormalities such as fractures or cancerous growths can then be located and measured in 3D at high resolution. The magnets used must have a large bore, large enough to accommodate a human patient lying on a table, or must use an open magnet design. MRI magnet designs are very different from NMR instrument magnet designs. Open magnet or short bore designs are used to avoid inducing claustrophobia in patients undergoing MRI. Field strengths of MRI medical imaging units range from 0.8 to 3 T, much lower than NMRs for chemical analyses. The cost of medical MRI units is extremely high compared with chemical analysis instrumentation; about \$1.5 million is typical for a 1.5 T state-of the-art MRI unit. The Toshiba Medical Systems website at http://medical.toshiba.com has numerous MRI images taken with its systems available for viewing.

X-rays have been used extensively for noninvasive medical imaging studies in the past, but the contrast between different forms of soft tissue is low and therefore abnormalities in soft






FIGURE 5.30 (a) An unenhanced MRI image of a human brain tumor. The tumor is the gray circular object on the left side of the brain behind the eye. (b) MRI image of the same tumor after administration of a gadolinium-containing contrast agent. Note the brightness of the tumor in this image compared to (a). (Images courtesy of H.T. Alberry, D. Derico, and M. Farrell, Albany Advanced Imaging, Albany, NY.)

tissues are hard to visualize using X-rays. Also, X-rays are ionizing radiation and can cause tissue damage at high exposure levels. In contrast, MRI, also a noninvasive procedure, has essentially no side effects and can more readily visualize very small differences in soft tissue. MRI can monitor in vivo concentrations of biologically important molecules like adenosine triphosphate (ATP) in a noninvasive manner; this permits studies of the effect of drugs on metabolism, for example. Figure 5.30 illustrates the use of MRI to locate a brain tumor. The image in Figure 5.30(a) shows the tumor, the gray oval object on the front left side of the brain behind the eye. The image in Figure 5.30(b) is of the same tumor after a "contrast agent" containing gadolinium was given to the patient. The tumor absorbs more of the contrast agent because of its fast growth and high blood supply. The Gd ion is paramagnetic and changes the relaxation times of nuclei in its vicinity resulting in signal enhancement; the tumor now appears bright or "lit up" against the surrounding tissue. A brief discussion of gadolinium MRI contrast agents can be found in the reference by Skelly Frame and Uzgiris. Recent advances in technology now permit MRI visualization of soft tissues and flowing blood even without the use of contrast agents. Some impressive examples can be found at http://medical.toshiba.com.

MRI instruments can be equipped to study polar ice and marine organisms in their saltwater environments, permitting the imaging of new marine species. The references by Bock and the website of the Alfred-Wegener-Institute for Polar and Marine Research offer amazing MRI pictures of ice microstructures and marine species *in vivo* (www.awi.de). A few examples follow. Figures 5.31 and 5.32 are *in vivo* MRI images and the NMR spectra of embryos in a live pregnant fish. Figure 5.32(b) shows a stack plot of phosphorus-containing compounds in a living codfish that undergoes hypoxia (lack of oxygen). As hypoxia is induced, the inorganic phosphate signal (Pi) on the left increases. At the same time, the phosphocreatine signal (PCr) decreases. As conditions return to normal, the inorganic phosphate disappears and the phosphocreatine returns to normal (as did the fish). These are all ³¹P NMR spectra. The Bruker BioSpin* website at www.bruker-biospin.com offers a wide variety of MRI images, including a movie of a beating rat heart with a myocardial infarction imaged *in vivo*, an MRI of a living newly discovered saltwater fish and false color images showing temporal differences in brain activity during an epileptic seizure in a rat.

MRI permits the noninvasive imaging of the interior of solid objects. This has been successfully utilized in the study of extruded polymers and foams and the study of spatial






FIGURE 5.31 In vivo MR images of a North Sea fish, the eelpout. This fish is pregnant and embryonic fish are visible inside the uterus. Other tissues are also visible as marked. This fish was free-swimming in a salt water-filled flow-through chamber. (Courtesy of Dr. Christian Bock, Alfred-Wegener-Institute for Polar and Marine Research, Bremerhaven, Germany; www.awi.de.)

distributions of porosity in porous materials. The structure of ice in polar ice cores has been studied as noted above; unlike optical imaging, MRI imaging is nondestructive. Ice has sufficient mobile protons to be imaged with conventional MRI.

While conventional MRI has been used effectively for imaging soft tissues, it had not been used for studying hard tissues in the body due to its inability to capture the rapidly decaying signals of these tissues. In addition, conventional MRI cannot image around air or metallic objects. New MRI technology from Agilent Technologies overcomes these problems and expands the applicability of MRI to materials and tissues previously invisible to MRI. The technique is called SWIFT (SWeep Imaging with Fourier Transformation). SWIFT uses broadband frequency-swept RF excitation with nearly simultaneous acquisition, allowing the imaging of objects and materials with extremely fast transverse relaxation rates.

In conventional MRI, RF excitation and signal acquisition are separated by an echo time greater than 1 millisecond. By the time this echo delay is completed, hard materials with fast transverse relaxation times have already decayed and cannot be measured. In SWIFT, the echo time approaches zero because the acquisition begins within a few microseconds of excitation.

SWIFT can image semisolid materials such as macromolecules and quadrupolar nuclei, such as oxygen-17, sodium-23, potassium-39 and others. With the SWIFT technique, acoustic noise is all but eliminated. The technique tolerates static magnetic field inhomogeneity, making it possible to image near and around air (imaging of lungs, for example) and metal, such as orthopedic hardware, iron nanoparticles, and the like. The article by Amy Herlihy provides more detail on this breakthrough imaging technology. (Note: Swift Raman is a trademark of Horiba Scientific for a completely different technique mentioned in Chapter 4.)

5.9 LOW-FIELD, PORTABLE, AND MINIATURE NMR INSTRUMENTS

There are a number of low-field NMR instruments with permanent magnets or electromagnets commercially available. These instruments are aimed at academic institutions where low resolution is adequate for educational and research purposes. Installations where temperature fluctuations or environmental vibrations occur are more suitable for a rugged permanent magnet or electromagnet than a superconducting magnet.




FIGURE 5.32 (a) In vivo localized proton NMR spectrum collected from the same fish embryos seen in figure 5.31. At location a on the image, signals identified in the embryo spectrum include ATP, glycine (gly), and creatine (Cr) as well as large signals from lipids (lip). **(b)** Stack plot of in vivo ³¹P NMR spectra from the muscle of a living codfish. Each spectrum was acquired over 5 min. When hypoxia (hypo) was induced in the fish by decreasing its oxygen supply, the inorganic phosphate levels (Pi) increased while phosphocreatine (PCr) decreased. As conditions return to normal, the Pi signal disappears, the PCr signal increases and the fish recovered its energy. (Courtesy of Dr. Christian Bock, Alfred-Wegener-Institute for Polar and Marine Research, Bremerhaven, Germany; www.awi.de.)

60 MHz and 90 MHz FTNMR instruments are available from Anasazi Instruments (www.aiinmr.com) in configurations for proton, carbon, fluorine, phosphorus and silicon studies, with common research capabilities such as 2D (COSY, HETCOR) and DEPT. The proton spectrum and peak assignments for ibuprofen and a good comparison of signal to noise, resolution and second order effects in the 60 MHz spectrum vs. a 90 MHz spectrum for ibuprofen can be found in their application note at http://www.aiinmr.com/ FIGURE 5.33 The miniaapplications/60-vs-90mhz-sample-2m-ibuprofen.


A novel miniature 45 MHz proton FT-NMR is available from Thermo Fisher Scientific picoSpin™ (www.thermoscientific.com/picospin). The NMR, seen in Figure 5.33, is based on a perma- (@Thermo nent magnet, weighs 7 lbs and needs only 20 microliters of sample. The very small foot- www.thermofisher.com. Used print (8" x 11") and low cost allow dedicated NMR systems to be placed in manufacturing with permission.)



ture Thermo Fisher Scientific™ proton Fisher Scientific,

operations, quality control labs and in classrooms. The instrument can be used for a variety of educational studies and process control applications, such as monitoring transesterification and condensation reactions, QC of food and beverage components and so on. Essential oils extracted from natural products such as fruit, herbs, and spices are often used in foods, perfumes, and personal care products. NMR can be used to evaluate purity of the oils, to identify different lots of product or even different geographical sources for a given oil. The major component of both orange oil and lemon oil is (+)-Limonene, but analysis of these two oils using the picoSpin-45 shows small peaks in the spectrum of the lemon oil that are due to other trace compounds extracted from the raw material (Figure 5.34).

Another example of the use of NMR for pharmaceutical quality control is the screening of final products for active pharmaceutical ingredients (API) as well as binders, excipients and contaminants. In soft gel tablets, a major component is polyethylene glycol (PEG), easily seen in the NMR spectrum of over-the-counter ibuprofen soft gel products (Figure 5.35).






FIGURE 5.34 picoSpin[™] proton NMR spectra. **(a)** Proton NMR spectrum of sweet orange essential oil. **(b)** Proton NMR spectrum of lemon essential oil. The lemon oil shows other trace compounds not found in the orange oil. (©Thermo Fisher Scientific, www.thermofisher.com. Used with permission.)




FIGURE 5.35 NMR spectra from the picoSpin[™] proton NMR. **(a)** Ibuprofen soft gel, showing the active ingredient as well as the PEG Component. **(b)** Pure ibuprofen. (©Thermo Fisher Scientific, www.thermofisher.com. Used with permission.).

5.10 LIMITATIONS OF NMR

There are two major limitations to NMR: (1) it is limited to the measurement of nuclei with magnetic moments and (2) it may be less sensitive than other spectroscopic and chromatographic methods of analysis. As we have seen, although most elements have at least one nucleus that responds in NMR, that nucleus is often of low natural abundance and may have a small magnetogyric ratio, reducing sensitivity. The proton, ¹H, and fluorine, ¹⁹F, are the two most sensitive elements.

Elements in the ionic state do not respond in NMR, rather the presence of ions in a sample contributes to unacceptable line broadening. Paramagnetic contaminants such as iron and dissolved oxygen also broaden NMR lines. Nuclei with quadrupole moments, such as ⁸¹Br, broaden the NMR signal. Line broadening in general reduces the NMR signal and hence the sensitivity.

SUGGESTED EXPERIMENTS

- 5.1 (For the instructor) Demonstrate to students in the laboratory the principal components of an NMR instrument. Indicate the steps taken in tuning the instrument.
- 5.2 Obtain the NMR spectrum of a straight-chain alkane, such as *n*-octane. Identify the methyl and methylene peaks. Note the chemical shift and the spin–spin splitting. Measure the total area of the methyl and methylene peaks and correlate this with the number of methyl and methylene protons in the molecule.
- 5.3 a. Obtain the NMR spectrum of ethyl alcohol (1) wet and (2) very dry.
 - b. Identify the methyl, methylene, and alcohol protons. Note the chemical shift and spin-spin splitting.
 - c. Measure *J*, the coupling constant, between the methyl and the methylene protons. Note the effect of water on the alcohol peak. Explain this phenomenon.
- 5.4 Integrate the peak areas obtained in Experiment 5.3. Measure the ratios of the areas and the numbers of hydrogen nuclei involved in the molecules. What is the relationship between the area and the number of hydrogen nuclei?
- 5.5 Obtain the NMR spectrum of a mixture of toluene and hexane. Integrate the peak areas of the different parts of the spectrum. From the ratio of the alcoholic hydrogen to the total hydrogen, calculate the percentage of toluene in the mixture.
- 5.6 Obtain the NMR spectra of (a) hexane and (b) heptane. Integrate the areas under the peaks in each spectrum. Would it be possible to distinguish between these compounds based on their NMR spectra? Compare with IR spectroscopy when Chapter 4 is covered and with MS (Chapter 10).
- 5.7 Record the NMR spectrum of a sample of cooking oil. Measure the ratio of hydrogen in unsaturated carbon and that in saturated carbons. Compare the degrees of unsaturation of various commercial cooking oils.
- 5.8 Repeat Experiment 5.7 using margarine as the sample. First dissolve a known amount of margarine in CCI₄ and obtain the NMR spectrum. Compare the degrees of unsaturation of different brands of margarine.
- 5.9 Obtain the NMR spectra, proton and ¹³C, for commonly available headache tablets and pain relievers. Most will dissolve in deuterated chloroform or acetone. Inert fillers may need to be filtered out of the solution. Read the labels—some are "pure" compounds such as aspirin, others contain more than one ingredient. Obtain the spectra of the pure components—acetylsalicylic acid, acetaminophen, and caffeine are common ingredients of these tablets. (The "pure" material can often also be purchased as a commercial tablet. Just be aware that you may see some impurity peaks if you are not using reagent grade materials.) Correlate the peaks with the structure of the compounds. In those tablets with more than one ingredient, note any spectral overlaps. Estimate the purity of different commercial brands of aspirin using your spectra.
- 5.10 Obtain the proton and ¹³C spectra of geraniol. Perform the following 2D experiments: COSY, HETCOR, and INADEQUATE. Using the 2D data, work out the structure of geraniol.
- 5.11 Repeat experiment 5.10 with caffeine, acetaminophen, or butyl acetate.
- 5.12 The reaction of 2,2-dimethyoxypropane with acid to form methanol and acetone can be followed by both proton and ¹³C NMR. Into a dry NMR tube, add 0.6 mL of 2,2-dimethoxypropane. Obtain the NMR spectrum and integration. Then add 0.1 mL of 1 M HCl and mix well for about 5 minutes. Obtain the NMR spectrum again. (a) Write out the reaction, using structures. Predict how many proton and/or carbon peaks you should see in the first spectrum. Predict how many peaks should be seen in the second spectrum. (b) Look up the chemical shifts of the protons (and ¹³C, if obtained) in the tables in the chapter and predict where each proton or carbon will be observed relative to TMS. (c) Confirm the identity of the peaks in your spectra.

PROBLEMS

5.1 Define the term chemical shift. Why does it occur? How is it measured for protons? For ¹³C?

- 5.2 a. Explain why spin–spin coupling occurs.
 - b. A methylene group (CH₂) is adjacent to a CH group. Into how many peaks is the CH₂ peak split by the adjacent single hydrogen?
- 5.3 What does a J coupling constant tell you? Proton A is coupled to proton B with $J_{AB} = 9$. Proton A is also coupled to proton C with $J_{AC} = 2$. Draw the predicted splitting pattern for proton A.
- 5.4 Draw a schematic proton NMR spectrum for each of the following compounds. Indicate chemical shift and peak multiplicity.
 - (a) *n*-Butane

(b) 2,2-dimethylpropane (also called neopentane)

- 5.5 Draw a schematic proton NMR spectrum for each of the following compounds. Indicate chemical shift and peak multiplicity.
 - (a) Benzene

(b) Benzaldehyde

5.6 The total area of the peaks in 1-butene (shown) is 80 units. What will be the area of the peaks caused by (a) the CH_2 group on carbon b and (b) the CH group on carbon c?

- 5.7 Draw a schematic block diagram of an FTNMR instrument.
- 5.8 Define magnetogyric ratio.
- 5.9 What is the "magic angle"? Explain why MAS is used to acquire the NMR spectrum of a solid sample.
- 5.10 Explain why liquid samples are spun in the magnetic field while acquiring an NMR spectrum.
- 5.11 Aldehydic protons occur at about 9–10 ppm, meaning that they are highly deshielded compared with other protons. Using Figure 5.9 as an example, show why the aldehyde proton is deshielded.
- 5.12 What are the rules for determining the spin number of an element?
- 5.13 Which of the following have a spin number = 0? ¹²C, ¹³C, ¹⁶O, ¹⁷O, ¹H, ²H, ¹⁹F, ²⁸Si, ³⁵Cl, ¹⁰⁸Ag, ⁹⁶Mo, ⁶⁶Zn, ⁶⁵Zn
- 5.14 What is the spin number for (a) ${}^{1}H$ and (b) ${}^{2}H$? What is the number of orientations for (a) ${}^{1}H$ and (b) ${}^{2}H$ in a magnetic field (spin number = 2I + 1)?
- 5.15 What information does the COSY experiment provide? Explain how you interpret a COSY plot.

- 5.16 What are the requirements for a standard reference material, such as TMS, in NMR?
- 5.17 What are (a) transverse relaxation and (b) longitudinal relaxation?
- 5.18 List the causes of relaxation in NMR.
- 5.19 How does the relaxation time affect linewidth?
- 5.20 What is the nuclear Overhauser effect? What advantages and disadvantages does the NOE result in for ¹³C NMR?
- 5.21 What is the chemical exchange rate at the temperature at which multiplicity is lost?
- 5.22 What is the effect of viscosity on T_1 ?
- 5.23 A proton appears at a chemical shift of 7.0 ppm (vs. TMS) in an NMR spectrometer operated at 60 MHz. What is the resonance frequency of the proton in Hz?
- 5.24 What is meant by saturation of a nucleus?
- 5.25 In the quantitative analysis example of a mixture of octane and 1-octene discussed in the text, the terminal olefinic protons that absorbed at 5.0 ppm were used to quantify the 1-octene. Could you have used any other resonance? (Look at Appendix 5, Table 5.3.) If so, show how the calculation would change from the sample calculation in the text. Is there any advantage to one calculation over the other?
- 5.26 What are the requirements for solvents used for NMR studies of dissolved organic compounds?
- 5.27 If a disubstituted benzene ring has the same two substituents, for example, dibromobenzene, the number of unique carbon atoms in the ring can be 2, 3, or 4. The ¹³C NMR spectrum depends on where the bromine atoms are located on the ring. (a) Draw the three possible dibromobenzene molecules. (b) Draw a mirror plane in each of your dibromobenzene molecules. A "mirror plane" is a plane of symmetry that gives you identical halves of the molecule on each side of the plane. Identify how many unique carbon atoms there are in each dibromobenzene molecule and predict how many peaks you will see in the ¹³C NMR spectrum of each molecule.

BIBLIOGRAPHY

Akitt, J.W. in *Multinuclear NMR*, Mason, ed., Plenum Press, NY 1987.

Akitt, J.W.; Mann, B.E. NMR and Chemistry, 4th; CRC/Taylor & Francis: Boca Raton, FL, 2000.

Ando, I.; Yamanobe, T.; Asakura, T. Prog. NMR Spectrosc. 1990, 22, 349.

Apple, T.M. NMR applied to materials analysis. Appl. Spectrosc 1995, 49 (6), 12A.

Arnold, J.T.; Dharmetti, S.S.; Packard, M.E. J. Chem. Phys. 1951, 19, 507.

Atherton, N.M. Principles of Electron Spin Resonance, Ellis Horwood, Chichester, 1993.

Bell, A.T.; Pines, A., Eds. NMR Techniques in Catalysis; Marcel Dekker, Inc.: New York, 1994.

Bock, C.; Frederic, M.; Witting, R.M.; Pörtner, H.-O. Magn. Reson. Imaging 2001, 19, 1113-1124.

Bock, C.; Sartoris, F.-J.; Pörtner, H.-O. In vivo MR spectroscopy and MR imaging on nonanaesthetized marine fish: techniques and first results. *Magn. Imaging* **2002**, *20*, 165–172.

Bovey, F.A. Nuclear Magnetic Resonance, 2nd; Academic Press: New York, 1988.

Bringmann, G.; Günther, C.; Schlauer, J.; Rückert, M. HPLC-NMR on-line coupling including the ROESY technique: direct characterization of naphthylisoquinoline alkaloids in crude plant extracts. *Anal. Chem.* **1998**, *70*, 2805.

Bruch, M.D.; Dybowski, C. Spectral editing methods for structure elucidation. In *NMR Spectroscopy Techniques*, 2nd; Bruch, M.D., Ed.; Marcel Dekker, Inc: New York, 1996.

Bruno, T.J.; Svoronos, P.D.N. CRC Handbook of Basic Tables for Chemical Analysis – Data Driven Methods and Interpretation; CRC Press: Boca Raton, FL, 2021.

Ebsworth, E.; Rankin, D.; Craddock, S. Structural Methods in Inorganic Chemistry, CRC Press, Boca Raton, 1987.

Farrar, T.C.; Becker, E.D. Pulsed and Fourier Transform NMR; Academic, New York, 1971.

Fukushima, E.; Roeder, S.B.W. Experimental Pulse NMR: A Nuts and Bolts Approach; Addison-Wesley: Reading, MA, 1981.

Fyfe, C.A. Solid State NMR for Chemists; CFC Press: Guelph, 1985.

Herlihy, A. SWIFT MRI:silent MRI that images the "invisible", Access Agilent eNewsletter, February 2011, www.chem.agilent.com/en-US/Newsletters/Accessagilent/2011/feb/pages/swift_mri.aspx.

Ichikawa, M.; Nonaka, N.; Amano, H.; Takada, I.; Ishimori, S.; Andoh, H.; Kumamoto, K. Appl. Spectrosc. 1992, 46, 1548.

- Lambert, J.B.; Shurvell, H.F.; Lightner, D.; Cooks, R.G. *Introduction to Organic Spectroscopy*; Macmillan Publishing Company: New York, 1987.
- Laupretre, F. Prog. Polym. Sci. 1990, 15, 425.
- Leyden, D.E.; Cox, R.H. Analytical Applications of NMR, John Wiley and Sons, Inc.: New York, 1977.
- Lindon, J.C.; Nicholson, J.K.; Wilson, I.D. *Advances in Chromatography*; Marcel Dekker, Inc.: New York, 1996, Vol. 36; 315.
- Maniara, G.; Rajamoothi, K.; Rajan, S.; Stockton, G.W. Method performance and validation for quantitative analysis by ¹H and ³¹P NMR spectroscopy. Applications to analytical standards and agricultural chemicals chemicals. *Anal. Chem* **1998**, *70* (23), 4921.
- Mathias, L.J. Solid State NMR of Polymers; Plenum Press: New York, 1991.
- McClure, C.K. In NMR Spectroscopy Techniques, 2nd ed.; Bruch, M.D., Ed.; Marcel Dekker, Inc.: New York, 1996.
- Pavia, D.L.; Lampman, G.M.; Kriz, G.S. *Introduction to Spectroscopy*, 3rd; Harcourt College Publishers: New York, 2001.
- Petersheim, M. Nuclear magnetic resonance. In *Analytical Instrumentation Handbook*, 2nd; Ewing, G.A., Ed.; Marcel Dekker Inc: New York, 1997.
- Robinson, J.W., Ed. Handbook of Spectroscopy; CRC Press: Boca Raton, FL, 1974, Vol. II.
- Rodgers, J.E. Wide line nuclear magnetic resonance in measurement of finish-on-fiber of textile products. *Spectroscopy* **1994**, *9* (8), 40.
- Ruan, R.; Chen, L. Water in Foods and Biological Materials-A Nuclear Magnetic Resonance Approach.

 Technomic Publishing Co., Inc., Lancaster, Pennsylvania, USA and Basel, Switzerland, 1998.
- Shoolery, J.J. NMR spectroscopy in the beginning. Anal. Chem 1993, 65 (17), 731A.
- Silverstein, R.M.; Webster, F.X. Spectrometric Identification of Organic Compounds, 6th; John Wiley and Sons, Inc: New York, 1998.
- Skelly Frame, E.M.; Uzgiris, E.E. The determination of gadolinium in biological samples by ICP-AES and ICP-MS in evaluation of the action of MRI agents. *Analyst* **1998**, *123*, 675–679.
- Skloss, T.W.; Kim, A.J.; Haw, J.F. High-resolution NMR process analyzer for oxygenates in gasoline. *Anal. Chem.* **1994**, *66*, 536.
- Smith, M.E.; Strange, J.H. NMR techniques in materials physics: a review. *Meas. Sci. Tech.* 1996, 7, 449.
 The Sadtler Handbook of Proton NMR Spectra, W.W. Simons, ed., Sadtler Research Laboratories, Inc., Phila. PA., 1978 (now Bio-Rad Laboratories, Informatics Division, Sadtler Software and Databases)
- Wendesch, D.A.W. Appl. Spectrosc. Rev 1993, 28 (3), 165.
- White, C.J.; Elliott, C.T.; White, J.R. Micro-ESR: miniature electron spin resonance spectroscopy, *Am. Lab.*, **2011**, April.
- Williams, E.A. Polymer molecular structure determination. In *Characterization of Materials*, Part I; Lifshin, E., Ed.; VCH Publishers, Inc.: New York, 1992.
- Williams, E.A.; Skelly Frame, E.M.; Donahue, P.E.; Marotta, N.A.; Kambour, R.P. Determination of bromine levels in brominated polystyrenes and poly(2,6-dimethyl-1,4-phenylene oxides). *Appl. Spectrosc.* 1990, 44, 1107.
- Yu, T.; Guo, M. Prog. Polym. Sci. 1991, 15, 825.



Atomic Absorption Spectrometry

6

The basis of atomic absorption spectrometry (AAS) is the absorption of discrete wavelengths of light by ground state, gas phase free atoms. Free atoms in the gas phase are formed from the sample by an "atomizer" at high temperatures. AAS was developed in the 1950s by Alan Walsh and rapidly became a widely used analytical tool. AAS is an elemental analysis technique capable of providing quantitative information on ~70 elements in almost any type of sample. As an elemental analysis technique, it has the significant advantage in many cases (but not all) of being practically independent of the chemical form of the element in the sample. A determination of cadmium in a water sample is a determination of the total cadmium concentration. It does not matter whether the cadmium exists as the chloride, sulfate, or nitrate, or even if it exists as a complex or an organometallic compound, if the proper analysis conditions are used. Concentrations as low as part per trillion (ppt) levels of some elements in solution can be determined and AAS is used routinely to determine ppb and ppm concentrations of most metal elements. Another principal advantage is that a given element can be determined in the presence of other elements, which do not interfere by absorption of the analyte wavelength. Therefore, it is not necessary to separate the analyte from the rest of the sample (the matrix). This results in rapid analysis times and eliminates some sources of error. This is not to say that AAS measurements are completely free from interferences; both chemical and spectral interferences do occur and must be compensated for, as will be discussed. The major disadvantages of AAS are that no information is obtained on the chemical form of the analyte (no "speciation") and that often only one element can be determined at a time. This last disadvantage makes AAS of very limited use for qualitative analysis. AAS is used almost exclusively for quantitative analysis of elements, hence the use of the term "spectrometry" in the name of the technique instead of "spectroscopy".

6.1 ABSORPTION OF RADIANT ENERGY BY ATOMS

AAS is based on the absorption of radiant energy by free gas phase atoms. In the process of absorption, an atom changes from a low-energy state to a higher energy state as discussed in Chapter 2. Gas phase atoms do not vibrate in the same sense that molecules do. Also, they have virtually no rotational energy. Hence, no vibrational or rotational energy is involved in the electronic excitation of atoms. As a result, atomic absorption spectra consist of a few very narrow absorption lines, in contrast to the wide bands of energy absorbed by molecules in solution.

Each element has a specific number of electrons "located" in an orbital structure that is unique to each element. The lowest energy electronic configuration of an atom is called the ground state. The ground state is the most stable electronic state. If energy ΔE of exactly the right magnitude is applied to a free gas phase atom, the energy will be absorbed. An outer electron will be promoted to a higher energy, less stable excited state. The frequencies and wavelengths of radiant energy capable of being absorbed by an atom are predicted from $\Delta E = hv = hc/\lambda$. The energy absorbed, ΔE , is the difference between the energy of the higher energy state and the lower energy state. As shown schematically in Figure 6.1, this atom has four electronic energy levels. E_0 is the ground state, and the other levels are higher energy excited




FIGURE 6.1 Schematic electronic energy levels in a free atom.

states. If the exact energies of each level are known, the three wavelengths capable of being absorbed can be calculated as follows:

$$\Delta E' = hc / \lambda_1 = E_1 - E_0$$

$$\Delta E'' = hc/\lambda_2 = E_2 - E_0$$

$$\Delta E''' = hc/\lambda_3 = E_3 - E_0$$

The calculated wavelengths λ_1 , λ_2 , and λ_3 all arise from transitions from the ground state to excited states. Absorption lines due to transitions from the ground state are called **resonance lines**. It is possible for an electron in an excited state to absorb radiant energy and move to an even higher excited state; in that case, we use the ΔE values for the appropriate energy levels involved. As we will see, in AAS most absorption does arise from the ground state.

Quantum theory defines the electronic orbitals in an atom and predicts the lowest energy configuration (from the order of filling the orbitals). For example, the 11 electrons in sodium have the configuration $1s^22s^22p^63s^1$ in the ground state. The inner shells (principal quantum number, n = 1 and 2) are filled and there is one electron in the n = 3 shell. It is this outer shell electron that is involved in atomic absorption transitions for sodium. UV and visible wavelengths are the range of radiant energies absorbed in AAS. UV/VIS radiation does not have sufficient energy to excite the inner shell electrons. Only the electrons in the outermost (valence) shell are excited. This is true of all elements: only the outermost electrons (valence electrons) are excited in AAS.

The number of energy levels in an atom can be predicted from quantum theory. The actual energy differences of these levels have been deduced from studies of atomic spectra. These levels have been graphed in *Grotrian diagrams*, which are plots for a given atom showing energy on the *y*-axis and the possible atomic energy levels as horizontal lines. An extensive compilation of Grotrian diagrams can be found in the book by Bashkin and Stoner. Although this book is relatively old, the compilation is valuable.

A partial Grotrian diagram for sodium is shown in Figure 6.2. The energy levels are split because the electron itself may spin one way or another, resulting in two similar energy levels and therefore two possible absorption lines rather than a single line. For the transition from the ground state to the first excited state of sodium, the electron moves from the 3s orbital to the empty 3p orbital. The latter is split into two levels, designated ${}^{2}P_{1/2}$ and ${}^{2}P_{3/2}$, by the electron spin, so two transitions are possible. The levels differ very slightly in energy




FIGURE 6.2 Partial Grotrian diagram for sodium.

because of the interaction of the electron spin and the orbital motion of the electron. The wavelengths that are associated with these transitions are 589.5 and 589.0 nm, respectively, the well-known sodium D lines which give rise to the yellow color of sodium vapor street lights.

Under the temperatures encountered in the atomizers used in commercial AAS systems, a large majority of the atoms exist in their lowest possible energy state, the ground state. Very few atoms are normally in the higher energy states. The ratio of atoms in an upper excited state to a lower energy state can be calculated from the Maxwell-Boltzmann equation (also called the Boltzmann distribution):

(6.1)
$$\frac{N_1}{N_0} = \frac{g_1}{g_0} e^{-\Delta E/kT}$$

where N_1 is the number of atoms in the upper state; N_0 , the number of atoms in the lower state; g_1 , g_0 , the number of states having equal energy at each level 0, 1, etc. (g is called the degeneracy of the level); ΔE , the energy difference between the upper and lower states (in joules); k, the Boltzmann constant = 1.381×10^{-23} J/K; and T, the absolute temperature (in kelvin).

For example, it can be calculated from the Boltzmann distribution that if zinc vapor (Zn^0 gas) with resonance absorption at 213.9 nm is heated to 3000 K, there will be only one atom in the first excited state for every 10^{10} atoms in the ground state. Zinc atoms need a considerable amount of energy to become excited. On the other hand, sodium atoms are excited more easily than the atoms of most other elements. Nevertheless, at 3000 K, only one sodium atom is excited for every 1000 atoms in the ground state. In a normal atom population, there are very few atoms in states E_1 , E_2 , E_3 , and higher. The total amount of radiation absorbed depends, among other things, on how many atoms are available in the lower-energy state to absorb radiation and become excited. Consequently, the total amount of radiation absorbed is greatest for absorption from the ground state. Excited state to excited state transitions are very rare, because there are so few excited atoms; only the ground state resonance lines are useful analytically in AAS.

This greatly restricts the number of absorption lines that can be observed and used for measurement in atomic absorption. Quite frequently, only three or four useful lines are available in the UV/VIS spectral region for each element, and in some cases fewer than that. The wavelengths of these absorption lines can be deduced from the Grotrian diagram of the element being determined, but are more readily located in AAS instrument methods manuals (called "AAS cookbooks") available from the major instrument manufacturers. A list of the most intense absorption wavelengths for flame AAS determination of elements is given in Appendix 6.A on the text website.

AAS is useful for the analysis of approximately 70 elements, almost all of them metal or metalloid elements. The energy required to reach even the first excited state of *nonmetals* is so great that they cannot be excited by normal UV radiation (>190 nm). The resonance lines of nonmetals lie in the vacuum UV region. Commercial AAS systems generally have air in the optical path, and the most common atomizer, the flame, must operate in air. Consequently, using flame atomizers, atomic absorption cannot be used for the direct determination of nonmetals. Nonmetals have been determined by indirect methods, discussed in the applications section.

6.1.1 SPECTRAL LINEWIDTH

According to the Bohr model of the atom, atomic absorption and emission linewidths should be infinitely narrow, because there is only one discrete value for the energy of a given transition. However, there are several factors that contribute to line broadening. The natural width of a spectral line is determined by the Heisenberg uncertainty principle and the lifetime of the excited state. Most excited states have lifetimes of $10^{-8}-10^{-10}\,\mathrm{s}$, so the uncertainty in the energy of the electron slightly broadens the spectral line. This is called the *natural* linewidth, and is on the order of $10^{-4}\,\mathrm{Å}$. $(1.0\,\mathrm{Å}=1.0\times10^{-10}\,\mathrm{m})$

Collisions with other atoms in the atomizer lead to *pressure* (*Lorentz*) *broadening*, on the order of 0.05 Å. *Doppler broadening*, due to random kinetic motion toward and away from the detector, results in broadening of the spectral line on the order of 0.01-0.05 Å. Doppler and collisional broadening are temperature-dependent. In an atomization source with high concentrations of ions and electrons (such as in a plasma, discussed in Chapter 7), *Stark broadening* occurs as a result of atoms encountering strong local electrical fields. In the presence of a magnetic field, *Zeeman splitting* of the electronic energy levels also occurs. Localized magnetic fields within atomizers from moving ions and electrons are negligibly small and their effects are generally not seen. However, by adding an external magnetic field, we can use Zeeman splitting to assist in the correction of background absorption. The width of atomic absorption lines is on the order of 0.002 nm. These are very narrow lines, but not infinitely narrow.

6.1.2 DEGREE OF RADIANT ENERGY ABSORPTION

The fraction of incident light absorbed by atoms at a particular wavelength is proportional to the number of atoms, N, that can absorb the wavelength and to a quantity called the oscillator strength f. The oscillator strength f is a dimensionless quantity whose magnitude expresses the transition probability for a specific transition. The **oscillator strength** is a constant for a particular transition; it is an indicator of the probability of absorbing the photon that will cause the transition. N is the number of ground state atoms in the light path, since most atoms are in the ground state at normal atomizer temperatures.

As discussed in Chapter 2, the fraction of incident light absorbed by a species can be expressed as the absorbance, A. The relationship between absorbance and the amount of analyte, in this case, atoms, in the light path is given by Beer's Law:

(6.2)
$$A = abc = (\text{constant} \times f)(b)(N/\text{cm}^3)$$

The proportionality constant a is called the absorptivity and includes the oscillator strength f. The term b is the length of the light path, and c is the concentration of ground state atoms in the light path (i.e., atoms/cm³).

The amount of radiation absorbed is only slightly dependent on temperature as shown by Equation 6.1. This is an advantage for AAS over atomic emission spectrometry and flame photometry (Chapter 7) where the signal intensity is highly temperature-dependent. Although the temperature does not affect the *process* of absorption by atoms, it does affect the efficiency with which free atoms are produced from a sample and therefore indirectly affects the atomic absorption signal. This effect can sometimes be significant. Some atoms, particularly those of the alkali metals, easily ionize. Low ionization energies and high temperatures result in the formation of ions rather than atoms. Ions do not absorb at atomic absorption wavelengths. Atoms that become ionized are effectively removed from the absorbing population, resulting in a loss of signal.

6.2 INSTRUMENTATION

A schematic block diagram of the instrumentation used for AAS is shown in Figure 6.3. The components are similar to those used in other spectroscopic absorption methods as discussed in Chapters 2 and 3. Light from a suitable source is directed through the atomizer, which serves as the sample cell, into a wavelength selector and then to a detector. The detector measures how much light is absorbed by the sample. The sample, usually in solution form, is introduced into the atomizer by some type of introduction device. The atomizer converts the sample to gas phase ground state atoms that can absorb the incident radiation.




FIGURE 6.3 Block diagram of the components of an AAS.

6.2.1 RADIATION SOURCES

Two radiation sources are commonly used in commercial AAS instruments: the hollow cathode lamp (HCL) and the electrodeless discharge lamp (EDL). Both types of lamps are operated to provide as much intensity as possible while avoiding line-broadening problems caused by the collision processes described earlier.

6.2.1.1 HOLLOW CATHODE LAMP (HCL)

Atomic absorption lines are very narrow (about $0.002 \, \text{nm}$). They are so narrow that if we were to use a continuous source of radiation, such as a hydrogen or deuterium lamp, it would be very difficult to detect any absorption of the incident radiation at all. Absorption of a narrow band from a continuum is illustrated in Figure 6.4, which shows the absorption of energy from a deuterium lamp by zinc atoms absorbing at 213.9 nm. The width of the zinc absorption line is exaggerated for illustration purposes. The wavelength scale for the deuterium lamp in Figure 6.4 is 50 nm wide, and is controlled by the monochromator bandpass. If the absorption line of Zn were 0.002 nm wide, its width would be $0.002 \times 1/50 = 1/25,000$ of the scale shown. Such a narrow line would be detectable only under extremely high resolution (i.e., very narrow bandpass), which is not encountered in commercial AAS equipment.

With the use of slits and a good monochromator, the bandwidth falling on the detector can be reduced to about 0.2 nm (much less than the earlier 50 nm example). If the light source is continuous, the entire 0.2 nm bandwidth contributes to the signal falling on the detector. If an absorption line 0.002 nm wide were absorbed from this light source, the signal reaching the detector would be reduced by only 1 % from the original signal. Since this is about the absorption linewidth of atoms, even with complete absorption of the radiation at 213.9 nm by Zn atoms, the total signal from a continuous light source would change by only 1 %. This would result in an insensitive analytical procedure of little practical use.

What is needed for a light source in AAS is a source that produces very narrow emission lines at the exact wavelengths capable of being absorbed by analyte atoms. The problem was solved by the development of the hollow cathode lamp or HCL, shown schematically in Figure 6.5. The cathode is often formed by hollowing out a cylinder of pure metal or making an open cylinder from pure metal foil. The metal used for the cathode is the metal whose spectrum will be emitted by the lamp. If we want to determine Cu in our AAS experiment, the lamp cathode must be a copper cylinder; if we want to determine gold, the cathode must be a gold cylinder, and so on. The cathode and an inert anode are sealed in a glass cylinder




FIGURE 6.4 Width of an atomic absorption line (Zn 213.9 nm line), greatly exaggerated, with the emission bandwidth from a continuum source such as a deuterium lamp.




FIGURE 6.5 Schematic diagram of an HCL. The anode and cathode are sealed in a glass cylinder filled with argon or neon gas at low pressure. The window must be transparent to the emitted radiation.

filled with Ar or Ne at low pressure (the "filler gas"). A window of quartz or glass is sealed onto the end of the lamp; a quartz window is used if UV wavelengths must be transmitted. Most HCLs have quartz windows, because most elements have emission and absorption lines in the UV. Glass can be used for some elements, such as sodium, where all the strong absorption lines are in the visible region of the spectrum.

The HCL emits narrow, intense lines from the element that forms the cathode. A tabulation of some relative intensities can be found in the book by Bruno and Svoronos. Applying a high voltage across the anode and cathode creates this emission spectrum. Atoms of the filler gas become ionized at the anode and are attracted and accelerated toward the cathode. The fast-moving ions strike the surface of the cathode and physically dislodge some of the surface metal atoms (a process called "sputtering"). The displaced atoms are excited by collision with electrons and emit the characteristic atomic emission spectrum of the metal used to make the cathode. The process is shown in Figure 6.6. The emitted atomic lines are extremely narrow. Unlike continuum radiation, the narrow emission lines from the HCL can be absorbed almost completely by unexcited atoms. Using this light source, atomic absorption is easily detected and measured. Narrow line sources such as the HCL provide not only high sensitivity, but also specificity. If only Cu atomic emission lines are produced by the Cu HCL, there are few species other than Cu atoms that can absorb these lines. Therefore, there is little spectral interference in AAS. The emitted spectrum consists of all the emission lines of the metal cathode, including many lines that are not resonance absorption lines, but these other lines do not interfere in the analysis.

Each hollow cathode emits the spectrum of metal used in the cathode. For this reason, a different HCL must be used for each different element to be determined. This is an inconvenience in practice and is the primary factor that makes AAS a technique for determining only one element at a time. The handicap is more than offset, however, by the advantage of the narrowness of the spectral lines and the specificity that results from these narrow lines.

It is possible to construct a cathode from more than one element. These are called "multielement" HCLs, and can be used for the determination of all of the elements in the cathode. This can be done sequentially but without having to change the lamp, which saves some time. In general, multielement cathodes do not perform as well for all of the elements in the




FIGURE 6.6 The HCL process, where Ar⁺ is a positively charged argon ion, M⁰ is a sputtered ground state metal atom, M* is an excited state metal atom, and λ is emitted radiation at a wavelength characteristic for the sputtered metal. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

cathode as do single HCLs for each element. The multielement cathode may have reduced intensity for one or more of the elements. All of the elements present will emit their atomic emission spectrum, resulting in a more complex emission than from a single element lamp. This may require that a less-sensitive absorption line be chosen to avoid a spectral interference. The obvious reason to use a multielement lamp is in the hope that more than one element can be measured simultaneously, making AAS a multielement technique. There are a few commercial simultaneous multielement AAS systems available for measuring up to eight elements or so. Most use a bank of single element lamps all focused on the atomizer rather than multielement cathodes. The disadvantage with this approach is that only one set of conditions in the atomizer can be used, and this set of atomization conditions may not be optimum for each element.

HCLs have a limited lifetime, usually due to loss of filler gas atoms through several processes. Adsorption of filler gas atoms onto the lamp surfaces causes decreased sputtering and decreased intensity of emission; eventually the number of filler gas atoms becomes so low that the lamp will not "light". The sputtering process causes atoms to be removed from the cathode; these metal atoms often condense elsewhere inside the lamp, trapping filler gas atoms in the process and decreasing lamp life. This is particularly a problem for HCLs of volatile metals like Cd and As. HCLs operated at currents higher than recommended will have shorter lifetimes than those operated according to the manufacturer's recommendation. Operating at higher currents results in more intensity in the lamp output, but also may increase noise, which impacts both precision and limit of detection. Since we are measuring the *ratio* of light absorbed to incident light, there is little to be gained by increasing the lamp current.

Single element HCLs cost between \$400 and \$700 per lamp, while multielement lamps cost between \$500 and \$700 each for most elements (2021 approximate costs). Lamps for particularly rare elements like Rh, Ir, and Os may cost up to four times as much.

6.2.1.2 ELECTRODELESS DISCHARGE LAMP (EDL)

It is difficult to make stable hollow cathodes from certain elements, particularly those that are volatile, such as arsenic, germanium, or selenium. The HCLs of these elements have short lifetimes and low intensities. An alternative light source has been developed in the EDL. A commercial EDL design is shown in Figure 6.7. A small amount of metal or a salt of the element whose spectrum is desired is sealed into a quartz bulb with a low pressure of Ar gas. The bulb is shown centered inside the coils in Figure 6.7. The coils are part of a self-contained RF generator. When power is applied to the coils, the RF field generated will "couple" with the metal or salt in the quartz bulb. The coupled energy will vaporize and excite the metal atoms in the bulb. The characteristic emission spectrum of the metal will be produced.

EDLs are very intense, stable emission sources. They provide better detection limits than HCLs for those elements that are intensity-limited either because they are volatile or because




FIGURE 6.7 Electrodeless discharge lamp. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

their primary resonance lines are in the low-UV region. Some elements like As, Se, and Cd suffer from both these problems. For these types of elements, the use of an EDL can result in a limit of detection that is two to three times lower than that obtained with an HCL. EDLs are available for many elements, including antimony, arsenic, bismuth, cadmium, germanium, lead, mercury, phosphorus, selenium, thallium, tin, and zinc. Older EDLs required a separate power supply to operate the lamp. Modern systems are self-contained. EDLs cost more than the comparable HCLs.

Most modern AAS systems have "coded" lamps that are recognized by the spectrometer software, which can then set up the analysis parameters automatically. The instrument "knows" that a copper lamp or a calcium lamp has been inserted and can apply the default analytical conditions without analyst intervention.

Having explained why narrow-line sources are needed for AAS, in Section 6.2.6 a new high resolution AAS using a continuum source will be introduced.

6.2.2 ATOMIZERS

The atomizer is the sample cell of the AAS system. The atomizer must produce the ground state free gas phase atoms necessary for the AAS process to occur. The analyte atoms are generally present in the sample as salts, molecular compounds, or complexes. The atomizer must convert these species to the reduced, free gas phase atomic state. The atomizer generally does this via thermal energy and some chemistry. The two most common atomizers are flame atomizers and electrothermal (furnace) atomizers.

6.2.2.1 FLAME ATOMIZERS

To create a flame, we need to mix an oxidant gas and a fuel gas, and light the mixture. In modern commercial *flame AAS* (FAAS), two types of flames are used. The first is the air-acetylene flame, where air is the oxidant and acetylene is the fuel. The second type of flame is the nitrous oxide-acetylene flame, where nitrous oxide is the oxidant and acetylene again is the fuel. The fuel and oxidant gases are mixed in a burner system, called a premix burner. An exploded view of one type of commercial flame atomic absorption burner is shown in Figure 6.8(a). In this design, the fuel gas is introduced into the mixing chamber through one inlet (not shown) while the oxidant gas is introduced through the sidearm on the *nebulizer*. The premix burner design generates laminar gas flow and a very steady flame. The steady flame generates less noise due to "flame flicker"; this improves precision. Mixing the gases in the mixing chamber eliminates the safety hazard of having a combustible gas mixture piped through the laboratory. The flame burns just above the burner head, along the slot shown in the figure.

The sample is introduced into the burner in the form of a solution. The solution is aspirated into the nebulizer, which is basically a capillary tube. The nebulizer sprays the solution into the mixing chamber in the form of a fine aerosol. Three nebulizer designs are shown schematically in Figure 6.8(b). The term "to nebulize" means to convert to a fine mist, like a cloud. The solution exits the capillary tube at high velocity and breaks into tiny droplets as a result of the pressure drop created. Kinetic energy transfer from the nebulizer gas overcomes the surface tension and cohesive forces holding the liquid together. The fuel and oxidant gases carry the sample aerosol to the base of the flame. In the flame, the sample aerosol is desolvated, vaporized, and atomized to form free gas phase atoms of the analyte. The process will be discussed in detail later.

When the sample solution passes through the nebulizer, an aerosol is formed, but the droplets are of different sizes. As a droplet enters the flame, the solvent (water or organic solvent) must be vaporized, the residue must vaporize, and the sample molecules must dissociate into atoms. The larger the droplet, the more inefficient this process is. The two devices shown in Figure 6.8(a) are used to overcome this problem. The **impact bead** is made of glass, quartz, Teflon, or ceramic, and is placed directly in front of the nebulizer spray inside the mixing chamber. The impact bead improves nebulization efficiency by breaking larger droplets into smaller ones through collision of the spray with the bead. The **flow spoiler** is




FIGURE 6.8 (a) Premix burner system. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].). **(b)** Schematic nebulizer designs. (Top): modified Babington type; (Left) concentric (the most common in FAAS); (Right) cross-flow type. (From Parsons, used with permission.)

a piece of polymer or other corrosion-resistant material machined into three or more vanes. The flow spoiler is placed in the mixing chamber, about midway between the end cap and the burner. It physically removes larger droplets from the aerosol through collision while smaller droplets pass through the openings between the vanes. The larger droplets drain from the mixing chamber through a drain opening (not shown). The aim of this system is to produce an aerosol with droplets about 4 μ m in diameter. The two devices may be used alone or in combination. The drain opening is connected to a liquid waste container with a length of polymer tubing. It is extremely important that there be a trap between the drain opening and the waste container to prevent the free flow of flame gases out of the burner assembly. The presence of the trap helps to eliminate "flashback", discussed subsequently. The trap is often a simple water-filled loop in the drain tubing itself.

The nebulizer described is a self-aspirating, pneumatic nebulizer and is the one shown schematically on the lower left of Figure 6.8(b). The nebulizer capillary is usually made of stainless steel but other materials such as Pt, Ta, and polymers may be used for corrosive solvents when contamination from the elements in steel must be avoided. Other nebulizer designs have been developed for specific applications but are not commonly used in AAS.




FIGURE 6.9 Basic AAS system. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

These other nebulizers are often used in atomic emission spectrometry and will be described in Chapter 7.

The burner head is constructed either of stainless steel or titanium. Different sizes and geometries of burner heads are used for various flames. The single slot burner head shown in Figure 6.8(a) with a 10 cm long slot is used for air-acetylene flames. The 10 cm long flame is the sample path length for the AA spectrometer in this case. A smaller 5 cm long single slot burner head with a narrower slot is used for nitrous oxide-acetylene flames. Some burner head designs use Ti and multiple fins for both flames. Usually, the slot is oriented parallel to the light beam from the radiation source, so the path length is as long as possible to achieve the highest sensitivity (remember Beer's Law), as shown in the AAS layout in Figure 6.9. The modern burner head design coupled with the use of a liquid-filled trap between the mixing chamber drain and the waste container prevents the possibility of a flashback. The gas mixture is ignited above the burner head and the flame, a highly energetic chemical reaction between the fuel and oxidant, propagates rapidly. The flame is supposed to propagate up from the burner head. It will do so if the linear gas flow rate through the burner slot is higher than the **burning velocity** of the flame. Burning velocity is a characteristic of the flame type; both nitrous oxide-acetylene and air-acetylene flames have low burning velocities. If the premixed gas flow rate is less than the burning velocity, a flashback can occur when the gas mixture is ignited. Flashback is the very undesirable and extremely hazardous propagation of the flame below the burner head slot and back into the mixing chamber. A flashback results in an explosion in the mixing chamber; it can destroy the burner assembly, create flying debris, rupture the fuel and oxidant lines thereby releasing combustible gases into the laboratory and cause injury personnel. Early burner designs and high burning velocity flames such as those using pure oxygen as oxidant were often prone to flashback. It is imperative that AAS systems be operated according to the manufacturer's directions, that only the correct gases, properly regulated, and the correct burner head be used, and that the trap and all safety interlocks be in place and functioning.

One reason for the long path length used in flame AAS (compared with the typical 1 cm path length in UV/VIS or IR absorption spectrometry) is that the premix burner and nebulizer system used is very inefficient and wasteful of sample. Sample solution is aspirated into the nebulizer at ~5 mL/min but only a small amount (<5 %) of that solution reaches the burner. The path length has to be as long as possible to compensate for the loss of sample in the mixing chamber. Flame AAS is very popular because it is fast, has high element selectivity, and the instruments are easy to operate, but the inefficiency of the sample introduction system combined with noise inherent in the system restricts detection limits in flames to the ppm range for most elements.

6.2.2.2 ELECTROTHERMAL ATOMIZERS

In order to measure ppb concentrations of metals, a different type of atomizer is needed. A furnace or electrothermal atomizer (ETA) was developed less than ten years after the technique of AAS was developed. In 1961, B.V. L'vov built a heated carbon tube atomizer, illustrated in Figure 6.10. The system used a carbon tube heated by electrical resistance (hence, an *electrothermal atomizer*). The tube was lined with Ta foil and purged with argon gas. After




FIGURE 6.10 High-temperature furnace atomizer designed and used by L'vov.

the tube or furnace reached an elevated temperature, the sample, on a carbon electrode, was inserted at the bottom, as shown in the figure. Atomization took place and the analyte atoms absorbed the light beam passing through the carbon tube. His system was orders of magnitude more sensitive than flame atomizers, but was difficult to control. Other workers in the field, particularly West, Massman, and Robinson, refined carbon rod and furnace atomizers. Most commercial instruments use some version of a carbon tube atomizer for electrothermal atomization. The most common atomizer of this type uses a tube of graphite coated with pyrolytic graphite and heated by electrical resistance; therefore, this commercial ETA is called a **graphite furnace atomizer**. The acronym GFAAS tells the reader that the atomizer used is a graphite furnace, as opposed to a flame.

A commercial graphite furnace atomizer is illustrated in Figure 6.11. This atomizer consists of a graphite tube, approximately 6 mm in diameter and 25-30 mm long, the electrical




FIGURE 6.11 Graphite furnace atomizer. This is a longitudinally heated furnace design. The graphite tube is shown in greater detail in figure 6.21. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

contacts required to heat the tube, a system for water-cooling the electrical contacts at each end of the tube, and inert purge gas controls to remove air from the furnace. An inert gas is used to prevent the graphite from being oxidized by air during the heating process. Quartz windows at each end of the furnace assembly permit the light from the HCL or EDL to pass through the furnace and out to the spectrometer. A small amount of sample solution, between 5 and 50 μL, is dispensed into the graphite tube through a small hole in the top of the tube. The furnace is heated in a series of programmed temperature steps to evaporate the solvent, decompose (ash, char) the sample residue, and finally to atomize the sample into the light path. Details of the graphite furnace atomization process and temperature program will be discussed later. The diagram in Figure 6.11 shows a longitudinally heated graphite furnace. The electrical contacts are at each end of the tube and they must be watercooled. Longitudinal heating results in a temperature gradient in the heated furnace—the ends are cooler than the center. This may result in recondensation of vaporized species at the ends of the tube. This can be a problem for the next sample analysis if material from the previous sample is still in the furnace. The problem is called "carry-over" or "memory effect", and can result in poor accuracy and precision. To overcome this problem, new graphite furnaces that are heated transversely have been developed. A transverse graphite tube is shown in Figure 6.12. The electrical contacts are transverse to the light path, and the tube is heated across the circumference. This results in even heating over the length of the furnace and reduces the carry-over problem significantly.

Modern graphite furnace atomizers have a separate power supply and programmer that control the electrical power, the temperature program, the gas flow, and some spectrometer functions. For example, the spectrometer can be programmed to "read", that is, collect absorbance data, only when the furnace reaches the atomization temperature. This saves data storage space and data processing time.

Researchers have developed other types of ETAs over the years, including filaments, rods, and ribbons of carbon, tantalum, tungsten, and other materials, but the only commercial ETA available is the graphite furnace atomizer.

6.2.2.3 OTHER ATOMIZERS

Two additional commercially available atomizers (really analysis techniques with unique atomizers) must be discussed, because they are extensively used in environmental and clinical analysis. They are the **cold vapor-AAS technique** (CVAAS) for determination of the element mercury, Hg, and the **hydride generation technique** (HGAAS) for several elements that form volatile hydrides, including As, Se, and Sb. These elements are toxic; federal and state laws regulate their concentrations in drinking water, wastewater, and air, so their measurement at ppb concentrations is very important. Because the CVAAS and HGAAS "atomizers" are analysis techniques they will be discussed under applications of AAS.




FIGURE 6.12 A graphite tube for a transversely heated furnace. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

An atomizer based on glow discharge techniques is commercially available for the analysis of solid metal samples by AAS. It will be discussed in the applications sections under solid sample analysis.

Some safety considerations should be mentioned concerning all furnaces and burners. The potential for exposure to heavy metal contamination due to the vaporized compounds is real, and therefore, it is best to have a snorkel in place above the burner or furnace. This snorkel should be connected to the laboratory fume hood system or connected to a dedicated exhaust blower. Details on these types of safety devices can be found in the book by Bruno and Svoronos, CRC Handbook of Basic Tables for Chemical Analysis—Data Driven Methods and Interpretation, 4th Edition, CRC Press, Boca Raton, 2021.

6.2.3 SPECTROMETER OPTICS

6.2.3.1 MONOCHROMATOR

A monochromator is required to separate the absorption line of interest from other spectral lines emitted from the HCL and from other elements in the atomizer that are also emitting their spectra. Because the radiation source produces such narrow lines, spectral interference is not common. Therefore, the monochromator does not need high resolution.

A typical monochromator is shown in Figure 6.13. The most common dispersion element used in AAS is a diffraction grating. The grating disperses different wavelengths of light at different angles, as discussed in Chapter 2. The grating can be rotated to select the wavelength that will pass through the exit slit to the detector. All other wavelengths are blocked from reaching the detector. The angle of dispersion at the grating is a function of the density of lines ruled on the grating. The more lines/mm on the grating, the higher is the dispersion. Higher dispersion means greater separation between adjacent lines. A high dispersion grating permits the use of wider entrance and exit slits on the monochromator to achieve the same resolution. Wider slits allow more light to pass through the system to the detector. Large high-quality gratings with high dispersion are expensive, but they offer better energy throughput than cheaper low-dispersion gratings. In addition to the number of lines ruled on the grating, the blaze angle affects the intensity of diffracted wavelengths. Gratings can be blazed for any wavelength; the farther away a given wavelength is from the wavelength for which the grating is blazed, the more light intensity will be lost in diffraction. The analytically useful wavelength range for commercial AAS is from 190 to 850 nm. If a grating is blazed for the middle of this range, there will be loss in intensity at both extremes. That is particularly bad for elements such as Se, As, P, Cd and Zn, with resonance lines at the low UV end, and for the alkali metals, with resonance lines at the high end of the visible region. To overcome this problem, the monochromator can be equipped with two gratings, one blazed for the UV and one for the visible. Modern spectrometers automatically control





FIGURE 6.13 Typical grating monochromator layout. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

the movement and alignment of the grating or gratings, so that the correct one is used for the wavelength being measured.

Most commercial AAS systems have the monochromator, optics, and detector designed for the measurement of one wavelength at a time; they are single-element instruments. There are a few systems available that perform multielement determinations simultaneously, using an Echelle spectrometer (discussed in Chapter 2) and a bank of HCLs all focused on the atomizer. The limitation to this approach is not the sources or the spectrometer or the detector, but the atomizer. The atomizer can only be at one set of conditions, and those conditions will not necessarily be optimum for all of the elements being measured. There will be a tradeoff in detection limits for some of the elements.

6.2.3.2 OPTICS AND SPECTROMETER CONFIGURATION

The spectrometer system for AAS can be configured as a single-beam system, as shown in Figure 6.8, as a double-beam system, shown in Figure 6.14, or as a pseudo-double-beam system, which will not be discussed. (See the reference by Beaty and Kerber for a description of this system.) Note that in AAS the sample cell is placed in front of the monochromator, unlike UV/VIS spectrometers for molecular absorption or spectrophotometry, where the sample is placed after the monochromator.






FIGURE 6.14 (a) Schematic double-beam AAS configuration. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].). (b) The optical path of the Shimadzu scientific instruments AA-7000 superimposed over the actual instrument body. On the right, from front to back, is the hollow cathode lamp, the beam-splitter (slanted rectangle) and the deuterium lamp. In the center, from front to back, we have the burner head with the sample beam passing over it, the reference beam and the monochromator at the center top. On the left is the mirrored chopper and, in the back, the detector. (Courtesy of Shimadzu Scientific Instruments, Inc. [www.shimadzu.com].)

A single-beam system is cheaper and less expensive than a double-beam system, but cannot compensate for instrumental variations during analysis. In a double-beam system, part of the light from the radiation source is diverted around the sample cell (flame or furnace atomizer) to create a *reference beam*, as shown in Figure 6.14. The reference beam monitors the intensity of the radiation source and electronic variations (noise, drift) in the source. The signal monitored by the detector is the ratio of the sample and reference beams. This makes it possible to correct for any variations that affect both beams, such as short-term changes in lamp intensity due to voltage fluctuations in the power lines feeding into the instrument. Compensation for these variations is performed automatically in modern double-beam spectrometers. Even though part of the source radiation is directed to the reference beam, modern double-beam instruments have the same signal-to-noise ratio as single-beam instruments with the advantage of more accurate and precise absorbance measurements.

Lenses or mirrors are used to gather and focus the radiation at different parts of the optical system. This avoids losing too much signal as a result of the light beams being nonparallel and focuses the light beam along the flame so that as much light as possible passes through the sample. Any light that does not pass through the sample cannot be absorbed and results in a loss in sensitivity. Quartz lenses have been used for this purpose, but most instruments today use front-surfaced concave mirrors, which reflect and focus light from their faces and do not lose much radiation in the process. The monochromator has two slits: an entrance slit and an exit slit. The entrance slit is used to prevent stray radiation from entering the monochromator. Light passes from the entrance slit to the grating. The entrance slit should be as wide as possible to permit as much light as possible to fall on the grating, but must be narrow enough to isolate the wavelength of interest. After dispersion by the grating, the radiation is directed toward the exit slit. At this point, the desired absorption line is permitted to pass, but the other lines emitted from the source and atomizer are blocked from reaching the detector by the monochromator exit slit. The system of slits and grating enables the analyst to choose the wavelength of radiation that reaches the detector. There is rapid loss in sensitivity as the mechanical slit width, and hence the spectral bandpass (spectral slit width), is increased.

Commercial AAS instrumentation may be purchased with fixed slits or with variable slits. Fixed mechanical slit widths are available so that the resolution and sensitivity are acceptable for most analytical purposes at a lower cost than instruments with variable slit widths. Variable slit widths are desirable for maximum flexibility, especially if samples are varied and complex. Instruments that have both flame and graphite furnace atomizers often have separate sets of slits of different heights for each atomizer. The furnace slits are usually shorter to avoid having emission from the small diameter incandescent furnace reach the detector. In general, the analyst should use the widest slit widths that minimize the stray light that reaches the detector while spectrally isolating a single resonance line for the analyte from the HCL.

6.2.4 DETECTORS

The common detector for AAS is the PMT. The construction and operation of a PMT has been described in Chapter 5. While PMTs are the most common detectors, solid-state single and multichannel detectors such as PDAs (discussed in Chapter 5) and CCDs (discussed in Chapters 5 and 7) are increasingly being used in AAS spectrometers. Many small systems, particularly those dedicated to one element such as a dedicated CVAAS mercury analyzer, use solid-state detectors instead of PMTs. Multielement simultaneous AAS systems also use multichannel solid-state detectors to measure more than one wavelength at a time.

6.2.5 MODULATION

Many metals, when atomized in a flame or furnace, emit strongly at the same wavelength at which they absorb. The emission signal can cause a serious error when the true absorption is to be measured. This problem is illustrated in Figure 6.15. Emission by the metal in




FIGURE 6.15 Emission by excited atoms in the atomizer can occur at the resonance wavelength, resulting in a direct error in the AAS measurement.

the atomizer is at precisely the same wavelength as the absorption wavelength of the metal because the same electronic transition is involved. Better resolution cannot improve the situation. Furthermore, since we are trying to measure I_1 , the interference by the emission from the flame will result in a direct error. Unless a correction is made, the signal recorded will be $(I_1 + E)$, where E is the emission intensity.

This problem is overcome most simply by modulation of the radiation source. **Modulation** means that the source radiation is switched on and off very rapidly. This can be done by using a rotating mechanical *chopper* placed directly in front of the source. A chopper is shown in Figures 6.9 and 6.14. The mechanical chopper is a circle of metal sheet with opposite quadrants cut out. Every quarter turn of the chopper alternately blocks and passes the source radiation. Another way to modulate the source is by pulsing the power to the lamp at a given frequency. When modulated, the signal from the source is now an alternating current (AC) signal. Therefore, the signal for both I_0 and I_1 is AC, but the sample emission E is not modulated. It is a direct current (DC) signal. The detector electronics can be "locked in" to the frequency of the AC signal. The modulated absorption signal will be measured and the DC emission signal will be ignored. This eliminates emission from the atomizer as a source of error. Modulation of the source is required for accurate results in AAS. All modern commercial instruments have some means of source modulation in the instrument.

6.2.6 COMMERCIAL AAS SYSTEMS

AAS is considered a mature analysis technique with decades-long production of instruments by a large number of companies around the world. The biggest change in most modern AA systems is in the size of the instruments and the capabilities of the software. Instruments today are much smaller than older designs. Some systems have automated switching between flame and furnace atomizers, eliminating what had been a labor intensive and potentially errorprone job; some have the ability to run both flame and furnace at the same time. Many have multiple lamp turrets, with lamps already warmed up to avoid waiting when switching from one element to the next. They incorporate features such as video cameras to observe what is happening in the furnace to enable better optimization and method development. Intelligent or smart software is found on most modern systems that will recognize the lamp installed, set the optimum instrument parameters or user-specified method parameters, and will even validate the performance of an instrument, all without any intervention by the analyst.

Complete systems are available from a large number of instrument companies. These include but are not limited to Agilent Technologies, Analytik Jena, Aurora Biomed, GBC, PerkinElmer, Shimadzu Scientific Instruments (who makes the only instrument with a vibration sensor to shut down the flame in case of earthquakes!), and Thermo Fisher Scientific. There are numerous smaller companies, like Buck Scientific and companies in China, India, and elsewhere who only distribute locally. A completely new AAS concept is now available from Analytik Jena AG, as described in the next section.

Cold vapor and hydride AAS systems for mercury, As, Se and other hydride-forming elements, discussed in Sections 6.5.3.4 and 6.5.3.5, are available from the major AAS manufacturers, and also from companies making dedicated analyzers, including Teledyne Leeman Labs, Teledyne Cetac Technologies, and Milestone, Inc.

6.2.6.1 HIGH-RESOLUTION CONTINUUM SOURCE AAS

AAS, as developed in the 1950's by Alan Walsh, required a narrow line source of light and modulation of that source. Recently, advances in source and detector technology, combined with a high-resolution double monochromator, have enabled the use of a continuum source for AAS (Welz and Heitmann; Welz et al.). The instruments, from Analytik Jena AG (www. analytik-jena.de), are the ContrAA* High-Resolution Continuum Source AAS systems (HR-CS AAS). The source is a small xenon arc lamp, which provides a continuous source of radiation with high intensity, especially in the UV range. The systems use a high-resolution double monochromator consisting of a prism pre-monochromator followed by an echelle grating monochromator. The detector is a UV-sensitive CCD linear array detector. No modulation is required. Each pixel of the CCD functions as an independent detector, with all pixel information shifted simultaneously into a read-out register. This configuration means that the analytical line does not need to be separated from the adjacent emission of the continuum source by an exit slit. There is no exit slit since the CCD array itself represents a large number of high-resolution detectors. Each individual detector accumulates a spectral range of about 2 pm; the entire array comprises a spectral range of about 0.4 nm.

Only 1-3 pixels are used for registering the analyte absorption, so all the remaining pixels are available for correction purposes. Both fluctuations in lamp emission and transmission of the atomizer are accounted for, making the system a simultaneous double beam system of high precision with simultaneous background correction.

Since the intensity of the source does not affect sensitivity, but does influence the noise, the high intensity source increases the detection limits of this system by a factor of 2-5 over conventional AAS. The linear dynamic range of the system is 5-6 orders of magnitude, much broader than conventional AAS and similar to ICP-OES (discussed in Chapter 7).

The high-intensity continuum source offers a number of advantages over narrow line sources. Secondary lines (non-resonance lines) can be used in order to reduce sensitivity, thereby avoiding dilutions. All spectral lines are available, including lines for which no HCL or EDL sources are available, such as fluorine and chlorine. In addition, molecular absorptions, such as those of diatomic molecules like CS or PO, can be used to measure sulfur and phosphorus (Huang et al.)

The CCD detector permits not only simultaneous background correction, but complete correction of spectral interferences such as structured background from molecular species such as OH and NO. The resolution permits collection of the spectra from these species and removal of them from the absorbance of the sample. Direct line overlap can also be corrected, if the matrix has an additional absorption line within the registered spectral range of the detector. Direct line overlap is rare and usually is due to line-rich matrices such as Fe, so the system can reliably correct for the direct overlap of Fe on Zn, for example.

We discussed above the desire to speed up AAS by having simultaneous multielement measurement and the compromises that current HCL/EDL systems make. The HR-CS AAS technique is not a simultaneous multielement system, but since it uses a single source, the "change" of elements, i.e., the reading of a different line, is extremely fast, especially for flame AAS. The system therefore functions as a fast sequential FAAS with the advantage that every element can be measured under automatically set optimum conditions, rather than the compromise conditions a bank of HCLs or a multielement HCL uses. The transient signals from a graphite furnace are still problematic due to the large amount of data collected with the concomitant increase in detector readout times.

6.3 THE ATOMIZATION PROCESS

6.3.1 FLAME ATOMIZATION

Most samples we want to examine by AAS are solid or liquid materials. Examples of solid samples are soil, rock, biological tissues, food, metal alloys, ceramics, glasses, and polymers. Examples of liquid samples are water, wastewater, urine, blood, beverages, oil, petroleum

	$M^* + A^-$	(Solution
1. Nebulization	↓ M*+A-	(Aerosol)
2. Desolvation	↓ MA	(Solid)
3. Liquefaction	↓ MA	(Liquid)
4. Vaporization	↓ M.A	(Gas)
5. Atomization	\downarrow $M^0 + A^0$	(Gas)
6. Excitation	↓ M*	(Gas)
7. Ionization	↓ M*+e	(Gas)

FIGURE 6.16 The processes associated anion. M^o and A^o are (© 1993-2020 PerkinElmer, inc. with permission. [www.perkinelmer.com].)

products, and organic solvents. For flame AAS (FAAS) and most GFAAS determinations, the sample must be in the form of a solution. This requires that most samples be prepared by acid digestion, fusion, ashing, or other forms of sample preparation (Chapter 1) to give us an aqueous, acidic solution, or a solution in a combustible organic solvent. We will look at aqueous acidic solutions, since they are the most common form of sample for FAAS. Metals are present in aqueous acidic solutions as dissolved ions; examples include Cu²⁺, Fe³⁺, Na⁺, and Hg²⁺.

To measure an atomic absorption signal, the analyte must be converted from dissolved ions in aqueous solution to reduced gas phase free atoms. The overall process is outlined in Figure 6.16. The sample solution, containing the analyte as dissolved ions, is aspirated through the nebulizer. The solution is converted into a fine mist or aerosol, with the analyte still dissolved as ions. When the aerosol droplets enter the flame, the solvent (water, in this case) is evaporated. The sample is now "de-solvated" and in the form of tiny solid particles. The heat of the flame can melt (liquefy) the particles and occurring in a flame atomizer. then vaporize the particles. Finally, the heat from the flame (and the combustion chem-M+ is a metal cation; A- is the istry in the flame) must break the bonds between the analyte metal and its anion, and produce free M⁰ atoms. This entire process must occur very rapidly, before the analyte the ground state free atoms is carried out of the observation zone of the flame. After free atoms are formed, several of the respective elements. things can happen. The free atoms can absorb the incident radiation; this is the process we want. The free atoms can be rapidly oxidized in the hostile chemical environment of All rights reserved. Printed the hot flame, making them unable to absorb the resonance lines from the lamp. They can be excited (thermally or by collision) or ionized, making them unable to absorb the resonance lines from the lamp. The analyst must control the flame conditions, flow rates, and chemistry to maximize production of free atoms and minimize oxide formation, ionization, and other unwanted reactions. While complete atomization is optimum and will yield the highest signal, it is much more important that the atomization process be consistent. If the atomization is not complete, any variation in the fractional atomization will result in errors in analysis.

> The flame is responsible for production of free atoms. Flame temperature and the fuel/ oxidant ratio are very important in the production of free atoms from compounds. Many flame fuels and oxidants have been studied over the years, and temperature ranges for some flames are presented in Table 6.1. In modern commercial instruments, only air-acetylene and nitrous oxide-acetylene flames are used, however data on additional flames can be found in the book by Bruno and Svoronos.

> Lower temperature flames are subject to interferences from incomplete atomization of the analyte. The air-acetylene flame is useful for many elements, but the hotter and more chemically reducing nitrous oxide-acetylene flame is needed for refractory elements and elements that are easily oxidized, such as A1 and Si. Appendix 6.1 lists the usual flame chosen for each element. This appendix also gives the fuel/oxidant ratio conditions used for maximum sensitivity for each element. Flames are classified as oxidizing (excess oxidant) or reducing (excess fuel). Air-acetylene flames can be used in either an oxidizing mode or a reducing mode; nitrous oxide-acetylene flames are usually run in a reducing mode. In general, excess oxidant helps to destroy organic material in samples. However, excess oxidant can react with elements that exist as stable oxides to form oxide molecules. These oxide molecules cannot undergo atomic absorption. Elements that form stable oxides, such as aluminum, boron, molybdenum, and chromium, are therefore determined using reducing flame conditions,

TABLE 6.1 Temperatures Obtained in Various Premixed Flames (°C)

	Oxidant	
Fuel	Air	N ₂ O
H ₂	2000-2100	
Acetylene	2100-2400	2600-3000
Propane (natural gas)	1700–1900	

usually with the high-temperature nitrous oxide-acetylene flame, to prevent the formation of oxide molecules. The chemistry that occurs depends on what part of the flame is observed; the base of the flame differs from the inner core of the flame and both differ from the outer mantle of the flame.

If we measure the absorbance signal of an atom with respect to the height of the signal above the burner, we arrive at a relationship called a flame profile. The burner assembly can be moved up and down with respect to the light source, by turning a knob manually or through the software that controls the burner position. The beam of light from the source is fixed in position. The flame profile is determined by aspirating a solution of an element into a flame with the burner height set so that the light beam from the lamp is at the base of the flame, just above the burner head. Then the burner head is slowly lowered, so that the light beam passes through higher and higher regions of the flame. The absorbance is plotted vs. the height above the burner. Flame profiles for Cr, Mg, and Ag in an oxidizing air-acetylene flame are shown in Figure 6.17. The signal for magnesium, Mg, starts off low at the base of the flame, because free atoms have not yet formed from the sample. The absorbance increases with increasing height in the flame (above the burner head), to a maximum. Moving farther up in the flame causes the absorbance to decrease. This curve is brought about by the complicated reactions that take place in a flame, including atomization, oxidation, and ionization. All of these processes compete in the flame. The maximum sensitivity for Mg will be obtained when the light beam is at the position of maximum absorbance, above the burner




FIGURE 6.17 (a) Flame profiles for Cr, Mg, and Ag demonstrating differences in free atom formation as a function of height above the burner in an oxidizing air-acetylene flame. **(b)** Two-dimensional atom distributions in a 10 cm air-acetylene flame. Fuel-rich (reducing) and fuel-lean (oxidizing) results are shown. The scale on the left is the height above the burner head (in cm). Maximum absorbance is shown as the smallest circle in the plot with the contour lines separated by 0.1 in absorbance. (The diagrams in **(b)** are adapted and reprinted with permission from Rann and Hambly, [Rann, C.S., Hamby, A.N., Anal. Chem., 7 (37), 786–790, 1965].)

head, but not very high up in the flame. The decrease in absorbance as we go higher up in the flame is due to the formation of oxide molecules. Many elements have flame profiles similar to Mg, but not all, as can be seen in Figure 6.17. Chromium forms very stable oxides that are hard to atomize. As can be seen from its profile, the absorbance by Cr atoms is actually highest at the base of the flame. Cr atoms combine with oxygen in air almost as soon as they are formed, and the absorbance decreases rapidly with height above the burner head (i.e., with increasing exposure to air). Chromium is an element that would be better determined in a fuel-rich (reducing) flame to minimize the formation of chromium oxide. Silver, on the other hand, starts with low absorbance at the base of the flame just like Mg. Then, the absorbance increases with increasing height in the flame, indicating that silver atoms are stable once formed; there is no decrease in absorbance due to oxide formation or ionization.

In practice, the optimum position for taking absorbance measurements is determined in exactly this way. A solution of the element to be determined is aspirated, the absorbance is monitored continually and the burner head is moved up and down (and forward and back) with respect to the light beam until the position of maximum absorbance is located. Older instruments have a ruler mounted along the burner compartment to indicate where the burner head is with respect to the light beam to assist in adjusting the height of the burner. Modern systems can control burner adjustment through the software. Figure 6.17(b) shows the 2D distribution of atoms in an air-acetylene flame for several elements. These are side views of the flames, as would be seen by the detector. The contour lines differ by 0.1 in absorbance, with the maximum absorbance at the center of the profile. Fuel-rich (reducing) and fuel-lean (oxidizing) conditions are displayed. As we discussed, Cr shows the highest absorbance in a fuel-lean flame just above the burner head; in a fuel-rich flame, the maximum absorption position is moved up in the flame. Molybdenum shows the same response, but even more strongly. Calcium can be determined in either a fuel-rich or fuel-lean flame, but the position of maximum absorbance is very different for each flame. In the fuel-rich flame, the optimum position is more than 2 cm above the burner, while in an oxidizing flame the position is between 0.5 and 1 cm above the burner. The need to optimize the horizontal position of the burner with respect to the light source can be seen from the width of the intervals of the atom distributions.

The flame profile results from the complex physical and chemical processes occurring in the flame. The formation of free atoms depends on the flame temperature and on the chemical form of the sample. Chemical species with small dissociation energies at high temperatures will dissociate to form free atoms. For a given flame temperature, free atom formation depends on the chemical species and its dissociation constant. If the metal exists in the sample in a stable chemical form (small dissociation constant), it may be difficult to decompose, and atomization efficiency is low. On the other hand, if the metal is in a chemical form that is easily decomposed, the number of atoms formed is high and the atomization efficiency is high. The atomization efficiency is a measure of how many free atoms are formed from all the possible species containing the atom. It can be expressed as the fraction of the total element in the gaseous state that is present as free atoms at the observation height in the atomizer or as the fraction of the total element present as both free atoms and ions. By total element we mean all atomic, molecular, and ionic species containing the atom of interest, M (e.g., M, MX, MO, M+). The atomization efficiency can vary from 0 to 1, and the value will depend on where in the atomizer the observation of the fraction M/(total M-containing species) is made. More detailed discussions are found in the Handbook of Spectroscopy, Vol. 1, edited by Robinson, or the references by Dean and Rains (Vol. 1), or Ingle and Crouch listed in the bibliography.

The loss of free atoms in the atomizer is also a function of the chemistry of the sample. If the oxide of the analyte element is readily formed, the free atoms will form oxides in the flame and the population of free atoms will simultaneously decrease. This is the case with elements such as chromium, molybdenum, tungsten, and vanadium. On the other hand, some metal atoms are stable in the flame and the free atoms exist for a prolonged period. This is particularly so with the noble metals—platinum, gold, and silver. Adjusting the fuel/oxidant ratio can change the flame chemistry and atom distribution in the flame as shown in Figure 6.17(b). Atoms with small ionization energies will ionize readily at high temperatures (and even at moderate temperatures). In an air-acetylene flame, moderate concentrations of potassium are about 50 % ionized, for example. Ions do not absorb atomic lines.

The maximum absorbance signal depends on the number of free atoms in the light path. These free atoms are in dynamic equilibrium with species in the flame; they are produced continuously by the flame and lost continuously in the flame. The number produced depends on the original concentration of the sample and the atomization efficiency (Table 6.2). The number

TABLE 6.2 Efficiencies of Atomization^a of Metals in Flames

	Flame		
Metal	Air-C ₂ H ₂	N ₂ O-C ₂ H ₂	
Ag	1.0	0.6	
Al	<0.00005	0.2	
Au	1.0	0.5	
В	< 0.0005	0.004	
Ва	0.001	0.2*	
Ве	0.00005	0.1	
Bi	0.2	0.4	
Ca	0.07	0.5*	
Cd	0.5	0.6	
Co	0.3	0.3	
Cu	1.0	0.7	
Cr	0.07	0.6	
Cs*	0.7	_	
Fe	0.4	0.8	
Ga	0.2	0.7	
In	0.6	0.9	
K*	0.4	0.1	
Li*	0.2	0.4	
Mg	0.6	1.0	
Mn	0.6	0.8	
Na*	1.0	1.0	
Pb	0.7	0.8	
Rb*	1.0	_	
Si	_	0.06	
Sn	0.04	0.8	
Sr	0.08	0.03	
Ti	_	0.2	
TI	0.5	0.56	
V	0.01	0.3	
Zn	0.7	0.9	

Source: Modified from Robinson, J.W. (ed.), Handbook of Spectroscopy, Vol. 1, CRC Press, Boca Raton, FL. 1975.

^a The efficiency of atomization in the flames has been measured as the fraction of total element in the gaseous state present as free neutral atoms or ionized atoms at the observation height in the atomizer. That is, efficiency of atomization = (neutral atoms + ions)/total element. Entries marked * obtained using ionization suppression, discussed in Section 6.4.1. The data were obtained under a variety of conditions by multiple researchers and may not be directly comparable between elements. The reference should be consulted for details. lost depends on the formation of oxides, ions, or other non-atomic species. The variation of atomization efficiency with the chemical form of the sample is called *chemical interference*. It is the most serious interference encountered in AAS and must always be taken into account. Interferences are discussed in detail in Section 6.4. Table 6.2 can be used as a guide for choosing which flame to use for AAS determination of an element. For example, aluminum will definitely give better sensitivity in a nitrous oxide-acetylene flame than in air-acetylene, where hardly any free atoms are formed; the same is true of Ba. But for potassium, clearly an air-acetylene flame is a better choice in terms of sensitivity than the hotter nitrous oxide-acetylene flame. This is because K is very easily ionized at high temperatures and ions do not give atomic absorption signals. Based on ionization energy trends, one expects that Cs and Rb would also be more sensitive in the cooler air-acetylene flame. There are no entries in the table for Cs or Rb in a nitrous oxide-acetylene flame; they ionize to such an extent that the nitrous oxide-acetylene flame cannot be used for determining Cs or Rb by FAAS, just as Si and Ti are too refractory to be determined in an air-acetylene flame.

6.3.2 GRAPHITE FURNACE ATOMIZATION

There are many differences in the atomization process in a flame and in a graphite furnace. One very important difference to keep in mind is that in FAAS, the sample solution is aspirated into the flame continuously for as long as it takes to make the absorbance measurement. This is usually not long, about 30 s once the flame has stabilized after introducing the sample solution, but it is a continuous process. GFAAS is not a continuous process; the atomization step produces a transient signal that must be measured in less than 1 s. We will again consider an aqueous acidic solution of our sample.

A small volume of solution, between 5 and 50 μ L, is injected into the graphite tube via a micropipette or an autosampler. The analyte is once again in the form of dissolved ions in solution, and the same process outlined in Figure 6.16 must occur for atomic absorption to take place. The graphite furnace tube is subjected to a multistep temperature program. The program controls the temperature ramp rate, the final temperature at each step, the length of time the final temperature is held at each step and the nature and flow rate of the purge gas through the furnace at each step. A typical graphite furnace program consists of six steps: (1) dry, (2) pyrolyze (ash, char), (3) cool, (4) atomize, (5) clean out, and (6) cool down.

A generic temperature program for GFAAS might look like that in Figure 6.18. The process of atomization is extremely fast and must be rigidly controlled. The temperature program is therefore very carefully controlled, both with respect to the times used for each section of the heating program and the temperature range involved in each step. It is vital to




FIGURE 6.18 Typical temperature program for a graphite furnace atomizer. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

avoid loss of sample during the first two steps, but it is also extremely important to eliminate as much organic and other volatile matrix material as possible.

The "dry" step is used to remove the solvent. The solvent must be removed without splattering the sample by rapid boiling, which would result in poor precision and accuracy. A slow temperature ramp from room temperature to about 110°C is used for aqueous solutions. The upper temperature is held for about a minute. The purge gas during this step is the normal inert gas (nitrogen or argon) at its maximum flow of about 300 mL/min to remove the solvent vapor from the furnace. The "pyrolyze" step is also called the ashing step or the "char" step. Its purpose is to remove as much of the matrix as possible without volatilizing the analyte. The "matrix" is everything except the analyte; it may consist of organic compounds, inorganic compounds, or a mixture of both. The sample is again subjected to a temperature ramp. The upper temperature is chosen to be as high as possible without losing the analyte and held for a short time. The gas flow is normally 300 mL/min and is usually the inert purge gas. With some organic sample matrices, switching to air is done in this step to help oxidize the organic materials.

A cool down step before the atomization step is used for longitudinally heated furnaces. This has been shown to improve sensitivity and reduce peak "tailing" for some refractory elements. This improves the accuracy of the measurement for these elements. The cool down step is not used in transversely heated furnaces.

The atomization step must produce gas phase free analyte atoms. The temperature must be high enough to break molecular bonds. In general, the temperature is raised very rapidly for this step, as shown in Figure 6.18, and the purge gas flow is stopped to permit the atoms to remain in the light path. Stopping the purge gas flow increases the sensitivity of the analysis. The atomization occurs very rapidly and the signal generated is a transient signal; as the atoms form, the absorbance increases. As the atoms diffuse out of the furnace, the absorbance decreases, resulting in a nearly Gaussian peak-shaped signal. An idealized signal is presented in Figure 6.19(a). Atomization signals for molybdenum from two different types of graphite furnace tubes are shown in Figure 6.19(b). The spectrometer system is programmed




FIGURE 6.19 (a) An ideal Gaussian-shaped atomization signal from a graphite furnace. (b) Atomization signals for molybdenum in a graphite furnace atomizer. (a) is the signal resulting from an uncoated graphite tube atomizer. (b) is the signal from a graphite tube coated with pyrolytic graphite. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

to begin to acquire the absorbance data as soon as the atomization step begins. The integrated area under the absorbance peak is used for quantitative measurements.

Finally, the furnace is taken to a temperature higher than the atomization temperature to burn out as much remaining residue as possible; this is the "clean out" step. The furnace is allowed to cool before the next sample is injected. The entire program for one replicate of one sample is usually about two minutes long. Modern GFAAS systems may allow for temperature programs of up to 20 separate steps. GFAAS systems are now available with high-definition video cameras in the furnace, so that the analyst can watch the sample behavior as part of method development. The camera could show, for example, if the sample spatters during the dry step, permitting the analyst to lower the temperature to avoid loss of sample.

In early GFAAS instruments, the sample was pipetted onto the bottom wall of the tube. The tube was heated in a programmed fashion as has been described and atomization occurred "off the wall" of the tube. Poor precision and a variety of interferences were serious problems with this approach. Modern graphite furnace atomizers make use of a pyrolytic graphite platform, first introduced by L'voy, inserted into the graphite tube or fabricated as an integral part of the tube. The sample is pipetted onto the platform and is atomized from the platform, not from the wall of the tube. The reasons for use of the L'voy platform will be discussed in Section 6.4. In addition, modern GFAAS methods add one or more chemicals to the sample in the furnace. These chemicals are called "modifiers" and are used to control interferences.

6.4 INTERFERENCES IN AAS

Interferences are physical or chemical processes that cause the signal from the analyte in the sample to be higher or lower than the signal from an equivalent standard. Interferences can therefore cause positive or negative errors in quantitative analysis. There are two major classes of interferences in AAS: spectral interferences and non-spectral interferences. Non-spectral interferences are those that affect the formation of analyte-free atoms. Non-spectral interferences include chemical interference, ionization interference, and solvent effects (or matrix interference). Spectral interferences cause the amount of light absorbed to be erroneously high due to absorption by a species other than the analyte atom. While all techniques suffer from interferences to some extent, AAS is much less prone to spectral interferences and non-spectral interferences than atomic emission spectrometry and XRF, the other major optical atomic spectroscopic techniques.

6.4.1 NON-SPECTRAL INTERFERENCES

6.4.1.1 CHEMICAL INTERFERENCE

A serious source of interference is *chemical interference*. Chemical interference occurs when some chemical component in the sample affects the atomization efficiency of the sample compared with the standard solution. The result is either an enhancement or a depression in the analyte signal from the sample compared with that from the standard. This effect is associated most commonly with the predominant anions present in the sample. The anion affects the stability of the metal compound in which the analyte is bound, and this, in turn, affects the efficiency with which the atomizer produces metal atoms. For example, a solution of calcium chloride, when atomized in an air-acetylene flame, decomposes to calcium atoms more readily than a solution of calcium phosphate. Calcium phosphate is more thermally stable than calcium chloride. A solution of calcium chloride containing 10 ppm Ca will give a higher absorbance than a solution of calcium phosphate containing 10 ppm Ca. If phosphate ion is added to a solution of calcium chloride, the absorbance due to Ca will decrease as the concentration of phosphate increases. This is a chemical interference. It occurs in the atomization process. Chemical interference is a result of having insufficient energy in the flame or furnace to break the chemical bonds in molecules and form free atoms.

There are three ways of compensating for chemical interference. The first approach is to match the matrix of the standards and samples; that is, to have the same anion(s) present in the same concentrations in the working standards as in the samples being analyzed. This supposes that the samples have been thoroughly characterized and that their composition is known and constant. This may be the case in industrial production of a material or chemical, but often the sample matrix is not well characterized or constant.

A second approach is to add another metal ion that forms an even more stable compound with the interfering anion than does the analyte ion. Such an ion is called a "releasing agent" because it frees the analyte from forming a compound with the anion and permits it to atomize. For example, lanthanum forms a very thermally stable phosphate, more stable than calcium phosphate. To determine Ca in solutions that contain an unknown or variable amount of phosphate, such as those from biological samples, the analyst can add a large excess of lanthanum (as the chloride or nitrate salt) to all standards and samples. The lanthanum "ties up" the phosphate by forming lanthanum phosphate. If all of the phosphate is now present as lanthanum phosphate, this eliminates the dependence of the formation of Ca atoms on the phosphate concentration. The exact concentration of phosphate does not have to be measured; it is only necessary to add enough La to completely react with the phosphate in the solution to be analyzed. Usually 500-2000 ppm La is sufficient for most types of samples. The same amount of La must be added to all the solutions, including the blank. The releasing agent should be of the highest purity possible.

The third approach is to eliminate the chemical interference by switching to a higher-temperature flame, if possible. For example, when a nitrous oxide-acetylene flame is used, there is no chemical interference on Ca from phosphate, because the flame has sufficient energy to decompose the calcium phosphate molecules. Therefore, no lanthanum addition is required.

A fourth possible approach is the use of the method of standard additions (MSA), discussed in Chapter 1. This approach can correct for some chemical interferences but not all. For example, in the graphite furnace, if the analyte is present as a more volatile compound in the sample than the added analyte compound, MSA will not work. The analyte form in the sample is lost prior to atomization as a result of volatilization, while the added analyte compound remains in the furnace until atomization; therefore, the standards additions method will not give accurate analytical results.

6.4.1.2 MATRIX INTERFERENCE

Other potential sources of interference are the sample matrix and the solvent used for making the sample solution. The sample matrix is anything in the sample other than the analyte. In some samples, the matrix is quite complex. Milk, for example, has a matrix that consists of an aqueous phase with suspended fat droplets and suspended micelles of milk protein, minerals, and other components of milk. The determination of calcium in milk presents matrix effects that are not found when determining calcium in drinking water. Samples with high concentrations of salts other than the analyte may physically trap the analyte in particles that are slow to decompose, interfering in the vaporization step and causing interference. Differences in viscosity or surface tension between the standard solutions and the samples, or between different samples, will result in interference. Interference due to viscosity or surface tension occurs in the nebulization process for FAAS because different volumes of solution will be aspirated in a given period of time and nebulization efficiency will change as a result of the solvent characteristics. Metals in aqueous solutions invariably give lower absorbance readings than the same concentration of such metals in an organic solvent. This is due in part to enhanced nebulization efficiency of the organic solvent. In aqueous acidic solutions, higher acid concentrations often lead to higher solution viscosity and a decrease in absorbance due to decreased sample uptake. Matrix and solvent effects are often seen in GFAAS as well as FAAS, and may be more severe in furnaces than in flames. The presence of matrix interference can be determined by comparing the slope of an external calibration curve with the slope of an MSA curve (discussed in Chapter 1). If the slopes of the two calibrations are the same (parallel to each other), there is no matrix interference; if the slopes are different (not parallel), interference exists and must be corrected for.

The solvent may interfere in the atomization process. If the solvent is an organic solvent, such as a ketone, alcohol, ether, or a hydrocarbon, the solvent not only evaporates rapidly, but may also burn, thus increasing the flame temperature. The atomization process is more efficient in a hotter flame. More free atoms are produced and a higher absorbance signal is registered from solutions in organic solvents than from aqueous solutions, even though the metal concentration in the two solutions is equal.

Matching the solutions in the working standards to the sample solutions can compensate for matrix or solvent interferences. Type of solvent (water, toluene, methyl isobutyl ketone, etc.), amount and type of acid (1 % nitric, 5 % HCl, 20 % sodium chloride, etc.), and any added reagents such as releasing agents must be the same in calibration standards and samples for accurate results.

Alternatively, the MSA may be used to compensate for matrix interferences. This calibration method uses the sample to calibrate in the presence of the interference. Properly used, MSA will correct for the solvent interference but care must be taken. The assumption made in using MSA is that whatever affects the rate of formation of free atoms in the sample will affect the rate of formation of free atoms from the added analyte spike in the same way. MSA will not correct for spectral interference or for ionization interference. MSA can correct for interferences that affect the slope of the curve but not for interferences that affect the intercept of the curve.

6.4.1.3 IONIZATION INTERFERENCE

In AAS, the desired process in the atomizer should stop with the production of ground state atoms. For some elements, the process continues as shown in Figure 6.16 to produce excited state atoms and ions. If the flame is hot enough for significant excitation and ionization to occur, the absorbance signal is decreased because the population of ground state atoms has decreased as a result of ionization and excitation. This is called ionization interference. Ionization interferences are commonly found for the easily ionized alkali metal and alkaline earth elements, even in cool flames. Ionization interferences for other elements may occur in the hotter nitrous oxide-acetylene flame, but not in airacetylene flames.

Adding an excess of a more easily ionized element to all standards and samples eliminates ionization interference. This addition creates a large number of free electrons in the flame. The free electrons are "captured" by the analyte ions, converting them back to atoms. The result is to "suppress" the ionization of the analyte. Elements often added as ionization suppressants are potassium, rubidium, and cesium. For example, in the AAS determination of sodium, it is common to add a large excess of potassium to all samples and standards. Potassium is more easily ionized than sodium. The potassium ionizes preferentially and the free electrons from the ionization of potassium suppress the ionization of sodium. The detection limit of the sodium determination thereby decreases. The ionization suppression agent, also called an ionization buffer, must be added to all samples, standards, and blanks at the same concentration for accurate results. An example of the use of ionization suppression is shown in Figure 6.20. Absorbance at a barium resonance line (atomic absorption) and absorbance at a barium ion line (by barium ions in the flame) are plotted as a function of potassium added to the solution. As the potassium concentration increases, barium ionization is suppressed; the barium stays as barium atoms. This results in increased atomic absorption at the resonance line and a corresponding decrease in absorbance at the ion line. The trends in absorbance at the atom and ion lines very clearly show that barium ion formation is suppressed by the addition of 1000 ppm of the more easily ionized potassium.

6.4.1.4 NON-SPECTRAL INTERFERENCES IN GFAAS

Graphite furnace atomizers experience significant non-spectral interference problems, some of which are unique to the furnace. Compensation or elimination of these interferences is different than what is done in flame atomizers.




FIGURE 6.20 The suppression of barium ionization in a flame atomizer by addition of the more easily ionized element potassium. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

Some analytes react with the graphite surface of the atomizer at elevated temperatures to form thermally stable carbides. These carbides do not atomize, thereby decreasing the sensitivity of the analysis. Carbide formation also results in poor precision and poor accuracy, because the amount of carbide formation depends on the condition of the graphite atomizer surface. Elements that tend to form carbides include W, Ta, B, Nb, and Mo, among others. The use of a dense pyrolytic graphite coating on the tube wall is highly recommended to minimize carbide formation. Normal graphite has a very porous structure that permits solution to soak into the graphite tube, thereby increasing the graphite/solution contact area and allowing more carbide formation at high temperatures. Pyrolytic graphic forms an impervious surface that prevents the solution from entering the graphite structure, decreasing carbide formation. Comparing the atomization profiles for Mo in Figure 6.19(b), it is apparent that the atomization from an uncoated tube (peak A) appears at a much later time than that from a pyrolytic graphite-coated tube. This time delay is due to the need for Mo to diffuse out of the porous uncoated graphite. The result is not only a time delay, but also a very broad absorbance signal that is difficult to integrate accurately. As you can see, the peak has not returned to the baseline, even after 5 min at the atomization temperature. The signal from the pyrolytic graphite-coated tube rises rapidly and returns to baseline rapidly, evidence that no significant diffusion of Mo into the graphite has occurred. This results in a higher absorbance signal and a peak that can be integrated accurately. It also permits a much shorter atomization step and increases tube life; both contribute to higher sample throughput.

When an analyte is atomized directly from the wall of the graphite tube, chemical and matrix interferences can be severe. The analyte, either as atoms or gas phase molecules, is released from the hot wall at the atomization temperature into a cooler inert gas atmosphere inside the tube. The atmosphere is heated by conduction and convection from the tube walls, so the temperature of the atmosphere lags behind that of the walls. The atoms or molecules enter this cooler atmosphere where a number of processes may occur. For example, the atoms may recombine with matrix components into molecules or the temperature may be low enough that vaporized analyte-containing molecules fail to atomize. In either case, nonspectral interference occurs. A solution to this problem is the use of a platform insert in the tube, shown schematically in Figure 6.21. The platform surface is pyrolytic graphite and is deliberately designed to be in poor contact with the tube. The platform is heated by radiation from the tube walls. When an analyte is placed on the platform, it does not atomize when the wall reaches the right temperature, but later, when the platform and the atmosphere are both at the same, higher temperature. The difference in temperature of the gas phase inside the




FIGURE 6.21 (a) Schematic of a L'vov platform inserted into a standard longitudinal graphite tube. The left diagram is a cutaway view of the platform inside the tube. The right diagram is an end-on view of the tube and platform looking along the light path. (b) Commercial platforms have a shallow depression into which the sample is pipetted through the opening in the top of the tube. The opening is shown as a dark area on the front and end-on views. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

atomizer for wall and platform atomization is shown in Figure 6.22. This higher temperature improves the atomization of molecules and prevents recombination of free atoms. The result is a significant reduction in interferences, and a significant improvement in precision.

6.4.1.5 CHEMICAL MODIFICATION

Chemical modification, also commonly called **matrix modification**, is the addition of one or more reagents to the graphite tube along with the sample. The use of these chemical modifiers is to control non-spectral interferences by altering the chemistry occurring inside the furnace. The reagents are chosen to enhance the volatility of the matrix, to decrease the volatility of the analyte, or to modify the surface of the atomizer. The use of a large amount of chemical modifier may, for example, convert all of the analyte into a single compound with well-defined properties. The end result of the use of chemical modifiers is to improve the accuracy and precision of the analysis by permitting the use of the highest possible pyrolysis temperature. This permits removal of the matrix with no loss of analyte.




FIGURE 6.22 Tube wall and platform temperature profiles. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com.].)




FIGURE 6.23 Effect of matrix modification on pyrolysis temperatures for cadmium. Without modification, Cd begins to volatilize out of the furnace at temperatures below 500 °C. By adding modifiers or combinations of modifiers, Cd is retained in the furnace at much higher temperatures. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

Cadmium is one of the heavy metal elements whose concentrations in the environment are regulated by law due to toxicity. Drinking water, blood, urine, and environmental samples are analyzed routinely for Cd at low ppb concentrations by GFAAS. Many common cadmium compounds, such as cadmium chloride, are relatively volatile. With no modifiers, Cd starts to volatilize out of the furnace at pyrolysis temperatures as low as 400 °C, as seen in Figure 6.23. By adding either single compounds or mixtures of compounds, the pyrolysis temperature can be increased significantly, to over 1000 °C. The addition of the modifier(s) converts cadmium in the sample to a much less volatile form. In general, this improves both the precision and accuracy of the analysis. If, for example, cadmium had been present in the sample in two different chemical forms, such as an organometallic Cd compound and an inorganic Cd compound, these two compounds might atomize at different rates and at different temperatures. The result would be multiple atomization signals, as shown in Figure 6.24. This can cause a serious error in the measurement of the signal. Multiple analyte peaks can usually be eliminated through the use of an appropriate matrix modifier that converts the analyte to one common species.

Another example of a modifier used to stabilize the analyte is the use of nickel nitrate in the determination of selenium in biological tissues. Addition of nickel nitrate as a modifier retains Se in the furnace as nickel selenide while allowing the pyrolysis and removal of the organic matrix. Without the addition of nickel nitrate, the pyrolysis temperature must be 350 °C or less to prevent loss of Se. With the use of nickel nitrate, temperatures up to 1100 °C can be used.

In some cases, the matrix itself can be made more volatile through chemical modification. For example, in the determination of traces of elements in seawater, the matrix in the graphite tube after drying would be primarily NaCl. NaCl is a high melting ionic compound




FIGURE 6.24 Multiple atomization signals caused by different chemical forms of analyte in the sample. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

and requires relatively high temperatures to volatilize it. The NaCl molecule stays intact on volatilization, increasing the background absorbance (a spectral interference). If all the NaCl could be volatilized out of the furnace, very volatile analyte elements like Hg, As, Se, Pb, and many more would have been lost in the process. By adding an excess of ammonium nitrate as a *matrix modifier* to the sample in the graphite tube, the NaCl matrix can be converted to the much more volatile compounds ammonium chloride and sodium nitrate. Most of the matrix can be removed at a temperature below 500 °C, which substantially reduces background absorption without loss of volatile analytes.

A generic "mixed modifier" of palladium and magnesium nitrate improves the GFAAS determination of many elements. The AAS cookbook of methods provided with commercial instruments should contain the recommendations for matrix modification for standard GFAAS determination of each element. Of course, it is imperative that very high-purity reagents be used for matrix modification and blank determinations that include the modifiers must be run.

6.4.2 SPECTRAL INTERFERENCES

Spectral interferences occur when absorption of the hollow cathode resonance line occurs by species other than the element being determined. For example, the Pb 217.0 nm line may be absorbed by the components of a flame even though no lead is present in the sample or in the flame. This is a spectral interference.

6.4.2.1 ATOMIC SPECTRAL INTERFERENCE

The resonance absorption lines of the various elements are very narrow, on the order of 0.002 nm, and at discrete wavelengths. Direct overlap between absorption lines of different elements is rare and can usually be ignored as a source of error. Absorption by the wings of the absorption lines of interfering elements present in high concentrations has been observed, but this is also a rare occurrence. A table of reported atomic spectral overlaps can be found in the handbook by Dean cited in the bibliography. The only cures for direct atomic spectral interference are (1) to choose an alternate analytical wavelength or (2) to remove the interfering element from the sample. Extracting the interfering element away from the analyte or extracting the analyte away from the interfering element can accomplish the last option. There are many successful methods in the literature for the separation of interferences and analytes, but care must be taken not to lose analyte or contaminate the sample in the process. The extraction approach also permits the analyst to concentrate the analyte during the extraction, improving the accuracy and the sensitivity of the analysis when performed correctly.

6.4.2.2 BACKGROUND ABSORPTION AND ITS CORRECTION

A common occurrence that results in spectral interference is absorption of the HCL radiation by molecules or polyatomic species in the atomizer. This is called "background absorption"; it occurs because not all of the molecules from the sample matrix and the flame gases are completely atomized. This type of interference is more commonplace at short wavelengths (<250 nm) where many compounds absorb, as discussed in Chapter 3. Incomplete combustion of organic molecules in the atomizer can cause serious background interference problems. If a flame atomizer is used, incomplete combustion of the solvent may take place, particularly if the flame is too reducing (fuel-rich). The extent of the interference depends on flame conditions (reducing or oxidizing), the flame temperature used, the solvent used, and the sample aspiration rate. Background interference is much more severe when graphite furnace atomizers are used because the pyrolysis step is limited to a maximum temperature that does not volatilize the analyte. Consequently, many matrix molecules are not thermally decomposed. They then volatilize into the light path as the higher atomization temperature is reached and absorb significant amounts of the source radiation.

We have seen that atoms absorb over a very narrow wavelength range and that overlapping absorption by other atoms of the resonance lines of the analyte is extremely unlikely. However, molecular absorption occurs over broad bands of wavelengths and is observed in flame and graphite furnace atomizers. The molecular absorption may come from hydroxyl radicals generated from water in the flame, incomplete combustion of organic solvent, stable molecular residues, metal oxides, and so on. Solid particles in flame atomizers may scatter light over a wide band of wavelengths; this is not absorption, but results in less light reaching the detector. Scattering of light therefore causes a direct error in the absorption measurement. If these broad absorption and scattering bands overlap the atomic absorption lines, they will absorb/scatter the resonance line from the hollow cathode and cause an increase in absorbance, a spectral interference. There are several ways of measuring this background absorption and correcting for it.

6.4.2.3 CONTINUUM SOURCE BACKGROUND CORRECTION

Let us remind ourselves why we usually do not use a broadband, continuum lamp as a light source in AAS. The normal monochromator and slit system results in a spectral slit width about 0.2 nm wide. If we have a continuum source, the light from the source will fill the entire spectral window, as shown in the lower left-hand side drawing in Figure 6.25. When the continuum emission passes through the flame, the atoms can only absorb that portion of it exactly equal to the resonance wavelength. The atomic absorption line has a total width of about 0.002 nm. Consequently, if the atoms absorb all of the radiation over that linewidth, they will absorb only 1 % of the radiation from the continuum lamp falling on the detector, as shown in the lower center drawing of Figure 6.25. All light within the 0.20 nm bandwidth, but not within the 0.002 nm absorption line, will reach the detector and not be absorbed by the sample. In other words, 99 % or more of the emitted light reaches the detector. Consequently, the effect of atomic absorption on the continuum lamp is negligible and we can say that atoms do not measurably absorb the continuum lamp emission. It is this observation that permits the use of a continuum light source to measure and correct for broadband molecular background absorption.

In the continuum source background correction method, when an HCL source is used, the absorption measured is the total of the atomic and background absorptions. When a continuum lamp source is used, only the background absorption is measured. The continuum




FIGURE 6.25 (a) Atomic and background absorption with a line source (HCL, EDL). (b) Atomic and background absorption with a continuum source (deuterium lamp, tungsten-filament lamp). The width (x-axis) of each diagram is the spectral slit width. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)




FIGURE 6.26 Continuum background corrector in a double-beam AAS system. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

lamp, which emits light over a range or band of wavelengths, is placed into the spectrometer system as shown in Figure 6.26. This setup allows radiation from both the HCL and the continuum lamp to follow the same path to reach the detector. The detector observes each source alternately in time, either through the use of mirrored choppers or through pulsing of the lamp currents. When the HCL lamp is in position as the source, the emission line from the HCL is only about 0.002 nm wide; in other words, it fills only about 1 % of the spectral window as shown in the upper left-hand side drawing in Figure 6.25. When the HCL radiation passes through the flame, both the free atoms at the resonance line and the broadband absorbing molecules will absorb the line. This results in significant attenuation of the light reaching the detector, as shown in the upper center and right-hand side drawing in Figure 6.25. When the continuum source is in place, the continuum lamp emission fills the entire spectral window as shown in the lower left-hand side drawing in Figure 6.25. Any absorption of the radiation from the continuum lamp observed is broadband background absorption, since it will be absorbed over the entire 0.2 nm as seen in the lower right-hand side drawing in Figure 6.25. We showed above that any atomic absorption of the continuum lamp is negligible. The absorbance of the continuum source is therefore an accurate measure of background absorption. An advantage of this method is that the background is measured at the same nominal wavelength as the resonance line, resulting in more accurate correction.

This correction method is totally automated in modern AAS systems. The HCL or EDL and the continuum lamp are monitored alternately in time; instrument electronics compare the signals, and calculate the net atomic absorption.

The lamps used as continuum sources are a deuterium lamp (D_2) for the UV region and a tungsten filament lamp for the visible region. Commercial instruments using continuum background correction normally have both of these continuum sources installed to cover the complete wavelength range; the continuum lamp used is computer-selected based on the analyte wavelength.

Continuum background correction is used for FAAS and can be used for furnace AAS. There are limitations to the use of continuum background correction. If another element (not the analyte) in the sample has an absorption line within the spectral bandpass used, especially if this element is present is large excess, it can absorb radiation and result in inaccurate background correction. The background correction is made using two different sources. The correction can be inaccurate if the sources do not have similar intensities, and if they are not aligned properly to pass through exactly the same region of the atomizer. This is especially true when the background levels are high. Continuum sources can generally correct for background absorbance up to A = 0.8. A problem can arise when the background absorption spectrum is not uniform over the spectral bandpass; such background absorption is said to have "fine structure". Absorption with fine structure may not be corrected properly using a continuum lamp corrector; the correction may be too large or too small. These limitations are particularly problematic in GFAAS which is prone to high background levels.

6.4.2.4 ZEEMAN BACKGROUND CORRECTION

Atomic absorption lines occur at discrete wavelengths because the transition that gives rise to the absorption is between two discrete energy levels. However, when a vapor phase atom is placed in a strong magnetic field, the electronic energy levels split. This gives rise to several absorption lines for a given transition in place of the single absorption line in the absence of a magnetic field. This occurs in all atomic spectra and is called **Zeeman splitting** or the Zeeman effect. In the simplest case, the Zeeman effect splits an absorption line into two components. The first component is the π component, at the same wavelength as before (unshifted); the second is the σ component, which undergoes both a positive and negative shift in wavelength, resulting in two equally spaced lines on either side of the original line. This splitting pattern is presented in Figure 6.27. The splitting results in lines that are separated by approximately 0.01 nm or less depending on the field strength. The strength of the magnetic field used is between 7 and 15 kgauss. Background absorption and scatter are usually not affected by a magnetic field.

The π and σ components respond differently to polarized light. The π component absorbs light polarized in the direction parallel to the magnetic field. The σ components absorb only radiation polarized 90° to the applied field. The combination of splitting and polarization differences can be used to measured total absorbance (atomic plus background) and background only, permitting the net atomic absorption to be determined.

A permanent magnet can be placed around the furnace to split the energy levels. A rotating polarizer is used in front of the HCL or EDL. During that portion of the cycle, when the light is polarized parallel to the magnetic field, both atomic and background absorptions occur. No atomic absorption occurs when the light is polarized perpendicular to the field, but background absorption still occurs. The difference between the two is the net atomic absorption. Such a system is a DC Zeeman correction system.

Alternately, a fixed polarizer can be placed in front of the light source and an electromagnet can be placed around the furnace. By making absorption measurements with the magnetic field off (atomic plus background) and with the magnetic field on (background only), the net atomic absorption signal can be determined. This is a transverse AC Zeeman correction system. The AC electromagnet can also be oriented so that the field is along the light path (a longitudinal AC Zeeman system) rather than across the light path. No polarizer is required in a longitudinal AC Zeeman system.

The use of a polarizer in either DC or AC Zeeman systems cuts the light throughput significantly, adversely affecting sensitivity and precision. DC Zeeman systems require less power, but have poorer linear working range and sensitivity than AC systems. AC Zeeman systems are more expensive to operate but have higher sensitivity and larger linear working ranges than DC systems.

Zeeman correction can also be achieved by having an alternating magnetic field surround the hollow cathode, causing the emission line to be split and then not split as the field is turned on and off. By tuning the amplifier to this frequency, it is possible to discriminate between the split and unsplit radiation. A major difficulty with the technique is that the




FIGURE 6.27 Zeeman effect causing shifts in electronic energy levels. **(a)** Hg resonance line in the absence of a magnetic field occurs as a single line at 253.7 nm. **(b)** Hg resonance line in the presence of a magnetic field. The π component is at the original, unshifted wavelength (253.7 nm); The $\pm \sigma$ components are shifted equally away from the original line to higher and lower wavelengths.

magnetic field used to generate Zeeman splitting also interacts with the ions in the hollow cathode. This causes the emission from the hollow cathode to be erratic, which in turn introduces imprecision into the measurement. Most commercial instruments with Zeeman background correctors put the magnet around the atomizer. Zeeman correction systems can be used with flame atomizers and are commercially available; one disadvantage to using this approach is that the magnet blocks the analyst's view of the flame. This makes it impossible to visually check that the flame conditions are correct, since the analyst cannot see the color of the flame. The analyst cannot see if the burner slot is partially blocked or if charred material is building up on the burner when organic solvents are run. These unobserved problems might result in errors in the analysis. The significant advantage of Zeeman background correction is to compensate for the high background absorption in graphite furnace atomizers.

The advantages of Zeeman background correction are numerous. Only one light source is required. Since only one light source is used, there is no need to match intensity or align multiple sources. The physical paths of the split and unsplit light are identical, as opposed to the use of a continuum lamp, where the radiation may not pass along the identical path as the HCL radiation. The background correction is made very close to the resonance line and at the same absorption bandwidth as the atomic absorption signal. Therefore, the correction is generally very accurate, even for background with fine structure and for high background levels, up to Absorbance = 2.0. The Zeeman correction system can be used for all elements at all wavelengths. One limitation to the use of Zeeman background correction is that it shortens the analytical working range. The relationship between absorbance and concentration becomes nonlinear at lower absorbances than in a non-Zeeman corrected system, and then the absorbance-concentration relationship "rolls over". That is, as concentration increases, absorbance first increases linearly, then nonlinearly until a maximum absorbance is reached. After the maximum, absorbance actually decreases with increasing concentration. It is possible for two completely different concentrations, one on either side of the absorbance maximum, to exhibit the same absorbance value. The roll-over point must be established by carefully calibrating the instrument and unknown samples may need to be run at more than one dilution factor to ensure that an unknown is not on the "wrong side" of the absorbance maximum. If this well-understood potential problem is kept in mind, the use of Zeeman background correction with modern GFAAS instrumentation and methodology provides accurate and precise GFAAS results. Use of Zeeman correction causes significant loss in sensitivity compared to continuum background correction for some elements, notably Li, Cs, Tl, Be, Hg, B, and V. Systems with Zeeman background correction are more expensive than those with only continuum background correction.

6.4.2.5 SMITH-HIEFTJE BACKGROUND CORRECTION

It will be remembered that the HCL functions by the creation of excited atoms that radiate at the desired resonance wavelengths. After radiating, the atoms form a cloud of neutral atoms that, unless removed, will absorb resonance radiation from other emitting atoms.

If the HCL is run at a high current, an abundance of free atoms form. These free atoms absorb at precisely the resonance lines the hollow cathode is intended to emit; an example is shown in Figure 6.28, with the free atoms absorbing exactly at λ over an extremely narrow bandwidth [Figure 6.28(b)]. The result is that the line emitted from the HCL is as depicted in Figure 6.28(c) instead of the desired emission line depicted in Figure 6.28(a). The emitted lines are broadened by the mechanisms discussed in Section 6.1.1. The phenomenon of absorption of the central portion of the emission line by free atoms in the lamp is called "self-reversal". Such absorption is not easily detectable, because it is at the very center of the emitted resonance line and very difficult to resolve. It is, of course, exactly the radiation that is most easily absorbed by the atoms of the sample. In practice, if the HCL is operated at too high a current, the self-reversal decreases the sensitivity of the analysis by removing absorbable light. It also shortens the life of the lamp significantly.

The Smith-Hieftje background corrector has taken advantage of this self-reversal phenomenon by pulsing the lamp, alternating between high current and low current. At low current, a normal resonance line is emitted and the sample undergoes normal atomic absorption.




FIGURE 6.28 Distortion of spectral line shape in an HCL due to self-reversal. (a) Shape of the spectral line emitted by the HCL. (b) Shape of the spectral energy band absorbed by cool atoms inside the HCL. (c) Shape of the net signal emerging from an HCL, showing self-absorption of the center of the emission band.

When the HCL is pulsed to a high current, the center of the emission line is self-absorbed, leaving only the wings of the emitted resonance line; the emitted line would look similar to Figure 6.28(c). The atoms of the sample do not significantly absorb such a line. The broad background, however, absorbs the wings of the line. Consequently, the absorption of the wings is a direct measurement of the background absorption at the wavelength of the atomic resonance absorption. The Smith-Hieftje technique can be used to automatically correct for background. In practice, the low current is run for a fairly short period of time and the absorbance measured. The high current is run for a very short, sharp burst, liberating intense emission and free atoms inside the hollow cathode and the absorbance is again measured. The difference between the measurements is the net atomic absorption. There is then a delay time to disperse the free atoms within the lamp before the cycle is started again.

The advantages of the Smith-Hieftje technique are that it can be used in single-beam optics and it is not necessary to align the beam measuring background absorption and atomic absorption since it is the same beam. In addition, the electronics are much simpler than that used in a Zeeman background correction system and no expensive magnet is needed. There are some disadvantages to the technique. It requires a special type of HCL that can operate both at low and high currents and the life of the special HCLs is significantly less than that of standard HCLs (150-500 hours depending on the element vs. 5000 hours for standard HCLs). The loss in sensitivity for this technique is about 50 % of that obtained using a continuum correction system, the dynamic range is shorter and the technique cannot correct for structured background. The Smith-Hieftje background correction system is commercially available in Shimadzu Scientific AAS instruments, where it is known as rapid self-reversal background correction. All lamps for the Shimadzu instruments are self-reversing lamps which can be run at low current for D_2 background correction work. A more detailed comparison of the methods used for background correction is given in the reference by Carnrick and Slavin listed in the bibliography.

6.4.2.6 SPECTRAL INTERFERENCES IN GFAAS

Graphite furnace atomizers have their own particular spectral interference problems. Any emission from the light source or atomizer that cannot be absorbed by the analyte should be prevented from reaching the detector. Usually, the emission from flames is low. At atomization temperatures in excess of 2200 $^{\circ}$ C, the graphite furnace is a white-hot emission source. If this intense visible radiation reaches the PMT, noise increases, which decreases precision. The emission from the hot graphite is essentially blackbody radiation, extending from 350 to 800 nm and varying in intensity with wavelength. The extent of emission interference caused by this radiation falling on the detector varies with analyte wavelength. Elements with resonance lines in the 400–600 nm region like Ca and Ba can be seriously affected. The control of emission interference lies in spectrometer design, which is not controlled by the analyst and in the correct installation, alignment, and maintenance of the furnace and optical windows, which are very definitely controlled by the analyst.

Background absorption can be severe in GFAAS. Decreasing the sample volume and choosing alternate wavelengths can be used to reduce background levels in some cases. Control of the chemistry in the furnace is key to reducing background. The pyrolysis step must be designed to volatilize as much of the matrix as possible without loss of analyte. Ideally, the matrix would be much more volatile than the analyte, so that 100 % matrix removal could occur in the pyrolysis step with 100 % retention of analyte in the furnace. This situation rarely occurs. It is possible to control the volatility of the matrix and analyte to some extent through matrix modification. The use of matrix modifiers seems to control background (a spectral interference) by controlling non-spectral interferences.

A potential problem with any automatic background corrector is that the analyst may be unaware of the extent to which the background is present. It should be remembered that when absorbance A=2, the transmittance T=1/100, and the absorbed radiation is 99 % of the available radiation. Therefore, the total signal falling on the detector is only 1 % of I_0 . If quantitative analysis is carried out using this very small signal, major errors may result. A 1 % error in measuring the background may result in a 100 % error in measuring the atomic absorption by the sample. Instrument manufacturers claim quantitative atomic absorption measurements while correcting background absorption in excess of 99 % using Zeeman background correction. Analysts should be aware of the magnitude of the background signal, because a small error in measuring the background becomes a major error in the net atomic absorption measurement. Steps such as the use of L'vov platforms, matrix modification, alternate wavelengths, reduction in sample volume, and other techniques to minimize background should be taken to keep background absorbance as low as possible to obtain accurate results.

6.5 ANALYTICAL APPLICATIONS OF AAS

AAS is a mature analytical technique. There are thousands of published methods for determining practically any element in almost any type of sample. There are books and journals devoted to analytical methods by AAS and other atomic spectrometry techniques. The bibliography provides a list of some texts on AAS. Journals such as *Analytical Chemistry*, *Applied Spectroscopy*, *Journal of Analytical Atomic Spectroscopy*, *The Analyst*, *Spectroscopy Letters*, *Spectrochim*. *Acta Part B* and others are sources of peer-reviewed articles, but many applications articles can be found in specialized journals on environmental chemistry, food analysis, geology, and so on. The applications discussion here is necessarily limited, but the available literature is vast.

AAS is used for the determination of all metal and metalloid elements. Nonmetals cannot be determined directly because their most sensitive resonance lines are located in the vacuum UV region of the spectrum. Neither flame nor furnace commercial atomizers can be operated in a vacuum. It is possible to determine some nonmetals indirectly by taking advantage of the insolubility of some compounds. For example, chloride ion can be precipitated as insoluble silver chloride by adding a known excess of silver ion in solution (as silver nitrate). The silver ion remaining in solution can be determined by AAS and the chloride ion concentration calculated from the change in the silver ion concentration. Similar indirect approaches for other nonmetals or even polyatomic ions like sulfate can be devised.

6.5.1 QUALITATIVE ANALYSIS

The radiation source used in AAS is an HCL or an EDL, and a different lamp is needed for each element to be determined (except for the new continuum source system discussed above). Because it is essentially a single-element technique, AAS is not well suited for qualitative analysis of unknowns. To look for more than one element requires a significant amount of sample and is a time-consuming process. For a sample of unknown composition, multielement techniques such as XRF, ICP-MS, inductively coupled plasma-optical emission spectrometry, and other atomic emission techniques are much more useful and efficient.

6.5.2 QUANTITATIVE ANALYSIS

Quantitative measurement is one of the ultimate objectives of analytical chemistry. AAS is an excellent quantitative method. It is deceptively easy to use, particularly when flame atomizers are utilized.

6.5.2.1 QUANTITATIVE ANALYTICAL RANGE

The relationship between absorbance and concentration of the analyte being determined in AAS follows Beer's Law over some concentration range. There is an optimum linear analytical range for each element at each of its absorption lines. The minimum of the range is a function of the detection limit of the element under the operating conditions used. The ultimate limiting factor controlling the detection limit is the noise level of the instrument being used. The LOD in AAS is defined by the IUPAC and by many regulatory agencies as the concentration giving a signal equal to three times the standard deviation of a blank solution measured under the same operating conditions being used for the analysis. (Review the discussion of LOD and LOQ in Chapter 1.) The maximum of the analytical range is determined by the element and wavelength used. The linear working range for AAS is small for most systems; generally, only one to two orders of magnitude at a given wavelength. The calibration curve deviates from linearity, exhibiting a flattening of the slope at high absorbance values. With a flat slope, changes in concentration of the sample produce virtually no changes in absorption. Hence, it is impossible to measure concentrations accurately at extremely high absorbance values. Many calibration curves deviate from linearity below A = 0.8, and Zeeman background correction shortens the analytical working range even more. Modern AAS instruments have computerized data collection and data processing systems. These systems have the ability to fit different types of calibration curves to the data using a variety of equations, including linear, quadratic, and higher-order polynomial functions. Such systems are capable of calculating concentration results from nonlinear calibration curves. The accuracy of such calculated results depends on the equations used for calibration and on the number and concentrations of the standards used to provide the calibration data. It is not advisable to use a nonlinear calibration curve without verification that the results are accurate. When in doubt, dilute the samples into the linear region, especially if using Zeeman background correction.

When a concentration range is quoted for an analytical method, it is important to know how the lower and upper limits were determined. Approximate upper limits for the linear range of elements determined by FAAS are listed in Appendix 6.A on the textbook website. Detection limits for elements by FAAS, GFAAS, cold vapor Hg and hydride generation AAS, and other atomic spectroscopic techniques discussed in later chapters are given in Appendix 6.B on the textbook website. For AAS, it had been customary to report *method sensitivity*, where sensitivity was defined as the concentration of analyte that gives an absorbance of 0.0044 (equal to 1 % absorption), so this term may be encountered in the literature. Sample sensitivities for FAAS and GFAAS are tabulated in Appendix 6.B. Both the LOD and the sensitivity are highly dependent on the sample matrix, operating conditions, the particular instrument used, and the way in which the data is processed.

6.5.2.2 CALIBRATION

Calibration of AAS methods can be performed by the use of an external calibration curve or by MSA; both calibration methods were presented in Chapter 1. Internal standards are not used in AAS because it is usually a single-element technique; we cannot measure an internal standard element at the same time we measure the analyte.

External calibration curves are prepared from solutions of known concentrations of the sample element. High-purity metals dissolved in high-purity acids are used to make the stock standard solution. For AAS, stock standard concentrations are either 1000 or 10,000 ppm as the element. Working standards are diluted from the stock standard. For example, if we wanted to make a calibration curve for copper determination in the range of 2-20 ppm, we




FIGURE 6.29 AAS calibration curve for the copper 324.8 nm line showing linear and nonlinear regions of the curve.

would make a stock standard solution of 1000 ppm Cu by dissolving Cu metal in nitric acid. Then, we would dilute this solution to make a series of working standards. The concentrations of the working standards must cover the complete range of 0-20 ppm. A calibration blank (the 0.0 ppm standard) is of course required to correct for any analyte present in the water or reagents used to prepare the standard solutions. In this example, the calibration blank would be prepared from deionized water and the same high purity nitric acid used to make the standard solutions. Three to five working standards are typical, so we might make Cu solutions of 0, 2, 5, 10, 15, and 20 ppm. These standard solutions would then be aspirated into the flame and the absorbance of each standard would be measured. The absorbance would be plotted vs. concentration. A calibration curve like that in Figure 6.29 results. It should be noted that the relationship between absorbance and concentration is linear over the range of 0-10 ppm Cu, but at higher concentrations the relationship deviates from linearity.

When a quantitative analysis is to be performed, the sample is atomized and the absorbance measured under exactly the same conditions as those used when the calibration standards were measured. The calibration standards are usually measured first, and the sample solutions should be measured immediately following calibration. If the sample has been prepared using reagents such as acids, it is necessary to prepare a method blank that is carried through the same sample preparation steps as the sample. The method blank is used to correct for any contamination that may have occurred during sample preparation. The absorbance of the method blank is subtracted from the sample absorbance to give the corrected or net sample absorbance. The concentration of the unknown copper solution is determined from the calibration curve. For example, suppose that the corrected absorbance reading of the sample solution was 0.58. Using the calibration curve shown in Figure 6.29, it can be deduced that the concentration of the solution is 8.7 ppm.

Stock standard solutions of single elements at 1000 and 10,000 ppm can be purchased from a number of companies. Purchasing the stock solutions saves a great deal of time and effort, and is often more accurate and less expensive than making these solutions "in-house". The US NIST also sells Standard Reference Material (SRM) solutions of many elements, certified for their concentration (https://www.nist.gov/srm). NIST SRM solutions are expensive, but are often used as verification standards to confirm that the analyst has made the working standard solutions correctly as part of a method quality control process. Stock standards of most elements have a shelf life of at least one year; commercial solutions will have the expiration date marked on the bottle. Working standards should be prepared fresh daily or as often as needed as determined by a stability test. Low concentrations of metal ions in solution are not stable for long periods of time; they tend to adsorb onto the walls of the container. In addition, evaporation of the solvent over time will change the concentration of the solution, making it no longer a "standard".

It is most important in preparing external calibration curves that the solution matrix for samples and standards be as similar as possible. To obtain reliable quantitative data, the following should be the same for the samples and standards:

- 1. The same solvent (e.g., water, 5 % nitric acid, alcohol, MEK); same matrix modifier if used.
- 2. The same predominant anion (e.g., sulfate, chloride) at the same concentration.
- 3. The same type of flame (air–acetylene or nitrous oxide–acetylene) or the same graphite tube/platform.
- 4. Stable pressure in the flame gases during the analysis.
- 5. Absorbance measured at the same position in the flame/furnace.
- 6. Background correction carried out on each sample, blank, and standard using the same correction technique.

Sample solutions should be measured immediately following calibration. If the instrument is shut down for any reason (the gas tank runs out, the power fails in a thunderstorm, the lamp burns out, the nebulizer clogs up and needs to be cleaned, the graphite tube cracks, etc.), the calibration must be repeated when the instrument is turned back on to be sure that items 3-6 are exactly the same for samples and standards. For GFAAS, the platform and tube must be the same for the calibration curve and the samples. If a tube cracks during a run, a new tube and platform are inserted, conditioned per the manufacturer's directions and the calibration standards rerun before samples are analyzed. For extremely complex sample matrices, it may not be possible to make external standards with a similar matrix. In this case, the MSA should be used for quantitative analysis.

The signal in FAAS is a continuous, steady state signal; as long as sample is aspirated into the flame, the absorbance stays at a constant value. Measurement of the absorbance in FAAS is fairly simple. In GFAAS, the signal is transient and the shape and height of the peak depend on the rate of atom formation. That rate can be affected by interferences from the sample matrix. The *integrated peak area* is independent of the rate of atom formation. For quantitative analysis by GFAAS, the concentration should be plotted against the peak area, not the peak height, for the most accurate results. Modern instruments are equipped with integrators to measure absorbance over the atomization period.

The accuracy can be excellent for both FAAS and GFAAS. The precision of FAAS is usually less than 1 %RSD. The precision of GFAAS can be in the 1-2 %RSD range, but is often 5-10 % for complex matrices.

6.5.3 ANALYSIS OF SAMPLES

6.5.3.1 LIQUID SAMPLES

Liquid solutions are the preferred form for sample introduction into flame and furnace atomizers.

Frequently liquid samples can be analyzed directly or with minimal sample preparation, such as filtration to remove solid particles. Typical samples that have been analyzed directly include urine, electroplating solutions, petroleum products, wine, fruit juice and, of course, water and wastewater. If the samples are too concentrated, they must be diluted prior to analysis. If they are too dilute, the solvent may be evaporated or the analyte concentrated by solvent extraction or other methods.

Milk may be analyzed for trace metals by FAAS by adding trichloroacetic acid to precipitate the milk proteins. The precipitate is removed by filtration or centrifugation. The standards should also contain trichloroacetic acid to match the samples. Trace metals can be determined in seawater, urine, and other high salt liquid matrices by complexing the metals with a chelating agent and extracting the metal complexes into organic solvent. For example, ammonium pyrrolidine dithiocarbamate (APDC) will complex Cu, Fe, Pb, and other metals. Complexation allows the metals to be extracted into methyl isobutyl ketone (MIBK). The standards are

made in MIBK and aspirated directly into the flame. This permits not just extraction, but preconcentration; for example, 1 L of seawater can be extracted into 50 mL of MIBK, resulting in a 20-fold concentration factor. Seawater can be analyzed for the major cations by preparing an artificial seawater solution for making calibration standards in a matrix similar to the samples. Artificial seawater contains calcium carbonate, magnesium oxide, potassium carbonate, and sodium chloride at levels that reflect the cation and anion levels found in real seawater. Oils may be diluted with a suitable organic solvent such as xylene and the soluble metals determined directly. Organometallic standards soluble in organic solvent are commercially available for preparing calibration curves for these types of analyses.

There are liquid sample matrices, such as blood, serum, very viscous oils, and the like that require sample preparation by acid digestion or ashing prior to FAAS determination. In many cases, these matrices can be analyzed without digestion or prior ashing by GFAAS.

6.5.3.2 SOLID SAMPLES

Solid samples are usually analyzed by dissolving the sample to form a liquid solution that can be introduced into the flame or furnace. Dissolution can be accomplished by mineral acid digestion ("wet ashing"), fusion of solids with molten salts and dissolution of the fusion bead, dry ashing of organic solids with acid dissolution of the residue, combustion in oxygen bombs, and other procedures (Chapter 1). Dissolution is time consuming, even with fast microwave digestion and ashing systems, automated fusion fluxers, and other automated sample preparation devices now available. In many cases, solid samples have to be ground into smaller particles before digestion (Chapter 1). Grinding generates heat and volatile elements may be lost; cooling the grinder with liquid nitrogen or dry ice is often used to prevent loss of volatiles. Dissolution entails the possibility of introducing impurities or losing analyte, causing error. This is particularly problematic at ppb and lower levels of analyte. However, hundreds of types of solid samples are dissolved for AAS analysis on a daily basis; it is still the most common approach to AAS analysis of solids. Types of samples that have been analyzed after dissolution include metals, alloys, soils, animal tissue, plant material, foods of all types, fertilizer, ores, cements, polymers, cosmetics, pharmaceuticals, coal, ash, paint chips, and many solid industrial chemicals. Solid particulates in air, gas, and fluid streams can be collected by filtration and analyzed by digesting the filter and the collected particulates.

For example, grains, plant tissues, and many other organic materials can be digested on a hot plate in a mixture of nitric and other mineral acids to destroy the organic matrix. The cooled, clear solution is diluted to volume and analyzed against aqueous acidic calibration standards. Dry ashing of food, plant, and biological tissue is performed by placing 10-50 g of the sample in a suitable crucible and heating in a muffle furnace for several hours to burn off the organic material. The ash is dissolved in mineral acid (nitric, HCl, or acid mixtures) and diluted to volume with deionized water. An aqueous acidic calibration curve would be used. Inorganic materials, ceramics, and geological materials often require fusion in molten salts at high temperatures to convert them to soluble forms. For example, bauxite, an aluminum ore, can be fused in a Pt crucible with a mixture of sodium carbonate and sodium borate. The mixture is heated over a Bunsen burner to form a clear melt. The fusion salts convert the aluminum, silicon, and titanium compounds in bauxite to salts that will dissolve in aqueous HCl. The calibration standards must contain HCl, sodium chloride, and sodium borate at levels that match those in the diluted fused samples. It is critical that a blank be prepared in the same manner as samples are prepared, to correct for any traces of analytes that might be present in the acids, salts, and other reagents used and for contamination from "the environment". Dust in the air is often a major source of contamination of samples by "the environment", especially for analytes such as Al and Si.

The analysis of solids is time consuming and is prone to many sources of error. Analytical chemists have been trying for many years to analyze solid samples directly, without having to dissolve them. For some types of samples, this can be done by AAS. Solids can be analyzed using *glow discharge atomizers*, by inserting small pieces or particles of sample directly into the flame or furnace, or by the use of *laser ablation* (Section 7.3.1.7).





FIGURE 6.30 The SS600° solids autosampler for direct solids analysis by graphite furnace AAS. (©2020 Analytik Jena, [www.analytik-jena.de]. Used with permission.)

A unique direct solid analysis approach for graphite furnace AAS, solid AA*, is the combination of the SSA 600 autosampler from Analytik Jena AG with their ContrAA* systems (Figure 6.30). The SSA 600 is a fully automated solid sampler that will analyze up to 84 samples. All that is required is to place the solid samples onto the sample carriers. The autosampler weighs the sample using an integrated microbalance with a precision of 1 μ g, transports it to the graphite furnace and returns the reusable carrier back to the sample tray. Sample sizes are on the order of 100 μ g-10 mg. Samples can be in the form of powders, granulates, fibers, and paste-like materials such as creams, sludge, and viscous oils.

Some of these approaches are also used in atomic emission spectrometry and in ICP-MS and are discussed in greater detail in Chapters 7 and 9, and in the references by Sneddon, Robinson, and Skelly Frame and Keliher listed in the bibliography.

One approach to the direct analysis of solids is to form a *slurry* of the sample in a suitable solvent and introduce the slurry directly into a graphite furnace atomizer. A slurry is a suspension of fine solid particles in a liquid. Slurry preparation requires that the sample either is in the form of a fine powder or can be ground to a fine powder without contamination from the grinding process. This can be done successfully for many types of samples, such as foods, grains, pharmaceuticals, and sediments. A key development in achieving reproducible results from slurry samples introduced into graphite furnace atomizers was to keep the slurry "stirred" with an ultrasonic agitator during sampling, as discussed in the reference by Miller-Ihli listed in the bibliography.

A commercial glow discharge source, the AtomSource (Teledyne Leeman Labs, Inc., Hudson, NH, www.teledyneleemanlabs.com) is available for the analysis of solid metals and metal alloys. A glow discharge is more commonly used as an atomic *emission* source, but this source acts as a unique atomizer for conductive samples. The source is shown in Figure 6.31(a). The atomizer cell is a vacuum chamber with the light path along the axis. The conductive sample is positioned as shown and is bombarded with six streams of ionized argon gas. This process sputters the sample, releasing free atoms into the light path, as shown in Figure 6.30(b). The method does not rely on a high temperature for atomization, so refractory metals such as boron, tungsten, zirconium, niobium, and uranium can be atomized easily. In addition to ground state atoms, the source also produces excited atoms. The emission from the excited atoms can be used to measure elements not able to be measured by AAS. Carbon in steels can be determined by emission, for example, while the other steel






FIGURE 6.31 (a) The AtomSource glow discharge atomizer for conductive solid samples. (b) Schematic of the sputtered atom cloud produced by bombardment of the sample surface by ionized argon. (Courtesy of Teledyne Leeman Labs, Inc., Hudson, NH (www.teledyneleemanlabs.com].)

components are determined by absorption. The AtomSource atomizer is shown incorporated into the entire spectrometer system in Figure 6.32.

6.5.3.3 GAS SAMPLES

There are some metal-containing compounds that are gaseous at room temperature and in principle the gas sample can be introduced directly into a flame atomizer. More commonly, the gas is bubbled through an appropriate absorbing solution and the solution is analyzed in the usual manner.




FIGURE 6.32 The AtomSource glow discharge atomizer incorporated into an analyzer for solid metals and metal alloys (the pulsar system). (Courtesy of Teledyne Leeman Labs, Inc., Hudson, NH (www.teledyneleemanlabs.com].)

The introduction of a gas phase sample into an atomizer has significant advantages over the introduction of solids or solutions. The transport efficiency may be close to 100 %, compared to the 5-15 % efficiency of a solution nebulizer. In addition, the gas phase sample is homogeneous, unlike many solids. There are two commercial analysis systems with unique atomizers that introduce gas phase sample into the atomizer. They are the cold vapor technique for mercury and the hydride generation technique. Both are used extensively in environmental and clinical chemistry laboratories.

6.5.3.4 COLD VAPOR MERCURY TECHNIQUE

Mercury is unusual in that it exists as gas phase free atoms at room temperature. Elemental mercury is a liquid at room temperature, but a liquid with a very high vapor pressure. So, it is not necessary to apply heat from a flame or furnace to measure mercury vapor by AAS.

The cold vapor (CV or CVAAS) technique requires the *chemical reduction* of mercury in a sample solution to elemental Hg. This is usually done with a strong reducing agent such as sodium borohydride or stannous chloride in a closed reaction system external to the AA spectrometer. The Hg atoms are then purged out of solution (sparged) by bubbling an inert gas through the solution or pumping the post-reduction solution through a gas/liquid separator. The gas stream containing the free Hg atoms is passed into an unheated quartz tube cell sitting in the AAS light path. The cell is usually clamped into the position normally occupied by the burner head. Mercury atoms will absorb the HCL or EDL Hg wavelength and the measurement is made. The cell is sometimes heated to prevent water condensation in the cell, but no heat is required to atomize the Hg. The mercury atomization process is a chemical reduction reaction. CVAAS can be performed manually or can be automated. Because Hg determinations are required in many environmental samples including drinking water, instrument companies have built small AAS cold vapor systems just for Hg measurements. Figure 6.33 shows a schematic of an automated dedicated mercury analyzer that uses a gas-liquid separator, a mercury lamp, a long optical path quartz cell, and a solid-sate detector. Samples are pumped from the autosampler tray and mixed automatically with the stannous chloride reductant. Stannous chloride will reduce mercuric ion, Hg²⁺, to Hg⁰, but will not reduce organomercury compounds or mercurous ion. Samples are normally predigested with a strong oxidizing agent to ensure that all Hg in the sample is in the form of mercuric ion before adding the stannous chloride.




FIGURE 6.33 Automated cold vapor mercury analyzer. Mercury in the sample is reduced to Hg. The Hg vapor is separated from the solution by a gas-liquid separator and carried to the optical cell. The Hg vapor absorbs the 253.7 nm emission line from the Hg lamp and the amount of atomic absorption is measured using a solid-state detector. (Courtesy of Teledyne Leeman Labs, Inc., Hudson, NH [www.teledyneleemanlabs.com].)

The sensitivity of the CVAAS technique for Hg is about 0.02 ppb, much better than that obtained from FAAS or GFAAS. The reasons are simple; the sampling is 100 % efficient and a large sample volume is used. All of the reduced Hg atoms are sent into the light path of the spectrometer, unlike the 5 % or so efficiency of a flame nebulizer system. Unlike GFAAS, the cold vapor technique uses large sample volumes (10-100 mL of sample) compared with the microliter sample volume put in to a graphite furnace. Incorporating a gold amalgamation accessory can increase the sensitivity of the CVAAS technique even further. The mercury vapor can be trapped and concentrated in the gold as an amalgam at room temperature, and then released into the optical path as a concentrated "plug" of vapor by rapidly heating the gold.

CVAAS systems are available as flow injection accessories for AAS systems or dedicated flow injection mercury systems, with or without amalgamation capability. Flow injection is described in Section 6.5.3.6. The detection limit (DL) for mercury varies with the system, but can be < 0.005 ppb without amalgamation and < 0.0002 ppb with amalgamation. Dedicated Hg analyzers for the analysis of solid samples are also available, for measuring total Hg in hair, biological tissues, coal, whole blood, food, soil and the like, using sample pyrolysis. Samples are usually weighed into quartz sample boats and placed into a solid sample autosampler. The DMA-80 from Milestone, Inc. (www.milestonesci.com) has a 40 position autosampler, the ability to store specific sample methods and unattended operation. Mercury results can be obtained in about six minutes with no sample preparation. This can result in faster, cheaper analyses with less hazardous waste to dispose of.

6.5.3.5 HYDRIDE GENERATION TECHNIQUE

The hydride generation (HGAAS) technique is similar in many ways to CVAAS. The atomizer is a quartz tube cell sitting in the light path of the AA spectrometer. In the hydride generation technique, the cell must be heated. Having the cell clamped above the burner head and lighting an air-acetylene flame accomplishes this. The flame surrounds the cell and heats it. Alternatively, some systems have electrically heated cells.

Sample solutions are reacted with sodium borohydride in a closed reaction system external to the AA spectrometer, as in CVAAS. Some elements will react with the sodium borohydride to form volatile hydride compounds. Arsenic, for example, forms arsine gas, AsH₃(g). The volatile hydrides are sparged from solution by an inert gas and sent to the heated quartz cell. Arsine is a molecule, not an atom, so to measure atomic absorption by arsenic, the hydride species must be decomposed (by breaking bonds) and reduced to free atoms. That is done in the heated quartz cell, and the absorption signal measured as usual. The elements that form volatile hydrides include As, Bi, Ge, Pb, Sb, Se, Sn, and Te. The HGAAS technique can also be operated in manual mode or automated through the use of flow injection techniques. The sensitivity for As, Se, and other elements is excellent because of the efficient transport of the hydride to the atomizer and the larger sample volumes used. Detection limits for CVAAS and HGAAS are given in Appendix 6.B. Similar analyzers based on atomic fluorescence will be discussed in Chapter 7.

6.5.3.6 FLOW INJECTION ANALYSIS

The term **flow injection analysis** (FIA) describes an automated continuous analytical method in which an aliquot of sample is injected into a continuously flowing carrier stream. The carrier stream usually contains one or more reagents that react with the sample. A transient signal is monitored as the analyte or its reaction product flows past a detector. We have just described CVAAS, where a reduction reaction occurs and the analyte must be swept in a carrier stream into the optical path. This results in a transient signal. All of the components for a FIA are present—sample, reagent, carrier stream, and transient signal measurement. The same is true of HGAAS. The implementation of FIA for CVAAS and HGAAS permits these determinations to be carried out completely automatically, from sample uptake to printout of concentrations measured.

An FIA system consists of four basic parts: a pump or pumps for regulation of flow, an injection valve to insert sample volumes accurately and reproducibly into the carrier stream,

a manifold, and a flow-through detector. A manifold is the term used for the tubing, fittings, mixing coils, and other apparatus used to carry out the desired reactions. The flow-through detector in AAS is the atomizer/detector combination in the spectrometer.

FIA techniques for AAS are described in detail in the reference by Tyson. In addition to automated CVAAS and HGAAS, FIA has been used to automate online dilution for the preparation of calibration curves, online matrix matching of solutions, online preconcentration and extraction for GFAAS, automated digestion of samples, and much more. Commercial FIA systems are available for most AAS instruments.

6.5.3.7 FLAME MICROSAMPLING

Most flame AAS determinations are performed using a continuous flow of solution taken up by the types of nebulizers described in Section 6.2.2.1. Uptake rates in these types of nebulizers can be as high as 5 mL/min, so a significant amount of sample solution is needed for a measurement.

The Shimadzu Scientific Instruments AAS has a flame micro-sampling option that uses a sampling port which allows 50-100 μ L of sample solution to be injected into the flame for a measurement. This micro-sampling option can be used when sample is in limited supply. In addition, it minimizes salt build-up on the burner and minimizes waste. The use of such small volumes permits "autodilution" of the sample, simply by injecting less volume into the flame. More details are available at www.shimadzu.com.

SUGGESTED EXPERIMENTS

For the following experiments, prepare at least 25 mL-100 mL of each solution in acid-cleaned volumetric flasks. If the solutions must be stored before analysis, be certain the solutions are acidified and that an acid blank is prepared, stored, and analyzed with the samples.

- 6.1 Prepare solutions of zinc chloride in deionized water containing 1 % (v/v) HNO₃. The solutions should contain known concentrations of zinc over the range of 0.5-50.0 ppm, and an acid blank of 1 % (v/v) nitric acid containing no added zinc should be prepared. Aspirate each solution in turn into the burner. Measure the absorbance of the solutions at 213.9 nm, the zinc resonance line. Plot the relationship between the absorbance and the zinc concentrations. Note the deviation from Beer's Law. Indicate the useful analytical range of the calibration curve. If your instrument permits it, try different curve-fitting algorithms and evaluate how they affect the working range of the analysis.
- a. Look up the wavelength, preferred flame conditions, and linear range for calcium in Appendix 6.1 or your instrument "cookbook" and set up the AAS to measure Ca. Prepare 1 L of a stock standard solution of 1000 ppm calcium using calcium phosphate. Prepare 1 L of a 10,000 ppm La standard using lanthanum chloride. Make two sets of calcium working standards. The two sets should have the same concentrations of Ca, but to one set of standards (including the blank) add enough of the La stock solution to make each of these solutions 2000 ppm in La. The La must be added before the Ca standards are made to volume. For example: to make a 10 ppm Ca standard, take 1 mL of the 1000 ppm Ca stock and dilute it to 100 mL in a volumetric flask. To make the 10 ppm Ca standard with added La, take 1 mL of the Ca stock solution and add it to an empty 100 mL volumetric flask. Add 20 mL of the stock La solution to the same flask, and then add deionized water to bring the solution to volume. Optimize the burner position for maximum absorbance. Run both sets of solutions and plot absorbance vs. concentration of Ca. Explain your observations.
 - b. Using one of the Ca working standards with La and the same concentration solution without La, aspirate each solution in turn while moving the burner position. Start with the HCL beam just above the burner head (at the base of the flame) and then lower the burner in increments, making note of the absorbance. Construct a flame profile for Ca with and without La by plotting absorbance vs. height above

- the burner. Are the two profiles different? Give a reasonable explanation for the observed flame profiles, based on your reading of the chapter.
- c. You can use the 1-10 ppm Ca working standards with La to determine the amount of Ca in commercial multivitamin tablets. Grind 1-2 coated multivitamin tablets into a fine powder using a mortar and pestle. For tablets containing about 200 mg Ca, accurately weigh out approximately 200 mg of the powder into a beaker and add 20 mL of concentrated HCl (analytical or trace metal grade). Stir well. Quantitatively transfer to a 100 mL volumetric flask which should already contain some deionized water and dilute to the mark with deionized water (Solution A). Pour this solution through coarse filter paper into a beaker. Dilute 10.0 mL of the filtrate to 100 mL with deionized water (Solution B). Test Solution: Put 10.0 mL of Solution B and 20.0 mL of La solution into a 100 mL volumetric flask and dilute to the mark with deionized water. Using your instrument cookbook parameters (usually 422.7 nm, air-acetylene flame), run the calibration standards and the test solution. Using the instrument software, determine the amount of Ca in the test solution. The % calcium in the multivitamin is calculated taking into account the two dilutions:

%Ca in tablet =
$$\left[\frac{(10)(10)(X \text{ mg Ca/L})(0.1000 \text{ L})}{\text{mg of tablet powder}}\right] \times 10^{2}$$

For tablets containing more than 200 mg Ca per tablet, use a higher dilution factor.

Why should there be some deionized water in the volumetric flask before you transfer the HCl solution?

Is there undissolved material in the first volumetric flask? If so, the analysis would be described as determining "leachable" calcium.

How does your measured %Ca compare to the amount of Ca listed on the label of the vitamin? If your measured amount is less than expected, explain why. If your measured amount matches what is on the label, why?

- 6.3 Prepare a series of standard solutions containing sodium at concentrations of 1, 3, 5, 7, 9, and 10 ppm. Measure the absorbance of each solution and plot the absorbance against the sodium concentration. Take water samples from various sources, such as tap water, bottled drinking water, distilled water, river water, distilled water stored in a polyethylene bottle, and distilled water stored in a glass bottle. Determine the sodium concentration in each sample. (If you choose any carbonated bottled waters as samples, allow the sample to "go flat" or loosen the cap and shake it slightly to release the dissolved gases to avoid poor precision in your measurements. If you want to make the comparison, analyze a carbonated water sample that is not flat. The reproducibility of the absorbance measurements should be better in the "flat" sample.) All samples should be at room temperature when measured.
- 6.4 Prepare a solution containing 20 ppm of Pb as Pb $(NO_3)_2$. Prepare similar solutions containing 20 ppm of Pb as (a) PbCl₂, (b) lead oxalate, and (c) lead acetate. Measure the absorbance by the solutions of the Pb resonance line at 283.3 nm. Note the change in absorbance as the compound changes. This is chemical interference. Find a literature method for the elimination of chemical interference using excess EDTA. Following the literature method, see if the use of EDTA does eliminate the chemical interference you observed.
- 6.5 Prepare an aqueous 1 % HNO₃ solution containing 5 ppm of NaCl; also prepare five separate aqueous 1 % HNO₃ solutions (100 mL each) containing 500 ppm of (a) Ca, (b) Mg, (c) Fe, (d) Mn, and (e) K. Take an aliquot of each of these solutions (10-25 mL, but use the same volume for all of the solutions). Spike each aliquot with 5 ppm Na. Be sure to prepare an acid blank and use the same acid for all solution preparation. Measure the absorbance at the Na resonance line at 589.0 nm by all solutions. Compare the absorbance of the Na spiked solutions (a) through (e) with the aqueous acidic Na

- solution (i.e., compare all the 5 ppm Na solutions in all matrices). Are any of the signals enhanced compared to the aqueous acidic solution? Which ones? Explain. Are any suppressed? Again, explain. For the solutions (a), (b), (c), (d), and (e) with and without Na, plot two-point standard addition calibration curves, and calculate the amount of Na present in the unspiked solutions. Any sodium present was caused by a Na impurity in the original (500 ppm) solutions. Look at the slopes of all five plots. Are they the same? If not, why not?
- For laboratories with a graphite furnace atomizer, the following experiments can be run. The instrument should be setup for the element according to the instrument "cookbook". (a) Dilute the lead solutions from Exp. 6.4 to give 10 ppb lead solutions (or some other concentration within the linear range of your furnace). Using the "cookbook" furnace program and background correction but no matrix modifiers, run triplicate injections of each solution (20 µL is a usual injection volume) and observe the peak shape, appearance time of the peak maximum, the peak height and area. Do the peak maxima appear at the same time? Do all peaks have the same shape? If not, why not? Repeat using a lower pyrolysis temperature. If the background absorbance is printed out, compare the background absorbance values at both sets of conditions. How is the background affected by pyrolysis temperature? Does it depend on the compound? (b) Using background correction and the matrix modifiers and furnace program recommended by the "cookbook" for Pb, rerun the 10 ppb solutions of lead compounds. Compare the peak appearance time, shape and so on with and without matrix modification. Comment on the approach you would use to obtain accurate results, based on your observations. (c) If your system has the ability to run atomization from the tube wall and from a L'voy platform, run the lead nitrate solution both ways (wall and platform). Perform 20 replicate injections at each condition and compare the precision of wall vs. platform measurements. Explain your results.

PROBLEMS

- 6.1 Why are atomic absorption lines very narrow?
- 6.2 Why must HCLs or EDLs be used as the radiation source for most AAS instruments? Illustrate schematically an HCL for lead (Pb). How would you make the cathode?
- 6.3 Why is "modulation" of the line source necessary for accurate results? How is modulation achieved?
- 6.4 If the radiation source is not modulated, will emission from the analyte in the atomizer result in a positive or negative error? Show your calculation to support your answer
- 6.5 Why is atomic absorption not generally used for qualitative analysis?
- 6.6 What causes chemical interference in AAS? Give three examples.
- 6.7 How are solid samples analyzed by AAS?
- 6.8 Several standard solutions of copper were prepared. These were aspirated into a flame and the absorption measured with the following results. Prepare a calibration curve from the data.

Sample Concentration (ppm)	Absorbance
Blank (0.0)	0.002
0.5	0.045
1.0	0.090
1.5	0.135
2.0	0.180
2.5	0.225
3.0	0.270

6.9 Samples of polymer were brought to the lab for a determination of their copper content. They were ashed, the residue was dissolved in mineral acid and diluted to a known volume. The absorbance of each solution and a digestion blank was measured.

Using the calibration curve from Problem 6.8, calculate the copper concentration in each solution and the blank and fill in the table below.

Sample	Absorbance	Concentration (ppm)
Blank	0.006	
Α	0.080	
В	0.105	
C	0.220	
D	0.250	

Exactly 2.00 g of each sample were digested and the final solution volume for each sample and the blank was 100.0 mL. Calculate the concentration of copper in the original polymer for each sample.

- 6.10 What is shown in a Grotrian diagram?
- 6.11 Why can nonmetal elements not be determined directly by AAS?
- 6.12 What is the relationship between the amount of light absorbed and the oscillator strength of the transition involved?
- 6.13 How can the population distribution of atoms in various energy levels be calculated?
- 6.14 What is the basis for concluding that at temperatures up to 3000 K the great majority of an atom population is in the ground state?
- 6.15 Describe the two major light sources used in AAS—the HCL and the EDL.
- 6.16 Why are EDLs used? List the elements that benefit from use of an EDL instead of an HCL.
- 6.17 What is meant by a flame profile?
- 6.18 Describe the atomization process that takes place in a flame.
- 6.19 How does the rapid formation of a stable oxide of the analyte affect its flame profile?
- 6.20 Define chemical interference. Give an example of how this interference is corrected.
- 6.21 What is the source of background absorption?
- 6.22 How is the background corrected?
- 6.23 Describe the operation of a Zeeman background corrector. Discuss its advantages and disadvantages compared with use of a deuterium lamp for background correction.
- 6.24 Describe the operation of a deuterium (D_2) lamp background corrector.
- 6.25 Draw a schematic of a typical graphite furnace atomization tube.
- 6.26 Describe the L'vov platform.
- 6.27 What is the advantage of the L'vov platform?
- 6.28 What are the advantages of graphite furnace atomizers over flames?
- 6.29 What are the disadvantages of graphite furnace atomizers vs. flames?
- 6.30 Define ionization interference and give an example. How is this interference corrected?
- 6.31 You need to determine potassium in serum samples by FAAS. What will you add to correct for ionization interference in the determination?
- 6.32 Distinguish between spectral and non-spectral interference in AAS.
- 6.33 The indirect determination of chloride ion by precipitation as silver chloride was described. What metal element could you use to determine sulfate ion in water indirectly by AAS? Describe how you would do this experiment and give an example calculation for a sulfate solution containing 200 mg SO_4^{2-}/L . (You may need to consult some external references on this question.)
- 6.34 Briefly explain the advantages of the newly developed high resolution continuum source AAS compared to line source instruments.

BIBLIOGRAPHY

Analytical Methods for Atomic Absorption Spectrometry; PerkinElmer, Inc.: Shelton, CT, 1994.
 Beaty, R.D.; Kerber, J.D. Concepts, Instrumentation and Techniques in Atomic Absorption Spectrophotometry; PerkinElmer, Inc.: Shelton, CT, 1993.

Bashkin, S.; Stoner, J.O. *Atomic Energy Levels and Grotrian Diagrams*; North Holland/American Elsevier: New York, 1975.

Bruno, T.J.; Svoronos, P.D.N. *CRC Handbook of Basic Tables for Chemical Analysis – Data Driven Methods and Interpretation*; CRC Press: Boca Raton, FL, 2021.

Burguera, J.L., Ed. Flow Injection Atomic Spectroscopy; Marcel Dekker, Inc.: New York, 1989.

Carnrick, G.R.; Slavin, W. Appl. Spectrosc 1983, 37 (1), 1.

Dean, J.A. Analytical Chemistry Handbook; McGraw-Hill, Inc.: New York, 1995.

Dean, J.A.; Rains, T.C., Eds. Flame Emission and Atomic Absorption Spectrometry; Marcel Dekker, Inc.: New York, 1969; Vol. 1 (1971; Vol. 2; 1975; Vol. 3).

Huang, M.D.; Becker-Ross, H.; Florek, S.; Heitmann, U. 2005, Spectrochim. Acta Part B.

Ingle, J.D. Jr.; Crouch, S.R. Spectrochemical Analysis; Prentice Hall: Englewood Cliffs, NJ, 1988.

Jackson, K.W., Ed. *Electrothermal Atomization for Analytical Atomic Spectrometry*; John Wiley and Sons, Inc.: New York, 1999.

Kirkbright, G.F.; Sargent, M. Atomic Absorption and Fluorescence Spectroscopy; Academic Press: New York, 1974.

Lajunen, L.H.J. Spectrochemical Analysis by Atomic Absorption and Emission; Royal Society of Chemistry: Cambridge, UK, 1992.

L'vov, B.V. Atomic Absorption Spectrochemical Analysis; Elsevier: New York, 1970.

Miller-Ihli, N. J. Anal. Atomic. Spectrosc. 1988, 3, 73.

Parsons, M.L. Atomic absorption and flame emission. In *Analytical Instrumentation Handbook*, 2nd; Ewing, G.A., Ed.; Marcel Dekker, Inc: New York, 1997.

Rann, C.S.; Hambly, A.N. Anal. Chem. 1965, 37, 879.

Robinson, J.W., Ed. Handbook of Spectroscopy; CRC Press: Boca Raton, FL, 1975; Vol. 1.

Robinson, J.W., Ed. Atomic Spectroscopy; Marcel Dekker, Inc.: New York, 1990.

Rumble, J., Ed. Handbook of Chemistry and Physics; 102 edition; CRC Press: Boca Raton, FL, 2021.

Schlemmer, G.; Radziuk, B. *A Laboratory Guide to Graphite Furnace Atomic Absorption Spectroscopy*; Birkhauser Verlag: Basel, 1999.

Skelly Frame, E.M.; Keliher, P.N. Atomic spectrometry. In *Materials Science and Technology*; Cahn, R.W.; Haasen, P.; Kramer, E.J., Eds.; VCH Publishers, Inc. New York, 1992, Vol. 2A.

Slavin, W. Graphite Furnace Source Book; PerkinElmer, Inc.: Shelton, CT, 1984.

Smith, S.B. Jr.; Hieftje, G.M. Appl. Spectrosc. 1983, 37, 419.

Smith, S.B. Jr.; Hieftje, G.M. Science 1983, 220, 183.

Sneddon, J., Ed. Sample Introduction in Atomic Spectroscopy; Elsevier: Amsterdam, 1990.

Sneddon, J. Ed. Advances in Atomic Spectroscopy; JAI Press: Greenwich, CT, 1992, Vol. I (1994; Vol. II).

Tyson, J.F. Flow injection techniques for atomic spectrometry. In *Advances in Atomic Spectroscopy*; Sneddon, J., Ed.; JAI Press: Greenwich, CT, 1992, Vol. I.

Walsh, A. Spectrochim. Acta 1955, 7, 108.

Welz, B.; Heitmann, U. 50 Years After Alan Walsh-AAS Redefined. Technical Note, Analytik Jena, 2005 (www.analytik-jena.de).

Welz, B.; Becker-Ross, H.; Florek, S.; Heitmann, U. *High Resolution Continuum Source AAS*; Wiley-VCH: Weinheim, 2005.

Welz, B.; Sperling, M. Atomic Absorption Spectrometry, 3rd; John Wiley and Sons: New York, 2002.



Atomic Emission Spectroscopy

7

Atomic emission spectroscopy is the study of the radiation emitted by excited atoms and monatomic ions. Excited atoms and ions relax to the ground state, as discussed in Chapter 2 and shown schematically in Figure 7.1. Relaxation often results in the emission of light, producing line spectra in the visible and UV regions of the spectrum, including the vacuum UV region. These emitted atom and ion lines can be used for the qualitative identification of elements present in a sample and for the quantitative analysis of such elements at concentrations ranging from low parts per billion (ppb) to percent. Atomic emission spectroscopy has relied in the past on flames and electrical discharges as excitation sources, but these sources have been overtaken by plasma sources, such as the inductively coupled plasma (ICP) source and the microwave plasma (MP) source. Atomic emission spectroscopy is a multielement technique with the ability to determine metals, metalloids, and some nonmetal elements simultaneously. The major difference between the various types of atomic emission spectroscopy techniques lies in the source of excitation and the amount of energy imparted to the atoms or ions (i.e., the excitation efficiency of the source). For many years, the abbreviation AES was used for atomic emission spectroscopy; however, the same abbreviation is used for Auger electron spectrometry. To minimize confusion, the term optical emission spectroscopy (OES) is now usually used for atomic emission spectroscopy.

Flame sources impart relatively low quantities of energy to the atoms produced in the flame. Electrons are promoted to only a few low-energy excited states in flames; this results in simple emission spectra. In practice, flame emission spectroscopy is most useful for the easily excited alkali metals and alkaline earth metals. Electrical discharges such as arcs and sparks provide significantly more energy than flames. Most elements can be atomized and ionized in these discharges; the higher energy input causes electrons to populate many higher-energy levels. This results in spectra with many emission lines. Plasma sources, such as the ICP, MP, and the direct current plasma (DCP), are high-energy sources that permit the excitation of most elements, both metals and nonmetals, and result in very line-rich spectra. This is one of the major advantages of emission spectroscopy; many elements, as atoms and ions, emit multiple wavelengths simultaneously. The analyst has a choice of several wavelengths for each element and the ability to measure multiple elements concurrently. The disadvantage is that as the number of emission wavelengths increases, so does the *spectral interference* from overlapping lines. This mandates the use of high-resolution spectrometers, which are more expensive than the spectrometers needed for flame emission systems or for atomic absorption (Chapter 6). Atomic emission spectroscopy provides elemental analysis and can measure most metals, metalloids, and nonmetals in a wide variety of liquid, solid, and gaseous samples.

The related subject of atomic fluorescence spectrometry (AFS), the emission of photons by excited gas phase atoms following excitation by absorption of photons, is also covered in this chapter.

7.1 FLAME ATOMIC EMISSION SPECTROSCOPY

Flame atomic emission spectroscopy, also called flame photometry, is based on the measurement of the emission spectrum produced when a solution containing metals or some non-metals such as halides, sulfur, or phosphorus is introduced into a flame. In early experiments, the detector used was the analyst's eye. Those elements that emitted visible light could be




FIGURE 7.1 Schematic diagram of the excitation and emission process. The energies a and b represent atomic excitation, c represents ionization and d represents ionization and excitation. Four possible emission energies and their respective wavelengths are shown; e is ionic emission and f, g, and h are atomic emission. The emission wavelength and energy are related by $\Delta E = hc/\lambda$. (© 1999-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

identified qualitatively, and these "flame tests" were used to confirm the presence of certain elements in the sample, particularly alkali metals and alkaline-earth metals. A list of visible colors emitted by elements in a flame is given in Table 7.1.

The human eye is a useful detector for qualitative analysis but not for quantitative analysis. Replacing the human eye with a spectrometer and photon detector such as a PMT or CCD permits more accurate identification of the elements present because the exact wavelengths emitted by the sample can be determined. In addition, the use of a photon detector permits quantitative analysis of the sample. The wavelength of the radiation indicates what element is present, and the radiation intensity indicates how much of the element is present. Flame atomic emission spectrometry is particularly useful for the determination of the elements in the first two groups of the periodic table, including sodium, potassium, lithium, calcium, magnesium, strontium, and barium. The determination of these elements is often called for in medicine, agriculture, and animal science. Remember that the term *spectrometry* is used for quantitative analysis by the measurement of radiation intensity.

7.1.1 INSTRUMENTATION FOR FLAME OES

TABLE 7.1

Flame OES can be performed using most modern atomic absorption spectrometers (discussed in Chapter 6). No external lamp is needed since the flame serves as both the atomization

Flame Colors from Atomic Emission

	Flame Color Through	
Flame Color	Blue Glass ^a	Element
Carmine red	Purple	Lithium
Dull red	Olive green	Calcium
Crimson	Purple	Strontium
Golden yellow	(Absorbed)	Sodium
Greenish yellow	Bluish green	Barium, molybdenum
Green		Copper, P as phosphate, B as borate
Blue		Copper
Violet	Violet red	Potassium

^a The blue glass is used to absorb the intense yellow emission from sodium, which is a common constituent of most samples.




FIGURE 7.2 Schematic atomic emission spectrometer. (© 1999-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

source and the excitation source. A schematic diagram of a flame emission spectrometer based on a single-beam atomic absorption spectrometer is shown in Figure 7.2. For measurement of the alkali metals in clinical samples such as serum or urine, only a low-resolution filter photometer is needed because of the simplicity of the spectra. The filter photometer is discussed in Section 7.1.1.2. Both instruments require a burner assembly, a flame, a wavelength selection device, and a detector.

7.1.1.1 BURNER ASSEMBLY

The central component of a flame emission spectrometer is the burner assembly. The Lundegardh or premix burner is the most commonly used and is depicted in Figure 6.8(a) (Chapter 6).

In the premix burner, the sample, in solution form, is aspirated into a nebulizer where it forms an aerosol or spray. An impact bead or flow spoiler is used to break the droplets from the nebulizer into even smaller droplets. Larger droplets coalesce on the sides of the spray chamber and drain away. Smaller droplets and vapor are swept into the base of the flame in the form of a cloud. Only a small portion (about 5 %) of the aspirated sample reaches the flame. The droplets that reach the flame are very small and easily decomposed. This results in an efficient atomization of the sample in the flame. The high atomization efficiency leads to increased emission intensity and increased analytical sensitivity compared with other burner designs. The process that occurs in the burner assembly and flame is outlined in Table 7.2. This process is identical to the atomization process for AAS, but now we want the atoms to progress beyond ground state free atoms to the excited state.

The common nebulizers used in flame emission spectroscopy are the pneumatic nebulizer and the cross-flow nebulizer, just as in AAS (see Chapter 6).

7.1.1.2 WAVELENGTH SELECTION DEVICES

Two wavelength selectors are used in flame OES: monochromators and filters.

Monochromators. These consist of slits and dispersion elements and are described in Chapters 2 and 6. The common dispersion element in modern flame atomic absorption and emission spectrometers is a diffraction grating.

TABLE 7.2 Process Generating Atomic Emission in Flames Liquid sample enters Small droplets of nebulizer liquid enter flame Evaporation of droplets \downarrow Oxidation of atoms Formation of excited Decomposition of Formation of fine solid atoms and emission of particles particles to free radiation from atoms atoms as relaxation occurs

Filters. The alkali metals in a low-temperature flame emit only a few lines and therefore have a simple emission spectrum. In this case, wider wavelength ranges may be allowed to fall on the detector without causing errors, so an optical filter may replace the more expensive diffraction grating. Filters are built with materials that are transparent over a narrow spectral range. The transparent spectral range is designed to be the one in which emission from a given element occurs. When a filter is placed between the flame and the detector, radiation of the desired wavelength from the sample is allowed to reach the detector and be measured. Other radiation is absorbed by the filter and is not measured. Therefore, a separate filter is required for each element to be measured. For example, a filter transparent to radiation with a wavelength of 766 nm is used to determine potassium, while a filter transparent to radiation of 589 nm permits the determination of sodium. The potassium filter absorbs sodium emission and the sodium filter absorbs potassium emission, so the two elements can be measured in the same sample without interference from the other element. Instruments that use filters as wavelength selectors are very convenient for simple repetitive analysis but are limited with regard to the number of elements for which they can be used unless a large number of filters are employed. Most flame photometers are single channel instruments; one element at a time is determined, then the filter is changed and a new element can be determined. Multichannel instruments have been designed where the emission from the flame falls on two or more filters. Each filter transmits the radiation for which it has been designed, and the transmitted radiation falls on a PMT behind the filter. This multichannel approach permits the use of an internal standard to improve precision. For example, a multichannel instrument with filters for lithium and sodium may be used for the determination of lithium in human serum. Alternatively, the Li channel could be used as an internal standard channel; lithium is added to all samples and standards to be analyzed for Na. The lithium internal standard corrects for instrument drift, changes in sample uptake due to viscosity differences, and other interferences as described in Chapter 2. Filter photometers designed for use in hospital or veterinary clinical laboratories often have autosamplers and autodilutors attached, permitting the unattended analysis of many samples per hour.

7.1.1.3 DETECTORS

The detectors in common use for these systems are the PMT or solid-state detectors such as CCDs and CIDs. PMTs and PDAs are discussed in Chapter 3. More detailed discussion of solid-state detectors is covered in Section 7.2.

7.1.1.4 FLAME EXCITATION SOURCE

A flame is the result of the exothermic chemical reaction between two gases, one of which serves as the fuel and the other as the oxidant. The reaction is an oxidation-reduction reaction, with the oxidant oxidizing the fuel. In the process, the reaction generates a great deal of heat. Common oxidants for modern AAS/OES systems are air and nitrous oxide. The only fuel used in modern AAS/OES systems is acetylene, although commercial filter photometer systems can use propane, natural gas, or butane as fuel. When a liquid sample is introduced into a flame, a complex process to produce excited state atoms occurs.

Spectral emission lines are generated by the excited atoms formed during the process of combustion in a flame. Emission lines are characterized by wavelength and intensity. The wavelengths emitted depend on the atoms present. Each element has a different set of quantized energy levels (such as those shown schematically in Figure 7.1 and will emit different, characteristic wavelengths of light (See Figure 7.19). The intensity of the emission depends on several factors including (1) the concentrations of the elements in the sample and (2) the rate at which excited atoms are formed in the flame. The latter depends on (3) the rate at which the sample is introduced into the flame, (4) the composition of the flame, and (5) the temperature of the flame. The intensity-concentration relationship is the basis for quantitative analysis by flame OES.

Flame temperature is probably the most important single variable in flame photometry. The type of fuel and oxidant used controls the temperature. In general, an increase in flame temperature causes an increase in emission intensity for most elements. This does not happen with elements that ionize easily, such as sodium, potassium, and lithium. If these elements are heated at too high a temperature, they become ionized; the outer electrons move to higher and higher energy states until they leave the atom completely, forming an ion. The valence electrons are lost and therefore cannot return to the ground state and emit atomic radiation in the process. A loss of atomic emission intensity results. These elements must be determined in low-temperature flames to minimize ionization.

The ratio of the number of atoms in an upper excited state to the number of atoms in a lower-energy state can be calculated from the Maxwell-Boltzmann equation (Chapter 6).

The Boltzmann distribution assumes the system is in thermal equilibrium. The emission intensity is related to the number of atoms in the higher excited state, since we are looking at emission as the atom relaxes from a higher state to a lower state.

Using the Boltzmann equation (Equation 6.1, Chapter 6), we can calculate the ratio of the number of excited state atoms at two different temperatures. For potassium atoms, the major atomic emission line occurs at 766.5 nm. The energy of this transition in joules is:

$$\Delta E = \frac{hc}{\lambda}$$
= (6.626×10⁻³⁴ J s)(2.998×10⁸ m/s)/(766.5 nm)(1×10⁻⁹ m/nm)
= 2.59×10⁻¹⁹ J

The temperature in a typical air-acetylene flame is about 2200 °C or 2473 K. The ratio of excited state potassium atoms at 2498 vs. 2473 K is calculated by dividing the Boltzmann equation at 2498 K by that at 2473 K. N_0 and the degeneracy terms cancel and we are left with:

$$\frac{N_{2498}}{N_{2473}} = \frac{\exp[-2.59 \times 10^{-19} (\text{J})/1.38 \times 10^{-23} (\text{J/K})(2498 \text{ K})]}{\exp[-2.59 \times 10^{-19} (\text{J})/1.38 \times 10^{-23} (\text{J/K})(2473 \text{ K})]}$$
$$= \frac{5.458 \times 10^{-4}}{5.059 \times 10^{-4}} = 1.08$$

This tells us that a 25 K increase in flame temperature results in an 8 % increase in the excited state population of potassium atoms that give rise to this emission line. The intensity of the emission line is directly proportional to the excited state population, even for systems not in thermal equilibrium. The relationship between emission intensity, *S*, and excited state population can be expressed as

$$(7.1) S = kN$$

where S is the intensity, k is a proportionality constant that includes a number of factors such as the transition probability and energy of the emitted photon, and N is the excited state atom population. S is related directly to the number of atoms in the excited state. As this number increases, the intensity of radiation increases. As the absolute temperature increases, the number of atoms in the excited state increases, therefore the emission intensity increases. Even a small change in temperature results in a significant change in excited state population, as just shown. Atomic emission spectrometry is very sensitive to changes in temperature. The temperature in the atomizer must be carefully controlled for quantitative measurement of emission intensity. This is not the case in atomic absorption spectrometry, where transitions from the ground state are measured. The ground state population is relatively unaffected by small changes in temperature. Table 6.1 (Chapter 6) lists representative maximum temperatures for some common flames.

As a consequence of the relationship $\Delta E = hv = hc/\lambda$, a decrease in the wavelength of the emission line indicates that more energy is required to excite the atom. The process becomes more difficult, fewer atoms are excited and the intensity of radiation decreases. Consequently, elements with emission lines in the short-wavelength part of the spectrum give weak emission signals in low temperature flames. For these elements, the high-temperature nitrous oxide—acetylene flame is favored, or the high-energy electrical or plasma excitation sources discussed later in the chapter should be used.

Another factor that influences emission intensity is the ratio of fuel to oxidant in the flame. The highest flame temperature is obtained when a stoichiometric mixture of the two is used. In a stoichiometric flame, the number of moles of fuel and oxidant present react completely and there is no excess of either after combustion. Any excess of oxidant or fuel results in a decrease in the temperature of the flame. However, some atoms are unstable in certain kinds of flames. Aluminum atoms oxidize very quickly to aluminum oxide in a stoichiometric flame or a flame with an excess of oxidant. Aluminum oxide emits molecular radiation that is not at the same wavelength as the line emission associated with aluminum atoms. This results in a direct loss of atomic emission intensity. To prevent the formation of aluminum oxide, the flame is usually run in a "reducing state", that is, with an excess of fuel. The excess fuel "mops up" free oxidant and minimizes oxidation of the aluminum in the flame. Some elements emit more strongly in oxidizing flames. Consequently, an oxidizing flame is recommended for these elements. In addition, the excess oxygen helps decompose other materials present in the sample and reduces the molecular background. Manufacturers of flame emission instruments provide a list of recommended flame compositions for elements measured by OES. Table 7.7.A.1 in Appendix 7.A on the textbook website provides flame OES detection limits for many elements and identifies the flame used.

7.1.2 INTERFERENCES

The radiation intensity measured may not represent the concentration of analyte in the sample accurately because of the presence of interferences. Interferences fall into two categories: spectral and non-spectral. Three principal sources of interference are encountered in flame OES; they are the same interferences that occur in FAAS.

7.1.2.1 CHEMICAL INTERFERENCE

If the analyte element is present in the sample with anions with which it combines strongly, it will not decompose to free atoms easily. If the anions present in solution combine only weakly with the analyte element, decomposition and formation of free atoms will be easier. For example, if calcium is to be determined, a given concentration of calcium in the presence of phosphate ion will give a lower signal than the same amount of calcium in a chloride solution. It is easier to decompose calcium chloride into free calcium atoms than it is to decompose calcium phosphate in the same flame. This effect is called *chemical interference*. Chemical interference is a non-spectral interference. It can be reduced or eliminated in a number of ways. The analyte ion may be extracted away from the sample matrix by using a chelating agent or the interfering anion may be removed by ion exchange. The standards can be made from the same salt (phosphate, chloride, etc.) present in the sample, compensating for the effect of the interference. A *releasing agent* may be added to the sample solution. Releasing agents reduce or minimize chemical interferences, often by forming a more stable salt with the anion than is formed by the analyte metal. For example, adding a large excess of lanthanum releases calcium from the effect of phosphate ion by preferentially forming lanthanum phosphate.

7.1.2.2 EXCITATION AND IONIZATION INTERFERENCES

Excitation and ionization interferences are non-spectral interferences. When a sample is aspirated into a flame, the elements in the sample may form neutral atoms, excited atoms, and ions. These species exist in a state of dynamic equilibrium which gives rise to a steady emission signal. If the samples contain different amounts of elements, the position of equilibrium

may be shifted for each sample. This may affect the intensity of atomic emission. For example, if sodium is being determined in a sample that contains a large amount of potassium, the potassium atoms may collide with unexcited sodium atoms in the flame, transferring energy in the collision and exciting the sodium atoms in the process. This results in an increased number of excited sodium atoms and increased atomic emission signal compared to a solution of sodium atoms at the same concentration with no potassium atoms in the solution. This is excitation interference, and is generally restricted to the alkali metals. It can be overcome by matrix-matching the samples and standards; the standards must be made up so that the standard solutions contain concentrations of the non-analyte elements similar to those present in the sample. Matrix matching is often done in routine industrial analysis where the sample composition is known. In cases where matrix matching is not practical, the method of standard additions (MSA) can be used. An example of the MSA is given in Section 7.1.3.

A related problem is *ionization interference*. If the analyte atoms are ionized in the flame, they cannot emit atomic emission wavelengths, and a reduction in atomic emission intensity will occur. For example, if potassium is ionized in the flame, it cannot emit at its atomic emission line at 766.5 nm and the sensitivity of the analysis will decrease. If a large amount of a more easily ionized element, such as cesium, is added to the solution, the cesium will ionize preferentially and suppress the ionization of potassium. The potassium ions will capture the electrons released by the cesium, reverting to neutral potassium atoms. The intensity of emission at 766.5 nm will increase for a given amount of potassium in the presence of an excess of cesium. The added cesium is called an *ionization suppressant*. Ionization interference is a problem with the easily ionized elements of groups 1 and 2. The use of ionization suppressants is recommended for the best sensitivity and accuracy when determining these elements. Of course, as ionization increases, *ion emission* line intensity increases. It may be possible to use an ionic emission line instead of an atomic emission line for measurements.

7.1.2.3 SPECTRAL INTERFERENCES

There are two types of spectral interferences in flame OES: (1) background radiation and (2) overlapping line emission from different elements. Excited molecules and radicals in the flame emit over broad regions of the spectrum; it is this broad *band emission* that we call background radiation. The molecules and radicals may be combustion products from the flame gases, oxides, and hydroxides formed from elements in the sample and similar species. For example, species such as BaOH, CaOH, SrOH, MnOH, CaO, CN, and the rare earth oxides all emit band spectra when introduced into a flame. These band spectra can in fact be used to identify these species in a gas phase form of molecular UV/VIS emission spectroscopy, but interfere when atomic emission is to be measured. An example of background emission from an air-acetylene flame is illustrated in Figure 7.3. Atomic emission lines of magnesium, nickel,




FIGURE 7.3 Emission spectrum of a flame. The broad background emission bands from polyatomic species such as OH and CH are seen. Superimposed on the broad background emission are the very narrow atomic emission lines from the elements Mg, Mo, Na, and K.

sodium, and potassium are superimposed on the broad molecular background. In order to accurately determine the intensity emitted by the atom of interest, the intensity due to the background emission must be measured and subtracted from the total intensity, using a blank solution. Subtraction of the blank intensity from the sample or standard intensity results in the intensity due to analyte. A sample calculation is given in Section 7.1.3.

A second method for measuring background intensity is to measure the background intensity of the actual sample at a wavelength very close to the analyte emission line, either slightly higher in wavelength or slightly lower in wavelength than the emission line. This intensity is then subtracted from the intensity of the sample measured at the analyte emission wavelength. This second approach can be less accurate than the first method if the background spectrum is not "flat" in the region of interest. For example, look at Figure 7.3 in the region of the Mo emission line. The background slopes sharply in the region of the Mo line; it is much higher on the high wavelength side than on the low wavelength side. The use of an "offline" background correction for Mo could result in a high degree of error because of the rapid change in background intensity with wavelength in this region. On the other hand, the background region around the potassium emission line is relatively flat; the method of "off-line" background correction would result in accurate background correction for potassium.

The other type of spectral interference is the emission by another element of the same wavelength as the analyte element. This is a direct source of error. The analyst may choose another analyte wavelength, extract the interfering element, or apply a correction factor if the concentration of the interfering element is known. This is not much of a problem in flame OES, due to the low temperature of flames and the relatively few excited states that are populated, but it is a major source of interference in high temperature excitation sources such as electric discharges and plasmas. By "same wavelength", we mean that the instrument we are using cannot resolve the interfering line from the analyte line, even if the actual wavelengths are slightly different. The spectral bandpass is such that both wavelengths pass through the exit slit of the system to the detector. For this reason, high-resolution spectrometers are needed for non-flame OES.

7.1.3 ANALYTICAL APPLICATIONS OF FLAME OES

7.1.3.1 QUALITATIVE ANALYSIS

Atomic emission spectroscopy can be used as a qualitative method for determining multiple elements in samples. Flames are not the optimum emission source for most elements because of the limited temperatures available. The presence of elements in a sample is determined qualitatively by observing emission at the wavelength characteristic of the element. Table 7.7.A.1 in Appendix 7.A (textbook website) lists common characteristic emission lines for flame OES. A more comprehensive list can be found in the Handbook of Spectroscopy Volume 1 by Robinson cited in the bibliography. The use of a flame source is not as reliable as the use of higher energy excitation sources where multiple wavelengths can be observed for each element, thereby providing more proof of the presence of a given element. For this reason, plasma sources have become the preferred atomic emission source for most elements. Flame OES is a fast, simple method for the qualitative identification of the group 1 and 2 elements and can be used for any element that emits radiation in a flame provided care is taken to discriminate the emission lines from any spectral interference.

7.1.3.2 QUANTITATIVE ANALYSIS

Flame OES can be used to determine the concentrations of elements in samples. The sample usually must be in solution form. Generally, one element is determined at a time if using an AAS system in emission mode. Multichannel instruments are available for the simultaneous determination of two or more elements. Detection limits can be very low as seen in Appendix 7.A, Table 7.7.A.1 (textbook website). Detection limits for the alkali metals are in




FIGURE 7.4 Calibration curves for lithium by flame emission using external calibration standards. Note the non-zero intercept for the blank due to background emission from the flame.

the ppt concentration range when ionization suppression is used. One part per trillion in an aqueous solution is 1 pg of analyte per mL of solution or 1×10^{-12} g/mL. Most elements have detection limits in the high ppb to low ppm range.

An important factor in quantitative analysis by flame OES is the solvent used for the samples and standards. When water is the solvent, the process of atomization is endothermic and relatively slow. With many organic solvents, the reactions in the flame are exothermic and atomization is rapid. Other things being equal, more free atoms are liberated and emission intensity increased in organic solvent than in aqueous solution. For accuracy, it is therefore critical that the samples and standards be prepared in the same solvent.

For a quantitative measurement, the sample is aspirated into the flame and the intensity of radiation is measured at the emission wavelength of the analyte element to be determined. The concentration of the element in the sample is calculated from comparison with an external calibration curve or by the standard addition method. Both of these methods have been discussed in Chapter 1. A typical external calibration curve for lithium is shown in Figure 7.4. The calibration curve was constructed by aspirating Li standard solutions of 5 and 10 ppm Li and the blank solution (0.0 ppm Li). A plot of intensity vs. concentration is made using a statistical curve-fitting program to construct the calibration curve and to calculate the concentrations of unknowns. Note that an emission signal was detected in the standard that contained no lithium (the zero-concentration standard or calibration blank). This is the *background signal* or *blank emission signal*. The source of the background signal was discussed in Section 7.1.2.3. In this case, the background emission was not subtracted from each standard, but was plotted as the 0.0 ppm Li standard. The calibration curve follows Beer's Law at low concentrations of analyte. Deviations from linearity at high concentrations are commonly observed in flame emission calibration curves.

As an example, assume that we have the calibration curve in Figure 7.4. The data points for this curve and the equations of the calibration curves determined by linear regression with and without background subtraction are given in Table 7.3.

If we aspirate an unknown sample solution and measure an intensity of 1626 counts, we can use the equation without blank correction to calculate the Li concentration in the unknown. Inserting 1626 as y in the equation and solving for x, the concentration x is calculated to be 5.88 ppm Li in the unknown solution.

If we subtract the blank first, inserting y = 1176 into the blank-corrected equation (Table 7.3) and solving for x gives us 5.88 ppm Li. The results are the same since the background was accounted for in both approaches (and assumed to be the same in all samples and standards).

TABLE 7.3 Calibration Curves for Li by Flame OES

Li Concentration (ppm)	Intensity	Blank-Corrected Intensity
0.00	450	0
5.00	1450	1000
10.00	2450	2000

Linear regression equation without blank correction: y = mx + b = 200x + 450Linear regression equation with blank correction: y = mx + b = 200x + 0 = 200x

TABLE 7.4 Detection Limits for Flame Photometry

Element	LOD (ppm) Model PFP-7	Range ^a (mmol/L) or LOD ^b (ppm) Model PFP-7C	LOD (ppt) Model 300
Na	≤0.2	120–190a	8
K	≤0.2	0-10.0 ^a	15
Li	≤0.25	≤0.25 ^b	5
Ca	≤15	≤15 ^b	
Ва	≤30	≤30 ^b	

Source: Data courtesy of Buck Scientific, Inc., East Norwalk, CT. (www.bucksci.com).

Note: LOD = limit of detection. ppt = parts per trillion, or ng/L. The Model PFP-7C is designed specifically for clinical chemistry and displays the Na and K concentrations in mmol/L. The Model 300 is designed for high sensitivity analysis of power plant feedwater.

Suppose we need to determine Li in human serum to monitor a lithium-based antidepressant medication. We would not expect the background from a serum sample to be the same as the background from an aqueous standard solution. We might make our calibration standards in lithium-free serum, but if we only have one sample to run, that is not efficient in terms of cost or time. This is a good example of when to use the MSA, described in Chapter 1.

In order to obtain a steady emission signal of constant intensity, each step in the process shown in Table 7.2 must be controlled. Modern equipment is able to do this with little attention from the analyst. The skillful analyst, however, is always aware of the chemical and physical processes involved and is thus able to recognize and correct any problems that may arise. Variations in emission intensity can be caused by several factors, including (1) blockage in the nebulizer or burner, preventing the flow of sample; (2) viscosity differences in samples or between samples and standards; (3) change of solvent in the sample; (4) change in the fuel or oxidant flow rate to the burner; and (5) change of the position of the burner in the instrument, causing the radiation to be displaced from the light path. The operating conditions must be optimized for the analysis, including the selection of the flame to use, the wavelength to monitor, the fuel/oxidant ratio, the sample uptake rate, the slit widths, and the position of the burner in the light path.

While flame OES is a simple, rapid method for the determination of the group 1 and 2 elements, it has been replaced for the determination of most elements in liquid samples by AAS, ICP-OES, and ICP-MS. A typical commercial flame photometer for clinical determination of Na, K, Li, and other elements is capable of detection limits as shown in Table 7.4. For quantitative analysis, the precision is about 1 %. There are many flame emission applications published in the literature before plasma emission systems became dominant in the early 1980s.

7.2 ATOMIC OPTICAL EMISSION SPECTROSCOPY

Radiation from excited atoms and ions is emitted by a sample when it is introduced into an electrical discharge, a glow discharge, or a plasma. Because these excitation sources are of higher energy than a flame source, all metallic and metalloid elements can be detected in

low concentration, including refractory elements such as boron, tungsten, tantalum, and niobium. Nonmetals can be measured, including C, N, H, Cl, Br, and I. Liquids and solids can be analyzed quite easily using a plasma source; electrical and glow discharge sources are used for the analysis of solids only. Pure gas phase elements, such as hydrogen, helium, neon, and mercury vapor, can be identified by the emission spectra generated by an electrical discharge through the gas confined in a sealed quartz tube. This same process generates the light in "neon" signs and mercury vapor street lights.

Because the temperatures of electrical discharges and plasmas are much higher than temperatures that can be achieved in flames, the emission spectra from these excitation sources are very complex. Two types of line spectra are generated from these systems. First are the *atomic emission spectra* from neutral atoms. These lines are designated in tables of emission lines by a Roman numeral I following the wavelength. Under spark and plasma conditions ions are often formed. A second electron in the ion may then become excited and enter one of the higher energy states. From these states, the ion relaxes and emits a photon in the process. The energy levels of the ions are not the same as the energy levels of the atoms. They therefore emit different emission lines, called *ion lines*. Lines from singly charged ions are designated by a Roman numeral II and lines from doubly charged ions by a Roman numeral III following the wavelength. Several reference books that list tables of emission lines are listed in the bibliography.

Ion lines are less sensitive than atomic lines but are not subject to reversal due to self-absorption, discussed below. They are used for quantitative analyses when a sufficient concentration of the analyte is available. Ion lines are seldom used for qualitative analysis because of their lack of sensitivity.

7.2.1 INSTRUMENTATION FOR EMISSION SPECTROSCOPY

In simple terms, an emission spectrometer with an electrical discharge source (Figure 7.5) functions as follows. An electrical source produces an electrical discharge in a spatial "gap" between two electrodes, the *sample electrode* and the *counterelectrode*. A solid machined piece of the metal to be analyzed serves as the sample electrode; the counterelectrode is an "inert" electrode of tungsten or graphite. Material from the sample electrode is introduced into the discharge, where it becomes vaporized and excited. The excited atoms emit radiation, which is detected and measured by the detector readout system. The wavelengths of the emitted lines identify the elements present and the intensity of the emission at each wavelength can be used to determine the amount of each element present. The individual components of the instrumentation are described in the following sections.




FIGURE 7.5 Schematic diagram of an emission spectrometer with an electrical discharge excitation source. The prism is meant only to illustrate a dispersive device; a diffraction grating is used in all modern spectrometers with a single dispersive device. Echelle spectrometers use two dispersive devices, either a prism and a grating or two gratings.

7.2.1.1 ELECTRICAL EXCITATION SOURCES

Historically, several types of electrical excitation sources have been used since the early part of the 1900s, among them the DC arc, the AC arc, and the AC spark. Commercial instruments using electrical excitation sources became available about 1940 with PMT detectors; prior to this, emission instruments used a photographic plate or film as the detector. Modern instruments are either DC arc emission instruments or high voltage spark emission instruments capable of operating under "spark-like" or "arc-like" conditions as necessary. A significant advantage of these electrical excitation sources is that conductive solids can be analyzed directly, avoiding the need for tedious sample dissolution and the degradation of detection limits by having to dissolve and therefore dilute the sample. Non-conductive solid powders can often be analyzed by mixing them with conductive graphite, which does dilute the sample to some extent, but not as much as dissolution.

Arc and spark emission spectroscopy are widely used for the qualitative, semiquantitative, and quantitative determination of elements in geological samples, metals, alloys, ceramics, glasses, and other solid samples. Quantitative analysis of more than 70 elements at concentration levels as low as 10-100 ppb can be achieved with no sample dissolution. The determination of critical nonmetal elements in metal alloys, such as oxygen, hydrogen, nitrogen, and carbon can be performed simultaneously with the metal elements in the alloys.

DC arc. In this source, a DC voltage is applied across a pair of graphite or metal electrodes separated by a small gap. The typical voltage for a DC source is 200 V with currents of 3-20 A. The arc must be initiated by the formation of ions, usually by a low current spark. Ions are formed in the gap, electrical conduction occurs, and the motion of electrons and ions formed by thermal ionization sustains the arc. A *plasma* forms into which the sample is vaporized by electrical and thermal energies. The term *burning* is used to describe the process, although no combustion is involved. The sample, in the form of solid powder, chips, or filings, is generally packed into the cupped end of a graphite electrode [Figure 7.6(a) and (b)]. This electrode




FIGURE 7.6 (a) Diagram of a direct current arc source. The solid sample is packed into the cupped end of the lower graphite electrode. The graphite counterelectrode is also shown. (From Hareland, used with permission.) **(b)** A schematic of the lower electrode used to hold the sample.








FIGURE 7.7 (a) and (b) Photographs of the electrode assembly in commercial DC arc emission spectrometers. (c) Photograph of the plasma formed by the DC arc in operation. The discharge is established in the gap between the electrodes.

would be at the bottom of the gap seen in Figure 7.5. The top electrode or *counterelectrode* is a solid graphite electrode. A photograph of the electrode assembly in a commercial DC arc emission spectrometer is shown in Figure 7.7(a). If the sample is a solid piece of conductive metal, it may be machined into the proper shape and serve as the bottom electrode. In DC arc emission, the entire sample packed into the electrode cup is usually vaporized or "burned" over a period of several minutes. The arc is a *continuous* discharge, and the emission intensity is collected and integrated over the burn period. An operating DC arc is shown in Figure 7.7(c).

The temperature of the arc depends upon the composition of the plasma and varies with the nature of the sample. If the sample is made of material with low ionization energy, the temperature of the plasma will be low; if the ionization energy of the material is high, the temperature will be high. In addition, the temperature is not uniform in either the axial or radial directions. This results in matrix effects and self-absorption. Arc temperatures are on the order of 4500 K with a range of 3000-8000 K. Emission spectra from arc sources contain primarily atomic lines with few ion lines. The DC arc can excite more than 70 elements.

A significant problem with DC arc sources is the poor stability of the emission signals. Generally, the plasma will link to a point or projection on the surface of the solid sample and will continuously erode the sample, vaporizing it in the process. A pit is formed in the sample by the erosion, and finally the pit becomes so large that the discharge can no longer be maintained at that point. The discharge then "wanders" to another nearby point on the sample surface. In practice, the wandering of the discharge is quite fast and causes the signals to fluctuate. Numerous such discharge points are created at the same time. Local hot spots are formed, which cause the sample in the immediate vicinity to evaporate rapidly and become excited easily; however, these hot spots are not continuous and soon die away, and the local emission intensity is reduced. As a consequence of this behavior, the total emission intensity is somewhat erratic and the signals produced lack precision. On the other hand, the signals are very intense, and the analytical sensitivity is better than when other types of electrical discharges are used.

Another problem with the DC arc is that volatile elements will selectively vaporize and enter the plasma before the less volatile elements in a sample. The electrode temperature increases slowly from the initiation of the arc. If the sample is the anode, which heats more rapidly and to a higher temperature than the cathode, volatile elements will rapidly enter the arc. For example, tungsten powder for light bulb wire contains added potassium and silicon. In a DC arc analysis, the low melting potassium would volatize first, followed later (possibly several minutes later) by the high melting silicon and tungsten. This can cause serious problems with quantitative analysis if standards are used that do not match the volatilization behavior of the sample matrix. The problem may be overcome by mixing the samples and standards with an excess of a "spectrochemical buffer". This is a salt or mixture of salts such

as NaF and Na $_2$ CO $_3$, often mixed with graphite. The "buffer" increases conductivity and provides a uniform matrix that keeps the arc temperature constant. Mixing with pure graphite is also used to give a common matrix. The purity of the graphite or other buffer materials used is very important, given the ppb detection limits that can be reached.

There is a positive aspect to the selective volatility of low melting elements, in that spectral interferences are likely to be less at the beginning of a burn (low temperature) than at high temperatures when line-rich elements such as Fe start to vaporize. In modern DC arc sources, this problem of selective volatility is addressed by having the polarity of the electrodes reversed for the first minute or so of the burn. With the sample as the cathode, the temperature is lower and the rate of heating lower. This slows the rate of evolution of volatile species and improves sensitivity and precision for the volatile elements. Sensitivity for the nonvolatile elements is somewhat reduced when the sample is the cathode. A common sequence for analysis would consist of a burn of 60 s with the sample as cathode (reverse polarity) at 8-10 A, a 60 s burn of normal polarity (sample as anode) at 8-10 A, and then 60 s at 15 A to volatilize the very refractory elements.

The DC arc is used primarily for semiquantitative and qualitative analysis of solids, including powdered solids, chips, and filings. Most elements can be determined. The spectrometer operates from about 190–800 nm which covers the UV and visible range in which most atomic emission occurs. The precision attainable in a modern DC arc spectrometer is 5-10 %, with detection limits in the 10-100 ppb range in solid samples. Detection limits for trace elements in high-purity copper by DC arc emission using a CID detector are given in Table 7.5.

TABLE 7.5 Detection Limits for Elements in High-Purity Copper and High-Purity Uranium Oxide Using DC Arc Emission Spectrometry

	High-Purity Copper	High-Purity Copper	High-Purity Uranium Oxide
Element	DC Arc with PMT detection (ppm)	DC Arc with CID detection (ppm)	Current-controlled DC Arc
Ag	0.2	0.15	0.12
Al			0.028
As	1.0	0.20	
В			0.083
Be			0.015
Bi	0.1	0.012	0.50
Ca			4.7
Cd			0.11
Cr			4.8
Cu			0.32
Fe	1.0	0.15	19.5
Mn	0.1	0.06	1.2
Ni	0.1	0.02	2.7
Pb	0.1	0.008	0.39
Sb	1.0	0.25	
Sn	0.5	0.02	0.13
Te	1.0	0.15	
Zn	1.0	0.02	0.33

Copper data: The DC arc/CID data were collected using a commercial system no longer in production.© Thermo Fisher Scientific (www.thermofisher.com). Used with permission.

Uranium Oxide data: collected on a Prodigy DC Arc spectrometer. Detection limits based on analysis of a certified uranium oxide standard and are therefore higher than those obtainable using a high purity uranium oxide blank. © Teledyne Leeman Labs, Inc., Hudson, NH. (www.teledyneleemanlabs.com). Used with permission.




FIGURE 7.8 Schematic spark excitation source. S is a switch, C is a capacitor, L is an inductor, R is a resistor, and V is a voltage source. (From Thomsen, used with permission from ASM International*.)

These detection limits are comparable to the instrumental detection limits of GFAAS and ICP-OES, both of which generally require dissolution of the solid and dilution to form a solution. The effective detection limits in the solid sample therefore would be poorer by GFAAS or ICP-OES than the DC arc detection limits. The limitation to DC arc is the requirement that the solid sample be electrically conductive. The linear working range of a DC arc source is about three orders of magnitude, limited by the relatively low energy of the source.

The uranium oxide data in Table 7.5 were collected on a Teledyne Leeman Labs Prodigy DC Arc. The uranium oxide was mixed with a small amount of gallium oxide/cobalt oxide buffer and 125 mg of the buffered sample were analyzed. The pre-burn time was 4 sec, and the elements were determined in a 4-45 sec integration time. The details are available in an application note available from Teledyne Leeman Labs, along with other examples of the use of DC arc emission for materials analysis.

Spark source. A schematic diagram of a high-energy spark source is shown in Figure 7.8. When the switch is closed, the capacitor is charged. When the switch is opened, the capacitor discharges through the inductor and the resistor and produces an electrical discharge in the spark gap. The voltage in the circuit shown in a modern instrument is between 400 and 1000 V. This voltage is not high enough to cross the 3-4 mm gap between the sample and the counterelectrode. A separate ignition circuit, similar to those used in automobiles, is used to create a very high voltage (10 kV). This high voltage initiates electrical excitation across the gap. Once the electrical path is initiated, the operating voltage sustains the discharge. The spark source is an interrupted discharge, unlike the continuous DC arc discharge.

In a modern spark source, the discharge is only in one direction, from the counterelectrode to the sample. This is done by including a diode across the capacitor so that current flows in only one direction. The switch is opened and closed electronically many times per second. This is the source frequency and is equal to the number of discharges per second. Spark source frequencies are generally in the 200-600 Hz range, resulting in hundreds o sparks per second. A modern spark source can be used in either spark-like or arc-like mode. Spark-like refers to a high-current discharge that comes in short bursts. Arc-like refers to a lower current, almost continuous discharge. A diagram of current in the gap vs. time for the two types of discharges shows the difference between the two modes (Figure 7.9). The sparks strike the sample surface randomly, resulting in an averaging of the composition and improved precision. The spark source is flushed with argon gas to eliminate oxidation of samples and to permit measurement of wavelengths below 200 nm. The flow of argon through the spark stand is as high as 250 L/h when intensity measurements are taken.

The temperature in a spark-like discharge is much higher than the temperature in a DC arc discharge. Temperatures are not stable in either time or space in the spark, but may be as high as 40,000 K. This permits excitation of most elements, including oxygen, nitrogen, the halogens, and the group 18 gases (Ne, Ar, etc.). The higher temperature also results in many ion emission lines being produced. Spark spectra contain ion lines for singly ionized elements and for doubly ionized elements. Spark spectra therefore are more complex than DC arc spectra. The spark-like discharge is more reproducible than the DC arc; this makes




FIGURE 7.9 Current-time relationship for a spark discharge and an arc discharge. (From Thomsen, used with permission from ASM International*.)

the spark a better choice for quantitative analysis. However, signal intensity is lost with this technique, with a consequent loss of analytical sensitivity. Spark-like conditions are used for the best precision; arc-like conditions for the best sensitivity.

While the primary function of the electrical excitation source is to generate a discharge that will vaporize and excite sample atoms, the source serves a second function. It provides a high-energy pre-spark (HEPS), a high current spark discharge that homogenizes the sample surface by melting it. The emission during the HEPS period (formerly called a pre-burn) is not integrated. After the HEPS, the sample is more homogeneous and the integration of the signals from the sparking period results in higher precision. A typical spark cycle for a metal sample would include a 10-20 s HEPS period, a 5 s measurement under spark-like conditions for major and minor constituents, and then a 5 s measurement under arc-like conditions for trace elements. Typical excitation source parameters are given in Table 7.6.

The SPECTROLAB spark emission system from SPECTRO Analytical Instruments GmbH, using micro-integrators to process PMT photon current, enables µsec readings to be obtained. A single spark can be divided into 100 or more steps, allowing for optimization of dynamic range and S/N. Inclusions, segregations and correlations between elements can be detected and evaluated. For example, a correlation in time between Ti and N indicates the presence of TiN in the sample; a similar correlation between Mn and S would indicate MnS.

7.2.1.2 SAMPLE HOLDERS

The function of the sample holder is to introduce the sample into the electrical discharge. There are two types of sample holders, those for solid samples and those for liquid samples. More than 50 types and sizes of electrodes for holding samples are commercially available.

TABLE 7.6 Typical Spark Excitation Source Parameters					
Parameter	HEPS	Spark	Arc		
Ω (resistance, ohms)	1	1	15		
L (inductance, μ henry)	30 130		30		
C (capacitance, μ farad)	12	2	12		
V (volt)	400	400	400		
υ (frequency, Hz)	300	300	300		
I (current, amp)	130	60	20		
t (time, μ sec)	100 90		600		
Source: Adapted from Thomsen, used with permission of ASM International*.					




FIGURE 7.10 A schematic spark source, showing a flat metal sample as the cathode and a tungsten counterelectrode as anode. (From Hareland, used with permission.)

Solid sample holders. Solid samples, especially nonmetallic materials, may be analyzed as powders. High-purity carbon electrodes are available with a small well drilled in one end to hold powdered samples, such as the electrode shown in Figure 7.6(b). Powdered samples may be loaded into the carbon electrode and packed or tamped down. In some cases, the sample powder is mixed with a large amount of a high-purity matrix powder, such as alumina or silica mixed with graphite. This ensures a constant matrix and therefore a constant plasma temperature, which improves the precision of the analysis. Another approach is to mix the sample powder with a large excess of a conducting powder, such as high-purity graphite or copper, and then to press a pellet of the mixture to serve as the electrode. The conducting powder also serves as a constant matrix, improving the precision of the measurements.

Metallic or electrically conductive samples, such as sheets, wires, or rods of alloys or pure metals, may be used directly as one or both of the electrodes. Some preparation may be required, such as milling the metal into the desired shape or melting the metal and casting it into a mold. The end of the electrode is either polished flat or tapered at one end. The formed electrode must be cleaned to remove any surface contamination before analysis. The most common approach used in modern spark instruments is to have a polished flat metal sample serve as the cathode and a tungsten electrode as the anode, shown schematically in Figure 7.10.

Liquid sample holders. Oil samples may be analyzed directly by spark emission spectrometry using a rotating disk electrode. The rotating disk electrode (RDE), or rotrode (Figure 7.11) is a graphite disk that rotates through the liquid sample, which wets the surface of the disk. The rotating wet surface carries the sample into the discharge at a steady rate. Calibration data must be obtained under identical conditions and an identical number of revolutions. This approach is used routinely for the determination of metals in lubricating and fuel oils. The analysis of oil for metal content indicates wear of the engine and other lubricated parts, corrosion, abrasion, degraded lubricants and lubricant mix-up. It is an important quality control measure in commercial and military aircraft, ship and vehicle maintenance. The rotrode is used with arc/spark sources.

Automation of a rotrode-based analysis had been difficult, due to the need to replace the rotating disk, resharpen the carbon rod electrode and reset the gap after each sample. The modern Spectroil Q100 system (Spectro Scientific) uses two graphite disk electrodes, which are changed robotically for each new sample. The disk electrode shafts form a fixed gap and the robotics permit analysis of 80 samples per hour. A short video demonstrating the Spectroil Q100 is on the Spectro Scientific website, www.spectrosci.com.

7.2.1.3 SPECTROMETERS

Simultaneous multichannel spectrometers are required for most arc and spark emission work because the instability of the source or the interrupted nature of the discharge requires that emission signals be integrated for 10 s or longer. A scanning spectrometer is therefore




FIGURE 7.11 A schematic rotating disk electrode (or rotrode) used for the introduction of liquid samples into an electrical discharge. The system is used primarily for the determination of metals in oils. The RDE is shown with an arc source and fiber optic lead to a Rowland circle polychromator with CCD detector. (Courtesy of Spectro Scientific, Chelmsford, MA. www.spectrosci. com. Used with permission.)

not practical. There are two types of spectrometers in use, polychromators and CID-based or CCD-based Echelle systems. The basic components of spectrometers were discussed in Chapter 2 and more detail on atomic spectrometers was covered in Chapter 6. A significant difference between systems for AAS and atomic emission spectrometry is in the spectral bandwidth or bandpass used. The bandpass in AAS is generally in the range of 0.2-0.5 nm, while for atomic emission, it is usually less than 0.1 nm. The reason for this difference is left as a problem for the student at the end of the chapter.

Polychromators. Polychromators are multichannel spectrometers with PMTs as detectors. Instruments with up to 108 PMTs are commercially available. These instruments generally use a concave diffraction grating as the dispersion device, as shown schematically in Figures 7.11 and 7.12. A concave grating focuses light of different wavelengths, λ_1 , λ_2 , λ_3 , and so on, at different points on the circumference of a circle.




FIGURE 7.12 A Rowland circle polychromator. This configuration is called a Paschen-Runge mount. The source shown is an inductively coupled plasma, but any of the electrical excitation sources can be substituted. Multiple photomultiplier detectors are placed at the appropriate positions on the circumference of the circle to measure dispersed wavelengths or a CCD detector can be used. (© 1999-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

For a given radius of curvature of the grating, the entrance slit, the surface of the grating, and the focal points of the dispersed wavelengths lie on a circle called the *Rowland circle*. The *diameter* of the Rowland circle is equal to the radius of curvature of the surface of the concave grating. Photomultiplier detectors are put behind fixed slits at the focal points of up to 64 different wavelengths as illustrated in Figure 7.12, which shows only four slits and detectors. The limitation on the number of channels (wavelengths monitored) is set by the physical size of the PMTs in a conventional Rowland circle system. The instrument buyer chooses the wavelengths, so each instrument is custom-built. The advantage of this system is that routine multielement analysis for many elements can be performed rapidly. Once chosen, the wavelengths and therefore the elements detected, are fixed, so the instrument lacks flexibility if nonroutine samples need to be analyzed. The precision of these instruments with a spark source is excellent, often better than 1 %RSD, and quantitative analysis can be performed rapidly. If a DC arc source is used, rapid semiquantitative analysis with ppb detection limits can be performed.

In order to measure 70 or 80 elements simultaneously, it is necessary to cover the entire range of wavelengths from the vacuum UV through the visible region (120–800 nm). A sealed purged optical system, continuous inert gas purging or a vacuum spectrometer is required to measure wavelengths in the 120–190 nm range.

Using a single Rowland circle, the number of PMTs is limited by the size of the detectors. The spark spectrometer shown schematically in Figure 7.13 uses fiber optics to carry the light from the excited sample to up to four separate polychromators, each optimized for a specific wavelength region. This greatly increases the number of wavelengths that can be measured; this system has a CCD detector in one spectral module and up to 108 separate PMTs can be arranged in the second spectral module. The UV polychromator has a sealed optical system filled with argon, permitting wavelengths as short as 120 nm to be measured without the need for vacuum pumping. A steel sample can be completely analyzed quantitatively, including determination of C and N in the steel, in less than 30 s using this system.

Echelle monochromators. In the past ten years, Echelle monochromators have become increasingly common in multielement emission systems. The Echelle design uses two





FIGURE 7.13 Schematic diagram of the SPECTROLAB spark emission spectrometer system. (Courtesy of SPECTRO Analytical Instruments GmbH, a division of AMETEK, Inc. www.spectro.com, www.ametek.com.)






FIGURE 7.14 A schematic diagram of an Echelle spectrometer. Two dispersive devices are used. **(a)** The prism disperses light in the vertical plane; The grating disperses the vertically dispersed light in the horizontal plane. The physical arrangement of the grating and prism can be reversed as in **(b)** or two gratings may be used. (Courtesy of SPECTRO, a unit of the materials analysis division of AMETEK, Inc., www.spectro.com, used with permission.)

dispersion devices in tandem, a prism and an Echelle grating, or two gratings. The design of the Echelle grating is discussed in Chapter 2. The two dispersion devices are placed so that the prism disperses the light in one plane. This light falls upon the grating, which disperses in a plane at right angles to the plane of dispersion of the prism. This is illustrated in Figure 7.14(a). The physical arrangement of the grating and prism can be reversed [Figure 7.14(b)] or two gratings may be used.

The final dispersion takes place over a 2D plane rather than along the single line of the Rowland circle optics. The radiation intensity can be measured using either PMT detectors or array detectors. More commonly, the entire 2D "echellogram" is imaged using a 2D solid-state detector, such as the CID or CCD discussed subsequently. Figure 7.15 shows a commercial Echelle spectrometer with a CID detector. A schematic representation of the resulting echellogram, wavelength vs. diffraction order, is shown in Figure 7.16. With new array detectors, up to 5000 different wavelengths can be monitored simultaneously, many more than could possibly be detected using PMTs. An additional advantage of an Echelle system with




FIGURE 7.15 Photograph of the interior of a commercial Echelle system with a CID detector. (© Thermo Fisher Scientific (www.thermofisher.com). Used with permission.)




FIGURE 7.16 Exit plane representing the 2D array of wavelengths produced by the Echelle configuration (an "Echellogram"). (Courtesy of SPECTRO, a unit of the materials analysis division of AMETEK, Inc., www.spectro.com, used with permission.)

a solid-state detector is the ability to correct for background emission in real time (i.e., at exactly the same time as the analyte intensity is measured).

7.2.1.4 DETECTORS

PMTs and linear photodiode array detectors are discussed in detail in Chapter 3. This section will cover the 2D array detectors used in arc/spark and plasma emission spectrometers. In order to take advantage of the 2D dispersion of wavelengths from an Echelle spectrometer, a 2D detector is required. The detector should consist of multiple individual detectors positioned (arrayed) so that different wavelengths fall on each individual detector. Such an array detector is called a multichannel detector, whether the detector units are arranged linearly or in two dimensions. The charge-injection device (CID) and the charge coupled device (CCD) are both silicon-based sensors that respond to light. They belong to a broader class of devices called charge transfer devices (CTD). The two detectors discussed can be considered to be 2D arrays of silicon photodiode detectors. CTDs store the charge created when electromagnetic radiation strikes them and permit the integrated charge to be read. The amount of charge measured is proportional to the intensity of the light striking the detector units.

An insulating layer of SiO₂ is grown onto a crystalline silicon substrate and thin conducting electrodes are placed on top of the silica layer to create metal oxide-semiconductor (MOS) capacitors. The crystalline silicon has Si-Si bonds arranged in a 3D lattice. A bond can be broken by a photon of sufficient energy, releasing an electron into the silicon lattice and creating a "hole" simultaneously. This is exactly analogous to the formation of an electron-hole pair in a photodiode, described in Chapter 3. In the presence of an applied electric field across the device, the electrons will move in one direction and the holes will move in the opposite direction, leaving an area depleted of positive charge (a depletion region or potential well). The electrons accumulate and are stored in the depletion region. The more photons absorbed by silicon, the more electrons are accumulated in the potential well. Wells can hold as many as 106 charges before "leaking" or "blooming" into an adjacent storage unit. The CTD storage units, or pixels, are arranged in a 2D array on a silicon wafer. The number of pixels varies from 512×512 to 4096×4096 . The difference between the CID and the CCD is the manner in which the charge is obtained, accessed, and stored. Both are multichannel detectors, permitting multielement analysis using several hundred wavelengths. A significant advantage to these multichannel detectors is that the background is measured simultaneously with the analyte emission, providing more accurate background correction and faster analysis times.

CID. Each pixel in a CID can be accessed randomly to determine the amount of charge accumulated during a given period of time. The time period is called the integration time. Positive charges from the photon production of an electron-hole pair are stored in a potential well beneath a negatively biased capacitor. Reading the amount of charge does not change the amount of charge; the CID readout is nondestructive. The charge can be accessed even while the pixel is exposed to light, that is, during the integration time. This helps to eliminate blooming, the spilling over of charge from one pixel to another. The random access and nondestructive readout are advantages for the CID. Another advantage is that in its operation, the CID provides complete wavelength coverage. It is possible to measure more than 250,000 lines simultaneously. Background correction and spectral interference correction are performed by processing the data after it is collected. The CID has a high noise level and must be cooled to liquid nitrogen temperature for operation. CIDs are available to cover the UV and visible regions of the spectrum (190–800 nm). The dynamic range for the CID used in the spectrometer shown in Figure 7.15 is eight orders of magnitude. A picture of this CID and a real echellogram image collected by the CID are shown in Figure 7.17. A megapixel Large Format Programmable Array Detector (L-PAD), a CID design, used by Teledyne Leeman Labs in their Prodigy high dispersion ICP spectrometer has an area of 28 mm², the largest active area solid state detector currently in use. The L-PAD provides continuous wavelength coverage from 165-1100 nm with a linear working range of over six orders of magnitude. For a given analytical wavelength, the Prodigy uses a 3x15 pixel subarray centered on the wavelength of interest. The analytical peak and background correction points




FIGURE 7.17 (a) Photograph of a CID. This solid-state array detector captures an electronic image of the complete emission spectrum. (b) The Echellogram of a sample of zinc oxide collected by a CID detector from a DC arc source. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

are defined in each subarray with pixel position and width values. For example, to measure lead in paint samples using the 220.353 nm Pb line, a typical subarray setup might use the first five pixels to measure the background on the left of the emission line. Pixels 7-9 are used for integrating the analytical peak. If a background measurement is needed on the right side of the analytical line, pixels 10-15 could be used. Details of the measurement can be found in Teledyne Leeman Labs Application note 1056 on the analysis of lead-based paint (www. teledyneleemanlabs.com).

CCD. The CCD operates in a manner identical to a linear photodiode array detector and similar to the CID, except for the way the individual detectors are accessed and controlled. The CCD depicted in Figure 7.18 shows the depletion region (potential well) and stored negative charge from photoelectrons generated when light hits a pixel. In a CCD, the accumulated charge must be read sequentially. In the process of reading it, the charge is destroyed. The charge is transferred from one pixel to the next in a row in a "bucket brigade" manner. The readout "buckets" are at the edge of the CCD chip. As each row is read, the charge from the next row is shifted to the corresponding pixels in the empty row, a process called parallel charge transfer. The readout electronics know the location in the original array of the pixel being dumped into the end bucket and match the measured charge with that position. This allows the CCD to provide intensity-wavelength correlation even though the charge has been




FIGURE 7.18 Schematic of a CCD. In this CCD, three electrodes define a pixel. (Courtesy of Horiba, Inc. © 2020 HORIBA Scientific [www.horiba.com/scientific]. All rights reserved.)

moved. The readout is very fast and has low noise associated with it. CCDs can be cooled by liquid nitrogen, but also by more convenient thermoelectric cooling devices and still have good signal-to-noise ratios. They are more susceptible to blooming than CIDs at high levels of illumination; this limits their dynamic range, but makes them good detectors for weak sources.

While PMT detectors are more sensitive and operate with lower signal-to-noise than CID or CCD detectors, they cannot match the multichannel capacity of the CTD array detectors. The references by Harnly and Fields, Sweedler et al., Epperson et al., and Pilon et al. provide more detail on CID and CCD detectors.

7.2.2 INTERFERENCES IN ARC AND SPARK EMISSION SPECTROSCOPY

7.2.2.1 MATRIX EFFECTS AND SAMPLE PREPARATION

The matrix, or main substance, of the sample greatly affects the emission intensity of the trace elements present. For example, the emission intensity from 5 ppm of iron in a sample of pure aluminum may be very different from the intensity of the same 5 ppm of iron in a sample of aluminum-copper alloy. This is because the matrix (i.e., the aluminum or the mix of aluminum and copper) has different properties such as thermal conductivity, crystal structure, and boiling point (or heat of vaporization). The matrix affects the temperature of the plasma and the heat build-up in the electrode, which affect the rate of vaporization of the iron into the electrical discharge. The rate of vaporization into the discharge affects the number of iron atoms excited per unit time, and therefore the emission intensity from the iron. If the iron volatilizes from the sample matrix faster than it does from the matrix of the iron standards used for calibration, a positive error will result. If the iron volatilizes more slowly from the sample than from the iron standards, a negative error will result. There are other causes for this matrix or **interelement effect**, including the physical state of the analyte element. Some elements exist in solid solution in metals, others occur as precipitated elements or compounds in the sample. Some alloys consist of two or more solid phases, and the proportion of these phases will change with how a metal alloy has been treated or worked. The physical state of the analyte in the sample will often affect the emission intensity. The text by Slickers discusses this in detail, especially for metals. Interelement effects result in changes in the slope of the calibration curve. This differs from the effect of spectral interference from an overlapping line. In the case of line overlap, the entire calibration curve is shifted parallel to a calibration curve with no spectral interference; no change in slope occurs.

To minimize this problem, it has been a common practice to convert all samples to a common matrix, especially for arc emission analysis. This may be done by converting the sample to an oxide powder through either wet ashing with oxidizing acid or dry ashing. The sample oxide powder is then mixed with a large excess of a common inert matrix, such as graphite powder. Organic compounds, such as animal tissue, body fluids, plant materials, plastics, paper, and textiles are analyzed in this manner. Metal powders are often oxidized before analysis. Mixing with a matrix powder allows the sample to enter the electrical discharge at a steady rate. It avoids sudden "flares" of emission from the sample, which give rise to erratic results. The common matrix permits the accurate and precise determination of the elements present.

Bulk solid samples must be machined or polished into the correct shape, and this must be done without contaminating the surface from the grinding material or altering the surface composition by polishing out a soft phase, for example. The surface must be cleaned of any lubricant or oil used in the machining process before analysis.

Advances in understanding of the spark and arc sources and improvement in electronics have led to redesign of the sources and spectrometers, so that in modern instruments, structure-induced interelement effects can be minimized by proper choice of excitation and measurement conditions. This has reduced the need for a common matrix and has permitted, in some cases, the use of one "global" calibration curve for multiple materials. If an interelement effect does exist, correction factors can be calculated to compensate for the effect.

7.2.2.2 SPECTRAL INTERFERENCE

There are two types of spectral interference: background interference and line overlap. Background in arc/spark emission can be due to thermal radiation (light emitted by a heated object), emission by molecular or polyatomic species such as CN from atmospheric nitrogen, or the edges of adjacent emission lines reaching the detector. Background from the edges of adjacent emission lines will vary depending on the elements present. In general, the background for atomic lines from an arc source is lower than the background for the same lines in a spark source. Background must be measured as close to the analyte emission line as possible and the analyte intensity corrected for accurate results.

Spectral line overlap is a serious problem with high-temperature excitation sources. Thousands of wavelengths are emitted from metal alloys such as steels and from heavy elements such as molybdenum and tungsten. The resolution of the spectrometer needs to be as high as possible to separate analytical lines of interest. Even with high resolution, spectral overlap will occur. The analyst needs to use published tables of emission lines, such as the MIT wavelength tables (see the bibliography) to choose an analytical line that is not directly overlapped by another element in the sample. For example, Mn has an intense emission line at 293.306 nm; the MIT tables indicate that uranium emits at exactly the same wavelength, so clearly this line cannot be used to measure Mn in uranium or U in manganese. There are five emission lines within \pm 0.008 nm of the Mn 293.306 nm line. None of the lines is from Cu or Al, so this Mn line could be used to measure Mn in copper alloys or Al alloys, but not in U, Th, W, or Ir.

If there is no suitable analytical line free of spectral overlap, corrections can be made for the interfering element, but only if the overlapping element's intensity is less than 10 % of the analyte intensity. Less than 1 % is even better, if possible. Corrections cannot be made if the overlapping line is one of the major elements in the sample (e.g., overlap from an iron line on Cr in a steel sample cannot be corrected mathematically).

7.2.2.3 INTERNAL STANDARD CALIBRATION

Apart from matrix effects, which must be controlled to obtain accurate analyses, such factors as physical packing and the size of particles cause a variation in the quantity of sample vaporized into the discharge from one sample to the next. Instrument drift, slight changes in the source energy, and other system problems can cause variations in intensity from measurement to measurement. Because arc/spark emission spectroscopy is a multielement technique, these problems may be compensated for by using *internal standard calibration*. In this calibration method, described in Chapter 1, the ratio of analyte intensity at its chosen wavelength to the intensity of an internal standard element at its emission wavelength is measured. The intensity ratio is plotted vs. the concentration ratio of analyte to internal standard. The use of the ratio should compensate for some variations if the internal standard element and its wavelength are chosen correctly. If something causes the analyte intensity to increase, the internal standard intensity should also increase and the ratio will remain constant.

For bulk solid samples such as metals and alloys, the easiest way to do this is to choose an emission line of the major matrix element as the internal standard line. For example, an iron emission line would be used in steels, a Cu line in copper alloys, and so on. If the sample is a powder, either the major element can be used or a separate element added to all standards and samples.

The following guidelines are used when choosing an element and wavelength to serve as an internal standard:

- 1. The element used as an internal standard should be similar in properties such as enthalpy of vaporization and ionization energy to the element to be determined.
- 2. The wavelength of the emission line from the internal standard should be *homologous* with the wavelength of the analyte. Homologous means that the lines should behave similarly with respect to excitation. Atomic internal standard lines should be used for atomic analyte lines; ion internal standard lines for ion analyte lines. (The Roman numerals after the wavelengths chosen should be the same. Examples of homologous line pairs for elements in steel are shown in Table 7.7.)

Analyte Line (nm)	Fe II 273.0 nm Internal Std. Line	Fe I 281.3 nm Internal Std. Line		
Mn II 293.3	×			
Cr II 298.9	×			
Ni II 376.9	×			
Mo II 281.6	×			
Si I 251.6		×		
Ni I 352.4		×		

Source: Adapted from Thomsen, with permission of ASM International*.
Note: The Roman numerals denote the type of line (atomic, ionic), not the valence state.

- 3. The concentration of the internal standard added should be similar to that of the analyte measured.
- 4. For spectrometers with more than one polychromator, the internal standard line and analytical line must be measured on the same polychromator.

The guidelines should be adhered to as far as possible to obtain the best accuracy. It is often not possible to meet all of the guidelines with one internal standard element. For example, if the analyst is required to measure 23 trace elements in a given sample, including transition metals, rare earth elements, nonmetals such as B, S, P, and refractory metals such as Nb, W, and Zr, it is not likely that one element chosen as an internal standard will meet all of the guidelines. More than one internal standard element may be added or more than one matrix wavelength chosen, but the possibility of spectral interference must be kept in mind. The more elements present, the more emission lines there will be and the greater the possibility of spectral overlap.

7.2.3 APPLICATIONS OF ARC AND SPARK EMISSION SPECTROSCOPY

7.2.3.1 QUALITATIVE ANALYSIS

Qualitative analysis is performed by recording the emission spectrum of the sample. The sample elements are then identified by comparing their emission spectra with previously recorded spectra from known elements. Examples of some elemental emission spectra are given in Figure 7.19. Generally, for trace amounts, the *raies ultimes*, or *RU lines*, must be present and identified in the emission spectra as discussed below. For higher concentrations, the RU lines are present together with many other emission lines. The emission spectra encountered in arc and spark spectroscopy are rich and intense for most elements in the periodic table, in contrast to those observed in flame photometry. As a result, these techniques are widely used in elemental qualitative analysis of solid samples. Most elements can be detected at low concentrations (ppm or ppb) with a high degree of confidence. In practice, emission spectra are now "matched" to identify the elements present using a computer database of emission lines contained in the instrument software.

7.2.3.2 RAIES ULTIMES

When an element is excited in an electrical discharge, it emits a complex spectrum that consists of many lines, some strong, some weak. When the concentration of the element is decreased, the weaker lines disappear. Upon continuing dilution of the element, more and more lines disappear until only a few are visible. The final lines that remain are called the raies ultimes or RU lines, although this term is not used in many modern publications. The RU lines are the most intense emission lines and invariably involve an electronic transition




FIGURE 7.19 (a) Atomic emission spectra of four elements from low to high atomic numbers. (b) High-resolution emission spectrum of hydrogen. (c) High-resolution spectrum of iron.

from an excited state to the ground state. These lines can be detected even when small concentrations of the element are present. Conversely, if the element is present in a sample, whatever other spectral lines are emitted from the sample, the RU lines should always be detectable. Some elements and their RU lines are listed in Table 7.8. Generally, for confirmation of the presence of a trace amount of a given element, two or three raies ultimes should be detected. Confirmation based on a single RU line is unreliable because of the possibility of spectral interference from other elements.

Because the plasma is not uniform in temperature throughout the discharge, there will be unexcited atoms of the analyte element in the cooler regions of discharge. These free atoms absorb radiation at the same wavelength as the emitted RU lines from other excited atoms of the same element since they involve the same transition. The greater the concentration of a given element, the greater the number of free atoms in the discharge. As a result, such emission lines are reabsorbed by neighboring unexcited atoms in a process called self-absorption or self-reversal. The result is seen as curvature in the emission calibration curve for the element at high concentrations. If the concentration is high enough, the self-absorption is so effective that the net emission intensity actually decreases as shown in Figure 7.20 for the beryllium 313.11 nm line, an RU line. A plot of emission intensity against concentration will go through a maximum and then decrease. The intensity therefore "reverses" at higher concentrations. Such lines are said to be reversible lines. They cannot be used for quantitative analysis at higher concentrations, but they are useful for measuring very small concentrations, where reversal is not a problem. In fact, these lines are usually the most sensitive; the Be 313 nm line can be used for determining ppb levels of Be, a highly toxic element, in biological samples. Ion lines do not suffer from self-reversal, because the ion energy states are not the same as the atomic energy states.

TABLE 7.8 RU Lines of Some Common Elements

Element	Wavelength of RU Lines (nm)	Element	Wavelength of RU Lines (nm)	Element	Wavelength of RU Lines (nm)
Ag	328.07	Co	344.36	Мо	379.63
	520.91		240.73		386.41
Al	396.15	Cr	399.86	Na	589.59
	394.40		425.43		568.8
As	193.76	Cs	852.11	Ni	341.48
	189.04		894.35		352.45
	286.04	Cu	324.75	Р	253.57
Au	242.80		327.40		255.33
	267.60	Fe	385.99	Pb	405.78
В	249.77		371.99		368.35
	249.68	Ge	265.12	Pt	265.95
Ва	265.05		303.90		292.98
	553.55	Hg	185.0	Se	196.03
Be	234.86		253.65		206.28
	313.11		435.84		203.99
Bi	306.77	K	766.49	Si	288.16
	289.80		769.90		251.61
C	193.09	La	624.99	Sn	286.33
	247.86		579.13		284.00
Ca	422.67	Li	670.78	Sr	460.73
	445.48		610.36		483.21
Cd	228.80	Mg	285.21	Ti	498.18
	326.11		383.83		399.86
Ce	569.92	Mn	403.08	V	318.40
	404.0		403.31		437.92




FIGURE 7.20 A plot of emission intensity vs. %Be at the 313.11 nm Be line. This is a reversible line for Be. Note that the emission intensity reaches a maximum and then decreases as the Be concentration increases. Such lines cannot be used for high concentrations of analyte but are excellent for low concentrations. (Modified from Thomsen, used with permission from ASM International*.)

7.2.3.3 QUANTITATIVE ANALYSIS

Quantitative analysis is carried out by measuring the intensity of one emission line of the spectrum of each element to be determined. The choice of the line to be measured depends on the expected concentration of the element to be determined and the sample matrix.

When a sample is introduced into an electrical discharge, there is a time lag before the emission signal becomes steady. In the first few seconds of discharge, the intensity of emission is erratic and difficult to control. In order to obtain reproducible quantitative results, the signal is not recorded until it is stable. This period is called the pre-burn time. The term used for modern spark instruments is high-energy pre-spark (HEPS) and is usually set for 10-20 s. In modern DC arc systems, the pre-burn is performed under conditions of reverse polarity for about 60 s. A pre-burn time is always used if accurate results are required. The pre-burn time is set in the software and performed automatically.

The relative accuracy and precision obtained by arc and spark emission spectroscopy is commonly about 5 %, but may be as poor as 20-30 %. Arc emission is much more prone to matrix effects than spark emission due to the lower temperature of the discharge. Both arc and spark excitation may require matrix matching of sample and standards for accurate analyses, and usually require the use of an internal standard.

In practice, the sample is excited in the electrical discharge. Intensities of emission lines are measured using the detector(s) in the spectrometer and concentrations of elements are determined by comparison to the intensities obtained from standard calibration curves. Certified metal alloy standards in flat polished forms and bulk solid pieces are available from government organizations such as the US NIST and from private standards companies. It is possible to purchase sets of solid steel standards, brass standards, nickel alloy standards, and so on for use as calibration standards and quality control check samples. High-purity metal powders are available from commercial suppliers as well. The accuracy of the analysis will be only as good as the accuracy of the standards used for calibration of the instrument. The simultaneous determination of the elements present in a sample can be carried out in a minute or less.

Emission spectroscopy with arc and spark excitation has been used since the 1930s for many industrial analyses. In metallurgy, for example, the presence in iron and steel of the elements nickel, chromium, silicon, manganese, molybdenum, copper, aluminum, arsenic, tin, cobalt, vanadium, lead, titanium, phosphorus, and bismuth have been determined on a routine basis. Modern instruments can also measure oxygen, nitrogen, and carbon in metals. Frequently the analysis can be carried out with very little sample preparation, apart from physically shaping the sample to fit in the discharge unit. Alloys of aluminum, magnesium, zinc, and copper (including brass and bronze), lead and tin alloys (including solders), titanium alloys, high-purity metals such as gold, platinum, palladium, and many others are routinely analyzed during production by arc and spark spectrometry. Alloy identification for metal scrap sorting and recycling has become so important that portable, handheld spark emission spectrometers have been developed. These units are battery operated, and contain a built-in computer database of alloy compositions, so that a metal recycling facility can immediately separate aluminum alloys from nickel alloys, for example, even when the metal pieces are out in a field or as they are unloaded from a truck.

Production and quality control of uranium fuel rods used in nuclear power plants are monitored by DC arc emission spectroscopy. Trace elements in high-purity metal powders are measured for quality control purposes. Tungsten powder can be analyzed for trace elements by arc/spark emission spectroscopy without the need to dissolve the tungsten; this eliminates the use of expensive and hazardous hydrofluoric acid.

In the oil industry, lubricating oils can be analyzed for iron, nickel, chromium, manganese, iron, silicon, copper, aluminum, and other elements. These metals get into the lubricant when bearings and pistons wear. Such analyses give the engine designer valuable information on the parts of the system that are likely to fail or need protection from wear and corrosion. The information is used in aircraft and railway engine maintenance to warn of bearing wear in the engine. The bearings may be replaced based on lube oil analysis rather than taking the engine apart for physical inspection, which is a long and expensive procedure. Oil feed stocks

to petroleum refinery catalytic cracking units are analyzed for iron, nickel, and vanadium, which can poison the catalyst and interfere in the production of the branched hydrocarbons desired in fuel.

7.3 PLASMA EMISSION SPECTROSCOPY

A *plasma* is a form of matter that contains a significant percentage (>1 %) of electrons and ions in addition to neutral species and radicals. Plasmas are electrically conductive and are affected by a magnetic field. The plasmas used in emission spectroscopy are highly energetic, ionized inert gases. The most common plasma in commercial use is the argon inductively coupled plasma (ICP). Other commercial plasma sources include the recently introduced nitrogen microwave plasma (MP), and the helium microwave induced plasma (MIP). The temperature of a plasma excitation source is very high, from 6500 to 10,000 K, so almost all elements are atomized or ionized and excited to multiple levels. The resulting emission spectra are very line-rich, which necessitates the use of high-resolution spectrometers to avoid spectral overlap.

7.3.1 INSTRUMENTATION FOR PLASMA EMISSION SPECTROMETRY

7.3.1.1 EXCITATION SOURCES

RF ICP Source. In ICP-OES, the sample is usually introduced to the instrument as a stream of liquid. The sample solution is nebulized and the aerosol transported to the plasma. In the plasma, the sample undergoes the same process outlined in Table 7.2. The argon plasma serves to atomize, ionize, and excite the elements in the sample. The emitted radiation is sorted by wavelength in a spectrometer and the intensity is measured at each wavelength. A schematic of a typical ICP-OES system is presented in Figure 7.21.

In Figure 7.21, the argon plasma is the flame-like object at the top of the ICP torch, above the coils (the dark lines) from the radiofrequency (RF) generator. Figure 7.22 depicts a cross-section of a typical ICP torch. This torch contains three concentric tubes for argon flow and sample aerosol introduction. The two outer tubes are normally made of quartz.




FIGURE 7.21 Major components and layout of a typical ICP-OES instrument. (© 1999-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)




FIGURE 7.22 Cross-section of an ICP torch. The emission is viewed in the region above the coils when the torch is in a radial position.

The inner tube, called the injector tube, may be made of quartz, alumina, sapphire, or other ceramic. Surrounding the torch is a water-cooled copper load coil or induction coil, which acts as an antenna to transmit power to the plasma gas from the RF generator. The power required to generate and sustain an argon plasma ranges from 700 to 1500 W. RF generators on some commercial instruments operate at 27.12 MHz; many instruments operate at 40.68 MHz, which results in better coupling efficiency and lower background emission intensity. The plasma initiation sequence is depicted in Figure 7.23. When RF power is applied to the load coil, an alternating current oscillates within the coil at the frequency of the generator. The oscillating electric field induces an oscillating magnetic field around the coil. Argon is swirled through the torch and slightly ionized using a Tesla coil. The few ions and electrons formed are immediately affected by the magnetic field. Their translational motion changes rapidly from one direction to the other, oscillating at the same frequency as the RF generator. The rapid movement in alternating directions is induced energy; adding energy in this manner is called inductive coupling. The high-energy electrons and ions collide with other argon atoms and cause more ionization. This continues in a rapid chain reaction to convert the argon gas into a plasma of argon ions, free electrons, and neutral argon atoms.

The ICP torch is designed with narrow spacing between the two outermost tubes, so that the gas emerges at a high velocity. The outer tube is designed so that the argon flow in this tube, called the plasma flow, follows a tangential path as shown in Figure 7.22. This flow keeps the quartz tube walls cool and centers the plasma. A typical flow rate for the plasma




FIGURE 7.23 Cross-section of an ICP torch and the load coil depicting an ignition sequence. **(a)** Argon gas is swirled through the torch. **(b)** RF power is applied to the load coil. **(c)** A spark produces some free electrons in the argon. **(d)** The free electrons are accelerated by the RF field causing more ionization and formation of a plasma. **(e)** The nebulizer flow carries sample aerosol into the plasma. **(©)** 1999-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

flow is 7-15 L argon/min. The argon flow in the middle channel is called the auxiliary flow and can be 0-3 L argon/min. The auxiliary gas flow serves several purposes, including that of reducing carbon deposits at the injector tip when organic solvents are being analyzed. The gas flow that carries the sample aerosol into the plasma goes through the center or injector tube. It is called the nebulizer flow or sample flow and is typically about 1 L/min. The tangential or radial flow spins the argon to create a toroidal or doughnut-shaped region at the base of the plasma through which the sample aerosol passes. The temperatures for various regions of the plasma are shown in Figure 7.24(a). Immediately above the load coil, the background emission is extremely high. The background signal drops with distance from the load coil, and emission is usually measured slightly above the load coil, where the optimum signal-to-background ratio is achieved. This area is called the "normal analytical zone" in a radially-viewed plasma, shown in Figure 7.24(b). An ICP torch in operation is shown in Figure 7.25.

The advantage of the argon ICP as an excitation source lies in its high temperature and its stability. The gas temperature in the center of the plasma is about 6800 K, which permits the efficient atomization, ionization, and excitation of most elements in a wide range of samples. In addition, the high temperature reduces or eliminates many of the chemical interferences found in lower temperature electrical sources and flames, making the ICP relatively free from matrix effects. Another important advantage of the ICP is that the sample aerosol is




FIGURE 7.24 (a) Temperature regions in a typical argon ICP discharge. **(b)** Zones of the ICP discharge. IR, induction region; PHZ, preheating zone; IRZ, initial radiation zone; NAZ, normal analytical zone. (© 1999-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)



FIGURE 7.25 Argon ICP torch in operation. The analytical zone is the blue region above the coils. Compare with Figure 7.24. (Courtesy of SPECTRO, a unit of the materials analysis division of AMETEK, Inc., www.spectro.com. Used with permission.)

introduced through the center of the plasma and is exposed to the high temperature of the plasma for several milliseconds, longer than in other excitation sources; this contributes to the elimination of matrix effects. Elements are atomized and excited simultaneously. The stability of the ICP discharge is much better than arc or spark discharges, and precision of less than 1 %RSD is easily achieved. The dynamic range of an ICP source is approximately four to six orders of magnitude. It is often possible to measure major, minor, and trace elements in a single solution with an ICP source. Many ICP systems permit the injection of air or oxygen into the plasma when running organics, to prevent carbon buildup and reduce background.

MP Source. In 2011, Agilent Technologies, Inc. introduced a unique excitation source for atomic emission spectrometry. The 4100-MP-AES uses a magnetically-excited nitrogen microwave plasma [Figure 7.26(a)]. The instrument uses an industrial magnetron, similar to that used in kitchen microwave ovens; its magnetic field couples the microwave energy into the plasma. The magnetron is air-cooled and operates at 2450 MHz. It creates a concentrated axial magnetic field around a conventional torch and produces a toroidal plasma. The plasma is ignited using a brief flow of Ar, and then automatically switches to nitrogen, either from a cylinder, Dewar (liquid N_2), or produced from air by a nitrogen generator. An external gas control module allows for injection of air into the plasma when analyzing organics to prevent carbon buildup and reduce background.

MIP Source. An atmospheric pressure helium MIP is generated using a 2.45 GHz microwave generator and an electromagnetic cavity resonator, called a Beenakker cavity. The helium gas is passed through a discharge tube placed in the cavity, as seen in Figure 7.26b. The plasma is initiated by a spark from a Tesla coil. The electrons produced by the spark oscillate in the microwave field and ionize the helium gas by collision, producing a plasma. The microwave energy is coupled to the gas stream in the discharge tube by the external cavity. The plasma is centered in the discharge tube, and is represented in Figure 7.25(b) by the shaded spheroid shape.

The MIP operates at lower power than the ICP and at microwave frequencies instead of the radiofrequencies used for ICP. Because of the low power, an MIP cannot desolvate and atomize liquid samples. Therefore, MIPs have been limited to the analysis of gaseous samples or very fine (1-20 μ m diameter) particles. Helium is the usual plasma gas for an MIP source. Electronic excitation temperatures in a helium MIP are on the order of 4000 K, permitting the excitation of the halogens, C, N, H, O, and other elements that cannot be excited in a flame atomizer. The lower temperature results in less spectral interference from direct line overlap than in ICP or high-energy sources, but also causes more chemical interference.

A helium MIP has been used as an element-specific detector for gas chromatography (GC), discussed in Chapter 11. This detector is shown in Figure 7.26(c). The effluent from the GC column consists of carrier gas and separated gas-phase chemical compounds. The separated compounds flow through the plasma contained in the discharge tube shown. A compound in the plasma is decomposed, atomized, excited, and emits the wavelengths characteristic of the elements present. The light from the plasma is sent to a grating monochromator with a PDA detector, as shown. Graphite furnaces, hydride generation instruments, and other devices have been used to generate gas-phase samples or desolvated particles for introduction into MIPs.

7.3.1.2 SPECTROMETER SYSTEMS FOR PLASMA SPECTROSCOPY

Spectrometer systems for ICP include all of the dispersive devices and designs discussed in Chapter 2 and earlier in this chapter. Scanning monochromators of all optical designs are used in *sequential* spectrometer systems. In a sequential instrument, one wavelength at a time is measured, and the grating must be moved if more than one element is to be determined. Scanning rates can be very rapid in commercial instruments, but sequential instruments are slower than *simultaneous* spectrometers. Simultaneous systems contain either a polychromator or an Echelle spectrometer, and measure multiple wavelengths at the same time as has been described for arc/spark instruments. *Combination instruments* are available, with both polychromators and a monochromator, to take advantage of the speed of the simultaneous system for routine work, but to have the flexibility of the sequential system if a




FIGURE 7.26 (a) The 4100-MP-AED nitrogen-based atomic emission spectrometer. [Copyright Agilent Technologies, Inc., www.agilent.com/runsonair. **(b)** A helium MIP. (Courtesy of Yokogawa Electric Company, Japan.) **(c)** Atomic emission detector for GC using a helium MIP as the excitation source. It uses a scanning diffraction grating spectrometer and PDA detector to measure atomic emission from samples excited in the MIP. The wavelength range covered is 171–837 nm. (Courtesy of Joint Analytical Systems GmbH, Moers, Germany [www.jas.de].)

PMT PMT PMT VIS-NIR Spectrometer Mirror Diffraction grating VIS-NIR Spectrometer Mirror Sequential spectrometer (Monochromator)

FIGURE 7.27 A combination sequential-simultaneous ICP emission spectrometer. Such a combination permits rapid multielement analysis using the polychromator and preselected wavelengths. The monochromator adds the flexibility to monitor additional elements or alternate wavelengths in case of spectral interferences. (Courtesy of Horiba Scientific. © 2020 HORIBA Scientific [www.horiba.com/scientific]. All rights reserved.)

nonroutine wavelength needs to be accessed. An example of the optical layout of a combination instrument is shown in Figure 7.27.

The detectors used in ICP systems include PMTs, CCDs, and CIDs. One variation of the CCD used for ICP is the segmented array CCD or SCD. The SCD has individual small subarrays positioned on a silicon substrate in a pattern that conforms to the echellogram pattern (Figure 7.28). More than 200 subarrays are used; they cover approximately 236 of the most important wavelengths for the 70 elements routinely measured by ICP emission spectrometry. The SCD differs from a standard CCD in that the individual subarrays can be rapidly interrogated in random order (much like a CID). The SCD detector responds from 160 to 782 nm.




FIGURE 7.28 SCD detector. (© 1999-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)




FIGURE 7.29 Axial (end-on) ICP torch position showing how the shear gas cuts off the cool plasma tail plume. Light emitted from the plasma passes through the ceramic interface into the spectrometer on the right side of the diagram (not shown). (© 1999-2020 PerkinElmer, Inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

The ICP source had traditionally been viewed from the side of the plasma, as shown in Figure 7.21. This configuration is called "radial viewing". However, looking along the plasma axis instead of across the diameter provides a longer optical path length and that results in lower detection limits. Unfortunately, the longer optical path includes more temperature zones, so more chemical interference can result. Radial viewing was chosen to avoid the problems of increased spectral interference, matrix interferences, and self-absorption in the cooler tip of the plasma that would result from axial viewing. Axial viewing of the plasma does, however, provide improved detection limits for many elements. Axial or end-on viewing of the plasma was made practical by use of a flow of argon, called the shear gas, to cut off the cool tip of the plasma, as shown in Figure 7.29. This reduces self-absorption and matrix or chemical interferences. There are commercial ICP systems available with only radial viewing, with only axial viewing, with simultaneous radial and axial viewing (dual view) and with the ability to flip the torch into either radial or axial position. A comparison of axial and radial detection limits for some elements on a specific instrument, as well as a comparison of various nebulizers is presented in Table 7.9.

In the 4100 MP-AES instrument (Agilent Technologies), the detector is a UV-sensitive solid-state CCD detector, cooled to 0 $^{\circ}$ C using a thermoelectric Peltier device and provides simultaneous background and interference correction. The spectrometer is a fast scanning, high-resolution sequential Czerny-Turner design which can be purged with air or nitrogen. The wavelength range is 178–780 nm. The plasma is vertically oriented but viewed end-on (axially) by using a 25 L/min flow of compressed air to protect the pre-optics.

7.3.1.3 SAMPLE INTRODUCTION SYSTEMS

Liquids are the most common form of sample to be analyzed by plasma emission. These are usually introduced with a nebulizer and spray chamber combination. An aerosol is formed and introduced into the plasma by the nebulizer gas stream through the injector tube. Nebulizers and spray chambers come in a variety of designs to handle aqueous solutions, high salt (high total dissolved solids) solutions, HF-containing solutions, and organic solvents.

There are sample introduction systems that can handle slurries of particles suspended in liquids. Powders can be injected directly into the plasma for analysis. Lasers, sparks, and graphite furnaces (exactly the same as AAS graphite furnaces) are used to generate gaseous samples from solids for introduction into the plasma. Hydride generation for As and Se and cold-vapor Hg introduction are used for ICP as for AAS; these two techniques were discussed in Chapter 6.




FIGURE 7.31 (a) A cross-flow nebulizer, with a close-up of the nebulizer tips. (b) A V-groove nebulizer. (© 1999-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

The *cross-flow nebulizer* uses a high-speed gas flow perpendicular to the sample flow capillary tip, as shown in Figure 7.31(a), to form the aerosol. Droplets formed by cross-flow nebulizers are larger than those from concentric nebulizers, so the cross-flow nebulizer is not as efficient. However, the sample capillary is a larger diameter and this minimizes clogging of the nebulizer by salt deposits. The cross-flow nebulizer has an inert polymer body and sapphire and ruby tips on the capillaries; it is more rugged and chemically resistant than a glass nebulizer.

The *Babington nebulizer* was originally developed to aspirate fuel oil. A variation of the Babington nebulizer, called a *V-groove nebulizer*, is commonly used for ICP sample introduction. A V-groove nebulizer is shown in Figure 7.31(b). The liquid sample flows down a smooth-surfaced groove in which there is a small hole. The high flow of gas from the hole shears the film of liquid into small drops. This nebulizer is the least prone to clogging and is used for viscous solutions, high salt solutions, and can be made of polymer for use with HF solutions.

Microconcentric nebulizers have been developed that put solution directly in the ICP torch sample capillary, thereby eliminating the need for a spray chamber. These nebulizers, also called direct insertion nebulizers (DIN), can be used for very small (microliter) sample volumes and for direct coupling of liquid chromatographs to the ICP as an element-specific detector.

Ultrasonic nebulizers (USN) operate by having the liquid sample pumped onto an oscillating quartz plate. The frequency of oscillation of the quartz plate for a commercial USN is 1.4 MHz, for example. The rapid oscillations of the quartz plate break the liquid film into an aerosol. This aerosol is of very fine, uniform droplets, unlike the aerosol from a pneumatic nebulizer. The fine aerosol contains a significant amount of solvent that must be removed before the aerosol reaches the plasma. The aerosol flows through a desolvation unit consisting




FIGURE 7.32 Schematic of a commercial USN, the CETACU-5000AT + and desolvation system. (Courtesy of CETAC Technologies, Omaha, NE [www.cetac.com].)

of a heated section to vaporize the solvent and then a chiller to condense the solvent so that a dry aerosol reaches the plasma. The efficiency of an ultrasonic nebulizer is 5-10 times greater than that of a pneumatic nebulizer. This results in improved sensitivities and better detection limits because more sample reaches the plasma. USNs have good stability, but are prone to carry-over or memory effects from one sample to the next. Carry-over is caused by one sample not being washed out of the nebulizer completely before the next sample is introduced. It is often related to the ease of adsorption of certain elements on nebulizer surfaces and is a problem if the concentrations of analyte in samples vary from trace to major. USNs cannot handle high total dissolved solids solutions and are not HF-resistant. They are very good at removing solvent from the sample before it reaches the plasma. Organic solvents can present problems in analysis by ICP because they tend to extinguish the plasma. Also, molecular species and radicals emit broad-band spectra, which give rise to high background radiation. The USN removes the solvent by cryogenic trapping in the chiller. A commercial USN is shown schematically in Figure 7.32. Comparative DLs for some elements determined using this nebulizer are presented in Table 7.9.

Spray chambers. Pneumatic nebulizers generally require a spray chamber placed in between the nebulizer and the plasma. The spray chamber is designed to remove large droplets from the aerosol, because large droplets are not efficiently desolvated, atomized, and excited. In addition, the spray chamber smoothes out pulsations in the aerosol flow that arise from the pumping action of the peristaltic pump. Droplets with diameters of 10 µm or less generally pass through the spray chamber to the plasma. Only about 5 % of the sample solution makes it into the plasma; the rest is drained to waste. The spray chamber shown in Figure 7.21 is a Scott double-pass spray chamber. New more efficient cyclonic spray chambers are now available. The spray chamber can be made of glass or inert polymer depending on the application. Water-cooled spray chambers may be used for volatile organic solvents, to decrease the amount of solvent vapor entering the plasma. Figure 7.33(a) shows the individual parts needed for aqueous liquid sample introduction. A three-part demountable torch of quartz is shown, with a Tracey cyclonic spray chamber and a glass concentric nebulizer. Figure 7.33(b) shows the components assembled for use. The fittings are for argon gas connection to provide the auxiliary and plasma gas flows. The demountable quartz torch parts are held in a polymer torch body. Other torch designs are constructed in a single piece, but still require a nebulizer and spray chamber.




FIGURE 7.33 (a) The components of a liquid sample introduction system for ICP: glass concentric nebulizer, demountable three-piece quartz torch, torch body, and glass cyclonic spray chamber. **(b)** The components assembled for use. This torch design is typical of that used in Horiba Scientific ICP instruments. (Courtesy of Glass Expansion Pty, Ltd., Australia [www.geicp.com].)

Solid sampling systems. The direct analysis of solid materials is the goal of every analyst who must deal with solid samples. Dissolution of solid samples is time consuming and error prone. There have been devices designed by researchers to place solid samples directly into the argon plasma of an ICP for analysis, but these have not been commercialized with the exception of the slurry nebulizer. A slurry is a suspension of fine particles in liquid. Samples that are powders or can be finely ground into powder can be suspended in water or an organic solvent and aspirated directly into the plasma. Slurry nebulizers are available in both concentric and V-groove types. Two of these available from Glass Expansion Pty. Ltd. (www.geicp.com) are the Slurry concentric nebulizer for analysis of samples with particles up to 150 μ m in diameter and the VeeSpray nebulizer, a V-groove type in either quartz or HF-resistant ceramic that can handle particulates up to 300 μ m in diameter. Slurry introduction is used for analysis of suspensions of cement powder and milk powder, for example.

The other commercial solid sampling systems all vaporize a portion of the solid sample first; the vapor or fine particulate is transported to the plasma where it is atomized and excited. The three techniques commercially available for solid sampling are electrothermal vaporization (ETV), spark ablation, and laser ablation. The advantage of separating the sampling step (using the ETV, spark or laser) from the atomization and excitation step (in the ICP) is that each process can be optimized and controlled separately. The disadvantage of direct solid sampling is calibration of the system to achieve quantitative results. It is often necessary to purchase a series of well-characterized solids similar to the sample matrix as standards; stainless steel alloys for stainless steel samples, nickel alloys for nickel alloy samples, certified glass standards for glass samples, and so on. There are limits as to the kinds of certified solid reference materials available and they are generally very costly.

ETV. ETV techniques adapted from graphite furnace AAS have been successfully applied as a means of introducing the vapor from a solid sample into plasma. The technique is particularly useful for organic matrices such as polymers and biological tissues since it eliminates

the need to digest the sample. The electrothermal vaporizer follows the same type of temperature program used in AAS, drying, ashing, and "atomizing" the sample in sequence, although in this case, vaporization is really all that needs to be accomplished since the ICP also serves as an atomizer. The vapor formed is swept into the ICP by a flow of gas, where it is atomized and excited. The method can be used with small volume liquid samples and solid samples. About 10-15 μL of liquid or a few milligrams of solid sample or slurry can be analyzed in this fashion. Detection limits for electrothermal vaporization-ICP-OES are given in Table 7.7.A.2, Appendix 7.A (textbook website). The same table compares GFAAS detection limits and the use of ETV with ICP-MS. The ICP-MS instrumentation will be discussed in Chapter 9.

Spark ablation. Spark ablation solid sampling uses the same type of spark source already described. The function of the spark in this case is to vaporize the solid sample; the ICP plasma can atomize any nonatomic vapor reaching it. Spark ablation is limited to the analysis of solids that conduct electricity. It is very useful for metals and alloys because it eliminates time-consuming sample dissolution and costly high-purity acids.

Laser ablation. Another technique for direct sampling of solids is laser ablation. A highenergy laser beam is directed at the solid sample. The photon energy is converted to thermal energy on interaction with the sample. This thermal energy vaporizes surface material and the vaporized material is swept into the plasma. Lasers can vaporize most types of solid surfaces, not just conductive materials, so laser ablation can be used to sample metals, glass, ceramics, polymers, minerals, and other materials. The sample does not have to be of any particular shape or size, as long as it fits into the sample chamber and a flat polished surface is not required. Laser beams can be focused to small spot sizes, so microscopic inclusions in a surface can be analyzed. The laser beam can be moved across the surface (a process called "rastering") for bulk analysis of a material. The laser beam can be focused on one position on the sample and the emission signals measured as material is vaporized from deeper and deeper below the surface, creating a *depth profile* of the sample composition. A depth profile is useful for the analysis of coatings on surfaces and multilayered composite materials, for example. Gas-filled excimer lasers such as XeCl and ArF, which emit in the UV region, can be used for laser ablation, but excimer lasers are costly and complex. Recent advances in solid-state laser design have resulted in a commercial Nd:YAG solid-state laser. This solidstate laser can be operated at its primary wavelength, 1064 nm, which is in the IR region, or can be frequency doubled or quadrupled to make lasers that operate at 532 or 266 nm. The UV solid-state laser shows efficient coupling of energy with most types of materials, high sensitivity, good precision, and controlled ablation characteristics. With ICP-OES, the laser ablation technique is used primarily for bulk analysis of solid samples, although depth profiling of materials is possible. The analysis of inclusions, multilayered materials, and microscopic phases in solids is often done by laser ablation and the more sensitive technique of ICP-MS (Chapter 9). A schematic of a commercial UV Nd:YAG laser system for laser ablation is shown in Figure 7.34.

7.3.2 CALIBRATION AND INTERFERENCES IN PLASMA EMISSION SPECTROMETRY

Calibration is achieved by the same techniques described in Chapter 1: external calibration with standard solutions or MSA. Plasma emission does not suffer from significant chemical interference because of the high temperatures achieved in the plasma, but it is good practice to matrix-match the standard solutions and calibration blank to the samples to be analyzed. Matrix-matching can correct for differences in viscosity and suppression or enhancement of analyte signal due to interelement effects. Matrix-matching enables accurate background corrections to be made. The same solvent should be used in standards and samples, the same concentration of acid, and when possible, the same major chemical species in solution. For example, in the analysis of tungsten metal for trace elements, if the sample solutions contain 100 mg of tungsten, the standards and calibration blank should contain 100 mg of high-purity tungsten. Standards for the analysis of steels should contain the appropriate amount of high purity iron, and so on.




FIGURE 7.34 A commercial laser ablation system for solid samples, the CETAC technologies LSX-500. (Courtesy of Teledyne CETAC Technologies, Omaha, NE [www.cetac.com].)

Most samples for analysis by plasma emission spectrometry are dissolved in acids, because metal elements are more soluble in acids. The acidic nature of the solution prevents elements from adsorbing onto the surface of the glassware. Some bases, such as tetramethyl ammonium hydroxide (TMAH), are used to prepare solutions but care needs to be taken to avoid the formation of insoluble metal hydroxides. Organic solvents may be used to dissolve organometallic compounds directly or to extract chelated metals from aqueous solution into the solvent as part of separation and preconcentration steps in sample preparation.

Calibration standards are made by dissolving very high-purity elements or compounds accurately in aqueous acid solution. In general, a concentrated stock standard is prepared, and then serially diluted to prepare the working calibration standards. Many vendors supply 1000 or 10,000 ppm single element standards in aqueous acidic solution, with certified concentration values. One new product recently introduced is a series of stable 1 ppm stock solutions from SPEX CertiPrep (www.spexcertiprep.com). As instrument detection limits continue to improve, less dilution is needed from a 1 ppm stock than from a 1000 ppm stock to make working standards. It is easier, more accurate, and more efficient to purchase these stock solutions from a high-quality supplier than to make them from scratch. Because emission is a multielement technique, the analyst combines single element standards to make the necessary working standings that contain all of the analytes of interest. If the same set of multielement standards is used routinely, these can be ordered from the standards vendors. Multielement solutions for environmental analyses are stocked by vendors, for example. Custom mixtures can be ordered for routine analyses in industry.

For most analyses, standard solutions are aqueous solutions containing several percent of a mineral acid such as HCl or nitric acid. When mixing different elements in acids, it is important to remember basic chemistry and solubility rules for inorganic compounds. The elements must be compatible with each other and soluble in the acid used so that no precipitation reactions occur. Such reactions would change the solution concentration of the elements involved in the reaction and make the standard useless. Combinations to be avoided are silver and HCl, barium, and sulfuric acid, and similar combinations that result in insoluble precipitates. The use of certain reagents, such as HF or strong bases, can etch glass and contaminate solutions prepared in glass with Si, B, and Na. HF is required to keep certain elements such as tungsten and silicon in solution, so the analyst needs to be aware that purchased stock solutions of these types of elements contain small amounts of HF that can etch glassware and nebulizers.

Because emission is inherently a multielement technique, accuracy and precision can be improved through the use of an *internal standard*. The internal standard is an element that is not present is the samples, is soluble in the sample and standard solutions, and that does not emit at a wavelength that interferes with the analyte emission lines. Ideally, the internal standard element should behave similarly to the analyte in the plasma; matching the ionization energies of the analyte and internal standard is a good approach. The use of internal standard ion lines to match analyte ion lines and internal standard atom lines to match analyte atom lines is also a good practice. In a multielement analysis, it may be necessary to use more than one internal standard element to achieve this "ideal" behavior. The internal standard element is added in the same concentration to all blanks, standards, and samples. The emission intensities of the analyte elements and the internal standard element are measured. The calibration curve is plotted as described in Chapter 1. Use of the ratio of intensities corrects for instrument drift, sample uptake rate changes, and other instrumental sources of error. Use of an internal standard does not correct for background interferences or spectral interferences.

7.3.2.1 CHEMICAL AND IONIZATION INTERFERENCE

Chemical interferences are rare in plasma emission spectroscopy because of the efficiency of atomization in the high-temperature plasma. For example, in flame AAS, there is a severe suppression of the calcium signal in samples containing high amounts of Al, as seen in Figure 7.35. The same figure shows the lack of chemical interference in the ICP emission signal for Ca in solutions containing Al up to very high Al/Ca ratios. In the few cases where chemical interference is found to occur, increasing the RF power to the plasma and optimizing the Ar flow rates usually eliminates the problem.

The alkali metals Li, Na, and K are easily ionized in flames and plasmas. Concentrations of an easily ionized element (EIE) greater than 1000 ppm in solution can result in suppression or enhancement of the signals from other analytes. The EIE effect is wavelength dependent;




FIGURE 7.35 A comparison of the chemical interference effect of Al on the determination of Ca by flame AAS and ICP-OES. The flame AAS signal for Ca is severely depressed by increases in the Al/Ca ratio, while the emission signal from the high-temperature plasma is not significantly affected. (© 1999-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

ion lines are affected differently than atom lines. The EIE effect can be minimized by optimizing the RF power and plasma conditions, by matrix-matching, by choosing a different wavelength that is not subject to the EIE effect, or by application of mathematical correction factors.

7.3.2.2 SPECTRAL INTERFERENCE AND CORRECTION

Spectral interference is much more common in plasmas than in flames due to the great efficiency of excitation in plasmas. Elements such as Fe, Mn, Ta, Mo, W, and U emit thousands of lines in a plasma source. Ideally, the analyte wavelength chosen should have no interference from other emission lines, but this is often not possible.

The most common type of spectral interference is a shift in the background emission intensity between samples and standards. Figure 7.36 shows a background shift that is a constant broad emission, from a solution containing 1000 ppm Al, measured at the tungsten 207.911 nm emission line. The tungsten emission spectrum shown is from an aqueous acidic solution containing no Al. The signal intensity increases from bottom to top in the figure. The spectral window being examined is 0.25 nm wide, centered on the tungsten emission line. This type of background emission difference can result in two positive errors. If we were trying to measure W in an Al alloy and used aqueous W standards (no Al), the continuum emission from the Al solution would result in a positive error in a determination of tungsten, if not corrected. We would be measuring both the background and the tungsten signal, and assuming it was all due to tungsten. Another error could occur if we were determining tungsten in mineral samples and did not know that some samples had a high Al content. Even if these Al-containing samples had no tungsten in them, we would erroneously report that tungsten was present, because we were measuring the background intensity inadvertently. Because the background is shifted uniformly in this example, the background signal can be corrected for by picking a wavelength near but not on the tungsten emission line as shown in Figure 7.37. The background correction point could be on either side of the tungsten peak in this case. The intensity at this correction point is measured and subtracted from the total intensity measured at the tungsten peak. Computer software is used to set the background point and automatically make the correction.

A more complicated background is seen in Figure 7.38. The Cd 214.438 nm emission line is overlapped by a nearby broad Al emission line, so the background intensity is not the same on both sides of the Cd peak. If Cd were to be measured in an aluminum alloy, this asymmetrical background would result in a positive error. When the background emission intensity is asymmetrical, two background correction points are needed, one on either side of the emission peak, as shown in Figure 7.39. The computer software uses the two chosen points to draw a new baseline for the peak and automatically corrects for the background emission.




FIGURE 7.36 A simple background shift caused by 1000 ppm Al at the tungsten 207.911 nm line. A 1000 ppm Al solution would give an erroneous positive reading for tungsten due to the increased background from the aluminum solution. (The baseline of the tungsten solution on either side of the W emission line can be assumed to be zero intensity.) (© 1999-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)




FIGURE 7.37 An example of single-point background correction for the simple background shift caused by Al at the tungsten emission line. A point on the left side of the tungsten emission is chosen and the intensity at this point subtracted from the intensity at the tungsten peak. This will have the effect of subtracting the increased background due to the Al matrix. The new baseline, shown as the dotted line, will return to the same baseline intensity (shown as the lower line) given by the tungsten solution in Figure 7.36. Because the baseline is symmetric with respect to the emission line, a background point on the right side of the tungsten peak could have been chosen instead; the result would be the same. (© 1999-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)




FIGURE 7.38 An aluminum background spectrum representing a sloping background shift at the Cd 241.438 nm line. This asymmetric background cannot be corrected using a one-point correction because the background intensity is different on each side of the emission line. (© 1999-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)




FIGURE 7.39 The sloping background shown in Figure 7.37 requires the use of a two-point background correction, with one correction point on each side of the Cd emission line. The peak is corrected using a straight line fit between the background correction points as shown by the dotted line (the new baseline). (© 1999-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)




FIGURE 7.40 The complex, line-rich emission spectrum of tungsten severely overlaps the Au emission line at 267.595 nm. The overlap is very severe on the left of the Au peak, so a two-point approach will not work for accurate determination of trace amounts of Au in tungsten. Finding a gold emission line with less interference or extracting the gold from the tungsten matrix is a possible solution to this problem. (© 1999-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

Figure 7.40 is an example of a very complex background pattern at the Au 267.595 nm emission line caused by closely spaced emission lines from a line-rich matrix, tungsten. The two-point approach will not work here, because of the severe overlap by the intense tungsten line on the left side of the Au line. Modern instrument software is available with mathematical programs that will model or "fit" the background and then deconvolute complex backgrounds. If such spectral deconvolution software is not available, the first choice of the analyst should be to find an alternate gold emission line with less interference. If there are no lines without significant interference, it may be necessary to separate the analyte from the matrix using classical "wet" chemistry, chelation and extraction techniques, ion exchange methods, or electrochemical methods. The chemical literature should be consulted for advice.

Figure 7.41 shows a case of direct spectral overlap between two emission lines, one from Pt and one from Cr. A high-resolution spectrometer will limit the number of direct spectral overlaps encountered, but not eliminate them entirely, as in this case. If the analyst has a choice of wavelengths, the first thing to do is to look for alternate emission lines for Pt and Cr. If no other analyte wavelength is available, the technique of *interelement correction* (IEC) may be used. The emission intensity of the interfering element at another wavelength is measured and a calculated correction factor is applied to the intensity at the wavelength that has the interference. The correction factor has to be determined through a series of prior




FIGURE 7.41 Direct spectral overlap of Pt and Cr emission lines. No background correction technique can solve this problem. A line with no interference must be found, an interelement correction factor must be applied or the elements must be separated chemically. (© 1999-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

experimental measurements. The use of the technique requires one interference-free emission line for each interfering element in the sample. Most modern instruments have powerful software programs that assist the analyst in this type of correction and may take different mathematical approaches. As an example, the Horiba Scientific Ultima 2 high-resolution sequential ICP uses software called CLIP, which calculates the profile of each line based on the instrument configuration: focal length, slit combination, diffraction grating and order used. Only a few minutes are needed to select lines for every element.

7.3.3 APPLICATIONS OF ATOMIC EMISSION SPECTROSCOPY


The applications of atomic emission spectrometry are very broad. The technique is used for clinical chemistry, biochemistry, environmental chemistry, geology, specialty and bulk chemical production, materials characterization of metal alloys, glasses, ceramics, polymers and composite materials, atmospheric science, forensic science, conservation and restoration of artworks by museums, agricultural science, food and nutrition science, industrial hygiene, and many other areas. The versatility of atomic emission spectrometry comes from its ability to determine a large number of elements rapidly in a wide variety of sample matrices and over a wide linear dynamic range.

The strength of plasma emission spectrometry is rapid, multielement qualitative and quantitative analyses. ICP emission spectrometry has a linear dynamic range of about six to ten orders of magnitude, meaning that elements from trace level to major constituents can usually be analyzed in one run. This eliminates the need for dilution of samples in many cases. Precision of ICP measurements is usually better than 1 %RSD. Aqueous solutions, organic solvent solutions and high salt solutions can be analyzed with virtually the same precision and accuracy. In addition to the peer-reviewed literature, thousands of application notes and methods can be found on the websites of the major instrument manufacturers.

Plasma emission is used in agricultural science to study elements in soils, plant tissue, animal tissue, fertilizers, and feed. Samples are usually acid-digested in a heating block or by using a microwave digestion system, or ashed in a muffle furnace and the ash dissolved in acid. The samples may be extracted instead of being totally dissolved; extraction results in the measurement of "available" elements. Such extracted available elements are usually considered to be biologically available to plants and animals, while digestion or ashing gives total element content. Applications include the determination of metals in beer, wine, infant formula, and fruit juice. It is possible to identify the country of origin of some food products based on their trace elemental "fingerprint".

Plasma emission is used to study elements in environmental and geological samples. The analysis of soil, water, and air for industrial pollutants is a common application. Contaminated soil and water can be analyzed as well as soil and water that have been treated to remove heavy metals, for example. This will verify if the treatment worked and provides the data engineers need to optimize and improve their removal processes. The soil and water content of naturally occurring potentially toxic metals such as As and Se can be studied as well as the uptake of As and Se by plants and animals grazing on the plants or living in the water. Particulates in air can be trapped on filters and the entire filter digested in acid or ashed prior to dissolution of the residue. This approach is used to study coal fly ash and Pb in house dust from lead-based paint. Geologists use ICP to measure major, minor, and trace components of minerals and rocks, to identify sources of metal ores, to study marine geochemistry, and to identify the origins of rocks. A picture of a mineral specimen, garnet, that has been sampled by laser ablation is shown in Figure 7.42. Laser ablation permits the spatial distribution of elements in minerals to be studied. The surface of the garnet was studied by rastering the laser across the face of the sample. Two lines of 50 μm diameter laser spots can be seen.

Biological and clinical chemistry applications of plasma emission spectrometry include determinations of those metals required for proper functioning of living systems, such as Fe, Cu, K, Na, P, S, and Se, in urine, blood, serum, bone, muscle, and brain tissue. Aluminum exposure was suspected of playing a role in Alzheimer's disease and Al concentrations in blood and tissue can be determined by emission spectrometry. In addition to essential elements,



Screen capture of garnet after two spot traverses. $50 \mu m$ spots, 4 Hz, 200 shots. Crossed polarized light.

FIGURE 7.42 A garnet sample analyzed by laser ablation to determine spatial distribution of elements in the mineral. Two traverses of the laser beam can be seen. Each ablated spot is 50 μ m in diameter. (Courtesy of Teledyne CETAC Technologies, Omaha, NE [www.cetac.com].)

plasma emission spectrometry can monitor metal-based therapeutic drugs in patients. Gadolinium compounds are used in patients undergoing some forms of MRI (Chapter 5) to enhance the contrast between normal tissue and tumors. The optimal dose of the Gd "contrast agent" can be determined from studies where the tissues are analyzed for Gd by ICP-OES (Skelly Frame and Uzgiris). ICP-OES (and ICP-MS) play a major role in the analysis of pharmaceutical products with the implementation of stringent new limits on the permitted daily exposure to approximately 16 elements (generally 5-2500 mg/day, which can translate into low to sub-ppm levels in individual drugs). An example of the use of ICP-OES for this type of application is the reference by Cassap.

Plasma emission spectroscopy is used in forensic science. By measuring the elemental composition of glass fragments, it is possible to distinguish among automobile windshield glass, headlamp glass and glass used for containers and bottles, as seen in Table 7.10.

Another forensic application is in the analysis of gunshot residue. Gunshot residue is the mixture of organic and inorganic compounds originating from the discharge of a gun and deposited on the person or clothing of an individual in close proximity to the weapon when it is discharged. The target elements are barium and antimony found together above a certain baseline as well as copper and lead. Plasma emission spectroscopy, GFAAS and methods including X-ray (Chapter 8) and neutron activation analysis have been used to study such residues. The goal is to place the discharged weapon into the hands of the shooter. Other examples may be found in the text by James and Nordby.

TABLE 7.10 Mean Percentages of Elemental Oxides in Various Types of Glass

Glass Usage	Al_2O_3	CaO	Fe ₂ O ₃	MgO	NaO
Structural window	0.158	8.50	0.123	3.65	13.53
Auto windshield	0.150	8.10	0.555	3.93	12.90
Headlamp	1.370	0.017	0.060	0.017	5.40
Container	1.416	8.266	0.117	0.283	11.73

Source: Courtesy of Tom Catalano, NYC Police Laboratory, in DeForest et al. @American Chemical Society, used with permission.

Plasma emission spectrometry is widely used to study metals, alloys, ceramics, glass, polymers, and engineered composite materials. The major difficulty with metals and alloys is the possibility of spectral interference from the rich emission spectra of the major metal elements, but high-resolution instruments permit the routine determination of trace elements in steels, nickel alloys, copper alloys, tungsten, and other refractory metals. Most metals and alloys can be dissolved in one or more acids for analysis. Elements like tungsten and silicon require HF for dissolution; it is therefore critical to use a polymeric sample introduction system for analysis, not a quartz nebulizer and spray chamber. Glass and ceramic samples are often fused in molten salt for dissolution; the resulting bead of molten salt is dissolved in acid and water for analysis. This fusion is done at high temperatures over a burner in a suitable crucible, often a Pt or Pt/Au crucible. There are commercial automatic fusion fluxers that will fuse up to six samples at once.

Polymers, oils, and other organic materials can often be analyzed by dissolution in an organic solvent. Lubricating oil and petroleum feedstock analysis was discussed in Section 7.2.3. Oils and fuels can be analyzed by ICP or MP instead of arc or spark emission instruments. Lead in gasoline is determined by dilution of the gasoline in organic solvent and analysis of the solvent solution. Metals in cooking oils can be determined by dilution with organic solvent and analysis of the organic solution. Organophosphates and organochlorine compounds from environmental and agricultural samples can be determined after extraction into organic solvents. The silicon in silicone polymers can be measured by dissolution of the silicone in organic solvent and analysis of the solvent solution. Such a method can be used to measure the amounts of silicone used on the two components of self-stick labels; both the adhesive on the label and the release coating on the paper backing are organosilicon polymers. In general, the ICP is very tolerant of organic solvents. Toluene, xylene, hexane, tetrahydrofuran, acetonitrile, methylene chloride, and many other solvents work perfectly well in this type of analysis. In some cases, it may be necessary to increase the RF power to the plasma or to add a small amount of oxygen to the plasma to help with combustion of the organic matrix.

ICP-OES, along with ICP-MS and XRF, is used for the analysis of the materials in electronic equipment. The European Union (EU) has established directives on the disposal of Waste Electrical and Electronic Equipment (WEEE) and the Restriction of the use of Hazardous Substances (RoHS) in electronic equipment sold in, into and out of the EU. The maximum allowable quantities in electrical equipment of the following hazardous substances are 0.1 % by weight for Pb, hexavalent chromium (CrVI), mercury, polybrominated biphenyl and diphenyl ethers (PBDEs) and 0.01 % by weight for Cd. Pb, Hg, Cd, and total Cr can be measured by ICP-OES, while the determination of hexavalent chromium requires a separation step in order to determine the oxidation state. This can be done using a hyphenated instrument, described below. Total bromine can also be measured by ICP-OES, but the determination of the PBDEs is generally done by GC-MS, described in Chapter 11. The WEEE/RoHS requirements have led many instrument manufacturers to have an installed method template for such analyses in their software.

7.3.4 CHEMICAL SPECIATION WITH HYPHENATED INSTRUMENTS

Plasma emission spectroscopy is an elemental analysis technique; that is, it provides no information on the chemical form or oxidation state of the element being determined. The identification of the chemical state of an element in a sample is called **speciation**. For example, in environmental samples, mercury may exist in a variety of species: mercuric ion, mercurous ion, methymercury compounds, and the extremely toxic compound dimethylmercury. Determination of mercury by ICP-OES results in total mercury concentration; chemical speciation would tell us how much mercury is present in each of the different forms. Arsenic is another element of environmental and health interest because of its toxicity. Arsenic, like mercury, exists in multiple organoarsenic compounds and multiple oxidation states as inorganic arsenic ions. Why is speciation so important? The most common arsenic compound found in shellfish is not metabolized by humans; therefore, it is not toxic. Estimating toxicity

from a determination of total arsenic concentration would vastly overestimate the danger of eating shellfish, for example. In order to perform chemical speciation, we need to separate the different species in the sample and measure each of them. Chromatography is a separation method; it permits different chemical compounds in a sample to be separated from one another by the processes and instruments described in Chapters 11-12. The use of chromatography to separate chemical species and then introduction of the separated species into an ICP sequentially can identify different chemical forms of the same element. An instrument combination formed by the connection of two separate types of instrumentation is called a **hyphenated instrument**. A very common type of hyphenated instrument is one that couples a separation technique such as chromatography with a spectroscopic technique such as NMR, FTIR, atomic emission spectrometry or MS. GC, HPLC, ion chromatography, and molecular exclusion chromatography instruments have all been interfaced to plasma emission spectrometers to identify chemical species in a sample.

For example, an HPLC coupled to a sequential ICP set to measure a silicon emission line has been used to separate and detect the small organosilicon molecules that result from the hydrolysis of high molecular weight silicone polymers (Dorn and Skelly Frame). The chromatograph separates the compounds in solution by the selective interaction of the compounds with the chromatographic **column stationary phase** and the **liquid mobile phase** that carries the sample through the column. The mobile phase with the now separated compounds flows from the column into the ICP. The ICP serves as the detector for this system; it detects and measures any silicon-containing compound that enters the plasma. This permits the study of silicone polymer degradation in a variety of environments, including degradation inside the human body. Leaking silicone polymer implants in humans have been suspected of causing serious health problems. The coupling of HPLC and ICP is one of the very few ways to separate and measure trace quantities of organosilicon compounds. This is only one of many applications of coupled chromatography-atomic emission spectrometry. There is a website dedicated to speciation methods at www.speciation.net.

The use of a helium MIP as a detector for compounds separated by GC has been mentioned and has been used for the determination of thiophene in benzene at ppb levels; F, C, N, and S in gasoline; organolead and organomanganese compounds in gasoline and elements in sediment and coal. The website at www.jas.de provides a number of application notes.

7.4 GLOW DISCHARGE EMISSION SPECTROMETRY

The glow discharge (GD) is a reduced-pressure gas discharge generated between two electrodes in a tube filled with an inert gas such as argon. The sputtered atom cloud in a glow discharge source consists of excited atoms, neutral atoms, and ions. The emission spectrum can be used for emission spectrometry in the technique of GD-OES, but the GD source can also be used for AAS, atomic fluorescence spectrometry, and MS. The source can be used with any of the types of spectrometers discussed for plasma emission: sequential monochromator, Rowland circle polychromator, Echelle spectrometer, or combination sequential-simultaneous designs. The detectors used are the same as described for plasma emission spectrometry: PMTs, CCDs, or CIDs.

7.4.1 DC AND RF GD SOURCES

A schematic DC GD source is shown in Figure 7.43. The argon gas is present at a pressure of a few torr. The DC GD source is operated with a negative DC potential of -800 to -1200 V applied between the electrodes. The sample is in electrical contact with and serves as the cathode as seen in Figure 7.43. The applied potential causes spontaneous ionization of the Ar gas to Ar^+ ions. The Ar^+ ions are accelerated to the cathode and a discharge is produced by argon ions colliding with argon atoms. The resulting plasma is called a glow discharge. The electric field accelerates some Ar^+ ions to the sample surface where impact causes neutral sample atoms to be *sputtered* or uniformly removed from the sample surface. Therefore, the




FIGURE 7.43 A DC GD source. A flat conducting sample serves as part of the cathode. (Courtesy of HORIBA Scientific. © 2020 HORIBA Scientific [www.horiba.com/scientific]. All rights reserved.)

GD source is both the sample introduction system and the atomizer. Dissociation, atomization, and excitation of the sputtered cathode material in the GD occur by collision. The emission spectrum of the cathode, that is, of the sample, is produced. The sample must be machined to have a flat surface and must be electrically conductive. The Grimm GD source (also called a GD lamp) was designed so that a flat conductive sample served as the cathode. The cathode could be easily changed for analysis of different samples. The Grimm design results in lower self-absorption and low material redeposition on the sample surface.

A DC GD source can only be used to sputter conductive samples. Some applications to nonconductive materials were made by mixing the nonconductive sample powder with graphite or pure copper powder and pressing flat pellets. In the 1990s, a new GD source based on RF excitation was developed (Marcus and Winchester et al.). This RF GD source permits the sputtering and excitation of nonconductive materials, such as glass and ceramics, as well as conductive samples. This source still has low Ar pressure and two dissymmetric electrodes, a planar analytical sample as the cathode and a tubular copper anode facing the sample. The sample is subjected to an RF frequency of 13.56 MHz. If it is an insulator, the sample acts as a capacitor with respect to the alternating RF voltage. This results in an alternating charge on the sample surface through each cycle. When the sample surface is negatively charged (a very rapid process), the positive Ar+ ions are accelerated to the negative surface and the sample material is sputtered into the glow discharge. The charge alternates very rapidly, so the sputtering process is very efficient. Excitation and emission occur as described for the DC source.

7.4.2 APPLICATIONS OF GD ATOMIC EMISSION SPECTROMETRY

7.4.2.1 BULK ANALYSIS

The first application of GD-OES using a DC source was for direct multielement analysis of solid metals and alloys, much like a spark source. The bulk composition of the sample was determined. The DC GD source for analysis of conductive solids has several advantages over spark emission spectrometry. The spectra produced by the GD exhibit lower background and narrower emission lines than spark sources due to less Doppler broadening. Emission lines that appear in the spectrum are almost exclusively atom lines. Linear calibration curves are achieved over a wide concentration range, which decreases the number of standards required for calibration. The GD source exhibits much lower levels of interelement and matrix interferences than arc or spark sources, since the sputtering step and the excitation step are separate events. This allows the use of one set of calibration standards for different families of




FIGURE 7.44 A GD "sputter spot" in a steel sample showing the uniform removal of the surface. It is this uniform sputtering process that permits accurate depth profiling of layered materials by glow discharge OES. (Courtesy of Sandvik Materials Technology, Sandvikem, Sweden, [www.smt.sandvik.com].)

materials, because there is less need to matrix-match for accurate results. Detection limits are on the order of 0.1-10 ppm for most elements, with a precision of 0.5-2 %RSD.

Applications now include the analysis of nonconductive materials such as polymers, ceramics, and glasses using the RF Marcus-type source. The advantages are similar to those just discussed, with a major improvement in detection limits and a decrease in sources of error.

7.4.2.2 DEPTH PROFILE ANALYSIS

Because the GD sputtering process removes uniform layers of materials from the sample surface, it can be used to examine coatings and multilayered materials. The analysis of composition of a sample as a function of depth from the surface is called *depth profiling*. Depth profiling is a major application for GD instruments. Uniform removal of the sample can be seen in Figure 7.44, which shows a GD sputtered spot in a steel sample. Layers that are only nanometers thick can be analyzed quantitatively. Applications of depth profiling are many. Paint layers on automobile bodies, the thickness of the Zn layer on galvanized steel, carbon and nitrogen concentrations as a function of depth in nitrocarburized steel, the structure of multilayer semiconductor materials, nonconductive coatings of nitrides or carbides on alloys, thermal barrier coatings on alloys and many other complex samples can be easily characterized by depth profiling with GD-OES. Examples are shown in Figures 7.45–7.47. Many other examples and application notes can be found on the Horiba Scientific website at www.horiba.com/scientific and the LECO website at www.leco.com.

7.5 ATOMIC FLUORESCENCE SPECTROSCOPY

The process of atomic fluorescence involves the emission of a photon from a gas phase atom that has been excited by the absorption of a photon, as opposed to excitation by thermal or electrical means. Figure 7.48 shows a few of the various types of fluorescence transitions that can occur. The solid arrows are photon absorptions or emissions; the dotted arrows are transitions that do not involve a photon. The lowest energy level represents the ground state. Two




FIGURE 7.45 A GD depth profile of a multilayered coating on stainless steel. The *y*-axis is concentration in atomic %; The *x*-axis is time, equivalent to depth in micrometers from the surface. (Courtesy of Horiba Scientific © 2020 HORIBA Scientific [www.horiba.com/scientific]. All rights reserved.)




FIGURE 7.46 A GD depth profile of a titanium nitride coating on steel. TiN is a hard, brittle material often used to modify the surface of steel. The quantitative depth profile software on this system can verify the stoichiometry and thickness of the coating layer. (Courtesy of LECO corporation, St. Joseph, MI [www.leco.com].)

resonance fluorescence transitions are shown in Figure 7.48(a), where the initial and final energy levels involved in the absorption and emission steps are the same. The absorption and emission wavelengths are the same in resonance fluorescence. Figure 7.48(b) depicts **Stokes direct-line fluorescence**, while Figure 7.48(c) shows an **anti-Stokes direct-line fluorescence** transition. There are other transitions that can occur, including stepwise transitions and multiphoton processes.

We know from the Boltzmann distribution that most atoms are in the ground state even at the temperatures found in graphite furnaces. Therefore, most analytical AFS uses ground-state resonance fluorescence transitions because these have the greatest transition probability and thus result in the highest fluorescent yield. Even so, the fluorescent yield is only a fraction of the total excitation source power, because not all the excitation source power is absorbed, not all absorbed photons result in fluorescence, and only a small amount of the total fluorescence is measured. A major disadvantage of the use of resonance fluorescence




FIGURE 7.47 (a) A quantitative GD depth profile of a painted, galvanized steel sheet. This profile shows an initial layer containing Ti, Si, C, H, and O. The paint is white, so titania and silica are probable ingredients and latex paints would certainly contain hydrocarbons. An intermediate layer containing Sr and Cr is seen, then the third layer (with the Zn peak) shows the galvanization and the increasing Fe signal shows where the steel base begins. (b) A GD depth profile of a photovoltaic cell, seen on the right, composed of the following layered materials: CulnGaSe coating/MO/glass. MO stands for metal oxide. (Courtesy of Horiba Scientific © 2020 HORIBA Scientific [www.horiba.com/scientific]. All rights reserved.)

lines is that scattered light from the source has exactly the same wavelength as the fluorescence emission and is a direct interference.

The calculation of fluorescence yields for AFS are similar to those for molecular fluorescence (Chapter 3). Ingle and Crouch present an extensive discussion of theory of atomic fluorescence. The theory will not be covered here. It is sufficient to understand that for a resonance transition and low analyte concentration, the fluorescence signal is proportional to the




FIGURE 7.48 Example of atomic fluorescence transitions: **(a)** resonance fluorescence, **(b)** Stokes direct-line fluorescence, and **(c)** anti-Stokes direct-line fluorescence.




FIGURE 7.49 Schematic saturation curve for AFS. At low intensity, the signal is linear with source intensity. At high source intensity, the signal is independent of the source intensity. This is the saturation region.

analyte concentration and to the intensity of the source. This assumption is valid for sources that do not alter the population of the analyte states. Intense laser sources can deplete the population of lower-energy states, including the state from which excitation occurs. This condition is called **saturation**. The use of an intense laser source can change the population of states in the analyte. In particular, the lower state, from which excitation occurs, can be depleted and an excited state populated using high-intensity sources such as pulsed dye lasers. For a simple two-level system (ground state and first excited state), complete saturation is defined as having one half of the atoms in the excited state. As we know from the Boltzmann distribution, this is not the usual distribution of atoms. If we graph the logarithm of the relative fluorescence signal vs. the logarithm of the source intensity, we obtain the saturation curve, shown schematically in Figure 7.49. In the region of low source intensity, which would occur with low laser power or with conventional EDL or HCL sources, the signal is linearly related to the source intensity. This region demonstrates the need for highintensity conventional sources. The higher the intensity, the higher is the signal in the linear region of the curve for conventional sources. With very high intensity sources, the signal becomes independent of the source intensity because the population of ground state and excited state atoms has been altered. The intense laser source has altered the population of atoms and caused the rates of absorption and fluorescence to become equal. This condition is called saturation or optical saturation. Saturated fluorescence gives several advantages. The fluorescence signal is the maximum obtainable signal, so the detection limits are the lowest obtainable. The signal is independent of fluctuations in the source intensity. Saturation eliminates quenching of the fluorescence signal by collisional deactivation and improves linearity by decreasing self-absorption of the fluorescence signal. In practice, sufficient laser power is used to just saturate a given transition. This provides the advantages just listed while minimizing scattered radiation.

7.5.1 INSTRUMENTATION FOR AFS

A block diagram for an AFS spectrometer is shown in Figure 7.50. The fluorescence signal is generally measured at an angle of 90° with respect to the excitation source to minimize scattered radiation from the source entering the wavelength selector, as was done in the measurement of molecular fluorescence (Chapter 3). While the fluorescence radiation is emitted in all directions from the atomizer, only a small fraction of it is collected and sent to the detector. This combined with the low fluorescent yield results in a very small signal in most cases.




FIGURE 7.50 Schematic AFS spectrometer system showing the typical 90° orientation between the source and the wavelength selector and detector to minimize scattered radiation.

The atomizer used can be a flame, a plasma, a graphite furnace, or a quartz cell atomizer used for hydride generation and CVAAS. The wavelength selector can be any of the devices discussed in earlier chapters, from grating monochromators to nondispersive filter systems. The detector commonly used is the PMT because of its high sensitivity. The fluorescence signal is directly proportional to the intensity of the excitation source at low concentration of analyte, so intense stable light sources are needed for AFS. The most common sources are line sources, and include EDLs and HCLs (described in Chapter 6); the HCLs are generally modified to be high intensity lamps. Laser excitation is ideal for AFS since lasers provide extremely intense monochromatic radiation and permit the use of less sensitive nonresonance fluorescence transitions. The primary disadvantage to lasers is the cost and complexity of operation of some types of lasers. In all cases, the source is pulsed or mechanically chopped to eliminate the interference from emission by the analyte caused by thermal or other means of excitation. Resonance emission occurs at the same wavelength as resonance fluorescence; however, the fluorescence signal will be modulated at the source frequency while the emission signal (from thermal or other excitation) will be a steady signal. A lock-in amplifier set to the source modulation frequency will measure only the fluorescence signal.

Commercial instruments are available for the determination of mercury by cold vapor AFS and for the determination of As, Se, and other hydride-forming elements by hydride generation AFS. The chemistry of these methods is the same as for their AAS counterparts (Chapter 6). The instruments use either a cold quartz cell for Hg or a heated quartz cell for As, Se, Sb, Bi, Te, Sn, and other hydride-forming elements. PMT detectors with high sensitivity in the UV region are used, since the most sensitive fluorescence lines for Hg and the hydride-forming elements are in the 180–260 nm region. These commercial instruments are equipped with autosamplers and automated sample/reagent mixing systems. Flow injection systems exactly as described for AAS in Chapter 6 are used for some systems. The Hg systems are often equipped with an amalgamation trap to preconcentration the mercury vapor on gold. The concentrated Hg vapor is released by heating the gold amalgamation trap.

7.5.2 INTERFERENCES IN AFS

AFS would be expected to suffer from chemical interferences and spectral interferences, as do the other atomic emission techniques we have discussed. The focus will be on the commercial instruments available.

7.5.2.1 CHEMICAL INTERFERENCE

Chemical interference in the cold vapor Hg AFS method is not a significant problem. The chemistry of the reaction is well understood and the interferences are both few and rare. Large amounts of gold, and several other metals interfere in the release of Hg atomic vapor, but the interferences are not encountered commonly in the biological and environmental

samples routinely analyzed for Hg. Chemical interference in hydride generation is also well understood. The elements must be converted to the appropriate oxidation state, for example. For routine analysis of biological and environmental samples using standard analytical protocols, AFS determination of As and Se does not suffer from significant chemical interference.

7.5.2.2 SPECTRAL INTERFERENCE

Spectral interferences can be significant in AFS and some of them are unique to AFS. The total fluorescence signal at the detector can include light scattered from the source, fluorescence from nonanalyte atoms and molecules, background emission, analyte emission, and analyte fluorescence. To measure only analyte fluorescence, the other spectral interferences must be eliminated or corrected for. As noted, if the source is modulated, analyte emission is not measured. Fluorescence from nonanalyte atoms and molecules, or background fluorescence is rare. The multistep nature of the fluorescence process makes it unlikely that nonanalyte species will absorb and fluoresce at the same wavelengths as the analyte. Any background fluorescence that occurs can be compensated for by having a suitable blank and subtracting the blank signal from the measured total signal. Background emission and scattered light are the major sources of spectral interference in AFS. Scattered light and background emission can both be compensated for by subtraction of a suitable blank. Scattered light is more significant in resonance fluorescence, where the excitation and fluorescence wavelengths are the same, than in nonresonance fluorescence. Wavelength selection can distinguish between the source scattering and the analyte signal in nonresonance fluorescence because the fluorescence wavelength is not the same as the excitation wavelength. The advantage to the use of a laser as the excitation source is that less sensitive nonresonance transitions can be used, and the scattered light eliminated as a source of interference by wavelength selection.

Spectral interferences are minimal for cold vapor Hg AFS and for hydride generation AFS, due to the chemical separation step that is used prior to excitation.

7.5.3 APPLICATIONS OF AFS

The AFS phenomenon has been studied extensively since the late 1950s. An overview of the research into AFS can be found in the book by Ingle and Crouch, the chapter by Michel, and in the handbook by Settle (see the bibliography). AFS is primarily used for quantitative analysis. The accuracy and precision of AFS depends on the atomizer used but is generally comparable to cold vapor AAS for Hg or hydride generation for As and Se, on the order of 1-2 %RSD. Use of a graphite furnace as the atomizer results in precisions typical of GFAAS, on the order of 5 %RSD for solutions to 10-30 %RSD for solid samples. Linear ranges vary from three to eight orders of magnitude.

7.5.3.1 MERCURY DETERMINATION AND SPECIATION BY AFS

Commercial cold vapor (CV)-AFS systems for mercury are available because of the dramatic improvement in detection limits for Hg using AFS. Detection limits for Hg on the Teledyne Leeman Labs Hydra II_{AF} Gold instrument using amalgamation to preconcentrate the mercury are reported to be less than 0.05 parts-per-trillion (ppt) with a dynamic range of 0.1 ppt to 250 ppb. That is at least 10-100 times more sensitive than CVAAS. This system is completely automated, performs an analysis every three minutes with amalgamation and has an autosampler that can hold 180 samples. These instruments are used to determine low levels of Hg in biological fluids and tissues, environmental samples, air, and gases. The commercial instruments can be coupled to an LC or GC for speciation of mercury compounds in samples, as can be seen at www.psanalytical.com. The PS Analytical GC-based Hg speciation system consists of a GC coupled to an AFS with an integrated pyrolysis control unit. The detector is a PMT with a low-pressure Hg lamp as the excitation source. Application notes and system diagrams are available from Teledyne Leeman Labs (www.teledyneleemanlabs.com) and PS Analytical Ltd., UK (www.psanalytical.com).

7.5.3.2 HYDRIDE GENERATION AND SPECIATION BY AFS

The hydride-forming elements, including As, Se, Sb, Bi, Te, Ge, Sn, and others, can be determined routinely using commercial hydride-generation AFS (HG-AFS) instruments. (Note that upper case HG means hydride generation, not mercury, Hg.) A number of these elements, like Hg, are important analytes because of their toxicity. Detection limits for most of these elements are in the low ppt (ng/L) range, with linear ranges up to 10 ppm. The Lumina 3300 AFS from Aurora Biomed, Inc. (www.aurorabiomed.com) states DLs for Hg and Cd of 1 ppt, while most other hydride-forming elements have DLs of about 10 ppt, for example, with < 1 %RSD. The detection limits are in general 5-10 times better than the equivalent hydride generation AAS detection limits. Speciation for these elements can be accomplished by coupling an LC or GC with the AFS system. Mercury, arsenic, and selenium are found in both inorganic and organic forms, with the toxicity of the forms varying widely. For example, hydrogen selenide is extremely toxic while selenomethionine is an essential nutrient. Selenium in fact has the smallest range between essentiality and toxicity of any essential element. Inorganic arsenic species are toxic, while compounds such arsenobetaine and arsenocholine, found in shellfish, are non-toxic. Using an LC attached to a PS Analytical Millenium Excalibur, their hydride generation AFS system, PS Analytical has demonstrated the separation and detection of five selenium species, five arsenic species and the two inorganic oxidations states of Sb (not simultaneously). Details and chromatograms can be found at www. psanalytical.com.

7.6 LASER-INDUCED BREAKDOWN SPECTROSCOPY (LIBS)

Laser-Induced Breakdown Spectroscopy (LIBS) is a relatively new atomic emission spectroscopy technique which uses a pulsed laser as the excitation source. LIBS is also referred to as Laser Spark Spectroscopy (LASS) and Laser-Induced Plasma Spectroscopy. The technique was developed in the early 1960s, after the invention of the laser, but the high cost and large size of lasers and spectrometers made this a specialized research tool until the 1990s. The early development of LIBS is covered in the reference by Myers et al. Recent advances in miniature fiber optic spectrometers and small high peak power lasers have led to the development of compact, portable analytical systems for laboratory and field use. There is as of August 2012 a LIBS system in operation on Mars, on board the Mars rover Curiosity.

7.6.1 PRINCIPLE OF OPERATION

The output of a pulsed laser, such as a compact Q-switched Nd:YAG laser, is focused onto the surface of the material to be analyzed, using simple focusing lenses. For the duration of the laser pulse, typically 10 nanoseconds, the power at the surface of the material can exceed 1 Gigawatt per cm². This creates an induced dielectric breakdown or plasma spark. At these high-power densities, a very small amount of material, less than a microgram, is ejected from the surface by the process of laser ablation. A short-lived but highly luminous plasma with instantaneous temperatures reaching 10,000 °C is formed at the surface of the material. In LIBS, the laser itself creates the plasma. Within the hot plasma, the ejected material becomes atomized, ionized, and excited. At the end of the laser pulse, the plasma quickly cools by expansion at supersonic speeds. The excited atoms and ions emit their characteristic emission lines as they return to lower energy levels. Using collecting lenses and fiber optic connections to an optical spectrometer, the elemental composition of the material can be determined.

LIBS can be used to analyze any material-solids, liquids, gases, slurries and the like-for all elements. Many elements can be detected at <1 ppm-100 ppm levels, with a smaller group of elements having detection limits in the 100-500 ppm range. The Applied Photonics Ltd. website at www.appliedphotonics.co.uk has a periodic table color-coded to show LIBS detections limits. Due to the extremely small amount of sample ablated, on the order of nanograms to

micrograms of material per laser shot, the method is considered non-destructive. No sample preparation is usually required. Because LIBS is an optical technique, remote analysis is possible, as will be seen. Heating of the sample is negligible as the average power incident on the sample is generally less than 1 Watt.

7.6.2 INSTRUMENTATION

A schematic of a modern LIBS system is shown in Figure 7.51. The components required are a high peak power Q-switched laser, optics to focus the laser onto the sample surface, laser pulse emission and detection timing circuitry, optics to gather the emitted light and transfer it to the spectrometer, and computer software for spectral analysis.

Different lasers have been used for LIBS, but the most common is a Q-switched Nd:YAG laser operated at its fundamental wavelength of 1064 nm, at the frequency doubled wavelength at 532 nm or higher harmonics at 355 and 266 nm. The requirements for the laser are that it have a short pulse duration or pulse width (1-20 nanoseconds), and a minimum of 10 mJ per pulse. Lasers pulses in LIBS are typically 10-100 mJ. Neodymium-doped yttrium aluminum garnet is the material used in this optically-pumped solid state laser. A Q-switch is an optical device that controls the laser's ability to oscillate, in this case by waiting for a maximum population inversion in the Nd ions. By keeping the laser Q-factor low, the laser is able to store higher levels of energy. The stored energy is then released in the form of extremely short pulses of high power. (It is important to note that these high-power lasers constitute a safety hazard both to people and as a potential fire risk, and should only be operated by trained, experienced analysts with the appropriate safety equipment.)

Time-gated detectors which allow the optical emission from the laser plasma to be recorded at some time delay after the laser pulse are required to accurately capture the emission spectra. For the first few microseconds after the "ignition" of the laser spark, the plasma emits a strong white light continuum (also called bremsstrahlung) which decays as the plasma cools; the characteristic atomic and ionic emission lines only appear as the plasma cools. A detector delay on the order of several microseconds after the laser pulse is used to eliminate interference from the continuum radiation. The principle is demonstrated in Figure 7.52.

Spectrometer designs are similar to those already discussed, including broadband diode array, Echelle, Czerny-Turner and Paschen-Runge spectrometers, with miniature echelle and CCD array systems most suited to portable LIBS systems. The LIBSCAN 25+ (Applied Photonics Ltd.) uses up to six compact CCD array spectrometers covering the 185–900 nm range.

The TSI ChemReveal Desktop LIBS comes in a variety of configurations, including four Czerny-Turner spectrographs with CCD detectors, and has a wavelength range of 190–950 nm. Photomultiplier tube detectors can be used, especially with multiple PMTs, with the drawback being that the wavelengths that can be monitored are fixed and limited to the number of detectors.




FIGURE 7.51 LIBS schematic showing the major components. (Image reproduced courtesy of Applied Photonics Ltd., UK [www.appliedphotonics.co.uk].)




FIGURE 7.52 Schematic time sequence for atomic emission after initiation of the LIBS plasma. (Courtesy of TSI, Inc. [www.tsi.com].)

The spectra are processed by computer software that now often includes advanced chemometric methods (see the discussion of chemometrics in Chapter 4). Methods such as Partial Least Squares and Principal Component Analysis are used by instrument software to construct calibration curves and provide quantitative analysis. LIBS software on many commercial systems supports library matching, sample classification, qualitative, semi-quantitative, and quantitative analysis including pre-loaded libraries and calibrations and customer-built libraries and calibrations.

A low-pressure Ar purge of the sample surface is used to prevent particulates from the laser ablation of the sample from dirtying the system optics, to generate a stronger emission signal and to displace air from the LIBS spark to enable the determination of N and O from samples.

Instruments can be run as open-beam systems by focusing the laser onto a sample that is not in an enclosure, or as benchtop enclosed systems, and as stand-off systems where the laser propagates through the atmosphere over significant distances and the emission is collected by a telescope.

7.6.3 APPLICATIONS OF LIBS

There are significant advantages to LIBS when compared with other atomic emission techniques discussed above and XRF techniques, discussed in Chapter 8. LIBS is capable of detecting all elements, including low atomic number elements like H, Be, B, C, N, and O, at detection limits in the ppm range. Some of these elements cannot be detected by most atomic emission instrumentation or by XRF, especially at such low levels. Little or no sample preparation is required. If the sample surface is coated with an oxide layer, paint, oil or other contaminants, the laser may be used to rapidly clean the surface to expose the underlying material. Coatings several hundred microns thick can be rapidly removed in this way. Since the laser can remove surface coatings, this allows LIBS to be used for depth profiling of coated and multilayer materials, as long as the sample can be ablated at the laser power available although not with the resolution of a GD system. Bulk simultaneous determination of all elements can be done in approximately 20 seconds. LIBS can rapidly provide an elemental fingerprint of a sample.

LIBS is used in industry, biomedical applications, analysis of materials in hazardous environments, such as inside nuclear reactors, analysis of materials underwater, and for the

remote detection of hazardous materials, including explosives. Samples may be solids, liquids, gases, slurries, sludges and other mixtures. Applications for LIBS (courtesy of Applied Photonics, Ltd.) include:

- Remote, non-invasive characterization and identification of materials
- Remote detection and elemental analysis of hazardous materials, including radioactive, high-temperature and chemically toxic substances
- In-situ detection of radioactive contamination
- In-situ compositional analysis of steel components in difficult-access environments, such as nuclear reactor pressure vessels
- Rapid identification of metals, alloys and plastics during scrap recycling. LIBS can be used to identify pieces moving at high speed on a conveyor belt.
- Positive metal identification of critical components during manufacturing and assembly
- On-line compositional analysis of liquid metals, alloys and glasses for process control
- In-situ identification of materials submerged in water
- Depth profiling and compositional analysis of surface coatings (e.g., galvanized steel)
- On-line monitoring of particles in air (stack emission monitoring)
- Compositional analysis of objects with complex shapes

Other applications of LIBS are in archeology, geology, gemology, art restoration, and conservation; military and homeland security analyses of explosives; landmines, chemical or biological warfare agents, bio-aerosols, and bio-hazards; in forensics and biomedical studies of bones, hair, teeth, cancer tissue, bacteria, and other biological materials; and real-time environmental monitoring of water, air, exhaust gases, and industrial waste.

7.6.3.1 QUALITATIVE ANALYSIS

Qualitative analysis is performed by identifying the specific atomic emission lines present in a LIBS spectrum. Commercial instrument manufacturers now include atomic spectral libraries and automatic line identification software.

Since all elements can be detected by LIBS, qualitative elemental "fingerprints"-lines and intensities- can be used to match samples. This can be used for quality control, for example. Biological materials will give a characteristic fingerprint of multiple lines and intensities from oxygen, nitrogen, hydrogen, carbon, and perhaps heteroatoms like S and P. An interesting example is the use of LIBS spectra to fingerprint bacteria and easily distinguish between similar bacteria-for example, distinguishing between anthrax (*Bacillus anthracis*) and the very common, related but not deadly *Bacillus thuringiensis*, *Bacillus cereus* and others. Based on demonstrated LIBS capabilities, it may soon be possible to perform *in vivo* analysis of tissue and diagnosis of pathogens in real-time. The article by Rehse et al. presents an excellent overview of biomedical applications of LIBS.

Gemstones are very valuable materials, especially rare colored gemstones of certain types, such as deep blue diamonds like the Hope Diamond. Artificial stones and treated, dyed, and coated gemstones are readily available, often being sold as "real" gemstones. In the evaluation of gemstones, using a UV 355 nm frequency-tripled Nd:YAG laser produces a smaller focal point on the gemstone and is only absorbed at the surface, causing an inconsequentially small area of laser "damage" while still producing useful spectra. Using this approach, TSI applications scientists were easily able to identify beryllium-treated sapphires and cobalt coatings of topaz, treatments used to change the color of the stones.

Diamonds, gold and gold-bearing ores, and minerals which are major sources of tin, nio-bium, tantalum, and tungsten are mined in various locations around the world. Profits from some of these "conflict minerals" may be used to finance wars. LIBS is being used to study the mineral "fingerprints" with the goal of identifying the geological source of these materials (Arnaud 2012; Hark, R.R. et al. 2012; Harmon, R.S. et al. 2011). In addition, researchers

have used LIBS to trace the origins of Neolithic artifacts made of obsidian, a volcanic glass (Remus, J.J. et al. 2012).

7.6.3.2 OUANTITATIVE ANALYSIS

Quantitative analysis usually requires the use of standards and/or certified reference materials, the selection of an appropriate elemental optical emission line and, in most cases, the selection of a normalization line, used as an internal standard. Calibration curves are then constructed using the normalized peak area versus concentration, as previously described for calibration using an internal standard. When there is a dominant matrix component for which the concentration will remain approximately constant across the calibration set, it is best to use an emission line from that matrix element for normalization. This approach helps minimize effects due to changes in plasma conditions caused by shot-to-shot fluctuations in laser intensity. Alternatively, chemometric correlation analysis of the entire observed spectrum with the concentration of the analyte can be used to construct calibration curves automatically. In general, RSDs of 5-10 % are readily achievable. To improve quantitation, sample preparation methods such as pressing pellets may improve results for soils and sediments and fusion with salts (Chapter 1) to convert the sample into a glass bead can eliminate matrix effects.

As discussed earlier, the RoHS directives of the European Union limit the amount of certain elements, including Pb, in electronic devices and equipment. Scientists at Applied Spectra, Inc. (www.appliedspectra.com) used their RT-100 series LIBS system to demonstrate the quantitative determination of Pb in tin-plated semiconductor leadframe packages without the need for sample preparation. The RT-100 used a 50 mJ laser at 1064 nm, with a laser spot size of 120 microns to determine lead over the range 20-1000 ppm Pb using the Pb 405.7 nm emission line. Quantification was done by calibration with a set of four standards obtained from NIST and MBH Analytical Ltd. The LIBS analysis showed excellent agreement with analyses by ICP-OES and laser ablation-ICP-MS, performed by third party laboratories. The advantages to the LIBS method are fast measurement time, the ability to measure the Pb content at various stages in manufacturing, and the elimination of toxic waste and expensive, high-purity acids, making the method cheaper and safer than methods like ICP-OES.

For the quantitative determination of boron in borosilicate glass and the boron-containing ores colemanite and ulexite, which are used as feedstocks in the glass industry, samples were ground to <60 microns, pressed into pellets using a hydraulic press and analyzed using the TSI, Inc. LIBS system. Using the oxygen emission line at 777 nm for normalization, B was measured at the 206.723 nm emission line. The analysis took 20 seconds. The detection limit for boron was estimated to be 0.001 % and quantitative results from 5-50 % calculated as B_2O_3 were obtained with RSDs of 1-2 %.

The lanthanide elements, Z=58-71, are widely used in industrial materials. Fluorescent lamp phosphors, nuclear reactor control rods, coloring agents in glass and ceramics and as constituents in laser materials and solid-state devices are some examples of materials which use lanthanide elements. The current global supply of lanthanides is controlled by China; as a result, many countries are evaluating the reopening of mines where low levels of lanthanide-containing ores may be found. Acid digestion or fusion for determination by ICP-OES or ICP-MS is tedious and often requires addition of internal standards and the use of expensive high purity acids and fluxes. XRF, which can analyze solid samples directly, suffers from overlap of the lanthanide fluorescence lines with those of the transition elements. LIBS can readily measure the lanthanide elements in ores at levels at or below 10 ppm and the ability to do this in the field allows geologists to quickly determine if the ore is worth mining.

The determination of composition without having to use calibration standards is a goal of every spectroscopic technique. There are a number of spectral modeling approaches available for various techniques that often permit semi-quantitative analysis. (How "semiquantitative" the results are is often a matter of how the models have been developed-"semiquant" can mean just about anything from qualitative to quantitative.) For LIBS, software is available that uses a database of atomic emission lines to create a theoretical spectrum using defined plasma parameters (Yaroshchyk et al.), permitting composition to be determined

in some matrices without calibration standards with results that are in "good agreement", according to the authors, with certified values.

7.6.3.3 REMOTE ANALYSIS

Because LIBS is an optical technique, only optical access to the material is required to carry out an analysis. Remote measurements using an instrument equipped with a telescope for a direct line of sight method allows analysis of objects up to distances of about 10 m, while fiber optic probes permit analyses at up to 100 m. This is extremely useful for analysis of hazardous or high temperature materials and for deployment in hostile environments. An exciting use of LIBS in the harsh environment of the planet Mars is currently underway (Figure 7.53). The Mars rover named Curiosity is equipped with a LIBS system called the Chemistry and Camera (ChemCam) instrument capable of determining the elemental composition of rocks and soil up to 23 feet (7 m) away, and through the thin dust layer that covers the Martian surface. This system uses an IR laser, a telescopic lens, and a trio of spectrometers with over 6000 UV, VIS and IR channels covering a range of 240–850 nm. This LIBS system was a collaboration between the French space agency Centre National d'Études Spatiales (CNES) and






FIGURE 7.53 (a) Artist's conception of the mars rover curiosity, showing the raised mast head. **(b)** Close-up of the actual mast head with the ChemCam. (Image credits: Courtesy of NASA/JPL-Caltech/LANL.)





FIGURE 7.54 LIBS plasmas on earth and mars. Studies at Los Alamos National Laboratory (LANL) show LIBS plasmas at typical atmospheric pressures on earth (left) and mars (right). At the lower atmospheric pressure on mars, the plasma is larger and brighter. (Image credit: Courtesy of LANL.)

the U.S. Los Alamos National Laboratory. The first test of the ChemCam system occurred on August 19, 2012, when the laser was fired at a rock about 10 feet away. Articles and pictures can be found on the websites of NASA, LANL, CNES and magazines such as Sky and Telescope or Astronomy Magazine.

LIBS has an advantage on Mars, in that the atmospheric pressure is only about 1 % of Earth's atmospheric pressure at sea level, allowing the plasma to expand and become brighter (Figure 7.54).

The first LIBS spectrum from the ChemCam was collected from a rock near the rover. The rock (Figure 7.55(a), called "Coronation", is about 3" (7.6 cm) across and located about nine feet (2.7 m) from ChemCam on the mast. The spectrum is shown in Figure 7.55(b). The plot is a composite of spectra taken over 30 laser shots at a single 0.016 inch (0.4 mm) diameter spot










FIGURE 7.55 (a) "Coronation", the first rock studied on mars by LIBS. (b) The first ChemCam spectrum of the rock, showing major and minor elements present. (c) The Calibration target for ChemCam. (Image credits: courtesy of NASA/JPL-Caltech/LANL/CNES/IRAP.)

on the rock. Major elements are identified and the upper left inset shows an expansion of the 398–404 nm region, identifying minor elements Ti and Mn. An inset on the right shows the hydrogen and carbon peaks. Carbon is present in carbon dioxide in the Martian atmosphere. The hydrogen peak was present only on the first laser shot, indicating that the element was only on the very surface of the rock. The heights of the peaks do not directly indicate relative abundances of the elements, since some emission lines are more easily excited than others. A preliminary analysis of the spectrum indicates that it is consistent with basalt, a type of volcanic rock known to be abundant on Mars from previous explorations.

The ChemCam is calibrated using the target shown in Figure 7.55(c), consisting of nine materials representing those expected on Mars. Circles 1-4 are glass samples representing igneous rocks, #5 is graphite, and circles 6-9 are ceramic samples representing sedimentary rocks. The square plate of Ti, #10, is used for laser diagnostics and wavelength calibration of the ChemCam.

Remote (standoff) LIBS systems have been built by Applied Photonics Ltd. with a range capability of >100 m for defense departments. They also built a transportable standoff LIBS with a 20 m range to characterize radioactive materials in a hot cell at the Sellafield, UK, high-level nuclear waste vitrification plant by directing the laser beam through the lead-glass window of the cell. LIBS is an excellent tool for remote and in-situ detection of uranium oxide fuel located in hard-to-reach places, under water or covered in sludge, for example, at a damaged nuclear reactor site such as the Fukushima Daiichi plant in Japan, because it is essentially immune to the effects of ionizing radiation. Conventional gamma spectroscopy would be swamped by the high gamma field from fission products such as Cs-137. LIBS therefore can be used to measure quantities of low specific activity radionuclides such as U-235, U-238, Pu-239, Pu-241, and Tc-99 in high gamma field environments.

7.7 ATOMIC EMISSION LITERATURE AND RESOURCES

There are many journals that publish articles on atomic emission spectroscopy. Analytical Chemistry, Applied Spectroscopy, Spectrochimica Acta Part B, and The Analyst publish articles on atomic emission spectroscopy as well as other analytical methods. The Journal of Analytical Atomic Spectrometry is a more focused journal, as the name implies. Applications articles that use atomic emission spectroscopy for analysis of specific materials may be found in journals related to the field of application, such as geology, agriculture, food science, pharmaceutical science, polymer science, and the like.

Methods and applications can be found on line from government, academic, and instrument manufacturer sites. The US EPA methods that use atomic emission spectrometry for analysis of environmental samples can be found at www.usepa.gov, for example. Most of the instrument companies whose websites are given in the chapter have applications notes and methods on their websites. Many also have tutorials and videos on the various techniques.

Tables of atomic spectral lines may be found in print in the books and handbooks by Boumans, Harrison, Robinson and Zaidel listed in the bibliography. Atomic spectral wavelengths can be found at the US NIST website, www.nist.gov. Most commercial instrument software contains a library of emission lines.

SUGGESTED EXPERIMENTS

Flame Emission

7.1 Warm up the flame photometer or flame atomic absorption spectrometer in emission mode, following manufacturer's directions. Using an air—acetylene burner, set the flow rates of air:acetylene to (a) oxidizing flame, (b) stoichiometric flame, and (c) reducing flame, following manufacturer's directions. Note the change in flame color, shape, and size. With each flame measure the emission at 589.0 and 589.5 nm. This is from sodium contamination in the flame gases and from dust in the atmosphere. Aspirate into the flame (a) deionized water from a plastic container, (b) deionized water from a soda-lime glass container (your typical "glass" jar or bottle), and (c) deionized water

- from a borosilicate glass container (e.g., Pyrex* or Kimax*). (Allow water to sit in each container overnight). Compare with freshly drawn deionized water. Compare the relative sodium contamination of the water by the containers (emission intensity at 589.0 nm).
- 7.2 Prepare aqueous solutions containing amounts of potassium varying from 1.0 to 100.0 ppm of K^+ . Aspirate each sample into the flame. Measure the intensity of emission at 766.0 and 404.4 nm. Plot the relationship between the emission intensity of each line and the concentration of the solution aspirated into the burner.
- 7.3 Repeat Experiment 7.2, but add 500 ppm of Cs to each solution. Note the change in the emission intensity. Explain.
- 7.4 Prepare solutions containing 20 ppm of Mg, Ca, Zn, Na, Ni, and Cu. Measure the emission intensity of Mg at 285.2 nm, Ca at 422.7 nm, Zn at 213.9 nm, Na at 589.0, Ni at 341.4 nm, and Cu at 324.7 nm. Note the wide divergence in emission intensity, even though the metal concentration was constant. Compare the sensitivity of your results with that of the results of Experiments 7.1 and 7.2. (This experiment can be done with an ICP-OES spectrometer as well as a flame emission spectrometer.) If both a flame emission system and an ICP system are available, do Experiments 7.1–7.4 on both instruments and compare the results. Explain your observations in terms of the excitation source temperature, type of nebulizer, and any other instrument variables that apply.
- 7.5 Take a sample containing an unknown quantity (about 3 ppm) of sodium. Split it into four 10 mL aliquots. To the first aliquot add 10 mL of standard sodium solution containing 2 ppm Na. To other aliquots add solutions containing 4 and 6 ppm of Na (10 mL of each, one per aliquot). To the remaining aliquot add 10 mL of deionized water so that all solutions now have a volume of 20 mL. Measure the intensity of Na emission at 589.0 and 589.5 nm. Using the MSA, calculate the Na concentration in the original sample.
- 7.6 Determine the sodium content of the drinking water in your chemistry department or city.

Arc/Spark/GD EMISSION

These experiments are suggested for emission sources for solid samples—GD, spark, DC arc with modern PMT or CCD/CID detectors. Experiments 7.11-7.14 can be made suitable for ICP-OES by dissolution of the solid samples in acid. For example, the point of Experiment 7.10 for solid samples is that the matrix can be a problem. Does that problem exist for ICP-OES if the samples are all in solution? Matrix effects (Experiment 7.10) can be studied in ICP-OES by running one of the copper salts in 5 %, 10 %, and 20 % nitric acid; then 5 % nitric acid plus varying amounts of NaCl (e.g., 5-20 %NaCl), or by running Experiment 7.12 using external calibration standards in acid alone and then using the MSA for brass, bronze, and so on to see if there is a difference in slope which would indicate a matrix effect. Note that if you want to dissolve SiO₂ (Experiment 7.10), you need to use hydrofluoric acid and have an HF-resistant sample introduction system in your ICP. HF is EXTREMELY toxic, causes severe burns which can result in death if not treated immediately and must only be used with the permission and under the supervision of your instructor. Alternatively, go through a molten salt fusion or substitute another material.

- 7.7 Take several 1 g portions of dry graphite powder to be used as the matrix. Add powdered anhydrous copper sulfate to make a powder containing 0.01 %Cu. Load this into the graphite electrode of an emission spectrometer and fire under spark conditions for 3 min. Record the spectrum.
- 7.8 Repeat Experiment 7.7, but record the spectrum after exposures of 1, 3, 5, 7, 10, 15, and 20 min. Measure the intensity of the emission lines at 327.4 and 324.7 nm. Plot the intensity of each line and a background intensity at a suitable position against the exposure time. Note that after a certain period of time, the intensity of the line does not increase, but the background does.

- 7.9 Using graphite powder and anhydrous copper sulfate powder, prepare powders that contain 0.01, 0.05, 0.1, 0.2, 0.5, 0.7, and 1.0 %Cu. Insert each powder separately into the emission spectrometer and expose for 3 min. Measure the intensity of the lines at 324.7 and 327.4 nm. Plot the relationship between intensity and the concentration of the copper. Note that the intensity of the lines goes through a maximum. These are reversible lines.
- 7.10 Repeat Experiment 7.9, but use (a) MgO, (b) SiO_2 , and (c) powdered Al metal as the matrix powder. Note that the changes in the matrix compound cause a variation in the emission from the copper, even though other conditions are constant. This is the matrix effect.
- 7.11 Repeat Experiment 7.9, but use (a) $CuCl_2$, (b) $Cu(NO_3)_2$, (c) Cu acetate, (d) CuO, and (e) CuS as the source of copper. Note the variation in the intensity of the copper emission when different salts are used, even though other conditions are constant. What causes this effect?
- 7.12 Determine the percentage of copper in (a) brass, (b) bronze, (c) a US quarter (or other suitable coin), and (d) a US nickel (or other suitable coin). Record the emission spectra of these samples.
- 7.13 Record the emission spectra of (a) Zn, (b) Sn, (c) Ni, (d) Fe, (e) Co, and (f) Cd.
- 7.14 Based on the emission spectra obtained in Experiments 7.12 and 7.13, what elements are present in (a) brass, (b) bronze, (c) a US twenty five cent coin, and (c) a US five cent coin, or other suitable coins?

ICP EMISSION

- 7.15 Determine the elements present in powdered infant formula by weighing a known amount of formula, dissolving the formula in deionized water and aspirating it into an ICP. Aqueous multielement standards can be used for calibration. Compare your results to the label. Compare your results from this dissolution procedure to a sample of formula you prepare by wet-ashing or dry-ashing.
- 7.16 Determine the elements present in a multivitamin tablet prepared by digestion in concentrated nitric acid and dilution to a suitable volume in deionized water. You may need to filter out a white insoluble powder (or allow it to settle) after digestion. Pharmaceutical tablets often contain silica or titania, which will not dissolve in nitric acid. Aqueous multielement standards in the same concentration of nitric acid should be used for calibration.

PROBLEMS

- 7.1 What is the difference between a monochromator and a polychromator?
- 7.2 When a sample is introduced into a flame, what processes occur that lead to the emission of radiant energy?
- 7.3 Does a spectral interference in the standards for atomic emission cause a positive or negative intercept in the calibration curve? Briefly discuss the possibilities.
- 7.4 List three elements that are commonly analyzed by flame photometry. What is the major use of flame photometry?
- 7.5 In preparing a calibration curve for the determination of potassium by atomic emission spectrometry, the following data were obtained:

nission Intensity
10
410
800
1620
2450
3180
3600
4850

- (a) Plot the results using a spreadsheet. Determine the equation of the calibration curve using linear regression. (b) Which of the results appear(s) to be in error? (c) What should the emission intensity of these point(s) have been assuming the relationship between concentration and intensity is linear? (d) What are you going to do with the data point(s) that appear to be in error? Explain your reasoning (you may want to reread Chapter 1).
- 7.6 The emission intensities from five samples were, respectively, 1020, 2230, 2990, 4019, and 3605 units. The blank prepared with the samples has an intensity of 398. Using the final calibration curve prepared in Problem 7.5 after you have decided what to do with any suspect data, calculate the potassium concentration of the five samples.
- 7.7 The following results were obtained using the standard addition method:

	Emission Intensity from Calcium
Sample alone	5.1
Sample + 0.1 ppm Ca	6.2
Sample + 0.2 ppm Ca	7.3
Sample + 0.5 ppm Ca	10.6
Flame alone	0.7

What was the concentration of calcium in the original sample?

- 7.8 Can a given nonanalyte element present in a sample cause both spectral and nonspectral interferences in atomic emission spectrometry? Explain, with diagrams as necessary.
- 7.9 In preparing a calibration curve for the determination of lithium, the following data were obtained:

Standard Concentration (ppm Li)	Radiation Intensity
0.1	360
0.2	611
0.4	1113
0.6	1602
0.8	2091
1.0	2570

Plot the curve. What was the radiation intensity of the flame with no lithium present (i.e., what is your *y* intercept)? The radiation intensity from a sample containing lithium was measured three times; the intensity readings were 1847, 1839, and 1851. What was the lithium concentration in the sample? Express the result including the uncertainty.

- 7.10 Spectral emission lines in flames are the same width as atomic absorption lines in flames, on the order of 0.01 nm. Why is the spectral bandpass in an atomic emission spectrometer much smaller than that in an AAS?
- 7.11 What causes background emission in atomic emission spectrometry? Consider all of the excitation sources discussed.
- 7.12 What is meant by chemical interference? Compare flame photometry, arc/spark, ICP, and GD sources in the amount of chemical interference exhibited by each technique.
- 7.13 How does emission spectrometry differ from flame photometry? How does this difference affect the number of elements that are detectable by each method? Explain.
- 7.14 Describe and illustrate a graphite electrode used for analysis of powdered samples by DC arc emission spectrometry.
- 7.15 What effect does the matrix have on the intensity of the emission signal in arc/spark emission, ICP emission, and GD emission?
- 7.16 Define the preburn time. Why is it used? Would you expect that (a) gallium and (b) tungsten could be satisfactorily determined in steel using the same preburn time? Explain your answer.

- 7.17 Sketch the components of a Rowland circle monochromator. What is the advantage of this design over a scanning monochromator?
- 7.18 Describe the components and operation of an Echelle monochromator. What are its advantages over a Rowland circle design?
- 7.19 What is the advantage to using a CCD or CID detector for an Echelle spectrometer instead of a PMT or multiple PMTs?
- 7.20 What is meant by matrix effect in atomic emission spectrometry? Give at least two examples.
- 7.21 How is an ICP formed? What gas is used to form the plasma? What other kinds of plasmas are there?
- 7.22 Draw a cross-flow nebulizer and explain its operation. What are its advantages and disadvantages when compared with an USN?
- 7.23 Describe how laser ablation is used for sample introduction. What kinds of samples would you run by laser ablation? Explain your answer.
- 7.24 What is the dynamic analytical range of a typical ICP? How does this compare to AAS? Is there any advantage to using ICP based on its dynamic range?
- 7.25 What are the advantages of using a GD source over a spark source for analysis of solids?
- 7.26 Explain what is meant by a depth profile and how it can be used in analysis of materials.
- 7.27 Compare atomic absorption and atomic emission for qualitative analysis. What are the advantages and disadvantages of each approach?
- 7.28 Compare atomic absorption and atomic emission for quantitative analysis. What are the advantages and disadvantages of each approach?
- 7.29 Draw the processes that occur for (a) resonance fluorescence, (b) Stokes direct-line fluorescence, and (c) anti-Stokes direct-line fluorescence.
- 7.30 What are the advantages of using resonance fluorescence? What is the major disadvantage to its use?
- 7.31 Why are high intensity line sources preferred for AFS over less intense or broad band sources?
- 7.32 What are the advantages of using a laser as the source for AFS? What are the disadvantages?
- 7.33 Briefly describe the spectral interferences in AFS and how they are eliminated or accounted for.
- 7.34 What is meant by saturated fluorescence? Why is saturated fluorescence used for analytical AFS?
- 7.35 Compare atomic fluorescence with atomic absorption and atomic emission. What are the advantages and disadvantages of each technique?
- 7.36 Describe how LIBS works. What are the advantages of LIBS versus other atomic emission techniques?

BIBLIOGRAPHY

American Society for Testing and Materials *Annual Book of ASTM Standards*; ASTM: West Conshohocken, PA, 2000–2001; Vols. 3.05 and 3.06.

Arnaud, C.H. Fingerprinting Conflict Minerals, C&E News, April 30, 2012, www.cen-online.org.

Beaty, R.D.; Kerber, J.D. Concepts, Instrumentation and Techniques in Atomic Absorption Spectrophotometry; PerkinElmer Instruments: Shelton, CT, 1993.

Berneron, R. A Study of Passive Films Formed on Pure Ferritic Steels. Corrosion Science, Vol. 20, Pergamon Press Ltd., Great Britain, 1980.

Boss, C.B.; Fredeen, K.J. *Concepts, Instrumentation and Techniques in Inductively Coupled Plasma Optical Emission Spectrometry*; PerkinElmer Instruments: Shelton, CT, 1999.

Boumans, P.W.J.M. Line Coincidence Tables for Inductively Coupled Plasma Emission Spectrometry; Pergamon Press: New York, 1984; Vols. I and II.

Boumans, P.W.J.M. *Inductively Coupled Plasma Emission Spectroscopy*; Wiley: New York, 1987; Parts 1 and 2.

Broekaert, J.A.C. Glow discharge atomic spectroscopy. Appl. Spectrosc 1995, 49 (7), 12A.

Busch, K.W.; Busch, M.A. Multielement Detection Systems for Spectrochemical Analysis; Wiley: New York, 1990.

Cassap, M. Analysis of Elemental Impurities in Liquid Pharmaceutical Products Using the Thermo Scientific iCAP 6000 Series ICPOES, Application Note 43086, Thermo Fisher Scientific, www. thermo.com.

Chandler, C. Atomic Spectra, 2nd; D. Van Nostrand Co. Inc: Princeton, NJ, 1964.

Cremers, D.A.; Radziemski, L.J. *Handbook of Laser-Induced Breakdown Spectroscopy: Fundamentals and Applications*; John Wiley and Sons Ltd.: Chichester, 2006.

Dean, J.A. Flame Photometry; McGraw-Hill: New York, 1960.

Dean, J.A.; Rains, T.E. *Flame Emission and Atomic Absorption Spectroscopy*; Marcel Dekker, Inc.: New York, 1965–1971; Vols. 1–3.

DeForest, P.R.; Petraco, N.; Kobilinsky, L. Chemistry and the challenge of crime in *Chemistry and Crime*, Gerber, S.M., Ed.; American Chemical Society: Washington, D.C., 1983.

Dorn, S.B.; Skelly Frame, E.M. Development of a high-performance liquid chromatographic-inductively coupled plasma method for speciation and quantification of silicones: from silanols to polysiloxanes. *Analyst* **1994**, 119, 1687–1694.

Dulski, T.R. A Manual for the Chemical Analysis of Metals; ASTM: West Conshohocken, PA, 1996.

Epperson, P.M.; Sweedler, J.V.; Billhorn, R.B.; Sims, G.R.; Denton, M.B. Anal. Chem. 1988, 60, 327A.

Hahn, D.W.; Omenetto, N. Appl. Spectrosc. 2010, 64, 355A.

Hahn, D.W.; Omenetto, N. Appl. Spectrosc. 2012, 66, 347A.

Hareland, W. Atomic emission spectroscopy. In *Analytical Instrumentation Handbook*, ^{2nd}; Ewing, G.W., Ed.; Marcel Dekker, Inc: New York, 1997.

Hark, R.R.; Remus, J.J.; East, L.J.; Harmon, R.S.; Wise, M.A.; Tansi, B.M.; Shughrue, K.M.; Dunsin, K.D.; Liu, C. Geographical analysis of "conflict minerals" utilizing laser-induced breakdown spectroscopy. *Spectrochim. Acta B* **2012** (submitted).

Harmon, R.S.; Shughrue, K.M.; Remus, J.J.; Wise, M.A.; East, L.J.; Hark, R.R. *Anal. Bioanal. Chem.* **2011**, *400*, 3377.

Harnly, J.M.; Fields, R.E. Solid-state array detectors for analytical spectrometry. Appl. Spectrosc 1997, 51 (9), 334A.

Harrison, G.R. MIT Wavelength Tables; The MIT Press: Cambridge, MA, 1969.

Ingle, J.D. Jr.; Crouch, S.R. Spectrochemical Analysis; Prentice Hall: Englewood Cliffs, NJ, 1988.

James, S.H.; Nordby, J.J. *Forensic Science, An Introduction to Scientific and Investigative Techniques*, ^{2nd}; CRC Press: Boca Raton, Florida, 2005.

Kirkbright, G.F.; Sargent, M. Atomic Absorption and Fluorescence Spectroscopy; Academic Press: London, 1974.

Lajunen, L.H.J. *Spectrochemical Analysis by Atomic Absorption and Emission*; The Royal Society of Chemistry: Cambridge, UK, 1992.

Lieberman, M.A.; Lichtenberg, A.J. Principles of Plasma Discharges and Materials Processing; Wiley: New York, 1994

Lonardo, R.F.; Yuzefovsky, A.; Yang, K.X.; Michel, R.G. JAAS 1996, 4, 279.

Marcus, R.K., Ed. Glow Discharge Spectroscopies; Plenum Press: New York, 1993.

Michel, R.G. Atomic fluorescence spectrometry. In *Metallobiochemistry, Part A*; Riordan, J.F.; Vallee, B.L., Eds.; Academic Press: San Diego, CA, 1988, Vol. 158.

Miziolek, A.W.; Palleschi, V.; Schechter, I., Eds. *Laser Induced Breakdown Spectroscopy*, Cambridge University Press: UK, 2006.

Miziolek, A.W. Progress in fieldable laser induced breakdown spectroscopy (LIBS), SPIE-DSS, Baltimore, MD, April 2012.

Montaser, A.; Golightly, D.W., Eds. *Inductively Coupled Plasmas in Analytical Atomic Spectrometry*, ^{2nd}; VCH: New York, 1992.

Myers, M.J.; Myers, J.D.; Myers, A.G. Laser induced breakdown spectroscopy. In *Lasers in Chemistry*, Lackner, M., Ed. Wiley-VCH: Weinheim, Germany, 2008.

Parsons, M.L.; Foster, A. An Atlas of Spectral Interferences in ICP Spectroscopy; Plenum Press: New York, 1980.

Payling, R.; Nelis, T.; Browner, R.; Chalmers, J. *Glow Discharge Optical Emission Spectroscopy: A Practical Guide*; Royal Society of Chemistry: Cambridge, UK, 2003.

Pilon, M.J.; Denton, M.B.; Schleicher, R.G.; Moran, P.M.; Smith, S.B. Appl. Spectrosc. 1990, 44, 1613.

Rehse, S.J.; Salimnia, H.; Miziolek, A.W. Laser-induced breakdown spectroscopy (LIBS): an overview of recent progress and future potential for biomedical applications. J. Med. Engr. Tech. **2012** (http://informahealthcare.com/toc/jmt/current)

Remus, J.J.; Harmon, R.S.; Hark, R.R.; Potter, I.K.; Bristol, S.K.; Baron, D.; Haverstock, G.; East, L.J. *Appl. Optics* **2012**, *51*, B65.

Robinson, J.W., Ed. Handbook of Spectroscopy; CRC Press: Boca Raton, FL, 1974; Vol. 1.

Robinson, J.W. Atomic Spectroscopy; Marcel Dekker: New York, 1990.

- Sacks, R.D. Emission spectroscopy. In *Treatise on Analytical Chemistry*; Elving, P.J.; Meehan, E.; Kolthoff, I., Eds.; Wiley: New York, 1981, Vol. 7.
- Settle, F., Ed. *Handbook of Instrumental Techniques for Analytical Chemistry*; Prentice Hall PTR: Upper Saddle River, NJ, 1997.
- Skelly Frame, E.M.; Suzuki, T.; Takamatsu, Y. Particle characterization by helium microwave induced plasma spectrometry. *Spectroscopy* **1996**, *11*, 1.
- Skelly Frame, E.M.; Uzgiris, E.E. The determination of gadolinium in biological samples by ICP-AES and ICP-MS in evaluation of the action of MRI agents. *Analyst* **1998**, *123*, 675–679.
- Slickers, K.A. Automatic Emission Spectroscopy, 2nd; Bruehlische University Press: Giessen, 1993.
- Sneddon, J., Ed. Sample Introduction in Atomic Spectroscopy; Elsevier: Amsterdam, 1990.
- Sneddon, J., Ed. *Advances in Atomic Spectroscopy*; JAI Press: Greenwich, CT, 1992, 1994; Vols. I and II. Sweedler, J.V.; Jalkian, R.D.; Denton, M.B. *Appl. Spectrosc.* **1989**, *43*, 953.
- Syty, A. Flame photometry. In *Treatise on Analytical Chemistry*; Elving, P.J.; Meehan, E.; Kolthoff, I., Eds.; Wiley: New York, 1981, Vol. 7.
- Thomsen, V.B.E. Modern Spectrochemical Analysis of Metals: An Introduction for Users of Arc/Spark Instrumentation; ASM International: Materials Park, OH, 1996.
- Winchester, M.R.; Lazik, C.; Marcus, R.K. Spectrochim. Acta 1991, 46B, 483.
- Winchester, M.R.; Payling, R. Radio frequency glow discharge spectrometry: a critical review. *Spectrochim. Acta* **2004**, *59B*, 607.
- Yaroshchyk, P.; Body, D.; Morrison, R.J.S.; Chadwick, B.L. Spectrochim. Acta 2006, 61B, 200.
- Zaidel, A.N.; Prokofev, V.K.; Raiskii, S.M.; Slavnyi, V.A.; Shreider, E.Y. *Table of Spectral Lines*, 3rd; IFI/ Plenum Press: New York, 1970.



X-ray Spectroscopy

8

8.1 ORIGIN OF X-RAY SPECTRA

X-rays were discovered in 1895 by Wilhelm Conrad Röntgen who received the first Nobel Prize in Physics, awarded in 1901, for his discovery. X-ray absorption, emission, and fluorescence spectra are used in the qualitative and quantitative determination of elements in solid and liquid samples. X-ray absorption is used in the nondestructive evaluation of flaws in objects, including voids or internal cracks in metals, cavities in teeth, and broken bones in humans, a technique called radiography or X-ray fluoroscopy. This same technique is used to perform security screening of baggage at airports. A computerized version of radiography, computed tomography (CT) scanning or computed axial tomography (CAT) provides a powerful, high-resolution medical diagnostic tool by giving a 3D cross-sectional image of body tissues. Diffraction of X-rays by crystalline materials, a technique called X-ray crystallography, provides crystal structure identification, orientation of atomic planes in materials, and other physical information about samples. X-ray astronomy uses cosmic X-rays to study the universe and X-ray spectrometers have been sent to the moon and Mars to study the surface rocks *in situ*. This chapter will focus primarily on X-ray fluorescence spectrometry (XRF) and X-ray diffractometry (XRD), the techniques of most use to analytical chemists.

X-rays consist of electromagnetic radiation with a wavelength range from 0.005 to 10 nm (0.05-100 Å). X-rays have shorter wavelengths and higher energy than UV radiation. X-rays are generated in several ways, by deceleration of electrons in matter or by electronic transitions of inner core electrons.

8.1.1 ENERGY LEVELS IN ATOMS

An atom is composed of a nucleus and electrons. The electrons are arranged in shells around the nucleus with the valence electrons in the outer shell. The different shells correspond to the different principal quantum numbers of the possible quantum states. The principal quantum number, n, can have integral values beginning with 1. The shells are named starting with the shell closest to the nucleus, which is called the K shell. The K shell is the lowest in energy and corresponds to the quantum level with n=1. The shells moving out from the nucleus are named the L shell, M shell, and so on alphabetically. The letters used for the two lowest shells are historical; K is from the German word kurz, meaning short, L is from the German word lang, meaning long. An atom is shown schematically in Figure 8.1a, with Φ_K , Φ_L , and Φ_M representing the energy of the K, L, and M shells, respectively. A partial list of elements and their electron configurations is given in Table 8.1. For example, a sodium atom contains filled K and L shells and one electron in the M shell.

When an X-ray photon or a fast-moving electron collides with an atom, its energy may be absorbed by the atom. If the X-ray photon or electron has sufficient energy, it knocks an electron out of one of the atom's inner shells (e.g., the K shell) and the atom becomes ionized as shown in Figure 8.1(b). An electron from a higher-energy shell (e.g., the L-shell) then falls into the position vacated by the dislodged inner electron and an X-ray photon is emitted as the electron drops from one energy level to the other [Figure 8.1(c)]. The wavelength (energy) of this emitted X-ray photon is characteristic of the element being bombarded.




FIGURE 8.1 A schematic atom showing the steps leading to the emission of an X-ray photon (a and b) or an auger electron (c and d). (From Jenkins et al. 1981, used with permission.)

A fourth process can also occur, as shown in Figure 8.1(d). Instead of emitting an X-ray photon, the energy released knocks an electron out of the M shell. This electron is called an Auger electron. This Auger process is the basis for a sensitive surface analysis technique. Auger electron spectroscopy and the related method of X-ray photoelectron spectroscopy, based on the measurement of the emitted electron shown in Figure 8.1(b), are discussed in Chapter 13.

If we plot the energy levels of the K, L, and M shells for a given element, we get a diagram similar to Figure 8.2.

Note that the K shell has only one energy level, while the higher shells have sublevels within each shell. If an electron is dislodged from the K shell, an electron from an L or an M shell may replace it. The resulting ion emits radiation with energy *E* equal to the energy difference between the electronic energy levels, such as:

$$(8.1) E_{X-ray} = \Phi_{L} - \Phi_{K}$$

where Φ_L is the energy of the electron in a specific electronic state within the L shell that "drops" to the K shell. Similar equations may be written for other transitions, such as between an M shell sublevel and an L shell sublevel, using the appropriate energy of the electron in the M shell sublevel that drops into the L shell and so on. As we know from Chapter 2,

$$E = hv = hc/\lambda$$

This relationship relates the energy of the emission to the wavelength and can be used to convert wavelength and energy. Most X-ray systems express wavelength in angstroms and energy in keV. To convert between these units, Equation 8.2 gives:

(8.2) Energy (keV) =
$$12.4/\lambda$$
 (Å)

TABLE 8.1 Electron Configurations of Various Elements

		K		L		М		N		
Element	Z	1s		2s	2p	3s	3р	3d	4s	4p
Н	1	1								
He	2	2								
Li	3	2		1						
Ве	4	2		2						
В	5	2		2	1					
C	6	2		2	2					
Ν	7	2		2	3					
Ο	8	2		2	4					
F	9	2		2	5					
Ne	10	2		2	6					
Na	11		Neon core (10)			1				
Mg	12					2				
Al	13					2	1			
Si	14					2	2			
Р	15					2	3			
S	16					2	4			
Cl	17					2	5			
Ar	18					2	6			
K	19			Argon core (18)					1	
Ca	20								2	
Sc	21							1	2	
Ti	22							2	2	
V	23							3	2	
Cr	24							5	1	
Mn	25							5	2	
Fe	26							6	2	
Со	27							7	2	
Ni	28							8	2	
Cu	29							10	1	
Zn	30			Cu+ core (28)					2	
Ga	31								2	1
Ge	32								2	2
As	33								2	3
Se	34								2	4
Br	35								2	5
Kr	36								2	6

Therefore, for the X-ray photon released when an L electron in a specific sublevel drops down to fill a vacancy in the K shell,

$$hv = hc/\lambda = \Phi_{\rm L} - \Phi_{\rm K}$$

Hence, the frequency of the emitted X-ray is:

(8.3)
$$v = (\Phi_{L} - \Phi_{K})/h$$

The frequency or wavelength for transitions between other sublevels and shells is calculated in the same manner. Transitions are not possible between all available energy levels.

As in all forms of spectroscopy, transitions are governed by quantum mechanical *selection rules*. Some transitions are allowed by these rules while others are forbidden. For a brief




FIGURE 8.2 Atomic energy levels and symbols used for some common X-ray transitions. (Modified from Parsons, 1997, used with permission.)

discussion of the selection rules, the interested student should consult the texts by Jenkins or Bertin listed in the bibliography.

X-ray emission lines from electron transitions terminating in the K shell are called K lines, lines from transitions terminating in the L shell are called L lines, and so on. There are three L levels differing by a small amount of energy and five M levels. These sublevels are different quantum states, as shown in Figure 8.2; the quantum numbers and states will not be discussed here in detail. An electron that drops from an L shell sublevel to the K shell emits a photon with the energy difference between these quantum states. This transition results in a K_{α} line. There are two possible K_{α} lines for atoms with atomic number > 9: $K_{\alpha l}$ and $K_{\alpha 2}$, which originate in different sublevels of the L shell. The K_{α} lines are often not resolved, and only one peak is seen. These lines are illustrated in Figure 8.2. The use of a Greek letter and numerical subscript to identify an X-ray emission line is called the Siegbahn notation. For the purposes of this text, the notation is just a "name" for the peak. An electron that drops from an M shell sublevel to the K shell generates a K_B X-ray. There is more than one K_B line, but the energy differences are so small between K_{B1} and K_{B3} that only a single K_B line is seen unless a high-resolution spectrometer is used. If an electron is ejected from an L shell, an electron from an M shell may fall into its place and emit an X-ray of characteristic wavelength with energy equivalent to the difference between the L and M shell sublevels. These are designated as L lines. A number of L lines are possible, as indicated by Figure 8.2. Table 8.2 indicates the actual transition that gives rise to selected X-ray emission lines. Electrons originating in an N or O shell and falling into the L shell also

TABLE 8.2	Electron Transitions for Selected X-Ray
	Emission Lines

Siegbahn Line Designation	Electron Transition			Siegbahn Line Designation	Electron Transition			
Κ _{α1}	L _{III}	\rightarrow	K	 L _{β1}	M _{IV}	\rightarrow	L _{II}	
K_{α_2}	L_{II}	\rightarrow	K	$L_{oldsymbol{eta}_3}$	$M_{\rm III}$	\rightarrow	L_{l}	
K_{β_1}	$M_{\rm III}$	\rightarrow	Κ	L_{β_4}	M_{II}	\rightarrow	L_{l}	
K_{β_3}	M_{II}	\rightarrow	Κ	L_{η}	M_{l}	\rightarrow	L_{II}	
$K_{oldsymbol{eta}_5}$	$M_{IV,V}$	\rightarrow	Κ	$L_{\gamma_{2,3}}$	$N_{\text{II, III}}$	\rightarrow	L_{l}	
K_{β_2}	$N_{\text{II, III}}$	\rightarrow	Κ	L_{β_6}	N_I	\rightarrow	$L_{\rm III}$	
K_{β_4}	$N_{\text{IV, V}}$	\rightarrow	Κ	M_{ξ_1}	$N_{\rm III}$	\rightarrow	$M_{\scriptscriptstyle V}$	
L_{α_1}	M_{V}	\rightarrow	L_{III}	M_{ξ_2}	N_{II}	\rightarrow	M_{IV}	
L_{α_2}	M_{IV}	\rightarrow	L_{III}					


Note: Not all lines are seen for all elements, and many of the lines are not resolved with standard X-ray spectrometers. Many $M \to M$, $N \to M$, $O \to L$, and $O \to M$ transitions have no Siegbahn notation associated with them.

generate L lines. The energy levels of the K, L, M, and higher shells are characteristic of the element being examined and the sharp emission lines resulting from electronic transitions are called *characteristic lines* or characteristic radiation. A schematic X-ray emission spectrum obtained under certain conditions by bombarding a solid metal, such as rhodium or lead or silver, with high-energy electrons is shown in Figure 8.3. The characteristic lines are shown as sharp peaks on a broad continuous background. The characteristic K X-ray emission lines from some elements are given in Table 8.3. A more comprehensive table of K and L lines for the elements is found in Appendix 8.A on the text website and in handbooks such as the *CRC Handbook of Chemistry and Physics* and the *CRC Handbook of Spectroscopy*, Vol. 1. Not all X-ray lines have a Siegbahn designation, so the IUPAC established a new identification system for X-ray lines in 1991. Appendix 8.A contains a list of the Siegbahn notation for lines and the IUPAC designation for these lines. For all new publication purposes the IUPAC designation should be used.

The wavelengths and energies of the characteristic lines depend only on the element, because the inner electrons do not take part in bonding. Therefore, the lines are independent of oxidation state, bonding and physical state, making the use of the characteristic lines an *elemental* analysis technique. No molecular information is obtained from these lines.

The broad continuous "background" emission of X-radiation seen in Figure 8.3 is due to a second process that occurs when high-energy electrons strike a solid. The continuous radiation results from the collision of electrons with the atoms of the solid. At each collision, the electron loses some energy and decelerates, with the production of an X-ray photon. The energy of the photon is equal to the kinetic energy difference of the electron as a result of the collision. Each electron generally undergoes a series of collisions with each collision resulting in a photon of slightly different energy. The result of these many collisions is emission of a continuum of X-rays over a wide wavelength range. This continuous radiation is called *Bremsstrahlung* or *white radiation*.

When all the energy of the impinging electrons is turned into X-rays, as would occur if the electrons transferred all their energy in one collision, the wavelength of the emitted photons is the shortest attainable. This is termed the minimum λ or λ_{\min} . The radiation with the highest energy (and therefore the shortest wavelength) is deduced as follows: when all the energy of the electrons is converted to radiant energy, then the energy of the electrons equals the energy of the radiation. The energy of the radiation is given by E = hv, whereas the energy of the electrons is given by E = eV. When they are equal, hv = eV, where






FIGURE 8.3 X-ray emission spectrum obtained by bombarding **(a)** rhodium metal (Rh) and **(b)** silver metal (Ag) with electrons. Both a broad continuum (Bremsstrahlung) and sharp characteristic emission lines from the metal are seen. **(a)** © Thermo Fisher Scientific (www.thermofisher.com). Used with permission. **(b)** Amptek MINI-X Silver (Ag) XRF Tube output spectrum. Courtesy of Amptek, Inc. (www.amptek.com).]

e is the charge of the electron; V, the applied voltage; and v, the frequency of the radiation. But:

$$v = c/\lambda$$

where c is the speed of light and λ is the wavelength of radiation. Therefore,

$$(8.4) hv = hc/\lambda = eV$$

Rearranging, we get:

$$\lambda = hc/eV$$

TABLE 8.3 Wavelengths of Absorption Edges and Characteristic Emission Lines of Various Elements

	Emission (Å)				
K absorption edge (Å)	$K_{\beta 1,3}^{a}$	$K_{\alpha_{1,2}}^{b}$			
9.512	9.559	9.890			
2.497	2.514	2.748, 2.752			
2.070	2.085	2.290, 2.294			
1.896	1.910	2.102, 2.106			
1.488	1.500	1.658, 1.662			
0.4858	0.4971, 0.4977	0.5594, 0.5638			
0.1582	0.1637, 0.1645	0.1855, 0.1904			
0.1492	0.1545, 0.1553	0.1751, 0.1799			
	9.512 2.497 2.070 1.896 1.488 0.4858 0.1582	K absorption edge (Å) $K_{β1,3}^{a}$ 9.5129.5592.4972.5142.0702.0851.8961.9101.4881.5000.48580.4971, 0.49770.15820.1637, 0.1645			

^a When more than one number is listed, $K_{\beta 1}$ is listed first.

When all the energy of the electron is converted to X-radiation, the wavelength of the radiation is a minimum and we achieve minimum λ conditions:

$$\lambda_{min} = hc / eV$$

Inserting the values for *h*, *c*, and *e*, which are constants, we have the **Duane-Hunt Law**,

(8.7)
$$\lambda_{min} = \frac{(6.626 \times 10^{-34} \text{ J s})(3.00 \times 10^8 \text{ m/s})(10^{10} \text{ Å/m})}{(1.60 \times 10^{-19} \text{ C}) \times \text{V}} = \frac{12,400}{\text{V}}$$

where h is Planck's constant; c, the speed of light; e, the charge of an electron; V, the applied voltage (in volts); and λ_{\min} , the shortest wavelength of X-rays radiated (in angstroms). The continuum radiation spectrum from a solid metal therefore has a well-defined short wavelength limit. This limit is a function of the accelerating voltage, but not of the solid metal. The same λ_{\min} would be obtained by bombardment of lead or tungsten or rhodium at the same accelerating voltage.

An X-ray emission spectrum is similar for all elements, in that K_{α} , K_{β} , and L_{β} lines may be seen, if the element possesses enough electrons to populate the appropriate levels. However, the actual wavelengths of these lines vary from one element to another, depending on the *atomic number* of the particular element. A mathematical relationship was discovered between the wavelengths of the K series and the atomic number of the element, and similar relationships were found for the L lines, and others.

8.1.2 MOSELEY'S LAW

Henry Moseley, a young graduate student working at Cambridge, UK, in 1913, discovered the relationship between wavelength for characteristic X-ray lines and atomic number. After recording the X-ray spectra from numerous elements in the periodic table, he deduced the mathematical relationship between the atomic number of the element and the wavelength of the K_{α} line. A similar relationship was found between the atomic number and the K_{β} line, the L_{α} line, and so on. The relationships were formulated in **Moseley's Law**, which states that

(8.8)
$$v = c/\lambda = a(Z - \sigma)^2$$

where c is the speed of light; λ , the wavelength of the X-ray; a, a constant for a particular series of lines (e.g., K_{α} or L_{α} lines); Z, the atomic number of the element; and σ , a screening

b When more than one number is listed, $K_{\alpha 1}$ is listed first.




FIGURE 8.4 Partial Moseley's law plots for selected K and L lines, showing the relationship between the X-ray emission wavelength and atomic number of the element. Using this relationship, it was possible to predict undiscovered elements and to correctly assign atomic numbers to known elements. (From Helsen and Kuczumow, 2nd ed., used with permission.)

constant that accounts for the repulsion of other electrons in the atom. A partial Moseley's Law plot for the K_{α} , K_{β} , L_{α} , and L_{β} emission lines is shown in Figure 8.4. Shortly after this monumental discovery, Moseley was killed in action in World War I. The impact of Moseley's Law on chemistry was substantial, in that it provided a method of unequivocally assigning an atomic number to newly discovered elements, of which there were several at that time. In addition, it clarified disputes concerning the positions of all known elements in the periodic table, some of which were still in doubt in the early part of the 20^{th} century.

8.1.3 X-RAY METHODS

There are several distinct fields of X-ray analysis used in analytical chemistry and materials characterization; namely, X-ray absorption, X-ray diffraction, X-ray fluorescence, and X-ray emission. The basic principles of each are described below. X-ray emission is generally used for microanalysis, with either an electron microprobe (Chapter 13) or a scanning electron microscope.

8.1.3.1 X-RAY ABSORPTION PROCESS

The absorption spectrum obtained when a beam of X-rays is passed through a thin sample of a pure metal is depicted in Figure 8.5.

As is the case with other forms of radiation, some of the intensity of the incident beam may be absorbed by the sample while the remainder is transmitted. We can write a Beer's Law expression for the absorption of X-rays by a thin sample:

(8.9)
$$I(\lambda) = I_0(\lambda)e^{-(\mu m)\rho x}$$

where $I(\lambda)$ is the transmitted intensity at wavelength λ ; $I_0(\lambda)$, the incident intensity at the same wavelength; μ_m , the **mass absorption coefficient** (in cm²/g); ρ , the density of the sample (in g/cm³); and x, the sample thickness (in cm). The mass absorption coefficient is a constant for a given element at a given wavelength and is independent of both the chemical and physical state of the element. An updated compilation of mass absorption coefficients can be found online at the NIST website: http://www.nist.gov/pml/data/xraycoef/index.cfm (J. H. Hubbell and S. M. Seltzer) or in the text by Bertin or handbooks listed in the bibliography.

Of course, most samples do not consist of a single pure element. The total mass absorption coefficient for a sample can be calculated by adding the product of the individual mass absorption coefficients for each element times the weight fraction of the elements present in the sample. That is, for a metal alloy like steel,

(8.10)
$$\mu_{\text{total}} = w_{\text{Fe}} \mu_{\text{Fe}} + w_{\text{Cr}} \mu_{\text{Cr}} + w_{\text{Ni}} \mu_{\text{Ni}} + \dots$$

where w_{Fe} is the weight fraction of iron and μ_{Fe} is the mass absorption coefficient for pure iron, w_{Cr} is the weight fraction of chromium, and so on for all the elements in the alloy. For accurate quantitative work, the *mass attenuation coefficient* is used in place of the mass absorption coefficient. The mass attenuation coefficient takes into account both absorption and scattering of X-rays by the sample.

The amount of light absorbed increases as the wavelength increases. This is reasonable since longer wavelengths have less energy and a less energetic photon has less "penetrating power" and is more likely to be absorbed. Only a few absorption peaks are seen in an X-ray absorption spectrum, but there is a very distinct feature in these spectra. An abrupt change in absorptivity (or the mass absorption coefficient) occurs at the wavelength of the X-ray necessary to eject an electron from an atom. These abrupt changes in X-ray absorptivity are termed absorption edges. Looking at Figure 8.5, it can be seen that radiation with a wavelength of 1.8 Å has a certain percent absorption value. As the wavelength of the X-ray decreases, its energy increases, its penetrating power increases, and the percent absorption decreases. This can be seen by the downward slope of the absorption trace, moving to the left along the x-axis from a wavelength of 1.8 Å. As the wavelength decreases further, the X-ray eventually has sufficient energy to displace electrons from the K shell. This results in an abrupt *increase* in absorption. This is manifested by the **K** absorption edge. After the absorption edge, the penetrating power continues to increase as the wavelength decreases further until finally the degree of absorption is extremely small at very small wavelengths. At wavelengths less than 0.2 Å, penetrating power is extremely high and we are approaching the properties of interstellar radiation such as cosmic rays, which have extremely high penetrating power. Wavelengths shorter than the K absorption edge have sufficient energy to eject K electrons; the bombarded sample will exhibit both continuum radiation and the





FIGURE 8.5 The X-ray absorption spectrum of a pure metal. Longer wavelengths are more readily absorbed than shorter wavelengths. The absorption spectrum is characterized by absorption edges, which are abrupt increases in absorption at energies sufficient to eject an electron from one of the atomic shells. The K absorption edge occurs at an energy sufficient to eject an electron from the K shell of the given metal.

characteristic K lines for the sample. This process is called X-ray Fluorescence (XRF) and will be discussed in detail. Wavelengths just slightly longer than the K absorption edge do not have enough energy to displace K electrons. The absorption spectrum is unique for each element; portions of the absorption spectrum showing the position of the K absorption edge for several pure elements are shown in Figure 8.6.

Another way of looking at X-ray absorption is to plot the mass absorption coefficient as a function of wavelength or energy. For a thin sample of pure metal and a constant incident






FIGURE 8.6 (a) Energies of the K absorption edges for several pure elements. (Courtesy of ORTEC (Ametek) [www.ortec-online.com]. From Jenkins et al., 1981, Used with permission.) (b) Energies of the K absorption edge plotted schematically for the main elements in steel. (Courtesy of the University of Western Ontario XRF Short Course, London, ONT, Canada.)




FIGURE 8.7 The mass absorption coefficient for Pb as a function of energy. The K, L, and M absorption edges are seen. (Courtesy of ORTEC (Ametek) [www.ortec-online.com]. From Jenkins et al., 1981, Used with permission.)

intensity, Equation 8.9 indicates that if the percent absorption changes as a function of wavelength, it must be that μ_m changes. A plot of μ_m versus X-ray energy for the element lead is shown in Figure 8.7. The K, L, and M absorption edges are seen.

The wavelengths of the absorption edges and of the corresponding emission lines do not quite coincide, as seen in Figure 8.6(b). This is because the energy required to dislodge an electron from an atom (the absorption edge energy) is not quite the same as the energy released when the dislodged electron is replaced by an electron from an outer shell (emitted X-ray energy). The amount of energy required to displace the electron must dislodge it from its orbital and remove it completely from the atom. This is more than the energy released by an electron in an atom falling from one energy level to another. A few absorption edge values are given in Table 8.3. Figure 8.6(b) shows that the energy of the K absorption edge is greater than the energy of the K emission lines. As opposed to emission spectra, only one K absorption edge is seen per element, since there is only one energy level in the K shell. Three absorption edges of different energies are observed for the L levels, five for the M levels, and so on; these can be seen in Figure 8.7. A comprehensive table of absorption edge wavelengths is located in Appendix 8.B.

8.1.3.2 X-RAY FLUORESCENCE PROCESS

X-rays can be emitted from a sample by bombarding it with electrons, alpha particles or with other X-rays. When electrons or alpha particles are used as the excitation source, the process is called X-ray emission or particle induced X-ray emission (PIXE). This is the basis of X-ray microanalysis using an electron microprobe (Chapter 13) or a scanning electron microscope. An alpha particle X-ray spectrometer (APXS) is currently on the Mars Curiosity rover collecting data on Martian rock composition.

When the excitation source is a beam of X-rays, i.e., photons, the process of X-ray emission is called fluorescence. This is analogous to molecular fluorescence discussed in Chapter 5 and atomic fluorescence discussed in Chapter 7, because the wavelength of excitation is shorter than the emitted wavelengths. The beam of exciting X-rays is called the *primary* beam; the X-rays emitted from the sample are called *secondary* X-rays. The use of an X-ray source to produce secondary X-rays from a sample is the basis of XRF spectroscopy. The primary X-ray beam must have a λ_{min} that is shorter than the absorption edge of the element to be excited.

8.1.3.3 X-RAY DIFFRACTION PROCESS

Crystals consist of atoms, ions or molecules arranged in a regular, repeating three-dimensional (3D) pattern called a crystal lattice. This knowledge came from the pioneering work of German physicist Max von Laue and the British physicists, W.H. Bragg, and W.L. Bragg. Max von Laue demonstrated in 1912 that a crystal would diffract X-rays, just as a ruled grating will diffract light of a wavelength close to the distance between the ruled lines on the grating. The fact that diffraction occurs indicates that the atoms are arranged in an ordered pattern, with the spacing between the planes of atoms on the order of short wavelength electromagnetic radiation in the X-ray region. The diffraction pattern could be used to measure the atomic spacing in crystals, allowing the determination of the exact arrangement in the crystal, the *crystal structure*. The Braggs used von Laue's discovery to determine the arrangement of atoms in several crystals and to develop a simple 2D model to explain XRD.

If the spacing between the planes of atoms is about the same as the wavelength of the radiation, an impinging beam of X-rays is reflected at each layer in the crystal, as shown in Figure 8.8. Assume that the X-rays falling on the crystal are parallel waves that strike the crystal surface at angle θ . That is, the waves O and O' are in phase with each other and reinforce each other. In order for the waves to emerge as a reflected beam after scattering from atoms at points B and D, they must still be in phase with each other, that is, waves Y and X must still be parallel and coherent. If the waves are completely out of phase, their amplitudes cancel each other; they are said to interfere destructively and no beam emerges. In order to get reinforcement, it is necessary that the two waves stay in phase with each other after diffraction at the crystal planes.

It can be seen in Figure 8.8 that the lower wave travels an extra distance AB + BC compared with the upper wave. If AB + BC is a whole number of wavelengths, the emerging beams Y and X will remain in phase and reinforcement will take place. From this deduction, we can calculate the relationship between the wavelengths of X-radiation, the distance d between the lattice planes, and the angle at which a diffracted beam can emerge. We employ the following derivation.

X-ray waves O and O' are parallel. The extra distance traveled by wave O' in traveling through the crystal is AB + BC. For diffraction to occur, it is necessary that this distance be a whole number of wavelengths, n; that is,

(8.11) distance
$$AB + BC = n\lambda$$

but

$$(8.12) AB + BC = 2AB$$

and

$$(8.13) AB = DB \sin \theta$$

where θ is the angle of incidence of the X-ray beam with the crystal; therefore:




FIGURE 8.8 Diffraction of X-rays by crystal planes.

where d is the distance between the crystal planes, called the interplanar distance. (Note from Figure 8.8 that d = DB).

Therefore:

$$AB + BC = n\lambda = 2AB = 2d \sin \theta$$

or

$$(8.15) n\lambda = 2d\sin\theta$$

The equation $n\lambda = 2d \sin\theta$ is known as the **Bragg equation**. The important result of this equation is that at any particular angle of incidence θ , only X-rays of a particular wavelength fulfill the requirement of staying in phase and being reinforced, and are therefore diffracted by the crystal. Diffraction of X-rays by crystals forms the basis of XRD for crystal structure determination and is also the reason XRF spectrometry is possible, as will be seen.

8.2 X-RAY FLUORESCENCE

When a sample is placed in a beam of X-rays, atoms in the sample are excited by the X-rays and emit X-rays of *characteristic* wavelengths (energies) from the elements in the sample. This process is called *X-ray fluorescence*. Since the wavelength (energy) of the fluorescence is characteristic of the element being excited, measurement of this *wavelength or energy* enables us to *identify* the fluorescing element. Tables of X-ray lines are given in the appendices of this chapter. The *intensity* of the fluorescence depends on *how much* of that element is in the sample. For most laboratory XRF equipment, the energy of the emitted X-ray is independent of the chemical state of the element; therefore, XRF is generally considered to be an elemental analysis method. Solid and liquid samples can be analyzed directly.

Instrumentation for X-ray spectrometry requires a source, a wavelength (or energy) selector, a detector and beam conditioners. Component parts of the instrument are similar for XRF, XRD, and the other fields, but the optical system varies for each one. One major point to note is that some systems have the source located above the sample (the sample is face-up to the X-ray beam); other systems have the source located below the sample, with the sample face-down to the beam. There are advantages and disadvantages to both designs, as will be discussed.


Generally, we can distinguish between two main techniques in XRF, energy dispersive XRF and wavelength dispersive XRF, as can be seen in Figure 8.9. Energy dispersive XRF (EDXRF) is based on a detector which can discriminate the various photon energies and count them individually, whereas wavelength dispersive XRF (WDXRF) is based on a set of analyzer crystals which only diffract one energy (wavelength) into a detector which counts all the photons. The subsequent instrumentation section will illustrate the components and setups used in today's commercially available instrumentation. EDXRF is sometimes called EDX or EDS (energy dispersive spectroscopy). It must be stressed that all X-ray systems use ionizing radiation which poses significant health hazards. X-ray systems of all types are regulated and commercial systems have the proper shielding and safety interlocks to comply with regulatory requirements and prevent accidental exposure to radiation.

8.2.1 X-RAY SOURCE

Three common methods of generating X-rays for analytical use in the laboratory or the field are:


1. Use of a beam of high-energy electrons to produce a broad band *continuum* of X-radiation resulting from their deceleration upon impact with a metal target as well as element-specific X-ray *line* radiation by ejecting inner core electrons from the target metal atoms. This is the basis of the X-ray tube, the most common source used in XRD and XRF.

EDXRF



E / keV

WDXRF






FIGURE 8.9 Schematic comparison of EDXRF and WDXRF. The upper squares show the differences in instrument configuration, while the lower squares show the resulting spectra. B indicates the background radiation, while 1, 2, and 3 (P1, P2, P3) are photons of different energies.

В

- 2. Use of an X-ray beam of sufficient energy (the primary beam) to eject inner core electrons from a sample to produce a secondary X-ray beam (XRF).
- 3. Use of a radioactive isotope which emits very high energy X-rays (also called gamma radiation) in its decay process.

A fourth method of producing X-rays employs a massive, high-energy particle accelerator called a synchrotron. These are available at only a few locations around the world, such as the Brookhaven National Laboratory or the Stanford Accelerator Center in the US, and are shared facilities servicing a large number of clients. X-rays may be generated when alpha particles or other heavy particles bombard a sample; this technique is called particle-induced X-ray emission (PIXE) and requires a suitable accelerator facility. The use of an electron beam to generate X-rays from a microscopic sample as well as an image of the sample surface is the basis of X-ray microanalysis using an electron microprobe or scanning electron microscopy.

These different X-ray sources may produce either broad band (continuum) emission or narrow line emission, or both simultaneously, depending on how the source is operated. Figure 8.3 displays the simultaneous generation of both a broad continuum of X-ray energies with element-specific lines superposed upon it, obtained by bombarding rhodium metal with electrons in an **X-ray tube**.

8.2.1.1 X-RAY TUBE

A schematic X-ray tube is depicted in Figure 8.10. The X-ray tube consists of an evacuated glass or ceramic envelope containing a wire filament cathode and a pure metal anode. A thin beryllium window sealed in the envelope allows X-rays to exit the tube. The envelope is encased in lead shielding and a heavy steel jacket with an opening over the window, to protect the tube. When a cathode (a negatively charged electrode) in the form of a metal wire is electrically heated by the passage of current, it gives off electrons, a process called thermionic emission. If a positively charged metallic electrode (called an anode) is placed near the cathode *in a vacuum*, the negatively charged electrons will be accelerated toward the anode. Upon striking it, the electrons give up their energy at the metallic surface of the anode. If the electrons have been accelerated to a high enough velocity by a sufficiently high voltage between the cathode and anode, energy is released as radiation of short wavelength (0.1-100 Å), called X-radiation or X-rays. X-ray tubes are generally operated at voltage differentials of 2-100 kV between the




FIGURE 8.10 (a) Schematic diagram of a side-window X-ray tube used for X-ray fluorescence. (b) Schematic of the 4.0 kW ceramic end-window X-ray tube, called the Super Sharp Tube[™]. (c) Close-up of the window end of the Super Sharp Tube[™], showing the circular cathode design of this tube. [(b) and (c) Courtesy of Malvern Panalytical Inc., Almelo, The Netherlands (www. malvernpanalytical.com). Used with permission.] (d) Schematic side view of an end-window X-ray tube showing the Be window and cooling water. (© 2020 Bruker, Inc. [www.bruker.com]. Used with permission.)

wire filament cathode and the anode. Figure 8.10(a) shows the window on the tube side. All modern tubes have the window in the end of the tube as in Figures 8.10(b) and (c).

The cathode is normally a tungsten-based wire filament. The anode is called the target. The X-ray tube is named for the anode; a copper X-ray tube has a copper anode, a rhodium tube has a rhodium anode, a tungsten tube has a tungsten anode; all have tungsten-based wire cathodes. The target is usually not a solid metal but a copper slug coated with a layer of the desired target material. Numerous metals have been used as target materials, but common target elements are titanium, copper, chromium, molybdenum, rhodium, gold, silver,

palladium, and tungsten. The target material determines the characteristic emission lines and affects the intensity of the continuum. The voltage between the anode and cathode determines how much energy the electrons in the beam acquire, and this in turn determines the overall intensity of the wide range of X-ray intensities in the continuum distribution and the maximum X-ray energy (shortest wavelength or λ_{\min} , as shown by the Duane-Hunt Law, Equation 8.7). Figure 8.11 shows how both the intensity of the continuum radiation and the short wavelength/high energy cutoff vary as the applied voltage to this silver (Ag) X-ray tube varies. This illustration also shows that the Ag L line emission varies as a function of the excitation.




FIGURE 8.11 (a) Amptek Mini-X Silver output spectrum at various voltages. 10 kV starts on the left side of the diagram; the curves increase in voltage moving from left to right. Below 30 kV only continuum radiation is seen. The high energy cutoff increases as the voltage increases and the Ag L line emission intensity increases with voltage. (Courtesy of Amptek, Inc. [www.amptek. com].) (b) The intensity of the continuum radiation from an X-ray tube and the short wavelength cut-off vary as the applied voltage varies. This plot is of a tungsten X-ray tube. (c) The characteristic radiation from an X-ray tube also varies as the applied voltage varies. Below 20 kV, the intensity of the tungsten L_{a1} line is very low. The intensity of this characteristic line increases as the applied voltage increases.

In choosing the element to be used for the target, it should be remembered that it is necessary for the energy of the X-rays emitted by the source to be greater than that required to excite the element being irradiated in an XRF analysis. As a simple rule of thumb, the target element of the source should have a greater atomic number than the elements being examined in the sample. This ensures that the energy of radiation is more than sufficient to cause the sample element to fluoresce. This is not a requirement in X-ray absorption or XRD, where excitation of the analyte atoms is not necessary. In XRD, the target is chosen to avoid the excitation of characteristic X-ray (XRF) emissions from the sample. For example, copper (Cu) target-based XRD units can excite the iron (Fe) commonly found in geological samples and the fluorescence from the sample will increase the background of the measurement. Using a cobalt (Co) target will avoid this.

In many high-power (>200 Watt) X-ray tube designs, the anode, or target, gets very hot during use because it is exposed to a constant stream of high-energy electrons, with most of the energy being dissipated as heat on collision. This problem is overcome by water-cooling the anode. Modern low power and compact X-ray tubes have been designed to operate at lower voltages and do not require any liquid based cooling of the anode.

The exit window of the X-ray tube is usually made of beryllium, which is essentially transparent to X-rays. The Be window is thin, generally 0.3-0.5 mm thick, and is very fragile. The window may be on the side of the tube, as shown in Figure 8.10(a), or in the end of the tube [Figures 8.10(b), (c), and (d)]. Side-window tubes are now obsolete; modern end-window tubes permit the use of a thinner beryllium window. This makes end-window tubes good for low energy X-ray excitation by improving the low-energy output of the tube. To minimize the tube size, a transmission target can be used. The target is a layer of the target element on the beryllium window. For example, a silver transmission target can be constructed from a 0.75 μm thick layer of Ag on a 127 μm thick Be window. Figure 8.12 shows both the schematic of a side and transmission target rhodium X-ray tube.

X-ray tubes must provide adequate intensity over a relatively wide spectral range for XRF in order to excite a reasonable number of elements. In some applications, monochromatic or nearly monochromatic X-rays are desired; that is accomplished by using filters or a monochromator as described below or by using a secondary fluorescent source, described subsequently. The tube output must be stable over short time periods for the highest precision and over long time periods for accuracy without frequent recalibration. The X-ray emission lines




FIGURE 8.12 Schematic diagrams of a Rh target side-window tube (ARTAX system) and a modern handheld transmission target design (TRACER system). (Courtesy of Roald Tagle, BRUKER NANO GmbH, Berlin. © 2020 Bruker, Inc. Used with permission.)




FIGURE 8.13 (a) The primary X-ray emission from a tungsten target. (b) The secondary emission from a copper target. Note the removal of the continuum radiation and the nearly monochromatic output from the secondary target. (From Parsons, used with permission.)

from the anode element must not interfere with the sample spectrum. Tube lines can be scattered into the detector and be mistaken for an element present in the sample.

8.2.1.2 SECONDARY XRF SOURCES

If it is necessary to prevent the continuum emission from an X-ray tube from scattering on a sample, a standard tube can be used to excite another pure metal target. The resulting XRF from the secondary target is used as the source of X-ray excitation for the sample. Such an example is shown in Figure 8.13. A standard tungsten X-ray tube is used to produce the emission spectrum on the left, with the tungsten characteristic lines superimposed on the continuum radiation. The radiation from this tube is used to strike a secondary pure copper target. The resulting emission from the copper is the copper XRF spectrum on the right.

This source emits very little or no continuum radiation but does emit quite strongly at the copper K and L lines. Of course, the metal used in the target of the first source must have a higher atomic number than copper to generate fluorescence. The Cu lines then can be used as an excitation source, although the intensity of the secondary source is much less than that of a Cu X-ray tube. However, when monochromatic or nearly monochromatic radiation is required, the loss of intensity is more than offset by the low background from the secondary source.

8.2.1.3 RADIOISOTOPE SOURCES

X-radiation is a product of radioactive decay of certain isotopes. The term gamma ray is often used for an X-ray resulting from such a decay process. Alpha and beta decay and electron capture processes can result in the release of gamma rays. Table 8.4 lists some common radioisotopes used as XRF sources.

The advantages of radioisotope sources are that they are small, rugged, portable, and do not require a power supply. They are ideal for obtaining XRF spectra from large samples or field measurements while not requiring any power, enabling small compact units with long operation times. Examples include the analysis of bulky objects that cannot have pieces cut from them, such as aircraft engines, ship hulls, and art objects. The disadvantage is that the intensity of these sources is weak compared with that of an X-ray tube, the source cannot be

Isotope	Primary Decay Mode	Half-life (years)	Useful Photon Energies Emitted	% Theoretical Yield ^a	Typical Activity (mCi)
⁵⁵ Fe	Electron capture	2.7	5.9, 6.4 keV Mn K X-rays	28.5	5–100
¹⁰⁹ Cd	Electron capture	1.3	22.2-25.5 keV Ag K X-rays	102	0.5-100
			88.2 keV γ -ray	4	
²⁴¹ Am	Alpha	458	14–21 keV Np L X-rays	37	1-50
			59.6 keV γ -ray	36	
⁵⁷ Co	Electron Capture	0.74	6.4, 7.1 keV Fe K X-rays	51	1
			14.4 keV γ-ray	8.2	
			122 keV γ -ray	88.9	
			136 keV γ-ray	8.8	
³ Hb	Beta	12.3	Bremsstrahlung source, endpoint at 18.6 keV		3000-5000
¹⁴⁷ Pm	Beta	2.6	Bremsstrahlung source, endpoint at 225 keV		500

Source: Table from Jenkins, R. et al., Quantitative X-Ray Spectrometry, Marcel Dekker, Inc., New York, 1981. Used with permission.

optimized by changing voltage as can be done with an X-ray tube and the source intensity decreases with time depending on the half-life of the source. In addition, the source cannot be turned off. This requires care on the part of the analyst to avoid exposure to the everpresent ionizing radiation. Isotope sources are more regulated than tube-based sources and although isotope sources are convenient for portable XRF systems, tube-based portable and handheld devices are more common. Isotope source uses are currently limited to K-line excitation approaches as well as for economical dedicated analyzers, such as for Pb in paint.

8.2.2 INSTRUMENTATION FOR ENERGY DISPERSIVE X-RAY SPECTROMETRY

In EDXRF spectrometry, there is no physical separation of the fluorescence radiation from the sample. There is no dispersing device prior to the detector. All of the photons of all energies arrive at the detector simultaneously. Any energy dispersive XRF (EDXRF) is designed around the following components- a source of primary excitation, a sample holder and a detector, seen in Figure 8.14.

All EDXRF systems are able to modify the primary signal to control the excitation of the sample. This is achieved by different means which results in three groups of systems: direct excitation, secondary or 3D excitation, and total reflectance XRF (TXRF).

In direct excitation systems, the source is directed towards the sample thus exciting the sample directly with the radiation from the target or isotope source (Figure 8.15). To modify the excitation or attenuate undesired parts of the excitation spectra, primary beam filters are used. To reduce the spot size and enable "micro" spot analysis, pinhole masks are in use as well. For micro spots below 100 microns in certain units, capillary optics are used. Typical direct excitation units are all handheld units, isotope-based units, the majority of low power and medium power benchtop EDXRF systems as well as the micro-XRF and dedicated plating thickness XRF units (Figure 8.16).

In secondary excitation units, the source is used to illuminate a selectable secondary target which is made of specific material to either scatter the beam or to act as a new "source". The geometric arrangement is such that the signal from the secondary target illuminates the sample and also ensures that the X-ray beam is polarized.

^a Photons per 100 decay transformations.

^b Radioactive tritium gas is adsorbed on nonradioactive metal foil, such as titanium foil.




FIGURE 8.14 (a) A schematic energy dispersive XRF system with an X-ray tube source. There is no dispersion device between the sample and the detector. Photons of all energies are collected simultaneously. (From Ellis, used with permission.) (b) A commercial Benchtop EDXRF spectrometer, the Rigaku NEX QC, set up to measure sulfur in crude oil. (Courtesy of Applied Rigaku Technologies, Inc., [www.rigakuedxrf.com].) (c) Component-based compact XRF kit, showing relative positions of the X-ray tube (top), the sample (right), and the X-ray spectrometer (bottom). (d) The compact component kit as part of a complete XRF system. [(c) and (d) Courtesy of AMPTEK, inc. (www.amptek.com).]

Total reflectance XRF systems use a secondary target and the principle of Bragg diffraction to create a more monochromatic beam. This beam is directed at very low incident angle to the sample to achieve "total reflectance". The signal from the sample, which has to be prepared as very thin film or micro powder will exhibit a very low background and thus an excellent signal-to-noise ratio. These systems are quite compact, as seen in Figure 8.17(b).

8.2.2.1 EXCITATION SOURCE

Most tubes in EDXRF systems are end-window or transmission target designs. For secondary target and mobile XRF units, side-window tubes are used. Tube voltage and excitation is




FIGURE 8.15 Schematic 3D view of a direct excitation EDXRF system. (© 2020 Bruker, Inc. [www.bruker.com]. Used with permission.)




FIGURE 8.16 Schematic drawing of a 3D beam of a secondary target EDXRF system. (Modified from a diagram provided by Bruno Vrebos, courtesy of Malvern Panalytical Inc., Almelo, the Netherlands [www.malvernpanalytical.com]. Used with permission.)

limited to usually 50 or 60 kV for handheld, portable, and benchtop devices. High voltages (≥ 100 kV) require more shielding and therefore require large floor units.

8.2.2.2 PRIMARY BEAM MODIFIERS

Primary beam filters, beam masks, and other devices are used to modify the excitation from the source. One of the problems with using an X-ray tube is that both continuum and characteristic line radiation are generated at certain operating voltages, as seen in Figure 8.3. For many analytical uses, only one type of radiation is desired. Filters of various materials can be used to absorb unwanted radiation but permit radiation of the desired wavelength to pass by placing the filter between the X-ray source and the sample.





FIGURE 8.17 (a) Schematic drawing of a TXRF system. From left to right is the X-ray source, the synthetic multilayer monochromator (Section 8.2.3.2), the thin sample on a support, the SDD detector above the sample and finally a beam-stop. **(b)** A commercial TXRF spectrometer, the Bruker S2 PICOFOX with its laptop computer. The displayed spectrum shows the high S/N ratio. (© 2020 Bruker, Inc. [www.bruker.com]. Used with permission.)

Primary beam filters are used to modify the excitation spectra by making use of characteristic, selective absorption. The nature of the material and thickness of the material are the parameters used to tune the primary excitation. Filters are customized based upon the target material and application. Manual filters are inserted by the user into the beam path whereas automatic filters are generally arranged in a wheel-like fashion and controlled by the instrument software (Figure 8.15).

A simple example of how a filter is used is shown in Figure 8.18. The solid line spectrum is the output of a Rh tube operated at 20 kV with no filter between the tube and the detector. The Rh L_{α} line at 2.69 keV is seen, along with a broad continuum of X-rays from 4 to 19 keV. If the Rh L_{α} line gets scattered into the detector, as it can from a crystalline sample, it can be mistaken for an element in the sample or may overlap another line, causing spectral interference. Placing a cellulose filter over the tube window causes the low energy Rh characteristic line to be absorbed; only the continuum radiation reaches the detector, as shown by the dotted line spectrum.

Alternatively, when monochromatic radiation is desired, a filter is chosen with its absorption edge between the K_{α} and the K_{β} emission lines of the target element or between the continuum and the characteristic emission lines of the target. Using an Al filter in front of a silver X-ray tube removes most of the continuum radiation (Bremsstrahlung) between 5 and




FIGURE 8.18 The use of a filter to remove unwanted radiation from entering the spectrometer is demonstrated. A cellulose filter placed between a Rh X-ray tube and the sample removes the Rh L_{α} line at 2.69 keV and allows only the continuum radiation to excite the sample. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

15 keV; the light reaching the sample is essentially the characteristic line or lines of the target [Figure 8.19(a)]. As seen in Figure 8.19(b), using the correct filter greatly improves the signal to background ratio of the sample spectrum, which will reduce uncertainty in the measurement of these lines and improve quantitative analysis.


Filters are commonly thin metal foils, usually pure elements, but some alloys such as brass and materials like cellulose are used. Varying the foil thickness of a filter is used to optimize peak-to-background ratios. Commonly used filters for various targets are listed in Tables 8.5 and 8.6.

Applications of primary beam filters include:


- Attenuation or suppression of the characteristic tube lines (e.g., Rh K_{α}) to enable determination of the target element or neighboring elements (Cd, Ag)
- Attenuation of elemental ranges (e.g., removal of all energies below 10 kV)
- Optimization of Signal-to-Noise (Signal to background) levels
- Use as "secondary" targets to emit the target radiation in addition to the nonabsorbed source radiation

In addition, the primary beam filter units can be equipped with a beam reducing device referred to as a mask or pinhole collimator. The device is based on the complete absorption of the primary beam except what passes through the opening. The smaller the reduced beam diameter, the more signal is being eliminated, thus reducing the signal from the sample. Units with small spot capability therefore are usually higher power (e.g., 50 Watts) to compensate for the decreased signal.

Beam restrictors and concentrators using capillary optics concentrate the beam on a small spot without the loss of signal from masks. Commercial units can achieve spot sizes of 25 microns with suitable intensity. Masks and beam restrictors are used to observe microscopic regions within a sample and, using raster techniques, can provide elemental image maps of samples that are heterogeneous.



Mini-X-Ag Output Spectrum with and without 80 mil (2 mm) Aluminum (Al) Filter






FIGURE 8.19 (a) Output spectra of the Mini-X silver X-ray tube at 40 kV unfiltered and filtered with 2 mm Al. The filter removes the majority of the continuum radiation. (b) A Pb sample analyzed with and without a filter on the Ag X-ray tube. With no filter, the Pb characteristic X-rays are superimposed on a large background of scattered X-rays. With the Al filter, the signal to background ratio for Pb is greatly improved. Note that the Pb ${\rm L}\gamma$ is much more visible in the filtered spectrum. (Courtesy of Amptek, Inc. [www.amptek.com].)

8.2.2.3 SAMPLE HOLDERS

XRF is used for the analysis of solid and liquid samples and similar sample holders and autosamplers are used for both EDXRF and WDXRF. Sample preparation and other considerations will be discussed in the applications section. For quantitative analysis, the surface of the sample must be as flat as possible, as will be discussed in the applications section.

TABLE 8.5 Filters for Commonly Available X-ray Tubes

Target	Target K _a (Å)	Target K _s (Å)	Filter Flement	Filter K-edge (Å)	Foil Thickness (µm)	% K _s Absorbed
larget	larget it _α (A)	larget K _β (A)	Lieilieile	(A)	(μπ)	70 K _β Absorbed
Cr	2.289	2.085	V	2.269	15.3	99.0
Fe	1.936	1.757	Mn	1.896	12.1	98.7
Co	1.789	1.621	Fe	1.743	14.7	98.9
Ni	1.658	1.500	Co	1.608	14.3	98.4
Cu	1.541	1.393	Ni	1.488	15.8	97.9
Мо	0.709	0.632	Zr	0.689	63.0	96.3
Ag	0.559	0.497	Pd	0.509	41.3	94.6
W	0.209	0.185				

Source: From Parsons, used with permission.

Note: No suitable filter is available for tungsten.

TABLE 8.6 Typical Primary Beam Filters and Range of Use in EDXRF Systems

	Thickness	X-ray Tube		
Filter	(μ m)	Range (kV)	Elements	Comments
None		4–50	Na-Ca	Optimum for light elements, 4–8 kV excitation ^a
Cellulose		5–10	Si–Ti	Suppresses tube L lines
				(Figure 8.18) ^a
Al, thin	25-75	8–12	S-V	Removes tube L lines ^a
Al, thick	75-200	10-20	Ca–Cu	Used for transition elements
Anode element, thin	25-75	25-40	Ca–Mo	Good for trace analysis ^b
Anode element, thick	100-150	40-50	Cu-Mo	Trace analysis with heavy element L lines ^b
Cu	200-500	50	>Fe	Suppresses tube K lines

Source: Table modified from Ellis, used with permission.

There are two classes of sample holders: cassettes for bulk solid samples and cells for loose powders, small drillings, and liquids. A typical cassette for a flat bulk solid such as a polished metal disk, a pressed powder disk, a glass or polymer flat is shown in Figure 8.20(a). The cassette is a metal cylinder, with a screw top and a circular opening or aperture, where the sample will be exposed to the X-ray beam. The maximum size for a bulk sample is shown. The sample is placed in the cassette. For a system where the sample is analyzed face down, the cassette is placed with the opening down and the bulk sample sits in the holder held in position by gravity, as shown in Figure 8.20(b). If the system requires the sample face-up, the body of the cassette must be filled with an inert support (often a block of wood) to press the sample surface against the opening. These cassettes are available with a variety of apertures, usually from 8 to 38 mm in diameter, to accommodate samples of different diameters. Other types of solid samples, such coatings on a solid substrate can be placed directly in this type of cassette.

The analysis of liquids, loose powders, or small pieces requires a different holder. The cells for these types of samples are multipart plastic holders, shown in Figure 8.21(a) and require squares or circles of thin polymer film to hold the sample in the cell. The body of the cell is a cylinder open on both ends. One end of the cylinder is covered with the plastic film (or even clear plastic adhesive tape) and the film or tape is clamped into place by a plastic ring. The cell is placed with the film down and the sample of liquid, powder, or filings is added. The film

^a He purge or vacuum path needed to avoid attenuation of low energy lines.

b Serves as a secondary fluorescence source, also called a monochromatizing filter; preferentially transmits tube K lines.




FIGURE 8.20 (a) Sample cassette for bulk solid samples. (b) Position of a bulk solid in the face-down configuration used in many spectrometers. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

surface should be completely covered, as uniformly as possible. A plastic disk that just fits into the cell is inserted and pressed against the sample to obtain as flat a surface as possible and a top cap is screwed or pressed on. For liquid samples, a vented top is used to avoid pressure build-up from heating of the sample by the X-ray beam. This assembled cell may be used "as is" or may be inserted into a standard cassette, as shown in Figure 8.21(b) in a face-down configuration. As you can imagine, if the thin polymer film breaks, samples of loose powder, chips, or liquid will spill into the interior of the spectrometer, contaminating the system and possibly breaking the Be window of the X-ray tube, if the tube is below the sample. It is for this reason that liquid sample cells are vented and that a vacuum is not used. This is the main disadvantage of the face-down configuration; for anything other than bulk samples, there is a risk of contaminating the instrument if the film covering the sample ruptures. Figure 8.21(b) shows that in the face-down configuration, a liquid naturally assumes a flat surface. Imagine what the liquid sample would look like face-up. An air bubble will form at the film surface if a sealed cell is used and not filled completely. A bubble may form at the surface by heating of the sample in the X-ray beam if the cell is filled completely. If this occurs, the intensity of X-ray fluorescence from the sample will drop dramatically and the possibility of film rupture as the pressure in the cell builds increases dramatically. So, if liquid samples must be analyzed, the face-down configuration gives better quantitative results, even at the risk of contaminating the spectrometer.

Polymer films used to cover the cell opening must be low in trace element impurities, strong enough to hold the sample without breaking, thermally stable, and chemically inert. They certainly must not be soluble in any liquid samples to be analyzed. Films of polyester (Mylar*), polyimide (Kapton*), polycarbonate, polypropylene, and fluoropolymer (Teflon*) are commonly used, with film thickness ranging about 3-8 μ m. Films of different composition and thickness transmit X-rays to varying degrees (Figure 8.22), and the film chosen must transmit the wavelengths for the elements to be measured in the sample.

The sample cassette is moved into position, either manually or with an automatic sample changer. In position, the sample is spun, generally at about 30 rpm, to homogenize the surface presented to the X-ray beam. Manual XRF units are designed for the operator to place the sample into the measurement position. This is done one sample at a time. Sample changers or






FIGURE 8.21 (a) Disposable polyethylene sample cups for liquids and loose samples, consisting of a cup and snap-ring to hold the polymer film cover. Both filled cells with polymer film in place and disassembled cups and ring pieces are shown. (© 2020 Chemplex Industries, Inc., Palm City, FL. (www.chemplex.com) All rights reserved. Used with permission.) (b) Liquid and other loose samples in cells such as those shown in the photo, and then inserted into a sample cassette of the type shown in Figure 8.21(a) for a face-down configuration spectrometer. As shown, dust sampled on impact filters or thin layer samples may be inserted directly into the sample cassette. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)




FIGURE 8.22 The X-ray transmission characteristics of some thin polymer films used as sample holder covers for liquid, loose powder, and similar samples. (Courtesy of SPEX Certiprep, Inc. Metuchen, NJ [www.spexcsp.com].)

auto samplers are used to enable units to operate unattended and the number of samples in the autosampler varies with instrument make and model. XFR units accommodate different atmospheres, including vacuum, helium, nitrogen, and air.

Batch sample changers are usually based on a circular tray or a conveyer belt with multiple sample positions. Samples are rotated or moved over the measurement position. This design does not allow a sample change while the measurement sequence is started since it is connected to an interlock and/or purged with the user selected atmosphere. This design though is simple and can be used for small units. Random access sample changers are more complex than standard autosamplers and allow the operator to add and remove samples while the unit is analyzing another sample in the measurement position.

8.2.2.4 EDXRF DETECTORS


The detector is the most crucial component of the EDXRF unit since it detects and sorts the incoming photons originating from the sample. The detector type and associated electronics determine the performance with respect to count rate, resolution and detection efficiency.

The count rate is the total of ALL photons detected and counted by the detector over the energy range being detected.

Two type of detectors are used in commercially available units: proportional detectors and semiconductor detectors such as Silicon PIN, Si(Li), Ge(Li), and SD Detectors. The detectors used in EDXRF have very high intrinsic energy resolution. In these systems, the detector resolves the spectrum. The signal pulses are collected, integrated and displayed by a multichannel analyzer (MCA).

Semiconductor Detectors. When an X-ray falls on a solid-state semiconductor, it generates an electron (e⁻) and a hole (e⁺). Based on this phenomenon, semiconductor detectors have been developed and are now of prime importance in EDXRF and scanning electron microscopy. The total ionization caused by an X-ray photon striking the detector is proportional to the energy of the incident photon. A formerly common semiconductor detector for laboratory EDXRF systems was the *lithium-drifted silicon diode*, represented as Si(Li) and called a "silly" detector. A schematic diagram of a silicon lithium-drifted detector is shown in Figure 8.23.

A cylindrical piece of pure, single crystal silicon is used. The size of this piece is 4-19 mm in diameter and 3-5 mm thick. The density of free electrons in the silicon is very low,






FIGURE 8.23 The Si(Li) semiconductor detector. **(a)** Schematic shows the n-type Si region on one end of the Si crystal, a central charge depleted intrinsic region and p-type Si on the other end. **(b)** The actual detector has 200 Å layers of gold as electric contacts on each end of the crystal. An X-ray photon striking the intrinsic region generates electron-hole pairs within the diode. (b: © Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

constituting a p-type semiconductor. If the density of free electrons is high in a semiconductor, then we have an n-type semiconductor. Semiconductor diode detectors always operate with a combination of these two types.

The diode is made by plating lithium onto one end of the silicon. The lithium is drifted into (diffused into) the silicon crystal by an applied voltage. The high concentration of Li at the one end creates an n-type region. In the diffusion process, all electron acceptors are neutralized in the bulk of the crystal, which becomes highly nonconducting. This is the "intrinsic" material. The lithium drifting is stopped before reaching the other end of the silicon crystal, leaving a region of pure Si (p-type), as shown in Figure 8.23. Submicron gold layers are applied at each end as electrical contacts. The detector is reverse-biased, removing any free charge carriers from the intrinsic region. Under this condition, no current should flow since there are no charge carriers in the intrinsic region. However, the band-gap between the valence band and the conduction band is small, only 1.1 eV for Si(Li). At room temperature, thermally generated charge carriers cross this barrier easily and become conductive even with no X-ray photons striking the detector. This causes a high noise level. To decrease this noise and increase the sensitivity of the detector, the temperature of the system must be decreased significantly. This is accomplished by cooling the detector to 77 K with liquid nitrogen, which must be replenished regularly. Peltier-effect based electronic cooling is used with temperatures of as low as -90°C on benchtop EDXRF units. A Peltier cooling device, also known as a thermoelectric cooling device, uses the Peltier effect to create a heat flux between the junction of two different materials. A Peltier cooler is a solid-state heat pump

which transfers heat from one side of the device to the other, depending on the direction of the electric current. The solid-state nature of the cooler means no moving parts, compact size, and no maintenance. These devices are commonly used to cool electronic components.

In exactly the same fashion, germanium, also in group IV of the periodic table, can be used instead of silicon, making a Ge(Li) drifted detector. (You might guess this is called a ielly" detector.) The Ge(Li) detector also requires liquid nitrogen or electronic cooling, since" its band gap is only 0.66 eV.

An X-ray photon striking the detector produces multiple electron-hole pairs in the intrinsic region [Figure 8.23(b)]. The number of electron-hole pairs produced is proportional to the photon energy. The energy required to make an electron-hole pair is 3.86 eV in Si(Li), so the number of electron-hole pairs formed is approximately:

$$(8.16) n = \frac{E}{\varepsilon} = \frac{E}{3.86 \text{ eV}}$$

where n is the number of electron-hole pairs; E, the energy of the incident X-ray photon (in eV); and ε , the energy to form an electron-hole pair in eV.

For a similar Ge lithium-drifted detector, the energy required for ionization is 2.96 eV. This is much less than the energy required for ionization in a proportional counter or a NaI(Tl) scintillation detector.

Under the influence of an applied voltage, the electrons move toward the positive end and the holes toward the negative end of the detector. The total charge collected at the positive contact is:

$$(8.17) Q = nq_e$$

where *Q* is the total charge in coulombs (C); *n*, the number of electron–hole pairs = E/ε ; and q_e , the charge on one electron = 1.69 × 10⁻¹⁹ C/electron.

The collection of charge results in a voltage pulse. Since the total charge is proportional to the energy of the incident photon, the amplitude of the voltage pulse produced is also directly proportional to the energy of the incident photon. The voltage pulses are amplified and "shaped" electronically and sent to a multichannel pulse height analyzer (Section 8.2.2.5) to be sorted by pulse height and counted.

Silicon PIN Diode Detectors. These consist essentially of a couple of mm thick silicon junction type p-i-n diode with a bias of 1000 V across it. The heavily doped central part forms the non-conducting i-layer (intrinsic layer), where the doping compensates the residual acceptors which would otherwise make the layer p-type. When an X-ray photon passes through, it causes a swarm of electron-hole pairs to form, and this causes a voltage pulse. To obtain sufficiently low conductivity, the detector must be maintained at low temperature with a Peltier device. Continuous improvement of the pulse processing results in resolution as low as 125eV. Count rate and resolution are strongly correlated; the resolution is best at a low count rate. The yield of this detector for higher energies is good although less than the Si(Li) detector.

Silicon Drift Detector. Commercially available silicon drift detectors (SDD) are based on the drift chamber principle. The detector crystal is moderately cooled by vibration free thermo-electric coolers. A monolithically integrated on-chip field effect transistor (FET) acts as a signal amplifier and controls energy resolution. The sideward depletion of the active detector volume in connection with the integrated drift structure provides an extremely small detector capacitance that enables the use of fast signal processing techniques, thus enabling high count rate processing. The processing electronics enable high count rate and the lowest possible resolution.

The unique property of this type of detector is the extremely small value of the anode capacitance, allowing the FET to be either integrated on the chip or connected to it by a short **8.24** Schematic metal strip. Using very elaborate and proprietary processing technology in the fabrication of a Silicon PIN detector, reduces the leakage current level to such low levels that the detector can be operated with moderate cooling. This cooling can be readily achieved by Peltier cooling and is in the vicinity of -15 to -20°C.



(Courtesy of Amptek, www.amptek.com.).




FIGURE 8.25 Schematic of a silicon drift detector. (Courtesy of Amptek, Inc. www.amptek. com.)

8.2.2.5 MULTICHANNEL PULSE HEIGHT ANALYZER

A multichannel pulse height analyzer, also called a multichannel analyzer (MCA) or digital pulse processor, collects, integrates, and displays the signal pulses from the detector. The operation of a multichannel analyzer can be modeled in a simple fashion. Assume we have a handful of coins of different denominations and a coin-sorting device to put each coin into a separate stack (Figure 8.26, left side). The stacks will have different heights, depending on the number of coins of each type (Figure 8.26, right side, second plot from the bottom). We can plot "counts" or number of coins versus the height of the stack. An MCA does the same thing with photons of different energies. Assume that we have a pulse height analyzer of a given total voltage range with the ability to change the voltage in small increments. As an example, the total voltage range is 10 V and the interval of change is 0.1 V. X-rays of short wavelengths (high energies) must be separated from X-rays of long wavelengths (low energies). That is what a pulse




FIGURE 8.26 Schematic of the pulse processing of a multichannel analyzer. Left side: the "coins" (photons) are separated by denomination and binned. Right side, second from the bottom: the number of coins gives a "stack height" (counts). The typical EDXRF output is the lower right plot of intensity (counts per second) versus energy.

8.2.3 INSTRUMENTATION FOR WAVELENGTH DISPERSIVE X-RAY SPECTROMETRY

There are three types of WDXRF instruments: **sequential** spectrometers which use a **goniometer** and sequentially measure the elements by scanning the wavelength, **simultaneous** spectrometers which use multiple channels, with each channel having its own crystal/detector combination optimized for a specific element or background measurement and **hybrid spectrometers** which combine sequential goniometers or scanners with fixed channels as well as XRD channels and goniometers. Hybrid instruments will be discussed in Section 8.4 with XRD instruments.

A WDXRF spectrometer can be generally divided into four major components based on their functionality: the generator, spectrometer, electronic pulse processing unit, and the sample changer. The **generator** supplies the current and high voltage for the X-ray tube to produce the tube radiation (primary X-rays). The generators available today can provide a maximum output of around 4kW with a maximum voltage of up to 70 kV and up to 170 mA current.

The **spectrometer** contains the X-ray tube, primary beam filters, collimators, analyzing crystals, and detectors. Parts of the spectrometer and the sample measurement position are generally under vacuum but other atmospheres (purge gases) can be used based on the desired application. X-ray tubes and primary beam filters have been discussed above. Most commercially available WDXRF units today use end-window X-ray tubes which are water cooled. The window thickness is around 75 microns or less (see Figure 8.10).

The primary beam filter wheel is equipped with a selection of absorbing foils, commonly Al and Cu foils of various thicknesses. It is located between the tube and the sample, filtering out undesirable or interfering components of the tube radiation to increase the peak-to-background ratio.

FIGURE 8.28 The function of a collimator is shown. All radiation is absorbed except for the photons passing through the gaps, forming a narrow, nearly parallel beam of X-rays. (© 2020 Bruker, Inc. [www.bruker.com]. Used with permission.)




FIGURE 8.29 Peak resolution and intensity as a function of finer and finer divergence (blade spacing). Finer divergence increases resolution but decreases intensity. (© 2020 Bruker, Inc. [www.bruker.com]. Used with permission.)

8.2.3.1 COLLIMATORS

The X-rays emitted by the anode in an X-ray tube are radially directed. As a result, they form a hemisphere with the target at the center. In WDXRF spectroscopy or XRD structural determination, the spectrometer's analyzing crystal or the crystalline substance undergoing structure determination requires a nearly parallel beam of radiation to function properly. A narrow, nearly parallel beam of X-rays can be made by using two sets of closely packed metal plates or blades separated by small gaps. This arrangement absorbs all the radiation except the narrow beam that passes between the gaps.

Decreasing the distance between the plates or increasing the total length of the gaps decreases the divergence of the beam of X-rays (i.e., it collimates, or renders them parallel). The use of a collimator increases the wavelength resolution of a spectrometer's analyzing crystal, cuts down on stray X-ray emission, and reduces background.

Commercial instruments use multiple tube or multiple slit collimator arrangements, often both before the analyzing crystal (the primary collimator) and before the detector (the secondary collimator). The collimator positions in a sequential WDXRF spectrometer are shown schematically in Figure 8.30. In many wavelength dispersive instruments, two




FIGURE 8.30 (a) Schematic of the optical path in a wavelength-dispersive sequential spectrometer, showing the positions of the collimators. **(b)** Schematic layout of a commercial sequential WDXRF system. (Courtesy of Malvern Panalytical Inc., Almelo, the Netherlands [www.malvernpanalytical.com]. Used with permission.)




FIGURE 8.31 A sequential spectrometer with two tandem detectors, showing the placement of the collimators in the optical path. (From Jenkins et al., 1981, Used with permission.)

detectors are used in tandem, and a third auxiliary collimator may be required. Such an arrangement is shown in Figure 8.31.

Collimators are not needed for curved crystal spectrometers where slits or pinholes are used instead nor are they needed for energy dispersive spectrometers. **Collimator masks** are situated between the sample and collimator and serve the purpose of cutting out the radiation coming from the edge of the sample cup aperture (Figure 8.32).

8.2.3.2 ANALYZING CRYSTALS

The analyzing crystals are the "heart" of a WDXRF spectrometer. As we have discussed, a crystal is made up of layers of ions, atoms, or molecules arranged in a well-ordered system, or lattice. If the spacing between the layers of atoms is about the same as the wavelength of the




FIGURE 8.32 Schematic commercial WDXRF system showing the position of a collimator mask changer, as well as the layout of X-ray tube, filter wheel, sample, collimator, analyzing crystal changer, and detector. (© 2020 Bruker, Inc. [www.bruker.com]. Used with permission.)

Crystal	Name and Orientation (Miller Indices)	2d-spacing (nm)	Element Range
LiF-420	Lithium fluoride (420)	0.1891	≥Ni Kα1
LiF-220	Lithium fluoride (220)	0.2848	≥ V Kα1
LiF-200	Lithium fluoride (200)	0.4028	≥ K Kα1
Ge	Germanium (111)	0.6530	P, S, CI
InSb	Indium antimonide (111)	0.7481	Si
PET ^a	Pentaerythritol (002)	0.8740	Al –Ti, Kr–Xe, Hf-Bi
ADP	Ammonium dihydrogen phosphate	1.064	Mg
TIAPb	Thallium acid phthalate (100) (Thallium hydrogen phthalate)	2.576	Fe-Na
XS55, OV055, AX06, PX-1, PX-3 and others	Multi-layered Synthetic Crystal ^c	5.0 to 19	Light elements from Be to N, N-Al, Ca-Br depending on the d-spacing

TABLE 8.7 Analyzing Crystals Used in Modern X-ray Spectrometers

The analyzing crystal is mounted on a turntable that can be rotated through θ degrees (see the arrow marked θ on the lower left side of Figure 8.31). The detector(s) are connected to the crystal turntable so that when the analyzing crystal rotates by θ degrees, the detector rotates through 2θ degrees, as shown by the marked arrow. Therefore, the detector is always in the correct position (at the Bragg angle) to detect the dispersed and diffracted fluorescence. This crystal positioning system is called a **goniometer**. Figure 8.34 shows the turntable and the concentric circles made by the crystal and the detector. In most systems, the maximum diffraction angle attainable is 75° θ (or 150° 2θ).

In some systems, the rotation of the crystal and the detector is mechanically coupled with gears. Other systems have no mechanical coupling but use computer-controlled stepper




FIGURE 8.34 Goniometer layout for a sequential XRF spectrometer.

^a The most heat sensitive crystal.

b Toxic.

^c The designations for these multi-layered synthetic crystals are commercial trade names from different instrument manufacturers.




FIGURE 8.35 Schematic of the optical path in a curved crystal spectrometer. (Courtesy of Malvern Panalytical Inc., Almelo, the Netherlands [www.malvernpanalytical.com]. Used with permission.)

motors for the crystal and the detector. The newest systems use optical position control by optical sensors or optical encoding devices. Optical position control permits very high angular precision and accuracy and very fast scanning speeds.

The analyzing crystals are interchanged by rotation of the crystal holder but the same goniometer is used to select the diffraction angle, meaning that only one wavelength can be measured at a time with a sequential system.

The analyzing crystal(s) shown schematically in Figures 8.30 through 8.34 has a flat surface. Flat crystals are used in scanning (sequential) spectrometers. Curved crystals, both natural and synthetic multilayers, are used in simultaneous spectrometers, electron microprobes, and for synchrotron X-ray spectrometry. The advantage to a curved crystal is that the X-rays are focused and the collimators replaced by slits, resulting in much higher intensities at the detector than with flat crystal geometry. This makes curved crystals excellent for analysis of very small samples. The use of a curved crystal and slits in a simultaneous spectrometer is illustrated schematically in Figure 8.35. The curved crystal spectrometer geometry should remind you of the Rowland circle geometry for optical emission spectrometers discussed in Chapter 7. Curved crystals are used in the "fixed" channel design of most simultaneous (multichannel) spectrometers.

8.2.3.3 DETECTORS

X-ray detectors transform photon energy into electrical pulses. The pulses (and therefore, the photons) are counted over a period of time. The *count rate*, usually expressed as counts per second, is a measure of the intensity of the X-ray beam. Operating the detector as a photon counter is particularly useful with low-intensity sources, as is often the case with X-radiation.

There are three major classes of X-ray detectors in commercial use: gas-filled detectors, scintillation detectors, and semiconductor detectors. Semiconductor detectors are used in EDXRF and handheld systems and were discussed above with EDXRF instrumentation. Both WDXRF and EDXRF detection make use of a signal processor called a pulse height analyzer or selector in conjunction with the detector

WDXRF systems commonly use one or more of the following detectors: gas flow proportional counter (flow counter, FC), sealed gas proportional counter, and scintillation counter (SC).

Gas-Filled Detectors. Suppose we take a metal cylinder, fit it with X-ray transparent windows, place in its center a positively charged wire, fill it with inert filler gas, such as helium, argon, or xenon, and seal it. If an X-ray photon enters the cylinder, it will collide with and ionize a molecule of the filler gas by ejecting an *outer shell electron*, creating a *primary*




FIGURE 8.36 Schematic diagram of a gas-filled X-ray detector tube. He filler gas is ionized by X-ray photons to produce He⁺ ions and electrons, e⁻. the electrons move to the positively charged center wire and are detected. (Modified from Parsons, used with permission.)

ion pair. With helium as a filler gas, the ion pair would be He⁺ and a photoelectron e⁻. A sealed gas-filled detector of this type is illustrated in Figure 8.36. The interaction

$$h\nu + \text{He} \rightarrow \text{He}^+ + \text{e}^- + h\nu$$

takes place inside the tube. The electron is attracted to the center wire by the applied potential on the wire. The positive charge causes the wire to act as the anode, while the positive ion, He⁺ in this case, migrates to the metal body (the cathode). The ejected photoelectron has a very high kinetic energy. It loses energy by colliding with and ionizing many additional gas molecules as it moves to the center wire. A plot of the number of electrons reaching the wire versus the applied potential is given in Figure 8.37.

With no voltage applied, the electron and the positive ion (He⁺) recombine and no current flows. As the voltage is slowly increased, an increasing number of electrons reach the anode, but not all of them; recombination still occurs. This is the sloping region marked A in Figure 8.37. At the plateau marked B in Figure 8.37, all the electrons released by a single photon reach the anode and the current is independent of small changes in the voltage. A detector operating under these voltage conditions is known as an *ionization counter*. Ionization counters are not used in X-ray spectrometers because of their lack of sensitivity.

As the voltage increases further, the electrons moving toward the center wire are increasingly accelerated. More and more electrons reach the detector as a result of an avalanche of secondary ion pairs being formed and the signal is greatly amplified. In the region marked C in Figure 8.37, the current pulse is proportional to the energy of the incoming X-ray photon. This is the basis of a *proportional counter*. In X-ray spectrometry, gas-filled detectors are used exclusively in this range, that is, as proportional counters. The amplification factor is a complex function that depends on the ionization potential of the filler gas, the anode




FIGURE 8.37 Gas-filled detector response versus potential. A detector operating at the plateau marked B is an ionization counter. A proportional counter operates in the sloping region marked C where the response is proportional to the energy of the incoming photon. The plateau marked D represents the response of a Geiger counter. (Modified from Helsen and Kuczumow, used with permission.)

potential, the mean free path of the photoelectrons, and other factors. It is critical that the applied potential, filler gas pressure, and other factors be kept constant to produce accurate pulse amplitude measurements. There are two main types of proportional counter: flow proportional counters and sealed proportional counters.

As shown in Figure 8.37, if the voltage is further increased, electrons formed in primary and secondary ion pairs are accelerated sufficiently to cause the formation of more ion pairs. This results in huge amplification in electrons reaching the center wire from each X-ray photon falling on the detector. The signal becomes independent of the energy of the photons and results in another plateau, marked D. This is called the Geiger-Müller plateau; a detector operated in this potential range is the basis of the Geiger counter or Geiger-Müller tube. It should be noted that a Geiger counter gives the highest signal for an X-ray beam without regard to the photon energy. However, it suffers from a long dead time. The dead time is the amount of time the detector does not respond to incoming X-rays. It occurs because the positive ions move more slowly than the electrons in the ionized gas, creating a space charge; this stops the flow of electrons until the positive ions have migrated to the tube walls. The dead time in a Geiger counter is on the order of $100 \, \mu s$, about $1000 \, times$ longer than the dead time in a proportional counter. Due to the long dead time compared with other detectors, Geiger counters are not used for quantitative X-ray spectrometry. They are, however, very important portable detectors for indicating the presence or absence of X-rays. Portable radiation detectors equipped with Geiger counters are used to monitor the operation of equipment that creates or uses ionizing radiation to check for leaks in the shielding.

As was the case with EDXRF, escape peaks which are detector artifacts occur in WDXRF gas-filled detectors. Ionization of the filler gas by an X-ray photon usually results in the ejection of an outer shell electron. However, it is possible for ionization to occur by ejection of an inner shell electron. When this happens, the incoming X-ray photon is absorbed and the filler gas emits its characteristic K or L lines. This will result in peaks appearing at an energy E' equal to:

$$E' = E(\text{incoming } X - \text{ray}) - E(\text{filler gas characteristic } X - \text{ray})$$
 (8.18)

As an example, if the detector filler gas is Ar, the Ar K line has energy of about 3 keV (or a wavelength of 3.87 Å). If an incoming X-ray has a wavelength shorter than 3.87 Å, it can eject an argon K electron. Assuming that the incoming X-ray is the Fe K_{α} line at 6.4 keV, a peak will appear at (6.4-3) keV or about 3.4 keV. This peak at 3.4 keV is an **escape peak** and can be called either the Fe K_{α} escape peak or the argon escape peak. An escape peak appears at a




FIGURE 8.39 Four primary ions pairs produce four "avalanches", all of which contribute to a single pulse. (Copyright Oak Ridge Associated Universities, www.orau.org.)

be Ne, Kr, or Xe. The detector is sealed with thicker windows than those used in the flow counter and therefore do not leak. Window materials include polymers, mica, aluminum, and beryllium. The window thickness generally prevents the sealed proportional counter from being used for the measurement of light elements from Be to Na. It is used for analyzing elements from As to Ti.

Multiple proportional counters are used in simultaneous X-ray spectrometers, described below, while one proportional counter is often used in tandem with a scintillation counter in a sequential system. It is for this reason that the detector has two windows as shown in Figure 8.38. X-ray photons pass through the proportional counter to the scintillation counter located behind it, as illustrated in Figure 8.31 and signals are obtained from both detectors. It should be noted that this tandem arrangement does not permit independent optimization of both detectors. There are sequential spectrometer systems available with independent proportional and scintillation detectors.

Scintillation Counter (SC). Photomultiplier detectors, discussed in Chapter 5, are very sensitive to visible and UV light, but not to X-rays, to which they are transparent. In a *scintillation detector*, the X-radiation falls on a compound that absorbs X-rays and emits visible light as a result. This phenomenon is called *scintillation*. A PMT can detect the visible light scintillations. The scintillating compound or phosphor can be an inorganic crystal, an organic crystal or an organic compound dissolved in solvent.

The most commonly used commercial scintillation detector has a thallium-doped sodium iodide crystal, NaI(T1), as the scintillating material. A single crystal of NaI containing a small amount of homogeneously distributed Tl in the crystal lattice is coupled to a PMT, shown in Figure 8.40.

When an X-ray photon enters the crystal, it causes the interaction

$$I^- \rightarrow I^0 + e^-$$

and the ejection of photoelectrons, as in the gas-filled detector. The ejected photoelectrons cause excited electronic states to form in the crystal by promotion of valence band electrons. When these excited electrons drop back to the ground state, flashes of visible light (scintillations) are emitted. The excited state lies about 3 eV above the ground state, so the emitted light has a wavelength of 410 nm. The intensity of the emitted light pulse from the crystal is proportional to the number of electrons excited by the X-ray photon. The number of electrons excited is proportional to the energy of the X-ray photon; therefore, the scintillation intensity is proportional to the energy of the X-ray.

The scintillations (visible light photons) from the crystal fall on the cathode of the PMT, which is made of a photoemissive material such as indium antimonide. Photoemissive materials release electrons when struck by photons. Electrons ejected from the cathode are




FIGURE 8.40 Schematic NaI(TI) scintillation detector. **(a)** The assembled detector. **(b)** Schematic representation of the photomultiplier and its circuitry. (Courtesy of ORTEC [Ametek], www.ortec-online.com from Jenkins et al., 1981, Used with permission.)

accelerated to the first dynode, generating a larger number of electrons. The electron multiplication process occurs at each successive dynode, resulting in approximately 10^6 electrons reaching the anode for every electron that strikes the cathode. The amplitude of the current pulse from the photomultiplier is proportional to the energy of the X-ray photon causing the ionization in the crystal.

To summarize, the scintillation detector works by (1) formation of a photoelectron in the NaI(Tl) crystal after an X-ray photon hits the crystal, (2) emission of visible light photons from an excited state in the crystal, (3) production of photoelectrons from the cathode in the photomultiplier, and (4) electron multiplication.

The NaI(Tl) scintillation detector is most useful for short-wavelength X-rays, <2 Å (Z > 27), so it complements the proportional counter. It also has the potential for escape peaks caused by the iodine K line (about 30 keV or 0.374 Å). Incoming X-rays with wavelengths less than 0.374 Å will result in escape peaks about 30 keV lower in energy than the true energy. The major disadvantage of the NaI(Tl) detector is that its resolution is much worse than that of the proportional counter. This is due to the wider pulse height distribution that results in the output pulse because of the multiple steps involved in the operation of this detector.

8.2.3.4 ELECTRONIC PULSE PROCESSING UNITS

In the detector, a photon generates a number of ion pairs, that is, a current pulse with a certain magnitude or pulse height. The pulse height (voltage) in an XRF detector depends on the energy of the photon. Unfortunately, the height of the current pulse that results is not exactly the same for photons of the same energy. Formation of ion pairs and secondary ion pairs is a statistically random process, so a Gaussian distribution of pulse heights centered on the most probable value results.

A series of pulses and their heights is shown in Figure 8.41. On the left side, this figure shows a series of current pulses from photons of two different energies counted over a period of time. If the pulses are plotted by height (amplitude), the result is a Gaussian **pulse height distribution**, shown on the right side of the figure. Two Gaussian pulse height distributions are seen since we had two photons of different energies reaching the detector. The width of the distribution is measured at half of the maximum height; this is called the full-width at




FIGURE 8.41 Amplitude or pulse height and time record of signals from the detector is on the left. Transformation of the data into a pulse height distribution is shown on the right. The FWHM measurement is shown for the higher peak. (From Helsen and Kuczumow, used with permission.)

half-maximum (FWHM). The FWHM is a measure of the energy resolution of a detector. Energy resolution is best in semiconductor detectors and worst in scintillation detectors, with gas-filled proportional counters in the middle.

In a wavelength dispersive instrument, the analyzing crystal separates the wavelengths falling on it, but as Bragg's Law tells us, it is possible for higher order (n > 1) lines of other elements to reach the detector. A higher-order line from a different element will have a very different energy and will result in a second pulse height distribution centered at a different energy reaching the detector. This would result in an error, since the signal would be misinterpreted as coming from just one element. This problem is eliminated by the use of a **pulse height discriminator**. The pulse height discriminator sets a lower and an upper pulse-height threshold. Only the pulse heights that lie within these limits are counted. It thus reduces the background noise from the electronics and eliminates the interference of higher order reflections. **A sine amplifier** ensures that a discriminator window, once set for a crystal, will be applicable for all detectable energies.

Pulse processing also incorporates **dead time correction**. Dead time results from the inability of the detector electronics to process the pulses fast enough to match the volume of input signals. Therefore, the greater the incident intensity, the greater the losses would be during measurement. Dead time is typically 300-400 ns for modern spectrometers.

8.2.3.5 SAMPLE CHANGERS

Commercial instruments are equipped with automatic sample changers. These are of various types and sizes, permitting either controlled loading of samples with sequential access or X-Y random access.

8.2.4 SIMULTANEOUS WDXRF SPECTROMETERS

A simultaneous WDXRF system, also called a multichannel system, uses multiple channels, optimized for a specific element or background measurement. Each individual channel consists of a crystal, detector, and electronics module and is dedicated to a specific wavelength. Instruments with as many as 38 fixed crystal/detector channels or as few as two are available. These systems are designed for specific applications, such as the analysis of steel in a production facility where hundreds of samples must be analyzed very quickly (e.g., in less than 60 seconds) for the same suite of elements every day.

It is difficult to arrange a large number of channels in close proximity to the sample. Therefore, curved crystal monochromators with slit optics are used (Figure 8.42). Two commonly used curvatures are those that follow a logarithmic spiral, shown in Figure 8.42, and the Johansson curvature, which results in a Rowland circle monochromator (Figure 8.43)




FIGURE 8.42 Monochromator schematic with a logarithmic spiral curved crystal. (© 2020 Bruker, Inc. [www.bruker.com]. Used with permission.)




FIGURE 8.43 Rowland circle type monochromator schematic with a Johansson curved crystal used as a scanning channel. (© 2020 Bruker, Inc. [www.bruker.com]. Used with permission.)





FIGURE 8.44 (a) The S8 TIGER, a floor-mounted commercial WDXRF system. (b) The sample compartment of the S8 TIGER, showing the multi-position autosampler with typical samples such as polished metal flats on the left and pressed pellets on the right. (The namesake operator is not standard but is useful in providing scale!) (© 2020 Bruker, Inc. [www.bruker.com]. Used with permission.)




FIGURE 8.45 (a) Schematic of a mono-capillary X-ray optic for producing micro-beams of X-rays. (b) Schematic of poly-capillary X-ray optics for producing micro-beams of X-rays. (©2020 HORIBA Scientific, Itd. [www.horiba.com]. All rights reserved.)

TABLE 8.8	Evolution of Kumakhov Capillary
	X-ray Optics

Lens Parameter	1985	2003
Channel Size	1 mm	$<\mu$ m
Lens Length	1000 mm	10 mm
No. of Channels	Max. 1000	>1,000,000
Lens Diameter	100 mm	1 mm
Focal Distance	Min. 50 mm	≤1 mm
Spot Size	500 μm	$3 \mu m$

Source: © 2020 Unisantis Europe GmbH. All rights reserved.

diameters of 40-50 μm are possible. Table 8.8 shows how rapidly these X-ray optics have evolved.

8.2.5.2 MICRO-XRF SYSTEM COMPONENTS

Commercial systems consist of an optical microscope for observation of the sample area, and an ED-based XRF system with a low power, micro-focused X-ray source using Kumakhov optics, a filter wheel and a detector [Si(Li), Si-PIN, SDD]. The X-ray source is generally air-cooled and some systems allow a choice of beam diameters. Systems are available that enable He purge gas for light elements, atmospheric pressure analysis, low- or high-vacuum analysis.

Systems generally have large sample chambers allowing for analysis of complete circuit boards, for example (Figure 8.46), and open beam systems are available to bring the measurement head anywhere, permitting investigation of very large samples as well as uneven or structured surfaces. The chamber contains an automated motor-driven sample stage that



FIGURE 8.46 A micro-XRF system with a large sample chamber, the SPECTRO MIDEX. This is used for analysis of large objects, such as the complete circuit board shown to the left of the analyst. (© SPECTRO analytical instruments, a unit of the materials analysis division, AMETEK, Inc. [www.ametek.com]. Used with permission.)




FIGURE 8.47 Comparison of the resolution of EDXRF (outer spectrum) and WDXRF (inner spectrum) systems. WDXRF provides higher resolution than EDXRF. (© 2020 HORIBA Scientific, Ltd. [www.horiba.com]. All rights reserved.)

(Z = 92); with a special SDD detector it is possible to measure from fluorine to uranium. Handheld EDXRF units with SDD detectors can measure from magnesium (Z = 12) to U and Si PIN units can do the same with vacuum or He purge.

Elements with atomic numbers between Mg (Z = 12) and U (Z = 92) can be analyzed in air. Elements with atomic numbers 3 (beryllium) through 11 (sodium) fluoresce at long wavelengths (low energy), and air absorbs the fluorescence. Analysis of this group must be carried out in a vacuum or in a helium atmosphere.

WDXRF units usually operate primarily under vacuum and use a helium atmosphere for loose powder samples and liquid samples. Benchtop EDXRF and micro-XRF systems can operate under vacuum, helium, or air, based on the configuration. Handheld or portable units generally operate in air at atmospheric pressure.

The detection limits are in the ppm range for most elements with a wide linear working range. XRF thus permits multielement analysis of alloys and other materials for major, minor, and trace elements. Sensitivity is poorest for the low Z elements and best for the high Z elements. XRF capabilities are dependent on the technique (ED or WD used) as well as the power and other design variables of the actual instrument employed.

8.2.8.1 THE ANALYZED LAYER

Both solid and liquid samples can be analyzed by XRF as described earlier in the chapter. With the exception of micro-XRF, XRF is considered to be a "bulk" analysis technique. This means that the analysis represents the elemental composition of the entire sample, assuming the sample is homogeneous. The term "bulk" analysis is used to distinguish such techniques from "surface analysis" techniques (Chapter 13) which look at only a very thin layer at the sample surface. But there are conditions that must be considered in XRF in order to obtain accurate results. The limiting factor for direct XRF analysis or the analysis of prepared samples is that the signal of the characteristic radiation from the sample originates from different layers within the sample.

The excited radiation inside the sample will need to travel out of the sample before it can be detected by the detector. Assuming a constant density for the sample, lower energy characteristic radiation will only exit from relatively close to the surface, whereas higher energy radiation will be detectable from increasingly deeper layers of the sample. Figure 8.48 illustrates the concept.




FIGURE 8.48 Illustration of the analyzed layer from the sample: the incoming primary radiation excites the lower and middle parts of the sample (dark and light pink) as shown but does not excite the upper part (white) since the sample is infinitely thick for the primary radiation. The excited characteristic radiation from the element in the middle part (light pink) is reabsorbed within the sample. Only the signal from the layer near the surface is able to be detected by the detector.

XRF is a *surface sensitive* technique because the depth of penetration and the thickness of the analyzed layer depend on the exciting radiation and the sample composition (atomic number).

The analyzed layer is a function of the characteristic energy of the emission line being measured as well as the density and composition of the sample. The effect is based on absorption of the excited radiation. The effective analyzed layer is also dependent on the geometry of the instrument. The effective analyzed layer is usually defined as the layer from which either 50 % or 90 % of the signal originates.

To better understand the implications for accurate XRF determinations of composition, Table 8.9 shows selected characteristic K_{α} emission lines and shows the analyzed layer depth

Analyzed Layer in Various Matrices						
Line	Energy	Graphite	Glass	Iron		

Li	ne	Energy	Graphite	Glass	Iron	Lead
Cd	KA1	23.17 keV	14.46 cm	8.20 mm	0.70 mm	77.30 µm
Мо	KA1	17.48	6.06	3.60	0.31	36.70
Cu	KA1	8.05	5.51 mm	0.38	36.40 µ m	20.00
Ni	KA1	7.48	4.39	0.31	29.80	16.60
Fe	KA1	6.40	2.72	0.20		11.10
Cr	KA1	5.41	1.62	0.12	104.00	7.23
S	KA1	2.31	116.0 µ m	14.80 µm	10.10	4.83
Mg	KA1	1.25	20.00	7.08	1.92	1.13
F	KA1	0.68	3.70	1.71	0.36	0.26
Ν	KA1	0.39	0.83	1.11	0.08	0.07
C	KA1	0.28		0.42	0.03	0.03
В	KA1	0.18	4.19	0.13	0.01	0.01

			Concentration		
Compound	Li	ine	(%mass/mass)	Energy (keV)	Layer Thickness (μm)
Fe ₂ O ₃	Fe	KA1	0.722	6.40	174
MnO	Mn	KA1	0.016	5.89	139
TiO ₂	Ti	KA1	0.016	4.51	66
CaO	Ca	KA1	30.12	3.69	104
K_2O	Κ	KA1	0.103	3.31	77
SO ₃	S	KA1	0.000	2.31	27
P_2O_5	Р	KA1	0.004	2.01	19
SiO ₂	Si	KA1	1.130	1.74	13
Al_2O_3	Al	KA1	0.277	1.49	8
MgO	Mg	KA1	21.03	1.25	7
Na ₂ O	Na	KA1	0.029	1.04	4
CO_2			46.37		

TABLE 8.10 Analyzed Layer Thickness of NIST 88B Dolomite Sample for Various Elements

(90 % signal) for various matrices which increase in density from the left to the right. Note that the table uses a typical "shortcut" for line notation: KA1 instead of $K_{\alpha 1}$ and the energies of the lines are expressed in keV. Some examples of the use of this table are presented.

Considering the S K_a emission line, in a graphite matrix the emission is detectable from a depth of 116 μ m in the sample, but that depth is reduced to 14.8 μ m in a silicate glass matrix and reduced even more in the dense matrices of iron and lead. This means that if the sulfur in the glass sample lies much deeper than 14.8 μ m from the surface of the sample, it will not be detected because the radiation cannot escape from the matrix. Conversely, this means that to measure sulfur in glass accurately, the top 14.8 μ m of the sample must be homogeneous and representative of the sulfur concentration throughout the glass; in graphite, the top 116 μ m of the sample must be homogeneous. The XRF analyst needs to ensure that the analyzed layer is *representative* of the entire sample. This might require intensive sample preparation to ensure that in a powdered sample the "grain" or particle size is well below the size of the analyzed layer. Table 8.10 shows this issue for a limestone sample with no binder.

The preparation of the sample needs to be designed to ensure that the analyzed layer is representative of the sample. This has implications mainly for solid samples such as minerals where the sample needs to be pulverized to be made homogeneous with the resulting grain size less than the analyzed layer of the lightest element to be determined. As can be seen in Table 8.10, the magnesium emission originates from a depth of only 7 microns. To grind a sample to particle diameters substantially below 7 microns while keeping the sample homogeneous is extremely difficult.

A coal sample (which we can approximate by using the graphite data in Table 8.9) would need to be about 14.5 cm thick to measure 90 % of the Cd K_{α} signal. Since most benchtop or laboratory units can only load samples with a maximum thickness of 5 cm, one has to ensure that all samples, standards and reference samples are prepared with identical thickness.

8.2.8.2 SAMPLE PREPARATION CONSIDERATIONS FOR XRF

While general sample preparation approaches were covered in Chapter 1, as seen from the examples above, XRF sample preparation requires some thought as well as an understanding of the chemical and physical properties of the sample material. Samples must be representative of the material to be analyzed. They must fit the sample holder being used and completely cover the opening in the sample holder or be larger than the measurement spot size being used.

Very flat surfaces are required for quantitative analysis. Liquid samples flow naturally into flat surfaces, but cannot be run under vacuum. Liquid samples are usually run in a polymer cup with a sleeve or ring to hold a polymer film in place over the liquid. The film needs to

be mechanically stable, chemically inert, and as thin as possible to allow transmission of radiation, especially for the low Z elements. Elements with atomic numbers less than Na cannot be detected through polymer films. As discussed in Section 8.2.2.3, liquid samples and loose powders are best run in a face-down configuration for greatest accuracy; that is, the source should be below the sample. The best solvents for samples that must be dissolved for analysis are $\rm H_2O$, $\rm HNO_3$, hydrocarbons, and oxygenated carbon compounds, because these compounds contain only low atomic number elements. Solvents such as $\rm HCl$, $\rm H_2SO_4$, $\rm CS_2$, and $\rm CCl_4$ are undesirable because they contain elements with higher atomic numbers; they may reabsorb the fluorescence from lower-Z elements and will also give characteristic lines for Cl or S. This will preclude identification of these elements in the sample. Organic solvents must not dissolve or react with the film used to cover the sample.

Solid samples may be prepared using several techniques. Solid samples that can be cut and polished to give a flat surface can be analyzed after polishing. Care must be taken not to contaminate the sample with the cutting tool or polishing compound. For example, cutting a flat piece of polymer with a steel razor blade can result in iron being detected in the polymer sample. Other solids should be ground to a powder, preferably using a ball mill or similar device to pulverize the sample. The grinding tools must not contaminate the sample, so boron carbide is often used to contain and grind samples. The sample powder may be pressed "as is" or mixed with lithium borate salt, borax, wax, or other suitable "binder" and formed into a briquette or disk. This procedure provides a sample that can be easily handled and has the advantage that the borate salts and hydrocarbon binders provide a standard matrix for the sample. Furthermore, the matrix is composed of low atomic weight elements, which interact only slightly with the X-ray beam. In addition, the disks or pellets are pressed to a uniform thickness, as is required for accurate analysis. Figure 8.49 presents a summary of the various sample preparation techniques used for XRF analysis, and shows some types of sample holders used.

Minerals in particular present challenges to grinding and achieving a uniform grain size due to the complex composition of mineral samples, a problem known as the mineralogical effect.

It may not be possible to grind a sample to achieve ideal grain size. The next best approach is to ensure that the grinding process results in a repeatable grain size in the samples to be analyzed. The sample grain size must be similar to the grain size in standards and reference materials used in the analysis. This may require different grinding procedures for different materials. Integrating over a larger sample by spinning the sample over the beam or making multiple measurements enables the analyst to average the analyzed layer and obtain more repeatable data. These approaches will create methods that work but may limit the accuracy of the measurement and applicability of the method.




FIGURE 8.49 Sample preparation techniques and sample holders for XRF analysis.

needs to understand that these only emit from very close to the sample surface. The calibration of the analyzer must be tuned to the preparation or presentation of the sample. If not done correctly (or not done at all) the values obtained from the analyzer will be incorrect.

8.2.8.3 QUALITATIVE ANALYSIS BY XRF

Each element fluoresces at its own characteristic wavelengths (energies); the fluorescing element can be identified from a table of wavelengths (energies) such as those in Appendix 8.A (textbook website). An example of qualitative analysis is shown in Figure 8.51. The EDXRF spectrum is that of a zinc-coated iron washer. The spectra are much simpler than those from atomic emission spectrometry. Fe gives hundreds of strong emission lines in an ICP emission






FIGURE 8.51 Qualitative EDXRF spectrum of a zinc-coated iron washer. **(a)** The coated washer. The peaks present are, from left to right, Fe K_{α} , Fe K_{β} , Zn K_{α} , and Zn K_{β} . (Confirm these peaks by looking in Table 8.8.A.2.) **(b)** The same washer, but after sanding to remove some of the surface. Note the decrease in the intensity of the Zn peaks and the increase in the Fe peaks. These spectra were collected for 50 s with an Rh tube at 30 kV and 0.01 mA, under vacuum, using a filter to remove the X-ray tube lines. (© Thermo Fisher Scientific (www.thermofisher.com). Used with permission.)




FIGURE 8.52 Spectral overlap in EDXRF spectra. **(a)** A simple overlap demonstrated by overlaying the spectra of pure Fe and pure Mn. There is overlap of the Fe K_{α} line with the Mn K_{β} line. **(b)** The spectrum of a multielement alloy showing multiple spectral interferences due to line overlaps. Despite the overlaps, knowledge of the relative line intensities permits qualitative identification of most of the elements present.

experiment; here only two lines are seen for Fe in this XRF spectrum. The coated washer also shows Zn which is fully resolved.

Even with the relatively simple spectra, spectral interference does occur in XRF. The major sources of spectral interference are: scattered radiation from the tube, higher order lines diffracted in a wavelength dispersive system, and L lines of higher atomic number elements overlapping K lines of lower atomic number elements. Two examples are given in Figure 8.52. The peaks in each spectrum are labeled, but you should use the tables in Appendix 8.A (website) to confirm that they have been labeled correctly and to give yourself some practice in figuring out what elements are present from the energy positions of the peaks. The top spectrum shows the overlap of the spectral lines from pure Fe and pure Mn; the spectral interference occurs between the Fe K_{α} and Mn K_{β} peaks. The peak maxima are not at exactly the same energy, so in a mixture or alloy of the two elements, the Fe K_{α} line can be identified, and if the Mn content of a mixture or alloy were high, the Mn K_{β} peak might appear as a shoulder on the Fe K_{α} peak. The overlap is not critical in a two-component system; as you can see, the unobstructed Mn K_{α} , the strong Fe K_{α} , and the unobstructed Fe K_{β} peaks can easily identify the presence of both elements.

The ratio between the K_{α} and K_{β} line of an emission is fixed and tabulated for every element. A K_{β} emission is <u>always</u> accompanied by a K_{α} emission. Similarly, an L_{β} emission is always accompanied by an L_{α} emission. Keep these facts in mind when examining an XRF spectrum.

The bottom spectrum in Figure 8.52 is that of a more complex alloy containing Cr, Mn, Fe, Co, Ni, and W. Qualitatively, it is easy to see that Cr, Fe, W, and Co are present. Cr and W have unobstructed lines that tell us they are in the alloy. Fe is clearly present, because if there is any Mn, it must be in low concentration compared to the Cr and Fe. The Mn K_{α} peak overlaps the Cr K_{β} peak; we know there is Cr present from its K_{α} peak, so some (at least) of the

intensity of the small peak at 5.8 keV is due to Cr. If Mn is present but in low concentration, then most of the intensity at about 6.4 keV is from Fe, since the Mn K_B peak is much smaller than its K_{α} peak, as seen in the top spectrum. Looking at the peak to the right of the Fe K_{α} peak, we see a much bigger peak than would be expected from Fe K_B alone. (Compare the Fe peak heights in the top spectrum.) Therefore, most of the peak at about 6.9 keV must be from Co K_a. That indicates that Co is present in the alloy. From the Mn and Fe peak ratios in the top spectrum, it is reasonable to assume that the Co K_{eta} peak is less intense than the Co K_{lpha} peak. But the peak at approximately 7.5 keV, about where we would expect the Co K_B peak, is actually more intense than the Co K_{α} peak (and the "Co K_{α} " peak intensity also includes some interfering Fe K_B intensity). Therefore, the high intensity of the 7.5 keV peak tells us we have another element, Ni, in the alloy. The one element that is not clearly present is Mn; the intensity ratio for the two Cr lines needs to be ascertained. If the "Cr K_B" peak is too high relative to the K_{α} peak, then Mn is probably in the alloy as well. So even though only two elements, Crand W, have lines with no spectral interference, knowledge of the relative intensities of lines allows us to state with certainly that Fe, Co, and Ni are present, and that Mn may be present in low concentration. We will come back to this spectrum in the discussion of quantitative analysis by XRF. Modern instrument software generally displays the position and relative heights of the lines of each element, superimposed on the collected spectrum.

The spectrum shown in Figure 8.53 is a more complex spectrum of a duplex steel sample, containing Cr, Mn, Fe, Cu, Ni, and Mo. The instrument software automatically shows element line positions and identity. The emission line from the Rh tube can be seen in the spectrum. There is also an emission line from argon. (Look at the figure caption. Can you suggest where the argon comes from?)

To analyze a spectrum to determine what elements are present, identify the strongest (most intense) line first and then continue with the next most intense lines. Look for the tube emission line and any lines that may come from air. Lines which do not match an element line may be scatter lines from the tube, an escape peak, or a sum peak.

The XRF method is nondestructive, an important feature when the sample is available in limited amounts or when it is valuable or even irreplaceable, as in the case with works of art, antiques, rocks from the moon or forensic samples. The nondestructive nature of




FIGURE 8.53 XRF spectrum of a duplex steel sample. HH XRF (handheld XRF) measurement under air, 15 sec, using a Rh tube at 15 kV. (Courtesy of Bruker Elemental, © 2020 Bruker, Inc. [www.bruker.com]. Used with permission.)



FIGURE 8.54 Scrap metal sorting using the TITAN, a handheld XRF analyzer (HHXRF), to identify elemental composition. (Courtesy of Bruker Elemental, © 2020 Bruker, Inc. [www.bruker.com]. Used with permission.)

XRF coupled with the fact that sample preparation may not be required means that direct multielement analysis can be performed *in situ*. Portable handheld XRF analyzers are used in the field by geologists to study soil and minerals, to sort metal scrap, glass and plastics at recycling centers, for quality control in steel plants and to check incoming lots of material before unloading a ship or a truck (Figure 8.54). In handheld XRF analyzers, the unit's "nose" is pressed against the sample, with no sample holder (or preparation). Portable and handheld units can accommodate either vacuum or helium purges in their instrument nose.

Antiques, jewelry, gems, and art objects can be characterized. Original art and copies of masterpieces can be distinguished from each other based on elemental composition and layering of pigments. Natural gems can be distinguished from synthetic gems in many cases, because the laboratory synthesis often adds specific elements not usually found in the natural gems or may even produce gems with fewer trace elements than real gems. Plated jewelry can be distinguished from solid gold or solid silver jewelry. Museums rely heavily on XRF for examining works of art. The sample is usually unaffected physically or chemically by the analytical process. Low-power EDXRF or micro-XRF units are used for this application and some units have dedicated software for particular applications. It is possible for some sensitive materials like paper or plastics to turn yellow or brown upon prolonged exposure to X-rays, so low power and short analytical times are required for these materials.

Forensic samples are often very small and inhomogeneous. It is difficult to perform quantitative analysis on such samples. It is possible to use qualitative XRF to provide a spectral

"fingerprint" of a sample, not exact concentrations. By matching a spectrum of soil found in a shoe to the spectrum of soil from the location of a crime scene, it is possible to place the object at that scene.

Examples of the use of nondestructive XRF of artworks, archeological items, pharmaceutical products, and other samples are available on several instrument companies' websites, including Bruker, Horiba Scientific, SPECTRO, Thermo Fisher Scientific, Unisantis, and Rigaku. A few examples will be discussed.

An altarpiece from 1424 A.D., the Göttingen Barfüßer altarpiece, was examined using a Bruker ARTAX \$\mu\$-XRF spectrometer (Bruker Nano GmbH, www.bruker.com). Thin layers of gold and silver approximately 1 \$\mu\$ thick were examined by single point measurements with a W target tube and a 0.65 mm collimator. Layers of pure silver, historical gold alloys like "green gold" containing 30 %Cu and layers of Au and Ag hammered together ("Zwischgold") were identified. Studies of two-colored copperplate engraving copies of a famous work by Albrecht Dürer using the ARTAX \$\mu\$-XRF system showed that the pigments used in one copy were consistent with it being painted in the 16th century, while the second copy contained pigments which were not in use until the 1800s (Gross; Hahn et al.). With the same system equipped with a Mo source and polycapillary lens, 2D mapping of a 2x2.5 mm piece of fabric with gunshot residue permitted identification of particles \$\geq 10 \mu\$ m in diameter. The particle distribution pattern across the fabric allowed the determination of the angle of incidence of the gunshot.

A key area which benefits from micro-XRF is the pharmaceutical industry where tablet imaging can determine active pharmaceutical ingredient (API) distribution, mixing uniformity, contamination, and inter-batch concentration fluctuations. The ability to pinpoint single microscopic particles and identify them is very important in ocular and IV formulations, which must meet stringent particulate concentration limits. An example of the use of micro-XRF in mapping a pharmaceutical tablet is shown in Figure 8.55.

Other pharmaceutical applications for micro-XRF can be found at www.horiba.com/scientific/products/X-ray-fluorescence-analysis/applications/pharmaceutics/.

The Unisantis XMF-104 X-ray Micro Analyzer (Unisantis S.A., www.unisantis.com) was used by researchers at the Institute for Roentgen Optics, Moscow, Russian Federation, to examine nondestructively the composition of ancient coins from the 4th century B.C through the 2nd century A.D. The 4th century B.C. coins were found to be an alloy of 82 %Ag/18 %Cu, but areas of pure Ag showed the inhomogeneity of the alloy. A drachma coin depicting Alexander was composed of 99 % Ag/1 %Cu. The XMF-104 system had a 50 W Mo tube, a




FIGURE 8.55 Mapping across a pharmaceutical tablet allows a buried steel particle to be visualized and identified. Contaminants such as this can be introduced from the manufacturing process and are typically caused by wear debris from mechanical mixing/compressing equipment. (© 2020 HORIBA Scientific [www.horiba.com/scientific]. All rights reserved.)

two-stage Peltier cooled compact Si-PIN detector and polycapillary focused X-ray beam with a 50-250 micron focal spot. Spectra, images of the coins and details are available at www. unisantis.com, application note 605.

8.2.8.4 QUANTITATIVE ANALYSIS BY XRF

Quantitative analysis can be carried out by measuring the intensity of fluorescence at the wavelength characteristic of the element being determined. The method has wide application to most of the elements in the periodic table, both metals and nonmetals and many types of sample matrices. It is comparable in precision and accuracy to most atomic spectroscopic instrumental techniques. The sensitivity limits are on the order of 1-10 ppm, although subppm detection limits can be obtained for the heavier Z elements under appropriate conditions. Accuracy depends on a thorough understanding of the sample heterogeneity, the sample matrix, and the absorption and fluorescence processes.

X-rays only penetrate a certain distance into a sample and the fluorescing X-rays can only escape from a relatively shallow depth (otherwise they would be reabsorbed by the sample) as we have seen. While XRF is considered a "bulk" analysis technique, the X-rays measured are usually from no deeper than 1000 Å from the surface. True surface analysis techniques such as Auger spectroscopy only measure a few angstroms into the sample, so in that respect XRF does measure the bulk sample, but only if the surface is homogeneous and representative of the entire sample composition.

The relationship between the measured X-ray intensity for a given peak and the concentration of the element can be written:

(8.19)
$$C = K(I)(M)(S)$$

where C is the concentration of the element. The factor K is a function of the spectrometer and the operating conditions. I, the intensity of the measured signal, is the net intensity after subtraction of the background. M represents interelement effects such as absorption and enhancement effects. Interelement effects must be corrected for or minimized to obtain accurate concentration values. S is the sample preparation term (also called the sample homogeneity term) and describes the difference between the reference sample with which K was obtained and the sample being measured. The classical approach to quantitative analysis is to use an external calibration curve. A set of standards at various concentrations is prepared in a manner similar to the sample preparation, intensity is carefully measured for all standards and samples using the same instrumental conditions, and a plot of C versus I is made. M and S are considered to be constant (a good assumption only if the standards reflect the matrix and particle size distribution of the samples). Precision depends only on careful measurement of intensity; accuracy depends on the elimination or evaluation of M, the interelement effects and elimination of S by using the same preparation of standards and unknowns.

Peak and background intensities are measured by counting photons at the appropriate wavelengths/energies. The net intensity is obtained via background correction. The process of background correction differs between EDXRF and WDXRF. In WDXRF, a fixed position close to the emission line to be measured needs to be identified. This position needs to be free of other emission lines which could occur in the sample. It is usual to perform a scan where the signal as a function of diffraction angle 2θ is obtained. From this scan (spectrum), a background is mathematically obtained by fitting a numerical function (e.g., a polynomial) using a user-defined minimization based on least squares. Once the background is determined, the remainder of the spectrum is the net intensity from the sample. In EDXRF, the area of the peak is used for quantification; in WDXRF, the peak height is used. In energy dispersive systems, background subtraction is usually performed. The background is very matrix-dependent in XRF, so background correction is more difficult than in other types of spectroscopy.

Calibration methods include the use of external standards, and may include the use of internal standards to improve precision. The internal standard may be an added element not

present in the sample, but this is a very time-consuming endeavor, both in making the standards and samples and in measuring all the lines. Frequently, the scattered radiation from the X-ray tube is used as an internal standard; this is a reasonable approach because the scattered radiation (background) is very dependent on the sample matrix. The ratio of analyte line to scattered radiation results in better precision than the measurement of the analyte line alone. XRF calibration used to require a set of accurate standards, as well as certified reference materials for verification of the accuracy and precision of the analysis. Depending on the range of materials that require analysis, laboratories can spend a great deal of money on the highly pure elements, compounds, and reference materials required for calibration and sample preparation.

A variety of mathematical approaches to the correction of absorption-enhancement effects and calibration are now in use, due to the availability of inexpensive, powerful computers, and powerful software programs. One approach is the **fundamental parameters method**.

Using a set of pure element samples or well-certified multielement reference materials, the M factor for each element (Equation 8.19) can be calculated using the fundamental parameters describing the primary spectral distribution (tube spectrum), effective mass absorption of the primary and secondary radiation and the fluorescent yield for each element. The M factor represents the effect the "other" elements have on the analyte element. The parameters used assume that the sample has a planar surface, is homogeneous and infinitely thick (no transmission of X-rays through the sample). This approach enables wide ranging "universal" calibrations to be established for metals and alloys, such as a FeCrNiCo base curve for WDXRF or dedicated calibrations for cement, glass, and so on.

These universal calibrations or standardless calibrations can now be found on any commercial XRF. They are still based on a calibration of a larger set of samples, but this is usually performed at the instrument manufacturer's factory and the calibration transferred to the unit. From the user's point of view, quantitative analysis is standardless since no calibration standards or standard reference materials are required. These calibrations allow for good accuracy if the samples are homogeneous, flat and infinitely thick or described in terms of thickness and weight to allow for corrections. Universal calibrations will fail when the sample is inhomogeneous. Results become more "semiquantitative" as samples become smaller and less homogeneous. Forensic samples and failure analysis samples may be small, nonplanar, and not particularly homogeneous. For forensic analysis, one does not compare concentrations but the ratio of the net signal or one tries to match the spectral "fingerprint".

The advantage to the fundamental parameters (FP) approach is that many industrial materials do not have readily available matrix-matched calibration standards commercially available. Preparation of good, stable calibration standards takes a lot of time and money even when it is possible to make such standards. Even when well-defined standards are available commercially, as they are for steels, brasses, bronzes, nickel-based superalloys, and many other types of alloys, as well as some glasses and ceramics, the standards are expensive and must be handled carefully to avoid scratching or contaminating their surfaces. Sources for prepared XRF standards include government standards agencies such as NIST in the US, as well as commercial firms. Although this standardless software approach has improved dramatically in accuracy over the years, the analyst should, when possible, verify the accuracy of any mathematical approach with known materials that reflect the samples being analyzed. More information on these approaches can be found in several of the introductory XRF texts (e.g., those by Bertin, Jenkins et al. and Herglotz and Birks listed in the bibliography).

Modern WDXRF systems can measure the entire periodic table in less than 20 min and calculate the composition of a complete unknown using an FP program. Using a "fast scan" approach, a semiquantitative analysis can be obtained in less than 2 min of measurement time. Handheld EDXRF systems with SDD detector technology require less than 5 sec to identify a standard alloy and about 20-30 sec to identify an aluminum or magnesium alloy.

When quantitative analysis is needed on complex samples with peak overlaps, a method of extracting the individual intensities of each element is needed. These mathematical corrections are now performed in instrument data processing software, and may include overlap corrections, interelement corrections, matrix corrections, corrections for non-Gaussian

peak shapes, and different statistical fitting routines. A combination of these corrections was used to determine the concentration of the elements in the alloy shown in Figure 8.53. The HH measurement of a 2205 type duplex steel sample took less than 10 sec.

Quantitative XRF is used in virtually every industry for almost any type of liquid or solid sample. XRF is used daily to analyze minerals, metals, paper, textiles, ceramics, cement, polymers, wood, environmental samples, food, forensic samples, cosmetics and personal care products, and more. Only a few examples will be given here.

The petroleum industry uses XRF to measure sulfur in fuels, the elemental composition of catalysts used to "crack" petroleum hydrocarbons, and lubricating oil additives. The sulfur in oil or fuel application is driven by the US federal government clean air regulations. Diesel fuel, for example, is required to contain less than 15 ppm S. Refineries, pipeline operators, and commercial and government labs need to be able to certify sulfur content to ensure fuel classification and compliance. There are procedures published by the American Society for Testing and Materials (ASTM) to ensure minimum performance for accuracy and precision: ASTM D2622 for WDXRF, ASTM D4294 for direct excitation EDXRF and D7220 for polarized (3D) EDXRF. The performance and detection limits for the methods are different but all enable the user to be able to comply with the regulatory requirements. Refineries often choose WDXRF due to the higher accuracy and precision achieved in about 3 min of measurement when compared to EDXRF.

Petroleum hydrocarbon cracking catalysts usually contain more than 12 elements, including transition metals, rare earth elements, alkali and alkaline earth elements at concentrations varying from 0.005 to 35 % (mass/mass)). The composition of the catalyst can be determined accurately after fusion into borate beads; the total analysis takes up to 1 hr. The procedure and approach are described in ASTM D7085. Lubrication oil blenders use EDXRF to check their blends and ensure that control samples from "lube" shops are what the products claim to be (ASTM D6481 outlines the procedure).

Used engine oil is monitored routinely for metal content, since the metal content indicates how parts of the engine are wearing away in use. The wear metals analysis indicated what parts needed to be replaced during maintenance. Analysis also enables extension of the oil life by verifying that there is still enough P, Ca, or Zn in the oil to function correctly. This analysis could be performed by XRF or by atomic emission spectrometry. Filters in modern engines are now so efficient at trapping wear metal particles that the analysis of oil is no longer a good indicator of engine wear. Micro-XRF is now used to measure the metals on the filters themselves to predict engine failure and part replacement by quantifying and analyzing the individual particles from the filter.

In metallurgy, alloy composition can be rapidly determined and unknown samples identified rapidly. XRF has an advantage over wet chemistry in that all of the components can be measured due to the wide dynamic range of XRF. For example, in the analysis of nickel alloys, a wet chemical approach would measure all the other elements and calculate the Ni content as the balance. With XRF, the major element, nickel, as well as the minor and trace components can be measured accurately. For high grade steel and alloys with multiple major components, WDXRF achieves better accuracy and repeatability than OES.

A limitation for XRF in a metallurgical application is the measurement of carbon in steel. The problem with carbon in this application is due to the small analyzed layer and the inhomogeneous distribution of carbon in steel. To ID the correct steel grade for low carbon steels, OES or combustion analysis is required.

The areas of Restricted/Prohibited Elements and Consumer Product Safety have major applications where XRF can be used successfully. Inspection of consumer goods for regulated elements such as Br (from flame retardants), Hg, Pb, Cr, Cd as part of government regulations such as RoHS, WEEE, and the Consumer Protection and Safety Improvement Act 2008 (CPSIA) use XRF (especially portable, handheld, and stationary micro-spot XRF) as screening tools. This is achieved by factory calibrations which adjust and switch automatically for common matrices: high density (HD) and low density (LD) polymers and PVC, and metals. These matrices are the ones found in toys and jewelry. Controlled elements can be measured rapidly using such "dedicated" systems. Pb concentrations as low as 10 ppm can be determined in soil samples with a portable handheld XRF system. XRF is used to measure

the amount of phosphorus-based flame retardant in textiles and the amount of antimony-based flame retardant in plastics. For textiles, a piece of fabric is cut into a square piece and stretched across a standard sample cup and held in place by the sample container ring. This results in a flat specimen for analysis. Phosphorus levels in the range of 0.3-3 %P can be measured in a sample in as little as 30 s. (Details of the method are available from SPECTRO Analytical Instruments (www.spectro-ai.com).

The ceramics industry routinely measures 6-12 elements quantitatively in both pressed pellet and fusion bead form for quality control using either WD or ED XRF. The elements (reported as oxides) vary in concentration from 0.01 to 70 % (mass/mass). Using a modern WDXRF spectrometer, aluminum (reported as Al_2O_3) can be determined at the 1 % (mass/mass) level in a magnesium oxide-based ceramic with a standard deviation of 0.006 and a detection limit of about 8 ppm.

The cement industry requires the close monitoring of at least 10 major elements as oxides (Na₂O, MgO, Al₂O₃, SiO₂, SO₃, P₂O₅, K₂O, CaO, MnO₂, and Fe₂O₃ and determination of adverse trace elements (Zn, Cr, Cl). Based on the requirements of time to result either WDXRF (simultaneous or sequential) or benchtop EDXRF can be used.

Most mining companies use XRF for the analysis of their process streams and monitor the "separation" of metals from the ore. XRF is faster than any wet or atomic spectroscopy technique since it can measure the sample as a solid. Trace elements in soil and sediment can be measured to collect geological, agricultural, and environmental data both in the lab and in the field, using portable or benchtop EDXRF analyzers.

Online XRF analyzers are available for monitoring process streams for metals in plating baths, metals in hydrocarbons, silicon in adhesive coatings on paper, acid leaching solutions, effluent discharge monitoring, and similar applications. The thickness of coatings can be measured on a wide variety of materials, such as paint on steel for the automotive industry and silicone release coating on paper (the shiny nonstick backing paper you peel adhesive labels from is coated with a silicone polymer called a "release coating"). Solar panels are routinely checked with XRF either online or at line.

Due to the extremely high current price for gold, many jewelers, pawn shops, and the like are buying scrap gold and old jewelry. Handheld or portable systems with dedicated software to determine %Au and carat weight, silver, and other precious metals are now available for accurate evaluation of the content of scrap jewelry, such as the Thermo Fisher Scientific Niton DXL Precious Metal Analyzer. This is a countertop unit which delivers fast XRF analysis for all precious metals and has an integrated program called AuDIT™, which automatically identifies gold plated items, based on the thickness of the Au layer. Units with dedicated software for determining plating thickness of other metal coatings on substrates are also common.

XRF can be superior to atomic spectroscopy when calibration and consumable costs are compared, assuming the detection limits are comparable. XRF units are calibrated usually either at the factory or on site when the source is changed; calibration is adjusted or checked with a set of solid check samples. Consumables for XRF are limited to those for sample preparation (fusion fluxes, disposable sample holders, polymer film) and helium, when liquid samples are measured. A significant advantage for XRF over atomic spectroscopy is the ability to measure major, minor, and trace elements simultaneously and directly in the solid or liquid; for most atomic spectroscopy techniques, major and minor components require serial dilutions and multiple analyses. Most solid samples for atomic spectroscopy must be dissolved for analysis. AAS, atomic emission systems, and ICP-MS systems need to be calibrated daily before use and when sample introduction systems are changed, and when parts are cleaned or replaced. They all require large amounts of gases, calibration standards for each element, large volumes of high-purity acids, disposable autosampler cups or tubes, graphite furnace components, torches, nebulizers, disposable pump tubing, and so on.

8.3 X-RAY ABSORPTION

If the wavelength of an X-ray beam is short enough (high energy), it will excite an atom that is in its path. In other words, the atom absorbs X-rays that have enough energy to cause it

to become excited. As a rule of thumb, the X-rays emitted from a particular element will be absorbed by elements with a lower atomic number. The ability of each element to absorb increases with atomic number.

Beer's Law indicates that

(8.20)
$$\log\left(\frac{P_0}{P_x}\right) = \mu_x$$

where μ_x is the linear absorption coefficient; x, the path length through the absorbing material; P_0 , the X-ray power before entering sample; and P_x the X-ray power leaving sample. However,

(8.21)
$$\left(\frac{\mu_x}{\rho}\right) = \mu_m$$

where μ_m is the mass absorption coefficient and ρ is the density. But

$$\mu_{\rm m} = \left(\frac{CN_0Z^4\lambda^3}{A}\right)$$

where C is a constant; N_0 is Avogadro's number; Z, the atomic number; A, the atomic weight; and λ , the wavelength of the radiation.

It can be seen that at a given wavelength, μ_m is proportional to Z^4 divided by the atomic weight. This relationship is shown in Figure 8.56. The set-up for X-ray absorption is slightly different than that for XRF, as seen in Figure 8.57. The sample is placed directly in line with the X-ray tube, in a configuration very similar to UV/VIS absorption spectrometry. The parameter measured is the decrease in intensity of the incident beam after passing through the sample. The same detectors described for XRF may be used for X-ray absorption spectrometry. Older systems and some current medical systems use photographic film for detection (radiography).

The most familiar example (and the oldest use) of X-ray absorption does not provide chemical information, but rather physical information. That is the use of X-ray absorption in medical radiography, but it is based on the relationship between absorption coefficient and atomic number. For example, the human arm consists of flesh, blood, and bone. The flesh or muscle is made up primarily of carbon, nitrogen, oxygen, and hydrogen. These are all low atomic number elements, and their absorptive power is very low. Similarly, blood, which is primarily water, consists of hydrogen and oxygen, plus small quantities of sodium chloride




FIGURE 8.56 Relationship between atomic number and X-ray absorption coefficient.




FIGURE 8.57 X-ray absorption. The sample is placed between the X-ray tube and the detector. The intensity of the source is I_0 . the intensity of light reaching the detector after passing through a sample of thickness t is l. l will be less than l_0 if absorption occurs.

and trace materials. Again, the absorptive power of blood is quite low. In contrast, bone contains large quantities of calcium and phosphorus, primarily as calcium phosphate. The atomic numbers of these elements are considerably higher than those in tissue and blood, and so the absorptive power is considerably higher. When an X-ray picture is taken of a hand (Figure 8.58), the X-radiation penetrates the muscle tissue and blood quite readily, but is



FIGURE 8.58 X-ray photograph of a human hand.




FIGURE 8.60 Schematic X-ray absorption photograph of a mechanical weld.

In the field of metallurgy, applications of X-ray absorption include the detection of voids or the segregation of impurities, such as oxides, in welds and other joints. Figure 8.60 shows an idealized X-ray absorption photograph of a mechanical weld that contains voids or internal holes. Such holes indicate that the weld is mechanically weak and might break in use. If the weld is weak, it must be strengthened to form a sufficiently strong joint. This type of non-destructive testing is used to check the manufacturing quality of ships, aircraft, bridges, and buildings. It also used to check these structures during routine maintenance. X-ray absorption is routinely used for measuring the thickness of thin metal films.

The technique of X-ray absorption can also be used to determine the levels of liquids in enclosed vessels or pipes without opening or breaking them. The same process can be used to detect metal supports or metal fillings inside constructed objects as diverse as buildings and small works of art. A major advantage is that X-ray techniques are usually nondestructive. Sometimes artists paint over old paintings, using the canvas for their own work and covering unrecognized masterpieces in the process. Using X-ray absorption, it is possible to reveal the covered painting without removing the top painting. When used to examine a metal horse sold for several million dollars as an ancient Greek art piece, X-ray absorption showed that the horse contained internal metal supports and was therefore a fake. This was done without destroying the art piece, in case it had been authentic.

For quantitative elemental analysis, X-ray absorption is not particularly useful except in the case of a single heavy element in a light matrix. As we saw in Equation 8.10, the mass absorption coefficient needed for the Beer's Law calculation (Equation 8.20) must be calculated from the weight fractions of elements present in the sample. The weight fractions are usually unknown. Quantitative analysis by X-ray absorption is usually only used for the determination of a high atomic number element in a matrix of lower atomic number elements. Examples include the determination of lead or sulfur in hydrocarbon fuels, and the determination of Pt catalyst in polymers, where the difference in mass absorption coefficients between analyte and matrix is large. One approach to quantitative analysis using X-ray absorption is based on the measurement of the intensities of two or more monochromatic X-rays passed through the sample. This is called X-ray preferential absorption analysis or dual-energy transmission analysis. The analysis depends on the selective absorption of the transmitted X-rays by the analyte compared with absorption by the rest of the sample (the matrix). The sensitivity of the analysis also depends on the difference in mass absorption coefficients of the analyte and sample matrix for the transmitted X-rays; a big difference results in a more sensitive analysis. The analyte concentration calculation in any absorption method requires that the thickness and density of the sample be known and requires a homogenous matrix for accurate quantitative results.

An example of the use of X-ray absorption (transmission) is the determination of sulfur in heavy hydrocarbon process streams. Accurate determination of sulfur is required for assaying and blending of crude oil, marine oil, and bunker fuel. The term used by the petroleum industry is X-ray Transmission (XRT) or Absorption (XRA) gauging. XRT/ XRA gauging involves measuring the attenuation of a monochromatic X-ray beam at 21 keV. This energy is chosen because at 21 keV, the molar absorptivity for S is 14 times larger than the molar absorptivity of the hydrocarbon matrix and 7 times larger than oxygen (Table 8.11).




FIGURE 8.63 (a) A portion of a 3D crystal lattice. The unit cell, or basic repeating unit, of the lattice is shown in heavy outline. The black dots represent the atoms or ions or molecules that make up the crystal. (b) A cubic unit cell, with the corners of the cell located at 1 unit from the origin (0). The triangular plane drawn within the unit cell intersects the x-axis at 1/2, the y-axis at 1/2, and the z-axis at 1. This plane has miller indices of (221). (c) A family of planes shown in a 2D lattice.

In Figure 8.64, radiation from the source falls on the crystal, some on the top atomic plane, some on the second plane. Since the two beams are part of the same original beam, they are in phase on reaching the crystal. However, when they leave the crystal, the part leaving the second plane has traveled an extra distance *ABC*. If *ABC* is a whole number of wavelengths, the two beams leaving the crystal will be in phase and the light is coherent. If *ABC* is not a whole number of wavelengths, the two beams come together out of phase and by destructive interference the light is destroyed.




FIGURE 8.64 Reinforcement of light diffracted from two crystal planes.

TABLE 8.12	Order of Diffraction for Values of N , λ				
n	λ (Å)	nλ	Order		
1	0.60	0.60	First		
2	0.30	0.60	Second		
3	0.20	0.60	Third		
4	0.15	0.60	Fourth		

As we derived earlier, $n\lambda = 2d \sin \theta$. This is the Bragg equation, which states that coherence occurs when $n\lambda = 2d \sin \theta$. It can be used to measure d, the distance between planes of electron density in crystals, and is the basis of **X-ray crystallography**, the determination of the crystal structure of solid crystalline materials. Liquids, gases, and solids such as glasses and amorphous polymers have no well-ordered structure; therefore, they do not exhibit diffraction of X-rays.

For any given crystal, d is constant for a given family of planes; hence for any given angle θ and a given family of planes, $n\lambda$ is constant. Therefore, if n varies, there must be a corresponding change in λ to satisfy the Bragg equation. For a given diffraction angle, a number of diffracted lines are possible from a given family of planes; n is known as the **order** of diffraction. As an example, if $2d \sin \theta$ equals 0.60, each of the conditions of Table 8.12 will satisfy the Bragg equation. Radiation of wavelength 0.60, 0.30, 0.20, or 0.15 Å will diffract at the same angle θ in first, second, third, or fourth order, respectively, as seen in Figure 8.65. This is called order overlap and can create difficulty in interpretation of crystal diffraction data.

It should be noted that radiation of 0.30 Å would also be diffracted at a different angle in first order from the same family of planes (same d value), as shown in Figure 8.65. Wavelengths corresponding to low orders such as first and second order give observable diffraction lines. Consequently, a single plane will generate several diffraction lines for each wavelength. Each of the planes in the three dimensions of the crystal will give diffraction lines. The sum total of these diffraction lines generates a diffraction pattern. From the diffraction pattern, it is possible to deduce the different distances between the planes as well as the angles between these planes in each of the three dimensions. Based on the diffraction pattern, the physical dimensions and arrangement of the atomic planes in the crystal can be identified.




FIGURE 8.65 Diffraction of radiation of different wavelengths. Overlap can occur when different orders are diffracted at the same angle.




FIGURE 8.66 Schematic layout of a single-crystal XRD.

8.4.1 SINGLE CRYSTAL X-RAY DIFFRACTOMETRY

The schematic layout of a single crystal diffractometer is given in Figure 8.66. This system uses an X-ray tube, a sample specimen, and a detector that rotates in an arc described by a Rowland circle. Note that the single crystal sample takes the place of the analyzing crystal in a WDXRF analyzer. The goniometer mounting for a single crystal diffractometer is very complex, because the crystal must be moved in three dimensions to collect data from many planes. A commercial benchtop single crystal XRD instrument is shown in Figure 8.67.

For any given experiment, λ is the known wavelength of the monochromatic X-ray beam, θ is controlled and varied by the goniometer. From this information d can be calculated. By rotating the goniometer and examining various sides of the crystal, hundreds (or thousands) of diffracted X-rays are collected. This data is processed to identify the positions of the planes and atoms in the crystal in three dimensions. Modern single crystal diffractometers use computers to control the goniometer and to process the data. The diffraction data is usually converted to a 2D electron density map by Fourier transformation. The electron density map shows the location of atoms. A 2D electron density map is produced for each angle. The computer program uses the 2D maps plus the rotation angle data to generate the 3D coordinates for atoms (molecules, ions) in the crystal. The mathematical treatment of the experimental data to produce a crystal structure from an unknown single crystal diffraction pattern is complicated and beyond the scope of this text, but an example of the results will be shown below.

The diffraction pattern of a single crystal of an inorganic salt is shown in Figure 8.68; an actual diffraction pattern is shown in Figure 8.69. A given molecule always gives the same diffraction pattern, and from this pattern we can determine the spacing between planes and the arrangement of planes in the crystal. Also, qualitative identification can be obtained by matching this pattern to previously identified patterns. Modern instruments are equipped with 2D imaging detectors such as CCDs.

8.4.2 CRYSTAL GROWING

In order to determine the structure of a single crystal, such a crystal must be grown from the material to be studied. The crystal quality determines the quality of diffraction results obtained. One limitation of XRD is that data is obtained on only one single crystal of the bulk material, unlike other techniques where multiple replicates are usually analyzed. The growth of single crystals of materials often is not easy. Simple inorganic salts and small organic molecules can be crystallized as single crystals by very slow evaporation of a supersaturated



(a)



FIGURE 8.67 (a) A benchtop single crystal XRD system, the Rigaku XtaLAB mini™. (b) Close-up of the goniometer, X-ray tube, and detector in the XtaLAB mini™. The single crystal sample is mounted at the tip of what looks like a sewing needle in the center of the photo. (Used by permission of Rigaku Corporation [www.rigaku.com].)




FIGURE 8.68 Diffraction pattern in two dimensions of a single crystal of an inorganic salt.




FIGURE 8.69 Single crystal diffraction pattern of sulfanilamide (para-aminobenzenesulfonamide) collected with a Rigaku XtaLAB mini™ by Lee M. Daniels, Ph.D., Director, Small Molecule Crystallography, Rigaku Americas Corporation, The Woodlands, TX. www.rigaku.com/smc. (©Rigaku Corporation [www.rigaku.com]. Used with permission.)

solution of the salt or compound. Once one tiny single crystal forms, it will grow in preference to the formation of more small crystals. Sublimation under vacuum can be used. Proteins and other biomolecules are more difficult to grow as single crystals because they are complex. One method that often works is to suspend a drop of protein solution over a reservoir of buffer solution. Water diffusion from the drop often results in single crystal growth. Different techniques are required to form metal crystals. The interested student can find many references and resources on the Internet, by searching the term "X-ray crystallography". The single crystal then has to be mounted; various mount types are available depending on the instrument and goniometer being used.

8.4.3 CRYSTAL STRUCTURE DETERMINATION

From the diffraction pattern, the crystal structure can be determined mathematically and the compound identified. While discussion of the details is beyond the scope of this text, small, benchtop automated single crystal XRD systems have come into use. These instruments possess a variety of powerful data processing programs and libraries that permit the determination of high-resolution crystal structures of small molecules rapidly and automatically. Systems include the Rigaku XtaLAB mini™ and the Bruker X2S.

The XtaLAB mini™ software shows the approach used by these automated systems. Figure 8.70 lists the steps involved in obtaining a structure from the diffraction pattern. Once the single crystal of the analyte has been mounted, a "project" is opened and the data collected. Then, the data is evaluated and the structure solved using one or more of the stored mathematical approaches. Some of the various methods and programs can be seen on the computer screen. A model is created, refined and a report with the crystal structure, lattice parameters and molecular identification produced. Figure 8.71 shows the refinement results for a particular crystal obtained using the program SHELX. The results after five cycles of refinement (which requires over 2000 observations and 231 variables) give a "goodness of fit" of 1.066, an indication that the result is highly probable. Perfect fit would be 1.000. The number of cycles, observations and variables make it clear that without modern computer processing, determination of a structure from an XRD pattern would take days or weeks of work, as it used to.

Measurement times for crystals of small molecules using such a system vary and depend on the complexity of the molecule. Potassium tetrachloroplatinate II, K_2PtCl_4 , required less than two hours of measurement time using the XtaLAB mini, while a structure like raffinose, $C_{18}H_{32}O_{16}$. $5H_2O$, required 5 hours and 30 minutes. The overall results from an analysis of the diffraction pattern would include the chemical structure, the name of the




FIGURE 8.70 Computer screen of the XtaLAB mini™ showing the automated program steps for solving a crystal structure, including a list of some of the mathematical methods available and the molecular structure resulting from the data processing. (Used by permission of Rigaku Corporation. www.rigaku.com.)




FIGURE 8.71 Computer screen of the automated results of the refinement of a crystal structure by the XtaLAB mini™. (Used by permission of Rigaku Corporation. www.rigaku.com.)

compound, formula weight, the space group to which the crystal belongs, and the crystal lattice constants.

8.4.4 POWDER X-RAY DIFFRACTOMETRY

Powdered crystalline samples can also be studied by XRD. The sample is loaded onto the specimen holder, which is placed in the X-ray beam in a setup similar to that used for single crystal XRD. The sample must be powdered by hand or by mechanical grinding and is pressed into a sample holder to form a flat surface or packed into a thin glass or polymer capillary tube. After mounting, the specimen is rotated relative to the X-ray source at a rate of (degrees θ)/min. Diffracted radiation comes from the sample according to the Bragg equation. The detector is simultaneously rotated at (degrees 2θ)/min, using traditional θ -2 θ geometry. Alternatively, instruments such as the Thermo Fisher Scientific ARL X'TRA powder diffraction system are available using a θ - θ geometry (Bragg-Bretano geometry).

A powdered crystalline material contains many thousands of tiny crystals. These crystals are oriented in all possible directions relative to the beam of X-rays. Hence, instead of the sample generating only single diffraction spots, it generates cones of diffracted X-rays, with the point of all of the cones at the sample (Figure 8.72). Each family of planes will have a different circular diameter, so the result is a series of concentric cones radiating from the sample. Imagine that inside the Rowland circle opposite the sample, we have a strip of X-ray film as shown in Figure 8.72 on the right. The circular cones of X-rays will hit the film, resulting in a series of curved lines on the film (Figure 8.72 left). A typical diffraction pattern from a powdered sample collected on film is shown in Figure 8.73. These are called Debye-Scherrer photographs. Film has been replaced by automated scanning with a standard X-ray detector as discussed for XRF or by the use of imaging detectors such as CCDs or image plates to give a 2D image. A cylindrical image plate detector used by Rigaku Corporation has an active area of 454 mm \times 256 mm, a pixel size of 100 μ m \times 100 μ m. extremely rapid readout, and a sensitivity of 1 X-ray photon per pixel for Cu K $_{\alpha}$ radiation. One X-ray photon




FIGURE 8.72 Schematic of diffraction from a powdered crystalline sample. The powdered sample generates the concentric cones of diffracted X-rays because of the random orientation of crystallites in the sample. The X-ray tube exciting the sample is not shown in this diagram. The cones of diffracted light intersect X-ray film curved to fit the diameter of the Rowland circle. The result is a series of curved lines on the X-ray film.




FIGURE 8.73 A schematic diffraction photograph, called a Debye-Scherrer photograph, from a powdered crystalline sample.

per pixel is a quantum efficiency of 100 %. The major advantage of these imaging detectors is that the images can be stored and manipulated electronically, and without the need for a photographic film-developing lab. The Thermo Fisher Scientific ARL X'TRA uses a Peltier cooled Si(Li) solid state detector which can be cooled to about –100°C, resulting in extremely low internal noise. This solid-state detector allows the user to electronically select photons based on their energy signature, which eliminates the need for beta filters or diffracted beam monochromators to remove Bremsstrahlung and sample fluorescence.

In order to obtain accurate XRD spectra, the sample must be ground finely and pressed, so that there is sufficient random orientation of the crystals in the sample. Non-random orientation (preferred orientation) will result in a distorted spectral pattern, like a broken line or series of spots instead of a complete curved line. Some materials exhibit preferred orientation, either naturally or by design, and can be identified through these distortions. Powder diffractometers come in a variety of sizes, including small benchtop units and field portable units (Section 8.4.5.1).

8.4.5 HYBRID XRD/XRF SYSTEMS

Hybrid systems are designed to combine the speed and flexibility of XRD and XRF systems in one spectrometer. Such systems permit more complete characterization of a given crystalline sample. These systems are varied: some are XRF systems with a few powder XRD-based channels to identify compounds, such as a system designed with a CaO channel for the cement industry. The combination can go as far as including a complete powder diffractometer and XRF spectrometer for flexible compound identification and quantification. These types of systems are generally used in industries, including metal and alloy production, cement production, mining, refractory materials production, and the like, for both R&D and process control.

Thermo Fisher Scientific's ARL 9900 series hybrid systems offer a variety of configurations of the XRF and powder XRD components for R&D, fast process analysis, qualitative and quantitative elemental analysis and phase analysis. The system can be configured in many ways: with up to 32 monochromators for fast elemental analysis, up to three goniometers for analysis of specific elements (quantitative and standardless analysis), scanning the XRF spectrum (qualitative and semiquantitative analysis), a compact XRD system for process control or a full powder XRD system. With the XRF unit, up to 83 elements (B to U) can be determined from ppm levels to 100 %. The full XRD goniometer, called the NeXRD, provides qualitative and quantitative phase analysis. Full pattern quantitative phase analysis results can be obtained in five minutes using automatic interpretation of the XRD pattern. The 9900 series has options for a variety of automated sample changers (12 or 98 position) and can be integrated with the ARL robotic sample preparation systems, allowing unattended continuous operation of the instrument. This system is a floor-mounted laboratory unit. The advantages of a hybrid unit for the laboratory are that it provides a single user interface for both XRF and XRD techniques, minimizes occupied floor space, merges elemental and phase analysis into a single report, and permits rapid, precise analysis of solid samples. One limitation of such systems is that they can only handle solid samples. Pictures and details are available at www.thermo.com./xray.

A revolution in powder XRD/XRF systems has resulted from the development of portable, compact, rugged systems designed originally for rock and mineral analysis in the field. The Terra Mobile XRD system (from Innov-X and Olympus [www.olympus-ims.com; www.inxitu.com]) is a high-performance combination 2D powder diffraction/XRF system that is battery powered, completely self-contained, very rugged, and field portable [Figures 8.74(a and b)].

The Terra provides full phase ID of major, minor, and trace components in rocks and minerals and an XRF system capable of scanning from Ca-U. It has a sample handling system that can sieve powders to <150 μ m and requires only 20 mg of sample. To obtain accurate powder XRD spectra, it is generally necessary to finely grind a sample and press a pellet, to ensure sufficient random orientation of the crystals in the sample. To avoid the problems





FIGURE 8.74 (a) and (b) Two images of geologists using the terra Mobile XRF system in real mining applications in field conditions. (Courtesy of Olympus NDT [www.olympus-ims.com; www.inxitu.com].)




FIGURE 8.78 Schematic diffraction pattern from a semicrystalline polymer, showing how both crystalline and amorphous phases may be detected. The amorphous portion results in broad scattering while the crystalline portion shows a typical diffraction peak pattern. A totally amorphous polymer would show no diffraction peaks. (There are no 100 % crystalline polymers.) The units on the x-axis are degrees θ .

In polymer characterization, it is possible to determine the degree of crystallinity of semi-crystalline polymers. The noncrystalline (amorphous) portion simply scatters the X-ray beam to give a continuous background, whereas the crystalline portion gives diffraction lines. A typical schematic diffraction spectrum of a semicrystalline polymer is shown in Figure 8.78. The ratio of the area of diffraction peaks to scattered radiation is proportional to the ratio of crystalline to noncrystalline material in the polymer. The ultimate quantitative analysis must be confirmed using standard polymers with known percent crystallinity and basing the calculation on the known ratio of crystalline diffraction to amorphous scattering.

Using an XRD pattern and looking at the intensity of peaks, it is possible to determine if the crystals of a polymer or a metal are oriented in any particular direction. "Preferred orientation" can occur after the material has been rolled out into a sheet, for example. This is sometimes a very undesirable property, since the material may be very weak in one direction and strong in another, with the result that it tears easily in one direction. Sometimes, however, this is a desirable property, as, for example, in packaging material that we may wish to tear easily in one direction to open the package.

Powder XRD is used for phase analysis and compound identification in a variety of industries, especially mineral, mining, and metal production, for materials such as rocks, minerals, oxide materials and products. Typical examples include the levels of Fe phases such as FeO, Fe₂O₃, Fe₃O₄, and FeC; determination of free lime in clinker and slags in the cement industry; phases related to the electrolysis of Al, and CaO, CaCO₃ and Ca(OH)₂ content.

XRD at different temperatures can be used to study phase transitions between different crystallographic forms of a material (e.g., tetragonal versus monoclinic forms of yttria-stabilized zirconia). This approach can be used to measure thermal expansion coefficients and to study crystalline-to-amorphous transitions in materials.

A property of metals that can be determined by XRD is the state of anneal. Well-annealed metals are in an ordered crystal form and give sharp diffraction lines. If the metal is subjected to drilling, hammering, or bending, it becomes "worked" or "fatigued"; the crystal structure and the diffraction pattern change. Working a metal initially increases its strength, but continued deformation (fatigue) weakens the metal and can result in the metal breaking. (Try bending a paper clip slowly—you should note that it becomes harder to bend after one or two workings, but then if you continue to bend it at the same point, it will eventually become fatigued and break.) Disorder in metals and alloys can also result from rapid cooling from the molten state. Disorder results in lower density and a more brittle material. Electrical conductivity of metals is also affected by the order in the metal crystal. XRD can be used to distinguish between ordered and disordered materials and provide valuable information on the suitability of a material for a given use.

A very important use of XRD is in the determination of the structure of single crystals, that is, identifying the exact position in 3D space of every atom (molecules, ions) in the crystal. Single crystal XRD was a major tool in elucidating the structure of ribonucleic acid (RNA) and deoxyribonucleic acid (DNA), insulin, vitamins, and proteins. Single crystal diffractometry is used for structural determination of biomolecules, natural products, pharmaceuticals, inorganic coordination complexes, and organometallic compounds.

XRD does have limitations. Amorphous materials cannot be identified by XRD, so many polymeric and glassy materials cannot be studied. XRD is not a trace analysis technique. A component should be present at 3-5 % by weight at a minimum in order for diffraction peaks to be detected. The unique pattern from a mixed crystal, where one atom has replaced another in the lattice, was discussed earlier. A mixed crystal is analogous to a solid solution of a contaminant in a pure material. The contaminated material will appear to be a single phase, since it is a solid solution, but the lattice of the pure material will be expanded or contracted as the result of contaminant atoms of the "wrong" size in the lattice. There will be a unique diffraction pattern, but such a pattern may be hard to match. Mixtures may be difficult to identify because of overlapping peaks.

8.5 X-RAY EMISSION

In XRF, characteristic X-rays from an X-ray source are used to excite characteristic X-rays from a sample. X-ray emission differs in that particles such as electrons and alpha particles are the sources used to generate characteristic X-rays from a sample. Several types of X-ray emission systems are available. Electron probe microanalysis and scanning electron microscopy will be covered in Chapter 13. Here we will focus on particle-induced X-ray emission (PIXE).

The use of a radioactive isotope as a source for XRF was discussed and a list of common radioactive sources was given in Table 8.4. The use of one that generates "particles"-electrons or alpha particles-gives rise to the term particle-induced X-ray emission (PIXE). The 2012 NASA Martian Space Laboratory rover, Curiosity, has on board a PIXE instrument called an Alpha Particle X-ray Spectrometer (APXS). The APXS uses a Curium-244 source to excite characteristic X-rays from Martian rocks. The spectrometer includes a calibration target with multiple elements. The target is a well-characterized rock slab brought from Earth to enable accurate determination of the composition of Martian rocks. The calibration target spectrum is shown in Figure 8.79.




FIGURE 8.79 Spectrum of the calibration target from the alpha particle X-ray spectrometer on the Martian rover "Curiosity". (Image credit: NASA/JPL-Caltech/LANL.)




FIGURE 8.80 The "Jake Matijevic" rock on mars, showing the circles where the APXS instrument obtained data, as well as the laser pits (black dots) from the LIBS instrument. (Image credit: NASA/JPL-Caltech/LANL. Full color images are available at www.Nasa.gov/mission_pages/msl.)

Figure 8.80 shows a Martian rock known as "Jake Matijevic" that has been studied using the APXS and the ChemCam LIBS instrument (described in Chapter 7). The two black circles on the rock face show the areas studied by the APXS. The black dots are the laser pits from the LIBS instrument. The results of the APXS analysis are shown in Figure 8.81.

The spectra from the rock and target were collected for 1 hour. Results showed that, compared to previous Martian rocks, the Jake rock is low in Fe and Mg, but high in Na, Al, Si, and K, which are often found in feldspar minerals. The results point to an igneous or volcanic origin for the rock.





FIGURE 8.81 Spectrum from "Jake" and the calibration target acquired by the APXS system. (Image credit: NASA/JPL-Caltech/LANL.)


These spectra were collected on a Thermo Scientific EDXRF using different voltages, filters, and atmospheres. The conditions are given in each spectrum. Check the voltage and filter combinations used for the elements that can be detected using that combination.

Filter	Tube Voltage (kV)	Elements Optimized	Other Elements Detected
None	8–15	Na–S (K lines)	K–Fe (K lines)
		Zn-Mo (L lines)	Tc-Ce (L lines)
Cellulose	8–15	CI-Sc (K lines)	Al–Zn (K lines)
		Tc-Cs (L ines	Zr-Gd (L ines)
Al, 0.127 mm	10-20	Ti-Mn (K lines)	CI-Br (K lines)
		Ba-Sm (L lines)	Ag-Hf (L lines)
Thin (0.05 mm Rh)	20-30	Fe-Ge (K lines)	K–Mo (K lines)
		Eu-Au (L lines)	Ba–U (L lines)
Five (0.127 mm Rh)	30-45	As-Mo (K lines)	Ti-Mo (K lines)
		Hg-U (L lines)	
Six (0.63 mm Cu)	45–50	Tc–La (K lines)	Zn–La (L lines)

8.24 Identify the binary inorganic salt that gives the following spectrum.




8.25 Identify the elements present in this spectrum.




514


8.26 Identify the elements present in this spectrum.




8.27 Identify the elements present and label the lines.




8.28 Identify the elements present-there are at least seven. (Hint: many are high Z elements).




8.29 More high Z elements to identify. Label the lines.



8.30 This is the spectrum of the X-ray tube. The line spectrum was obtained with NO filter in the X-ray tube path. The dotted spectrum was obtained using a 0.63 mm Cu filter. (1) Identify the X-ray tube anode. (2) What do we call the radiation emitted by the filtered X-ray tube? (3) What elements will be excited using the filtered tube radiation? (4) Why do you want the tube voltage so high? (50 kV is high voltage). (5) Why not use the unfiltered X-ray tube spectrum to excite your sample? Can you list two elements that could not be determined using the unfiltered X-ray tube, other than the anode element itself?



8.31 A sample with many elements. Identify as many as you can. This sample is loaded with stuff!! Good Luck!



- 8.32 In Figure 8.27(a), there is a peak labeled by the software as francium, Fr. The text states that this is an unlikely element in the sample. Why?
- 8.33 A thin coating of osmium is used on non-conducting samples for SEM analysis. Why? Osmium is highly toxic. Why use such a toxic element instead of a less harmful one?

BIBLIOGRAPHY

American Society for Testing and Materials. *Annual Book of ASTM Standards*; ASTM: West Conshohocken, PA. 2002.

Application reviews. Anal. Chem. 1994, June.

Bertin, E.P. *Principles and Practice of X-Ray Spectrometric Analysis*, 2nd; Plenum Press: New York, 1975.

Bertin, E.P. Introduction to X-Ray Spectrometric Analysis; Plenum Press: New York, 1978.

Burr, A. In Handbook of Spectroscopy; Robinson, J.W., Ed.; CRC Press: Boca Raton, FL, 1994; Vol. 1.

Clark, G.L., Ed. Encyclopedia of X-Rays and Gamma Rays; Reinhold Publishing: New York, 1963.

Criss, J.W.; Birks, L.S. Anal. Chem. 1968, 40, 1080-1086.

Ellis, A.T. *Handbook of X-Ray Spectrometry*, 2nd Ed.; Van Griekin, R.E., Markowicz, A.A., Eds.; Marcel Dekker, Inc.: New York, 2002.

Formica, J. X-ray diffraction. In *Handbook of Instrumental Techniques for Analytical Chemistry*; Settle, F., Ed.; Prentice-Hall, Inc.: Upper Saddle River, NJ, 1997.

Gross, A. The Characterization of Historic Pigments by μ XRF Spectrometry, Bruker Nano Lab Report XRF 422, www.bruker.com. 2010.

Hahn, O.; Oltrogge, D.; Bevers, H. Archaeometry, 2003.

Havrilla, G.J. X-ray fluorescence spectrometry. In *Handbook of Instrumental Techniques for Analytical Chemistry*, Settle, F., Ed.; Prentice-Hall, Inc.: Upper Saddle River, NJ, 1997.

Helson, L.A.; Kuczumov, A. In *Handbook of X-Ray Spectrometry*, 2nd Ed.; Van Griekin, R.E.; Markowicz, A.A., Eds.; Marcel Dekker, Inc.: New York, 2002.

Herglotz, H.K.; Birks, L.S. X-Ray Spectrometry; Marcel Dekker, Inc.: New York, 1978.

Jenkins, R. X-ray fluorescence. Anal. Chem. 1984, 36, 1009A.

Jenkins, R. X-Ray Fluorescence Spectrometry, 2nd; John Wiley and Sons, Inc: New York, 1999.

Jenkins, R.; Snyder, R.L. *Introduction to X-Ray Powder Diffractometry*; John Wiley and Sons, Inc.: New York, 1996.

Jenkins, R.; Gould, R.W.; Gedcke, D. *Quantitative X-Ray Spectrometry*; Marcel Dekker, Inc.: New York, 1981.

Jenkins, R.; Manne, R.; Robin, J.; Senemaud, C. Pure Appl. Chem 1991, 63 (5), 785.

Lubhofsky, H.A.; Schweikert, E.A.; Myers, E.A. *Treatise on Analytical Chemistry*, 2nd; Wiley Interscience: New York, 1986.

Markowicz, A.A. In *Handbook of X-Ray Spectrometry*, 2nd Ed.; Van Griekin, R.E., Markowicz, A.A., Eds.; Marcel Dekker, Inc.: New York, 2002.

Parsons, M.L. X-ray methods. In *Analytical Instrumentation Handbook*, 2nd Ed.; Ewing, G.W., Ed.; Marcel Dekker, Inc.: New York, 1997.

Robinson, J.W. Handbook of Spectroscopy; CRC Press: Boca Raton, FL, 1974; Vol. 1.

Robinson, J.W. Practical Handbook of Spectroscopy; CRC Press: Boca Raton, FL, 1991.

Stout, G.H.; Jensen, L.H. *X-Ray Structure Determination*; Macmillan Publishing Co., Inc.: New York, 1968.

Teo, B.K.; Joy, D.C., Eds. *EXAFS Spectroscopy: Techniques and Applications*; Plenum Press: New York, 1981.

Van Griekin, R.E.; Markowicz, A.A., Eds. *Handbook of X-Ray Spectrometry*, 2nd; Marcel Dekker, Inc. New York, 2002.



Mass Spectrometry

9

Mass spectrometry (MS) is a technique for creating gas phase ions from the molecules or atoms in a sample, separating the ions according to their mass-to-charge ratio, m/z, and measuring the abundance of the ions formed.

J.J. Thompson in 1913 first used MS to demonstrate that neon gas consisted of a mixture of nonradioactive isotopes, ²⁰Ne and ²²Ne. The atomic weight of neon listed in a modern periodic table is 20.18. Thompson obtained two peaks in the mass spectrum of neon, at masses of 20 and 22 with a roughly 10:1 intensity ratio, but no peak at mass 20.18. This work was revolutionary because it demonstrated that elements existed as isotopes with different atomic weights and explained why the apparent atomic weight of an element based on chemical reactions was not a whole number. Neon in fact has three natural isotopes, but ²¹Ne is present in much smaller amounts than the other two isotopes. In 1923, Francis W. Aston used a higher resolution instrument he designed to determine the atomic weights of the elements and the isotope ratios of each particular element. This was extremely useful to inorganic chemists and helped solve many of the problems concerning the position of elements in the periodic table at that time. During World War II, Nier at the University of Minnesota developed the high-resolution double-focusing instrument that permitted the analysis and separation of ²³⁵U from ²³⁸U, aiding in the development of the atomic bomb.

In the 1940s, the first commercial mass spectrometers were developed for petroleum analysis. Subsequent instrument developments, many of them only in the past decade, have led to the widespread use of MS in many branches of science. It has been estimated (Busch) that a billion mass spectra are recorded daily.

MS is currently one of the most rapidly advancing fields of instrumental analysis. It has developed from an inorganic method used to prove that most elements exist as isotopes of differing masses, to both a cornerstone technique used to elucidate the structure of organic and biomolecules of all molecular weights, and a fundamental extremely sensitive elemental analysis technique. MS provides the analyst with information as diverse as the structure of complex organic and biomolecules to the quantitative determination of ppb concentrations of elements and molecules in samples.

MS is an analytical technique that provides qualitative and quantitative information, including the mass of molecules and atoms in samples as well as the molecular structure of organic and inorganic compounds. MS can be used as a qualitative analytical tool to identify and characterize different materials of interest to the chemist or biochemist. MS is used routinely for the quantitative analysis of mixtures of gases, liquids, and solids. MS is a powerful analytical tool with vast applications in organic, inorganic, environmental, polymer and physical chemistry, physics, geology, climatology, paleontology, archaeology, materials science, biology, and medicine. Advances in MS instrumentation have made possible major advances in our understanding of the human genome, protein structure, and drug metabolism. For example, intact viruses of millions of daltons have been analyzed by MS with retention of viral activity and structure (Fuerstenau et al.). Commercial hyphenated GC-MS and LC-MS systems permit rapid, sensitive biomonitoring of humans for exposure to chemicals, including chemicals used by terrorists. Hyphenated chromatography-ICP-MS systems allow the speciation of inorganic and metallo-organic compounds.

9.1 PRINCIPLES OF MS

The mass spectrometer is an instrument that separates gas phase ionized atoms, molecules, and fragments of molecules by the difference in their mass-to-charge ratios. The mass-to-charge ratio is symbolized by m/z, where the mass m is expressed in **unified atomic mass units** and z is the number of charges on the ion. The statement found in many texts that MS separates ions based on *mass* is only true when the charge on the ion is a single + or -. In this case m/z is numerically equal to the mass of the ion. While some MS methods do generate mostly +1 charged ions, many new techniques generate ions with multiple charges.

The mass of an ion is given in **unified atomic mass units, u**. One unified atomic mass unit is equal to 1/12 of the mass of the most abundant, stable, naturally occurring isotope of carbon, 12 C. The mass of 12 C is defined as exactly 12 u. The abbreviation **amu**, for atomic mass unit, is now considered obsolete but may still be encountered in the literature. A synonym for the unified atomic mass unit is the dalton (Da); 1 u = 1 Da. In the SI unit of mass, $1 \text{ u} = 1.665402 \times 10^{-27} \text{ kg}$. Table 9.1 presents the exact masses for some common isotopes encountered in organic compounds.

The term z symbolizes the *number of charges* on the ion; this number may be positive or negative, such as +1, -1, +2, +10, and so on. The number of charges is not the same as the total charge of the ion in coulombs (C). The total charge q = ze, where e is the magnitude of the charge on the electron, 1.6×10^{-19} C.

TABLE 9.1	Comparison of Atomic Weights and Measured
	Accurate Isotope Masses for Some Common
	Elements in Organic Compounds

Element	Atomic Weight	Isotope	Massa	%Abundance
Hydrogen⁵	1.00794(7)	¹ H	1.007825	99.99
		² H (or D)	2.01410	0.01
Carbon ^b	12.0107(8)	¹² C	12.000000 (defined)	98.91
		¹³ C	13.00336	1.1
Nitrogen ^b	14.0067(2)	¹⁴ N	14.0031	99.6
		¹⁵ N	15.0001	0.4
Oxygen⁵	15.9994(3)	¹⁶ O	15.9949	99.76
		¹⁷ O	16.9991	0.04
		¹⁸ O	17.9992	0.20
Fluorine	18.99840	F	18.99840	100
Phosphorus	30.97376	Р	30.97376	100
Sulfur ^b	32.065(5)	³² S	31.9721	95.02
		³³ S	32.9715	0.76
		³⁴ S	33.9679	4.22
Chlorine ^b	35.453(2)	³⁵ Cl	34.9689	75.77
		³⁷ Cl	36.9659	24.23
Bromine	79.904(1)	⁷⁹ Br	78.9183	50.5
		⁸¹ Br	80.9163	49.5

- ^a Many of the isotope masses have been determined by MS accurately to seven or more decimal places. Numbers in parentheses in the atomic weights represent the first uncertain figure.
- b The atomic weights for these elements and a few others are now given as ranges due to the variability of values in natural terrestrial materials. Atomic weights are based on the 2009 values in *Pure Appl. Chem.* 2011, 83, 359–396 as tabulated at http://www.chem.qmul.ac.uk/iupac/AtWt/. Used with permission. Newer tables now provide a range of isotope abundances of some elements due to variations in Earthly sources. Other celestial bodies (e.g., Moon, Mars, asteroidal meteorites) display even more different isotope variations, which enables MS measurements to identify the particular source of some meteorites.

For simplicity, the following discussion will focus on what happens to an organic molecule in one type of MS experiment. One method of forming ions from sample molecules or atoms is to bombard the sample with electrons. This method is called **electron ionization** (EI, note that one will often encounter this process referred to as electron impact as well as electron ionization):

$$(9.1) M+e^- \rightarrow M^{+\bullet} + 2e^-$$

where M is the analyte molecule; e^- , the electron; and M^+ , the ionized analyte molecule; this species is called the **molecular ion**.

In many cases, only ions with a single positive charge are formed; that is, the charge on the ion, z, equals +1. The MS separates ions based on the mass-to-charge ratio, m/z; for ions with a single positive charge, m/z equals the mass of the ion in unified atomic mass units. For a molecular ion, m/z is related to the molecular weight (also called the relative molecular mass, relative to carbon, which is exactly set at 12 as shown in the table) of the compound. The symbol M^{+*} indicates that a molecular ion from an organic compound, is a radical cation formed by the loss of one electron. In most cases, molecular ions have sufficient energy as a result of the ionization process to undergo *fragmentation* to form other ions of lower m/z. All these ions are separated in the mass spectrometer according to their m/z values and the abundance of each is measured.

A **magnetic sector** mass spectrometer is shown schematically in Figure 9.1. This instrument is a *single-focus* mass spectrometer. The gas phase molecules from the sample inlet are ionized by a beam of high energy (i.e., high velocity) electrons passing closely among them.




FIGURE 9.1 (a) Schematic magnetic sector mass spectrometer. (b) Schematic magnetic sector mass spectrometer showing a gas sample reservoir with fill and inlet valves and an electron multiplier (EM) detector. (c) Forces and energies associated with ions traveling through a magnetic sector mass spectrometer. For an ion to reach the detector, Bzv must equal mv²/r.

The rapidly changing electric field produced by the passage of an energetic electron can both eject electrons from the atom or molecule (ionization) and transfer sufficient energy to the molecule to cause its bonds to rupture (fragmentation). Only a very small percentage (0.1 to 0.001 %) of the molecules are ionized. A permanent magnet is often used to produce a magnetic field which causes the beam of electrons to follow a spiral trajectory of longer path length as they transit the ion source, thus increasing the ionization efficiency and improving sensitivity. However, too many ions in the ion source, especially when present from a high excess of unseparated matrix components, will add to and distort the instrument's operating fields from this space charge. The ions are then accelerated in an electric field at a voltage V. The energy of each ion is equal to the charge ztimes the accelerating voltage, zV. The energy acquired by an ion on acceleration is kinetic energy. It is important to note that the kinetic energy of an ion accelerated through a voltage V depends only on the charge of the ion and the voltage, not on the mass of the ion. The translational component of the kinetic energy is equal to $1/2mv^2$. The kinetic energy of all singly charged ions is the same for a given accelerating voltage; therefore, those ions with small masses must travel at higher velocity than ions with larger masses. That is, for ions with a single positive charge:

$$(9.2) 1/2mv^2 = zV$$

hence

$$(9.3) v = \left(\frac{2zV}{m}\right)^{1/2}$$

where m is the mass of the ion; v, the velocity of the ion; z, the charge of the ion and V, the accelerating voltage.

As m varies, the velocity ν changes such that $1/2m\nu^2$ remains a constant. This relation can be expressed for two different ions as follows:

(9.4)
$$zV = 1/2m_1v_1^2 \text{ (ion 1)}$$
$$zV = 1/2m_2v_2^2 \text{ (ion 2)}$$
$$1/2m_1v_1^2 = 1/2m_2v_2^2$$

where m_1 is the mass of ion 1; v_1 , the velocity of ion 1; m_2 , the mass of ion 2 and v_2 , the velocity of ion 2.

The velocity of an ion depends on its mass; the velocity is inversely proportional to the square root of the mass of the ion.

After an applied voltage has accelerated the charged ions, they enter a curved section of a magnet of homogeneous magnetic field B and a fixed radius of curvature. This magnetic field acts on the ions, making them move in a circle. The attractive force of the magnet equals Bzv. The centrifugal force on the ion is equal to mv^2/r , where r is the radius of the circular path traveled by the ion. If the ion is to follow a path with the radius of curvature of the magnet, these two forces must be equal:

$$(9.5) \frac{mv^2}{r} = Bzv$$

or

$$\frac{1}{r} = \frac{Bzv}{mv^2}$$




FIGURE 9.2 (a) A mass spectrum of benzene, C_6H_6 (MW = 78), plotted as relative abundance versus m/z, with the most abundant peak set to a relative abundance of 100. In this spectrum, the most abundant peak (or base peak) is the molecular ion peak at m/z 78, marked by the dark triangle on the x-axis. Some fragment ion m/z values are also marked on the spectrum. (b) A mass spectrum of cocaine. In this spectrum the molecular ion peak is not the base peak; The fragment ion at m/z 82 is the most abundant ion. (The cocaine spectrum is courtesy of Dr. Robert Kobelski, CDC, Atlanta.)

TABI	LE 9.2	Mass Spect	ral Da	nta for Benzene
m/z	Relativ	e Abundance	m/z	Relative Abundance
37		4	53	0.80
37.5		1.2	63	2.9
38		5.4	64	0.17
38.5		0.35	73	1.5
39		13	74	4.3
39.5		0.19	75	1.7
40		0.37	76	6.0
48		0.29	77	14
49		2.7	78	100
50		16	79	6.4
51		18	80	0.18
52		19		

interested student should see the texts by Lambert et al., McLafferty and Tureček, Silverstein et al. or Pavia et al. listed in the bibliography.

There is a difference between the mass of an atom (or ion) and what chemists are used to thinking of as the atomic weight or molecular weight of a species. Atomic weight is the average weight of all of the isotopes of an element and molecular weight is calculated from these average atomic weights. This is the value we would need to use if we wished to weigh out an exact number of moles of a substance whose component atoms have a distribution of different isotopes, which is usually the case. Each stable isotope (nuclide) of an element has an exact mass (more properly called a measured accurate mass), which has been determined accurately by MS. MS separates compounds containing ¹²C atoms from compounds with ¹³C atoms precisely because of the difference in mass between the isotopes. Table 9.1 gives a few examples of the atomic weights of some of the elements found in organic compounds as well as the measured accurate mass and abundance of the isotopes of the element. In a mass spectrum, a given ion is monoisotopic, not a weighted average. For example, the molecular weight of acetone, C₃H₆O, is calculated from the atomic weights of the elements to be $(3 \times 12.011) + (6 \times 1.00797) + (1 \times 15.9994) = 58.0795$ g/mol. The molecular ion of acetone as measured by MS has a mass that consists of only contributions from the one most abundant isotope of each element, that is, ¹H, ¹²C, and ¹⁶O; its mass can be calculated from the formula ${}^{12}C_3{}^{1}H_6{}^{16}O$ to be $(3 \times 12.000) + (6 \times 1.00783) + (1 \times 15.9949) = 58.0419$ u or 58.0419 g/mol, if we had a mole of the monoisotopic compound.

The term m/z is the correct term to use for the mass-to-charge ratio of an ion. Older literature used the term m/e; however, the symbol e is used for the charge on the electron in coulombs and is not what goes into the divisor when the mass is given in unified atomic mass units, u. Two terms used in the older literature that are no longer acceptable for use in MS are "parent ion" for molecular ion and "daughter ion" for fragment ions. Ions do not have gender. The terms molecular ion and fragment ion should be used; "precursor ion" and "product ion" are used for tandem MS/MS experiments described later in the chapter.

9.1.1 RESOLVING POWER AND RESOLUTION OF A MASS SPECTROMETER

The **resolving power** of a mass spectrometer is defined as its ability to separate ions of two different m/z values. Numerically, the resolution is equal to the mass of one singly charged ion, M, divided by the difference in mass between M and the next m/z value that can be separated. For example, to separate two singly charged ions of 999 and 1001 Da, requires a resolving power of 999/(1001 – 999) = 500. That is:

(9.9) resolving power =
$$\frac{M}{\Delta M}$$

In practice, it is found that if we wish to distinguish between ions of 600 and 599 Da, the resolving power required is 600, or 1 Da in 600 Da. As a rule of thumb, if we wish to distinguish between ions differing by 1 Da in the 600 Da mass range, we need a resolving power of 600. If we need to distinguish between ions differing by 1 Da in the 1200 Da range, we need a resolving power of at least 1200. This is not a very high resolution. Some isotopes of different elements or molecular fragment ions composed of different combinations of atomic isotopes adding up too close to the same mass, may produce ions differing by *much less* than 1 Da. To distinguish between these types of species, high-resolution mass spectrometry, with resolution in the range of 20,000-100,000 or higher, is required.

Both the magnetic sector and other designs of MS instruments control ion movement and trajectories by controlling the voltage fields from charge (electrons) on conductive metal components, often described as *lenses*, which focus and concentrate ions; or *extractors*, which move them between stages, or multipole rods with applied radio frequency alternating voltages and polarities which induce controlled resonant spiral orbits to select ions of a given m/z, etc. All these components must be interactively set to obtain the optimum MS ion peak shapes, ideally a Gaussian profile with the top of the symmetrical peak at a location on

the mass axis corresponding to the actual m/z value. The instrument must be "tuned" to this optimum (analogous to the much simpler process of tuning a radio to a particular station). As these components age or become contaminated, the voltages on the surfaces will shift, the MS peak shapes will deteriorate, and the instrument will require retuning. Depending on usage conditions, this might be required daily. Most modern computerized instruments employ "autotune" algorithms, whereby the computer observes selected peaks from an autotune compound vapor (often PFTBA [perfluorotributylamine]) continuously infused into the ion source, and iteratively adjusts all these interlocking voltages, checking selected MS peak shapes and positions, until an optimum set of tuning conditions is achieved.

The resolving power is determined by actual measurement of the mass spectral peaks obtained. The method for calculating ΔM must also be specified. Two methods are commonly used to indicate the separation between peaks and these are shown in Figure 9.3. One definition is that the overlap between the peaks is 10 % or less for two peaks of equal height; that is, the height of the overlap should not be more than 10 % of the peak height. A second method is to use the full width at half maximum (FWHM) as a measure of ΔM . The FWHM method results in a resolving power twice that of the 10 % overlap method, so it is important to state how the calculation was performed.

Resolving power for commercial mass spectrometers depends on the instrument design, and can range from 500 to more than 1×10^6 . In general, the higher the resolving power, the greater the complexity and cost of the MS instrument.

Resolution is the value of ΔM at a given M and is often expressed in ppm. For the spectrometer with a resolving power of 600 earlier described, the resolution would be 1 part in 600 parts. To distinguish between 14 N $_2^+$ with an exact mass of 28.0061 Da and 12 C 16 O $^+$ with an exact mass of 27.9949 Da, we would need a resolution of (28.0061 – 27.9949) = 0.0112 Da in 28 Da. To convert this resolution to ppm, divide 0.0112 by 28 and multiply by 1 × 10 6 ; a resolution of 400 ppm is required. The resolving power needed would be 27.9949/0.00112 = 2500. **Mass Accuracy** describes how well the top of the MS peak can be defined and kept stable, and its




FIGURE 9.3 Illustration of the peaks used to calculate the resolving power of a mass spectrometer showing the location of the FWHM, the 10 % valley, and the 5 % valley. (From Sparkman, O.D. *Mass Spectrometry Desk Reference*; Global View publishing: Pittsburgh, PA, 2000. Used with permission.)

position identified on the mass axis. Mass axis calibration is usually established by a separate portion of the tuning algorithm which identifies the centroids of several mass peaks of precisely known mass in the spectrum of a suitable calibration compound, and adjusts tuning parameters to place these at the appropriate positions on the mass axis. Like resolution, it can be expressed as a percentage or ppm value of the calibration mass values.

9.2 INSTRUMENTATION

All mass spectrometers require a sample input system, an ionization source, a mass analyzer, and a detector. All of the components with the exception of some sample input systems or ion source volumes are under vacuum (10^{-6} – 10^{-8} torr for that portion where ions are separated by mass, i.e., the **analyzer**, or 10^{-4} – 10^{-5} torr in some **ion sources**, where the ions are initially formed), so vacuum pumps of various types are required. Other ion sources, such as the DART (discussed in Section 9.2.2.3), ESI (Sections 9.2.2.3 and 12.1.6.1) or CI (Section 9.2.2.2) operate at atmospheric pressure (AP) and use extraction lenses set to a polarity opposite that of the ions to draw them into subsequent stages of the MS instrument. Modern mass spectrometers have all of the components under computer control, with a computer-based data acquisition and processing system. A block diagram of a typical mass spectrometer is shown in Figure 9.4.

A BRIEF DIGRESSION ON UNITS OF MEASURE—VACUUM SYSTEMS

In this book, we express vacuum in units of torr (named after the Italian physicist Evangelista Torricelli). This unit is not part of the SI system, nevertheless it is still widely used in discussion of mass spectrometry and in the presentation of measurements. It is approximately one millimeter of mercury in a mercury manometer operated at 0°C. It is converted to the SI unit, the Pascal, using the factors below:

torr	Pa	mbar	micron	psi	mmHg (0 °C)
1	133.322	1.33322	1000	0.0193368	0. 99999984

The unit micron can be found in the vacuum industry and its derived from the unit torr, where one milliTorr is equal to one micron. A complete list of conversion factors can be found in the book by Bruno and Svoronos.




FIGURE 9.4 Block diagram of a mass spectrometer.

9.2.1 SAMPLE INPUT SYSTEMS

9.2.1.1 GAS EXPANSION

This method of sample introduction is useful for gases and for liquids with sufficiently high vapor pressures. The gas or vapor is allowed to expand into an evacuated, heated vessel. The sample is then "leaked" into the ionization source through pin holes in a gold foil seal. This is sometimes termed a "**molecular leak" inlet**. Vacuum pumps control the system so that the pressure in the ionization source is at the required $10^{-6} - 10^{-8}$ torr.


9.2.1.2 DIRECT INSERTION AND DIRECT EXPOSURE PROBES

A **direct insertion probe** is used for introduction of liquids with high boiling points and solids with sufficiently high vapor pressure. The sample is put into a glass capillary that fits into the tip of the probe shown in Figure 9.5. The probe is inserted into the ionization source of the mass spectrometer and is heated electrically, vaporizing sample into the electron beam where ionization occurs. Direct insertion probes can be retrofitted onto existing mass spectrometers that are made for other sample introduction methods. A problem with this type of sample introduction is that the mass spectrometer can be contaminated because a relatively large sample is introduced in a quartz crucible and heated directly.

A **direct exposure probe** usually has a rounded glass tip. The sample is dissolved in solvent, a drop of the solution is placed on the end of the probe and the solvent is allowed to evaporate. A thin film of sample is left on the glass tip. The tip is inserted into the ion source and heated in the same manner as the direct insertion probe. Much less sample is introduced into the ion source and the spectrometer is less likely to be contaminated as a result.

9.2.1.3 CHROMATOGRAPHY AND ELECTROPHORESIS SYSTEMS

The appropriate chromatographic instrument can separate mixtures of gases and liquids and the separated components are then introduced sequentially into a mass spectrometer for detection. Mass spectrometrists consider the chromatograph to be a "sample inlet" for their spectrometers, while chromatographers consider the mass spectrometer to be "a detector" for their chromatographs. Indeed these hyphenated (or coupled) chromatography-mass spectrometry systems are extremely powerful analytical techniques, much more powerful than either instrument alone. The major problem to be overcome in coupling these two types of instruments is that the chromatography systems run at atmospheric pressure with



The sample is placed into the cavity or quartz insert (called a crucible) in the tip of the probe. When not in use, the cutoff valve is closed and gas samples can be introduced by opening the stopcock shown. The black dot at the center of the square shows the point at which the electron beam impacts the sample. (From Ewing, used with permission.)

large amounts of "carrier gas" or solvent. The mass spectrometer operates at very low pressures as noted above. The carrier gas or solvent must be removed without losing the analyte, before the analyte can be introduced into the evacuated ionization source or analyzer regions. Alternatively, one may use an ionization source which can ionize the target analytes under the conditions of higher pressure produced by the accompanying carrier fluid, and then selectively extract the ions into a lower-pressure region while diverting and discarding the vast majority of that vaporized fluid. Interfaces for these systems have been developed and are described in the chapters on the individual chromatographic techniques.

GC coupled with MS is known as GC-MS. It is a well-established method for separating gases or volatile compounds; the mass spectrum of each component in a mixture can be obtained and the components measured quantitatively. The interfacing, operation, and applications of GC-MS are discussed in Chapter 11.

Several types of LC and one non-chromatographic separation system for liquids have been interfaced with MS. HPLC is widely used to separate nonvolatile organic compounds of all polarities and molecular weights. Coupled to a mass spectrometer, the technique is called LC-MS. Supercritical fluid chromatography (SFC) and the non-chromatographic separation technique of capillary electrophoresis (CE) are also used with mass spectrometric detection. The interfacing, ionization sources, operation, and applications of these hyphenated methods are covered in Chapter 12.

9.2.2 IONIZATION SOURCES

9.2.2.1 ELECTRON IONIZATION (EI)

The EI source is a commonly used source for organic MS. Electrons are emitted from a heated tungsten or other metal filament. The electrons are accelerated by a potential of 50-100 V toward the anode (Figure 9.6). A standard value of 70 V is often used to produce comparable fragmentation patterns. Modern EI sources have a small permanent magnet which produces a field aligned with the electron beam. This causes the electrons to follow a spiral path, increasing the number of target atoms or molecules encountered. Still only 1 in 10^5 or 10^6 of them are ionized. As shown in this figure, the paths of the electrons and sample molecules meet at right angles. Ionization of the sample molecules and fragmentation into smaller ions




FIGURE 9.6 Cross-section of an El source. The filament and anode define the electron beam. The ions are formed in the space above the two repellers (the solid color blocks). A positive charge on the repellers together with a negative potential on the focus electrodes cause positive ions to be accelerated upward in the diagram, into the mass analyzer. (Modified from Ewing, used with permission.)

occur as a result of interaction with the high-energy electrons. Ions are accelerated out of the center of the source into the mass analyzer by an accelerating voltage of about 10⁴ V.

The EI source forms both positive and negative ions, so it can be used as a source for negative ion MS. Negative ions form from molecules containing acid groups or electronegative atoms. The high energy imparted to the ions by the EI source causes significant fragmentation of organic molecules. This type of high-energy ionization source is referred to as a *hard* ionization source. The fragmentation of the molecular ion into smaller ions is very useful in deducing the structure of a molecule. However, EI fragmentation can be so significant for some types of molecules that either no molecular ions remain, or they are so few that they cannot be reliably distinguished from background contamination. This means that the molecular mass of the compound cannot be determined from the spectrum. This is a critical loss of information, as deduction of the structure of an unknown compound is greatly facilitated by knowing its molecular mass, and this provides the starting point for assigning the mass losses to fragment ions formed.

Collisions between ions and molecules in the source can result in the formation of ions with higher m/z values than the molecular ion. A common ion-molecule reaction is that between a proton, H⁺, and an analyte molecule, M, to give a protonated molecule, MH⁺ or $(M + H)^+$. Such a species has a +1 charge and a mass that is 1 u greater than that of the molecule and is called a proton **adduct**, often represented as (M + 1). In LC-MS experiments, sodium salts from the LC buffer solution often produce a mass (M + 23) Na-adduct ion. One reason for keeping the sample pressure low in the EI ionization source is to prevent reactions between ions and molecules that would complicate interpretation of the mass spectrum.

The electron ionization source used to be called the electron impact source and the term EI meant electron impact ionization. The use of the term *impact* is now considered archaic. Ionization and fragmentation are more often induced by the close passage of the energetic electron and the consequent large fluctuation in the electric field as opposed to a physical direct "impact", and an energetic electron may well perform this function multiple times on different molecules. As the student will note throughout the chapter, MS terminology has changed in recent years as a result of agreements by professional scientific organizations to standardize definitions and usage of terms to avoid confusion. Not all organizations have agreed to the same terms and definitions. The recommendations from Sparkman (see the bibliography) have been followed, but even current literature will be found that uses "archaic" terminology. The old or alternate terms will be provided when necessary.

9.2.2.2 CHEMICAL IONIZATION (CI)

A chemical ionization (CI) source is considered a *soft* ionization source; it results in less fragmentation of analyte molecules and a simpler mass spectrum than that resulting from EI. Most importantly, the molecular ion is much more abundant using CI, allowing the determination of the molecular weight. Since proton adduct ions (M+1)⁺ form more easily in CI-MS, one needs to exercise care in assigning the molecular ion mass (M⁺). If the CI process is "soft" enough, the spectrum may consist almost entirely of only the molecular ion or an adduct ion. Such a lack of fragmentation provides less structural information than an EI spectrum. Concentration of the charge on mostly this one ion in CI-MS improves the sensitivity of detection when the method of selected ion monitoring (SIM) is employed for quantitative measurements in GC-MS (Chapter 11, Section 11.8.1). If a fragmented EI spectrum is absent of a molecular ion, then combining data from a CI spectrum containing a strong molecular ion will greatly assist interpretation of an unknown compound's spectra. The two modes complement one another for identification and quantitation of unknowns.

In CI, a large excess of **reagent gas** such as methane, isobutane, or ammonia is introduced into the ionization region. The pressure in the ion source is typically several orders of magnitude higher than in EI ion sources. A CI source design will be more enclosed with smaller orifices for the source vacuum pump to remove the reagent gas, allowing the higher source pressure to be maintained. The mixture of reagent gas and sample is subjected to electron bombardment. The reagent gas is generally present at a level 1000-10,000× higher than the sample; therefore, the reagent gas is most likely to be ionized by interaction with

the electrons. Ionization of the sample molecules occurs indirectly by collision with ionized reagent gas molecules and proton or hydride transfer. A series of reactions occurs. Methane, for example, forms $CH_4^{+\bullet}$ and $CH_3^{+\bullet}$ on interaction with the electron beam. These ions then react with additional methane molecules to form ions as shown:

$$CH_4^{+\bullet} + CH_4 \rightarrow CH_5^{+} + CH_3^{\bullet}$$

$$CH_3^+ + CH_4 \rightarrow C_2H_5^+ + H_2$$

Collisions between the ionic species CH_5^+ or $C_2H_5^+$ and a sample molecule M causes ionization of the sample molecule by proton transfer from the ionized reagent gas species to form MH^+ or by hydride (H^-) transfer from the sample molecule to form $(M-H)^+$, also written as $(M-1)^+$:

$$\begin{split} M + CH_5^+ &\to MH^+ + CH_4 \\ M + C_2H_5^+ &\to MH^+ + C_2H_4 \\ M + C_2H_5^+ &\to (M-H)^+ + C_2H_6 \\ M + CH_5^+ &\to (M-H)^+ + CH_4 + H_2 \end{split}$$

Hydride transfer from M occurs mainly when the analyte molecule is a saturated hydrocarbon. In addition, the ionized reagent gas can react with M to form, for example, an $(M + C_2H_5)^+$ ion with m/z = (M+29). The presence of such an *adduct* ion of mass 29 Da above a candidate molecular ion in a methane CI mass spectrum is a good confirmation of the identity of the molecular ion.

Many commercial sources are designed to switch from EI to CI rapidly to take advantage of the complementary information obtained from each technique. The main advantage of CI is that fragmentation of the sample molecule is greatly reduced and significant peaks at m/z = (M+1) or (M-1) are seen, permitting the identification of the molecular weight of the analyte.

It is possible to introduce a sample directly into the chemical ionization source on a tungsten or rhenium wire. A drop of sample in solution is applied to the wire, the solvent is allowed to evaporate, and the sample inserted into the CI source. The sample molecules are desorbed by passing a current through the wire, causing it to heat. The analyte molecules then ionize by interaction with the reagent gas ions as has been described. This technique is called **desorption chemical ionization** and is used for nonvolatile compounds.

9.2.2.3 ATMOSPHERIC PRESSURE IONIZATION (API) SOURCES

There are two major types of ionization sources that operate at atmospheric pressure, electrospray ionization (ESI) and atmospheric pressure chemical ionization (APCI). A modified version of the ESI source is the ion spray source. These sources are described in detail in Chapter 12, Section 12.1.6.1, because they are used to interface LC with MS for the separation and mass spectrometric analysis of mixtures of nonvolatile high molecular weight compounds, especially in the fields of pharmaceutical chemistry, biochemistry, and clinical biomonitoring. ESI will be described briefly so that its use may be demonstrated but more detail will be found in Chapter 12.

When a strong electric field is applied to a liquid passing through a metal capillary, the liquid becomes dispersed into a fine spray of positively or negatively charged droplets, an electrospray. The electric field is created by applying a potential difference of 3-8 kV between the metal capillary and a counter electrode. The highly charged droplets shrink as the solvent evaporates until the droplets undergo a series of "explosions" due to increasing coulombic repulsion of the electrons as their droplet surface density increases. Each "explosion" forms smaller and smaller droplets. When the droplets become small enough, the analyte ions




FIGURE 9.7 Schematic diagram of an ESI source. This source is shown with a lens system and skimmers to focus the ions and heated nitrogen gas to de-solvate the ions.

desorb from the droplets and enter the mass analyzer. A schematic *ESI source* is shown in Figure 9.7. The ESI source is at atmospheric pressure. The droplets and finally the analyte ions pass through a series of orifices and skimmers. These serve to divert and exclude unevaporated droplets and excess vaporized solvent from the higher vacuum regions where analyte ions are accelerated and analyzed by m/z. A flow of gas such as nitrogen or argon serves to desolvate the droplets and to break up ion clusters. The skimmers act as velocity filters. Heavier ions have less velocity from random thermal motions, transverse to the direction of voltage acceleration through the orifices than lighter ions and continue in a straight path to the mass analyzer; while the lighter ions (and solvent vapors and gases) are pumped away, permitting the pressure to be reduced without affecting the ion input to the mass analyzer. Liquid flow through the metal capillary is in the range of 1-10 μ L/min for the standard ESI design. For the increasingly important HPLC-MS instrumentation used in analysis of biomolecules, orthogonal spray ESI interfaces operate at 1 mL/min, and by addition of jets of heated gas such as N_2 to increase droplet evaporation rates, they can handle flow of up to 4-8 mL/min from monolithic HPLC columns.

The advantage of ESI lies in the fact that large molecules, especially biomolecules like proteins, end up as a series of multiply charged ions, M^{n+} or $(M+nH)^{n+}$ with little or no fragmentation. For example, a given analyte M might form ions of M^{9+} , M^{10+} , M^{11+} , and so on. If the mass of the analyte M is 14,300 Da, then peaks would appear in the mass spectrum of this analyte at m/z values of (14,300/9) = 1588.9, (14,300/10) = 1430.0, and (14,300/11) = 1300.0. These ions are at much lower m/z values than would be the case if we had a singly charged M^+ ion at m/z 14300. One advantage of having multiply charged ions with low m/z values is that less-expensive mass analyzers with limited mass range can be used to separate them. Another is that high m/z ions such as high MW biomolecules with only a single charge leave a CI source with low velocities; these low velocities result in poor resolution due to dispersion and other processes in the mass spectrometer. Ions with low m/z values due to high charge are easily resolved.

Examples of mass spectra of biological molecules obtained with ESI are shown in Figures 9.8 and 9.9. In reality, the analyst does not know the numerical charge on the peaks in the mass spectrum, but the successive peaks often vary by 1 charge unit. Computer-based algorithms have been developed for deconvoluting the sequence of m/z values of the multiply charged ions into the equivalent mass of single charged ions; such a deconvolution has been done in Figure 9.8. This permits identification of the molecular weight of the analyte. Applications of LC-ESI-MS are described in Chapter 12, Section 12.1.6.1. Dr. John Fenn, one of the inventors of ESI, received the Nobel Prize in Chemistry in 2002.




FIGURE 9.8 ESI mass spectrum **(a)** and deconvoluted mass spectrum **(b)** of carbonic anhydrase. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

Direct Analysis in Real Time (The DART source). This source was originally developed by JEOL (Japan Electron Optics Laboratory—a major MS vendor) and is now owned by Ion Sense. This ion production process reacts electronically excited atoms or vibrationally excited molecules to form energetic metastable species, M*. When M* collides with a sample, energy is transferred to the analyte molecule A, causing it to lose an electron and become a radical cation A+. This process is called Penning Ionization. In Figure 9.10 for the DART source, a gas stream of N_2 or Ne carries the ions thus formed to the inlet cone of an ambient pressure MS source. When He is used as a carrier, a different ionization process occurs. Helium first collides at atmospheric pressure with H₂O to form H₂O+, which undergoes several more transformations to become a protonated water cluster. This cluster eventually transfers the proton to the analyte molecule to produce MH+. The excitation in either case is due to an applied potential of +1 to +5 kV, which generates the ionized gas or metastable species. A potential of 100 V on an electrode lens removes other charged particles from the gas stream, which permits only excited species to continue on. The excited species can react with solid, liquid, or gas samples to desorb and ionize the analytes. After entry into the ambient pressure sampling cone of the MS inlet, ions in the gas stream are pulled out at an angle by a charged lens into the MS analyzer stage inlet, while the obliquely directed gas stream containing neutral contaminants, is directed to a trapping region and pumped away. This helps greatly to keep the ion optics free from the major contaminants of the outside world. DART spectra are simple, mainly protonated MH $^+$ in positive ion mode or [M – H] $^-$, and even sometimes just M⁺ for some polynuclear aromatic hydrocarbons (PAHs). Multiply charged or alkali metal cation adducts are never observed, although ammonia and chloride may form $[M + NH_4]^+$ or $[M + CI]^-$ adducts. The DART source's strength is in the simplicity of its operation: the sample is presented to the source entrance as one might bring something to one's

nose to sniff, and M+, MH+ or $[M-H]^-$ ions are picked up for everything present above the detection limits. Use of a high-resolution MS with a library of likely vapors to be found for the environment being tested can provide almost instant identification, hence the designation DART = *Direct Analysis* in *Real Time*. The source can "sniff" a variety of simple sample collection media, e.g., wipe papers or cloths, TLC plate spots, even "stains"—just present them to the input and stand back (figuratively). A tale told by the DART developers was that an employee walked into the lab after passing a construction site where blasting was underway, and on a whim waved his necktie in front of the sampling orifice; the MS immediately reported a nitrate explosive MS signature.

9.2.2.4 DESORPTION IONIZATION

Large molecules, such as proteins and polymers, do not have the thermal stability to vaporize without decomposing. Desorption ionization sources permit the direct ionization of solids, facilitating the analysis of large molecules. There are several types of desorption sources in which solid samples are adsorbed or placed on a support and then ionized by bombardment with ions or photons. Desorption CI, one form of desorption ionization, has already been described. The important technique of **secondary ion mass spectrometry (SIMS)** is used for surface analysis as well as characterization of large molecules; SIMS is covered in detail in Chapter 13, Section 13.4. Several other important desorption sources are described subsequently.

Laser Desorption and Matrix-Assisted Laser Desorption Ionization (MALDI). The use of a pulsed laser focused on a solid sample surface is an efficient method of ablating material from the surface and ionizing the material simultaneously. A variety of lasers have been used; examples include IR lasers such as the CO_2 laser (λ = 10.6 μ m) and UV lasers such as Nd:YAG (λ = 266 nm, 355 nm). YAG stands for yttrium aluminum garnet. Selective ionization is possible by choosing the appropriate laser wavelength. The laser can be focused to a small spot, from submicron to several microns in diameter. This permits the investigation of inclusions and multiple phases in solids as well as bulk analysis. The laser pulses generate transient signals, so a simultaneous detection system or a time-of-flight mass analyzer or a Fourier Transform (FT) mass spectrometer is required. The laser provides large amounts of energy to the sample. This energy must be quickly dispersed within the molecule without fragmenting the molecule. Until the development of matrix-assisted laser desorption, the use of a laser resulted in fragmentation of biological molecules with molecular masses above about 1000 Da.

By mixing large analyte molecules with a "matrix" of small organic molecules, a laser can be used to desorb and ionize analyte molecules with molecular weights well over 100,000 Da with little fragmentation. The function of the matrix is to disperse the large amounts of energy absorbed from the laser, thereby minimizing fragmentation of the analyte molecule. This technique of "matrix-assisted" laser desorption ionization (MALDI) has revolutionized the mass spectrometric study of polymers and large biological molecules such as peptides, proteins, and oligosaccharides. The actual process by which ions are formed using the MALDI approach is still not completely understood.

Typical matrices and optimum laser wavelengths are shown in Table 9.3. A matrix is chosen that absorbs the laser radiation but at a wavelength at which the analyte absorbs moderately or not at all. This diminishes the likelihood of fragmenting the analyte molecule.

TABLE 9.3 MALDI Experimental Conditions				
Matrix Wavelength				
Nicotinic acid		266 nm	2.94 μm	10.6 μ m
2,5-Dihydroxybenzoic acid		266 nm	337 nm	355 nm
		$2.8\mu m$	10.6 µm	
Succinic acid		2.94 µm	10.6 µm	
Glycerol (liquid)		$2.79\mu m$	2.94 μm	10.6 µ m
Urea (solid)		2.79 µ m	2.94 u m	10.6 u m




FIGURE 9.11 The MALDI process. Isolated analyte molecules are desorbed from a bed of matrix molecules by laser irradiation of the matrix. Subsequent de-solvation and ionization of the analyte molecule occur by processes that are not completely understood.

A typical sample is prepared for MALDI by mixing 1-2 μ L of sample solution with 5-10 μ L of matrix solution. A drop (<2 μ L) of the mixture is placed on the MALDI probe and allowed to dry at room temperature. The solvent evaporates and the now crystallized solid is placed into the mass spectrometer. The analyte molecules are completely separated from each other by the matrix, as shown in Figure 9.11.

The matrix material must absorb strongly at the wavelength of the laser used for irradiation. In addition, the matrix must be stable in a vacuum and must not react chemically. Matrix compounds used for MALDI include 2, 5-dihydroxybenzoic acid, 3-hydroxypicolinic acid, and 5-chlorosalicylic acid for the UV region of the spectrum and carboxylic acids, alcohols, and urea for the IR region of the spectrum. Intense pulses of laser radiation are aimed at the solid on the probe. The laser radiation is absorbed by the matrix molecules and causes rapid heating of the matrix. The heating causes desorption of entire analyte molecules along with the matrix molecules. De-solvation and ionization of the analyte occurs; several processes have been suggested for the ionization, such as ion-molecule reactions but the MALDI ionization process is not completely understood. A useful if simplistic analogy is to think of the matrix as a mattress and the analyte molecules as china plates sitting on the mattress. The laser pulses are like an energetic person jumping up and down on the mattress. Eventually, the oscillations of the mattress will cause the china to bounce up into the air without breaking. The plates (i.e., molecules) are then whisked into the mass analyzer intact.

MALDI acts as a soft ionization source and generally produces singly charged molecular ions from even very large polymers and biomolecules, although a few multiple-charge ions and some fragment ions and cluster ions may occur (Figure 9.12).

Fast Atom Bombardment. Fast atom bombardment (FAB) uses a beam of fast-moving neutral inert gas atoms to ionize large molecules. In this technique, the sample is dissolved in an inert, nonvolatile solvent such as glycerol and spread in a thin layer on a metal probe. The probe is inserted into the mass spectrometer through a vacuum interlock. The beam of fast atoms is directed at the probe surface (the target). Argon is commonly used as the bombarding atom, although xenon is more effective but more expensive.

Argon ions are produced in a heated filament ion source or gun, just as in SIMS (Chapter 13). The ions are accelerated through a cloud of argon atoms under an electrostatic field of 3-8 kV toward




FIGURE 9.12 The MALDI mass spectrum of a mouse monoclonal antibody. The matrix used was nicotinic acid; The laser radiation used was 266 nm. (Karas, M.; Bahr, U. *Trends anal. Chem.* **1990**, *9*, 323. Reprinted with permission from Elsevier.)

the target. The fast-moving ions exchange their charge with slow-moving argon atoms, but lose no kinetic energy in the process. This results in a beam of fast-moving argon atoms and slow-moving argon ions. The latter are repelled and excluded from the system using a negatively charged deflection plate. The fast-moving atoms now strike the target, liberating molecular ions of the sample from the solvent matrix. The process may again be visualized using the analogy of china dishes atop a mattress. Instead of responding to repetitive laser pulses, the matrix (mattress) absorbs, moderates, and transfers impact energy from the heavy fast atoms to the analyte molecules (dishes). If the analytes have surfactant character, they will preferentially concentrate at the liquid matrix surface, in a location optimal for being lofted into the vapor state. Positively charged $(M + H)^+$ or negatively charged $(M - H)^-$ ions may be produced, so positive ion or negative ion mass spectra may be collected. The process is shown schematically in Figure 9.13.

There are several advantages to the FAB technique. The instrumentation is simple and the sensitivity is high. Analytes such as surfactants have been measured quantitatively at concentrations as low as 0.1 ppb. It is difficult to get very large molecules into the gas phase because of their low volatility, and it is difficult to ionize large molecules and retain the molecular ion




FIGURE 9.13 Schematic FAB ionization source. The sample, dissolved in solvent, is spread on a thin film on the end of a metal probe and bombarded by fast-moving argon atoms. Both positive and negative ions are produced.




FIGURE 9.14 Schematic of continuous flow FAB-MS operated in the flow-injection mode.

in many ionization sources. The FAB process works at room temperature; volatilization is not required, so large molecules and thermally unstable molecules can be studied. The duration of the signal from the sample is continuous and very stable over a long period.

Sample fragmentation is greatly reduced in the FAB process, resulting in a large molecular ion, even with somewhat unstable molecules. This provides information on the molecular weight of the molecule, which is particularly important in biological samples such as proteins. Spectra from molecules with molecular weights greater than 10,000 have been obtained. Although a strong molecular ion is obtained with FAB, fragmentation patterns are also obtained, providing structural information on biologically important molecules such as proteins.

An important advantage of FAB is that only those analyte molecules, sputtered from the glycerol are lost; the remainder can be recovered for other analyses. Samples as small as 1 μ g can be placed on the probe, and after the mass spectrum is obtained, a significant amount of the sample can be recovered.

A modification of the FAB technique is **continuous-flow FAB (CFFAB)**. In this approach, the sample in solution is introduced into the mass spectrometer through a fused silica capillary. The tip of the capillary is the target. The solution is bombarded by fast atoms produced as described earlier. Solvent is flowing continuously and the liquid sample is introduced by continuous flow injection (Figure 9.14). The mass spectrum produced has the same characteristics as that from conventional FAB, but with low background. Typically, the solvent used is 95 % water and 5 % glycerol. The ability to inject aqueous samples is an enormous advantage in biological and environmental studies. Very frequently, these types of samples are aqueous in nature, such as blood, urine, and other body fluids, water, and wastewater.

The sensitivity at the lower molecular weight range (1500 Da) is increased by two orders of magnitude over conventional FAB. Further, the background is reduced because of the reduced amount of glycerol present. In addition, when the solvent alone is injected, a background signal can be recorded. This can be subtracted from the signal due to sample plus solvent, and the net signal of the sample is obtained. This is especially valuable for trace analysis; amounts as low as 10^{-12} g have been detected using CFFAB.

The CFFAB system can be incorporated into LC-MS systems (Chapter 12). The mobile phase is the solvent used. The effluent from the LC is transported directly into the mass spectrometer and the MS obtained by CFFAB. This provides a mass spectrum of each separated peak in mixtures.

FAB and CFFAB have greatly increased the potential of mass spectrometry by increasing the molecular weight range of molecules whose molecular ion can be determined. The system can be directly attached to LC, permitting identification of the components of a solution. Also, trace analysis is possible. The method can be applied to the important research areas of the health sciences, biology, and environmental science, as well as to chemistry.

Desorption Electrospray Ionization (DESI) Source. While ESI, APCI, FAB, etc. operate from flowing chromatographic effluents or dipped point sources, other techniques introduce ions from 2-D planar surfaces such as tissue thin sections or TLC plates (Chapter 12, section 12.7.1). DESI combines electrospray (ESI) and desorption ionization (DI). Under ambient




FIGURE 9.15 Prosolia DESI omni spray ion source geometry and operation diagram. The family of different (manual, 1D and 2D) ion sources can be used on MS equipment from Agilent, Thermo, Waters, ABSciex, Bruker, and LECO. (Used with permission from Prosolia, inc., www.prosolia.com.)

atmospheric conditions an electrically charged cloud of droplets is directed at a small spot on a sample surface only a few mm distant. This charged mist is pulled to the surface by a voltage of opposite polarity applied to it. The droplet charge is transferred to analytes on the surface, and the resultant ions travel into an atmospheric pressure interface similar to that in APCI or ESI. For high MW targets such as large protein molecules, multiple charges can be transferred with the subsequent behavior of the droplets essentially the same, as the series of coulomb explosions and desolvation steps seen in ESI. By contrast, for low MW analytes the ionization occurs by charge transfer of either an electron or a proton (thus yielding MH⁺ ions, but not adducts such as [M + Na]⁺), similar to the APCI or DART ionization mechanisms. The geometry of the DESI source is illustrated in Figure 9.15. The key features are the two angles: α and β , d (distance from tip to surface), and the unmarked distance (surface to center of MS inlet). Optimal conditions for high MW analytes are high $\alpha = 70-90^{\circ}$, and short d = 1-3 mm. For low MW analytes, conditions are reversed: $\alpha = 35-50^{\circ}$ and d = 7-10 mm. This is consistent with and predicted for the two different ionization mechanisms described above. The spray emitter and the sample surface holder are each attached to a 3-D stage which moves with 3 orthogonal degrees of freedom, which allows variation of all 4 of those geometric parameters. One can take full-scan mass spectra from a raster of points, covering the whole 2-D surface to discover and identify all unknown molecules within the MS capability, or set the MS to map the distribution of a specific analyte or analytes, and process the data to be displayed as an image of their location(s). One of the authors (GMF) worked in drug metabolism at Pfizer Central Research in the 1980's, where the only practical way to image drug distribution patterns in tissue was to synthesize radiolabeled analogs of a drug in question, feed them to test animals which were then killed. Tissue slices were obtained from quick frozen (in liquid N_2) target organs and stored for weeks in a freezer, pressed against X-ray film, which was finally developed to produce images. These showed only the tissue location of the drug and/or perhaps some unknown metabolites retaining the radiolabel. This was achieved only with much time and at great expense. With automated 2-D DESI-MS, the imaging portion of such a study can now be completed in an hour or so using unlabeled drug, and with all the drug-related materials in the image yielding positive MS identification.

Laser Ablation Electrospray Ionization (LAESI). This method of ionization of samples from a surface and introduction for MS profiling is similar in some ways to DESI. An electrospray plume containing charged droplets is created over the sample surface, and a small

spot on this *water-containing or water-wetted* surface is hit with a short (5 ns) intense pulse from a mid-IR laser tuned to the 2.94 micron absorption line of water. Four steps then ensue:

- 1. A small hemispherical plume rises over the spot without ionization.
- 2. The plume collapses, ejecting a sample jet from the surface; still with little ionization.
- 3. The ESI spray plume hits the jet and transfers charge to molecules within it.
- 4. The ionized molecules (some from ESI droplet shrinkage), are swept into the MS for analysis.

Steps 1 and 2 are the laser ablation process and steps 3 and 4 are the ESI-MS analytical finish

The sample surface stage can be positioned and rastered in the x-y plane as in the DESI process to enable rapid production of an image, or to sample arrays of 96 or 384 microplate wells containing microliters of aqueous solutions. Each analysis from a laser shot is completed in two seconds, so throughput is high, and use of internal standards and calibration curves permits absolute quantitation of targeted molecules over a dynamic range of four orders of magnitude. LAESI has been used to image plants, tissues, cell pellets, even single cells, as well as historical documents, and untreated urine and blood spots. Analytes range from small molecules, saccharides, lipids and metabolites up to large biomolecules such as peptides and proteins of mass >100,000 Da. For single cell experiments and analyses, etched optical fibers are used to shrink the laser spot sizes to less than 50 μ m, giving a 4X improvement on the imaging resolution. LAESI is an immensely powerful technique.

9.2.2.5 IONIZATION SOURCES FOR INORGANIC MS

The following ionization sources are used mainly in inorganic (atomic) MS, where the elemental composition of the sample is desired. The glow discharge (GD) and spark sources are used for solid samples, while the inductively coupled plasma (ICP) is used for solutions. All three sources are also used as atomic emission spectroscopy sources; they are described in more detail with diagrams in Chapter 7.

GD Sources and Spark Sources. The GD source and spark source are both used for sputtering and ionizing species from the surface of solid samples (Chapter 7). As MS ionization sources, they are used primarily for atomic MS to determine the elements present in metals and other solid samples. The DC GD source has a cathode and anode in 0.1-10 torr of argon gas. The sample serves as the cathode. When a potential of several hundred volts is imposed across the electrodes, the argon gas ionizes forming a plasma. Electrons and positive argon ions are accelerated toward the oppositely charged electrodes. The argon ions impact the cathode surface, sputtering off atoms of the cathode material. The sample atoms are then ionized in the plasma by electrons or by collision with excited argon (Penning ionization). The sample ions are extracted from the plasma into the mass analyzer by a negatively charged electrode with a small aperture. The DC GD source is used for the analysis of conductive samples including metals, alloys, and semiconductors. The sample must be conductive to serve as the cathode. RF GD sources have been developed that enable the sputtering of electrically nonconductive samples such as ceramics and other insulators. Spark sources also can be used for sputtering of solids, but the GD source produces a more stable ion beam with better signal-to-noise ratio. The GD source sputters more material from a sample and gives more representative and more quantitative results of the elemental bulk composition than the spark source.

ICP Source. The argon ICP source has also been described in Chapter 7. This source is used primarily for liquids. Solid samples are generally dissolved in acid and diluted for analysis; organic solvents can also be used. The source produces ions from the elements introduced into the plasma as well as radiation; these ions can be extracted into a mass analyzer. The ICP torch is often mounted horizontally with the tip of the plasma at the entrance to the mass analyzer as shown in Figure 9.16. Most of the plasma gas is deflected by a metal cone with a small orifice in its center, called the sampling cone. The gas that enters through the orifice expands into an evacuated region. The central portion passes through another






FIGURE 9.16 (a) Argon ICP torch used as an ionization source for ICPMS. (From Ewing, used with permission.) (b) Photo of the plasma in a SPECTRO MS system (described in section 9.2.3). (Courtesy of SPECTRO analytical instruments, inc., AMETEK* materials analysis division [www.spectro.com, www.ametek.com]. Used with permission.)

metal cone, the skimmer cone, into the evacuated mass analyzer. Singly charged positive ions are formed from most elements, metallic and nonmetallic. The ICP has a high ionization efficiency, which approaches 100 % for most of the elements in the periodic table. The mass spectra are very simple and elements are easily identified from their m/z values and their observed isotope ratios. Background ions from the solvent and from the argon gas used to form the plasma are usually observed. Such ions include Ar^+ , ArH^+ , ArO^+ , and polyatomic ions from water and the mineral acids used to dissolve most samples.

9.2.3 MASS ANALYZERS

The mass analyzer is at the core of the mass spectrometer. Its function is to differentiate among ions according to their mass-to-charge ratio. There are a variety of mass analyzer designs. *Magnetic sector* mass analyzers employing narrow metal slits to isolate individual




FIGURE 9.18 Early mass spectrometer designs. **(a)** Aston, 1919; **(b)** Dempster, 1918; **(c)** Mattauch-Herzog, 1935; **(d)** Bainbridge, 1933. In each case, *B* signifies the magnetic field. Spectrometers **(c)** and **(d)** are dispersive mass spectrometers; **(c)** the Mattauch-Herzog design is also a double sector instrument, using an electric sector before the magnetic field. Modern versions of these spectrometers are still in use, with the photoplate replaced by one of the modern array detectors discussed subsequently.

However, ions in a radial electrostatic field also follow a circular trajectory. The electrostatic field is an *electric sector* and separates ions by kinetic energy, not by mass (Figure 9.19). The ion beam from the source can be made much more homogeneous with respect to velocities of the ions, if the beam is passed through an electric sector before being sent to the mass analyzer. The electric sector acts as an energy filter; only ions with a very narrow kinetic energy distribution will pass through.

Most magnetic sector instruments today combine both an electric sector (ESA) and a magnetic sector. Such instruments are called double-focusing mass spectrometers. One




FIGURE 9.19 A cylindrical electrostatic-sector energy filter. (From Ewing, used with permission.)




FIGURE 9.20 A Nier-Johnson double focusing mass spectrometer. (From Ewing, used with permission.)

common commercial double-focusing design is the Nier-Johnson design (Figure 9.20), introduced in 1953; the geometry involves $\pi/2$ radian deflection in the ESA and $\pi/3$ radian deflection in the magnetic sector. This design is also used with the ions travelling in the opposite direction in "reverse" Nier-Johnson geometry. A second common design using two sectors is the Mattauch-Herzog dispersive design, shown in Figures 9.18(c) and 9.23. This design uses $\pi/(4\sqrt{2})$ radian deflection in ESA followed by $\pi/2$ radian deflection in the magnetic sector.

Mass ranges for magnetic sector instruments are in the m/z 1-1400 range for single-focusing instruments and m/z 5000-10,000 for double-focusing instruments. Very high mass resolution, up to 100,000, is possible using double-focusing instruments.

Double-focusing sector field instruments of the Nier-Johnson and Mattauch-Herzog designs are used in ICP-MS instruments (ICP-sector field MS or ICP-SFMS, also referred to as high resolution ICP-MS or HR-ICP-MS) as well as in organic MS instruments. In atomic MS, the ICP-SFMS instruments offer high sensitivity, high resolution, very low noise and very low detection limits—on the order of $< 1 \times 10^{-15} \text{g/L}$ [that is, less than one femtogram/mL or less than one part per quadrillion (ppq)] for most elements. The Thermo Fisher Scientific Element XR, introduced in 2005 uses a reverse Nier-Johnson geometry with the magnetic sector first for directional focusing and then an electric sector for energy focusing of the ion beam (Figure 9.21). The instrument is a single ion collector and is available as an ICP-MS




FIGURE 9.21 Reverse Nier-Johnson geometry of the Thermo Scientific element MS with a GD source. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

or GDMS. The instrument has three mass resolution settings: low, m/ $\Delta m \approx 300$; medium, m/ $\Delta m \approx 3000$ and high, m/ $\Delta m \approx 10,000$. Medium resolution and high resolution can separate isobaric interferences of analyte ions from polyatomic ions. Examples include 80 Se⁺ from 40 Ar₂⁺ and 56 Fe⁺ from 40 Ar¹⁶O⁺. The Element is equipped with two detectors, a secondary electron multiplier, and a Faraday detector for a linear dynamic range of 12 orders of magnitude (Figure 9.22). This permits detection of sub-part-per-quadrillion to % concentrations. The detectors are described in Section 9.2.4.

In 2011, SPECTRO Instruments GmbH (www.spectro.com, www.ametek.com) introduced the first simultaneous ICP-MS, the SPECTRO MS, based on Mattauch-Herzog geometry and using a novel direct charge detector (Section 9.2.4) placed in the focal plane of the magnet occupying the location of the photoplate shown in Figure 9.18(c). The instrument consists of a novel ion optic (Figure 9.23(a) and a double-focusing Mattauch-Herzog spectrometer (Figure 9.23(b)) with an entrance slit (which defines resolution), a 31.5° electrostatic analyzer (ESA), a drift length with energy slit and a 90° magnetic field sector with the detector attached at the focal plane. The assembled instrument is shown in Figure 9.24.

The novel ion optic consists of a curved ESA (not to be confused with the ESA in the mass spectrometer), an Einzel lens, and a quadrupole doublet. The ESA separates ions of a defined [www.thermofisher.com]. kinetic energy, which have been extracted by a prefilter, from neutrals, particles and photons. Used with permission.)




FIGURE 9.22 The dual detectors on the Thermo Scientific element MS. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)




FIGURE 9.23 (a) The ion optic in the SPECTRO MS. lons of a defined kinetic energy are introduced into the curved ESA (top). An Einzel lens focuses the ions (middle) into a quadrupole doublet (bottom). (Courtesy of SPECTRO analytical instruments, inc., AMETEK* materials analysis division [www.spectro.com, www.ametek.com]. Used with permission.) **(b)** The Mattauch-Herzog geometry of the SPECTRO MS. (Courtesy of SPECTRO analytical instruments, inc., AMETEK* materials analysis division [www.spectro.com, www.ametek.com]. Used with permission.)



FIGURE 9.24 Cutaway view of the SPECTRO MS, showing the ICP torch box upper left, the ion optic to the right of the torch box, leading to the mass spectrometer on the left under the torch box. (Courtesy of SPECTRO analytical instruments, inc., AMETEK® materials analysis division [www.spectro.com, www.ametek.com]. Used with permission.)

The ions are focused by the Einzel lens into a quadrupole doublet, which changes the shape of the ion beam from round to rectangular to match the entrance slit of the mass spectrometer.

The ESA sector reduces the ion beam energy bandwidth to achieve high resolution m/z separation in the magnetic field. The Mattauch-Herzog geometry of the mass spectrometer focuses all of the ions, separated by m/z, onto the focal plane at the exit of the magnet using a fixed setting for the electrostatic analyzer and a permanent magnet. This enables the use of a flat surfaced array detector. No scanning is required, resulting in a fully simultaneous determination of all the elements (5-240 Da) and fully utilizing the continuous ion beam produced by the ICP. Because the entire spectrum is recorded at once, it is possible to go back and retrieve concentration data for any element in any sample at any time.

The major disadvantage of double focusing MS systems for elemental analysis is their high cost compared to quadrupole-based systems. Moreover, data file sizes can be very large.

9.2.3.2 TIME OF FLIGHT (TOF) ANALYZER

A TOF analyzer does not use an external force to separate ions of different m/z values. Instead, pulses of ions are accelerated into an evacuated field free region called a drift tube. If all ions have the same kinetic energy, then the velocity of an ion depends on its mass-to-charge ratio, or on its mass, if all ions have the same charge. Lighter ions will travel faster along the drift tube than heavier ions and are detected first. The process is shown schematically in Figure 9.21.

A schematic TOF mass spectrometer is shown in Figure 9.26. The drift tube in a TOF system is approximately 1-2 m in length. Pulses of ions are produced from the sample using




FIGURE 9.25 A pulse of ions of two different m/z values enters the field free drift tube of a TOF mass spectrometer at time one. The large white circles have m/z > than the small dark circles. As they travel down the tube, the lighter ions move faster, and by time three, have been separated from the heavier ions.




FIGURE 9.26 Schematic TOF mass spectrometer.

pulses of electrons, secondary ions, or laser pulses (e.g., MALDI). Ion pulses are produced with frequencies of 10-50~kHz. The ions are accelerated into the drift tube by a pulsed electric field, called the ion-extraction field, because it extracts (or draws out) ions into the field-free region. Accelerating voltages up to 30~kV and extraction pulse frequencies of 5-20~kHz are used.

Ions are separated in the drift tube according to their velocities. The velocity of an ion, ν , can be expressed as:

$$(9.10) v = \sqrt{\frac{2zV}{m}}$$

where V is the accelerating voltage. If L is the length of the field-free drift tube and t is the time from acceleration to detection of the ion (i.e., the flight time of the ion in the tube),

$$(9.11) v = \frac{L}{t}$$

and the equation that describes ion separation is:

$$\frac{m}{z} = \frac{2Vt^2}{L^2}$$

The flight time, *t*, of an ion is:

$$(9.13) t = L\sqrt{\frac{m}{2zV}}$$

Equation (9.13) can be used to calculate the difference in flight time between ions of two different masses. Actual time separations of adjacent masses can be as short as a few nanoseconds, with typical flight times in microseconds.

TOF instruments were first developed in the 1950s, but fell out of use because of the inherent low-resolution of the straight drift tube design (as in Figure 9.26). The drift tube length and flight time are fixed, so resolution depends on the accelerating pulse. Ion pulses must be kept short to avoid overlap of one pulse with the next, which would cause mass overlap and decrease resolution. Interest in TOF instruments resurfaced in the 1990s with the introduction of MALDI and rapid data acquisition methods. The simultaneous transmission of all ions and the rapid flight time means that the detector can capture the entire mass spectral range almost instantaneously.

The resolution of a TOF analyzer can be enhanced by the use of an ion mirror, called a **reflectron**. The reflectron is used to reverse the direction in which the ions are traveling and to energy-focus the ions to improve resolution. The reflectron's electrostatic field allows faster ions to penetrate more deeply than slower ions of the same m/z value. The faster ions follow a longer path before they are turned around, so that ions with the same m/z value but differing velocities end up traveling exactly the same distance and arrive at the detector together. The use of a curved field reflectron permits the focusing of ions over a broad mass range to collect an entire mass spectrum from a single laser shot. In a reflectron TOF, the ion source and the detector are at the same end of the spectrometer; the reflectron is at the opposite end from the ion source. The ions traverse the drift tube twice, moving from the ion source to the reflectron and then back to the detector. A schematic of a commercial reflectron TOF mass analyzer is shown in Figure 9.27.

The mass range of commercial TOF instruments is up to 10,000 Da. Resolution depends on the type of TOF and ranges from 1000 for instruments designed as dedicated detectors for GC (GC-TOFMS) to 20,000 for reflectron instruments. One limitation to the use of a conventional reflectron instrument is a loss in sensitivity; about 10 % of the ions are lost with a conventional wire grid reflectron.




FIGURE 9.27 A commercial reflectron TOF mass analyzer, the Pegasus III from LECO. The analyzer is shown with sample introduction from a GC. (Diagram courtesy of LECO Corporation [www.leco.com].)




FIGURE 9.28 Figure-8 ion trajectories in the JEOL SpiralTOF. (Used with permission from JEOL inc., www.jeol.com.)

JEOL Spiral TOF. The ion flight path length of a TOF instrument can be extended to increase resolution by bending the flight path into a series of figure-8's offset or staggered along an axis perpendicular the plane of the curved paths. Curved electrodes bend the paths of ion packets as illustrated in Figure 9.28 for multiple figure-8 stages. They are also focused back after every figure-8 stage before transfer to the next ones, until a total pathlength of 17 m is traversed without the packets diverging at the detection plane, thus achieving high mass accuracy (< 1ppm), resolution (> 60,000 FWHM), and high ion transmission. Several configurations are available: 1) MALDI-TOFMS; 2) a Linear TOF, where the ion packets bypass the spiral stages and proceed directly to a detector (for high MW analytes and ones undergoing post source decay); and 3) TOF/TOF, where a highly resolved and isolated ion from the ion packets from the 17 m spiral array separation is fragmented in a collision cell, and its fragment ions are passed on to a single reflectron 2nd TOF stage for further MS characterization. All this is compacted into a space not much larger than a student desk. In the MALDI-TOF/ TOF configuration, the long spiral path enables monoisotopic selection of precursor ions. The selected precursor ions undergo high energy fragmentation in the collision cell, and the second TOFMS incorporates a reacceleration mechanism and an offset parabolic reflection, which permits observation of product ions from very low m/z up to that of the precursor ion. The high resolution of the system simplifies interpretation of the product ion spectra, as both they and the selected precursor ion are both monoisotopic. The curved electric sectors in the spiral TOF 1st stage remove ions arising from post source decay, which are common in MALDI, yielding simpler product ion spectra characteristic only of the high-energy collision-induced-fragmentation.

LECO *Pegasus GC-HRT*** *and Citius LC-HRT***. These two new designs of TOFMS instruments employ multiple (20 to 40) gridless back and forth reflections of the ion packets to produce flight paths of 20 to 40 m with minimal reflection losses, achieving resolutions of 50,000 to 100,000, respectively. These exceed even the 17 m in the SpiralTOF above. Figure 9.29(a) depicts the multiple reflection stages and Figure 9.29(b) shows three selectable pathlength modes. The ultra-high-resolution mode can cover the m/z range of 300 to 1200, while the other two cover 50 to 2500. The instruments are therefore suited to high resolution MS characterization of "small molecules" and the scan rate of up to 200 full spectra/s makes them a good match for the narrow peaks from high-speed UHPLC separations or fast, short-capillary GC separations. Figure 9.30 shows how accurate mass measurements from a Pegasus GC-HRT mass spectrum with sub-ppm mass accuracy enabled assignment of the correct formula of $C_{24}H_{23}NO$ to the measured m/z of 341.17749, where that empirical formula was the only one fitting the constraints of the high-resolution mass fit table. This formula in




Figure 1. Illustration of Folded Flight Path technology.




Figure 2. Depiction of the Pegasus GC-HRT's three modes of operation.

FIGURE 9.29 LECO multi-reflectron TOF-MS: **(a)** Diagram of mass analyzer assembly; **(b)** selection of three different TOF pathlengths to give three increasingly higher resolutions. (Materials used with permission from LECO Corporation [www.leco.com].)




FIGURE 9.30 High-resolution TOF mass spectrum of cannabinomimetic unknown obtained with LECO Pegasus GC-HRT. (Material used with permission from LECO Corporation [www.leco.com].)




FIGURE 9.31 (a) Transmission quadrupole mass spectrometer. Rods A and B are tied together electrically, as are rods C and D. The two pairs of rods, AB and CD, are connected both to a source of direct potential and a variable RF excitation such that the RF voltages are 180° out of phase. (b) The geometry of the rods. (c) Sequential detection of elements by peak hopping (ICP-MS).

where $V_{\rm DC}$ is the voltage of the DC signal; $V_{\rm RF}$, the amplitude of the voltage of the RF field; f, the frequency of oscillation of the RF field (rad/s); r, half the distance between the inner edges of opposing poles such as A and B as shown in Figure 9.31(b); and t, the time.

The motion is complex because the velocity in the *x* direction is a function of the position along y and vice versa. In order for an ion to pass through the space between the four rods, every time a positive ion is attracted to a negatively charged rod, the AC electric field must be present to push it away; otherwise, it will collide with the rod and be lost. The coordination between the oscillating (AC) field and the time of the ion's arrival at a rod surface over the fixed distance between the rods is critical to an ion's movement through the quadrupole. As a result of being alternately attracted and repelled by the rods, the ions follow an oscillating or "corkscrew" path through the quadrupole to the detector. For a given amplitude of a fixed ratio of DC to RF at a fixed frequency, only ions of a given m/z value will pass through the quadrupole. If the mass-to-charge ratio of the ion and the frequency of oscillation fit Equations 9.14 and 9.15, the ion will oscillate toward the detector and eventually reach it. If the m/z value and the frequency do not meet the conditions required, these ions will oscillate with an increasingly wide path until they collide with the rods or are pulled out by the vacuum system. In any case, the ions will not progress to the detector. Only a single m/z value can pass through the quadrupole at a given set of conditions. In this respect, the quadrupole acts like a filter, and is often called a mass filter. One m/z value is filtered from the ion beam and passed to the detector; the ions (elements in the case of ICP-MS) are measured sequentially by "peak hopping" as shown in Figure 9.31(c).

The separation of ions of different m/z can be achieved by several methods. The frequency of oscillation of the RF field can be held constant, while varying the potentials of the DC and

RF fields in such a manner that their ratio is kept constant. It can be shown mathematically that the best resolution is obtained when the ratio $V_{\rm DC}/V_{\rm RF}$ is equal to 0.168. If the ratio is greater than this number, a stable path cannot be achieved for any mass number; if the ratio is lower than this number, resolution is progressively lost.

The resolution of the system is dependent on the number of oscillations an ion undergoes in the drift chamber. Increasing the rod lengths; therefore, increases resolution and extends the use of the system to higher molecular weight compounds. Increasing the frequency of the RF field can bring about this same improvement. The rod diameter is also important. If the diameter is increased, the sensitivity is greatly increased, but then the mass range of the system is decreased. The manufacturer must come to a compromise with these factors when designing an instrument for analytical use. The resolution achievable with the quadrupole mass spectrometer is approximately 1000; the m/z range for a quadrupole mass analyzer is 1-1000 Da. As with other mass spectrometers, the sample must be available in the gas phase and must be ionized.

Quadrupole mass analyzers are found in most commercial ICP-MS instruments, in most GC-MS instruments (Chapter 11) and in many LC-MS instruments (Chapter 12). Quadrupoles or higher number multipole rod arrays are also used in both organic and inorganic MS/MS systems as mass analyzers or collision cells, respectively. This use will be described in Section 9.2.3.4.

Although the quadrupole mass analyzer does not have the range or resolution of magnetic sector instruments, it is very fast. It can provide a complete mass spectrum in less than 100 ms. This property and its wide angle for acceptance of ions make it suitable for coupling to transient signal sources such as those from chromatography or laser ablation. In addition, the quadrupole mass analyzer is inexpensive, compact, and rugged. Most ICP-MS, GC-MS, and LC-MS instruments with quadrupoles are small enough to fit on a benchtop. Figure 9.32 shows the cutaway view of the smallest benchtop ICP-MS. Quadrupoles are the most common mass analyzer in commercial use. The term **transmission quadrupole** mass spectrometer is sometimes used for this mass analyzer to avoid confusion with the **quadrupole ion trap** mass spectrometer discussed in Section 9.2.3.5.




FIGURE 9.32 Cutaway view of the single quadrupole 7700-series benchtop ICP-MS from Agilent Technologies. The hyperbolic quadrupole is shown between the reaction cell and the detector. The sample introduction system and ICP torch are on the left of the diagram. (© 2018 Agilent Technologies [www.agilent.com/chem]. All rights reserved. Used with permission.)

9.2.3.4 MS/MS AND MS^N INSTRUMENTS

Many analytical questions require the mass spectrometrists to obtain more information about the structure of fragment ions or about ion-molecule reactions than can be obtained from the initial ionization of an analyte. In such cases, the technique of MS/MS, also called tandem MS may be useful. MS/MS is a mass spectral technique that uses two (or more) stages of mass analysis combined with a process that causes a change in mass of the ion of interest, such as dissociation into lighter fragment ions by collision with an inert gas or conversion into a heavier ion by reaction with a neutral molecule. An ICP-MS/MS is now available (Figure 9.33(b)) and operates in a similar fashion.

The stages of mass analysis may be performed by two physically separate mass analyzers, such as two quadrupoles coupled in series on either side of a multipole collision cell; this type of arrangement for MS/MS is called "tandem in space". Figure 9.33(a) shows a quadrupole MS/MS instrument with three quadrupoles for "tandem in space" analysis. We reiterate again that the 2nd "quad" may actually have more than four rods. It serves to isolate and focus individual selected ions from the 1st quad, allows them to collide with a collision gas, and moves the secondary fragment ions to the 3rd quad analyzer stage. Such an arrangement is often referred to as a "triple quad" despite the different design and function of the 2nd stage. Alternatively, ion traps, discussed in Sections 9.2.3.5 and 9.2.3.6, may be used to perform MS/MS experiments within the same mass analyzer; this type of MS/MS experiment is called "tandem in time".

Using Figure 9.33(a), we will look at a simple MS/MS experiment. For example, an analyte may be ionized as usual by the ion source. One ion of a particular m/z value is of interest. This ion is called the **precursor** ion. The precursor ion is selected by the first quadrupole, which is operating as a mass analyzer, permitting only the precursor ion (plus any direct on-mass interferences) to pass into the second stage. The precursor ion enters the second stage. This second stage is the reaction region and acts as a collision cell and ion lens, not as a mass analyzer. An inert gas is usually added in this region to cause collision-induced fragmentation of the precursor ion into lighter product ions, or a reactive reagent gas may be introduced to form heavier product ions through ion-molecule reactions. The second stage also serves to confine and transfer the product ions; that is:

$$M_{precursor}^+ \rightarrow M_{product}^+$$

where the precursor *ion* and product *ions* have different m/z values. The product ions then undergo mass analysis as usual in the third quadrupole. This type of design, where the first and third quadrupoles are used for mass analysis and the center quadrupole is used for collision and focusing, is often abbreviated as a QqQ design, to indicate that there are only two stages of mass analysis symbolized by the capital Q. The schematic of the ICP-MS instrument in Figure 9.33(b) shows the same two quadrupole analyzers, separated in this case by an octopole collision/reaction cell; it is still called a triple quadrupole instrument (by the manufacturer) and is of the QqQ type.

If we had an instrument with three mass analyzers, the fragmentation process could be repeated before final analysis. A precursor ion is selected, fragmented, a given product ion is selected and fragmented again before mass analysis of its product ions; that is:

$$M_{\text{precursor}}^+ \to M_{\text{product }1}^+ \to M_{\text{product }2}^+$$

where all three ions have different m/z values. This is an example of MS/MS/MS or MS³; the number of steps can be increased to give an MSⁿ experiment. It is not practical to build "tandem in space" instruments with large numbers of mass analyzers; three or four is the upper limit. Commercial MS/MS instruments are limited to two mass analysis stages. Ion trap instruments are used for higher order experiments. In general, n = seven or eight is a practical upper limit in ion trap instruments.

Tandem mass spectrometers have been built with three quadrupoles as shown in Figure 9.33(a), with hexapole or octopole reaction/collision cells [Figure 9.33(b)] and with




FIGURE 9.33 (a) A commercial quadrupole tandem MS/MS instrument for organic MS. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.) **(b)** The 8800 ICP-QQQ with two hyperbolic quadrupoles separated by an octopole cell for ICP-MS/MS. (© 2020 Agilent technologies [www.agilent.com/chem]. All rights reserved. Used with permission.)

(b)

other combinations of sector and TOF mass analyzers. Electric and magnetic sector analyzers have been combined with quadrupoles and with TOF analyzers. Quads are often used as the first stage of mixed-mode tandem systems, where the second stage is a high-resolution system (e.g., a TOF or OrbitrapTM, see 9.2.3.7). The second stage resolution and performance could be degraded by the fields of extraneous ions, especially from high levels of non-analyte contamination (the space charge interference). The analyte M^+ or a characteristic fragment ion can be isolated from most of these and then transferred to the next stage (e.g., Q-TOF, Q-Trap).

9.2.3.5 QUADRUPOLE ION TRAP

An **ion trap** is a device where gaseous ions can be formed and/or stored for periods of time, confined by electric and/or magnetic fields. There are three commercial types of ion traps in use in MS, the *quadrupole ion trap* (QIT), the OrbitrapTM, which uses a spiral trajectory that oscillates along a 1-D linear axis and the *ion cyclotron resonance* trap (ICR).

The QIT mass spectrometer is also called a **Paul ion trap**, a **3-D ion trap** or more commonly, just an ion trap. This analyzer uses a quadrupole field to separate ions, so "quadrupole" is used in the name to distinguish this system from the OrbitrapTM and ICR traps discussed in the next section. The QIT is shown schematically in Figure 9.34. A ring-shaped electrode and two end cap electrodes, one above and one below the ring-shaped electrode, are used to form a 3-D field. A fixed frequency RF voltage is applied to the ring electrode, while the end caps are either grounded or under RF or DC voltages. Ions are stored in the trap by causing them to move in stable trajectories between the electrodes under the application of the field. This is done by varying the potentials, so that just before an ion collides with an electrode, the potential changes sign and repels the ion. Ions with a very broad range of m/z values can be stored simultaneously in the ion trap.

Ionization of the sample can take place outside of the ion storage area of the ion trap; such external ionization is required for LC-MS using an ion trap and may be used for GC-MS. Alternatively, ionization can take place inside the ion storage area; this internal ionization approach can be used for GC-MS. Inert gas may be introduced into the trap after initial ionization for MS/MS experiments using collision-induced dissociation.

Ions are extracted from the trap by changing the amplitude of the ring electrode RF. As the amplitude increases, the trajectory of ions of increasing m/z becomes unstable. These ions move toward the end caps, one of which has openings leading to the detector. Ions of a given m/z value pass through the end cap sequentially and are detected.

The use of various RF and DC waveforms on the end caps allows the ion trap to selectively store precursor ions for MS/MS experiments or to selectively store analyte ions while eliminating ions from the matrix. This can result in improved detection limits in analysis. The ion trap has limitations. Because the stored ions can interact with each other (a space-charge effect), thereby upsetting stability of trajectories, the concentration of ions that can be stored is low. This results in a low dynamic range for ion trap mass spectrometers. Trace level signals from a target analyte ion at one mass can be destabilized by the presence of great excesses of contaminant ions, even if these are of sufficiently different mass to be well resolved from the ion of interest. Ion trap MS instruments are less forgiving of "dirty samples" than are quadrupoles, which "throw away" such unwanted ions as they are measuring




FIGURE 9.34 Cross-section of a quadrupole ion trap mass spectrometer. This schematic shows a gas phase sample introduced from a GC and ionized inside the trap by electrons from the filament. (From Niessen and Van Der Greef, used with permission.)

the target ion. The stored ion interaction also limits the accuracy of the mass-to-charge ratio measurement. Resolution of commercial QIT mass spectrometers is on the order of 0.1-1, with an m/z range of 10-1000.

9.2.3.6 FOURIER TRANSFORM ION-CYCLOTRON RESONANCE (FTICR)

The ICR instrument, also called a **Penning ion trap**, uses a magnetic field to trap and store ions. As shown in Figure 9.35, six conducting plates arranged as a cube serve as the ion trap. The cubic cell is about 100 mm on a side, is under very high vacuum (<10⁻⁸ torr) and is located inside a strong magnetic field produced by a superconducting magnet. Sample is introduced into the cell and ionized by an external ion source such as an electron beam passing through the trap. Ions in the presence of a magnetic field move in circular orbits perpendicular to the applied field, at a frequency called the cyclotron frequency:

(9.16)
$$\omega_c = \frac{z}{m}(eB) = \frac{v}{r}$$

where ω_c is the frequency of rotation of ions (radians/s); e, the charge on electron (coulombs); B, the magnetic field (tesla); z, the charge on the ion; m, the mass of the ion; ν , the velocity of the ion; and r, the radius of orbit.

The frequency of motion of an ion depends on the inverse of its m/z in a fixed magnetic field. Mass analysis is performed by applying an RF pulse of a few milliseconds' duration to the transmitter plates. The RF pulse provides energy to the ions, causing them to move in larger circular orbits at the same frequency. For a given m/z value, a pulse at a frequency of ω_c causes all ions of that m/z value to absorb energy and increase their orbit of rotation. When the RF pulse is off, the motion of the ions is detected by current induction in the receiver plates. As a group of positive ions approaches the receiver plate, its charge attracts electrons to the inside surface of the plate. As the group recedes, the electrons are released. This induced current, called an "image current" is a sinusoidal signal with frequency ω_c . The larger the orbit, the larger is the induced current. The frequency provides the m/z information about the ion and the current amplitude depends on the number of ions of that m/z value, providing information about the concentration of ions.

It would be possible to scan the RF and measure the magnitude of the image current at each m/z value to obtain the mass spectral information, but the process would be very slow. Instead, an RF pulse is used that contains a range of frequencies. The range of frequencies is chosen to excite the desired m/z range. When the pulse is off, all of the excited ions induce image currents in the receiver plates as they rotate. The output current, which contains all of the frequency and magnitude information from all of the ions present, can be converted mathematically to a mass spectrum by application of the Fourier transform (FT). The use of an ICR ion trap and Fourier transformation is called Fourier transform ion-cyclotron




FIGURE 9.35 "Exploded" view of an ICR ion trap. The ICR has been the primary mass analyzer used in FTMS, both alone and in newer "hybrid" FTMS instruments.

resonance mass spectrometry (FTICR-MS) or just FTMS. As of early 2003, this was the only type of FTMS instrument commercially available.

There are several advantages to the ICR. One is that the ion detection is non-destructive. Therefore, signals can be accumulated by averaging many cycles, resulting in greatly improved S/N and signal-to-background as well as very low detection limits. Detection of attomoles of analyte is possible. Frequency can be measured very accurately, so the mass accuracy and resolution of these FTMS systems can be very high, on the order of 1 ppb for a mass of 100 Da. In order to acquire sufficient information to achieve such high resolutions by the FT process, the data must be acquired over a longer period. In order that collisions with residual gas atoms in the ICR trap do not remove the ions during this period, it must be operated at very high vacuum ($<10^{-8}$ torr) if such high resolution is to be attained. The ICR can also be used for MS/MS and MSⁿ experiments, by storing precursor ions and fragmenting them in the trap using a collision gas, lasers, or ion beams. An advantage of the FTMS system is that it is nondestructive, so ions at all stages of an MSⁿ experiment can be measured. A QIT instrument expels ions to be analyzed, so only ions in the final step can be measured.

The major disadvantages of the ICR are a limited dynamic range due to the same space-charge effect described for the quadrupole ion trap, a more complex design, and high instrument cost, resulting from the need for extremely high vacuum operation and high field superconducting magnets.

Despite the high cost of the FTICR instrument, new "hybrid" FTMS instruments costing significantly more than 1 million US dollars were introduced commercially in 2003 because of their ability to determine the structure of proteins. Protein structure determination is critical to fundamental biology, genomics, proteomics, and the understanding of drug-bio-molecule interactions for development of pharmaceuticals. "Hybrid" FTMS instruments combining either an ion trap or quadrupole(s) on the front end, with the FTICR on the back end, exhibit both high sensitivity and high resolution. The diversion of non-target ions in the earlier stages greatly reduces their space-charge effects in the ICR trap, enabling it to operate at its maximum capability. Ion trap and FTICR instruments are not available for ICP-MS due to the large Ar+ intensity (from the plasma) relative to the analyte ions. Only a limited number of ions can be stored in the ion trap, resulting in poor sensitivity for the analytes compared to other ICP mass spectrometer designs.

9.2.3.7 THE ORBITRAP™ MS

The final and most recent MS design combines features of the Paul Trap and the FTICR trap described above, with vastly greater resolution and mass range than the former, and much better data acquisition rate and resistance to space-charge disruption than the latter. The operation is of greater complexity than can be addressed in full here, but some general points can be described. Figure 9.36 displays the heart of the instrument, a cross section of




FIGURE 9.36 The Orbitrap™ mass analyzer. (© Thermo Fisher Scientific [www.thermofisher. com]. Used with permission.)

pipe results in the loss of some chromatographic resolution, but with carful control of the chromatographic conditions, one can usually gain additional information about the sample that the mass spectrum cannot alone provide. The application of GC-ITR-MS had been most prominent in forensic analysis of drug samples, especially heroin tars. It has also been used in fuels analysis, especially coal derived liquid fuels with large numbers of naphthalenic compounds. GC-IR-MS systems are costly and are delicate, with a high maintenance overhead.

The applications for molecular MS have grown enormously in recent years. MS (molecular and atomic) is used by clinical chemists, pharmaceutical chemists, synthetic organic chemists, petroleum chemists, geologists, climatologists, molecular biologists, marine biologists, environmental scientists, forensic chemists, food scientists, nuclear scientists, materials scientists, inorganic chemists, organometallic chemists, analytical chemists, and scientists in many other fields. MS is not just used in laboratories, but online MS analyzers and field-portable MS systems are available commercially for process control and on-site detection of volatile pollutants, explosives, and gases. Applications are as diverse as determination of molecular weight, molecular structure, reaction kinetics, dating of minerals, fossils and artifacts, fundamental studies of ion-molecule reactions, and quantitative analysis of elements and compounds at sub-ppb concentrations. Inorganic and organic solids, liquids, and gases can be analyzed. Subcellular structures such as whole ribosomes can be studied. Some applications examples will be discussed, but the field is vast and cannot be adequately covered in this text. In addition to the scientific literature, many applications of MS can be found on the websites of the instrument manufacturers. Some of the websites are given subsequently.

9.4.1 HIGH-RESOLUTION MASS SPECTROMETRY

Double-focusing magnetic sector mass spectrometers, Fourier transform (FT) mass spectrometers, long path, folded multi-reflection or multi-turn spiral TOFs, and OrbitrapTM instruments are capable of mass measurements with high *resolution*, which enables separate measurements of mass and signal intensity of ions of closely similar mass and high *mass accuracy*, which enables determination of the exact masses of the resolved ions. The most important use of high-resolution MS is the direct determination of molecular formulas by exact mass measurements.

The atomic masses of the individual isotopes (nuclides) of the elements are nominally whole numbers, H=1 and 2; C=12 and 13; N=14 and 15; O=16, 17, and 18, and so on. If these masses are measured with sufficient accuracy, we find that actually they are only close to being whole numbers. This is due to the "mass defect", discovered by the early MS pioneer Aston in the 1920s. The mass defect is characteristic of a given isotope. If we use ^{12}C as the standard, the atomic masses of some common isotopes are as shown in Table 9.5. As a consequence, two molecular formulas may have the same nominal unit molecular weight, but actually differ slightly but significantly. For example, $C_{20}H_{26}N_2O$ and $C_{16}H_{28}N_3O_3$ have the same

IADLE 7.3	.5 Exact mass of common isotopes		
Element	Atomic Weight	Isotope (nuclide)	Exact mass
Hydrogen	1.00794	¹ H	1.007825
		² H (or D)	2.014102
Carbon	12.01115	12	12.000000
		¹³ C	13.003355
Nitrogen	14.0067	¹⁴ N	14.003074
		¹⁵ N	15.0001
Oxygen	15.9994	¹⁶ O	15.994915
		¹⁷ O	16.9991
		¹⁸ O	17.999159
Fluorine	18.998405	¹⁹ F	18.998405

TABLE 9.5 Exact Mass of Common Isotopes




FIGURE 9.48 Application of CERNO MassWorks™ and CLIPS programs to MS isotope cluster raw data. (Used with permission from CERNO bioscience, www.cernobioscience.com.)

best elemental composition match to the candidate mass and formula. Thus, mass accuracy and spectral accuracy from low resolution MS instruments can be improved *in silico* (i.e., by computer processing) to values similar to those attained by high resolution instruments, at greatly reduced cost, *if* one can be assured that the cluster MS peaks are only from one pure ion. Hence the desirability of a preliminary MS stage or chromatographic isolation of the compound being examined.

An illustration of the operation of the CERNO MassWorks[™] program is displayed in Figure 9.48, which shows both a heavily distorted raw MS signal of an ion isotope cluster and the restored ideal trace after the processing with a correction algorithm. As an example of the power of these algorithms, a compound of unit mass M^+ = 400, whose formula is $C_{25}H_{23}N_2OS$ could be measured in a low-resolution MS with a peak shape with FWHM (full width at half maximum) of 0.600 Da. There are 4110 possible formulas within a mass tolerance window of 20 mDa (51 ppm). When the spectral accuracy match for each of these, which was calculated from the data on all the higher masses in the isotope cluster, is added to the search parameters, the above formula is the 2^{nd} closest hit among the total of 4110 formulas having a spectral error of 1 %. Even applying the industry standard mass matching tolerance of 5 ppm (2 mDa), there remain 411 possible candidates. This not only demonstrates the feasibility for unknown formula determination on a unit mass resolution quadrupole MS, but demonstrates that spectral accuracy is more important than mass accuracy for differentiation among large numbers of formula candidates, regardless of the MS resolving power available. These programs can be usefully applied even to data obtained on high resolution instruments.

9.4.2 QUANTITATIVE ANALYSIS OF COMPOUNDS AND MIXTURES

Quantitative analysis of compounds can be performed by measuring the relative intensities of a spectral peak or peaks unique to the compound and comparing the intensity of the sample to a series of known standards of the compound. The use of **isotope dilution** for

quantitative measurements in MS is common. Isotope dilution is a special case of calibration using an internal standard; the internal standard calibration approach was covered in Chapter 1. For molecular analysis, the internal standard is the analyte molecule, but with some of its atoms replaced by heavier isotopes. Such a compound has been isotopically labeled. Labeling with deuterium (2H) and 13C is common, but isotopes of heteroatoms can also be used. For example, orotic acid, $C_5H_4N_2O_4$, is a compound with two nitrogen atoms in a six-membered ring; it is a metabolite present in only trace amounts in human urine, but an increase in orotic acid in urine can signify diseases that disrupt the urea cycle (McCann et al.). If both ¹⁴N atoms in natural orotic acid are replaced with ¹⁵N atoms, designated 1,3-[¹⁵N₂] orotic acid, the isotopically labeled orotic acid has a MW that is 2 Da higher than natural orotic acid, but behaves in all respects like natural orotic acid during analysis. An isotopically labeled compound added in a known amount to known amounts of the natural compound is the perfect calibration standard in this respect. A quantitative mass spectral determination of orotic acid in urine by GC-MS as the trimethylsilyl derivative, can be performed by measuring ions with m/z = 357 or 254 for natural orotic acid and m/z = 359 or 256 for the labeled acid. The ratio of m/z = 357/359 or 254/256 is plotted vs. the concentration of orotic acid in a set of calibration standards.

Quantitative analysis can also be performed by external calibration or by the use of an internal standard that is not a labeled analyte molecule, but a compound that is not present in the sample.

In some cases, components in a mixture can be determined quantitatively without prior separation, if the mass spectrum of each component is sufficiently different from the others. Suppose that a sample is known to contain only the butanol isomers listed in Table 9.6.

It can be seen that the peak at m/z = 33 is derived from butanol, but not from the other two isomers. A measurement of the m/z = 33 peak intensity compared to butanol standards of known concentration would therefore provide a basis for measuring the butanol content of the mixture. Also, we can see that the abundances of the peaks at m/z = 45, 56, and 59

TABLE 9.6 Mass Spectral Distribution of the Fragments of Isomers of Butanol^a Using Electron Ionization at 70 eV

m/z	Butanol	2-Butanol	2-Methyl-2-propanol
15	8.4	6.80	13.3
27	50.9	15.9	9.9
28	16.2	3.0	1.7
29	29.9	13.9	12.7
31	*100	20.31	35.5
33	8.5	0	0
39	15.6	3.4	7.7
41	61.6	10.1	20.8
42	32.4	1.7	3.3
43	61.4	9.8	14.5
45	6.6	*100	0.6
55	12.3	2.0	1.6
56	99.9	1.0	1.5
57	6.7	2.7	9.0
59	0.3	17.7	*100
60	0	0.7	3.2
74	0.8	0.3	0

^a Molecular weight for all isomers = 74 Da. Asterisks in table body denote the most abundant fragment (the base peak). The abundance is normalized to 100 for the base peak in each pattern, but the actual abundances of these peaks probably differ from each other.

vary greatly among the isomers. Three simultaneous equations with three unknowns can be obtained by measuring the actual abundances of these three peaks in the sample and applying the ratio of the abundances from pure compounds. The three unknown values are the percentages of butanol, 2-butanol, and 2-methyl-2-propanol in the mixture. The three equations can be solved and the composition of the sample determined. Computer programs can be written to process the data from multicomponent systems, make all necessary corrections, and calculate the results.

Complex mixtures of molecules such as biological fluids, natural products, foods, and beverages will result in mass spectra that are quite complicated, even if soft ionization is used to minimize fragmentation. Mixtures are more commonly analyzed by using GC-MS or LC-MS to separate the components of the mixture and to obtain mass spectral information on the separated components. This allows the analyst to obtain the pure MS spectra of each chromatographic peak. Chromatographic retention time matches will add to the confidence of the peak assignments. Standards are run, often using isotope dilution and internal standard calibration and the peak intensities or intensity ratios of appropriately selected peaks are used to make a calibration curve from which unknown concentrations in samples can be determined.

A few examples of GC-MS and LC-MS will be given here. A JEOL GCmate II^{TM} high resolution GC-MS with a magnetic sector mass analyzer was used to analyze Scotch whiskey and tequila samples. Over 50 compounds were identified in the whiskey using exact mass measurements from EI high-resolution spectra. Figure 9.49(a) shows the gas chromatogram for a sample of whiskey; the peaks are the separated compounds, identified by their retention time. Figure 9.49(b) presents the high-resolution exact mass measurements and the elemental compositions of the identified compounds. Such an analysis would permit distillers, food scientists, and regulators to compare brands, compare different batches for quality, and monitor contaminants. One of the compounds identified in the whiskey was a plasticizer that may have leached from packaging material. The GC-high-resolution MS system was also able to separate and measure trace amounts of polychlorinated biphenyls (PCBs) in crude oil, quite a complicated mixture. (These and the following JEOL applications, along with many others, can be found on the JEOL website at www.jeol.com.)

While we have focused on positive ion MS, there are classes of compounds that give much better mass spectral detection limits as negative ions. The use of a highly selective ionization source, a tunable-energy electron beam (the TEEMTM from JEOL), allows negative ions to be formed directly from analyte molecules. The electron beam energy can be tuned in the range




FIGURE 9.49 (a) Gas chromatogram of compounds in a sample of whiskey analyzed on A GCmate IITM high-resolution magnetic sector GC-MS instrument. (From JEOL applications note MS-1126200-A.) (b) The exact masses, elemental compositions, and identification of the compounds in a whiskey sample analyzed by high-resolution GC-MS. (From JEOL applications note MS-1126200-A. Both graphics courtesy of JEOL USA, inc., Peabody, MA [www.jeol.com].)




FIGURE 9.50 Determination of less than 10 ppb of a mixture of explosives spiked into a "dirty" matrix by negative ion MS using a JEOL TEEMmate[™] with a highly selective tunable-energy electron ionization source. (Courtesy of JEOL USA, inc., Peabody [www.jeol.com].)

of 0-25 eV; this permits selective ionization of the analyte, not matrix molecules. The combination of the tunable-energy electron ionization source with the JEOL GC-MS system into an instrument called the TEEMmateTM has permitted the determination of less than 10 ppb of explosives such as TNT, nitroglycerin, pentaerythritol tetranitrate, and RDX in complex matrices like soils by negative ion mass spectrometry. An example is shown in Figure 9.50. The instrument has also been applied to the detection of chemical warfare agents, bacterial spores, and environmental contaminants. Another mode of negative ion MS operation is Negative Ion Chemical Ionization (NICI), where the target molecules possess strong electronegativity, (e.g., heavily halogen substituted), and the "chemical" is actually an electron captured from a donor molecule or low energy electron beam, sometimes referred to as an electron capture (EC) process.

9.4.3 PROTEIN-SEQUENCING ANALYSIS (PROTEOMICS)

Proteins make up some of the most important components of the human body and indeed all animal life. They are major components in all living cells and are therefore of great importance in all chemical studies of life sciences. It is estimated that in human blood plasma alone there are about 100,000 proteins ranging in concentration from millimolar levels for proteins such as albumin to femtomolar levels for proteins such as tumor necrosis factor.

Proteins are made up of amino acids, which, as the name implies, include both an amino group and a carboxylic acid. There are 20 essential amino acids and the many hundreds of thousands of proteins are made up of these building blocks. What distinguishes one protein from another is the sequence in which these amino acids are arranged in the molecule. Sequencing has become a cornerstone of the research into proteomics, the study of protein structure and function. There are several approaches that can be taken to identify the sequence of amino acids in a protein by MS. The reference by de Hoffman and Stroobant contains a large section on analysis of biomolecules by MS. 2-D gel electrophoresis separation followed by MALDI-TOF MS and digestion of the protein into peptide fragments followed by HPLC-MS-MS are two ways in which protein sequences and structure can be obtained. A detailed description of the HPLC-MSⁿ approach to protein sequencing is given in Chapter 12.

and gaseous products such as HCl can all be measured using the mass spectrometer. (This and other applications as well as a useful tutorial with pictures of the quadrupole and other parts of the mass spectrometer can be found on the MKS Instruments, Inc. website at www. mksinst.com). Even smaller quadrupole mass analyzer systems are available as field portable gas analyzers; quadrupoles in these field portable systems are as small as 0.5 inches in length.

9.4.5 ENVIRONMENTAL APPLICATIONS

Molecular MS, especially GC-MS, is widely used in the identification and quantitative measurement of compounds that are of concern in the environment. PCBs, dioxins, dibenzofurans, PDBEs, PFOAs, and pesticides can be measured in the tissues of shellfish, fish, birds, and other animals, as well as in water, soil, sediments, and materials using MS, generally coupled to GC.

Brominated flame-retardants are under increasing scrutiny for their environmental impact. Common brominated flame-retardants are the polybrominated diphenyl ethers (PBDEs), of which there are 209 individual compounds (congeners) just as there are for polychlorinated biphenyls (PCBs). GC coupled to high resolution MS is the method of choice for determining PCBs and PBDEs in the environment. PCB or PBDE congeners with the same number of halogen substituents (from one to ten halogens are possible) are isomers with identical molecular weights and very similar mass spectra. The retention time information from the GC portion of the GC-MS will be needed to distinguish among such isomers. The isomers cannot be differentiated on the basis of the mass spectra alone.


GC-MS is the basis for most US Environmental Protection Agency (EPA) official analytical methods for organic pollutants in water and wastewater. Detection limits in the ppb to ppt ranges are common. Accuracy of ± 20 % relative standard deviation is usual.


For example, EPA Methods 8260 and 8270 use GC-MS to determine the pollutant 1,4-dioxane in water. Using deuterium-labeled 1,4-dioxane- d_8 and isotope dilution GC-MS, it can be demonstrated that the % recovery of ppb-level spikes improves from 60% to >90% when corrected using the isotope dilution technique. The two compounds differ slightly in retention time and can be separated on the GC column and measured quantitatively. Figure 9.51 shows the chromatogram and the mass spectra of the labeled and unlabeled 1,4-dioxane.


9.4.6 OTHER APPLICATIONS OF MOLECULAR MS


Biomolecules of all types can be analyzed by MS. The molecular weight and sequence of bases in nucleotides can be determined by MALDI-TOF-MS or by MS-MS. This allows the comparison of normal and mutated genes, for example. Analysis of nucleotides is important in medicine, agriculture, environmental science, and molecular biology. Oligosaccharides, long chains of sugar units, are extremely complex in structure, more so than proteins or nucleotides. These compounds can be linear or branched, and the sugar units have isomers and specific configurations at the bonds between units. All of this structural information can be obtained from mass spectral analysis of the oligosaccharides. FT-ICR and MSⁿ instruments are valuable in determining the structure of these complex molecules. Lipids such as fatty acids and steroids can be determined by MS. Drugs, toxins, and other compounds often undergo metabolic changes in the human body; MS is used to measure metabolites of compounds as well as the compounds themselves. The whole families of "-omics" studies have depended on highly-automated, large-scale use of hyphenated chromatographic-MS systems to profile the hundreds or thousands of DNA nucleotide sequences, peptide sequences in proteins, lipids, low MW metabolites, etc. that characterize the molecular biology and disease states of life forms ranging from bacteria to human beings.

In organic and inorganic chemistry, MS can be used to identify reaction products and byproducts. Impurities at concentrations as low as parts per trillion (ppt) can be detected; MS is widely used for this purpose. In inorganic chemistry, with special inlet techniques, the












FIGURE 9.51 (a) Separation of labeled and unlabeled dioxane by GC; The labeled dioxane elutes first in this case. (b) Mass spectrum of unlabeled 1,4-dioxane (m/z = 88). (c) Mass spectrum of deuterium-labeled 1,4-dioxane- d_8 (m/z = 96). The ions of the known internal standard are used to calibrate the mass scale.

elemental composition of materials as diverse as crystals and semiconductors can be determined. Reaction kinetics and ion-molecule reactions can be studied using MS.

Polymers are routinely characterized by MS, with MALDI now being the most common form of sampling and ionization of polymeric materials, using MALDI-TOF-MS or MALDI-FTMS. Synthetic polymers actually have a distribution of chain lengths and so have a distribution of molecular weights. Polymer molecular weights are reported as the average MW (the center of the MW distribution). The average mass of polymers can be determined more accurately by MS than by the more commonly employed method of gel permeation chromatography (Chapter 12).

9.4.7 LIMITATIONS OF MOLECULAR MS

The major limitation to the use of MS is that compounds must be volatile or must be able to be put into the gas phase without decomposing. A variety of ionization sources have been developed to handle materials that are volatile, semi-volatile, nonvolatile, or thermally labile. For compounds that are not volatile, chemical derivatization to a more volatile form can be performed to make them suitable for MS or GC-MS. Carboxylic acids can be converted to the corresponding volatile methyl esters, for example; trimethylsilane is another common derivatizing agent used to make volatile ether derivatives.

Certain isomers cannot be distinguished by MS alone. Some isomers, such as the PCB and PBDE isomers, may be able to be separated by chromatography prior to determination by MS.

9.5 ATOMIC MS

The original use of MS was for the detection and determination of elements. The elements have different masses, so MS provided a method of determining atomic weights. The various elements as well as their isotopes could be separated from each other with this technique. This made it possible to obtain the isotope distribution of pure elements (Appendix 9.A, textbook website). The application of MS to the determination of atomic weights and isotope distribution was crucial in the development of atomic chemistry and physics. While there are several types of ionization sources for atomic MS, such as the glow discharge (GD) and spark source (described in Chapter 7 and Section 9.2.2.5) used for atomic mass spectrometric analysis of solids, it is the development of the inductively coupled plasma (ICP) and the quadrupole mass analyzer that has caused a recent enormous increase in the use of atomic MS as an analytical tool.

9.5.1 INDUCTIVELY COUPLED PLASMA MASS SPECTROMETRY (ICP-MS)

ICP-MS permits determination of most of the elements in the periodic table at very low concentrations. More than 60 different elements from lithium to uranium can be determined in a few seconds using an ICP-MS with a quadrupole mass analyzer. This technique has great advantages over other techniques for elemental analysis in that ICP-MS can be used to determine most elements at high sensitivity and over a wide range of concentrations. In addition, isotope ratios can be obtained, providing geochemical and geochronological information, for example, that cannot be obtained by other elemental analysis techniques.

There are several properties of the mass spectrometer as an analyzer and the argon ICP (described in Chapter 7 and Section 9.2.2.5) as an ionization source that make ICP-MS an attractive combination. The ICP has a high ionization efficiency, which approaches 100 % for most of the elements in the periodic table, and it produces mainly singly-charged positive ions. The mass spectra therefore are very simple, elements are easily identified from their masses and isotope ratios are easily measured. ICP-MS in this respect overcomes the major problem of ICP optical emission spectrometry (i.e., the line-rich complicated optical

TABLE 9.7 Complementary Aspects of MS and ICP-OES: Why ICP-MS Evolved

ICP-OES Efficient but mild ionization source (produces mainly

Efficient but mild ionization source (produces mainly singly charged ions)

Sample introduction for solutions of inorganic salts is rapid and convenient

Sample introduction is at atmospheric pressure.

Efficiency is poor (5 % of sample into plasma; rest to waste using conventional nebulizer)

Matrix or solvent interelement effects are observed but relatively large amounts of dissolved solids can be tolerated

Complicated spectra with frequent spectral overlaps
Detectability is limited by relatively high background
continuum over much of the useful wavelength range

Moderate sensitivity (ppm to ppb range) Isotope ratios cannot be determined

MS

Ion source required

Sample introduction can be difficult for inorganic samples (generally not volatile). Thermal ionization, spark source, glow discharge and lasers restricted to solid samples and are time consuming

Requires reduced-pressure sample introduction

Limited to small quantities of sample and low amounts (<1 %) of dissolved solids

Relatively simple spectra


Very low background level throughout a large section of the mass range

Excellent sensitivity (ppb to ppt range) Isotope ratio determinations are possible

emission spectrum with high and variable background). In addition, the mass spectrometer is very sensitive, with detection limits up to three orders of magnitude better than ICP-OES (see Appendix 7, textbook website) and is linear over a wide dynamic range of up to five orders of magnitude. Table 9.7 presents some of the aspects of ICP-OES and MS that complement each other. The ability to rapidly analyze solutions of dissolved inorganic materials (metals, rocks, bones, ceramics, ash, and the like), combined with the simple mass spectra, low background and excellent sensitivity, led to the rapid spread in the use of ICP-MS in many fields.

The RF ICP source was described in Chapter 7, Section 7.3.1, and the quadrupole mass analyzer was described in Section 9.2.3. The interfacing between the ICP source and the quadrupole mass analyzer will be looked at with a little more detail to explain how ICP-MS provides the information it does.

Simplistically, the instrument is an ICP interfaced with a quadrupole MS as shown in Figure 9.52(a). This ICP source is horizontal, with the argon plasma concentric to the mass spectrometer inlet. Figure 9.52(b) shows the layout of an ICP-MS, the PerkinElmer NexION 300, with the plasma vertical (right side of diagram) to the mass spectrometer. This instrument has a quadrupole ion deflector (QID) above the torch. The QID turns positively-charged ions from the plasma 90° to the left, into the mass analyzer, while non-ionized material flows straight up and out of the system. While the instrument has a QID and a quadrupole reaction cell, it has only one analyzing quadrupole, not a QqQ system as described earlier. ICPs operate at atmospheric pressure and at a temperature of about 10,000 K. On the other hand, the mass spectrometer requires a high vacuum (10⁻⁴-10⁻⁶ torr) and operates at room temperature. Interfacing of the two systems is therefore the critical problem to be overcome. Most ICP-MS systems have an interface similar to the one shown in Figure 9.53, but the NexION 300 has three cones. In Figure 9.53, the argon ICP plasma is on the right side of the diagram. Ions from the plasma enter into the mass spectrometer through a two-stage interface. The plasma is centered on the sampler cone, and ions and plasma gas pass through the orifice in the cone into a vacuum-pumped region. Most of the argon gas is pumped away in this region. The remaining ions pass through the skimmer cone into the mass spectrometer. The skimmer cone is a sharper-angled cone with an orifice of about 0.9 mm in diameter. The design of this cone restricts the flow of ions into the mass spectrometer to the central part of the flow initially coming from the plasma. The region behind the skimmer cone is evacuated to a pressure of about 10⁻⁴ torr by a turbomolecular pump. This region can be isolated from the higher pressure of the interface region by a gate valve. This permits the sampler and skimmer cones to be removed for cleaning without breaking the vacuum in the mass spectrometer.






FIGURE 9.52 (a) Schematic diagram of an ICP-MS system with a quadrupole mass analyzer. (b) NexION 300 ICP-MS showing its three quadrupoles, three cones and the ICP torch, and sample introduction system. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)




FIGURE 9.53 Close-up of an ICP-MS interface, showing the sampler and skimmer cones. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

Both sampler and skimmer cones are made of either nickel or platinum, and are water cooled by contact with water flowing within the interface chamber. The hyperskimmer cone in the PerkinElmer instrument is designed to focus the ions even more tightly, with the aim of increasing stability and eliminating drift.

A series of ion-focusing elements (ion lenses) similar to those developed for double-focusing mass spectrometers have been utilized to introduce the ions into the quadrupole. Interference effects due to the presence of large numbers of photons reaching the detector, are eliminated by photon stops in older designs or off-axis ion lens in newer instruments. Background signals have been largely eliminated in modern ICP-MS instruments.

Other mass analyzers are used with the ICP ionization source, including high-resolution magnetic sectors and TOFs. ICP-TOF mass analyzer systems as well as other designs have the advantage of simultaneous measurement of ions. Simultaneous measurement is critical for accurate determination of isotope abundances as well as for accurate quantitative work using isotope-dilution. The article by Blades contains an excellent review of atomic MS instruments and an extensive bibliography. However, the instrumentation is constantly improving. In 2003, a new quadrupole-based ICP-MS design was introduced, with an ion mirror that reflects the analyte ions through 90° , while the neutrals and photons pass through. This results in exceptionally high S/N and extremely low detection limits compared with older quadrupole instrument designs. The instrument uses an all-digital extended range detector that gives nine orders of linear dynamic range, meaning that concentrations from ppt to hundreds of ppm can be measured reliably. The instrument is available from Analytik Jena. In 2012, Agilent Technologies introduced the first triple quadrupole ICP-MS, the 8800 ICP-QQQ. This instrument has tandem quadrupoles separated by an octopole reaction system, making it a QqQ design as discussed earlier. The advantages to this design will be described below.

9.5.2 APPLICATIONS OF ATOMIC MS

The high-temperature plasma decomposes the sample into its elements. A high percentage of these elements are ionized in the plasma and therefore do not need to pass through an additional ionization source. ICP-MS is particularly useful for rapid multielement determination of metals and nonmetals at concentrations of ppq, ppt, and ppb.

Only unit mass (low) resolution is required to discriminate between different elements, because isotopes of different elements differ by one unit mass as can be seen in Appendix 9.A (textbook website). There are only a few isotopic overlaps between elements, so one can usually find an isotope to measure for any given element. In fact, there is only one element that cannot be definitely identified by ICP-MS, the element indium. One of the problems at the end of the chapter asks you to explain why. The abundance of each isotope is a quantitative measure of that element's concentration in the original sample. The isotope patterns for the elements are shown in Figure 9.54.

The applications discussed are from many forms of atomic MS, including ICP-MS, glow discharge MS (GDMS), and coupled chromatography-ICP-MS.

Some of the many uses for ICP-MS include analysis of environmental samples for ppb levels of trace metals and nonmetals, the analysis of body fluids for elemental toxins such as lead and arsenic, determination of trace elements in geological samples, metals and alloys, determination of isotope ratios, analysis of ceramics and semiconductors, analysis of pharmaceutical and cosmetic samples, determination of platinum group catalysts in polymers, forensic analysis, elemental analysis in the petroleum and chemical industries, and metals determinations in clinical chemistry and food chemistry.

The most common samples analyzed by ICP-MS are aqueous solutions. The sample is dissolved in acid, digested or fused in molten salt (all described in Chapter 1), and then diluted to volume with water. All acids, bases, reagents, and water must be of extremely high purity, given the sensitivity of the ICP-MS technique. "Ultra-trace metals" grade acids, solvents, and deionized water systems are all commercially available. The aqueous solution is introduced into the plasma using a peristaltic pump, nebulizer, and spray chamber system identical to those used for ICP-OES (Chapter 7).




FIGURE 9.54 Element isotope patterns. (© 1993-2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

Solid samples can be analyzed by laser ablation ICP-MS or by coupling an electrothermal vaporizer or atomizer [ETV, ETA; identical to a graphite furnace used in AAS (Chapter 6)] to the ICP-MS. Both sample introduction systems are described in Chapter 7 and operate the same way they do for ICP-OES. The direct analysis of solid samples is certainly desirable as it eliminates sample preparation and the errors that go along with sample preparation. Table 9.8 compares the detection limits of ETV-ICP-MS with those of GFAAS. Solids can

TABLE 9.8 Approximate Detection Limits for Electrothermal Atomizer-ICP-MS

	ETA-ICP-N	15	GFAAS		
Elements	ng/ml (2 μL)	pg	ng/ml (10 μL)	pg	
¹⁰⁷ Ag	0.08	0.16	0.01	0.1	
²⁷ AI	0.03	0.05	0.2	2	
⁷⁵ As	0.05	0.1	1	10	
⁴⁴ Ca	0.7	1.4	0.5	5	
¹¹⁴ Cd	0.15	0.3	0.01	0.1	
⁵² Cr	0.1	0.2	1	10	
³⁹ K	1.5	3	0.1	1	
²³ Na	0.2	0.4	1	10	
⁵⁸ Ni	0.47	0.93	1	10	
²⁰⁸ Pb	0.1	0.3	0.2	2	
⁷⁸ Se	5.7	11.4	1	10	
²⁸ Si	2.7	5.4	5	50	
⁶⁴ Zn	0.2	0.4	0.05	0.5	

Note: This table presents a comparison of GFAAS with the use of a graphite furnace (electrothermal atomizer) as the sample vaporization step in conjunction with ICP-MS. The solution detection limit, the sample volume (μL), and the absolute detection limit in picograms are given for each technique. The isotope measured is specified for the ICP-MS technique; the isotope number has no meaning for AAS.

also be analyzed by GDMS and spark source MS. Laser ablation-ICP-MS is used to measure elements in fluid inclusions in rocks, microscopic features in heterogeneous materials, and individual crystals in samples such as granite. It can be used for analysis of artworks and jewelry, since the small laser spot size (<10 μm) available with modern lasers results in minimal damage to the object.

Quantitative analysis by ICP-MS is usually done with external calibration standards and the addition of internal standards to all standards and samples. When a large number of elements across the periodic table are to be determined, it is usual to add Li, Y, In, Tb, and Bi; and measure the ions ⁶Li, ⁸⁹Y, ¹¹⁵In, ¹⁵⁹Tb, and ²⁰⁹Bi as internal standards (unless you need to measure one of these elements as an analyte). Not all of the internal standard elements are used to quantitate every analyte. The internal standard that is most closely matched in first ionization potential to the analyte is generally used, since this will compensate for ionization interferences in matrices containing easily ionized elements such as Na. Results obtained using this approach are generally very accurate and precise. Table 9.9 presents typical spike recovery and precision data for ICP-MS determination of 25 elements in a certified reference material (CRM) "Trace Elements in Drinking Water" from High Purity Standards, Charleston, SC.

TABLE 9.9 Precision and Recovery Data for "Trace Metals in Drinking Water" Certified Reference Material (CRM) by ICP-MS

		Average			High Purity	Recovery of	Spike	Average		
		Measured			Certified	Certified	Level	Spike	Std. Dev. of	
Analyte	Isotope	Conc (µg/L)	Std. Dev.	Rel.% Dif.	Value	Value (%)	(μ g/L)	Recovery (%)	Spike Rec.	Rel.% Dif.
Be	9	17.17	0.13	0.75	20	85.8	50	92.1	1.0	1.1
Na	23	5,711.45	113.71	1.99	6,000	95.2	_	_	_	_
Mg	24	8,544.22	11.45	0.13	9,000	94.9	_	_	_	_
Al	27	113.60	0.37	0.33	115	98.8	50	106.7	3.8	3.5
K	39	2,421.85	22.01	0.91	2,500	96.9	_	_	_	_
Ca	44	33,871.41	611.84	1.81	35,000	96.8	_	_	_	_
V	51	28.92	0.08	0.28	30	96.4	50	101.0	1.3	1.2
Cr	52	18.99	0.04	0.22	20	94.9	50	103.2	5.6	5.4
Mn	55	33.58	0.73	2.18	35	95.9	50	99.0	2.6	2.6
Co	59	23.71	0.81	3.41	25	94.8	50	100.9	2.2	2.2
Ni	60	60.46	0.26	0.43	60	100.8	50	102.6	3.9	3.8
Cu	63	19.32	0.51	2.64	20	96.6	50	101.1	4.6	4.5
Zn	66	68.98	1.29	1.87	70	98.5	50	101.2	3.2	3.2
As	75	78.67	0.54	0.68	80	98.3	50	108.4	0.0	0.0
Se	82	9.21	0.15	1.61	10	92.1	50	91.7	0.6	0.7
Мо	98	94.93	3.23	3.40	100	94.9	50	105.4	1.1	1.0
Ag	107	2.34	0.04	1.78	2.5	93.6	50	99.4	1.0	1.0
Cd	111	11.35	0.01	0.12	12	94.6	50	96.3	1.1	1.2
Sb	121	9.55	0.03	0.31	10	95.5	50	99.8	1.0	1.0
Ва	135	48.49	0.73	1.51	50	97.0	50	117.5	0.3	0.2
Hg	202	0.11	0.03	27.27	Not available	_	1.5	100.7	0.04	0.04
TI	205	10.21	0.14	1.34	10	102.1	50	106.3	2.1	2.0
Pb	208	34.85	0.73	2.10	35	99.6	50	109.7	4.8	4.4
Th	232	0.01	0.01	79.75	Not available	_	50	107.6	0.8	0.8
U	238	10.16	0.20	1.97	10	101.6	50	106.7	2.7	2.5

Source: Wolf, R. et al., EPA Method 2008 for the Analysis of Drinking Waters, Application Note ENVA-300; (© 1995–2014 PerkinElmer, Inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

Note: The CRM is from High-Purity Standards, Charleston, SC.

9.5.2.1 GEOLOGICAL AND MATERIALS CHARACTERIZATION APPLICATIONS

Atomic MS has the ability to measure the isotope ratios of the elements. This was the original application of mass spectrometry both by Aston and by Thompson. Both quantitative measurement of trace elements in minerals and accurate isotope ratio determinations are extremely important in geology, climatology, and earth science, among other fields. Most elements have fixed ratios because their isotopes are stable, but some elements, such as uranium, carbon, lead, and strontium have isotopes that vary in their abundance because of natural radioactive decay processes. The isotope ratios of elements such as these can be used for estimating the age of a sample or for identifying the source of the element. The application of atomic MS to geological and fossil samples for accurate isotope ratios permits the dating of samples (geochronology), as well as applications in paleothermometry, marine science, and climatology.

The incorporation rates of the elements uranium, magnesium, and strontium into corals appear to be a function of water temperature. Accurate measurements of the elements and their ratios in fossil corals can provide information to climatologists about historical sea temperatures (paleothermometry). An ICP-MS method for determining these ratios accurately using internal standard isotope dilution is described by Le Cornec and Correge. As these authors note, the precision of the ICP-MS instrument must be very high, because the rate of change of the Sr/Ca ratio is only 0.9 % per °C and yearly variations in the sea surface temperature are only 5-6°C.

A long-standing method for thermometry has been to measure the stable oxygen isotope ratios in carbonate rocks using MS. Uranium/lead isotope ratios, determined by MS, are used to estimate the age of the earth.

Accurate isotope ratios often require high-precision mass spectrometers. Instruments capable of such high precision are either ICP-TOF-MS or high-resolution magnetic sector ICP-MS instruments of either the single detector or multicollector type. An excellent fundamental discussion of high precision isotope ratio measurements using the LECO RenaissanceTM TOF-based instrument is the cited technical brief by Allen and Georgitis. Despite the high cost of the magnetic sector instruments (approximately two to six times the cost of a quadrupole ICP-MS), it is estimated that in 2003 there were more than 350 magnetic sector single detector ICP-MS instruments and more than 100 multicollector magnetic sector ICP-MS units in operation around the world, testifying to the need for high-precision, high mass resolution measurements. The high mass resolution permits analysis of complex minerals and other matrices. The high sensitivity of these instruments makes them especially suitable for laser ablation analysis of geological specimens. (The instrument numbers and cost estimates are courtesy of Chuck Douthitt of Thermo Fisher Scientific, a manufacturer of magnetic sector-based high-resolution instruments.)

Trace levels of all of the rare earth elements (REEs) can be determined in rock samples and their distribution provides critical information to geologists. Some of the REE concentrations in basalt samples are in the sub-ppm range, but can be measured accurately in basalt samples that have been fused with lithium metaborate and diluted 5000-fold. The high dilution is necessary to keep the total dissolved solids <2000 mg/L, as the ICP-MS instrument does not tolerate high salt solutions well. The application is described by Ridd. Use of ICP-MS for the REEs gives spectra that are simpler than those obtained by ICP-OES and all of the REEs can be measured, which is not the case with techniques such as neutron activation analysis.

An interesting overlap of geology and synthetic materials characterization is the result of improvements in recent years in the ability to synthesize gem quality diamonds in large quantities and in rare, and therefore valuable colors. In addition, it is now possible to chemically diffuse trace amounts of metals like Ti and Be into low quality sapphires and rubies, dramatically improving their color and value. Rubies and sapphires are both ${\rm Al_2O_3}$ minerals, and as few as five Be atoms in the ${\rm Al_2O_3}$ crystal lattice can result in dramatic color change in the gem. In most cases, these synthetic diamonds and chemically treated gemstones cannot be detected by traditional gemological testing. Laser ablation ICP-MS is now being used to quantify Be and other trace elements in gems to distinguish natural gemstones from treated or synthetic ones. (Figure 7.42 in Chapter 7 shows laser ablation spots in a garnet

crystal, for example.) The cited article by Yarnell and the website of the Gemological Institute of America (www.gia.edu) provide details of this application and other spectroscopic techniques used to examine gems.

GDMS is used for the characterization of solid materials, especially coated and layered materials. The GD ablates the sample from the surface inward, providing the ability to depth profile materials. Bulk analysis of solid metals with detection limits in the low ppb range is possible. Coatings and layered materials, a few nanometers thick can be characterized by GDMS. Examples are given by Broekaert. The major disadvantage to GDMS is its relatively poor precision and the severe matrix effects encountered in analysis. Matrix effects are described below in Section 9.5.3.1. GDMS measurements generally have 20-30 %RSD compared with <5 %RSD for solutions analyzed by ICP-MS. The poor precision and severe matrix effects make GDMS suitable only for qualitative and semi-quantitative work, unless matrixmatched standards are available. In the experience of one of the textbook authors, GDMS determination of an easily ionized trace element in a heavy metal matrix gave results that were 100× higher by GDMS than results obtained by ICP-OES and AAS after dissolution of the sample. The GDMS results were in error because of a matrix effect. Because the analyte element was in the zero-oxidation state in the metal sample, but was present as an oxide in the glass used as the GDMS calibration "standard", the analyte was ionized from the metal sample much more easily than it was ionized from the glass used as the calibration standard. This resulted in a high signal from the sample which was interpreted as a high analyte value. This is an example of really poor "matrix-matching" of sample to calibration standard.

9.5.2.2 SPECIATION BY COUPLED CHROMATOGRAPHY-ICP-MS

The coupling of chromatography (GC, LC, IC) or capillary electrophoresis (CE) to ICP-MS allows the separation of complex mixtures and speciation by compound or oxidation state of the elements present. GC is described in Chapter 11; liquid chromatography (LC) including HPLC, ion chromatography (IC), and the non-chromatographic separation method of CE are described in Chapter 12. All of these separation instruments have been interfaced to ICP-MS systems. Coupling a separation technique to a quadrupole ICP-MS may require the use of additional software that can handle transient signals; such software is commercially available, as are complete hyphenated chromatography- ICP-MS systems for speciation.

Chong and Houk used an argon ICP-mass spectrometer as a GC detector for chemical compounds containing nitrogen, oxygen, phosphorus, sulfur, carbon, chlorine, bromine, boron, and iodine. GC-ICP-MS applications include the measurement of siloxanes, brominated flame retardants, and sulfur in fuels. Interfacing a GC to an ICP-MS is a relatively simple matter of connecting the GC outlet to the base of the ICP torch with a heated transfer line. In general, detection limits for GC-ICP-MS are 10-100 times better than GC with an atomic emission detector (GC-AED) for those elements that can be measured. Gases such as arsine, germane, phosphine, carbonyl sulfide, hydrogen sulfide, and silane can be determined at ppb or lower levels in bulk process gases. This is becoming an important area of analysis as demands for high purity gases in the microelectronics and polymer industries now specify impurity levels for metal hydrides and similar compounds to be 10 ppb or lower (Geiger and Raynor).

Commercial coupling of ion chromatography and mass spectrometry was introduced by Dionex and Thermo Fisher Scientific, who now owns Dionex. An application of ion chromatographic separation of ionic species coupled to ICP-MS is the determination of halogen oxyanions such as IO_4^- , IO_3^- , BrO_3^- , and CIO_3^- . IC generally uses a conductivity detector (described in Chapter 12), which is not a specific detector. Identification of ionic species must be made based on retention time and comparison to known standards. There is always some risk that two ionic species will have the same retention time, which could lead to misidentification of the species. Coupling the IC to an ICP-MS allows the anions to be separated, their retention times measured, and the specific halogens confirmed by ICP-MS. The mass spectrometer monitors the ^{127}I isotope, confirming that the ions giving rise to these peaks in the ion chromatogram are iodine-containing ions. The ions can be measured quantitatively using either the IC conductivity detector or the much more sensitive detector on the mass

spectrometer, depending on the concentrations. For perchlorate ion, an environmental concern in drinking water at ppb concentrations, two peaks, at 99 and 101 Da, can be used to confirm perchlorate due to the relative isotopic abundances of ³⁵Cl and ³⁷Cl. The use of MS as the detector permits quantitative determination of perchlorate in drinking water at ppt (ng/L) concentrations. Many other IC-MS application examples can be found at the Thermo Fisher Scientific website (www.thermofisher.com).

Organic solvents and organic petroleum fractions often need to be analyzed by ICP-MS for trace element content. LC is the most common separation technique coupled to ICP-MS and commercial systems for conventional HPLC, as well as capillary and nano-LC are available from several companies. HPLC separations are often carried out in organic solvents ranging from nonpolar solvents like xylene to polar alcohol-water mixtures. Organic solvents can be analyzed by ICP-MS with the same limitations that organic solvents present in ICP-OES. The RF power, the temperature of the ICP spray chamber, the nebulizer gas flow rate, and sample uptake rate may need to be adjusted depending on the volatility of the solvent to avoid extinguishing the plasma or causing carbon deposition on the sampler cone. Running organic solvents can cause specific polyatomic interferences, discussed in Section 9.5.3.


Speciation of compounds of environmental concern is another important application of coupled GC-ICP-MS and LC-ICP-MS. Arsenic compounds in shellfish are one example of the importance of being able to speciate arsenic-containing compounds; that is, to determine the exact chemical forms of arsenic present. Most of the arsenic in shellfish (80-99 %) in is the form of organoarsenic compounds, including arsenobetaine, monomethylated, and dimethylated arsenic acids. Arsenobetaine is not toxic because humans do not metabolize it, while the other organoarsenic compounds are much less toxic than inorganic arsenic compounds. To assess the risk of eating shellfish based on a determination of the total amount of arsenic present would greatly overestimate the danger of eating shellfish. Inorganic arsenic is present as well, in two oxidation states, As(III) and As(V). As(III) is more toxic than As(V). The ability to separate all of these arsenic species and detect them at extremely low levels by LC-ICP-MS permits a much better assessment of As exposure and hazards from consumption of water and food than a determination of total, as by elemental techniques such as ICP-OES, AAS, AFS, or ICP-MS. The cited articles by Milstein et al. describe arsenic speciation using IC-ICP-MS. A website dedicated to speciation analysis can be accessed at www.speciation.net.

9.5.2.3 APPLICATIONS IN FOOD CHEMISTRY, ENVIRONMENTAL CHEMISTRY, BIOCHEMISTRY, CLINICAL CHEMISTRY, AND MEDICINE

Foods and beverages of many types have been analyzed by ICP-MS. Solid or semisolid samples are generally digested with mineral acid, as are some beverages. Peanut butter, commercial breakfast cereal, dried milk, fish and shellfish, wine, beer, and the likes have been analyzed for trace elements such as Cu, Fe, Se, and Zn for nutritional purposes as well as for toxic metals like As and Pb. Al has been determined in many foods because dietary Al was being studied for a possible link to Alzheimer's disease; no such link has been demonstrated.

Whole blood and serum have been analyzed by ICP-MS for Al, Cu, Se, Zn, As, Cd, Mn, and Pb, among other elements. Blood lead (Pb) measurements are done to determine exposure to lead-based paint in infants and small children. Pb, like many of the heavy metals, is a central nervous system toxin, and ingestion of lead-based paint chips or exposure to lead-containing dust has been implicated in learning disabilities in small children. ICP-MS is sensitive enough to permit multielement quantitative analysis of blood using sample volumes of $100~\mu L$ or less. In addition, the isotopic ratio pattern of the four Pb isotopes can be used like a fingerprint to match the source of lead (home, environment, industrial exposure) to the lead in the patient's blood (Allen and Georgitis).

The inherent magnetic resonance imaging (Chapter 5) of tumors cannot always reliably distinguish tumors from normal tissue. However, gadolinium compounds targeted at tumors can enhance the MRI signal from tumors as seen in Figure 9.55. Gadolinium affects the T1 relaxation time in MRI, making the tissue that has absorbed the Gd compound "stand out" from adjacent tissue. The subject in Figure 9.55 is a rat with a mammary tumor. The tumor






FIGURE 9.55 MRI of a tumor in a rat before injection with a gd-containing contrast agent **(a)** and after injection **(b)**. The tumor is at the top of each image slightly to the left of center. The contrast agent is preferentially taken up by the tumor and appears enhanced (brighter) compared to the surrounding muscle tissue. (Images courtesy of Dr. E. E. Uzgiris.)

is at the top of both images, just to the left of center. Before injection with the Gd-containing contrast agent, the tumor cannot be distinguished from the surrounding tissue very well. Following injection with the contrast agent the tumor is clearly enhanced (seen as a much brighter area) because of preferential uptake of the contrast agent by the tumor. The other bright area in the lower right of the post-injection image is the rat's liver/kidneys. The use of ICP-MS to accurately determine the amount of Gd in rat tissues, blood, plasma, and serum is discussed in the article by Skelly Frame and Uzgiris. Accurate concentrations were needed so that the dose of contrast agent could be optimized for use in humans to obtain the best image with the lowest possible dose. Blood, serum, and plasma samples of 30-100 μL and tissue samples of 0.1-1.0 g wet weight were microwave digested in high purity nitric acid and analyzed after dilution. The Gd isotopes 156 and 158 were measured; the detection limit was $\sim\!0.005$ ppb Gd. Recent determination of high levels of Gd in San Francisco Bay has been reported and are blamed on the increased use of MRI by doctors and hospitals.

Environmental applications of ICP-MS are numerous, and include analysis of water, wastewater, soil, sediment, air particulates, and so on. A typical environmental analysis is to determine the leachable metals from soil or sediment; the solid is not dissolved but leached or extracted to determine labile elements. These labile or leachable elements are the ones that might be mobilized from a landfill into a drinking water supply; for example, Table 9.10 gives an example of determining leachable metals from an NIST Standard Reference Material (SRM) soil sample by ICP-MS.

As is the case with isotopic labeling of molecules, enriched levels of stable isotopes of elements can be used as tracers. Isotopes of elements can be used as nutritional supplements for plants or animals to trace absorption, assimilation, and metabolism of elements (Allen and Georgitis). Processes such as biomethylation of elements like mercury and arsenic in the environment can be studied using isotopically enriched elements. In some cases, methylated metals are more toxic than the inorganic species, and generally accumulate up the food chain.

ICP-MS has recently become a very important tool for screening and quantitation of elements in pharmaceuticals due to recent (2013) changes in the United States Pharmacopeia (USP) and new proposed guidelines from the US Food and Drug Administration. The USP is the official standards-setting agency for pharmaceutical products manufactured in or sold in the US. Similar organizations exist around the world (e.g., the European Medicines Agency, EMEA) and some have already implemented limits that require the sensitivity of ICP-MS as well as the speciation ability of coupled chromatography-ICP-MS in some cases. Inorganic impurities in pharmaceuticals can arise from impurities in raw materials or reagents, contaminants introduced during manufacturing, residues from catalysts, naturally-occurring elements from plants or minerals, and leachable elements from packaging materials, among

TABLE 9.10	ICP-MS Results from Leaching of NIST SRM 2711 Moderately Contaminated
	Montana Soil

		Measured				NIST Leach	Ran	ge	Spike Amount	Spike Recovery
Analyle	Mass	Conc (mg/kg)	Std Dev	RSD	RPD	Value (mg/kg)	Low	High	(ppb)	(%)
Ве	9	1.1	0.03	2.54	3.59				100.0	104
Al	27	20,066.5	621.82	3.10	4.38	18,000.0	12,000.0	23,000.0	100.0	_
V	51	48.2	1.63	3.39	4.79	42.0	34.0	50.0	100.0	98
Cr	52	23.7	0.23	0.95	1.35	20.0	15.0	25.0	100.0	97
Mn	55	493.0	14.82	3.01	4.25	490.0	400.0	620.0	100.0	110
Co	59	8.1	0.12	1.44	2.03	8.2	7.0	12.0	100.0	98
Ni	60	17.1	0.01	0.08	0.11	16.0	14.0	20.0	100.0	96
Cu	63	104.1	3.62	3.48	4.92	100.0	91.0	110.0	100.0	99
Zn	66	315.8	8.79	2.78	3.94	310.0	290.0	340.0	100.0	111
As	75	94.0	1.93	2.06	2.91	90.0	88.0	110.0	100.0	103
Se	82	2.2	0.11	4.92	6.96	NR			100.0	109
Мо	98	1.2	0.02	1.48	2.09	<2			100.0	105
Ag	107	4.3	0.03	0.67	0.94	4.0	2.5	5.5	100.0	102
Cd	111	40.0	0.91	2.27	3.20	40.0	32.0	46.0	100.0	102
Sb	123	3.9	0.14	3.71	5.25	<10			100.0	98
Ва	135	192.2	6.64	3.45	4.88	200.0	170.0	260.0	100.0	98
TI	205	1.8	0.06	3.58	5.07				100.0	105
Pb	208	1,087.3	35.25	3.24	4.58	1,100.0	930.0	1,500.0	100.0	132
Na	23	320.3	5.82	1.82	2.57	260.0	200.0	290.0		_
Mg	24	7,726.8	201.46	2.61	3.69	8,100.0	7,200.0	8,900.0		_
K	39	5,064.4	128.65	2.54	3.59	3,800.0	2,600.0	5,300.0		_
Ca	44	20,742.0	166.68	0.80	1.14	21,000.0	20,000.0	25,000.0		_
Fe	54	21,662.2	526.25	2.43	3.44	22,000.0	17,000.0	26,000.0		_

Source: Wolf, R. et al., RCRA SW-846 Method 6020 for the ICP-MS Analysis of Soils and Sediments, Application Note ENVA-301; (© 1996–2020 PerkinElmer, Inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

other sources. Elements, chemical form and limits vary depending on the nature of the pharmaceutical (drug vs. dietary supplement), and the method of dosing-oral, inhalation, parenteral (by intravenous drip or injection). Limits are set by Permissible Daily Exposure (PDE) based on a 50 kg person, by concentration; and for parenteral administration, by the Large Volume Parenteral Component Limit (LVP), defined as the absolute level that may occur in any component of the solution.

For example, in dietary supplements, the USP individual component limits in $\mu g/g$ are: inorganic As, 1.5; Cd, 0.5; Pb, 1.0; Hg (total), 1.5; methylmercury (as Hg), 0.2. Speciation is clearly required for As and Hg. In pharmaceuticals, the USP regulates inorganic As, Cd, Pb, inorganic Hg, Cr, Cu, Mn, Mo, Ni, Pd, Pt, V, Os, Rh, Ru, and Ir at levels varying from 5-2500 $\mu g/day$ PDE. The platinum group metals are usually residues from catalysts, but there are several platinum cancer drugs in use. The EMEA regulates an almost identical list of elements. ICP-MS is almost the only technique available for rapidly determining all of these elements at the required sensitivity. More details are available in the white paper "Simultaneous ICP-MS in the Pharmaceutical Industry" available from SPECTRO Analytical Instruments GmbH at www.spectro.com.

9.5.2.4 COUPLED ELEMENTAL ANALYSIS-MS

While not strictly speaking "atomic" mass spectrometry, mass analyzers have now been coupled with traditional elemental analyzers for trace levels of C, H, N, S, and O in metals and alloys. These elemental analyzers are also confusingly called "gas analyzers" because

they determine C, H, N, O, and S as gases released from samples by heat or combustion. These traditional elemental analyzers are of two basic types: oxygen-assisted combustion for carbon and sulfur and inert gas fusion for hydrogen, oxygen and nitrogen determinations. They utilize high temperature furnaces and either thermal conductivity (TC) and/or IR detectors. These instruments, made by a number of instrument companies, have been used for years to analyze metals and alloys for materials development, process control, and quality assurance.

Hydrogen has a particularly deleterious effect on the physical properties of steel. Because hydrogen atoms are so small, they can easily diffuse into the metal lattice during fabrication and processing of steel. Hydrogen atoms can accumulate in the voids of the lattice and form pockets of molecular hydrogen with high internal pressure. This process is called hydrogen embrittlement. When the steel is stressed, the metal can crack at these hydrogen pockets (Oxley et al.). Bruker Corporation has introduced a series of extremely low detection limit hydrogen analyzers for diffusible hydrogen and for diffusible and total hydrogen, as well as oxygen and nitrogen by coupling their traditional elemental analyzers with a compact quadrupole mass spectrometer, the ESD 100, from InProcess Instruments (www.in-process.com). The Bruker G8 Galileo O/N/H analyzer, with an ESD 100 mass analyzer and an external IR furnace for diffusible hydrogen measurements, utilizes the inert gas fusion principle. A steel sample is fused in a graphite crucible at > 2500°C. Total hydrogen is released from the sample and measured with the ESD 100. The ESD has a channeltron detector optimized for the low m/z range. Using a TC detector, 0.43 ppm hydrogen is at the detection limit for steel, but the mass spectrometer can detect 0.043 ppm (430 ppb) hydrogen in steel.

9.5.3 INTERFERENCES IN ATOMIC MS

Mass spectral interferences are observed in atomic MS. These interferences are of two types, direct m/z overlap between two ions, and matrix interferences which cause enhancement or suppression of analyte signals.

9.5.3.1 MATRIX EFFECTS

The introduction of the sample into the plasma suffers from the same problems in ICP-MS as in ICP emission spectrometry. These include the complicated process of nebulization and atomization. These processes occur before introduction of the sample into the mass spectrometer system.

The interface between the two systems includes the one torr region where deposition of products can occur. Severe suppression of signal has been observed when high concentrations of dissolved solids are present. This may be caused by suppression of ionization by other more easily ionized elements present in the sample. The exact cause of this interference is not clear, but the fact remains that interference does take place. The problem can be overcome to some extent by limiting the concentration in the samples to less than 0.2 % total solids. This can be a serious limitation, particularly when body fluids or fused minerals are being examined. Newer instruments employ a variety of usually proprietary sample introduction devices to enable higher matrix concentrations to be tolerated.

The solvent and other elements present in the sample cause matrix effects. These affect atomization efficiency, ionization efficiency, and therefore the strength of the MS signal. This directly impacts quantitative results. Signals may be suppressed or enhanced by matrix effects. Aqueous solutions act very differently from organic solvents, which in turn act differently from each other. The problem can be overcome for the most part by matrix-matching (i.e., the standards used for calibration are matched for acid concentration or solvent, major elements, viscosity, etc., to the matrix of the samples being analyzed). This is similar to atomic absorption and atomic emission spectrometry where the same requirement in matching solvent and predominant matrix components is required for accurate quantitative analysis. The use of internal standards will also compensate for some matrix effects and will improve the accuracy and precision of ICP-MS measurements.

9.5.3.2 SPECTRAL (ISOBARIC) INTERFERENCES

In ICP-MS interferences are seen from argon ions and argon-containing polyatomic species, since these are present in high abundance in the argon plasma. Argon is composed of three isotopes, but 40 Ar is 99.600 % of the total, so 40 Ar+ is the ion of most concern. 40 Ar+ and 40 Ca+ have the same nominal mass, and we can say that they overlap. A single quadrupole MS cannot distinguish between the two. Such mass overlaps are called isobaric interferences; they are spectral interferences. Unfortunately, 40 Ca+ is the most abundant Ca isotope, constituting 96.941 % of Ca. To determine Ca using a standard quadrupole ICP-MS instrument, another less abundant Ca isotope must be chosen for measurement. Polyatomic ions such as ArH+, ArN+, ArCl+, ArOH+, and Ar₂+ are commonly formed in the plasma and interfere with a number of possible analytes, as shown in Tables 9.11–9.13 These polyatomic spectral interferences are very problematic when the element affected is monoisotopic, as is the case with 75 As and 55 Mn or when the isotope affected comprises more than 90 % abundance of the element, as happens with 56 Fe, 39 K, 40 Ca, and 51 V.

Polyatomic ionic species also form from air, solvents, and matrix components, such as oxides of metals present in large amounts in the sample as well as from the acids and other reagents used to digest samples. For example, titanium has five isotopes, 46 Ti, 47 Ti, 48 Ti, 49 Ti, and 50 Ti, which can form Ti 16 O oxide ions that interfere with 62 Ni, 63 Cu, 64 Zn, 65 Cu, and 66 Zn. Examples in addition to the argon ions mentioned earlier include CO $_2$ +, CO+, SH+, SO $^{2+}$, NOH+, ClO+, ArS+, and so on, which are derived from the plasma gas, and from reactions of Ar with water, carbon, and other elements present in the solvent or the sample. Based on

TABLE 9.11 Potential Interferents in a Carbon-Rich Plasma with Oxygen Addition

Potential Interfering Species	m/z	Affected Element
¹² C ₂	24	Mg
¹² C ¹³ C	25	Mg
⁴⁰ Ar ¹⁶ O	56	Fe
¹² C ¹⁶ O	28	Si
¹² C ¹⁶ O ₂	44	Ca
⁴⁰ Ar ¹² C	52	Cr
$^{40}Ar^{12}C^{16}O$	68	Zn

TABLE 9.12 Common Polyatomic Interferences in ICP-MS

Polyatomic Ion Interference	m/z	Affected Element
¹⁴ N ₂	28	²⁸ Si
¹² C ¹⁶ O	28	²⁸ Si
¹⁴ N ¹⁶ O ¹ H	31	31 p
¹⁶ O ¹⁶ O	32	³² S
$^{38}Ar^{1}H$	39	³⁹ K
⁴⁰ Ar	40	⁴⁰ Ca
35C 16O	51	51 V
³⁶ Ar ¹⁶ O	52	⁵² Cr
⁴⁰ Ar ¹² C	52	⁵² Cr
⁴⁰ Ar ¹⁴ NH	55	55Mn
$^{38}Ar^{16}O^{1}H$	55	55Mn
⁴⁰ Ar ¹⁶ O	56	⁵⁶ Fe
²³ Na ⁴⁰ Ar	63	⁶³ Cu
⁴⁰ Ar ³⁵ Cl	75	⁷⁵ As
⁴⁰ Ar ⁴⁰ Ar	80	⁸⁰ Se

	a Reaction Ce	211	
Isotope	Abundance (%)	Interfering Species	Typical Reaction Gas
³⁹ K+	93.3	³⁸ Ar ¹ H+	NH_3
⁴⁰ Ca+	96.9	⁴⁰ Ar+	NH_3
51 V +	99.8	35C 16O+	NH_3
⁵² Cr+	83.8	³⁶ Ar ¹⁶ O+	NH_3
		⁴⁰ Ar ¹² C+	
		35CI16O1H+	
⁵⁵ Mn+	100	$^{38}Ar^{16}O^{1}H^{+}$	NH_3
⁵⁶ Fe+	91.7	$^{40}Ar^{16}O^{+}$	NH_3
⁶³ Cu+	69.2	²³ Na ⁴⁰ Ar	NH_3
⁷⁵ As+	100	⁴⁰ Ar ³⁵ Cl+	H ₂ /Ar mix
⁸⁰ Se+	49.6	⁴⁰ Ar ⁴⁰ Ar+	CH ₄

TABLE 9.13 Examples of Spectral Interferences Addressed Using a Reaction Cell

studies of these interfering ions, nitric acid is considered to be the most attractive acid to be used in preparing sample solutions. Unfortunately, not all elements are soluble in nitric acid alone. No ions occur, however, with a mass greater than 82 from any of the common acids. Therefore, the higher part of the mass range is unaffected by these interfering ions.

The analysis of organic solvents presents some unique polyatomic interferences. Some analysts add oxygen to the plasma, when running organic solvents to minimize carbon (soot) formation on the cones. The additional oxygen can, not only create the polyatomic species listed in Table 9.11, but can also react with some elements to form refractory oxides, as happens in aqueous solution. Examples include 46 Ti 16 O, which interferes with 63 Cu and rare earth element oxides, such as 143 Nd 16 O, which interferes with 159 Tb.

One approach to minimizing the formation of polyatomic species is to adjust plasma and operating conditions. A "cool plasma" or "cold plasma" can be formed by decreasing the power to the plasma. Using cool plasma conditions eliminates formation of or reduces many of the Ar polyatomic ions, permitting accurate ppt level determination of Na, K, Ca, and Fe. The drawbacks to changing the operating conditions to a cool plasma, are that detection limits for some elements may be poorer than in a normal "hot plasma", matrix effects may increase and longer analysis times may be needed. It may be necessary to run samples under two sets of operating conditions to optimize detection limits for all elements.

Appendix 9.A (textbook website) indicates that there are also direct spectral interferences of one element on another. 58 Ni overlaps with 58 Fe; even though 58 Fe is the least abundant Fe isotope at 0.28 %, trying to measure trace 58 Ni (the most abundant Ni isotope at 68 %) in an iron sample would be difficult. It would be better to measure 60 Ni, which is not interfered with by Fe. Other overlaps can be seen in this table; Zr and Mo have three isotopes that directly interfere with each other; Lu, Hf, and Yb all have a176 isotope; while Ta, W, and Hf all have a 180 isotope. Although most ions formed in the plasma have a single positive charge, some doubly charged ions form with the same apparent mass as a singly charged ion of another element. Remember that we are still measuring m/z in atomic mass spectrometry, not mass. When the doubly charged ion is the most abundant isotope and is present in large quantities in the sample, this can cause significant problems. For example, 88 Sr²⁺ interferes with 44 Ca⁺ and 86 Sr²⁺ interferes with 43 Ca⁺; 112 Cd²⁺ interferes with 56 Fe⁺; and 138 Ba²⁺ interferes with 69 Ga⁺. An analyst needs to consider the relative abundances and nature of the sample matrix and acids or other reagents used when assessing potential isobaric interferences in ICP-MS.

Many of these interferences are well-documented, and in a well-controlled system, many can be corrected for mathematically. Most instrument companies have interference-correction software as part of their data handling software. A problem with this approach has been that sometimes the necessary data was not collected during analysis, requiring reanalysis if possible. Multiple scans or longer analysis times may have been needed. One instrument that has an advantage with respect to software corrections, is the simultaneous ICP-MS,

from SPECTRO, already described. Because the SPECTRO MS collects the complete mass spectrum simultaneously without scanning, all data is available. Having been collected at the same time, measurement-based corrections can be made more reliably.

9.5.4 INSTRUMENTAL APPROACHES TO ELIMINATING INTERFERENCES

There are now five primary instrumental approaches to eliminating or reducing interferences in atomic mass spectrometry: (1) use of high mass resolution ICP-MS (HR-ICP-MS); (2) use of a collision cell to break apart polyatomic interferences; (3) use of gas phase chemical reactions in a "reaction cell" to eliminate polyatomic interferences; (4) changing the instrument operating conditions to form a cool or cold plasma; (5) use of tandem quadrupoles in MS/MS mode to exclude all non-target analyte masses.

9.5.4.1 HIGH-RESOLUTION ICP-MS (HR-ICP-MS)

As is the case with high-resolution molecular mass spectrometers, these magnetic sector or TOF based instruments permit accurate mass determination (resolution <0.1 Da). Quadrupole systems are limited to unit mass resolution (1 Da). Therefore, the use of HR-ICP-MS eliminates many of the spectral interferences seen with quadrupoles because the "overlaps" do not occur; the resolution is sufficient to separate the exact masses of the polyatomic species and analyte elements. HR-ICP-MS is the only way to measure accurately low levels of elements that suffer from significant interferences, including S, P, Si, F, and Cl, using MS. HR-ICP-MS allows interferences to be characterized using exact mass measurements. Using high resolution ICP-MS, it is possible to separate 31 P, 30 SiH, 12 Cl 9 F, 14 N 17 O and 13 Cl 18 O. All these species have a nominal mass of 31 Da. The high S/N of these instruments results in extremely low detection limits (parts per quintillion limits are claimed by one manufacturer). This allows direct analysis of low concentration samples without preconcentration, allows dilution of samples, and allows the use of low-flow rates, minimizing matrix effects.

9.5.4.2 COLLISION AND REACTION CELLS

A collision cell is often a small hexapole, octupole, or quadrupole inserted between the ion optics and the mass analyzer of the instrument. As the ions, including polyatomic ions, pass through the cell, they are bombarded with gas molecules, usually helium or hydrogen. While both analyte ions and polyatomic ions lose the same amount of energy every time they collide with a helium atom, polyatomics are bigger and therefore collide more often, and lose more energy as they transit the cell than do analyte ions. At the exit of the collision cell, the ion energies no longer overlap. A bias voltage "step" rejects the low energy polyatomic ions. This method of removing polyatomic interferences is called **kinetic energy discrimination** (KED). A simple hexapole collision cell can reduce the interference on ⁵⁶Fe⁺ by the polyatomic ArO+ ion by 102. Collision cells are commonly used with single quadrupole ICP-MS systems to remove polyatomic interferences in high matrix samples. Advantages include no reactive signal loss for analytes and no formation of new interferences in the cell, which can occur with reactive gases. However, He gas collision mode cannot effectively remove intense interferences on analytes such as P, S. and Se, or enable ppt-level analysis of high purity materials. He collision mode cannot remove direct isobaric interferences such as 40Ar on 40Ca and is not effective against doubly-charged interferences such as $^{150}\text{Sm}^{2+}$ and $^{150}\text{Nd}^{2+}$ on $^{75}\text{As}^+$. For ultra-trace analysis a reactive gas is used in "reaction mode" to eliminate interferences.

One example of a collision/reaction cell is the ORS³ octopole reaction system from Agilent Technologies. The ORS³ can operate in collision mode with He and KED removal of interferences (Figure 9.56). It can also operate in reaction mode, using specific gas phase chemical reactions to greatly reduce polyatomic interferences. The ORS³ is an octopole placed inside an enclosed reaction chamber. The cell is positioned between the ion optics and the mass analyzer in a single quad MS (see Figure 9.32). The gas inlet allows a small volume of reactive gas into the cell. Some of the gases used in reaction mode are ammonia, methane, oxygen,




FIGURE 9.56 The process of interference removal using He mode and kinetic energy discrimination in an octopole reaction cell. (© 2020 Agilent Technologies [www.agilent.com/chem]. All rights reserved. Used with permission.)

and hydrogen. The gas is selected based upon its ability to undergo a gas phase chemical reaction with the interfering species. Examples are given in Table 9.13. The gas phase ion-molecule reaction converts the interfering ions into non-interfering products. These reaction products are ejected from the analyte ion path, either by the reaction cell or by the analyzer quadrupole. Using this approach, the ArO+ interference on 56 Fe+ is reduced by 10^{6} .

For ultra-trace analysis, reaction mode may provide better interference removal than collision mode. There are some disadvantages to this approach. Each reaction gas will only remove interferences which react with that cell gas, so some interferences may remain. The analyst must know what interferences to remove in order to choose the reaction gas. This is not always possible with unknown samples. Reaction gases can react with the sample matrix and analytes to create new interferences. These cell-formed interferences are often unpredictable and may lead to erratic results. Reaction gases may react with analytes and reduce their sensitivity; severe loss of sensitivity for Cu and Ni has been reported when using $\rm H_2$ and ammonia.

PerkinElmer uses a patented scanning quadrupole-based collision/reaction cell, called a Universal Cell, which can operate with collision/KED or reactive gas. The scanning quadrupole in the cell removes side reaction product and new interferences, so that only the analyte passes to the analyzing quadrupole.

9.5.4.3 MS/MS INTERFERENCE REMOVAL

Quadrupole-based reaction cells used in single quadrupole ICP-MS instruments, can reject some non-target ions by operating the ion guide as a low mass cutoff or bandpass filter. However, these devices cannot remove all overlapping ions so reaction mode can be erratic, except in the case of simple, well-characterized matrices. In 2012, Agilent Technologies introduced the first tandem MS instrument for ICP-MS, the 8800 ICP-QQQ. QQQ stands for triple quadrupole or "triple quad", although there are only 2 quadrupole mass analyzers in this system (a QqQ design). In the 8800 ICP-QQQ, a single quadrupole mass analyzer (Q1) is placed in front of the Agilent ORS³ octopole collision/reaction cell. A second quadrupole mass analyzer (Q2) follows the collision/reaction cell. This configuration is call MS/MS or tandem MS. Figure 9.57 shows the hardware without the instrument box.

The MS/MS mode removes interferences in a number of ways, depending on the configuration of the quadrupoles. The two main modes are MS/MS on-mass mode and MS/MS mass-shift mode. (Remember we are using mass to mean m/z.)





FIGURE 9.57 (a) The Agilent technologies 8800 ICP-QQQ. **(b)** The interior of the 8800 ICP-QQQ. From the left, sample introduction, the ICP torch box (note the cooling coils for the torch), Q1, the ORS³ octopole collision/reaction cell, Q2 and finally the electron multiplier detector. (© 2020 Agilent Technologies [www.agilent.com/chem]. All rights reserved. Used with permission.)

In on-mass mode, both Q1 and Q2 are set to the same target mass. In this case, Q1 controls which ions enter the collision/reaction cell. All masses except the analyte mass and any direct mass interferences are rejected by Q1; only the analyte mass and any direct on-mass interferences pass into the collision/reaction cell. The ORS³ separates the analyte from interferences by neutralizing the interference or shifting it to a new mass. Q2 then rejects any cell-formed interferences except for the target analyte ion. The on-mass mode removes the variability seen in reaction cell systems caused by different samples (ions) changing the reaction processes and product ions. The on-mass mode is used when the analyte is <u>not</u> reactive and the interferences <u>are</u> reactive with a particular cell gas.

An example of this mode of interference removal is the use of O_2 cell gas to remove the $^{186}W^{16}O^+$ (202 Da) overlap on $^{202}Hg^+$. The mercurous ion does not react with oxygen, but WO^+ does, as follows:

$$WO^+ + O_2 \rightarrow WO_2^+$$
 and WO_3^+

Q1 and Q2 are both set to 202 Da. If Q1 is set to 202 Da, both the analyte Hg⁺ and the interference $^{186}W^{16}O^+$ will pass into the ORS³ cell. WO⁺ reacts with O_2 in the cell and is converted

to WO_2^+ and WO_3^+ . These product ions are no longer at mass 202 and are rejected by Q2. Only the analyte ion, $^{202}Hg^+$, passes through Q2 and is detected free from overlap interference.

Another example of the use of this mode is the removal of S-based interferences on ⁵¹V. In high purity materials, the interferences are generally well-known and consistent. In the analysis of high purity sulfuric acid for trace elements, ⁵¹V⁺ is overlapped by ³³S¹⁸O⁺ and ³⁴S¹⁶OH⁺ ions from the matrix. The sulfur-based interferences react rapidly with ammonia gas in the cell; vanadium reacts very slowly with ammonia, so use of on-mass mode with the quadrupoles set at 51 Da removes the SO/SOH interferences by formation of S ion-ammonia cluster ions. No other ammonia cluster ions can form in the cell because only the ions at 51 Da were allowed to enter the cell. Only ⁵¹V⁺ exits the cell to Q2 and the detector. Detection limits for this type of analysis are generally one-two orders of magnitude better than those achieved with a standard He collision cell.

The second mode of interference removal is mass-shift mode, where Q1 and Q2 are set to different masses. This mode is used when the analyte <u>is</u> reactive with a particular cell gas and the interferences are not reactive.

In mass-shift mode, Q1 is set to a precursor ion mass, usually the analyte mass. Only the analyte mass and any on-mass interferences pass through to the ORS³. In the ORS³, the reactive analyte is separated from the nonreactive interferences by shifting the analyte to a new product ion mass.

Q2 is set to the mass of a target reaction product ion containing the analyte. Q2 rejects all cell-formed product ions except the target analyte product ion.

An example of using mass-shift mode is the conversion of ${}^{32}S^{+}$ to ${}^{32}S^{16}O^{+}$ (at 48 Da) by reaction with oxygen gas. In a single quadruple system, ${}^{32}S^{+}$ is overlapped by O_2^{+} , while ${}^{48}SO^{+}$ is overlapped by ${}^{48}Ca^{+}$, ${}^{48}Ti^{+}$, and ${}^{36}Ar^{12}C^{+}$. By setting Q1 to 32 Da and Q2 to 48 Da (Q1 + 16 Da in oxygen mode), only the ${}^{32}S^{+}$ ion enters the reaction cell and only ${}^{48}SO^{+}$ enters Q2 and is detected. The Ca, Ti, and ArC ions are rejected by Q1 and do not interfere. Since all of the S isotopes react with oxygen, it is possible using this MS/MS mode and oxygen cell gas to perform S isotope ratio analysis by measuring ${}^{32}S^{16}O$, ${}^{33}S^{16}O$, and ${}^{34}S^{16}O$ ions. A similar O-atom addition reaction to Ti⁺ enables all of the Ti isotopes to be measured as the respective TiO ions with no interference from on-mass ions Ni, Cu, and Zn.

In 2017, Thermo Scientific announced its entry into the ICP-MS "triple quad" market, so more of these instruments will become available from different instrument companies in the future.

9.5.5 LIMITATIONS OF ATOMIC MS

The major limitations to atomic MS at this point are the inefficient introduction system to the ICP (a common problem with the ICP), matrix effects, and isobaric interference. In addition, quadrupoles are limited in sensitivity for trace amounts of light elements such as S, Cl, P, and Si due to significant interferences from C, N, and O based ions. ICP-MS cannot measure H, N, O, C, or Ar because it is open to the atmosphere and the plasma is Ar-based. Fluorine cannot be measured because of its ionization potential.

The flow rate, gas mixture, and solvent used affect formation of polyatomic species and therefore the degree of interference from polyatomic species, including refractory oxides. For reproducible results, the operating conditions must be rigorously controlled. Plasma conditions can be chosen that minimize the formation of interferences but may cause loss of sensitivity.

The isobaric interference problem can be assessed and perhaps avoided by measuring a different isotope of the analyte. That may require measuring a less-abundant isotope, reducing the sensitivity of the analysis. The use of high-resolution MS can eliminate the mass overlap problem, but the cost of such instruments is very high compared with quadrupole instruments. The use of collision cells and gas phase reaction cells in a quadrupole instrument can be used to eliminate or reduce polyatomic interferences. The new simultaneous ICP-MS from SPECTRO offers more reliable software interference corrections from simultaneous acquisition of the complete mass spectrum, while the Agilent triple quad uses the MS/MS instrumental approach to removing interferences completely.

9.5.5.1 COMMON SPURIOUS EFFECTS IN MASS SPECTROMETRY

As the foregoing discussion has noted, sample introduction for mass spectral instrumentation is done by a variety of approaches. All of these techniques can give rise to artifacts or spurious signals that must be recognized. In addition, leaks in vacuum systems can lead to spurious signals. The hyphenated methods, in which chromatographic instrumentation is used as the inlet for a mass spectrometer, can produce characteristic artifacts distinct from those present is stand-alone mass spectrometers. In the table below, we provide some of the more common spurious signals that one must watch out for (used with permission from the book by Bruno and Svoronos).

lons Observed, m/z	Possible Compound	Possible Source
13, 14, 15, 16	methane*	chlorine reagent gas
18	water*	Residual impurity; outgasing of ferrules; septa and seals.
14, 28	nitrogen*	Residual impurity, outgasing of ferrules; septa and seals; leaking seal.
16, 32	oxygen*	Residual impurity; outgasing of ferrules; septa and seals; leaking seal.
44	carbon dioxide*	Residual impurity, outgasing of ferrules; septa and seals; leaking seal; note it may be mistaken for propane in a sample.
31, 51, 69, 100, 119, 131, 169, 181, 214, 219, 264, 376, 414, 426, 464, 502, 576, 614	perfluorotributyl amine (PFTBA), and related ions	This is a common tuning compound; may indicate a leaking valve.
31	methanol	Solvent; can be used as a leak detector.
41, 43, 55, 57, 69, 71, 85, 99	hydrocarbons	Mechanical pump oil; fingerprints
43, 58	acetone	Solvent; can be used as a leak detector.
78	benzene	Solvent; can be used as a leak detector.
91, 92	toluene	Solvent; can be used as a leak detector.
105, 106	xylenes	Solvent; can be used as a leak detector.
151, 153	trichloroethane	Solvent; can be used as a leak detector.
69	mechanical pump fluid, PFTBA	Back diffusion of mechanical pump fluid; possible leaking valve of tuning compound vial.
73, 147, 207, 221, 281, 295, 355, 429	dimethylpolysiloxane	Bleed from a column or septum, often during high temperature program methods in GC-MS
77, 94, 115, 141, 168, 170, 262, 354, 446	diffusion pump fluid	Back diffusion from diffusion pump, if present.
149	phthalates	Plasticizer in vacuum seals, gloves.
X – 14 peaks	hydrocarbons	Loss of a methylene group indicates a hydrocarbon sample

PROBLEMS

- 9.1 What is meant by "molecular ion"? What is the importance of identifying it, to a
- 9.2 How are resolving power and resolution defined for a mass spectrometer?
- 9.3 What is the difference between hard ionization and soft ionization?
- 9.4 Describe how an EI source form ions from analyte molecules. Is this a hard or soft ionization source? What are the advantages and disadvantages of this source?
- 9.5 Describe how a CI source forms ions from analyte molecules. Is this a hard or soft ionization source? What are the advantages and disadvantages of this source?
- 9.6 Draw a block diagram of a typical mass spectrometer.
- 9.7 Consider an ion with z = 1. Calculate the kinetic energy added to the ion by acceleration through a potential of 1000 V in an electron ionization source. Does the kinetic energy acquired depend upon the mass of the ion? Explain.
- 9.8 In an electron ionization source, does the mass of the ion affect its velocity? Explain.

- 9.9 Describe two methods for ionizing liquid samples for mass spectral analysis.
- 9.10 Diagram a transmission quadrupole mass analyzer. What are the advantages and disadvantages of this mass analyzer compared with a double-focus mass spectrometer?
- 9.11 What resolution is necessary to differentiate between
 - a. an ion with m/z = 84.0073 and one with m/z = 84.0085
 - b. ArCl+ and As+
 - c. $C_4H_6O_2^+$ (m/z = 86.0367) and $C_5H_{10}O^+$ (m/z = 86.0731)
- 9.12 How would you expect the EI and CI mass spectra of stearyl amine (MW = 269) to differ? If the CI mass spectrum is collected using methane as a reagent gas, would you expect to see any peaks in the spectrum at m/z > 269? Explain.
- 9.13 Diagram the process that occurs in MALDI. What are the advantages of this technique?
- 9.14 Diagram a simple TOF mass spectrometer and explain how mass separation is achieved in a TOF mass analyzer. What is the advantage to a reflectron TOF over a TOF with a straight drift tube?
- 9.15 Explain the steps in an MS/MS experiment. Why are MS^n experiments valuable?
- 9.16 Diagram an ESI source and describe its uses.
- 9.17 Diagram a discrete-dynode electron multiplier and describe its operation.
- 9.18 Diagram a CEM and describe its operation.
- 9.19 What is meant by "gain" in an EM?
- 9.20 Compare the advantages and disadvantages of the Faraday cup detector and electron multipliers.
- 9.21 What is meant by FTMS? What is the most common type of FTMS instrument?
- 9.22 Compare the principles of operation, advantages, and disadvantages of the QIT and the ICR. How are they used in MSⁿ experiments?
- 9.23 Describe or illustrate the ion trajectories in an OrbitrapTM analyzer. Why do you think it is less susceptible to space-charge resolution degradation than other trap designs? Compare the acquisition of image currents in the OrbitrapTM and an FTICR instrument. Why does the longer full-scan acquisition period for maximum resolution in an FTICR require higher vacuum operation? Which is more suited for interfacing with UHPLC sample introduction? Why?
- 9.24 What fundamental properties of ions are the bases of separations in Ion Mobility Spectrometry versus all other forms of "classical" MS. Which is better for small metabolite molecule characterization and which for misfolded protein discrimination?
- 9.25 Why is a low mass IMS spectrometer easier to engineer for a cheap, simple, handheld scanner for detecting target toxic vapors, than a Quadrupole, Trap, TOF, or permanent Mag. Sector MS?
- 9.26 If the source, analyzer, and detector stages of the latter MS designs in question 9.25 could be ultra-miniaturized using silicon chip manufacture techniques (a project well under way as of this writing), how might hand-held, field-portable versions have performance superior to the IMS designs [Speculate!]
- 9.27 The long-standing problem of how to achieve atmospheric pressure vapor introduction or even more demanding liquid chromatography effluent interfacing was eventually solved by the APCI, ESI, DART etc. source designs. These employ sprays, skimmer cones, and "Differential Pumping" to separate the analytes from the matrix and present it to the higher vacuum environment required for the analyzer stage(s). Outline how these features function. Why is this less necessary for IMS spectrometers?
- 9.28 Why can the element indium not be identified definitively by atomic MS?
- 9.29 Using Appendix 9.A (textbook website), list all the Hg isotopes and their abundances and all the WO⁺ isotopes and their abundances. The discussion explains the use of the on-mass mode to remove the ²⁰²WO⁺ ion from ²⁰²Hg⁺. What other Hg ions are interfered with by WO? Is there any other way to measure Hg in the presence of WO?
- 9.30 What are the advantages of high-resolution MS for molecular MS? What are the disadvantages?
- 9.31 What are the advantages and disadvantages of high-resolution atomic MS?

- 9.32 Why is it important to understand the difference between atomic weight and exact mass in interpreting mass spectra?
- 9.33 Explain how quantitative analysis is performed using isotope dilution. What is the advantage of an isotope-labeled compound as a calibration standard?
- 9.34 Diagram an ICP-MS interface. What is the purpose of the sampler and skimmer cones?
- 9.35 Ni and Pt are the two common materials for making ICP-MS cones. What are the advantages and disadvantages of the two materials for this application?
- 9.36 Which is easier to interface to a mass spectrometer, a gas chromatograph or a liquid chromatograph? Why?
- 9.37 What mass analyzers are used for ICP-MS instruments?
- 9.38 What advantages are there to a TOF-based ICP-MS?
- 9.39 Explain the two major types of interference in atomic MS.
- 9.40 Describe two instrumental approaches for eliminating or reducing polyatomic interferences in ICP-MS.
- 9.41 Explain the difference between MS/MS on-mass and mass shift modes. When is on-mass mode used? Give an example of how this removes interferences.
- 9.42 Explain how mass-shift mode removes interferences and give an example.
- 9.43 Using the exact mass value for the monoisotopic lowest mass ion of each of the elements in Table 9.1 prepare a spreadsheet program using Excel or other spreadsheet program to construct an "exact mass calculator" for the lowest mass ion in a molecular ion cluster for any molecule of a given empirical formula containing only these atoms. Input in one line of cells the number of each kind of atom, and set up the sheet to produce the exact mass in an answer cell. Use this calculator to compute the exact mass of the monoisotopic $M^+ = 2538$ for $C_{101}H_{145}N_{34}O_{44}$ illustrated in Figure 9.47. Print and submit the sheet with the cells displaying the formulas used. How close does your value come to that on the Figure? Given the number and identity of the atoms in this molecule, what class of compound is it likely to be? [hint an important biological structure]
- 9.44 Looking at the structures in Figure 9.46 of the two very different compounds with essentially the same EI mass spectrum, draw the structure of each with a crossing the bond that breaks to form each of the major fragment ions, and put their mass on each side of the break symbol.
- 9.45 If one of the candidate hits in Figure 9.46 had one sulfur atom, how could you identify it? Would this be easier or harder if the odd atom were Cl? Br? Suppose these hypothetical heteroatoms were at different positions in the molecules (structural isomers). Would the MS spectra always still be hard to distinguish? What information could you use to locate the position of the heteroatom on the backbone?
- 9.46 Using your exact mass calculator, what is the difference in exact masses of the M+ monoisotopic ions of each candidate in Figure 9.46? What MS resolution would you require to distinguish between these?
- 9.47 Given the compound formula in Figure 9.48, try to devise a spreadsheet employing both the number of each of the different atoms in the formula and their % abundances. Design this to calculate the exact proportions of each ion in the molecular ion cluster (i.e., M+, M++1, M++2, M++3) that gives the theoretical spectrally accurate relative proportions for each ion in the cluster. The CERNO algorithm corrects and matches the acquired mass spectrum to this, in order to find the closest matches at high resolution (along with the separately calculated value of high mass accuracy for the monoisotopic, lowest mass ion in the cluster).

BIBLIOGRAPHY

Alexander, M.L.; Hemberger, P.H.; Cesper, M.E.; Nogar, N.S. Laser desorption in a quadrupole ion trap: mixture analysis using positive and negative ions. *Anal. Chem.* 1993, 65, 1600 Application Reviews. *Anal. Chem.* 1993, *June.*

Barker, J. Mass Spectrometry: Analytical Chemistry by Open Learning, 2nd; Wiley: Chichester, UK, 1999.

Barnes, J.H. IV; Hieftje, G.M.; Denton, M.B.; Sperline, R.; Koppenaal, D.W.; Baringa, C. A mass spectrometry detector array that provides truly simultaneous detection. *Am. Lab* 2003, *October*, 15.

Becker, J.S. *Inorganic Mass Spectrometry: Principles and Applications*; John Wiley and Sons, Ltd.: Chichester, UK, 2007.

Blades, M.W. Atomic mass spectrometry. *Appl. Spectrosc.* 1994, 48 (11), 12A. (Reprinted in *Focus on Analytical Spectrometry*; Holcombe, J.A., Hieftje, G.M., Majidi, V., Eds.; Society for Applied Spectroscopy: Frederick, MD, 1998 (www.s-a-s.org).)

Borman, S.; Russell, H.; Siuzdak, G. A mass spec timeline. *Today's Chemist at Work*, September 2003, 47 (www.tcawonline.org).

Broekaert, J.A.C. Glow discharge atomic spectroscopy. *Appl. Spectrosc.* 1995, 49 (7), 12A. (Reprinted in *Focus on Analytical Spectrometry*; Holcombe, J.A., Hieftje, G.M., Majidi, V., Eds.; Society for Applied Spectroscopy: Frederick, MD, 1998 (www.s-a-s.org).)

Buchanan, M.V.; Hettich, R.L. Fourier transform mass spectrometry of high-mass biomolecules. *Anal. Chem* 1993, 65 (5), 245.

Busch, K.L. Units in mass spectrometry. Current Trends in Mass Spectrometry (Spectroscopy Magazine), 18 (5S), May 2003, S32 (www.spectroscopyonline.com).

Bruno, T.J.; Svoronos, P.D.N. CRC Handbook of Basic Tables for Chemical Analysis – Data Driven Methods and Interpretation; CRC Press: Boca Raton, FL, 2021.

Caprioli, R.M. Continuous flow FAB MS. Anal. Chem 1990, 62 (8), 177A.

Cody, R.N.; Tamura, L.; Musselman, B.D. Electrospray ionization/magnetic sector MS calibration and accuracy. *Anal. Chem.* 1992, 64, 1561.

Chong, N.S.; Houk, R.S. Appl. Spectrosc. 1987, 41, 66.

Cole,, Electrospray and MALDI Mass Spectrometry, Wiley, New York, 2010

Dass,, Fundamentals of Contemporary Mass Spectrometry, Wiley, New York, 2007

De Hoffman, Mass Spectrometry - Principles and Applications, 3rd; Wiley: New York, 2007.

Duncan, W.P. Res. Dev. 1991, April, 57.

Eiceman, Ion Mobility Spectrometry, 3rd; Taylor & Francis: Boca Raton, 2013.

Ewing, G.W. Mass spectrometry. In *Analytical Instrumentation Handbook*, 2nd; Ewing, G.W., Ed.; Marcel Dekker, Inc: New York, 1997.

Fenn, J.B.; Mann, M.; Meng, C.K.; Wong, S.E.; Whitehouse, C. Science 1989, 64, 246.

Finnigan, M. Anal. News, 1990, February.

Fuerstenau, S.D., et al. Angew. Chem. Intl. Ed. 2001, 40, 541.

Geiger, W.M.; Raynor, M.W. ICP-MS: A universally sensitive GC detection method for specialty and electronic gas analysis. *The Application Notebook (Spectroscopy Magazine supplement)* February 2009 (www.spectroscopyonline.com).

Goldner, H.J. Electrospray excites scientists with its amazing potential. R&D Mag. 1993, 10, 43.

Gross, J.H., *Mass Spectrometry – A Textbook*, Springer VCH, Berlin, 2011.

de Hoffmann, E.; Stroobant, V. Mass Spectrometry: Principles and Applications, 2nd; John Wiley and Sons LTD: Chichester, 1999.

Holmes, J.L.; Aubry, C.; Meyer, P.M. Assigning Structures to Ions in Mass Spectrometry; Taylor & Francis: Boca Raton, 2006.

Jarvis, K.E.; Gray, A.L.; Houk, R.S. *Handbook of Inductively Coupled Plasma Mass Spectrometry*; Blackie: London, 1992.

Karas, M.; Bahr, U. Trends Anal. Chem. 1990, 9, 323.

Karas, F.H.; Beavis, R.C.; Chait, B.T. Matrix-assisted laser desorption ionization mass spectrometry of biopolymers. *Anal. Chem* 1991, 63 (24), 1193A.

Knight, A.K.; Sperline, R.P.; Hieftje, G.M., et al. Int. J. Mass Spectrom. 2002, 215, 131.

Kraj, A.; Silberring, J. Eds., Introduction to Proteomics; Wiley: New York, 2008.

Lambert, J.B.; Shurvell, H.F.; Lightner, D.; Cooks, R.G. *Introduction to Organic Spectroscopy*; MacMillan Publishing Company: New York, 1987.

Le Cornec, F.; Correge, T. A New Internal Standard Isotope Dilution Method for the Determination of U/Ca and Sr/Ca ratios in fossil corals by ICP-MS. Varian ICP-MS Applications Note ICP-MS-18, September 1998. (Varian is now Agilent Technologies and the Varian Application Notes are no longer available).

Lovric, J.. Introducing Proteomics, From Concepts to Sample Separation, Mass Spectrometry and Data Analysis; Wiley-Blackwell: Oxford UK, 2011.

March, Quadrupole Ion Trap Mass Spectrometry, 2nd; Wiley: New York, 2005.

McCann, M.T.; Thompson, M.M.; Gueron, I.C.; Tuchman, M. Clin. Chem. 1995, 41/5,739-743.

McLafferty, F.W.; Tureček, F. *Interpretation of Mass Spectra*, 4th; University Science: Mill Valley, CA, 1993.

Mahoney, J.; Perel, J.; Taylor, S. Primary ion source for FABMS. Am Lab. 1984, March, 92.

Milstein, L.S.; Essader, A.; Fernando, R.; Akinbo, O. Environ. Int 2002, 28 (4), 277–283.

Milstein, L.S.; Essader, A.; Murrell, C.; Fernando, R.; Akinbo, O. JOAC 2003a, 51 (15), 4180–4184.

Milstein, L.S.; Essader, A.; Fernando, R.; Levine, K.; Akinbo, O. Envr. Health Persp 2003b, 111 (3), 293-296

Montaser, A., Ed. Inductively Coupled Plasma Mass Spectrometry; VCH: Berlin, 1998.

Niessen, W.M.A.; van der Greef, J. *Liquid Chromatography–Mass Spectrometry*; Marcel Dekker, Inc.: New York, 1992.

NIST Mass Spec Data Center. Mass spectra. In NIST Chemistry WebBook, NIST Standard Reference Database Number 69; Lindstorm, P.J., Mallard, W.D., Eds.; NIST: Gaithersburg, MD, March 2003 20899

Oxley, E.S.; Stremming, H.; Paplewski, P. Ultra-low hydrogen detection in steel. *Bruker FIRST Newsletter*, Bruker Corporation, May 2012 (www.bruker-axs.com).

Pavia, D.L.; Lampman, G.M.; Kriz, G.S. *Introduction to Spectroscopy: A Guide for Students of Organic Chemistry*, 3rd; Harcourt College Publishers: Fort Worth, TX, 2001.

Richards, S. Proteome Portraits, The Scientist, August 2012.

Ridd, M. Determination of trace levels of rare earth elements in basalt by ICP-MS. Varian ICP-MS Applications Note ICP-MS-2, April 1994 (Varian is now Agilent Technologies and the Varian Application Notes are no longer available).

Sevastyanov, V. Isotope Ratio Mass Spectrometry; Taylor & Francis: Boca Raton, 2013.

Silverstein, R.M.; Webster, F.X. Spectrometric Identification of Organic Compounds, 6th; Wiley: New York, 1981.

Skelly Frame, E.M.; Uzgiris, E.E. The determination of gadolinium in biological samples by ICP-AES and ICP-MS in evaluation of the action of MRI agents. *Analyst* 1998, *123*, 675–679.

Smith, R.D.; Wahl, J.H.; Goodlett, D.R.; Hofstadler, S.A. Anal. Chem 1993, 65 (13), 574 A.

Smith, R.M.; Busch, K.L. Understanding Mass Spectra-A Basic Approach; Wiley: New York, 1999.

Sparkman, O.D. Mass Spectrometry Desk Reference; Global View Publishing: Pittsburgh, PA, 2000.

Svartsburg,, Differential Ion Mobility Spectrometry, Taylor & Francis, Boca Raton, 2008

Thomas, R. Practical Guide to ICP-MS, 2nd; Taylor & Francis: Boca Raton, 2011.

Van Haecke, F.; Degryse, P., Eds. Isotopic Analysis: Fundamentals and Applications Using ICP-MS; Wiley-VCH Verlag & Co. KGaA: Weinheim, Germany, 2012.

Voreos, L. Electrospray mass spectrometry. Anal. Chem 1993, 66 (8), 481A.

Watson, J.T.; Sparkman, O.D. Introduction to Mass Spectrometry, 4th; John Wiley and Sons Ltd: Chichester, 2007.

Wolf, R.; Denoyer, E.; Grosser, Z. *EPA Method 2008 for the Analysis of Drinking Waters, Application Note ENVA-300*; PerkinElmer Life and Analytical Sciences, Shelton, CT, July 1995.

Wolf, R.; Denoyer, E.; Sodowski, C.; Grosser, Z. RCRA SW-846 Method 6020 for the ICP-MS Analysis of Soils and Sediments, Application Note ENVA-301; PerkinElmer Life and Analytical Sciences, Shelton, CT, January 1996.

Wilkins, C,L. *Ion Mobility Spectrometry-Mass Spectrometry*, Taylor & Francis, Boca Raton, 2010 Yarnell, A. The many facets of man-made diamonds. *Chem. Eng. News* 2004, 82 (5), 26.

Principles of Chromatography

10

10.1 INTRODUCTION TO CHROMATOGRAPHY

Many of the techniques of spectroscopy we have discussed in preceding chapters are selective for certain atoms or functional groups and structural elements of molecules. Often this selectivity is insufficient to distinguish compounds of closely related structure from each other. It may be insufficient for measurement of low levels of a compound in a mixture of others which produce an interfering spectral signal. Conversely, when we wish to measure the presence and amounts of a large number of different compounds in a mixture, even the availability of unique spectral signatures for each analyte may require laborious repeated measurements with different spectral techniques to characterize the mixture fully. Living systems have evolved large protein molecules (e.g., receptors, enzymes, immune system antibodies) with unique 3D structures which can bind strongly only to very specific organic compounds. Analytical procedures such as immunoassay, enzyme mediated assays, and competitive binding assays, employ the extreme selectivity of such protein macromolecules to measure particular biomolecules in very complex mixtures. Microarrays of thousands of these, each with unique selectivity, can rapidly screen complex mixtures for a list of expected components. However, precise quantitation of each detected component is difficult to achieve this way.

Analysis of complex mixtures often requires separation and isolation of components, or classes of components. Examples in non-instrumental analysis include extraction, precipitation, and distillation. These procedures partition components between two phases based on differences in the components' physical properties. In liquid-liquid extraction, components are distributed between two immiscible liquids based on their similarity in polarity to the two liquids (i.e., "like dissolves like"). In precipitation, the separation between solid and liquid phases depends on relative solubility in the liquid phase. In distillation, the partition between the mixture liquid phase and its vapor (prior to recondensation of the separated vapor) is primarily governed by the relative vapor pressures of the components at different temperatures (i.e., differences in boiling points). When the relevant physical properties of the two components are very similar, their distribution between the phases at equilibrium will result in slight enrichment of each in one of the phases, rather than complete separation. To attain nearly complete separation the partition process must be repeated multiple times, and the partially separated fractions recombined and repartitioned multiple times in a carefully organized fashion. This is achieved in the laborious batch processes of countercurrent liquid liquid extraction, fractional crystallization, and fractional distillation. The latter appears to operate continuously, as the vapors from a single equilibration chamber are drawn off and recondensed, but the equilibration in each of the chambers or "plates" of a fractional distillation tower represents a discrete equilibration at a characteristic temperature.

A procedure called **chromatography** automatically and simply applies the principles of these "fractional" separation procedures. Chromatography can separate very complex mixtures composed of many very similar components. The various types of chromatographic instrumentation which have been developed and made commercially available over the past half century now comprise a majority of the analytical instruments for measuring a wide variety of analytes in mixtures. They are indispensable for detecting and quantitating trace contaminants in complex matrices. A single chromatographic analysis can isolate, identify, and quantitate dozens or even hundreds of components of mixtures. Without their ability

to efficiently characterize complex mixtures of organic biochemicals at trace levels from microscale samples, research in molecular biology as we know it today would be impossible. We will be discussing another powerful separation technology, **electrophoresis**, together with chromatography, because much of the way electrophoresis operates, and the appearance of its separations, is analogous to chromatography, even though the underlying separation principle is different. Chromatographic-type separation is at the heart of earlier generations of the instrumentation used to separate fragmented DNA molecules and to sequence the order of the "bases" which form the genomes of all living creatures on Earth. The heroic sequencing of around 3 billion DNA bases in the human genome, completed in the year 2001, could never have been envisioned, let alone completed, without chromatographic-type instrumentation. This forms the basis of the new field of *genomics*. Even more extensive analytical separation, identification, and quantitation problems arise in the next new field of molecular biological research, coming in the so-called "post-genomic" era; namely, proteomics. This requires separation, identification, and quantitation of the thousands of proteins that may be produced ("expressed") by the genome of each type of living cell. The contents and proportions of this mix will depend on what the cell is doing, and whether it is in a healthy or diseased state. The amounts of analytes may be at the nanomolar scale or less, and unlike DNA analysis, there is no handy polymerase chain reaction (PCR) procedure to amplify the amounts of analytes. If genomics provides a complete parts list for an organism, then proteomics will be necessary to understand the assembly and operating manual. Another "-omics" field, metabolomics, studies the complete array of relatively small polar metabolite molecules in blood circulation and urinary excretion, and employs ultra-fast liquid chromatography columns interfaced to very fast scanning MS or MS/MS instrumentation monitored by fast computer matching to libraries of known metabolites (and sometimes even identifying heretofore unknown metabolites).

Billions of dollars of chromatography-based instrumentation, and hundreds of thousands of jobs using it, will be required for research in these fields. Environmental monitoring and regulation are already a multimillion-dollar market which uses chromatography's ability to isolate, identify, and measure trace pollutants in complex environmental mixtures.

10.2 WHAT IS THE CHROMATOGRAPHIC PROCESS?

The Russian botanist Mikhail Tswett invented the technique and coined the name chromatography. Early in the 20th century he placed extracts containing a mixture of plant pigments on the top of glass columns filled with particles of calcium carbonate. Continued washing (elution) of the mixtures through the columns with additional solvent (called the eluent) resulted in the separation of the pigments, which appeared as colored bands adsorbed on the solid particles, moving along the column at different rates, thus appearing at different distances down the column. He named this technique "chromatography", from the Greek for "color writing". An example of this is shown in Figure 10.1. By collecting separated components as they exited the bottom of the column, one could isolate pure material.

If a detector in the exiting fluid stream (called the **effluent**) can respond to some property of a separated component other than color, then neither a transparent column nor colored analytes are necessary to separate and measure materials by "chromatography".

When there is a great difference in the retention of different components on the material filling the column, a short column can be used to separate and isolate a rapidly moving component from highly retained material. This is the basis of a useful sample preparation technique called **solid phase extraction (SPE)**, described in Chapter 1.

Real instrumental chromatography employs highly engineered materials for the **stationary phase** past which the **mobile phase** fluid carrying the mixture of analytes passes, with continuous partitioning of the analytes between the two phases. The column needs to be sufficiently long and the eluent flow sufficiently slow for the process to approach equilibrium conditions. Then, partitioning will be repeated a large number of times. Even very slight differences among mixture components in the ratio of the amounts which would exist in each phase at equilibrium will result in their separation into bands along the column. These bands can be separately detected or collected as they elute off the column.






FIGURE 10.1 (a) Schematic example of separation of colored compounds using a packed column. The initial mixture is the dark color at the top of the column on the left. Looking from left to right, one sees the colored components both separating and eluting down the column as eluent is added. **(b)** An actual packed column with eluting bands of colored compounds. (Modified from Alexiots A. Zlatich - own work, CC BY-SA 3.0, https://commons.wikimedia.org/w/index.Php?curid=36387464.)

The critical defining properties of a chromatographic process are:

- 1. Stationary and mobile phases
- 2. An arrangement whereby a mixture is deposited at one end of the stationary phase
- 3. Flow of the mobile phase toward the other end of the stationary phase
- 4. Different rates or ratios of partitioning for each component of the mixture, and many cycles of this process during elution
- 5. A means of either visualizing **bands** of separated components on or adjacent to the stationary phase, or of detecting the eluting bands as **peaks** in the mobile phase effluent. Here we emphasize that peaks are traces of electronic detector responses to the eluting analyte bands exiting the separation column. Often chromatographers use the word peak to refer to the band itself. This more common usage is acceptable, and the distinction between bands and peaks is useful mainly to clarify how the former gives rise to the latter. Mostly we observe peaks in chromatography. In some applications the bands are also referred to as **zones**.

The first major implementation of instrumental chromatography was based on partition between a liquid, nonvolatile, stationary phase supported on inert solid particles packed in metal columns, and an inert gaseous mobile phase flowing through the column from a pressurized tank. The various partition ratios between the phases, which affected separation, were primarily related to the components' different volatilities (i.e., boiling points). The initial application of this procedure, **gas chromatography (GC)**, to petroleum hydrocarbon




FIGURE 10.2 (a) A schematic gas chromatography instrument, showing carrier gas, column, oven, injection port and detector. (b) A modern GC instrument with autosampler, the Shimadzu GC-2030. [(b) Courtesy of Shimadzu Corporation, Kyoto, Japan, www.ssi.shimadzu.com.] Details of the instrumentation will be discussed in Chapter 11.

samples, led to facile separation of many more components than could be achieved by the fractional distillation process used in petroleum refining. A schematic GC instrument is shown in Figure 10.2. The inert mobile phase (carrier gas) is in the pressurized tank on the left, the packed column is shown curled inside an oven. Sample is injected through the injection port and is carried through the column to a detector.


Instead of just petroleum "fractions", individual specific hydrocarbons could be resolved and isolated, if the GC column was long enough. The analogy to the well-studied theory of multiple plate fractional distillation columns used in refining processes led to the initial plate theory of the chromatographic process. This assumed that the separation of the bands as they migrated down the column proceeded as a series of sequential, discrete equilibrium partitionings, instead of the actual situation, which is a continuous, not-quite-in-equilibrium process. Nevertheless, this **plate theory** proved fairly accurate for most cases. It contained useful terms [e.g., N = the number of plates in a column as a descriptor of its separation efficiency, and the "height equivalent to a theoretical plate" (HETP)]. These remain central to the simplified theoretical characterization of the chromatographic process, despite the fact that continuous, non-equilibrium kinetic (or rate) theory is more accurate, and there exist no actual plates in a chromatographic column. GC was not suitable for separation and measurement of more polar and less volatile compounds or less thermally stable large biomolecules. Optimized chromatographic separations of these types of molecules at ambient

temperatures were achieved later using more polar, water miscible liquid mobile phases. The instruments and stationary phases which enabled this improvement on the traditional vertical **gravity column LC** apparatus, form the basis of the even more widely used **high-performance liquid chromatography** or **HPLC**.

10.3 CHROMATOGRAPHY IN MORE THAN ONE DIMENSION

In GC, the gaseous mobile phase must be confined in a column, so that a pressure gradient can cause it to flow past the stationary phase and eventually elute the separated bands out at the effluent end of the column. This is inherently a 1D separation, along the column, from one end to the other. This dimensionality applies even should the column be coiled to fit in a GC oven rather than vertically straight, like Tswett's gravity flow liquid mobile phase column. However, unlike gases, liquids as mobile phases do not always require confinement to move in a desired direction or retain their volume. If they are in contact with porous beds of small particles or fiber mats, surface forces (capillary attraction) can often induce them to flow. Thus, it is possible to carry out the LC process on a stationary phase arrayed as a thin surface layer, usually a planar 2D surface. Examples include the matted cellulose fibers of a sheet of paper, or a thin layer of silica gel or alumina particles on a planar support (e.g., a pane of glass).

An example of paper chromatography, beloved of grade-school science fairs for its simplicity, is to place a drop of colored ink in the center or at one end of a sheet of paper. After drying, a series of drops of organic solvent are slowly added to the spot. Capillary attraction causes a radial eluent flow away from the spot in all directions. The different colored dyes in the ink adhere more or less strongly to the multiple hydroxyl groups on the cellulose molecule chains through polar or hydrogen-bonding interactions. Therefore, the capillary eluent flow carries some dyes further than others, resulting in a pattern of colored circles of different radii, if the ink was in the center of the paper, or a series of bands if the ink was at the edge of the paper (Figure 10.3). This recreates Tswett's original 1D column chromatography








FIGURE 10.3 (a) Schematic separation of ink dyes using paper chromatography. (b) Paper chromatography separation of black ink dyes.

experiment on a 2D surface using his original definition. Being on a piece of paper, it seems even more like "color writing".

The radial separation in the earlier example is not the most efficient way to perform surface chromatographic separations. A square planar **thin layer chromatography (TLC)** plate (not to be confused with the "theoretical plates") may have a line of spots containing sample mixtures and reference standard materials deposited just above one edge. Submerge that edge in solvent to a level just below the line of spots, and capillary attraction will produce a unidirectional, ascending, eluent flow which will move and separate each spot's components vertically up the plate in separate **lanes**. If they are not already colored, they may be sprayed with a reagent which will react to "develop" a color, just as a photographic plate may be developed chemically to reveal a latent image. Alternatively, the separated component spots may be visualized, or even quantified, by observing their fluorescence emission induced by exposing them to UV light, or by their quenching of the natural fluorescence of a silica gel TLC layer. Note that an advantage to this form of surface chromatography is that multiple 1D (i.e., in one direction) chromatographic separations of samples or standard mixtures are carried out simultaneously in parallel.

If a mixture has enough components, and some are sufficiently similar in structure and physical properties, it is likely that chromatography in one dimension, either on a column or a surface, will not separate all of them from each other. Many column bands or surface spots will contain multiple unseparated components. These are said to co-elute in the chromatographic system. If we repeat the previous TLC plate separation, but this time place just one spot containing a mixture to be separated near one corner of the plate, we will again achieve a line of eluted spots in a lane along a vertical edge. Some of these spots may contain still unseparated, coeluting components. Now let us rotate the plate ninety degrees and place this line of separated spots back in the tank just above a new eluting solvent with polarity or pH or some property very different from the first solvent. This will elute each of the partially separated spots from the first chromatographic separation vertically up the plate perpendicular (or orthogonal) to the initial separation dimension. If the nature of the solvent used for the second, orthogonal elution produces different stationary/mobile phase partition ratios for components that coeluted in spots from the first separation, they will now separate in the dimension perpendicular to that of the first chromatographic separation. This is an example of true 2D chromatography. It is most easily achieved in the planar surface mode described here. A 2D column chromatography instrument, necessary for 2D GC separations, requires more complex hardware. The effluent from one column may be sampled one time, or in continuous segments, by a device which collects, reconcentrates, and redirects it to a second column. The second column must have separation selectivity different from the first one. If the coeluting components in just a single peak isolated from the first column are separated on the second one, the procedure is heart-cutting, 2D chromatography. If segments of the effluent from the first column are continuously and very rapidly separated by the second column at a pace matching that at which they are sampled, the resulting detector signal may be transformed by computer to yield **comprehensive 2D chromatograms**, displayed as a planar array of spots like those observed directly on the TLC plate. These examples of multidimensional chromatography should not be confused with the use of a spectroscopic detector (e.g., a mass spectrometer at the end of a GC column, or a UV/VIS diode array spectrometer monitoring the effluent of a liquid chromatograph). Such hyphenated systems, so called from their abbreviations such as GC-MS or LC-diode array, are said to add a second spectral dimension to the initial chromatographic separation. If components coeluting in a chromatographic peak have sufficiently different spectral characteristics, they may be measured separately in the peak despite their co-elution.

10.4 VISUALIZATION OF THE CHROMATOGRAPHIC PROCESS AT THE MOLECULAR LEVEL: ANALOGY TO "PEOPLE ON A MOVING BELT SLIDEWAY"

Molecules undergoing chromatographic separation may be likened to people standing on a moving slideway, such as those which transport people between terminals in an airport. Imagine a very broad moving belt, capable of accepting a large number of passengers across its width, with no side rails to prevent them from stepping on and off along its length. If several ranks of people step on together at one end and rigidly hold their positions, the group will proceed to the end in the formation in which it boarded. This is like a crystalline particle suspended in a mobile phase flowing down a column. The time, $t_{\rm m}$, taken to transit the belt or column is the product of the speed of the belt and the length of the belt. If the people are free to mill about while on the belt, like molecules dissolved in a flowing mobile phase, they will tend to spread out along the length of the belt as they transit. The narrow, compact band of people/molecules which was put on at the head of the belt/column becomes increasingly wider, and the degree of spread is proportional to the time elapsed before the exit is reached. In the case of a narrow band of molecules, this spreading occurs by a process of **random diffusion**, resulting in a **Gaussian-like distribution** about the mean, producing a peak with the "bell-shaped curve" familiar from statistics. The center, and maximum, concentration of people/molecules still travels at the velocity of the belt/mobile phase. Note that the peak shape can never be truly Gaussian because of both thermodynamic and mass-transfer influences.

Now, imagine that during their progress down the belt/column, the people/molecules can step-on-and-off/partition to the nonmoving floor/stationary phase. This happens continuously, rapidly, and repeatedly during the trip. During their visits to the floor/stationary phase, they are delayed from moving toward the exit, so they come off the belt/column later than if they had spent all their time on it. We can characterize the extent of the effect of the interaction between the people/molecules and the floor/stationary phase by the **adjusted retention time**: $t_{\rm r}' = t_{\rm r} - t_{\rm m}$, where $t_{\rm m}$ is the time it takes people/molecules not getting-on-and-off/partitioning to go from one end to the other, and $t_{\rm r}$ is the time required when these processes take place. The elution of a solute through a GC column is shown schematically in Figure 10.4.

Imagine we have two different categories of people (e.g., people in purple shirts and people in gold shirts) in our initial compact group at the start, and the purple shirts are slightly more inclined than gold shirts to linger on the floor when they step off the moving slideway. On average, the gold shirts will reach the end of the system sooner, and their t_r and t_r' times will be shorter. If the tendency of the purple shirts to linger is sufficiently greater than that of the




FIGURE 10.4 Schematic elution of a solute through a GC column. (Modified from Scott. R., Introduction to analytical gas chromatography, ©1998 Marcel Dekker, Inc. Used with permission.)

10.5 THE CENTRAL ROLE OF SILICON-OXYGEN COMPOUNDS IN CHROMATOGRAPHY

Elemental silicon is central to the vast industry of solid-state electronics. Appropriately doped with other elements it forms a variety of semiconductors that constitute most transistors and integrated circuits. Other elements and compounds such as germanium or gallium arsenide have also found a niche as semiconductors in electronics, but silicon occupies the prime position. How fortunate that it is the second most abundant element in the Earth's crust. Its compounds with the most abundant crustal element, oxygen, are equally central in many different aspects of chromatography. Silica, silica gel, glass, quartz, fused silica, silicones—all have a remarkable variety of key roles to play in chromatography. Let us familiarize ourselves with some of their relevant properties.

Crystalline silicon dioxide, SiO₂, *quartz*, is a transparent, very high melting, 3D network of silicon—oxygen tetrahedra. When melted and cooled it forms a noncrystalline, high-melting glass known as *fused silica*. This no longer has the regular crystalline lattice of quartz. Being a glass, it can easily be drawn while molten into long fibers. If other elements, such as calcium, sodium, or boron are mixed in, the lower melting glasses can be more easily shaped, blown, molded, and so on. Their transparency, moldability, and ability to be ground and polished lead to many applications in optics, which are well represented in optical spectroscopic instrumentation. Their resistance to heat and most chemical reagents make them the primary material for the vessels in which chemists perform and observe reactions. In chromatography, the lower melting glasses with their guest atoms in the silica structure are generally less desirable than pure silica.

Silica can also be precipitated from aqueous solutions of silicic acid, H₄SiO₄. Quartz forms in nature from very slow hydrothermal crystallization from hot solutions under great pressure deep underground. A more porous open structure called *silica gel* can be precipitated quickly in the laboratory. Particles of this can be coated as the stationary phase on a glass substrate to prepare one of the most useful types of TLC plates. A vast variety of very pure, monolithic, or porous silica particles, as carefully controlled monodisperse spheres (all about the same dimension, 3-50 µm in diameter) can be synthesized for use as supports for the liquid-like stationary phase of packed columns in GC or LC. At the surface of silica, those oxygen atoms which are attached to silicon by only one bond generally have an H atom as the other bond. The resulting —Si—OH on the surface of silica interacts with water both by polar and hydrogen-bonding interactions to bind it tightly (this moiety is usually called a silanol group). Thus, unless vigorously heated and kept in a very dry environment, silica has a bound surface layer of adsorbed water. This may serve as the very polar stationary phase in a chromatographic system. Many early simple gravity flow liquid-solid column chromatography systems employed silica or similar particles such as alumina (Al₂O₃). Non-polar compounds could be separated on such a polar stationary phase by eluting with and partitioning between a less polar, water-immiscible mobile phase. This is called "normal phase" chromatography.

The great majority of molecules we want to separate by LC are polar organic molecules, which are more suitably eluted in an aqueous mobile phase against a less-polar stationary phase than "bare" silica or alumina. We can still use the array of specially tailored silica particles. We simply replace adsorbed water by chemically attaching a less-polar organic substituent, such as a long hydrocarbon chain, to the dangling —OH groups on the silica surface. Using this method, we have replaced very polar water adsorbed by hydrogen bonding to the silica surface silanol groups with nonpolar hydrocarbon. Since such columns reverse the relative polarity of the stationary and mobile phases from what used to be considered "normal" for column chromatography, this is called "reversed phase" LC. It becomes increasingly difficult to force more of these large chains to attach to every last — OH group on the silica surface, so some OH sites are left uncovered. Analytes penetrating the less-polar stationary phase layer during the chromatographic partitioning process may burrow down to bind strongly to these "active" sites. They are the "chairs" of our slideway analogy. They can be deactivated and blocked by reacting with a small molecule reagent




FIGURE 10.7 (a) Schematic cross section of a capillary column. (b) Schematic of a fused silica open tubular column for chromatography.

that attaches as a methyl group, a process called **end capping**. Glass or silica columns, or particular supports with which a stationary phase is coated but not chemically bonded, are similarly pretreated to deactivate all such sites which could cause tailing peaks. As the pH of an aqueous mobile phase in LC increases (becomes more basic), the higher mobile phase [OH-] concentration combines with the H on the surface of —Si—OH, and at high enough pH slowly dissolves and destroys the silica surface and its attached stationary phase. To operate at high pH, a more resistant substrate, such as *zirconia*, ZrO₂, or the use of polymer resins, is required.

Chromatographers learned that coating a stationary phase inside a long narrow tube of *capillary dimension* (i.e., internal diameter about 0.1-1.0 mm) yielded exceptionally efficient separations, especially for GC. Metal capillaries were replaced by glass, which was more inert. Glass still had some activity due to its dissolved metal ions, and was brittle and broke easily when being installed into instruments. The billion-dollar fiber optic communication industry learned to draw fibers from rods of extremely pure silica, which absorbed light much less than glass, and was much more flexible when incorporated in fiber optic cable bundles. If an open tube of such pure fused silica were drawn by similar machinery, an inert, flexible capillary perfectly suited for supporting a chromatographic stationary phase was formed (Figure 10.7). A deliberate scratch across the capillary allows it to be broken cleanly by hand to a desired length. Protection against inadvertent scratches which might induce unwanted breaks is provided by fusing a high-temperature resistant *polyimide coating* to the outside of the capillary. As a result, instead of appearing clear, fused silica capillary tubing for chromatography has a brown to golden hue (Figure 10.8).

The separation technique of CZE has no stationary phase deposited or bonded to the interior of the capillary. As discussed, it is not a chromatographic process, but it yields a separation into bands or peaks in a fashion that looks much like chromatography. The —Si—OH on the surface actually begins to lose some H⁺ at pH above 2, so the silica surface becomes more and more negatively charged with —Si—O⁻ units as the pH rises. As we will see, in capillary electrophoresis (CE), a high electrical voltage between the ends of the capillary causes charged analytes to move in different directions at different speeds through the aqueous solvent. Because of the charge on the silica surface, the solvent as a whole move from one end of the capillary to the other, carrying the separating charged analytes past a detector and out of the column, even those which move in a direction opposite to the solvent flow.

When charges flow through a CE column, great frictional heat is released. This could result in excessive band broadening and loss of resolution. Fused silica has much higher heat





FIGURE 10.8 (a) A commercial glass capillary column for gas chromatography. (b) Close-up of a fused silica capillary column. (Both courtesy of Restek corporation, Bellefonte, PA., www.restek. com. Used with permission.)

conductivity than glass, and the small diameters and thin walls of the capillaries enable this heat to be efficiently dissipated to a surrounding bath. Conversely, when used for GC, a fused silica chromatographic column rapidly equilibrates with temperature changes produced by the column oven.

Finally, chains of alternating silicon and oxygen form the backbone of a class of polymers called *silicones*, whose temperature stability and variable polarity make them the workhorse of GC stationary phases. Their general structure is:

where R_1 , R_2 and R_3 are organic groups.

If R_1 and R_2 are both methyl groups, this is **polydimethylsiloxane** (**PDMS**), the most widely used silicone polymer. If the chains are much longer than the 5 unit one illustrated here, the material is very viscous and nonvolatile. It can be coated on silica particles or on the

wall of a fused silica capillary. It will dissolve small molecules and partition them to liquid or gaseous mobile phases. Changing the R-groups will affect the polarity of the polymer and thus the relative separability of pairs of molecules dissolving in it. The silicon-oxygen backbone is more resistant to higher temperatures than many other polymers used as stationary phases. At high-enough temperatures, the ends of the chains can cyclize with themselves to successively shorten the chain by losing 4 or 5-membered rings of $-\text{Si}(R_x)_2$ —O. Substituting a bulky aromatic hydrocarbon group for occasional O atoms in the chain can interrupt this decomposition and make a phase with a higher temperature limit. Reactive functional groups on some of the R-groups can cross-link the polymer chains and bond them to -Si-OH on the silica support to further increase phase stability. The remaining -Si-OH on the silica surface can then be reacted with reagents like trimethylchlorosilane to deactivate them to $-\text{Si}-\text{O}-\text{Si}-(\text{CH}_3)_3$.

The majority of HPLC columns are packed with very highly engineered, spherical, **monodisperse** (very narrow diameter range) silica support particles, 1.7-10 µm in diameter, with an interior network of much smaller scale passages or **pores** permeating them (cf. Figure 12.2). These greatly increase the surface area for bonding the adsorption coatings, thereby increasing analyte capacity. The depth that analytes must travel in and out of these pores adversely affects the equilibration of these materials with the flowing liquid mobile phase and degrades column resolution. A further refinement of particle structure puts a porous layer (~20-40 % of its radius) on the surface above an impermeable solid core. Such **core-shell** particles have much better resolution than fully porous particles of the same diameter, while retaining adequate sample capacity. They can be operated at lower LC pump pressures than columns packed with the smaller particles, while approaching the latter's performance. Columns using particles at the lowest end of the above diameter range or with core-shell structure give rise to such improved performance that they define UHPLC (*ultra*-high-performance LC), which has already taken over more than 50 % of the LC market.

10.6 BASIC EQUATIONS DESCRIBING CHROMATOGRAPHIC SEPARATIONS

We will state or derive a bare minimum of the equations most useful for understanding and describing how the most easily measured or controlled variables affect separations in chromatography. Many of the factors in these equations can be derived or calculated from more fundamental parameters, such as diffusion coefficients of analytes in the two chromatographic phases, column dimensions, or variables defined in the statistical theory of random variation. Such details are covered in more advanced texts.

The chromatographic process for a component X is governed by its **equilibrium partition ratio**, K_x , (also called the *distribution ratio*). This is the ratio of its concentrations at distribution equilibrium between the two immiscible phases [(A) in Equation 10.1]. In chromatography, these immiscible phases are the stationary phase (s) and the mobile phase (m). In the chromatographic separation process, we are not interested so much in knowing the ratio of concentrations in each phase as in the ratio of the amounts. These are related to volumes of each phase at each point along the separation path [(B) and (C) in Equation 10.1]. We define the amount ratios and volume ratios in expression (C) by the new terms in (D), namely k' and β . The ratio of the amounts distributed at equilibrium, k', is called the **capacity factor** or **retention factor**. It tells us the relative capacity of each phase in the particular chromatographic system, under the particular operating conditions (e.g., temperature in GC), for each particular compound. Instead of measuring these directly in the phases, we most often infer them from measurements of retention times, thus the use of "retention factor". The β factor is the volume phase ratio. Note that the terms for (s) and (m) are in opposite order in these two ratios.

(10.1)
$$K_{x} = \frac{[X]_{s}}{[X]_{m}} = \frac{\text{Amt } X_{s}/V_{s}}{\text{Amt } X_{m}/V_{m}} = \frac{\text{Amt } X_{s}}{\text{Amt } X_{m}} \times \frac{V_{m}}{V_{s}} = k' \times \beta$$

Manufacturers of open tubular GC columns often specify **column radius** r_c and stationary phase **film thickness** d_f , which is usually much smaller. Simple geometry enables us to calculate the phase ratio:

(10.2)
$$\beta = \frac{r_{\rm c}}{2d_{\rm f}} \qquad \text{(the limit when } d_{\rm f} \text{ is much smaller than } r_{\rm c}\text{)}$$

For packed GC columns, one might have weighed the stationary phase applied to the particulate support, calculated its volume knowing its density, and measured the gas flow rate through the column, and combined it with the time for an unretained component to transit the column to get the mobile phase volume. The gas volume flow rate can be measured with a soap-bubble flow meter. This is a simple handheld glass cylinder with volume calibrations along its length, similar to a burette. Instead of a stopcock at the bottom it has a medicinedropper-like squeeze bulb, filled with soap solution which can create a flat "bubble" above the bulb and above a side port which is attached to the column gas effluent flow. The bubble rises through the tube and the time it takes to transit two volume markings is obtained with a stopwatch, and the volume flow rate is calculated. Many modern GC instruments now feature electromechanical flow controllers by which the gas flow can be set, measured and displayed, and held to a constant optimum value as the oven temperature scans through a wide range. The manual soap bubble meter used on simple instructional GCs is much cheaper to operate. In section 10.7 and Figures 10.11 and 11.12, one can see the justification for controlling the (linear) mobile phase flow rate to achieve optimal column efficiency. In the case of LC columns, where a molecular scale layer of stationary phase is bonded to an unknown surface area of support, stationary phase volume is very difficult to estimate.

Figure 10.9 illustrates a very simple chromatogram with a single retained component peak. The y-axis represents detector signal response, while the x-axis has either mobile phase volume eluted, or time, increasing from left to right. In chromatography, the more accessible measurement is the retention time of a component, t_r , which is measured from its introduction at one end, until elution of the peak maximum at the center of the eluting band. In Figure 10.9, point O is the start. An **unretained component** (i.e., one that does not partition to the stationary phase, and so travels through the system at the speed of the mobile phase) gives a small peak at point D at time (t_m) . This could be air, methane, or dichloromethane in GC depending on the detector and conditions, while in LC it might be a large ionized dye molecule that does not interact with the stationary phase. The retention time of the component peak is t_r , at point B. Tangents at maximum slope to the peak intersect the **baseline** at points A and C. Since the peak merges imperceptibly at each end with the baseline, time segment AC can be used to define the **peak width at base** (w_b) . If AB = BC, the peak has perfect Gaussian shape. If AB > BC, it displays some degree of **leading** or **fronting**, often associated with stationary phase overload. If AB < BC, it displays a tailing character, associated with some adsorption on active sites (cf. also Figure 10.3)

How much a component is retained by the stationary phase is better described by $(t_r - t_m) = t'_r$, which is defined as the "**adjusted retention time**" (i.e., we count time from the introduction on the column, and then adjust it by subtracting the time it would take to flow through the column if no stationary phase interaction occurred). The capacity or retention




FIGURE 10.9 Chromatogram with a single eluted peak; Peak position and shape terms.

factor described in Equation 10.1 can be calculated from these time measurements using Equation 10.3:

(10.3)
$$k' = \frac{(t_{\rm r}')}{(t_{\rm m})} = \frac{(t_{\rm r} - t_{\rm m})}{t_{\rm m}}$$

If a component is unretained, k' = 0. If k' < 2, all peaks are packed together too closely at the beginning of the chromatogram. If k' is between 2 and about 10, good separations are observed. If k' > 10, the peaks are separated, but they take too long to elute, have become wider and lower, and if close to baseline noise in magnitude, they may become difficult to distinguish from it. These wide peaks with high k' have spent the same amount of time in the mobile phase, where most band spreading takes place, as have the narrower ones eluting earlier. Their greater width is due to slower elution of their band off the column to form the peak.

The amount by which we can separate two components as peaks in time or bands in distance on a chromatographic system is determined by the selectivity of the stationary phase. It is defined for specific conditions; namely, temperature in GC, or mobile phase composition in LC. Selectivity, α , is related to the ratio of partition constants of two components, A and B, or their more easily measured adjusted retention times, as illustrated in Figure 10.10 and calculated from Equation 10.4.

(10.4)
$$\alpha = \frac{K_{\rm B}}{K_{\rm A}} = \frac{(V_{\rm R}')_{\rm B}}{(V_{\rm R}')_{\rm A}} = \frac{k_{\rm B}'}{k_{\rm A}'} = \frac{(t_{\rm r}')_{\rm B}}{(t_{\rm r}')_{\rm A}}$$

When the selectivity is close to 1, the peaks elute closely together, as illustrated in Figure 10.6. They may even overlap one another; in which case we say that they are incompletely resolved. This concept of **peak resolution**, R_s , is put on a quantitative basis by ratioing twice the **separation** d between two closely eluting peaks (determined by the column's selectivity), to the sum of their two widths at the base, w_b , (Figure 10.10).

(10.5)
$$R_{\rm S} = \frac{2d}{(w_{\rm b})_{\rm A} + (w_{\rm b})_{\rm B}}$$
 or $\frac{d}{w_{\rm b}}$ for adjacent peaks of equal area and width

Resolution is a measure of the efficiency of the column. Another parameter which defines the efficiency is the **number of theoretical plates**, N. Review the discussion of plates in chromatography at the end of Section 10.2. The determination of N from measurements of retention time and peak width in time units will not be derived, but will simply be given here in Equation 10.6. An advantage of N as a measure of efficiency is that it may be calculated from measurements on a single peak. Unlike R_s , it does not require a pair of peaks and is independent of their relative selectivity α . It may be calculated using either the peak width at base, w_b , or peak width at half the peak height, w_h . The latter is sometimes better, as w_b can often be subtly broadened by overloading (leading) or the effects of adsorption (tailing).

(10.6)
$$N = 16 \left(\frac{t_{\rm r}}{w_{\rm b}}\right)^2 = 5.54 \left(\frac{t_{\rm r}}{w_{\rm h}}\right)^2$$




FIGURE 10.10 Incompletely resolved closely eluting peaks of equal size; parameters defining resolution (R_c).

The plates may be imagined as distances along the column where a complete equilibration of the sample between the two phases takes place. The greater the number of plates for a given column length, the shorter the **height equivalent to a theoretical plate**, **H**, and the more *efficiently* the column operates. This distance along the column is described as a height, since early chromatographic columns (and fractional distillation towers) were oriented vertically.

$$(10.7) H = \frac{L}{N}$$

where L is the length of the column.

Since d in Equation 10.5 equals $(t_r)_B - (t_r)_A$, we can solve for w_b in Equation 10.6, insert it into the second expression of Equation 10.5 and relate resolution R_S to plate number N as follows:

(10.8)
$$R_{\rm S} = \frac{(t_{\rm r})_{\rm B} - (t_{\rm r})_{\rm A}}{w_{\rm b}} = \frac{(t_{\rm r})_{\rm B} - (t_{\rm r})_{\rm A}}{t_{\rm r}} \times \frac{\sqrt{N}}{4}$$

Substitution of appropriate versions of Equations 10.3 and 10.4 into Equation 10.8 and rearrangement result in Equation 10.9:

(10.9)
$$R_{\rm S} = \frac{\sqrt{N}}{4} \times \left(\frac{\alpha - 1}{\alpha}\right) \times \left(\frac{k_{\rm B}'}{1 + k_{\rm B}'}\right)$$

Equation 10.9 can be approximated by Equation 1.10:

$$R_{\rm S} = \frac{\sqrt{N}}{4} (\alpha - 1) \times \left(\frac{k'}{1 + k'}\right)$$

where k' = the average of k'_A and k'_B .


Equations 10.9 and 10.10 enable us to estimate the degree of resolution of two closely eluting peaks if we have information on the *column's* **selectivity**, (α , Equation 10.3) and **efficiency**, (N, Equation 10.6), and the *peaks'* **average capacity factor** (k', Equations 10.1 and 10.3) under the conditions of the separation.

10.7 HOW DO COLUMN VARIABLES AFFECT EFFICIENCY (PLATE HEIGHT)?

At the microscopic, molecular level, very complex theoretical equations are required to describe the chromatographic process. These include expressions for laminar or turbulent fluid flow, random walk, diffusional broadening of analyte bands in both the mobile and stationary phases and the kinetics of near-equilibrium mass transfer between the phases. Such discussions are beyond the scope of this text.

Fortunately, Dutch scientists in the 1950s related the performance of columns in terms of H, the height equivalent to a theoretical plate, to a single variable, the **linear mobile phase velocity**, u. This could be calculated from column dimensions and volume flow rates, or more simply measured directly using the retention time of an unretained analyte, $t_{\rm m}$, and the measured column length, L. Three constants, the ABCs of chromatographic column efficiency, combine in the **Van Deempter Equation** (Equation (10.11), to describe how H varies with u for a particular geometry and construction. Three terms sum together, one independent of u, one inversely proportional to it, and one directly proportional to it.

$$(10.11) H = A + \frac{B}{u} + Cu$$



* d_e refers to the effective particle size. For Kinetex 1.7 μ m particles, $d_e = 1.5 \mu$ m and for Kinetex 2.6 μ m particles, $d_e = 1.7 \mu$ m. For fully porous particles, $d_e = d_p$.

FIGURE 10.11 Van Deempter plots for open tubular columns as sum of three terms: **A, B, & C. (a)** is for HPLC with standard size packing and **(b)** is for UHPLC with small core-shell particles. Note the depression of both the **(a)** contribution and flatter right branch for **(b)**. (Used with permission from Phenomenex, Inc., Torrance, CA, USA., www.phenomenex.com.)

Two generalized plots of the Van Deempter Equation are illustrated in Figure 10.11. Each of the terms is plotted individually, and their sum is shown as the dashed line with a distorted U-shape. The important feature of the plots is that each chromatographic system will have a *minimum* value for H as a function of u. This value defines the flow conditions which will produce the highest possible resolution. When there is high selectivity of a column for all pairs of analytes, a desire to decrease analysis time may encourage operation at flows above the Van Deempter minimum. The coefficients of the three terms are governed by the following processes:

- 1. The multipath term (A): This term applies to columns packed with support particles. It becomes zero for open tubular columns when the mobile phase velocity is slow enough for the flow to be laminar (i.e., without turbulent eddies). In a packed column, the paths of individual analyte molecules will differ as they take different routes through the spaces between the particles. Thus, they will travel varying distances before they exit the column, and the difference between these distances contributes to band broadening. The relative magnitude of the multipath term depends on the particle and column dimensions. If Figure 10.7 depicts packed columns, A would be a constant value for all values of u, and would appear as a horizontal line raising the curve by a constant amount. The multipath process is illustrated in Figure 10.12.
- 2. The longitudinal diffusion term (B): This term accounts for the spreading of molecules in both directions from the band center along the length of the column as a result of random-walk diffusion. This occurs primarily in the mobile phase in GC, but significantly in both phases in LC (as the analytes dissolved in the stationary phase behave much as if they were in a liquid). The faster the linear mobile phase




FIGURE 10.12 Mechanism of origin of multipath term a of Van Deempter equation.

- velocity u, the less time the analytes have to spread in the mobile phase. Thus, band spreading and H are inversely proportional to u. The B term is much more significant in GC than in LC, since diffusion rates in gases are much higher than in liquids.
- 3. The mass transfer term (C): Diffusion in both the mobile and stationary phases also occurs perpendicular to the direction of flow. If the distance molecules traveled into and back out of each phase were infinitely small, and the mobile phase flow were infinitely slow, there would be time at every point along the column for the molecules to achieve perfect equilibration between the phases. However, the faster the mobile phase moves, the more some analytes move ahead in it due to insufficient time for diffusion to allow them to come to equilibrium. Conversely, the further some analytes are left behind in the stationary phase as they penetrate more deeply into it. Thus, this mechanism for band spreading is directly proportional to u. Additionally, under laminar flow conditions in small channels, the flow rate will actually vary from zero at the boundary between the two phases to a maximum at the channel center. Molecules diffusing further away will be carried ahead even faster. In Figure 10.11 we can see how B and C work against each other as u varies to produce a minimum H value. Figure 10.11(a) is representative of packed column GC, and to a lesser extent of fully porous particle packed LC. The optimal flow value is defined by the position of this pronounced minimum. Figure 10.11(b) shows the superior performance obtained in UHPLC operation with small, superficially porous (core-shell) particles. Note that the A term contributes less and that the curve minimum is almost flat and remains much lower as flow rates increase above that at the minimum. This is due to the faster equilibration between the narrower porous shell and the mobile phase liquid, and it allows use of faster flows to attain shorter analysis times without sacrificing significant resolution or the improved sensitivity of sharper peaks.

10.8 PRACTICAL OPTIMIZATION OF CHROMATOGRAPHIC SEPARATIONS

As analysts, how do we employ the principles summarized in the equations listed in Sections 10.6 and 10.7? We want to arrive at the best tradeoff between optimum resolution and separation of mixture components, and the time to complete the separation. Even if time were of no concern, recall from the discussion following Equation 10.3 that components with very high retention times and thus very large k' values elute off the column slowly. This spreads out the peak in the detector, making the signal lower and more difficult to measure above the baseline, thus decreasing sensitivity of detection. On the other hand, if we operate with conditions that make k' and retention times too small, many of the earliest eluting peaks will be crowded together, and we will lose resolution. Note what happens to the value of R_s in Equation 10.10 as k' becomes much less than 2 in the last factor. The first step is to select a stationary phase (and in LC, a mobile phase solvent mixture) which optimizes selectivity for the analytes of interest. The principles governing this choice will be treated in Chapters 11 and 12 for the various types of chromatography. Catalogs and application manuals (now usually online) from suppliers of chromatography columns publish extensive descriptions of optimized separations and the most suitable stationary phases for all classes of analytes. Analysts consult these catalogs or the companies' online web sites for suggested chromatographic separations of commonly encountered analytes or ones structurally similar to the ones they wish to determine. (Lists of internet chromatography resources are found in Appendices 11.A and 12.A on the text website.)

From Equation 10.7, we see that greater efficiency of the column is indicated by lower values of H. The number of plates is directly proportional to the length L but, from Equation 10.8, the resolution is proportional only to the square roots of either N or L. The retention time increases directly with L. Thus, if all other conditions are unchanged, doubling the column length doubles the analysis time but only increases the resolution by the square root of two (i.e., 1.4 times). We could change the temperature in GC or the polarity of the mobile phase in LC to keep the analytes longer in the mobile phase and thus get them off

the column faster, but as k' gets near 2 or below, the last factor in Equation 10.10 rapidly becomes much smaller than its maximum value of 1, and resolution decreases. With many analytes spread out in retention time, bringing later eluting pairs into the region of k' near 2 will force even earlier eluting pairs into the region of severely degraded resolution. Speeding up the mobile phase flow rate causes us to climb up the right-hand side of the Van Deempter curve in Figure 10.11. This results in decreased resolution by increasing the plate height, which thereby decreases the number of theoretical plates. The ability to increase the mobile phase flow rate is also limited by the instrument's ability to supply a column head pressure necessary to increase the flow rate. The more efficient columns with narrower channels for passage of the mobile phase require more pressure per unit length to maintain a given linear flow rate, and the required pressure also increases linearly with increasing column length. For these reasons, going to a longer column should be a last resort to improve resolution. A set of mobile and stationary phases with improved selectivity should be sought first, followed by optimization of k' and u (i.e., operating close to the minimum of the system's Van Deempter Curve).

Increasing column temperature often improves efficiency in LC systems, because the resulting decrease of the C term is greater than the increase of the B term (i.e., improvement in mass transfer outweighs the effect of diffusive band broadening in liquids). The decrease in liquid viscosity with increasing temperature means less pressure is required to achieve optimum values of u if longer columns are used. To properly employ a liquid mobile phase at elevated temperature, one must be careful to assure that it is preheated to the desired operating temperature before entering the column. If not, a temperature and flow rate gradient will be set up across the width of the column which will act to broaden bands and reverse the desired resolution improvement. Contrary to our intuitive understanding that increasing temperature lowers the viscosity of liquids, the effect is the opposite with gases. Additionally, temperature is the primary variable that affects retention of analytes in GC, so it cannot be independently changed to affect resolution only through the terms in the Van Deempter Equation which affect plate height and efficiency. In GC, increasing the temperature increases the mobile phase viscosity and thus decreases flow rate. Even though analytes will come off more quickly because k' becomes much smaller, u will have decreased. If we were originally operating with optimum efficiency at the Van Deempter minimum, the smaller u will shift operation to the steeply rising left hand branch, resulting in a significant loss of resolution. In GC we often employ temperature programming (see Section 11.6), raising the column temperature at a constant rate during the analysis to more rapidly elute mixtures of analytes with a wide range of boiling points. In these circumstances it is advisable to start with a u value on the less steeply rising right-hand side of the Van Deempter Curve, so that raising the temperature during the run causes u to shift back toward, but not much past, the position of the curve's minimum.

10.9 EXTRA-COLUMN BAND BROADENING EFFECTS

In Sections 10.7 and 10.8, we have seen how interacting parameters of column efficiency and linear flow velocity (the Van Deempter Equation), selectivity, and capacity factor (related to the distribution of analytes between phases under operating conditions) affect our ability to resolve mixture components. These descriptions apply to columns generating ideal symmetrical Gaussian peaks. We know that processes of overloading or adsorption on active sites can lead to peak fronting or tailing, which degrade this ideal resolution. We have not treated these processes occurring in the column quantitatively. There are other sources of band or peak broadening which occur outside of the column that we need to take care to avoid. Working backwards from the chromatographic instrument's detector to its injector we may lose resolution in the following ways:

1. *Mixing in too large a detector volume*: If the volume of the detector is much larger than the volume of mobile phase carrying a small fraction of the eluting band, the resulting peak will begin to broaden as the differing concentrations eluting from the

- band mix together in it. In an extreme case, two bands just resolved on a column could completely mix in a large volume detector cell and all separation could be lost. A classic example of this is using a capillary GC column with very high resolution and low flow rate with a large volume detector designed to handle the much higher flows and broader peaks associated with packed column GC. This mixing can be suppressed by supplying a flow of **makeup gas** to the detector to sweep the column effluent through it rapidly before it has time to mix significantly. The resulting dilution of the effluent may lower the sensitivity of detection relative to that which could be obtained with a detector specifically designed to handle low capillary flows.
- 2. Open space within a packed column: While this is not strictly "extra-column", the effect is very similar to what happens when bands enter a large detector and lose resolution by mixing. This will happen when voids or openings in the bed of particles in a packed column are present. The problem occurs most frequently in HPLC separations, where the packing particles are of micron dimension and the bed is subject to large fluctuations in pressure during pump startup and shutdown. If the bed is not tightly packed between supporting frits, voids can develop at either end or elsewhere. Channels may form along the walls of the column if the packing bed is not of uniform density across the entire diameter. Dissolved gases (air) may form bubbles as pressure drops along the column, similar to what happens when a pressurized carbonated drink container is opened. Even a few small bubbles can disrupt the packed bed. Initially these could impede mobile phase flow, but if the gas in the bubbles redissolves in the liquid mobile phase, a void which acts as a remixing chamber within the column may remain.
- 3. Injector spreading and tailing: Mixtures deposited on the head of a column prior to elution and separation exist as a band of finite thickness. If this band is broadened beyond its ideal possible minimum when it is put on the column, maximum resolution performance from the column will not be attainable. In GC, the sample is vaporized in a hot injection port, and then swept onto the column by the mobile phase flow. The analyte mixture is often dissolved in a much lower boiling solvent. If the vapor volume of solvent and analytes resulting from flash vaporization in the hot injector exceeds the capacity of the injector port, some sample may be blown back into unheated portions of the gas lines where it will continue to seep slowly back into the system. If bands of some components deposited at the head of the column move significantly down the column while more sample is still entering the column from the injector, they will start with a larger than ideal width. Many chromatographic procedures load the sample from the injector under conditions where k' is very high. Little movement of the bands takes place until all the sample is on the head of the column and an ideal minimum initial bandwidth is achieved. Then the temperature is raised in GC, or the mobile phase polarity in LC is changed to more closely match that of the analytes, and movement and separation of these initially narrow bands begins.

10.10 QUALITATIVE CHROMATOGRAPHY: ANALYTE IDENTIFICATION

Each compound has its own characteristic **retention time**, t_r , in a chromatographic system. This is useful in identifying compounds, but in general it is not as specific as the compound's mass, IR, UV/VIS absorption, or NMR spectra. The t_r depends on the compound, the stationary and mobile phase compositions, the mobile phase flow rate, and column dimensions. It is generally not practical to predict t_r for an analyte precisely from all these parameters, nor to maintain reference data which will enable an analyst to identify a compound from its t_r the way we do from interpretation or comparison of spectra. Further, within the range of k' = 2-10, where resolution is optimal and t_r is not unreasonably long, there is space for only several hundred resolved peaks at best. There are thousands of compounds which could elute in this region, so coelutions are highly possible and a t_r is not a unique identifier of only one compound.

We can, however, use t_r to indicate the absence of a detectable level of a compound if there is no peak at the retention time that we have determined for the compound on our system by separately running a standard. How closely must the t_r of an unknown and a standard peak match for us to say that they could be the same compound? A slight difference in t_r between the two runs might be due to a shift in flow, temperature, or mobile phase composition between the runs. Spiking the standard into the unknown solution and chromatographing them together at the same time and observing a single undistorted peak eliminates this uncertainty. Another way to factor out instrumental variations from run to run is to coinject a retention time internal standard (IS) with both unknowns and standards. This compound should have a t_r different from any analytes to be measured or contaminants that might elute closely enough to be mistaken for it. Relative retention times (RRT) can be calculated by ratioing the t_r of the standards to that of this IS. These RRTs are more reproducible and may even be compared between columns with the same stationary and mobile phases and operating conditions but having slightly different dimensions. Use of RRT values avoids the need to confirm identity by coelution with spiked standards when there are many peaks to be identified in a chromatogram.

Additional certainty in using $t_{\rm r}$ values to assign peak identity is obtained when retention times match on two columns with significantly different stationary phases, or a single planar stationary phase eluted by orthogonal, sequential application of two mobile phases. This is the principle and application of 2D chromatography discussed in Section 10.3. Many analyses of complex environmental mixtures specify splitting an injection to two different capillary GC columns operating in parallel to separate detectors. An analyte is considered to be measurable only if it elutes with the appropriate RRT on both columns and the measured quantities of it on each column differ by less than a specified amount. The latter condition ensures that there is no significant co-elution with yet another compound on one of the columns. The second column in such a pair is called the *confirmation column*.

Even more certainty of peak identification is obtained by using detectors that are **selec**tive for certain classes of compounds (e.g., only those with particular heteroatoms, such as halogens, N, P, S, etc.). These are covered in Chapters 11 and 12. Even more selectivity can be obtained by so-called hyphenated detection techniques. Here the effluent is delivered to a spectrometer (e.g., MS, IR, Raman, UV/VIS, NMR), and full spectra or characteristic regions from them are sampled continuously and stored in computer data files as the peaks elute from the column. This provides the best of both worlds: the instrumental analytical worlds of chromatographic separation and of unique spectral fingerprints of pure separated compounds. If their spectra are sufficiently different, it is often possible to identify and quantitate compounds which the chromatograph has failed to separate and which coelute in a single peak. Recall that there is only limited retention space in any chromatographic system, and there are thousands of compounds which could possibly elute and coelute there. Conversely, in MS, for example, there are isomers, such as ortho-, meta-, and para-xylene (dimethyl benzenes), which fragment to produce identical mass spectra, but which can be distinguished by their different t_r values in a chromatographic system. Such instrumentation is complex and expensive, and it demands computerized data handling, but it dominates instrumental analytical chemistry in the fields of biomedical and environmental monitoring and research. The techniques for interfacing chromatographs to spectrometers and acquiring and processing the resulting flood of data are discussed at the ends of Chapters 11 and 12.

10.11 QUANTITATIVE MEASUREMENTS IN CHROMATOGRAPHY

Quantitation may be done crudely on the spots separated by planar chromatographic techniques such as TLC or slab gel electrophoresis (Chapter 12). One might compare the optical density, the fluorescence, or the degree of stationary phase fluorescence suppression by the unknown spot to a series of standards of known concentration. In contrast, the electrical signals from the variety of detectors used in various column chromatography instruments can be precisely, reproducibly, and linearly related to the amount of analyte passing through the detector cell. If all parameters of injection, separation, and detection are carefully controlled

from run to run and especially if appropriate quantitative internal standards are incorporated in the procedure, accuracy and precision better than ± 1 % may be attained.

10.11.1 PEAK AREA OR PEAK HEIGHT: WHAT IS BEST FOR QUANTITATION?

In chromatography, we measure each of the signals from a series of peaks. Unlike spectrometric measurements where a single stable signal level is proportional to the amount of analyte, the peak signal rises from the baseline (background) level to a maximum and then returns to baseline. The amount of analyte is proportional to the area of the peak. The instrument or the operator must decide when a peak starts and ends, how to estimate the position of the baseline beneath the peak signal, and then to integrate the signal level above the baseline between the start and end points.

In earlier instrumentation where the signal was displayed as a pen trace from a chart recorder, the baseline was drawn manually. The area of a symmetrical Gaussian peak could be approximated by drawing tangents to each side of the peak and calculating the area of the resulting triangle formed by these tangents and the baseline. This is illustrated in Figure 10.5. A more accurate but laborious method involved actually cutting out the peak areas from the chart paper and comparing their weights obtained on an analytical balance. Most chromatographic instrumentation now employs computerized data systems. The analog signal level is continuously sampled and digitized, and a summation of these digital "counts" during the peak's elution, after subtraction of levels calculated from a hypothetical baseline between the peak start and end points, produces a peak area value. The operator of the data system must select a "trigger level" of baseline rise that signals the start of a peak. Another one after the descent from the peak maximum level determines either that the signal has returned to a level value (baseline) or is ascending again with the elution of a following peak. These tell the system when to start and stop peak integration. At analyte levels close to the instrumental limit of detection, baseline noise (i.e., random small variations in the signal) will increasingly corrupt the proper functioning of these triggers. If they are set high enough not to be incorrectly tripped by random noise, the baseline will be drawn too high and a significant portion of the peak will not be integrated. If they are set too low, they may be tripped by noise, and integration could be either started or cutoff too early. These problems of setting parameters for computerized peak integration are often the primary source of chromatographic standard curve nonlinearity near the lower limit of quantitation.

Peak heights are easier to measure either manually or in a computerized method. The signal level at the top of the peak has the greatest signal-to-noise ratio, and if closely eluting peaks are incompletely resolved, the tops are the easiest points to locate. The problems associated with proper estimation of the baseline above which the height is to be measured are similar to the case for peak areas, but heights only have to be evaluated at the single point on the baseline beneath the peak maximum. For well-separated peaks of ideal Gaussian form, the peak height is directly proportional to the peak area. However, as the peak shape becomes more and more distorted due to leading or tailing processes, the relation no longer holds. This introduces nonlinearity into standard curves of peak height versus concentration, which would not occur if properly measured peak areas were used instead of heights. Therefore, peak area measurements are preferred whenever possible, despite their greater complexity. The only common exception may be when measuring a small peak eluting on the front or back of a larger one. In such cases, a data system may not be capable of being programmed to accurately start and stop integration and draw an appropriate baseline for the small peak. Printing the peak pairs and manually drawing and measuring baselines and peak heights of the unknown and appropriate standards may enable a quantitation calculation.

Review the description of the two different types of detector (mass detector or concentration detector) at the end of Section 10.4. Note well that the area that will be calculated for a peak measured by a mass detector is independent of mobile phase velocity, but when a concentration detector is used, it is not. When calibrating against standards using a concentration detector, it is important that the analyte peaks in both the unknown and standard runs elute at the same time and under the same mobile phase flow conditions.

Conversely, if quantitation is by peak height comparison using a mass detector, the same requirements apply.

10.11.2 CALIBRATION WITH AN EXTERNAL STANDARD

The same principles that are outlined for calibration in Chapter 1 apply to chromatography. A series of solutions containing analytes at levels covering the concentration range to be measured are injected, peak areas are measured, and standard curves of peak areas versus concentrations are produced. In contrast to spectrometric measurements, a well-designed chromatographic separation will move mixture components away from the analyte's retention time, so a blank background subtraction need not be applied to peak area values. It is vital, however, to analyze a blank sample using the same injection solvent, and if possible, one processed using the same sample preparation procedure from a similar matrix not containing the analyte. This should confirm the absence of interfering peaks eluting at the same times as target analytes. If these are found, the chromatographic conditions should be adjusted to separate them from the analytes. Note that the MSA (method of standard additions) could only be applied if there were sufficient experience with the samples to warrant the assumption that no interferences eluting at the positions of the analytes would be encountered. Such an assumption will always have some level of uncertainty, so this method of calibration is seldom applied in quantitative chromatography. Since chromatography separates the analyte from most matrix components, its detectors do not often suffer from the matrix suppression effects that this calibration method corrects for in spectroscopy.

The standard curve should be linear over the calibration range. Samples with levels above this range should be diluted to fall within it and then be reanalyzed. Advanced data handling systems can fit peak heights or areas to nonlinear (e.g., quadratic, logarithmic) standard curves, but best practice is to find the linear response region and to operate within it. The precision and accuracy of an externally calibrated assay are limited by the reproducibility of sample preparation recoveries, sample volume injections, and the stability of instrument detector response over the course of calibration and analysis runs. In chromatography, we may be comparing the detector response from unknowns against those from an external standard curve run hours before.

To quantitate unknown peaks against a standard curve, one plots the response (e.g., area counts from a digital integrator) on the y-axis (ordinate) against the concentration on the x-axis (abscissa). The absolute value of the y-axis intercept of a linear, least squares fit of the data to the points should be a small fraction of the value at the lowest calibrated point on the "curve" (i.e., the response extrapolates to a value close to zero at zero concentration). If so, or if we select a least-squares-fitting program which forces the line through zero, then we can calculate the concentration C of an unknown from its peak area A and the slope S of the calibration curve using Equation 10.12.

$$(10.12) C = \frac{A}{S}$$

This is only valid for areas and concentrations within the limits of the standard curve calibration levels. While in principle one may calibrate against a standard curve which has a substantial *y*-axis intercept, this will yield valid results only if the background signal level causing the large intercept is the same in both the standards and unknown sample matrices. This is a dangerous and often unverifiable assumption to make, and the use of such calibration curves should be avoided.

10.11.3 CALIBRATION WITH AN INTERNAL STANDARD

Some of the factors mentioned earlier, which introduce error when calibrating with external standards only, can be compensated for by introducing a constant amount of an internal standard in both the unknown and the standard calibration samples. The internal standard (IS)

should be a compound with a chemical nature similar to that of the analytes, so that it will pass through the sample extraction and preparation procedure similarly. In general, it should elute in the chromatographic system close to the other peaks in the system, but separated from all of them, so it can be identified and measured accurately. One calculates the **ratio** of the peaks' responses to their concentrations. Then the **ratio** for each analyte peak (A) is divided by the ratio of the IS peak, to give the **relative response factor (RRF)**, for the analyte to the internal standard, as summarized in Equation 10.13.

(10.13)
$$Ratio A = \frac{Area A}{Conc. A}; Ratio IS = \frac{Area IS}{Conc. IS}$$
$$RRF = \frac{Ratio A}{Ratio IS} = \frac{Area A \times Conc. IS}{Area IS \times Conc. A}$$

For a given constant concentration of IS added, if we plot the ratio of the analyte peak area to the IS peak area against the analyte concentration A, we should get a standard curve whose slope is the RRF. In a fashion analogous to Equation 10.12 for external standard calibration, we can determine the Ratio U of analyte of unknown concentration to IS peak area and calculate the unknown concentration *C* using Equation 10.14.

(10.14)
$$C = \frac{\text{Ratio U}}{\text{RRF}} \text{ or } C = \frac{\text{Area U/Area IS}}{\text{RRF}}$$

The criteria for acceptable linearity of least squares fit and zero intercept when plotting ratios of analyte to internal standard areas versus concentration are similar to the case for external standard calibrations described earlier. More than one IS can be used, both for calculating RRTs to compensate for retention time variations as well as the RRFs for improving quantitation. The variations that a quantitation IS can compensate for depend upon the point at which it is introduced in the analysis. If it is put into the final extract prior to injection on the chromatograph, it can correct for concentration variations due to evaporative volume changes, variations in injection volume, and variations in detector response. This is called an **injection internal standard**. If the internal standard is put into the initial sample, and into calibration standards prepared in an equivalent matrix, it can additionally correct for variations in recovery during the sample preparation process. This is called a **method internal standard**. Combined use of separate compounds for each purpose can aid in determining the causes of peak area variability.

10.12 EXAMPLES OF CHROMATOGRAPHIC CALCULATIONS

To illustrate the operation of some of the equations and calibration principles earlier outlined, consider the data from the following hypothetical chromatogram summarized in Table 10.1. This is for a capillary GC column, 30 m long, with a diameter of 0.25 mm, operated at a constant temperature of 200 $^{\circ}$ C under a helium pressure of 20 psi above atmospheric pressure, resulting in an average linear flow rate of 31.3 cm/s. We measured the time for an unretained component to pass through the column as 1.6 min. We determined the typical number of theoretical plates on the column to be 30,000. (How would you easily measure and/or calculate these last two values?) If the column is 30 m, or 30,000 mm, long, it is trivial to see that the height equivalent to a theoretical plate is 1 mm. This is a very efficient column!

There are five analytes, giving peaks 1 through 5, plus an internal standard peak 6. Observe peaks 2 and 3, eluting at 4.00 and 4.10 min, respectively. Their widths at the base are somewhat more than 5.5 s, and their peaks are separated only by 0.1 min (= 6 s), so they probably overlap a bit near the bottom. This is reflected by the calculated resolution of 1.07. A rule of thumb is that we need a resolution of 1.5 or more to achieve complete baseline resolution. We note that k' is about 1.53 for this pair; a little less than the minimum preferable value of 2 or more. We can improve resolution by lowering the temperature from 200 °C to a value

that will increase k' and the resolution. From the last factor in Equation 10.9, we can calculate that increasing k' to 3.06, corresponding to t_r of about 6 min, will increase the resolution from 1.07 to 1.34. Perhaps this will be sufficient. We could double the number of plates by going to a 60 m column. This improves resolution by the square root of 2; namely, 1.4. That improvement, 1.4 times 1.07, gives us a resolution of 1.5. But this is at the cost of purchasing and installing a 60 m column at nearly twice the price, requiring 40 psi pressure for the same optimum flow rate (perhaps out of our instrument's range), and IS peak 6 will now take 16 min to come off before we can run the next sample or standard. It is much easier to adjust the temperature (by lowering it) to get better resolution of the close pair of analytes 2 and 3. Speaking of close pairs, the resolution of 0.5 between peaks 4 and 5 may well cause them to overlap so much that they cannot be separately quantitated. Based on what we could do by lowering temperature or lengthening the column to increase the resolution of 1.07 for peaks 2 and 3, these remedies are unlikely to be practical for resolving 4 and 5. If we need to measure them, we should find a column with a different stationary phase which has a selectivity, α , for this pair which is not so close to 1. Of course, we must hope that resolution for the other analyte pairs does not decrease too much with the new column. Such are the tradeoffs in finding the best column and conditions for a mixture separation. One can easily imagine that the probability of problems and conflicts increases with the number of components we would like to measure.

The second segment of Table 10.1 shows peak area counts for each of the five analyte peaks over a standard range of five concentration levels from 10 to 200 ppm, and the areas of the 50 ppm IS peak 6 in each of those five standards. The ratios of each peak area to the IS area are calculated and displayed in the third segment. We can plot each line of data for each peak against the standard concentration, and obtain the slopes and intercepts of the linear least squares fits. If you do this you will find that there is some small variation of the data points about the line, but the intercept is close to zero, and much smaller than the response from the

TABLE 10.1		Data from	a Hypoth	etical Chro	matogram
Peak	t _r (min)	K '	w _b (s)	w(1/2) (s)	Resolution
1	3.70	1.31	5.13	3.02	
2	4.00	1.50	5.54	3.26	3.37
3	4.10	1.56	5.68	3.34	1.07
4	4.30	1.69	5.96	3.51	2.06
5	4.35	1.72	6.03	3.55	0.50
6 IS	8.00	4.00	11.09	6.52	5.77
			Conc. (ppm)		
	10	25	50	100	200
Peak are	ea counts f	or five-level sta	andard curve		
1	64,871	138,589	300,767	654,611	1,132,301
2	53,422	150,838	345,670	647,345	1,319,829
3	65,668	151,856	235,309	530,813	1,094,460
4	54,705	116,870	253,633	552,025	954,854
5	49,904	140,906	322,911	604,723	1,232,931
6 ISa	287,296	262,670	270,879	300,977	279,087
Peak are	ea ratios (st	tandard/peak 6	internal stand	dard)	
1	0.23	0.53	1.11	2.17	4.06
2	0.19	0.57	1.28	2.15	4.73
3	0.23	0.58	0.87	1.76	3.92
4	0.19	0.44	0.94	1.83	3.42
5	0.17	0.54	1.19	2.01	4.42

Note: Capillary GC 30 m \times 0.25 mm i.d. column; 20 psi helium mobile phase; 31.3 cm/s; t_m = 1.6 min; temperature = 200°C; N = 30,000.

^a The concentration of IS was 50 ppm.

TABLE 10.2 Use of Retention and Quantitation Internal Standard to Correctly Identify Peaks and Correct for Sample Loss or Concentration Changes

Peak	RT (min)	RRT	Area Counts	Slope Ext. Std.	Slope Int. Std.	Ratio (<i>U</i>)
2	4.00	0.500		6635	0.0235	
Α	4.01	0.489	175,000			0.831
3	4.10	0.513		5435	0.0193	
В	4.12	0.502	194,500			0.924
C	4.24	0.517	254,000			1.207
6 IS	8.00		280,182			
D IS	8.20		210,500			

	Ext. Std. Quant. (ppm)		int. Sta. Quant. (ppm)		
	Wrong ID	Right ID Uncorrected	Wrong ID	Right ID Corrected	Identification
Α	26.4	Contam.a	35.4	Contam.	Unknown
В	35.8	29.3	47.9	39.3	Cpd. 2
C	Contam.	46.7	Contam.	62.5	Cpd. 3

a Contam. = Contaminant

First Carl Occame (mmm)

lowest level standard. We can therefore use the slopes, and area or area ratios for unknowns, to calculate concentrations using either Equation 10.12 or 10.14 for external or internal standard method calculations, respectively.

In the top segment of Table 10.2, we display data for peaks 2, 3, and IS 6 from the standard curve runs, and for three unknown peaks (A, B, C) in a separate chromatographic run eluting with similar RT, plus D, which is the IS 6 peak in that run. In both runs, we use IS 6 as a retention internal standard to calculate RRT values displayed in the third column of the table. If we only compared RTs (i.e., t_r), we might say A is 2 and B is 3. We note, however, that IS D elutes 0.2 min later than it did in the standard runs. Something has caused a shift in retention between the runs, perhaps the flow has slowed a little, or the GC oven temperature dropped a bit. If we compare RRTs, we see that B and C are better matches to 2 and 3, respectively.

Notice that not only has the retention time of the D IS shifted, but its peak area is significantly lower than the average value from the five standard runs displayed directly above it. If D were employed as a method IS, we may have a recovery difference between the unknown sample and the standards, or perhaps the unknown solution was diluted more during the final step before injection, or perhaps a smaller volume was inadvertently injected, or possibly some combination of all these or other factors. The method IS will quantitatively correct for any or all of these, even if we do not know which may have occurred. The bottom section of Table 10.2 shows the different results which will be obtained with or without correction for either or both the retention and quantitation shifts. The bold values displayed at the lower right are obtained using the IS to calculate RRTs for peak assignment and RRFs for quantitation. Note how they differ from the uncorrected and incorrect values calculated without full benefit of internal standard retention and quantitation calibration.

PROBLEMS

- 10.1 In GC what is the effect on the retention time of a peak (increase, decrease, remain the same, become zero?) of:
 - a. raising the column temperature (if head pressure is kept constant)?
 - b. lengthening the column?
 - c. increasing the gas flow rate?
 - d. increasing the volume of stationary phase in the column?

- e. increasing the column head pressure?
- f. overloading the column with sample?
- g. having some stationary phase slowly volatilize from column?
- h. forming a more volatile derivative of the analyte compound?
- 10.2 In LC what is the effect on the retention time of a peak (increase, decrease, remain the same, become zero?) of:
 - a. raising the column temperature (if head pressure is kept constant)?
 - b. decreasing the particle size in packed column HPLC (at constant pressure)?
 - c. Having a bubble form in the column?
 - d. Increasing the column head pressure?
 - e. Using an open tubular column of the same length with a diameter 5× the spacing between particles in a packed column at the same head pressure?
 - f. Increasing the polarity of the mobile phase in "reversed-phase" HPLC?
 - g. Using a less polar stationary phase in "normal-phase" HPLC?
 - h. Using a more efficient column with twice as many plates with the same length, mobile and stationary phase compositions, operated at the same flow rate?
- 10.3 Can one perform planar GC? 2D GC? How?
- 10.4 What controls the mobile phase flow rate in ascending TLC or paper chromatography? Do you think it is constant during the separation?
- 10.5 Distinguish among the terms: elution, eluent, effluent.
- 10.6 What form of chromatography is SPE?
- 10.7 Acronym Quiz: Identify—HETP, HPLC, TLC, CZE, GC-MS, IS, RRT, RRF.
- 10.9 For a pair of peaks, what is the effect on Resolution (R_s) of increasing one of each of the terms in Problem 10.8.
- 10.10 What do the Van Deempter equations look like for packed column chromatography, capillary chromatography, and capillary electrophoresis (hint: in the last of these there is no stationary phase)?
- 10.11 Draw a Van Deempter curve for each of the three techniques in Problem 10.10—the answer should be "schematic", not necessarily quantitative. Explain the differences in appearance.
- 10.12 a. Calculate the phase ratio for a 30 m by 0.2 mm diameter capillary column coated with a $0.5 \mu m$ film of stationary phase.
 - b. If a similar column uses a $2.0 \,\mu m$ film of the same stationary phase how will k' change?
 - c. Will $t_{\rm m}$ differ between columns a and b if operated the same way?
 - d. If $t_{\rm m}$ for the column in a is 1.5 min and a peak has a $t_{\rm r}$ on it of 3.5 min, what will be the $t_{\rm r}$ of that peak on the column in b?
- 10.13 Under what conditions are peak heights proportional to area? When are they not?
- 10.14 Calculate how many theoretical plates a column must have to achieve a resolution of 1.5 (baseline) between two peaks eluting at 8 and 8.2 min.
- 10.15 An HPLC column received from a manufacturer was specified to have 4000 plates measured under standard conditions with a test compound. When the customer repeated the test, she found only 1500 plates, despite a symmetrical Gaussian peak shape. What might account for this?
- 10.16 In an experiment, an analyst injected a pure compound into a gas chromatograph in volumes increasing from 0.2 to 5.0 μ L in 0.2 μ L increments. At first the amount of "tailing" observed in each successive peak decreased, but then started increasing at volumes above 3.0 μ L. Account for what happened (hint: two different processes dominate at each end of the volume range).

QUESTIONS BASED ON EXAMPLE IN SECTION 10.13, TABLES 10.1 AND 10.2

10.17 Using a calculator or personal computer program, use the appropriate data from the second and third segments of Table 10.1 to calculate the slopes for all five peaks used for both the external standard and internal standard calibration calculation. Check your values against those reported for peaks 2 and 3 in Table 10.2.

- 10.18 How might you satisfy yourself that peak *C* and not peak *B* is actually component 3? Suggest two different ways. Which is easier to implement?
- 10.19 Describe how using separate injection and method internal standards could allow you to separate analyte recovery variations from injection volume variations.
- 10.20 Suppose the five standard curve mixtures in this example and then two unknowns are injected at 9 min intervals. All six peaks in the five standard levels appear normal, and peaks A, B, and C appear in the first unknown as described in Table 10.2. In the second unknown, the IS is again at 8.2 min, and peaks are seen at the same times as A, B, and C in the previous chromatogram, but there is now a symmetrical Gaussian peak at 4.55 min. with a w_b of 19 s.
 - a. Should we identify and quantitate this as component 5?
 - b. What does the width of this peak tell us?
 - c. Where did it come from?
 - d. How can we confirm our hypothesis as to its origin?
 - e. How should we modify our operating procedure to deal with peaks like this?

BIBLIOGRAPHY

Ayres, G.H. Quantitative Chemical Analysis, 2nd; Harper and Row: New York, 1968.

Berthod, A. Chiral Recognition in Separation Methods, Springer VCH, Berlin, 2010.

Bouchonnet, S. Introduction to GC-MS Coupling, Taylor & Francis, Boca Raton, 2013.

Giddings, J.C. Unified Separation Science; Wiley: New York, 1991.

Harris, D.C. Quantitative Chemical Analysis, 5th; W.H. Freeman: New York, 1999.

Hyotylainen, T.; Wiedmer, S.; Smith, R.M. *Chromatographic Methods in Metabolomics*, RSC Pub., Cambridge UK, 2013.

Jonsson, J.A., Ed. Chromatographic Theory and Basic Principles; Marcel Dekker, Inc.: New York, 1987.

Miller, J.M. Chromatography: Concepts and Contrasts; Wiley: New York, 1987.

Scott, R.P.W. Techniques and Practice of Chromatography; Marcel Dekker, Inc.: New York, 1995.

Scott, R.P.W. Introductio to Analytical Gas Chromatography; Marcel Dekker, Inc.: New York, 1998.

Shaliker, R.A. *Hyphenated and Alternative Methods of Detection in Chromatography*, Taylor & Francis, Boca Raton, 2011.

Skoog, D.A.; Holler, F.J.; Nieman, T.A. *Principles of Instrumental Analysis*, 5th; Harcourt, Brace and Company: Orlando, FL, 1998.

Willard, H.H.; Merrit, L.L.; Dean, J.A.; Settle, F.A. *Instrumental Methods of Analysis*, 7th; Van Nostrand: New York, 1988.

Wixon, R.L.; Gehrke, C.W. Chromatography: A Science of Discovery, Wiley, New York, 2010.



Gas Chromatography

11

11.1 HISTORICAL DEVELOPMENT OF GC: THE FIRST CHROMATOGRAPHIC INSTRUMENTATION

The general concept of **gas chromatography** (GC) was put forward in a Nobel Prize-winning paper by Martin and Synge in 1941, and implemented by James and Martin in 1952 under the name of vapor phase chromatography. In gas chromatography, the *mobile phase* is a gas, usually nitrogen, helium, or hydrogen, introduced to the column through a pressure regulator from a cylinder of compressed gas. These mobile phase gases do not have significant solvation interactions with analyte molecules. Initially, the stationary phases were high boiling liquids dispersed on a particulate solid support, which was then packed into a column of metal, generally stainless steel or copper, or borosilicate glass tubing 1/16 to 1/4 in. in diameter. Hence the terms gas-liquid GC (sometimes expressed as GLC) and packed column GC. The coated particles were secured by plugs of glass wool or porous metal frits at each end. The column (wound in a coil to fit) was maintained in a thermostatted oven (or even a water bath) set to a controlled constant temperature (Figure 11.1). Higher molecular weight analytes, with higher boiling points, would require correspondingly higher temperatures to partition sufficiently into the gaseous mobile phase to be eluted in a reasonable time. True liquid stationary phases would eventually begin to vaporize slowly at such elevated temperatures and be carried off the column as well, a phenomenon referred to as column bleeding. In time, such liquid stationary phases were replaced with very high molecular weight polymers, especially long-chain, substituted silicones (cf. Section 10.5), which would behave like liquids to the analytes, but which were stable at higher temperatures. At high enough temperatures, these would eventually bleed as well, but instead of volatilization of intact molecules of the stationary phase, this was now due to stepwise loss of small fragments from the ends of the polymer chains. Liquids still do find application in specialized circumstances and are certainly encountered in the literature. A comprehensive listing of liquid stationary phases, including specialized liquid crystalline liquids, can be found in the book by Bruno and Svoronos.

Mixtures of volatile liquids (e.g., the components of a petroleum oil fraction, mixed products of an organic synthesis procedure, lipid mixtures, etc.) would be sampled with a **syringe**, and injected on the GC column for separation and detection of separated components (Figure 11.2).

The mobile phase gas, called the **carrier gas**, would be introduced to the head of the column into an unpacked open space above the restraining frit or plug. This empty volume lay beneath a plastic or silicone rubber **septum**, which sealed the top of the column and through which the syringe needle could be inserted.

The liquid mixture was injected, vaporized at the elevated oven temperature, and was swept along by the carrier gas to initially pile up as a narrow band on the beginning of the packing. Its components subsequently progressed more slowly, at different rates along the packed portion of the column, and the chromatographic separation ensued. If the carrier gas were helium or hydrogen, these very low molecular weight gases had much higher thermal conductivity than almost any analyte they might carry off the column. A simple detector at the effluent end of the column produced a signal proportional to the amount of analyte in each eluting peak. This resulted from the increase in electrical resistance of a wire placed in the effluent stream and heated by passage of an electrical current. This was initially thought

- 2. Because diffusion is so much more rapid and viscosity so much lower in gases than in liquids, mass transfer equilibrium between stationary and mobile phases in GC was easily achieved while using large-dimension packing particles, in the range of $100-1000~\mu m$. It was not necessary to use complex pumps to achieve suitable pressures, as was required for the later realization of instrumental LC, which is performed in packed beds of much smaller particles ($1-10~\mu m$).
- 3. One parameter for controlling partition between the phases, the temperature, was easily varied and maintained by readily available thermostatted oven technology.
- 4. A simple, universal detector, the **katharometer**, or **thermal conductivity detector** (TCD), applicable to chromatography with analytes eluting in the gas phase, was available to provide an electrical signal which could be displayed as a chromatogram.

11.2 ADVANCES IN GC LEADING TO PRESENT-DAY INSTRUMENTATION

If the dimensions of stationary phase coating thickness and diffusion distance to the film from the gas phase have been optimized, for further improvement of GC resolution, it becomes necessary to increase the length of the column. This is seen from the simple relation of Equation 10.7, which indicates that for an optimal minimized value of H (the height equivalent to a theoretical plate), the number of plates, N, is proportional to the length of the column. From Equations 10.8 and 10.9, we note that the resolution is proportional to the square root of N. For columns packed with particles of optimal size, and operated at the optimal linear flow rate at the minimum of the Van Deempter curve (Figure 10.11), the typical maximum pressure of ~100 psi achievable from a regulated gas cylinder requires that most packed columns be less than 4-7 m long. More typically, they are only 2-4 m in length. These considerations limit the resolution achievable in packed column GC.

In 1958, Marcel Golay demonstrated that coating the stationary phase on the inner walls of narrow bore tubing of capillary dimension (generally in the range of 0.1-0.5 mm diameter) could allow columns up to 50 or even 100 m to be operated within these pressure ranges. When the flow rate was optimized, the H values were similar to or even better than those obtainable from the best packed columns, so the much longer *open tubular* or *capillary* columns could have much larger values of N, and consequently much greater resolution. Since they have no packing, the H values for capillary columns can be smaller because there is no contribution from a multipath A term in Equation 10.10.

A number of additional advances in GC instrumentation were necessary before the advantages of capillary columns over packed columns could be widely employed.

- 1. The actual amount of stationary phase per unit column length on a capillary column is much less than that supported on the particles of the typical packed column. Therefore, the capacity for analytes of the capillary is much less than that of the packed column. When the capacity is exceeded, the analytes will spread out over the front of the column after injection, and the improved resolution of the capillary will be lost. This results in the phenomenon of **leading** or **fronting** peak shape described in Section 10.4. In capillary GC, the concentrations of the injected analytes must be decreased, often by dilution with solvent to levels which are at concentrations in the part per thousand or ppm level. For this to be practical, detectors must be orders of magnitude more sensitive than the TCD mentioned in Section 11.1 and described in Section 11.7.1.
- 2. Inventors developed a variety of *ionization detectors* based on measurement of the tiny currents of ions or electrons induced or suppressed when analyte peaks eluted. One, the flame ionization detector (FID), was almost universal, giving sensitive and generally similar responses for almost all carbon containing compounds capable of eluting through a GC system. Others were even more sensitive, and displayed selectivities for certain classes of organic compounds, such as halogen or other electronegative substituent-containing compounds (electron capture detector, ECD), nitrogen- or phosphorus-containing compounds (NPD), or sulfur- and

- phosphorus-containing compounds (FPD). These and several others will be discussed at length (Section 11.7). The key point is that the sensitivity of these detectors was sufficient to measure the low levels of analytes which were within the column capacity of capillary columns.
- 3. The typical GC syringe injection volume of 0.5-2 μL of liquid solvent typically expands to 0.5-1.5 mL vapor volume, depending on injector temperature. This is a volume increase on the order of 1000×. A capillary GC column is operated at a much lower flow rate than a packed column (typically on the order of 1 mL/min instead of 20-40 mL/min). The handling of the volume of vaporized solvent and analyte(s) in capillary GC required a more complex control of gas flows in and out of the injector volume. At the typical capillary column flow rates, it may require a minute or more for all this vapor volume to be transferred to the column. To prevent the analytes from spreading out after entering the column, the column oven must be maintained at a temperature much lower than that used to vaporize the sample in the injector space. This requires that a separate *injector port* volume be independently heated to a different and higher temperature than the initial oven temperature.

If the analyte concentrations are so high that they will overload the column, an automatic diversion valve may be used to *split* the sample, allowing only a small percentage (1-5 %) of the injected vapor volume to enter it. Split and split-less injection is described in Sections 11.3.4 and 11.3.5.

4. Long capillary columns must be coiled to fit in a GC oven. While this can be done with metal capillary tubing, metal at the elevated temperatures used in GC often interacts unfavorably with many analytes. Such interactions, which could lead to complete analyte destruction, or tailing, as described in Section 10.4, will more severely impact the smaller sample levels required in capillary columns. The development of the flexible fused silica capillary GC column described in Section 10.5 resulted in the domination of the GC market by open tubular columns and instruments tailored to their use. Fused silica capillaries were easy to install. They were more inert (i.e., contained fewer active sites causing tailing), than glass or metal capillaries, or the particle supports used in packed column GC. Even when the resolution of packed columns was sufficient for simple separations, a capillary coated with the same stationary phase could achieve equivalent separation in a shorter run time.

Packed columns, especially those with diameters larger than 2 mm, will possess much higher analyte capacity than capillaries. They are still preferred for gas analysis (Section 11.10.3) and for preparative separations, where the separated peaks are captured for later processing or use. The TCD is still the most universal detector, responding to everything but hydrogen or helium when these are used as the carrier gas. When it is necessary to analyze for the gases that are commonly used as carrier gases, it is possible to use a special mixed carrier gas (8.5 % hydrogen in helium, mol/mol) that has a minimum in thermal conductivity. It is also possible to detect and measure hydrogen in a helium carrier stream if the polarity of the TCD is momentarily reversed during the passage of the hydrogen peak. Note that this is not the most sensitive method to determine hydrogen, however. Additional information on carrier gases for GC in general and for TCD use in particular can be found in the book by Bruno and Svoronos. Compounds such as carbon monoxide, oxygen, nitrogen, and small molecules not containing carbon require TCD use, and its low sensitivity often dictates the use of high concentrations of analytes requiring the peak capacity of packed columns. Some regulatory standard assay procedures developed in the early days of GC instrumentation still specify the use of packed columns, although most of these have been updated to capillary GC equivalents. Therefore, we shall discuss GC and GC instrumentation primarily from the perspective of open tubular column GC. For those needing more detailed information on packed column GC, the reference by Scott (1998) should be consulted.

11.3 GC INSTRUMENT COMPONENT DESIGN (INJECTORS)

11.3.1 SYRINGES

The most common way of introducing a sample into a GC instrument is with a syringe. The typical hypodermic syringe used to administer vaccines or intravenous medications has a volume on the order of 1 mL, a plastic body and plunger, and a sharply pointed, detachable needle with an internal bore of 0.2-0.5 mm, and is often designed for onetime use. In contrast, the usual GC syringe has a narrower bore, permanently attached needle, long enough (2-3 in.) for the tip to penetrate to the center of an injector port, a volume on the order of 5-25 μ L, and is composed of a glass body with a very tightly fitting metal plunger. Figure 11.3 shows several typical GC syringes.

The usual volume of liquid sample or solution injected is 0.5- $2.0\,\mu\text{L}$ when open tubular GC columns are used. Larger volumes might expand to a vapor volume >1-2 mL, which is larger than the capacity of a standard heated injector port, and *blow back* into the gas supply system and condense there. Such vapor volumes would require an excessive time to transfer to GC columns at typical 1-2 mL/min capillary flow rates. The GC syringe needle must be very narrow, both to minimize the volume of sample remaining in the syringe when the plunger is depressed, and to pass smoothly through the deformable silicone **septum disc** (Figure 11.4) which withstands temperatures up to 250 °C, and seals the entrance to the injector port to maintain the column **head pressure**. Too wide a needle diameter could cut out a plug of the septum, a process called *coring* (as in coring an apple).

This causes gas leaks, preventing the GC from maintaining the desired head pressure, and the **septum core** is likely to be projected into the hot injection port, where it will decompose to liberate *septum bleed* into the column or trap sensitive analytes. Syringes designed for very small volume injection (< 1 μ L) may contain the sample within the bore of the needle itself; expelling it with an internal wire plunger. Such designs place a limit on how narrow



FIGURE 11.3 Syringes used for GC: **(a)** Microliter syringe for liquids. **(b)** Gastight syringes for gas samples/headspace analysis. (Courtesy of Hamilton Company, Reno, NV. www.hamiltoncompany.com.)

like miniature versions of the GC injector port septum. The rack or carrousel moves to present each vial sequentially to a GC syringe mounted in a robotic assembly. The syringe penetrates the sample vial septum, the plunger is pumped several times to pull up a set volume of sample and expel air bubbles. Then the syringe is withdrawn, moved over the injector port septum, inserted smoothly and rapidly, and the plunger depressed to complete the injection. Upon injection, a signal is sent to the GC electronics to initiate any temperature control programs needed in the various GC ovens and to the detector and recording electronics to start recording the chromatogram signal. Many refinements can be programmed into these operations. For example, a plug of air may be drawn into the syringe before the sample volume is pulled up, and after sampling the plunger is further withdrawn in air again to pull the entire sample out of the needle bore. The sample is thus sandwiched between two plugs of air. When the needle is initially inserted into the hot injector port the needle is empty; solvent is not present in it to start vaporizing prematurely. When the plunger is depressed, the rear air plug forces the entire sample from the needle and again there is no boil off of the sample from within the hot metal needle. The long thin narrow-bore needle required for these microliter injections is the weak point of the syringe-through-septum technique. Bad operator technique or autosampler malfunction can easily result in a severely bent needle. Once it is bent, the one-piece GC syringe/needle assembly is beyond repair. This is called "zeeing" the needle, since the needle often resembles the letter z after malfunction. Typically, if a needle is misaligned or is faulty, the failure will result quickly; the needle will zee after the first or second injection. If a syringe is properly aligned and is of good quality, it will usually function well for hundreds of analyses before wear causes a malfunction.

11.3.3 SOLID PHASE MICROEXTRACTION (SPME)

A recently developed procedure called SPME combines the principles of the mini-column sample isolation and concentration technique of SPE (Chapter 1), and the technique of automated GC sample injection via a syringe assembly. A small amount of a solid phase into which analytes can partition from the sample is coated on one end of a fine fused silica fiber (See Figure 1.9). These solid phase materials can often be the same as GC stationary phases. The other end of the fiber is fastened to a GC syringe plunger, such that the coated portion of the fiber can be extended beyond the needle tip, or be withdrawn entirely within the needle. A sample, generally liquid, is contained in a septum-capped vial. The syringe needle pierces the sample vial septum, and the fiber is extended for several minutes—either into the sample liquid or the headspace gas above its surface. Analytes partition and concentrate into the fiber coating. The volume of this solid phase coating is very small; hence the "micro" in SPME. After equilibration, the fiber is retracted; the syringe needle is pulled from the vial, and it is then inserted through the GC septum into the heated injector port, where the fiber is immediately re-extended. Analytes are thermally desorbed and are swept by the carrier gas flow to the top of the much cooler capillary GC column, where they collect. The column temperature is raised to an appropriate value and separation of analytes proceeds in the normal fashion.

The SPME injection procedure is illustrated in Figure 11.6. If the sample matrix is not so dirty that it coats the fiber with high boiling material that is not thermally desorbed, the fiber may be used for many repeated sampling and injection cycles. If the analytes are quite volatile, it may be possible to sample them in the confined headspace volume above a "dirty" matrix, thereby avoiding the contamination of the fiber by high boiling contaminants. This **headspace analysis** is one of the most useful modes of SPME injection. The fiber concentrates only a small portion of the analytes, but all of the extracted material is injected into the GC by the thermal desorption process. Contrast this with classical liquid-liquid extraction or SPE procedures, where the extract is into a large volume (e.g., 1-10 mL), which must then be concentrated (to perhaps 25-100 μ L), of which perhaps only 1-2 μ L may be injected. A good application of headspace SPME analysis would be for volatile organic vapors (alcohols, solvents, hydrogen cyanide, etc.) from a messy whole blood sample. The amount of analyte absorbed is based on the equilibrium concentration that accumulates in




FIGURE 11.6 Diagrams of SPME **(a)** Extraction sampling, and **(b)** GC desorption injection. (Used with permission from Sigma-Aldrich, a part of MilliporeSigma. www.sigmaaldritch.com. Copyright 2020 Sigma-Aldrich Co. LLC. All rights reserved.)

the fiber, and it is far from the total amount of analyte present in the sample. This equilibrium concentration can vary substantially with equilibration time, temperature, and other conditions. To obtain quantitative data when employing SPME, it is necessary to calibrate against an IS introduced into both unknowns and calibration solutions. The IS must behave in a fashion similar to the analytes, both in its equilibration behavior and in its response to the GC detector employed. Even when using an IS, good quantitative values are difficult to obtain, unless the IS is an isotopically labeled version of the analyte, and it is used with mass spectrometric detection. The fiber coating in SPME is often the same as a GC stationary phase. Analytes are moved off it into the GC column by varying the same parameter, temperature, which controls GC elution. In the capillary GC column, the coating is on the inside of a long cylindrical tube. On the SPME fiber, it is on the outside of a short cylindrical rod, of slightly smaller diameter. For this reason, SPME sampling and injection is sometimes characterized as "inside-out gas chromatography". It is not really chromatography, because there is no continuous partitioning to mobile phase, but otherwise many of the principles and materials are similar.

11.3.4 SPLIT INJECTIONS

The sample capacity of capillary columns is limited. GC analysis of neat mixtures or highly concentrated solutions may require that only a portion of the sample which is vaporized in the injection port enters the column. Modern capillary GC instruments often feature a **split**splitless injector. This has a time programmable on-off valve controlling flow to a split vent gas line from the injector port. When this valve is open, only a fraction of the carrier gas flow (and of the vaporized injected sample) passing through the injector port enters the column. The rest flows out the split vent. The relative proportions passing to the column and the vent may be adjusted by a variable needle valve (the backpressure regulator) in the split vent line. The ratio of split vent flow to column flow can typically be varied from 5 to 100, and is called the split ratio. When operating the GC column isothermally (at a constant temperature chosen so analytes move down the column at a reasonable rate), the sample must enter the column over a short time, if the initial chromatographic bandwidth is to be minimized. At capillary column flow rates of ~1 mL/min. the ~1 mL vapor volume from a 1 μL injection would take about a minute to load onto the column, and the sample would spread out during loading. With the much larger flow through the port with the split vent open and set to a high split ratio, a small fraction of the vapor cloud enters the column over a much shorter period. A diagram of the flows in the **split mode** of a split-splitless injector is illustrated in the upper section of Figure 11.7.




FIGURE 11.7 Diagram of GC flows for split and splitless injections: **(a)** split mode; **(b)** splitless mode. (Adapted with permission of Restek Corporation, Bellefonte, PA, www.restek.com.)

Analytical column

To detector

Backpressure regulator

11.3.5 SPLITLESS INJECTIONS

(b)

When sample concentrations are much lower (ppm to <ppb), one will wish for all the analytes to be transferred to the capillary column, and overloading will be less of a concern. As illustrated in the lower section of Figure 11.7, when the valve to the split vent is closed, all of the vaporized sample must flow to the column. When this **splitless mode** of injection is used, the valve must be closed while most of the sample and its solvent vapor have time to enter the column. As discussed (Section 11.3.4), this time may be on the order of 1-2 min. In order that the analytes not spread out on the front of the column, the initial column oven temperature must be well below that at which they begin to move down the column. The lower boiling solvent they were dissolved in will pass rapidly ahead of them. In the splitless mode of operation, the column temperature will then be raised to temperatures (constant or steadily increasing) at which the analytes begin to move down the column and separate. Traces of the much higher concentration of the solvent remaining in the injection port might continue to enter the column and obscure the signals from the lower levels of analytes. Therefore, at the end of the splitless injection period, the valve is returned to the split mode position to rapidly divert the remaining solvent. A high split ratio setting enhances this.

An important technique used with splitless injection is **solvent focusing**. In this approach, the solvent is chosen such that it will accumulate or even slightly condense in the first few cm of the capillary column. This solvent layer forms what might be termed a pseudo stationary phase that prevents the solute species from moving too rapidly down the column, and in fact

focuses the solute at the head of the column. After the period of the splitless operation is concluded, the temperature of the column is rapidly increased just enough to begin vaporization of this solvent layer, leaving behind the focused solute to begin moving through the column, for separation, behind this solvent front.

11.4 GC INSTRUMENT COMPONENT DESIGN (THE COLUMN)

11.4.1 COLUMN STATIONARY PHASE

As described in Section 10.5, silicone polymers form the most common and useful class of GC stationary phases. Figure 11.8(a) displays a two-monomer segment of the PDMS chain. This is the fundamental silicone polymer. Various polymers used for GC phases differ in their polarity. The degree to which the polarity of the analyte is similar to that of the phase is an indication of the strength with which it will dissolve into and be retained by the phase. This in turn depends on the analyte's polarity. The general rules of "like dissolves like" and its converse apply here. At one end of the polarity scale are pure long-chain hydrocarbons, whose intermolecular interactions are governed almost entirely by Van der Waals forces (alternatively referred to as London's dispersion forces). These are the least polar compounds and phases. Unless pure hydrocarbons have a molecular weight high enough not to volatilize or decompose under the full range of GC temperatures, they make poor stationary phases. PDMS itself is of intermediate polarity, with the oxygen atoms in its backbone contributing some dipole and hydrogen bonding character to its polarity. Substitution of the methyl groups in PDMS with longer hydrocarbon substituents (e.g., $-C_8H_{17}$ or $-C_{18}H_{35}$) yields a silicone polymer with a lower polarity more similar to hydrocarbons. The oxygen in the backbone is less accessible, and there is a higher proportion of the hydrocarbon-type Van der Waals dispersive interactive surface presented to the analyte.

Figure 11.8(b) illustrates two other types of modification to the PDMS structure. In the "y" monomer, a more polar (by virtue of π -electron bonding interaction) phenyl group has been added. This increases the polarity of the phase, and thereby the retention of analytes which have a similar functionality. In the "x" unit, occasionally substituting a phenyl ring for an O-atom in the polymer backbone again enhances this type of polarity, but it removes the hydrogen-bonding and dipole polarity of the replaced oxygen atom. The net overall effect on the polarity interaction is difficult to predict. It will depend on the structure of the analyte. Such an inserted **spacer** is in fact not present for polarity adjustment, but rather to stabilize the polymer chain against thermal decomposition at high temperatures. This suppresses the phenomenon of **column bleeding**, which results in an increased detector signal and a rising baseline signal as temperature is increased. If one wishes an even more polar column, a substituent such as $-CH_2CH_2CH_2CN$, with a very strong *cyano* group dipole can be substituted for a PDMS methyl. The polarity changes introduced by substitutions such as these phenyl or cyanopropyl groups can be varied by adjusting their percentage on the chain. More information on these compounds can be found in the book by Bruno and Svoronos.

Occasionally, other substituents with reactive end functional groups can be introduced. After the phase is coated on the interior of the column, these groups can be reacted to bond

$$\begin{bmatrix} \mathsf{CH_3} & \mathsf{CH_3} \\ -\mathsf{Si} - \mathsf{O} - \mathsf{Si} - \mathsf{O} \\ \mathsf{CH_3} & \mathsf{CH_3} \end{bmatrix}_n \quad \begin{bmatrix} \mathsf{CH_3} \\ -\mathsf{O} - \mathsf{Si} \\ \mathsf{CH_3} \end{bmatrix}_x \begin{bmatrix} \mathsf{CH_3} \\ -\mathsf{CH_3} \end{bmatrix}_x \begin{bmatrix} \mathsf{CH_3} \\ -\mathsf{CH_2} - \mathsf{CH_2} - \mathsf{O} - \mathsf{I}_n \\ \mathsf{CH_3} \end{bmatrix}_y \quad (c)$$

FIGURE 11.8 Representative monomer units for several common types of GC stationary phase polymers: **(a)** PDMS, **(b)** backbone phenylene-stabilized and phenyl-substituted PDMS (more polar π -electron character), and **(c)** carbowax (polyethyl ether phase).




FIGURE 11.10 Chromatograms of GC separations of a mix of 22 18-carbon fatty acid methyl esters (FAMEs) on **(a)** SP-2560 and **(b)** ionic liquid SLB-IL 100. Note particularly the retention shifts of C18:1 D9c + C18:1 D12t, and many others. C18:X represents X number of double bonds in the 18-carbon chain, and the other D characterization represents their position and geometric orientation along the FAME chain. The ionic liquid responds to these differences more radically than traditional silicone-based polymers. (Used with permission from Sigma-Aldrich, a part of MilliporeSigma. www.sigmaaldritch.com. Copyright 2020 Sigma-Aldrich Co. LLC. All rights reserved.)

the common polymer phases that they often offer a good opportunity to radically shift the selectivity term α in Equation 10.9 or Equation 10.10, when variation of other terms will not achieve sufficient resolution of some analytes. Figure 11.10 displays the difference in elution of 22 fatty acid methyl esters (FAMEs) on a traditional silicone-based GC stationary phase and an ionic liquid. Note the achievement of separation of several geometric isomers about double bonds which coelute with other FAMEs on most traditional GC phases. The initial commercialization of these phases is from Sigma-Aldrich, and more details can be obtained their website listed in Appendix 11.A on the text website.

The descriptions just given highlight a few examples from the major categories of polymer stationary phase coatings. In the modern practice of GC, these are almost always employed in open tubular or capillary columns. Any assay which might employ them in packed column

mode can be implemented more efficiently or faster or both, using open tubular columns, and a vast selection of these are now readily available from commercial vendors. Because many very simple instructional GCs only operate with packed columns, the undergraduate student may still encounter them in the instructional laboratory. They may lack separately heated injector or detector regions and be capable only of isothermal separations. The student should be aware that in industrial and research practice, the analysis time and resolution advantages of open tubular columns makes them the overwhelmingly dominant choice for most applications. Packed column GC is relegated to large-scale **preparative GC**, where the greater sample capacity of wide-bore, packed columns is required, and to a few niche applications such as the separation of fixed gases (Section 11.10.3).

Until the development of immobilized films attached to the tube walls, WCOT columns had two main disadvantages. The small quantity of stationary phase in the column results in limited solute retention. If the coating is applied thickly, the coating becomes unstable and the column deteriorates rapidly. Porous layer open tubular (PLOT) columns were developed, with coatings of alumina, carbon, molecular sieve particles, and the like. Particles are generally 1-5 μm in diameter, with a coating thickness of 20 μm or so. They are stable and have a significantly greater sample capacity than immobilized film columns. Some examples of PLOT column separations are given in Section 11.10.3.

11.4.2 SELECTING A STATIONARY PHASE FOR AN APPLICATION

With thousands of possible analytes, even more different combinations of these analytes, and upwards of a hundred stationary phase materials generally available, how should one go about selecting the right column for the job? In earlier times, analysts compiled tables of McReynolds or Rohrschneider constants of characteristic compound types for different phase materials. If the data for the compounds of interest were available from these tables, one could employ these values with calculation algorithms to estimate the relative elution orders and resolution of the components on different columns. This approach has fallen into disuse. A modern commercial capillary column with all the features described in Section 11.4.1 is a very highly engineered product, not easily created or duplicated in the analyst's lab. The column manufacturers have amassed extensive databases and application notes for optimum separations using the most suitable columns from their stables. The best place to start when looking for a column and phase to achieve separations for a group of analytes is the book by Bruno and Svoronos. In addition, it is often useful to consult the manufacturers' applications literature. Their catalogs, in hardcopy or on searchable CD-ROM disc, and their websites, with search programs for the analyst to enter the compound type or application, illustrate thousands of optimized separations. It is beyond the scope of this chapter to attempt to summarize this information. Appendix 11.A on the textbook website lists some selected web resources. The student is encouraged to access them, or catalog data if available, to gain a sense of the scope and organization of this information. This is where one should now start when confronted with a GC separation problem.

Once a reasonably suitable column phase has been identified, the dimensions of the column employing it should be selected, and then the separation is optimized by varying the flow and temperature parameters. The column dimension decisions will depend on the difficulty of achieving the necessary peak resolutions, which is likely to increase with the number of analytes to be measured. The column's analyte capacity depends on these dimensions as well. The column dimensions, carrier gas flow, and column oven temperature parameters thus chosen will determine the time required to perform each GC run.

It may be useful to attach a length of uncoated capillary tubing to the front of the coated column. This **retention gap** serves two purposes: it allows space for the injected sample and solvent vapors to collect on the column without being significantly retained until they encounter the coated portion. Dirty, poorly volatile contaminant residues can accumulate in this region, and front portions of the gap section can be cut away to remove these without affecting the separating and retaining functions of the column. When the gap region becomes too short, it can be replaced by another. Figure 11.11 illustrates the processes which




FIGURE 11.11 Illustration of on-column injection with a retention gap. (Cazes, used with permission.)

occur following sample and solvent injection on a capillary column using a similar procedure, **direct on-column injection**. Here, an extremely fine syringe needle actually enters the capillary column, bypassing the injector port (whose heater should be turned off), and deposits the liquid sample solution directly in the gap region of the column, usually at a low starting temperature near or below the solvent's boiling point. This is a delicate process, required for delicate, thermally unstable analytes, which might be destroyed by vaporizing in a hot injector port. After vaporization, the retention gap functions as illustrated, whether the injection is on-column or through a splitless injector.

11.4.3 EFFECTS OF MOBILE PHASE CHOICE AND FLOW PARAMETERS

A column with a particular stationary phase and dimensions has these as fixed parameters. To change these parameters, a different column must be obtained (purchased) and installed. New columns require a significant **conditioning** or "breaking in" period after installation. This conditioning process should be done with the column connected to the heated injection port but not to the detector port. This will prevent residual monomer and other impurities from contaminating the detector.

Another fixed parameter is the choice of mobile phase (the carrier gas used). Three are commonly employed: helium (He), hydrogen (H_2), or nitrogen (N_2). As discussed in Section 11.7, proper operation of the GC detector being used will sometimes dictate use of a particular carrier gas. If the detector tolerates any of these gases, then their flow and diffusion characteristics govern how well each attains optimum chromatographic resolution. This is best illustrated by their respective **Van Deempter curves** (cf. Sections 10.8 and 10.9, Equation 10.10, Figure 10.11). These are displayed in Figure 11.12. N_2 has the deepest **minimum** H (HETP) value (i.e., greatest efficiency), but only over a limited range of linear flow rates, u.




FIGURE 11.12 Van Deempter plots for three GC carrier gases: N_2 , He, H_2 : H (height equivalent to theoretical plate) versus u (linear flow velocity, cm/s).

Lighter gases He and H_2 do not quite attain such low H values, but they stay lower over a much wider range of u than does N_2 . One would like to operate the column close to the flow rate of the Van Deempter minimum for the gas. Modern chromatographs equipped with automatic flow controllers can maintain the flow at this point as other parameters change. In the absence of constant flow mode, if one is raising the column temperature over the course of an analysis, it is better to use the light gases and to start at a flow rate above the Van Deempter minimum. As column temperature goes up, gas viscosity increases, and the flow will decrease toward the minimum position of H. Information on carrier gas viscosity as a function of temperature can be found in the book by Bruno and Svoronos. Low values of H are more difficult to maintain over the steep-sided valley of the N_2 curve. In Section 11.7, we will see that such rising **temperature programs** are often required to optimize separations of mixtures of large numbers of compounds.

Helium is more expensive to purchase than N₂ or H₂. N₂ can be generated on-site at 99.9995 % purity from standard compressed air using a laboratory gas generator; H₂ can be generated on site from water electrolysis. (See the Parker Hannifin Gas Filtration and Generation Division websites, www.labgasgenerators.com or www.parker.com, for examples). Shortfalls in the availability of He are becoming more common, even in the US. Many large organizations (for example, those with multiple NMR instruments) have installed He recapture systems. H₂ forms explosive mixtures with air. A catastrophic column rupture or leak might allow enough into the oven to contact hot heating coils and trigger an explosion. The US held a near monopoly on He, so GC users there preferred it to H₂ on grounds of safety. In Europe and elsewhere, chromatographers learned to use H₂, since He was not available (recall that the Hindenburg Dirigible was forced to employ hydrogen to its ultimate demise). The capillary GC resolution performance of H₂ exceeds even that of He. As flow controllers became more available on GC instruments, and lower flow capillary systems became the norm, one could program them to recognize a sudden catastrophic H₂ leak and command the shutdown of carrier gas flow before the H₂ concentration reaches dangerous values. This facilitates the use of superior H₂ as a carrier gas. While it is simple to use with flame ionization detectors, which add in H₂ for the flame, or thermal conductivity detectors which require either He of H₂ as mobile phase gas, care must be taken when interfacing a column end directly into the vacuum of an MS system. If an insufficiently long or narrow column is so interfaced, retention times and orders may shift significantly from values observed in non-vacuum interfaced systems, and the increasingly common GC electronic flow controllers may be forced unsuccessfully to try to set the exit pressure to negative values. Too high an H₂ pressure in the MS ion source may result in its reaction with analytes to produce a non-standard EI mass spectrum, with molecular ions adding an H atom. These problems may be circumvented by installing a flow restrictor at the column end.

11.5 GC INSTRUMENT OPERATION (COLUMN DIMENSIONS AND ELUTION VALUES)

The column temperature is the major instrumentally controllable variable that can be used to affect the speed and resolution of the GC separation. Much precision engineering goes into designing ovens which can precisely control and reproduce the temperature profile that the column encounters during each analysis.

Before we move to a description of how temperature affects peak elution on GC columns, let us review how some of the column dimension and stationary phase composition factors interact. In Figure 11.13(a), we see the effect on retention time and resolution of increasing the stationary phase **film thickness** d_p and thereby lowering the **phase ratio** (cf. Section 10.7, Equation 10.2). Thicker films are especially effective at retarding faster eluting components to elute at suitable k' values (cf. Equation 10.3), while providing modest improvements in the resolution of close pairs eluting in the middle of the run. The primary value of the thicker film is to keep very volatile components from eluting too fast before they have time to separate well. It also confers greater column capacity against overloading, which would result in leading peaks and degrade resolution. Another way to increase resolution is to use a longer column, as illustrated in Figure 11.10(b). Note that for the illustrated pair separation,




FIGURE 11.13 Effects of stationary phase film thickness or GC column length on retention time (R_t) and resolution (R). (a) Film thicknesses (d_t) of 0.25, 0.50, and 1.0 μ m (30 m × 0.25 mm PDMS column) and (b) column lengths (L) of 15, 30, and 60 m (0.25 mm × 0.5 μ m PDMS column). (Used with permission from SGE analytical science, Pty Ltd, Melbourne, Australia, www.sqe.com.)

the longest column takes a little longer and does not achieve quite as good resolution of this pair as did the thicker film column. Moreover, diffusion broadening of peaks is more of a problem as the column length is increased. The longer column is more costly and requires higher pressures to achieve a flow to operate it at the Van Deempter optimum. Thus, longer columns are not always the best way to achieve better separation. Going to a longer column should be the last resort. Recall from Equation 10.8 that resolution increases only as the square root of the number of plates, N, or the column length, L. Note that it is not necessarily the thicker film that provides the better resolution, it is lowering of the phase ratio. This could also be achieved with a thinner film and a correspondingly narrower bore column, to achieve the same low phase ratio. With a thinner film, equilibration in the stationary phase would be faster as well, leading to even lower values of H (plates/m) and a more efficient column. However, the narrow bore thin film column has less capacity and is more easily overloaded, and it requires higher head pressures to be operated at or above the Van Deempter optimum. The pressure limits of the GC may limit the usable length of such columns.

In Figure 11.14(a), we see how a shorter column, with film thickness and diameter reduced to keep phase ratio constant, can achieve nearly the same separation performance in half the




FIGURE 11.14 (a) Comparison of PAH separations on a column of normal dimensions and on a column designed for *fast GC*. **(b)** Comparison of BTEX compound separations on carbowax and PDMS GC phases. (Used with permission from SGE Analytical Science, Pty Ltd, Melbourne, Australia, www.sqe.com.)

time as a column of more normal dimensions. If overloading can be avoided, this is the road to achieving **fast GC**. For some detectors, the lower carrier gas flow is a benefit; for others designed for higher flow levels, special adjustments (e.g., use of **makeup gas**, cf. Section 11.7, Item 4) may be required. If none of these resolution enhancing tricks and no adjustments of the column temperature will achieve resolution of critical analyte pairs, it is time to fall back and consider finding a column with a different stationary phase to do the job. A classic example is the analysis of BTEX (benzene, ethyl benzene, toluene, and three isomeric xylenes)—all single ring aromatic hydrocarbons. Many silicone-based phases fail to separate the *meta-*(1, 3-dimethyl) and *para-*(1,4-dimethyl) benzenes (xylenes). This is illustrated in Figure 11.14(b), where the SolGel-1MS (a PDMS-type phase) fails, but the BTEX compounds are all separated on a SolGel-WAX (carbowax-type phase). Note that the other xylene isomer, the *ortho-*(1, 2-dimethyl), is more strongly retained on either phase. In general, one cannot predict relative retention for similar structures precisely enough to guess which peak is which or whether a given phase will separate them or not. This is where recourse to the manufacturer's databases on separations and phases is invaluable.

11.6 GC INSTRUMENT OPERATION (COLUMN TEMPERATURE AND ELUTION VALUES)

Finally, we reach the discussion of the most easily adjusted variable controlling GC peak elution. Recall from Chapter 10 that for a given stationary phase, the temperature of the column is the primary determinant of the equilibrium partition ratio between the stationary and mobile phases. The larger the percentage of time the analyte spends in the gas flow of the mobile phase, the more quickly it elutes from the column. A modern GC instrument is designed to precisely and reproducibly control the temperature of the oven compartment in which the coiled-up column resides. This will promote reproducible retention times to enable peak identification.

In a very simple GC analysis of a group of similar analytes which would elute close together, the analyst chooses an appropriate stationary phase, optimizes its film thickness, and selects the necessary column diameter and length, all as outlined in Section 11.5. Then, the oven is set to a column temperature where k' for these analytes is between 2 and 10 (cf. Equation 10.3). The highest value of temperature T at which adequate resolution of the closest eluting pair is observed will yield the fastest analysis. Such operation is called **isothermal GC**. It is the simplest for the temperature controllers to maintain, and as soon as the last component has eluted, the instrument is ready to accept injection of the next sample.

Most often, more complex mixtures of components varying widely in polarity and volatility must be analyzed. In Figures 11.15 and 11.16, we will examine the problems these sorts of mixtures present for the development of a simple isothermal GC analysis, and we describe how to separate them all in a single GC run. The two figures illustrate the **early eluting** and **later eluting** peaks of a single analysis. The column parameters have been selected: a 30 m long, 0.25 mm inside diameter (i.d)., 0.25 μ m film PDMS column; the archetypical standard capillary GC column. It uses H₂ carrier flow controlled at 46.3 cm/s, the minimum of the H₂ Van Deempter curve. The column *dead time*, $t_{\rm m}$, was determined to be 1.08 min. The analytes consist of four groups:

- 1. Normal straight-chain hydrocarbons, labeled C9 through C15, for the number of carbons in the chain
- 2. A group of three branched-chain C10 hydrocarbon isomers, labeled 3 C10s
- 3. A group of three branched-chain C14 hydrocarbon isomers, labeled 3 C14s
- 4. Three dimethylnaphthalene isomers, labeled D1, D2, and D3

There are several points of caution to note when interpreting these figures:

1. These "chromatograms" were not obtained on an actual GC instrument. They are accurate simulations of retention data from a computer program using data on the column and the analytes.




FIGURE 11.15 Separations of three branched chain C10 hydrocarbons, and C9, C10, C11 n-alkanes on 30 m \times 0.25 mm \times 0.25 μ m PDMS column; At **(a)** 100 °C, **(b)** 120 °C, **(c)** 150 °C, and **(d)** programmed 100 °C/1 min-10 °C/min-140 °C/4 min early eluting peaks. (Separations simulated using pro $EZGC^*$ software, Restek Corp., Bellefonte, PA, www.restek.com. Used with permission.)

- 2. The retention time axes *differ* for each run, a through d (i.e., the peaks do not line up with one another on a single elution time axis).
- 3. Only retention time and peak width data are simulated, to illustrate analysis time and resolution. The peaks are always displayed at the same height (except when they merge), while in a real chromatogram, as peaks having the same amount of analyte, with equal detector response, were eluted more slowly, their height would decrease as their width increased, thus keeping their area constant.

Parts a, b, and c of each figure illustrate three isothermal GC analyses, at 100 °C, 120 °C, and 150 °C, respectively. At 100 °C isothermal, the three early eluting branched-chain C10s elute sufficiently far from $t_{\rm m}$ to be well resolved from each other and from C9. As the temperature is increased, they begin to elute too close to $t_{\rm m}$ (i.e., k' becomes too much less than 2) and




FIGURE 11.16 Separations of three branched chain C14 hydrocarbons, three dimethylnaphthalene isomers, and C13, C14, C15 n-alkanes on 30 m × 0.25 mm × mm PDMS column; At **(a)** 100 °C, **(b)** 120 °C, **(c)** 150 °C, and **(d)** programmed 100 °C/1 min-10 °C/min-140 °C/4 min, late eluting peaks. (Separations simulated using pro EZgc* software, restek corp., Bellefonte, PA, www.restek.com. used with permission.)

resolution is lost. On the other hand, if we look at the later eluting sections in Figure 11.16, we see that at 100 °C isothermal, C15 requires more than 30 min to elute. If we could run the separation at 150 °C isothermal, last peak C15 would be out in only 4.5 min and we would still be able to resolve all the earlier eluting peaks. By contrast, the poor separation of C9 and three C10s in Figure 11.15(c) reveals that this temperature would not do for the early eluters' separation. The solution to the problem is to change the temperature as the run proceeds. Start at 100 °C, and when the initial group of peaks has been resolved and eluted, increase the temperature linearly to around 150 °C to speed up the elution of the less volatile components. This is what was done in the chromatograms depicted in (d). The procedure is called **programmed temperature GC**. The temperature program illustrated is abbreviated as "100 °C (1 min)-10 °C/min-140 °C (4 min)". Translated, this states that the oven was held

at 100 °C isothermal for 1 min, then programmed to increase steadily at a rate of 10 °C/min to 140 °C, where it is held for 4 min. Now all peaks are resolved and the entire analysis takes only 9 minutes (plus enough time for the oven to be rapidly cooled back to the starting temperature to repeat the program for the next sample). The cool down time is short (a minute or two) unless the start temperature is close to room temperature, where the cooling rate becomes very slow. If such is the case, liquid CO_2 or even liquid N_2 injection to the column oven may be employed to speed the last stage of cooling. An alternative to the injection of these fluids into the oven is the application of the vortex tube to speed cool down. A vortex tube is a device that separates a stream of compressed laboratory air into a hot flow and a cold flow, with the cold flow reaching as low as -40 °C. Vortex tube cooling in many aspects of chromatography was introduced by Bruno, and includes not only the column but syringes, extractors/concentrators, and sample conditioners (Bruno, T.J., Applications of the vortex tube in chemical analysis, Proc. Contr. Qual., 3,195–207, 1992).

The simplest and most common temperature program is the single linear ramp just illustrated. More complex programs, with multiple ramps interrupted by isothermal intervals may be designed to optimize critical separations and minimize overall analysis time. Environmental and biological samples often contain very slowly eluting heavier background contaminants of no interest to the analysis, which must be cleared off the column before the next injection, lest they elute with and interfere with analyte peaks from subsequent injections. Such late eluters can be recognized because their peaks appear much broader than those of the faster moving analyte peaks that they co-elute with. The cure for these is to rapidly program the column oven to a temperature close to the column stability limit after the last analyte of interest elutes, and to hold it there until all late eluters are cleared. Close comparison of isothermal runs A, B, and C with programmed temperature run D will reveal that in the former, peaks become broader with increasing retention time, while in the latter, the peaks have very similar widths. This can be understood because in the programmed temperature runs each peak (more precisely each band) exits the column at nearly the same rate and has been in the mobile phase for the same length of time. This may seem unobvious, but it can be rationalized if one has a clear understanding of the chromatographic process (e.g., the discussion in Section 10.5), and the explanation is left as an exercise for the student (or the instructor). Figure 11.17 illustrates another aspect of this point in a different manner. Here, the same temperature program is applied to the separation of many acid methyl esters on equivalent columns differing in length by a factor of 2. Although the small scale of the




FIGURE 11.17 Effect of column length on elution time in programmed temperature GC of bacterial long-chain acid methyl esters. (From Restek Corporation, Bellefonte, PA, www.restek.com. Used with permission.)

reproduction prevents it from being seen, the resolution of closely eluting peaks on the longer column is improved by a factor of about 1.4, just the amount predicted by the square root of N relation in Equation 10.8. Note, however, that the analysis time has NOT been extended by a factor of 2, but only from 22 to a little more than 24 min! Under temperature programming conditions, the interval during which the temperature passes through the range where each component moves at a significant rate is only several minutes. This is the order of magnitude of the extra time it takes to complete the analysis on the longer, more highly resolving column.

In Sections 11.5 and 11.6, we have seen that elution and resolution behavior of analytes depend in a complex interactive way upon a number of different factors:

- 1. The *composition* of the stationary phase (*strongly*: effects on both absolute and relative retention) and the mobile phase gas (*less strongly*: effects on resolution via differences in the parameters which control the Van Deempter constants, but essentially no effect on retention).
- 2. Column *dimensions* (length L) and phase ratio (column i.d. and film thickness d_f).
- 3. Column gas flow (depends on gas, pressure drop across column, and temperature).
- 4. Column *temperature* (the major controllable variable, can be very complex if programmed).

Most of these factors interact with one another. One could specify all the equations for these interactions and require a student to master calculations using them to predict the results on a GC separation of varying them. An even more challenging task would be to use them all to optimize a given separation. This is beyond the scope of this introductory chapter, but the need for it remains. The solution is to avail oneself of interactive computer programs which perform the linked calculations almost instantaneously. One such was used to create Figures 11.15 and 11.16. Several are available to download from the World Wide Web at no charge. The **Agilent pressure-flow calculator** allows one to specify all the factors in 2-4, and instantly see the effect of varying any one at a time. The **Agilent** method translator allows retention information from a particular method (with a column described by factor 1) to be used to quickly predict how a separation will change with variation in any of the other three categories of factors. Appendix 11.A on the text website provides instructions to access these programs. The student is encouraged to download them and experiment with the results of varying parameters. The use of free interactive GC separation optimization programs beats working through a tangle of equations whose variables interlock with one another.

11.7 GC INSTRUMENT COMPONENT DESIGN (DETECTORS)

The third and final major component encountered by analytes after the injector and the column is a detector. This produces an electrical signal (usually analog, but often converted to digital) which is proportional to either the concentration or the mass flow rate of the analyte molecules in the effluent stream. The signal is displayed as a chromatogram on the screen of a computer data system. Retention times are automatically calculated, heights of peaks are measured or they are automatically integrated to obtain their areas, peaks can be identified by their elution within in a retention time window and quantitated by comparison to the areas or heights of a quantitative standard. We will not discuss the details of the operation of this signal processing equipment, but will describe only the operation and characteristics of the most useful *GC* detectors.

There are around a dozen GC detectors in common use. Spectroscopic instruments can be interfaced to the effluent of a GC and act as a form of detector which has the compound identification power of a spectroscopic measurement. This mating of a separation instrument to a spectroscopic instrument is called a **hyphenated technique**. The acronyms for the two classes of instruments are separated by a hyphen [or sometimes a slash (/)], as in GC-MS: gas chromatography-mass spectrometry. Hyphenated techniques will be discussed

in Section 11.8. Some of the general characteristics of GC detectors which need to be considered are the following:

- 1. *Universality versus selectivity*: if a detector responds with similar sensitivity to a very wide variety of analytes in the effluent it is said to be universal (or at least almost so—no GC detector is absolutely universal). Such detectors are valuable when one needs to be sure that no components in the separated sample are overlooked. At the other extreme, a selective detector may give a significant response to only a limited class of compounds: those containing only certain atoms, (e.g., atoms other than the ubiquitous C, H, and O atoms of the majority of organic compounds), or possessing certain types of functional groups or substituents which possesses certain affinities or reactivities. Selective detectors can be valuable if they respond to the compounds of interest while not being subject to interference by much larger amounts of coeluting compounds for which the detector is insensitive.
- 2. Destructive versus nondestructive: some detectors destroy the analyte as part of the process of their operation (e.g., by burning it in a flame, fragmenting it in the vacuum of a mass spectrometer, or by reacting it with a reagent). Others leave it intact and, in a state where it may be passed on to another type of detector for additional characterization.
- 3. Mass flow versus concentration response: these two modes of detector response were described in Section 10.4. In general, destructive detectors are mass flow detectors. If the flow of analyte in effluent gas stops, the detector quickly destroys whatever is in its cell, and the signal drops to zero. A nondestructive detector does not affect the analyte, and the concentration measurement can continue for as long as the analyte continues to reside in the detector cell, without decline in the signal. Some types of nondestructive detectors (e.g., the ECD) measure the capture of an added substance (e.g., electrons). The saturation of this process results in a loss of signal to analyte proportionality, and they are mass flow detectors.
- 4. Requirement for auxiliary gases: some detectors do not function well with the carrier gas composition or flow rates from a capillary column effluent. Makeup gas, sometimes the same as the carrier gas, may be required to increase flow rates through the detector to levels at which it responds better and/or to suppress detector dead volume degradation of resolution achieved on the column. Some detectors require a gas composition different from that used for the GC separation. Some detectors require both air and hydrogen supplied at different flow rates than the carrier to support an optimized flame for their operation. Makeup flow dilutes the effluent but does not change the detection mechanism from concentration to mass flow detection.
- 5. Sensitivity and linear dynamic range: detectors (both universal and selective) vary in their sensitivity to analytes. Sensitivity refers to the lowest concentration of a particular analyte that can be measured with a specified **signal-to-noise ratio**. The more sensitive the detector, the lower this concentration. The range over which the detector's signal response is **linearly proportional** to the analyte's concentration is called the *linear dynamic range*. Some exquisitely sensitive detectors have limited linear dynamic ranges, so higher concentrations of analytes must be diluted to fall within this range. Another less than satisfactory solution to a limited linear dynamic range is to calibrate against a multilevel nonlinear standard curve. This requires injections of more standards and is more prone to introduce quantitative error. Dilution will not work satisfactorily if there is a wide range of concentrations in the sample. A very insensitive detector will perforce have a more limited dynamic range, and multilevel standard curves or dilution will be of no avail with it.

Figure 11.18 compares the sensitivities and dynamic ranges of several of the most common types of GC detectors. The further to the left the range bar extends, the more sensitive the detector. The longer the bar, the greater the dynamic range. Each vertical dotted line denotes a span of three orders of magnitude (1000×), so the overall ranges covered are very large. The




FIGURE 11.18 Approximate limits of detection (left end of bar) and dynamic ranges for 12 GC detectors from 1 µL sample injected.

values along the x-axis assume an injected volume of 1 μ L (1/1000 of an mL or cm³) of solution. The ranges are approximate; their exact endpoints will depend on the design and model of the detector and optimization of its operating conditions. They provide a good general comparison. The IRD and MSD at the bottom are hyphenated method spectroscopic detectors, operable in several modes, and will be discussed in Section 11.8. Note that the original GC detector, the TCD, is the least sensitive, but also the only one suitable for handling neat (i.e., 100 % pure single component) samples. The FID has the greatest single-mode dynamic range, while the micro-ECD is more sensitive, but with a more limited dynamic range. Let us proceed to describe the operation, characteristics, and applications for each of these nonhyphenated method detectors.

11.7.1 THERMAL CONDUCTIVITY DETECTOR (TCD)

Universal (except for the H_2 and H_2 and rearrier gas considerations discussed earlier); non-destructive; concentration detector; no auxiliary (aux.) gas; sensitivity based on thermal conductivity differences; limited dynamic range.

The TCD was the first widely commercially available GC detector, in the era when all the columns were packed, and samples to be separated were neat mixtures, not diluted solutions. It measured differences in the thermal conductivity and/or specific heat (actually both, combined in a heat transfer coefficient) of highly thermally conductive (either H_2 or H_2) carrier gas when diluted by small concentrations of much less conductive analyte vapor (anything else). A current through a thin resistive wire heated the wire in the detector flow cell. The thermal conductivity of the flowing carrier gas cooled the wire. When analytes were in the stream, their lower thermal conductivity produced less cooling, which caused the wire's temperature to rise and its resistance to increase. This wire resistor was in a **Wheatstone bridge** circuit (an arrangement of four resistors on the sides of a square). One of the other resistors was in a matching TCD cell connected to a matching column and flow with no analyte passing through. In isothermal GC, carrier flows and temperatures would remain constant, but with temperature programming of the column the temperature would increase and the flow would decrease, independently affecting the conductivity. The matching *reference cell* would




FIGURE 11.19 Diagrams of two types of thermal conductivity detectors (TCD). (Cazes, used with permission.)

compensate for these effects on the resistance changes. A fixed and a variable resistance constituted the other two legs of this bridge. A voltage sensor was connected across opposite points on the diagonal of the square array. The variable resistance was used to null (or "zero" the signal from) the voltage sensor. Once the bridge circuit was thus balanced, passage of analyte changed the resistance of the wire in one leg of the bridge, throwing the bridge out of balance and producing a voltage signal proportional to the resistance change. The designs of two TCD cells are illustrated in Figure 11.16. This design of TCD cell was also referred to as a **katharometer** cell, a name for a gas thermal conductivity measurement device.

Note the application of the TCD for the detection of **fixed gases** in the chromatogram of Figure 11.30 (Section 11.10.3). These are generally not seen by other detectors (except hyphenated GC-MS). Note the low sensitivity signal for H_2 , whose thermal conductivity is the only one to closely match that of the He carrier gas used. If only H_2 were being measured, it would be better to use N_2 as the carrier. This would yield a peak signal in the negative direction. In Figure 11.31 (Section 11.10.3), note that the detector is described as a μ -TCD (micro-TCD). This must employ miniaturized cells to be compatible with the low carrier flows of the open-tubular PLOT column and the need for small detector cell volumes to avoid extra-column band broadening.

11.7.2 FLAME IONIZATION DETECTOR (FID)

Nearly universal (all carbon compounds except CO, CO_2 , HCN, but not many inorganic gases); destructive; mass flow detector; needs H_2 and air or O_2 aux. gas; sensitive with wide dynamic range.

The FID is the most commonly employed detector, as it gives a response to almost all organic compounds. On a molecular basis, the signal is roughly proportional to the number of carbon atoms in the molecule, or more correctly, the number of carbon hydrogen bonds. Hydrogen and oxygen (or air) must be separately provided to fuel a flame in the detector cell. As illustrated in Figure 11.20, the H_2 is introduced and mixed with the carrier effluent from the GC column. Even if H_2 is used as capillary carrier gas, an additional separately controlled H_2 supply is necessary to adjust the appropriate **fuel** supply for the flame. The mixed gas




FIGURE 11.20 Diagram of the flame ionization detector (FID). (Cazes, used with permission.)

enters the cell through a jet, where air or O_2 flows past to serve as the flame **oxidizer** supply. An electrical **glow plug** in the cell (not illustrated) can be pulsed to ignite the flame. The fuel and oxidizer flows are adjusted with needle valves to achieve a stable flame with optimal FID response, often by bleeding a volatile unretained hydrocarbon into the carrier stream to provide a reference signal. The **jet tip** is charged by several hundred volts positive relative to several **collector electrodes** or a **collector ring** surrounding the flame. In the absence of eluting organic analytes, no current flows in the jet-collector circuit. When a carbon-containing analyte elutes into the flame, the molecule breaks up into smaller fragments during the cascade of oxidation reactions. Some of these are positively charged ions, and they can carry current across the flame in the circuit. Although the ionization efficiency of the FID is low, its base current is also very low. Hence, its signal-to-noise ratio is very high. Against such a low background, even very small ionization currents can be accurately measured using modern electronics which draw very low currents (high input impedance, voltage measurement circuits), hence the good sensitivity and extraordinary dynamic range of this detector, often exceeding six orders of magnitude.

One can detect essentially any organic compound that can survive passage through the GC to the detector. A very wide range of analyte concentrations can be measured in a single run. The FID is the forerunner of a series of more selective and sometimes even more sensitive ionization detectors, some of which will be discussed subsequently. It led the way to GC as it is currently practiced, with analytes being present in dilute concentrations in a preparation or extraction solvent solution instead of being mixtures of the neat compounds. Precise quantitation requires calibration against reference standards of the analytes being measured. The responses on a compound weight basis are sufficiently similar so that for approximate quantitation, calibration for many components can be made against a single reference compound peak area. The wide dynamic range minimizes the number of calibration levels required for an adequate standard curve. The flame gases can be supplied from compressed gas cylinders or generated on site by gas generators employing hydrolysis of water, as well as compression and filtration (to avoid organic contaminants) of ambient air. If H_2 is used as carrier instead of He, all compressed gas cylinders could be dispensed with. Some organic compounds can be problematic to analyze with the FID, such as chlorinated compounds. Such compounds cause soot formation in the flame and the soot particles cause electronic spiles in the chromatograms.

11.7.3 ELECTRON CAPTURE DETECTOR (ECD)

The ECD is very selective for organic compounds with halogen substituents, nitro and some other oxygen-containing functional groups; non-destructive; is a concentration detector; needs to use N_2 or argon/CH₄ as carrier, or as makeup gas if used with H₂ or He capillary carrier flow; extreme but highly variable sensitivity but with limited dynamic range.




FIGURE 11.21 Diagrams of two types of electron capture detectors (ECD). **(a)** ECD for use with pulsed electrode potential and **(b)** ECD for use with constant electrode potential. (Cazes, used with permission.)

If the FID brought GC into the realm of characterizing dilute solutions of organics, it was the ECD that allowed it to spark a revolution in the understanding of the threat of bioaccumulation in tissue and bioconcentration up food chains, of lipophilic, persistent organic pollutants (POPs) in the environment. The classic example of this was the discovery of the threat posed by the organochlorine pesticide DDT, and its subsequent banning. J.E. Lovelock (subsequently famous as the founder of the Gaia theory of the whole earth as an organism) invented this deceptively simple but exquisitely sensitive and selective detector. It is not too much of a reach to claim that observations which were only made possible by the use of this GC detector set off the revolution in environmental consciousness in the 1960s.

How then does this little marvel function? Two versions are illustrated in Figure 11.21. The right-hand diagram displays features of the initial design (operation in DC mode). The column effluent enters from the right. A nickel foil doped with radioactive 63 Ni, a β particle (energetic electron) emitter, constantly bombards the carrier gas, ionizing some of its molecules, creating an atmosphere of positive ions and the negative electrons which have been knocked loose. This radioactive source is chosen for its ability to withstand the high operating temperatures that GC detectors may require to prevent condensation of high boiling analytes. A *low voltage* (several volts, instead of the hundreds of volts across the FID) between the negative inlet side of the detector and the positive outlet side is sufficient to set up a current between these two electrodes. Under this low voltage, it is the more mobile, lighter, free electrons that carry the **standing current** to the positive electrode.

If an analyte with highly electronegative, highly polarizable substituents enters the cell, the electrons of the standing current can be captured by these molecules. The mobility of the captured negative charge is drastically reduced, and some may be more easily neutralized by collision with the positive ions that are generated. It is the depression of this standing negatively charged electron current which is displayed reversed and appears as a peak signal. The electron capture sensitivity varies dramatically (one to two orders of magnitude) with the nature and number of the substituents: I > Br > Cl » F among the halogens, and 5-8 halogen atoms >4 >3 » 2 » 1. Note that most electronegative F is surpassed by more polarizable Cl, Br, and I, increasing in that order, so it is the *polarizability* that dominates, although both are necessary for electron capturing effectiveness. Some other groups such as $-NO_2$, -NO, and so on fall somewhere on the low side of the responsiveness series. Hydrocarbons are essentially unresponsive, although in great excess they can depress the sensitivity of the ECD response of ECD active compounds if they coelute with them. So, with the ECD, calibration standards for every analyte are necessary to perform quantitative work.

Note that ECDs require special carrier or makeup gases. Most early ECD cells were designed for high packed column flow rates, and will need makeup gas at higher flow rates and of different composition when He or $\rm H_2$ are employed as capillary carrier gases. Use of a radioactive ionization source in the detector requires a license from the Nuclear Regulatory Commission (NRC) in the United States, and a program of regular wipe tests to detect radioactivity leaks in and around the detector. Another problem is that the depression of the standing current soon saturates. As the level of electron capturing analytes rises, the tiny current of electrons becomes more and more depleted. Additional increase in the analyte level is not reflected by a proportional decrease in the standing current—there just are not enough electrons left to go around (the circuit). This results in severe nonlinearity of the detector response, curvature of the standard curve (it eventually levels out as concentrations continue to increase), and a severely limited linear dynamic range. Quantitative calibration becomes a tricky problem with ECDs.

The left-hand ECD diagram shows a more modern design which attempts to alleviate some of these difficulties. The ionization is achieved by the discharge electrode using a special discharge gas flow, thereby replacing the radioactive foil. A special dopant gas is introduced to enhance this. Instead of maintaining a constant potential across the cell, it may be intermittently pulsed at a higher voltage. Typically, a pulse at ~30 V of around 1 μs repeated at 1 ms intervals (a duty cycle of 0.1 %) collects all free electrons in the ECD cell, while during the "off period", the electrons reestablish equilibrium with the gas. The very fast collection time is enabled by admixture of 5-10 % methane in the argon ECD gas, which serves to enhance the voltage-induced migration rate of the free electrons. The current during the pulsed collection is integrated to produce the standing current level. The benefit of this method of controlling the standing current is to extend the linear dynamic range, and most modern ECDs are designed to operate as pulsed-mode ECDs. Such an extended linear dynamic range is illustrated for the μ -ECD (micro-ECD) in Figure 11.18. The micro- or μ - designation indicates that this model is equipped with a much smaller cell volume adapted for the effluent flow rates of capillary columns. Dispensing with the need for dilution of the effluent stream with makeup gas also increases the sensitivity even more. All other things remaining equal, pushing the sensitivity even lower extends the dynamic range since it is mainly limited by the effects of saturation of the standing current at the upper end of the range. The earlier model, large volume, DC-mode ECDs often had a linear dynamic range of only 100 or less. This made measuring multiple analytes (especially if they covered a much larger range of concentration) within a valid calibration range very complicated. Many dilutions and re-assays were often required to do good quantitative work—a great contrast to operating within the huge dynamic range of the FID. On the other hand, the special selectivity and extraordinary sensitivity of the ECD for certain classes of compounds, such as multiply chlorinated DDT, were indispensable for the discovery of the bioconcentration pathways of that compound and others such as PCBs, dioxins, and PBDEs (polybrominated diphenylether flame retardants). It is an important general principle that the detection limits for given analytes in chromatographic methods applied to real samples from environmental or biological systems are more often determined by the selectivity of the detector against background coeluting interferences than by its absolute instrumental signal to noise sensitivity limit.

11.7.4 ELECTROLYTIC CONDUCTIVITY DETECTOR (ELCD)

Heteroatom selective (for organic compounds with halogen [X] substituents, or N or S atom); destructive; mass flow detector; requires liquid reagents; good sensitivity and linearity; response is directly proportional to flow rate of the X, N, or S atoms.

The ELCD operates by consuming the analyte in a hydrogen-air flame and dissolving the resulting gases in an aqueous solution whose electrolytic conductivity is proportional to the amounts of any halogen (X), S, or N atoms that were present and oxidized to the corresponding acids. It represents the first example of a detector specifically and proportionately responsive to specific atoms in organic compounds. It is complex to operate and now not commonly used. Its unique value is its proportional response only to the number of

heteroatoms, not to their position in the molecule. If a mixture of compounds with only one of these elements present is analyzed, and additional information is available about the number of its atoms in each compound in each peak (obtainable from a GC-MS analysis), then a single standard peak response can serve to calibrate many other peaks, for which no standards exist. An example is the calibration of PCB congener peaks in commercial mixtures against the response of a chlorine compound standard. There are 209 of these PCB isomers, and their ECD responses vary widely. The TCD, FID, or GC-MS responses vary less, but still by too much, and individual standards were initially available for only a small subset. The exact atom-proportionate response and good dynamic range of the ELCD permits quantitation in the absence of complete standard sets for these homologous compounds.

11.7.5 SULFUR-PHOSPHORUS FLAME PHOTOMETRIC DETECTOR (SP-FPD)

Heteroatom selective (for organic compounds with S or P atoms; separately); destructive; mass flow detector; less sensitive and shorter dynamic range than FID.

When organic compounds containing S or P atoms are burned in an FID, the flame conditions can be adjusted to produce a lower temperature which enhances the emission from S_2 fragments at 394 nm or HPO fragments at around 515 nm. The FID electrodes are omitted, and a temperature-resistant window or fiber-optic light guide in the side of the detector cell passes the emitted light to filters designed to isolate these wavelengths and pass the characteristic emission to a sensitive photomultiplier tube. Operated in S-selective mode, it is useful to characterize the organosulfur compounds in complex petroleum mixtures, as the much higher levels of coeluting hydrocarbon peaks give minimal response. Operated in P-selective mode, it is a sensitive detector for organophosphorus pesticide trace residues in complex environmental mixtures. Only the sulfur mode response range is illustrated in Figure 11.18.

11.7.6 SULFUR CHEMILUMINESCENCE DETECTOR (SCD)

The SCD detector is heteroatom selective (for organic compounds with S atoms only); destructive; mass flow detector; more sensitive and greater dynamic range than SP-FPD.

This detector takes the gases from a flame produced in the same manner as in an FID (again minus the electrodes), and reacts it with ozone to induce chemiluminescence from sulfur products produced from eluting organosulfur compounds burned in the flame. The intensity of this luminescence is detectable at even lower levels than the S_2 emissions produced in the S-FPD, making it useful for monitoring trace environmental pollutant sulfur organics. This is another equimolar detector for which calibration can be done with any sulfur compound. An after-catalyst bed is required with this detector to destroy any remaining ozone, and prevent it from escaping into the laboratory.

11.7.7 NITROGEN-PHOSPHORUS DETECTOR (NPD)

The NPD is heteroatom selective (for organic compounds with N or P atoms; separately); more sensitive for N and P compounds than FID, as well as selective for them; destructive; mass flow detector; more sensitive than FID for N, more sensitive than P-FPD for P, but with less dynamic range than the FID.

The NPD is yet another variation on the workhorse of GC detectors, the FID. Comparison of Figure 11.22 for an NPD to Figure 11.20 for the FID highlights the similarities. Both are defined as **thermionic detectors**, that is, the high temperature of a flame breaks the eluting analytes into fragments, some of them positive ions, which release electrons to carry a current under the influence of the voltage between two electrodes. The NPD is operated under **fuel rich (i.e., H₂-rich)** conditions. Under these conditions, the normal carbon compound FID thermionic response is suppressed by orders of magnitude. The new element in the detector is **rubidium** in the form of a glass or ceramic **bead** doped with a rubidium salt, which




FIGURE 11.22 Diagram of the nitrogen-phosphorus detector (NPD). (Cazes, used with permission.)

is heated by immersion in the flame, but is also additionally and variably heated by passing current through thin wires which support the bead in the flame. What exactly happens near the surface of the bead while organonitrogen or organophosphorus compounds are decomposing in this not-so-hot flame is complex and poorly understood. In some designs, the flame would not be self-supporting were it not for the independently heated bead embedded in it. Somehow, fragments containing C–N or C–P interact with easily ionizable rubidium atoms to produce ions and electrons that then produce a signal like that in the FID, but one that is exquisitely sensitive and selective to either N or P atoms (depending on how the detector parameters are set). The extreme sensitivity of this detector to some organophosphorus compounds explains why it has largely supplanted the P-P-PD for this application. The N-PD produces no response to N atoms not bound to carbon in organic molecules. This is a fortunate circumstance which renders it immune from interference from ubiquitous atmospheric N_2 .

11.7.8 PHOTOIONIZATION DETECTOR (PID)

Compound class selective (for organic compounds with more easily ionizable π -electrons, especially aromatic compounds); nondestructive; mass flow detector; slightly more sensitive than FID for many compounds it detects, but with less dynamic range than the FID.

Ionization detectors like the FID and the NPD have great sensitivity. Is there any other way to selectively ionize some classes of compounds to achieve a sensitive, selective ionization detector like the NPD? Let us take the "thermo" out of thermionic by dispensing with the flame, and supply ionization energy instead by passing high-energy UV radiation into the cell. This is the reverse of measuring flame emission coming out as in the S-FPD. The UV radiation provides enough energy to knock electrons out of some aromatic compounds and other compounds that have electrons in higher energy level π -bond orbitals. Precise selection of the UV wavelength can allow some selectivity within these compound classes. Organic compounds like alkyl hydrocarbons containing only electrons in more tightly held single bonds will be unaffected. The resulting PID is selective for aromatic hydrocarbons, and other organic compounds with unsaturated bonds. The high-energy UV lamp and its power supply are much more compact and robust than the FID and its associated gas supplies. Combined with its exceptional sensitivity to a reasonably broad-based selection of organic compounds, this operational simplicity makes the PID especially suitable as a detector for field-portable GC instruments. An additional factor supporting such applications is that it is not affected by oxygen in air and can even be used with air as a carrier gas, if the column stationary phase can withstand this at the temperature conditions employed.

11.7.9 HELIUM IONIZATION DETECTOR (HID)

This is a universal detector (everything except neon); nondestructive; mass flow detector; a little less sensitive than FID for FID-active compounds, and with less dynamic range than the FID.

The HID is like the FID, NPD, or PID in that it is a sensitive detector which measures a current of ions produced from the analyte molecules. An analogous **argon ionization detector** employing the same principle was another early GC detector. They are sometimes also referred to as **discharge ionization detectors (DIDs)**. In the HID, a flow of He gas atoms (as He carrier or He makeup gas) is activated to an excited metastable state by **discharge electrodes**. These have sufficient energy to ionize any analyte molecules (except Ne atoms) they come in contact with, which then produce an ionization current proportional to sample amount between two other electrodes in the detector. As with the ECD, pulsing the discharge electrode to maintain a constant current yields a design with superior dynamic range. It can be operated in series with the other universal detector, the TCD, since both are nondestructive, and their two overlapping dynamic ranges can cover the range up to 100 % of the neat compound. It is often employed in simple portable GC instruments designed to measure both fixed gases and very volatile low molecular weight hydrocarbons (Figure 11.23).

A more modern version of the HID is the **Dielectric Barrier Discharge Ionization Detector (BID)** from Shimadzu. It contains a two-stage cell (Figure 11.24). In the top stage, all sides of a He plasma discharge cell are protected by a dielectric coating, which enables a lower discharge current, preventing overheating and electrode damage. Helium flows down through this upper compartment and undergoes a series of reactions:

$$\text{He} \rightarrow \text{He} \left(A^{1} \sum_{u}^{+} \right) \rightarrow \text{He} \left(1S^{1} \right) - - - \text{hv} - - - - - \rightarrow \left[M - - - \rightarrow M^{+} + e^{-} \right]$$

$$\text{emitted He Photon at 17.7 eV } \text{M=Analyte}$$




FIGURE 11.23 Separation and detection of fixed gases and low MW hydrocarbons on high surface area molecular sieve using a helium ionization detector (HID). (Adapted with permission of Restek Corporation, Bellefonte, PA. www.restek.com.)




FIGURE 11.24 Design of the dielectric barrier discharge ionization detector (BID). (Used with permission from Shimadzu corporation, Kyoto, Japan; www.shimadzu.com.)

The He plasma contains He atoms excited to high energy states as represented by the spectral term symbols in parentheses. The excited He atoms emit a very energetic photon (much higher energy than the UV photons of the PID detector) that can then ionize all other atoms or molecules except Ne, whose ionization potential is 21.56 eV (electron volts). The ionized target materials are collected in the lower cell, which is purged top and bottom to clear out uncollected ions and prevent them from entering the plasma generation cell. This destructive detector is even more universal and orders of magnitude more sensitive than the TCD and equal or slightly more sensitive than a FID, but the dynamic range does not reach quite as high analyte percentages as these other two detectors. This is easily dealt with by diluting or reducing sample size or splitting the effluent and reinjecting, or operating the BID in tandem behind a nondestructive TCD. The GC requires only a He gas supply, which has no flammability hazard. The detector can operate up to 350 °C and can in principle detect gases (H₂, H₂O, CO, CO₂, Argon) up to high boiling liquids (with nearly uniform sensitivity over the range of C_8 to $> C_{44}$ organics) in a single run, were a suitable column and elution conditions capable of handling such a wide range of molecular weights (2 to ~ 618) to be found! The mechanism of operation is like a combination of the PID and the FID detectors, with more universality and no need for a UV lamp or a H_2/O_2 flame.

11.7.10 ATOMIC EMISSION DETECTOR (AED)

Tunable; separately or simultaneously selective for compounds containing many specific atoms (e.g., C, O, N, S, P, Si, Sn, halogens, other metals); destructive; mass flow detector; sensitivity and dynamic range vary with element measured (Figure 11.18).

The AED employs a **microwave-induced He plasma** to dissociate eluted analyte molecules to their component atoms and excite them to emit at characteristic wavelengths. This is very similar to the mechanism in the argon plasma ICP source (cf. Section 7.3.1). A spectrometer with a diode array detector [Figure 7.26(c)] isolates and measures the intensity of sensitive emission lines unique to each element. Depending on the relative sensitivity and proportion of atoms in the molecules, separate element response channels may display peaks in several element-selective chromatograms. These data may be combined with retention information to additionally characterize the peaks, to separately quantitate coeluting peaks, and to suggest identification of unknown peaks based on their elemental composition. Like the ELCD, its response is atom selective and atom proportional, but each different element may be simultaneously detected, identified, and quantified. It is now available from

a German instrument company: joint analytical systems (www.jas.de). It is particularly useful for detection and quantitation of the total N, F, S, P contents of gasoline samples from a single GC injection, or wear metal contents of used lubricating oils to identify failing aircraft or motor vehicle engines. Since it interfaces a chromatographic separation instrument with a multiwavelength spectrometric detector, it verges on being classified as a 2D hyphenated instrument. Fully 2D instruments are the subject of the next section.

11.8 HYPHENATED GC TECHNIQUES (GC-MS; GC-IR; GC-GC; 2D-GC)

Two-dimensional (2D) analytical techniques can combine two similar separation procedures by sequentially varying the mobile phase compositions and developing with the second phase in a direction perpendicular to the first (e.g., 2D gel electrophoresis, Chapter 12).

If we can (1) find a way to join two chromatography systems with differing stationary phases, (2) separately and repeatedly trap everything eluting from the first phase (column), (3) then repeatedly separate each trapped fraction on a second column, and (4) store and manipulate the data signals from a detector at the end of the second column, we can produce a comprehensive 2D chromatography system (e.g., 2D-GC, Section 10.3).

Another way to add a second dimension to chromatographic detection is to employ as a detector a spectroscopic instrument capable of sequentially and rapidly acquiring full spectra and storing them as a series of computer data files. In the case of GC, the two major hyphenated techniques of this type are GC-MS and GC-IR. There are four critical requirements for achieving this:

- 1. A spectrometric detector capable of acquiring full spectra quickly enough to sample the eluting peak at least 5-10 times over its width. This is a challenge in capillary GC, where peak widths may be as small as several seconds.
- 2. A method of **interfacing** the chromatographic effluent stream to the spectrometer's detection cell that presents the sample under the conditions required for proper detector functioning.
- 3. A computer data processing system fast enough to deal with the high information rate of such a detector, with sufficient data storage capacity for the many spectra to be acquired.
- 4. Efficient and intuitive software for viewing and manipulating these data files, extracting subsets of the information, and using it for qualitative identification and quantitative measurement.

11.8.1 GAS CHROMATOGRAPHY-MASS SPECTROMETRY (GC-MS)

If we consider their wide availability and capability, GS-MS instruments could have been said to provide the largest total amount of analytical power available to the instrumental analysis world. With the more recent spread of LC-MS instrumentation (Chapter 12) to serve the biochemical research market, they now must share this status. If analytes are volatile and thermally stable, capillary GC-MS can identify and quantitate hundreds of them from a single injected mixture. In GC-GC-TOFMS, thousands of analytes can be identified and quantitated from a single injected mixture. The various types of mass spectrometers have been described in Chapter 9. It is the **quadrupoles** and **ion-traps** which best meet the earlier-mentioned scan speed criterion. Magnetic sector instruments with their higher mass resolution but slower scan speeds will require that the GC peaks be broadened and slowed down. This works against the goals of faster analyses and better chromatographic resolution. On the other hand, **fast GC**, employing short, narrow-bore, thin-film capillary columns, will require MS scan acquisition speeds of 50-500 s⁻¹, which are attainable only by TOFMS instruments.

The major problem for GC-MS is interfacing. Mass spectrometers form and move their ions at highly reduced pressures, and the mass analyzer sections need to be operated at even lower pressures (10^{-5} or 10^{-6} torr). The effluent of a GC consists primarily of carrier gas around




FIGURE 11.25 Diagram of GC-MS jet separator interface operation.

atmospheric pressure (760 torr). The MS vacuum pumps must remove this fast enough to maintain the necessary low pressure. With packed column flows of 10-40 mL/min, this was impractical. With capillary GC flows around 1 mL/min, modern diffusion pumps, or even better, powerful turbomolecular pumps, can achieve this. Many modern GC-MS instruments simply introduce the end of the capillary column into the ion source (*direct coupling*). A separate pump evacuates the small, largely confined volume of the source, while the ions are extracted through a small orifice into the mass analyzer region, which is kept at a lower pressure by another pump. Such an MS design is called a differentially pumped system. To interface packed columns, a device called a jet separator (or molecular jet separator, Figure 11.25) preferentially removes light He or H₂ carrier gas atoms or molecules from the effluent, allowing a smaller but enriched concentration of analyte molecules to enter the ion source at a lower total gas flow rate. The much higher speed of the lighter carrier gas atoms or molecules causes most of them to spread more widely in the vacuum of the separator chamber, and not to pass on through the conical orifice leading to the ion source. Jet separators are not much used or needed for GC-MS now, but we will encounter a similar design feature when we come to discuss the even more challenging problem of dealing with the much denser and larger mobile phase mass in LC-MS interfacing (Section 12.1.5).

In principle, one could monitor a GC effluent with a nondestructive detector like a TCD, pass it on through a suitable interface, and acquire and print out the mass spectra of peaks as they are eluting. With fast digital data converters and the speed and power of modern desktop PCs, it is better to simply acquire mass spectral data as a continuous sequence of spectra or selected mass fragment signals as the GC run proceeds. Improvements in computer data acquisition speed and memory storage capacity now make it possible to record and store complete MS line profiles (i.e., for all masses) instead of converting these on-the-fly to numbers of detector counts and calculation of the centroid of the *instrumentally distorted* peak top on the mass axis. This allows the now complete MS data acquisition files to be processed by computer programs which have stored data on MS instrument tuning distortions to correct each line to an ideal Gaussian shape whose MS peak area and position on the mass axis can be determined much more precisely. This enables "quasi" high-resolution mass determinations from unit mass instruments and better use of MS isotope peak areas to prune the number of possible elemental formulas.

A data file for a GC-MS analysis in computer memory consists of a sequence of MS scans ordered by retention time. There are three main modes of acquiring and employing such data files:

1. *Full-scan*: if the file consists of a sequence of full-scan spectra, the total counts from ions of all masses in each scan may be summed, and these totals plotted against successive scan numbers (or equivalently, GC retention time). This display is called a **total ion chromatogram (TIC)**. Here, the mass spectrometer acts like an ionization

detector, using whatever MS ion-source ionization mode was selected (EI, CI, etc.). The TIC chromatogram will appear similar to that obtained by a FID detector. One difference is that the FID output digitized by a chromatographic data system will likely define each peak at many more points across its width than the number of scans that the MS could make unless it is the very fast scanning TOFMS (Section 9.2.3). For this reason, integration of FID peaks yields more accurate quantitation than TIC peaks. The advantage of the TIC data file is that by selecting any scan comprising a TIC peak one can display the mass spectrum of the compound in the peak. If the peaks are sharp and narrow, the level of the analyte may vary significantly over the time of the scan, thus distorting the proportions of mass fragments in the spectrum. It would be best therefore to select a scan at the top of the peak. Even better would be to sum scans across the whole peak to get an average spectrum. Even better than that would be to select and sum an equal number of scans of background mass spectra near the peak where nothing else is obviously eluting. Then subtract that sum from the peak average sum, and thereby obtain a cleaner mass spectrum, with spurious fragments from column bleed eliminated. This illustrates the power and flexibility of manipulating a data file of continuous, contiguous MS scans. We have combined the great separation power of capillary GC to the great characterization and identification power of MS. This is particularly feasible because in GC the samples are in the vapor state, which is mandatory for the MS ionization and fragment identification process to proceed. The vast libraries of EI-MS spectra are based on this mode of operation. In many cases, it is possible to automate the process of peak detection, spectral selection, library spectra searching, and separated compound identification by matching to a library spectrum. A naïve person might be forgiven for wondering whether GC-MS eliminates the need for an analyst. Not quite, since the limitations are significant and were discussed earlier in the chapter on mass spectrometry. But the interfacing of vapor-separation GC with vaporrequiring MS, when combined with the fluency of PC processing of digital data files is an excellent combination.

- 2. Mass chromatograms (XIC): one may seek to locate and measure only certain categories of analytes in the chromatogram of a much larger and more complex mixture. These might have very characteristic mass fragments. An example would be mono-, di-, and trimethylnaphthalene isomers in a complex mixture of petroleum hydrocarbons such as a fuel oil. Their mass spectra consist mostly of a single intense molecular ion (M+) at masses 142, 156, or 170, respectively. We can program a GC-MS data system to extract from the full-scan GC-MS files and plot only the ions of these masses in three separate chromatograms. Such plots are called extracted ion chromatograms (XIC), from their mode of production, or mass chromatograms, since they display peaks whose spectra contain the selected ion mass(es). If in the mass chromatogram of a petroleum sample at $M^+ = 142$, we observed a pair of large peaks close together, we might well suspect them of being from the two possible monomethylnaphthalene isomers, and could confirm our suspicion by inspecting the complete spectrum of the scans at the center of each peak. Thus, we may be able to determine the retention times of various compounds without injecting a standard. Unfortunately, mass spectra of isomers of such compounds are indistinguishable, so we will need some sort of retention information based on standards run on the particular GC stationary phase to say which isomer is which. A method of accessing such information without actually running the standards is described in Section 11.9. Such a process could be repeated at many other characteristic masses for the different classes of hydrocarbons. The data for all masses in the range scanned, at every point in the TIC chromatogram, are present in the full-scan GC-MS data file.
- 3. Selected ion monitoring (SIM): in full-scan mode, the mass spectrometer is acquiring counts at any particular ion mass for only a brief portion of the scan. For example, if scanning from mass 50 to 550 each second, with unit mass resolution, the detector spends less than 2 ms at each mass during one scan. If we have only a few

classes of analytes we wish to measure, and we know their characteristic major mass fragments, we can program the MS to acquire counts only at the selected masses, thereby increasing the dwell time at each mass, increasing the signal-to-noise ratio, and improving the sensitivity. If we wanted the three successive methylnaphthalene isomer distributions, we could monitor at only $M^+ = 142$, 156, and 170. In 1 s each of these three ions would be monitored for a little less than 330 ms instead of 2 ms, greatly improving the sensitivity over the 50-550 full-scan acquisition. In fact, we could cut the cycle time from 1 to 0.2 s, still acquire for 66 ms per cycle, but now be sampling and defining the GC peak shape 5 times/s instead of once per second. If we know that each class of isomers elutes over a unique range of retention times, we can set MS acquisition to monitor just their most characteristic and abundant ions during this period and achieve even greater sensitivity. This mode of acquisition is called SIM. SIM improves sensitivity by collecting more counts at the masses of interest, and it improves quantitative precision by enabling the GC-MS peak to be defined and integrated using more points. The extension of the linear range of measurement to lower values with SIM versus full-scan is represented by the two sections of the GC-MS sensitivity range in Figure 11.18. Ultimate SIM sensitivity is a complex function of MS ionization efficiency for the particular analyte compound, number of different masses monitored, dwell time, and cycle time. Figure 11.18 indicates that in the most favorable instances, GC-MS-SIM can reach detection limits below that of the FID and in the range of the ECD. It is far more selective than any of the general GC detectors. This sort of analysis is characterized as target compound analysis since the system is tuned or programmed to select specific characteristic ions from specific target compounds expected to elute in specific retention time ranges.

To reiterate, the difference between XIC and SIM chromatograms is that in the former case, the desired ion masses are extracted from a full-scan data file, while in the latter case, the MS is directed to acquire the data only at those selected masses. The ability to improve sensitivity and quantitative precision by using SIM applies mainly to magnetic sector (including use of high-resolution MS) and quadrupole MS instruments. The mode of operation of ion-trap MS and TOFMS instruments yields near-optimum sensitivity in full-scan mode. There is generally no provision for SIM acquisition on these instruments, and quantitation is done on XIC files. The MS in GC-MS is a destructive mass flow detector. Only with mass spectrometric detection can the analyst use the "perfect" internal standard, namely, the identical chemical species labeled with stable isotopes of atoms with a higher mass (e.g., ²H, ¹³C, ¹⁵N, ¹⁸O, etc.). This procedure, **isotope-dilution mass spectrometry (IDMS)**, can correct for differences in sample preparation recovery, derivatization efficiency, MS ionization efficiency, and so on, for which use of a different chemical species as an IS may not fully compensate. Review Section 10.12 for a discussion of chromatographic IS. However, IDMS IS materials are difficult to make, expensive to purchase, and commercial products are limited to only several thousand especially important target analytes.

11.8.2 GAS CHROMATOGRAPHY-IR SPECTROMETRY (GC-IR)

At the concentrations eluting from GC columns, with analytes extensively diluted as vapors in the carrier gas, IR is not nearly as sensitive a detector as MS. Unfortunately, since IR spectrometry is traditionally carried out on analytes in a liquid or solid matrix, the libraries of vapor phase IR spectra are much less extensive than those in the other phases, and the spectra differ significantly. The vapor phase IR spectra are sharper, with greater interpretive structure than in the other phases, but comparable upper range concentrations are unattainable. The spectra must be acquired during a rather brief passage of the peak through a detector cell. This makes acquisition by the rapid-sampling FTIR process (Chapter 4) mandatory. The beam from the FTIR passes from one end to the other of a long narrow cylindrical **light pipe** flow cell. The GC effluent enters and exits the sides of each end of this tube, while the ends are capped by flat windows of IR transmitting material. The cell must be

heated to prevent condensation of analyte vapors. The interior side walls are coated with an IR-reflective gold film, and the beam remains confined within the pipe by grazing-incidence total internal reflection.


The cell must have a volume small enough not to introduce extra-column GC band broadening. This conflicts with the need to make it as long as possible to increase the IR absorption from the dilute analyte vapor in the peak. Remember that an IR detector is a nondestructive concentration detector, and as such, its absorbance signal is proportional to both concentration and path length. Something has to give, and it is sensitivity. The FTIR acquisition process could improve sensitivity if more time could be taken to acquire more scans. One way to achieve this is to stop carrier flow (best achieved by closing shut-off valves upstream and downstream of the detector) while the peak is in the cell. For reasonable times, diffusion will not spread the band too much outside the cell. This **stopped-flow-analysis** is an awkward process. Chromatography of other peaks still on the column may slowly degrade during the pauses in flow, one has to know in advance exactly when to stop the flow, and the analysis time increases dramatically, especially if one wishes to do this for many peaks. The lower sensitivity range of GC-IR is reflected in Figure 11.18 (the IRD).

Why then does anyone even want to do GC-IR? We have seen that MS information cannot distinguish between many isomers of the same molecular weight, such as the methylnaphthalenes mentioned earlier. Perhaps standards and retention data for the GC phase can help us distinguish them. If several co-elute, GC-MS cannot tell how much of each is in the peak, or which one is present or absent. An example of this is seen in an important GC assay for "BTEX" aromatic hydrocarbons (Section 11.5, Figure 11.14). On the PDMS column phase, para- and meta-xylenes co-elute. All three xylenes have indistinguishable mass spectra. The carbowax type phase will separate them, but it is not as stable as PDMS if we must also elute other analytes later at much higher temperatures. The gas phase IR spectra for xylenes in Figure 11.26 show significant differences in the positions of the large absorptions in the 900-600 cm⁻¹ region, in particular, between coeluting p- and m-xylene. These absorptions are due to the out-of-plane C-H bending modes. The ortho and para compounds have one band each, at 745 cm⁻¹ and 800 cm⁻¹, respectively. The meta compound shows two bands at 680 and 760 cm⁻¹. Expanded spectra and details of the spectra collection are found at www. webbook.nist.gov/chemistry.


We could monitor absorbance at these distinctive wavenumbers and separately quantify each xylene, even in the presence of a coeluting one. As with GC-MS, examination of the full spectrum of resolved GC peaks could enable identification even without retention data from standards (i.e., using spectral library matching). IR spectra will distinguish among structural isomers whose MS spectra will appear identical. Since the GC-IR detector is nondestructive, after IR spectra are acquired, the peaks may be passed on to a destructive detector such as an FID, or even an MS. A GC-FTIR-MS instrument is very complex and expensive, but correspondingly powerful in its ability to characterize separated analytes.

11.8.3 COMPREHENSIVE 2D-GAS CHROMATOGRAPHY (GCxGC OR GC²)


At the beginning of Section 11.8, we described how an additional different GC column in series could add a second dimension to GC analyses. The second dimension is a very fast GC column with separation capability different from the first column. The speed of the second short fast column enables it to quickly separate and elute effluent collected and briefly stopped from the much longer and slower separation on the first column. Because the second column uses a phase with different polarity characteristics than the first one, it may separate components co-eluting in the peak trapped from the first column. What is the trick for repeatedly trapping and then transferring sequential segments of the chromatogram in the first column for separation on the second one? A length of uncoated fused silica capillary tubing connects the two. It is alternately flash cooled to **trap** and then flash heated to **desorb** segments into the second column. In some versions, the flash cooling is done by jets of liquid N_2 , and the flash heating by electrically conductive paint on the outside of the bare capillary.



NIST Chemistry WebBook (https://webbook.nist.gov/chemistry)



NIST Chemistry WebBook (https://webbook.nist.gov/chemistry)



NIST Chemistry WebBook (https://webbook.nist.gov/chemistry)

FIGURE 11.26 Gas phase infrared spectra of **(a)** 1,2-dimethylbenzene (orthoxylene); **(b)** 1,3-dimethylbenzene (metaxylene), and **(c)** 1,4-dimethylbenzene (paraxylene). (The spectra are from the NIST gas phase infrared database. http://webbook.nist.gov. Copyright 2020, U.S. Secretary of Commerce on behalf of the United States of America. All rights reserved. Used with permission.)

This is the same material used for electrically heated automobile rear window defrosters. The very high heat conductivity of the thin-walled fused silica capillary facilitates these processes. This interfacing device is known as the **thermal modulator**. Data from the detector at the end of this pair of serially coupled columns is acquired and stored as a sequence of fast separations (second column GC scans) at equal retention time intervals from the first column. This is analogous to full-scan GC-MS data files. The computer system displays the data set as a planar 2D array of spots, looking like a developed 2D TLC plate or 2D gel electrophoresis plate. Each "spot" is a peak, and quantitation is by volume integrated over peak area, instead of area integrated over peak baseline as in 1D GC. An example of this is shown in Figure 11.27, the GCxGC-ECD separation of several persistent organic pollutants (POPs) in human milk. POPs include chlorinated pesticides, polychlorinated biphenyls (PCBs), polybrominated diphenyl ethers (BDEs), and similar compounds. In Figure 11.27, elution time on the first column is plotted on the x-axis; elution on the second column is plotted on the y-axis. Note the much faster elution times on the y-axis. Both PCB 209 and BDE 99 elute at the same time on the first column, a little over 3209 seconds. If this was the only column used, the two peaks would co-elute. The second column, with different selectivity, moves the two compounds apart, as seen in the vertical direction. Alternatively, a 3D plot shows




FIGURE 11.27 GCxGC-ECD separation of POPs in human milk. (Copyright Restek Corporation, Bellefonte, PA. www.restek.com. Used with permission.)




FIGURE 11.28 Using comprehensive GCxGC-ECD, a complex mix of organochlorine pesticides, polychlorinated biphenyls and brominated flame retardants is separated and displayed as a 3D plot. (Copyright Restek Corporation, Bellefonte, PA. www.restek.com. Used with permission.)

the analyte signals as peaks, with color-coding used to indicate compounds. Figure 11.28 is a 3D plot of POPs in human milk. More applications of this technique can be found at www. restek.com/gcxgc. Many coelutions are thus resolved. The technique is called **comprehensive** because all components injected are measured, and most are resolved from one another. In this sense, it differs from **heart-cutting 2D GC**, where only a selected peak is diverted by a valve to a second slow GC column for additional separation.

Using comprehensive GCxGC-FID, a light fuel oil like the one whose 1D separation is shown in Figure 11.29, has been resolved into 3000-4000 quantitated peaks. The textbook page is hopelessly inadequate to display this.




FIGURE 11.29 Linear programmed temperature GC-FID analysis of hydrocarbon fuel oil. (Reprinted with permission of SigmaAldrich, Inc., A part of MilliporeSigma, Bellefonte, PA. www. sigmaaldritch.com/supelco.)

An additional valuable feature of the thermal modulator is that it acts in a fashion similar to the retention gap (Figure 11.11). A slow-moving, late-eluting peak will be gradually accumulated off the first column during the cold trapping phase. Then it is quickly flashed back to vapor, and much more rapidly transferred to the head of the second column, where it is refocused to a very narrow band like that of an initial retention gap injection. The fast separation on the second column retains this very narrow peak width, so at the detector the peak height is correspondingly increased from what it had been exiting the first column, yielding a great improvement in signal-to-noise at the peak top. In some circumstances, the *S/N* improvement can be an order of magnitude or more, making it worthwhile to use a thermal modulator even if the second column is not needed for or capable of resolving coelutions.

11.9 RETENTION INDICES (A GENERALIZATION OF RELATIVE R_{+} INFORMATION)

We saw in the case of xylene isomers that even the great compound fingerprinting capability of full scan MS detection could not distinguish among them. The differences in elution times on a GC column could resolve this problem, if we had run authentic standards of each isomer on the system to establish where each one elutes. What if no standards are available in the lab? We know that absolute values in minutes of R_t will depend on many factors: the column phase and exact dimensions, temperature program, flow rate. Such numbers from someone else's lab will be useless. How about RRTs (Section 10.11)? This might get us closer, but the values will still vary significantly with the temperature program used. Elution orders and RRTs among compounds will differ with and be specific to the stationary phase in use. The best system devised to codify data on these parameters is a library of compound **retention index (RI)** values, specific for each stationary phase. The most common such system was devised by Hungarian-born chemist Ervin Kováts in the 1950s.

Compounds of similar structure, differing by only the number of $-CH_2$ — units in linear hydrocarbon chain substituents, or in the number of the same substituents on aromatic rings (like the methylnaphthalenes), are called homologs. The simplest example is the sequence of n-alkanes (methane, C1; ethane, C2; propane, C3; ... octane, C8; ... hexadecane, C16; etc.). The n-alkane elution sequence on most stationary phases displays a simple regularity. Under isothermal GC conditions their adjusted retention times t'_r (Section 10.7) follow a **logarithmic** progression. In the **Kovats RI system**, each is assigned an RI value of $100\times$ its carbon number; thus, octane has an RI of 800 and nonane, an RI of 900. By definition, these numbers are the same on any GC phase. The RI of any other compound (U) is calculated by substituting the adjusted R_t values of both the compound and the alkane pair between which it elutes into Equation (11.1):

(11.1)
$$RI = 100 \left[n + (N - n) \frac{\log t_{\rm r}'(U) - \log t_{\rm r}'(n)}{\log t_{\rm r}'(N) - \log t_{\rm r}'(n)} \right]$$

where n and N are the number of carbon atoms in the smaller and larger alkanes, respectively. This formulation gives the official, most accurate, thermodynamic evaluation of a compound's RI. The measurement and calculation are fairly complex. One must measure in the appropriate isothermal temperature range, use the dead time t_m to calculate t_r' values from measured t_r , and use Equation 11.1.

GC runs covering a wide range of analyte boiling points will generally be done by programming temperature using a linear ramp covering the desired range of elution temperatures. Figure 11.26 illustrates a GC-FID chromatogram of a hydrocarbon fuel oil. The *n*-alkanes from C10 to C24 are seen under these conditions to elute at almost regularly spaced intervals. Correspondingly, a close estimation of RI can be made much more simply:

(11.2)
$$RI = 100 \left[n + (N-n) \frac{t_{r}(U) - t_{r}(n)}{t_{r}(N) - t_{r}(n)} \right]$$

Note the use of actual rather than adjusted retention times. Although not as accurate or conforming to the operational definition of RI as defined in Equation 11.1, use of Equation 11.2 with retention times acquired over the linear ramp portion provides a useful approximate value. Essentially, the RI values of unknowns are calculated by linear interpolation between the values of the flanking alkanes. If one had the PDMS phase RI values for the three dimethylnaphthalenes illustrated in Figure 11.16, one could probably assign identity to these compounds, whose mass spectra in GC-MS would be indistinguishable. To be certain, however, one would need to have RI values for all such isomers (there are many more than these three). If there were some others whose RI values were very close to those observed in that chromatogram, it would be dangerous to rely on RI to clinch the identification. At best, it would tell which the most likely candidates were, and then the confirmation standards could be selected. If RIs are within less than one unit of one another, co-elution is a possibility, and resort to a different column which will resolve the candidates is indicated. Tables of RIs for the compounds on different phases will aid in selecting such an appropriate column. In general, RI values are useful for aiding in sorting out small sets of isomer elutions. There are far too many possible compounds relative to the number of reliably distinguishable RI values to make these values useful for identifying general unknowns. Kovats' retention indices are an adjunct to identification with hyphenated GC methods rather than a substitute for them.

A shortcut in the use of Kovats' retention indices is to simply measure a series of n-alkanes on a given column, and plot the retention time (or the adjusted retention time, subtracting for the void volume of the column) against the Kovats' retention index. For the n-alkanes, this will result in a near perfect straight line (with uncertainty only in the retention time axis since the index axis is fixed by definition). Thereafter, the Kovats' retention indices can be read off the graph by noting the corresponding point on the retention time axis. This approximation is most useful when identifying many related compounds on a chromatogram, such as in the analysis of liquid fuels. Note that methods for determining the void volume or more correctly, the gas holdup volume, are covered extensively in the book by Bruno and Svoronos.

11.10 THE SCOPE OF GC ANALYSES

Appropriately configured GC instrumentation can separate and identify molecules ranging from the very smallest (H_2) to those with masses on the order of 1000 Da. This upper mass range limit applies only for compounds with great thermal stability at high temperatures and very low polarity leading to minimal boiling points for a given mass. The n-alkanes, the reference series for the Kovats RI system, are the prototype of such compounds, which present the characteristic "picket fence" profile of a homologous series when they elute under linear temperature programs. This is illustrated in the FID chromatogram of a light fuel oil in Figure 11.29. Heavier petroleum crude oils might extend this pattern out to n-C60 or beyond. The limiting factors are:

- 1. The ability to efficiently volatilize the compound.
- 2. A stationary phase which will not decompose at a temperature sufficient to partition the analyte into the mobile phase for a large enough percentage of the time. This will enable it to pass through the column in a reasonable time, and come off the column quickly enough to produce a peak well above the noise background. Recall that very slowly eluting compounds with long retention times elute so gradually as they exit the column into the detector that their peaks spread out and eventually become not much higher than and indistinguishable from background noise and baseline drift.
- 3. The column tubing itself must be stable at the necessary temperature. The polyimide scratch-protective outer coating of fused silica capillaries is itself stable only to about 380 °C. Some exceptional stationary phases can exceed this limit, and may require use of metal capillaries, which for some analytes at those temperatures must be deactivated—perhaps with an inner coating of silica, which will not yield a flexible column coil.

The strength of GC relative to other chromatographic techniques which combine separation, identification, and quantitation, is the number of compounds in a mixture that it can characterize in a single run. The illustration of capillary GC-FID analysis of the fuel oil in Figure 11.29 only suggests what has been resolved. Magnification of the smaller peak regions between successive *n*-alkane peaks would show perhaps 15-20 resolved hydrocarbons. Use of GC-MS SIM or GC-MS XIC chromatograms could tease out many times more classes of hydrocarbon peaks which are too small and overlap too much to be distinguished in the FID chromatogram. Among these would be a majority of the methylnaphthalene isomers we discussed earlier, as well as many other such extended families of hydrocarbons. In the comprehensive 2D-GC-FID run of a similar fuel oil, 3000-4000 peaks were resolved and quantitated (approximately—certainly standards for many of these were not available!). This spectacular performance is a tribute both to the extreme resolution of multiple capillary GC separations and the sensitive, wide-dynamic-range FID.

Applications of GC include analysis of environmental, industrial hygiene, chemical, agricultural, food and beverage, flavor and fragrance, personal care and cosmetic, clinical, forensic and life science samples, to name just a few areas where this technique is used. In the environmental forensics field, identification of the source of spilled fuel oil is an important analysis. Nitrogen-selective detection with GC has been used by US. Coast Guard researchers to fingerprint oil spills (Frame, Flanigan and Carmody, 1979). The 209 congeners of polychlorinated biphenyl (PCBs) and the identification of commercial PCB mixtures (sold under the trade name "Arochlor") have posed a significant challenge in environmental samples. The papers by Frame and colleagues highlight the use of high-resolution GC and GC-MS-SIM to separate and quantitate all 209 PCBs and commercial PBC mixtures. There are standard GC methods specified by multiple regulatory agencies around the world, including the US EPA, US FDA, OSHA, USP, and ASTM. As an example, the MilliporeSigma Sigma-Aldrich website alone lists well over 900 application notes for GC, sorted by industry, method number for standard methods, phase polarity, compound class and column type. Other instrument companies and column manufacturers have similar databases for GC (See Appendix 11.A on the text website).

11.10.1 GC BEHAVIOR OF ORGANIC COMPOUND CLASSES

Hydrocarbons, aliphatic or aromatic, have low polarity and high stability, and perform well at molecular weights limited only by the three factors listed earlier. Organic compounds with only ketone groups (R-(C=O)-R'), or ester groups (R-(C=O)-O-R'), or ether groups (R-O-R'), or halide substituents (-F, -Cl, -Br, -I), are somewhat more polar, and will have higher boiling points for their mass, but are still relatively unreactive to components of the GC.

Compounds with strong hydrogen-bonding groups or ionizable H⁺, like alcohols, carboxylic acids and phenols, as well as compounds with basic functionality, including amines, amides, and aromatic ring nitrogens may react with column active sites, leading to tailing peaks. They are more prone to decomposition at higher temperatures. It requires specially engineered phases and carefully deactivated columns to handle even the lighter molecules of this sort. The heavier they become and the more such features they possess, the less likely they are to make it through the GC while exhibiting good chromatographic behavior. Really active compounds, like strong acids, bases, and water can destroy a column after one or two injections at elevated temperature. Ionizable compounds which form salts will also fail to elute. One must use highly specialized columns to handle such compounds by GC.

11.10.2 DERIVATIZATION OF DIFFICULT ANALYTES TO IMPROVE GC ELUTION BEHAVIOR

One way to deal with the recalcitrant compounds described in the preceding section is to modify the troublemaking functional groups(s) to a more tractable form. Their reactivity and polarity are the cause of their bad behavior. We can use this reactivity to add a substituent

which converts them to a less-active, less-polar group. A few examples are provided below; however, a comprehensive discussion and list of derivatization reagents can be found in the book by Bruno and Svoronos.

- 1. We can **methylate** alcohols (—OH) to methyl ethers, or **esterify** organic acids (—COOH) to esters. An excellent reagent for this is **diazomethane**, CH_2N_2 . This is a toxic gas which must be generated on site, dissolved in ethyl ether, and handled with great care in a fume hood. Upon addition of its ether solution to a solution (not in alcohol or water) containing analytes, their alcohol or acid functionalities are instantly converted (methylated), the byproduct is inert nitrogen gas, and excess reagent is quenched by adding water.
- 2. We can deactivate both acids and alcohols by replacing their end hydrogen with a **trimethylsilyl** (—Si(CH₃)₃) group, and also tame the basic amines by bonding this group to their N atom. The silyl esters, ethers, or amides thus formed present a relatively nonpolar trimethyl face to the stationary phase, where earlier an active, polar irritant was present. Despite the larger mass added by this group, such derivatives are actually more volatile, and will elute faster at lower temperatures. Derivatizing agents such as trimethylchlorosilane or hexamethyldisilazane are used to accomplish this.

Such agents function less instantaneously than diazomethane. They react faster at quite high temperatures. One way to achieve those has been to mix them with the injection solution. Upon flash vaporization in the hot injection port at the head of the column, the derivatization reaction is nearly instantaneous and complete. This procedure is known as **on-column derivatization**. Such a mode of introduction of this reagent also achieves the purpose of reacting with and deactivating the free —Si—OH active sites in the column, as described in Section 10.5. This treatment is called **silanization**.

3. We can **acylate** alcohols to esters by reacting them with active organic acids or anhydrides. For example, heptafluorobutyric anhydride derivatizes R—OH to R—O— (C=O)—C₄F₇. After quenching excess anhydride, the liberated heptafluorobutyric acid must be left behind in an aqueous phase by extracting the derivative into an organic layer under basic buffer conditions. The acid is extraordinarily strong, and just a trace in a single injection could utterly destroy even a robust PDMS stationary phase.

The heavy $-C_4F_7$ group nevertheless is so much less polar than the -OH it replaced (think "Teflon") that the derivative will elute more easily than the parent compound. An additional advantage is that all those electronegative F-atoms yield a derivative with ECD sensitivity, making our analyte responsive to a more sensitive and selective detector. Derivatizing to add groups with heavier halides like Cl or Br would confer even greater ECD sensitivity, albeit with perhaps less volatility. Incorporating Cl or Br atoms into the analyte derivative would produce MS mass fragments with the characteristic isotope cluster patterns of these halides, which would make them stand out when using GC-MS detection.

To summarize, derivatization for GC can confer greater thermal stability to an analyte. It can convert the analyte to a form which is more volatile, less polar, and with fewer tendencies to produce tailing peaks by interaction with column active sites. It can introduce elements into it which make it detectable by more sensitive or selective detectors. In real-world analyses, selectivity often confers more effective sensitivity to an assay. The scope of derivatization for GC is far greater than the several examples listed here. See the bibliography (Grob, Jennings, Scott) or product literature from specialty derivatization agent vendors (Appendix 11.A on the text website) for more examples.

11.10.3 GAS ANALYSIS BY GC

Not surprisingly, GC is the method of choice for the analysis of mixtures of gases (compounds that are vapors at room temperature). The procedures for sampling and introduction to the

GC instrument differ from the standard syringe injection or SPME techniques employed for neat liquids or dilute solution samples. Gases at trace levels in air or dissolved in water may be present at levels too low to measure with the volumes one might sample and inject with a syringe. Certainly, one would not wish to introduce several milliliters of water into a GC column!

Trace levels of gases in air can be sampled by drawing large volumes of air (up to cubic meter volumes) with a pump through a trap (a tube or plate filled with a special sorbent packing) for periods up to an hour or more. One especially useful sorbent is a packed bed of **Tenax*** particles. These are beads of polyphenylether polymer [(... $-\Phi$ -O $-\Phi$ -O-...), where $\Phi = 6$ -carbon aromatic *para*-phenylene ring]. Some varieties have additional phenyl rings substituted on the phenylene units in the polymer backbone. At room temperature, this will absorb small organic vapor molecules while letting fixed gases, and, most importantly, water vapor pass through. After these are concentrated from a large volume of air slowly sampled over time, a trap oven heats the trap rapidly to desorb the mixture almost instantaneously to a GC configured for low molecular weight gas analysis. An alternative form of trap employs activated charcoal. Thermal desorption is not as efficient with this, so the trap packing is emptied after sampling, and the analytes are desorbed by carbon disulfide solvent, which is then filtered, concentrated, and injected into a standard low temperature GC system. This method works best for a range of higher MW vapor molecules than the range covered by thermal desorption from Tenax*. Figure 11.23 displays elution of both fixed gases and low MW organics from a new GC column which can handle both while operated near room temperature. Trace level sampling for this type of analysis would probably require liquid N₂ **cryotrapping** for the fixed gases after Tenax* trapping for the less volatile small organics. It is remarkable that a single GC column phase can handle separation of both classes simultaneously.

Trace levels of gases or volatiles in water can be sampled by **purging** a water sample with a cloud of gas bubbles (N_2 or He) introduced through a **frit** at the bottom of the sample vessel. The purged vapors and large amounts of entrained water vapor pass through a trap packed with Tenax or porous polymer beads that does not retain the large excess of water. After the analyte vapors are completely purged from the sample and captured on the trap, they are thermally desorbed to a GC column separation and detection system in a fashion similar to the procedure for trace gases in air. Dedicated instruments connected to a GC are designed to sequentially perform such a procedure on multiple samples of water and are called "**purge and trap samplers**".

These traps for volatiles at room temperature behave like GC columns operated at too low a temperature to have significant elution in a reasonable time. Since the sample is being loaded constantly over a long sampling time, eventually the trap may become saturated with analyte, and/or slow elution through the trap tube will eventually cause analytes to start coming out the downstream end of the trap. At this point, the amount on the trap reaches an equilibrium value and is no longer proportional to the time-averaged concentration in the volume sampled. **Breakthrough** is said to have occurred. Often a smaller trap will be added in series behind the main trap. If it is first separately desorbed and analyzed, and no analytes are detected, and it is then removed or left at the desorption temperature, one may be confident that breakthrough has not occurred on the primary trap and proceed to desorb and analyze its contents.

For the separation of **fixed** (sometimes called **permanent**) **gases** (e.g., H₂, He, Argon, O₂, N₂, CH₄, CO, CO₂), one scarcely needs a column oven—a column refrigerator would seem more in order. Unfortunately, when most polymer phases are frozen solid, gas molecules do not partition efficiently into them. Packed particles of a **molecular sieve** material can separate these small ultra-volatile molecules. Molecular sieve materials, sometimes produced from the catalyst minerals called zeolites, have pores of the dimension of the fixed gas molecules. Larger molecules cannot enter and elute with the mobile phase gas stream. The small molecules vary in the extent to which they can diffuse in and out of the pores and through the sieve, and are thereby separated. Figure 11.6 displays such a separation. The principle of excluding the larger molecules is similar to what happens in **size exclusion chromatography** described in Chapter 12. For those molecules which can enter the openings of the sieve




FIGURE 11.30 Molecular sieve PLOT column separation of fixed gases with TCD detection.

particles, the factors governing relative retention are more complex. It is not easy to rationalize the elution order seen in Figure 11.30.

Another type of packed column particle useful for relatively small molecule separations is a **porous polymer** (trade name: **Porapack* or HaySep**). These are like the molecular sieve, but made of organic polymers or resins with larger sized pores. Highly volatile molecules larger than the fixed gases, but of a size containing only a few atoms, are retained by these materials, even at temperatures high enough to be controlled by standard GC column ovens. Even these materials have now been engineered into coatings for open tubular GC, with its inherent advantages, and are sold as **porous layer open tubular (PLOT)** columns. A representative separation of small molecules on a PLOT column is displayed in Figure 11.31. An advantage of these porous polymer phases is that they will even tolerate and separate water, albeit with poor tailing peak shape. This ultra-polar and strong hydrogen-bonding liquid is




FIGURE 11.31 Porous polymer PLOT column separation of low molecular weight gases with TCD detection: analysis of PH₃ and AsH₃ in C_1 – C_3 hydrocarbons.

usually totally incompatible with and destructive of other polymer stationary phase coatings. PLOT columns are susceptible to releasing the small particles coated onto the walls of capillary tubing, and these can clog the column flow through the column or of narrow-bore components downstream of it.

11.10.4 LIMITATIONS OF GAS CHROMATOGRAPHY

GC serves well for analyzing many mixtures of compounds significant for environmental pollution monitoring, checking processes and contaminants in synthetic chemical manufacture, characterizing complex petroleum hydrocarbon mixtures, and of course it shines at the low end of the compound volatility range. The huge area of application of chromatographic instrumentation in the 21st century is in biochemical, medical, and pharmaceutical research. The chemistry of life sciences is mostly chemistry in aqueous media, and many of the compounds are correspondingly polar, to function in this very polar medium. The complexity of life processes demands large, complex molecules: enzymes, proteins, receptors, hormones, the double helix of DNA, RNA, nucleotides, and so on. These things are generally polar, full of acidic and basic functionality, and too large to be volatilized into a GC without suffering catastrophic thermal decomposition, even if derivatization is attempted. Chromatography in the liquid state, at temperatures closer physiological values, is required to separate, identify, and quantitate these complex mixtures. GC led the way in instrumentation for chromatography, but the torch is being passed to those methods which are carried out in liquids. One does not see many GC instruments in genomics or proteomics laboratories. Chapter 12 covers the instruments and methods for chromatography in the liquid state.

PROBLEMS

- 11.1 Indicate whether packed GC columns or open-tubular GC provide the best performance in each of the following categories:
 - 1. Analyte capacity
 - 2. Peak resolution
 - 3. Number of peaks resolvable in a given time
 - 4. Operation of detectors without need for makeup gas flow
 - 5. Ease of interfacing to mass spectrometer
 - 6. Ease of interfacing to FTIR spectrometer
 - 7. Operability without need for separately heated injection port
 - 8. Capable of using the longest columns
 - 9. Capable of producing the most inert deactivated column
- 11.2 Indicate which injection mode (split or splitless) best fits or meets the criteria below
 - 1. More sensitive detection
 - 2. Less solvent peak tailing
 - 3. Most appropriate for injection of "neat" samples
 - 4. Not appropriate for packed column application
 - 5. More likely to need initial temperature hold before temperature program begins
 - 6. Preferred for operation with gas sampling valve injection
 - 7. Works best when doing SPME desorption
- 11.3 What is the effect on retention time (longer, shorter, unchanged) of the following?
 - 1. Septum coring
 - 2. Loss of stationary phase by column bleeding
 - 3. Operating column at higher temperature
 - 4. Operating column at higher head pressure
 - 5. Clipping off front 5 % of column to remove nonvolatile contaminants
 - 6. The air peak's elution on a PDMS column when temperature is raised
 - 7. Changing carrier gas from He to N_2 , if flow, temperature, and column are same
 - 8. A small leak where the column is attached to the detector
 - 9. A small leak where the column is attached to the injector port

- 11.4 Describe the sequence of events that would lead to septum bleed giving rise to spurious GC peaks
- 11.5 Why does column bleed not give rise to such spurious peaks? What is its GC signature? Are you more likely to observe this signature in isothermal or programmed temperature GC? Why?
- 11.6 Answer the questions below for each of the following analyte mixtures
 - 1. HCN volatilized from whole blood
 - 2. Pure gasoline
 - 3. Organophosphorus pesticides at 1 ppm each in hexane
 - 4. Trace volatile chlorocarbons in swimming pool water
 - 5. Trace inert gases in air
 - 6. Rapidly repeated sampling of major hydrocarbons in natural gas pipeline
 - 7. Dimethylbenzothiophene ($C_{12}H_8S$) isomers in crude oil
 - 8. <50 ppm polychlorinatedbiphenyl mixtures in transformer fluid
 - 9. Two completely unknown peaks at 0.1 % concentration each in toluene
 - 10. BTEX vapors in refinery air
 - A. Which of the following sampling and injection methods would best for each sample?
 - a. Split injection
 - b. Splitless injection
 - c. SPME
 - d. Headspace SPME
 - e. Has valve injection
 - f. Tenax trapping with thermal desorption
 - g. Purge and trap sampling
 - B. Select one or more detectors from Section 11.7 (and only one example from hyphenated methods, Section 11.8) which would be most suitable to analyze these samples
 - C. Which of the following columns would be best for each sample?
 - a. 10 m Porapak PLOT Q
 - b. $20 \text{ m} \times 0.25 \text{ mm} \times 0.25 \text{ } \mu\text{m} \text{ PDMS}$
 - c. 5 Å molecular sieve
 - d. $40 \text{ m} \times 0.18 \text{ mm} \times 0.1 \mu\text{M PDMS}$
 - e. 10 m SolGel-Wax column
- 11.7 A. Draw a representative structural formula of a portion of a PDMS polymer phase deposited on fused silica
 - B. Draw the structure for such a crosslinked PDMS phase
 - C. Draw the structure for such a bonded PDMS phase
 - D. Draw the structure for such a bonded and crosslinked PDMS phase
- 11.8 Using the chromatographic system pictured in Figures 12.10 and 12.11 to analyze two trichloronaphthalene isomers
 - 1. Which selective detector from section 12.7 is most suitable?
 - 2. With N₂ carrier gas what flow rate (cm/s) should be used?
 - 3. With H₂ carrier gas what flow rate (cm/s) should be used?
 - 4. How would you measure and set these flow rates?
 - 5. Which compound would be most suitable to use to measure the linear flow rate $(Cl_2, CH_3Cl, or chlorobenzene)$?
 - 6. What auxiliary gases (if any) will be needed to operate with H₂ carrier gas?
 - 7. If the Kovats RI of two of the analytes are known to be 915 and 920, what temperature would be suitable for an isothermal analysis to separate this pair?
 - 8. If chloronaphthalenes with more chlorines are present as well, what temperature program should be used?
 - 9. If the first pair cannot be separated, describe three changes in the column that might be tried to achieve this

- 11.9 Which detector (from Section 11.7) is most suitable for each analyte below:
 - 1. Neon
 - 2. Krypton and xenon in air
 - 3. Nitrogen in air
 - 4. CO₂
 - 5. Trace carbon tetrachloride in hexane
 - 6. Trace "eau de skunk", n-butyl mercaptan, C₄H₉SH
 - 7. Trace PCB (polychlorinated biphenyl) mixture in solvent
 - 8. Trace TNT (trinitrotoluene) vapor in air
 - 9. Mixture of fatty acid methyl esters
 - 10. Heavy crude oil sample
 - 11. Trace BTEX mixtures on handheld monitoring GC instrument
- 11.10 Which hyphenated GC system detector and mode of detection (listed in Section 12.8) would be most suitable for analysis of the following samples:
 - 1. Identification by library searching of 100 possible different pesticides in vegetation extracts
 - 2. Finding traces of mono-, di-, and trimethyldibenzothiophene isomers in a fuel oil sample
 - 3. Identifying the compounds found in (2) against standards of the authentic isomers
 - 4. Identifying the compounds in (2) against library spectra
 - 5. Identifying the maximum possible number of components in a fuel oil sample over the widest concentration range.
 - 6. Detection of small amounts of an unanticipated class of isomers in a hydrocarbon mixture, followed by identification of the compound class, followed by quantitation of relative amounts of the peaks for this subset of compounds assuming they all had similar relative response factors (RRFs)
- 11.11 Retention data for three dimethylnaphthalene isomers (D1–D3) and the *n*-alkanes between which they elute in Figure 11.16 are listed in the table below:

Temperature	Compound	R _t (n)	R _t (N)	$R_{\rm t}(U)$
100 °C	D1	9.55	15.20	14.80
	D2	15.20	29.80	16.40
	D3	15.20	29.80	17.20
120 °C	D1	4.84	7.60	7.37
	D2	7.60	12.60	8.03
	D3	7.60	12.60	8.47
150 °C	D1	2.43	3.38	3.23
	D2	3.38	4.57	3.61
	D3	3.38	4.57	3.78
Program	D1	5.21	6.67	6.61
	D2	6.67	8.92	6.97
	D3	6.67	8.92	7.21

The retention times are in minutes for preceding (n) and following (N) n-alkane peaks, and for each of the three D1–D3 unknowns (U). As mentioned in the text the column dead time was 1.08 min.

Using the formulas of Equations (11.1) and (11.2), set up and use a spread-sheet to calculate the RI values for each of the three compounds at each of the four temperature conditions. If you cannot program this, calculate the values with a hand calculator, which will take lots more time. How well do the RI values compare? Some of the variation is due to inaccuracies in the simulation program used to generate the data, but some reflects how these values depend on the conditions under which they are acquired.

How well do the values approximated from the programmed temperature formula compare with those of the theoretically more accurate isothermal runs? Which isothermal run do you think should provide the best RI values?

Perhaps the RIs vary more with temperature because the analytes are aromatic and the reference compounds are aliphatic. If you have the spread-sheet set up, measure the retention times in the figures and put in the appropriate values for the triplets of branched hydrocarbons C10s or C14s and see whether their RIs are more consistent with variation of temperature.

There are actually ten possible dimethylnaphthalene isomers. See if you can draw them all. Naphthalene consists of two hexagonal rings of six carbons sharing an edge (so there are ten carbons in all). The eight carbons to which substituents can be attached are numbered clockwise from 1 to 8 around the ring starting at the top right side. Suppose we obtained a GS-MS-SIM chromatogram of a petroleum oil at mass 156, which showed a cluster of six peaks, three of which matched the RIs of D1, D2, and D3, and two of these are "fatter" than the other four.

- 1. Why might we not be seeing all ten isomers (more than one reason)?
- 2. How might we attempt to find the others?
- 3. How would running authentic standards of all 10 isomers help resolve the uncertainties?
- 4. How would having RI data on all ten help? As much as the standards? Why or why not?
- 5. You find another mass 156 peak in the SIM chromatogram with an RI of 1100. Is that one of the missing isomers? What might it be? If you had acquired data with an ion-trap MS, how might you check this out?
- 11.12 Suppose all the compounds eluting in the chromatogram of Figures 11.13 and 11.14 had the same detector RRF and were all present at the same concentration. How would the peak heights differ from the "phony" artificial ones in the simulated chromatogram? Sketch the appearance of the actual chromatograms for the 100 °C isothermal run and the programmed temperature run using the same retention time scale. What causes the difference in peak heights, areas, and widths?

BIBLIOGRAPHY

Barry, E.F.; Grob, R.L. Columns for Gas Chromatography: Performance and Selection, Wiley, New York, 2007.

Blumberg, L.M. Temperature-Programmed Gas Chromatography, Wiley: New York 2010.

Bruno, T.J., Svoronos, P.D.N., CRC Handbook of Basic Tables for Chemical Analysis – Data Driven Methods and Interpretation, CRC Taylor & Francis, Boca Raton, FL, 2021.

Cazes, J. Encyclopedia of Chromatography; Marcel Dekker Inc.: New York, 2001.

Frame, G.M.; Flanigan, G.A.; Carmody, D.C. J. Chromatog. 168, 365, 1979.

Frame, G.M.; Cochran, J.W.; Bowadt, S.S. J. High Res. Chromatogr. 19, 657-668, 1996.

Frame, G.M. Fresenius J. Anal. Chem., 357, 701-722, 1997.

Frame, G.M. Anal. Chem., 69, 468A-475A, 1997.

Grob, R.L. Modern Practice of Gas Chromatography, 4th edn; Wiley: New York, 2004.

Hubschmann, H.-J. Handbook of GC-MS, Fundamentals and Applications, Wiley: New York, 2008.

Jennings, W.; Mittlefehlt, E.; Stremple, P. Analytical Gas Chromatography, 2nd edn; Harcourt Brace: Orlando, FL, 1997.

Koel, M. Ionic Liquids in Chemical Analysis, Taylor & Francis, Boca Raton, FL, 2008.

McMaster, M. GC/MS: A Practical Users Guide, 2nd edn; Wiley: New York, 2008.

McNair, H.; Miller, J.M. Basic Gas Chromatography, 2nd edn; Wiley: New York, 2009.

Niessen, W.M.A., (ed.) Current Practice of Gas Chromatography—Mass Spectrometry, Marcel Dekker, Inc.: New York, 2003.

Rood, D. A Practical Guide to the Care, Maintenance, and Troubleshooting of Capillary Gas Chromatographic Systems, 3rd revised edn; Wiley: New York, 1999.

Scott, R.P.W. Chromatographic Detectors, Marcel Dekker, Inc.: New York, 1996.

Scott, R.P.W. Introduction to Analytical Gas Chromatography, 2nd; Marcel Dekker, Inc: New York, 1998.Sparkman, O.D.; Pentan, Z.; Kitson, F.G. Gas Chromatography and Mass Spectrometry, A Practical Guide, 2nd edn; Elsevier Academic Press: Oxford UK, 2011.

Chromatography with Liquid Mobile Phases

12

12.1 HIGH-PERFORMANCE LIQUID CHROMATOGRAPHY

The first chromatography was performed using liquid mobile phases to separate colored plant pigments, which caused its inventor, Tswett, to give it the name of "color writing" (Section 10.1). Crude liquid chromatographic separations under gravity flow were commonly used to characterize synthetic mixtures from the organic research lab, but it was the chromatographic version of the venerable distillation process which was first instrumentalized as gas chromatography. The reasons for this precedence were discussed in Section 11.1. Diffusion and equilibration in the column are much faster with gases. To attain equivalent diffusion equilibration using a liquid mobile phase requires that the dimensions for diffusion be much smaller. These dimensions will be those of interstitial space in a packed column or the diameter of an open tubular column. Liquids are much more viscous than gases. To force liquid to flow through such narrow pathways requires that orders of magnitude greater pressures be imposed across a column capable of withstanding these pressures. Suitably small support particles need to be coated with an extremely thin layer of stationary phase, then be packed tightly, and not develop resolution-destroying voids as high-pressure pumps cycle over the immense range necessary to move the liquid through the bed of microscopic particles. Detectors for analytes in the small eluted peak volumes of the liquid mobile phases needed to be designed. Analytical chemists invented this whole suite of improvements, resulting in an instrumental version of liquid chromatography known as HPLC. In the early days of the method, this was often understood to stand for high-pressure liquid chromatography, for it was instrumentation that could control these necessary pressures that made HPLC possible. The abbreviation is now used to mean high performance LC.

HPLC is now a larger market than GC. Why has this happened? Analytes for GC are limited to compounds with relatively low molecular weight and low polarity, which are electrically neutral (uncharged) and thermally stable. Vast numbers of biochemically important molecules fall outside these categories. There are more parameters available to vary in liquid mobile phase chromatography than in GC, so it is divided into a number of techniques. Some are named for the different mechanisms of separation employed (e.g., partition, adsorption, size-exclusion, ion-exchange, immunoaffinity, etc.). Others are described by the design of the separating technique (e.g., thin layer, high-pressure column, and electrophoresis, which is not even really a chromatographic method, but has similar features such as peaks, elution times, resolution, capillary columns or 2D plates, and chromatographic type detectors.)

The major method is HPLC, operating as **partition chromatography**. This is what is commonly implied when the term HPLC is used. It is the mode we will discuss initially as we cover the design and function of the pumps, columns, stationary and mobile phases, injectors, and detectors. Recall the discussion in Section 10.5, where initially, the partitioning of analytes between nonpolar liquid mobile phases and silica particles with adsorbed water became known as "**normal phase**" chromatography. For the larger population of more polar analytes encountered in biological systems, it became more advantageous to reverse this. A more polar, more aqueous mobile phase could carry such analytes past particles coated not with adsorbed water molecules, but with covalently attached nonpolar organic groups. This received the name "**reversed phase**" HPLC (RP-HPLC), and it became the workhorse of the field. Let us then start our discussion with RP-HPLC, and contrast the design features of the instrumentation with those of GC, which were covered in Chapter 11.

12.1.1 HPLC COLUMN AND STATIONARY PHASES

Compare GC with HPLC. The typical capillary GC column has an internal diameter around 0.25 mm (or 250 μm). A typical polymer stationary phase coating on the inner wall of this capillary is 0.25 μm (or 250 nm). The high diffusion rate of analytes in the gas phase permits rapid near-equilibration over such distances. Diffusion in a liquid is much slower. If we compensate by reducing the dimensions of a capillary LC system sufficiently to attain the desired near equilibration condition, they will be very small indeed, with a bore measured in a few microns. To retain a phase ratio similar to GC, the stationary coating must shrink to a thickness of several nanometers (nm). This is in the size range of single molecules. An open-tubular LC column with such dimensions would have a very minimal sample capacity before it overloaded, and it would be very difficult to build a detector that would work on such a small scale. Larger volume detectors would introduce severe extra-column band broadening or require extensive makeup flow which would further dilute the already miniscule concentrations of analyte eluting from such a column. Capillary HPLC is possible when samples are limited to very small amounts, but it is nowhere near as common as capillary GC.

The way to achieve HPLC is to return to packed columns, but to implement them with support particle and stationary phase coating dimensions much smaller than those of packed column GC. Typically, one employs spherical silica particles of uniform diameters (mono**disperse**) in the range of 1.7-10 μ m. The interstitial spaces between the tightly packed spheres will be of similar dimension. Unlike the much larger support particles in packed column GC, these LC particles often have a smaller scale **secondary internal porosity** of channels permeating the particle, into which analytes can diffuse. The stationary phase coating in GC is like a true quasi-liquid polymer many molecular sizes thick—a true phase with a boundary across which molecules diffuse, dissolve, and partition from the mobile gas phase. Indeed, GC stationary phase behaves thermodynamically like a liquid, with the same enthalpy of solution, activity coefficients, etc., as can be measured in a bulk liquid. In contrast, the stationary phase on these porous micro-HPLC particles is an organic monomolecular layer chemically bonded to the free silanol groups on the silica surface. The most common such group is a long-chain *n*-C18 hydrocarbon (**octadecyl silyl group, ODS**). See Figure 12.1. If stretched out, such a chain is on the order of several nanometers long, which is just the thickness proposed in the previous paragraph. The structure of such coated microporous particles

(ii)
$$\begin{cases} -CH_3 \\ -CH_3 \\ -CH_3 \end{cases} \rightarrow \begin{cases} -CH_2 \\ -CH_3 \\ -CH_3 \end{cases} + HCI + CI - \frac{CH_3}{S_1 - OH_3} - \frac{CH_3}{CH_3} + HCI + CI - \frac{CH_3}{S_1 - OH_3} - \frac{CH_3}{S$$

FIGURE 12.1 Types of ODS-silica HPLC stationary phases: **(a)** i, synthesis of monomeric C18; ii, synthesis of polymeric C18; iii, endcapping process; and **(b)** i, monomeric C18 ligand; ii, endcapped silanol; and iii, residual silanol. (Cazes, used with permission.)




FIGURE 12.2 (a) and **(b)** Conventional microporous structure of bonded phase HPLC particle. A particle of column packing is honeycombed by pores. Most of the surface area is inside these pores. Drawing not to scale; typical pore diameters are 1-5 % of the particle diameter. **(c)** Magnified cross-section of a pore, showing a layer of alkyl Chains bonded to the silica surface. (Used with permission from Sigma-Aldrich, a part of MilliporeSigma. www.sigmaaldritch.com. Copyright 2020 Sigma-Aldrich Co. LLC. All rights reserved.)

is diagrammed in Figure 12.2. Here are some points of contrast between HPLC and packed or capillary GC stationary phases:

- 1. Each LC phase molecule is *bonded* to its solid support surface, but is less often *cross-linked*.
- 2. The HPLC phase is so thin that it is not a fully randomized fluid, like a GC polymer coating.
- 3. Usually it is impossible, due to steric hinderance or increasing crowding, to attach a molecule [like the $-O-Si-(CH_3)_2C_{18}H_{37}$ group] to every free silanol bonding site on the silica surface.
- 4. These unreacted silanol sites lie closer to the mobile phase than in GC, and can easily act as active sites degrading the chromatography as described in Section 10.4.
- 5. The unreacted active sites on the support surface must be masked by reacting with a very short group [such as —Si—(CH₃)₃] which can penetrate to react and bond with many if not most of the remaining silanol groups, a process called **endcapping**.
- 6. Because the composition of the liquid mobile phase is varied, it can interact to cause alterations in the alignment of the stationary phase molecules, and thereby affect their partition behavior with some analytes. This dependence of stationary phase behavior upon mobile phase composition is not found in GC, and it adds more complexity to prediction of HPLC separation behavior.
- 7. The small interparticle spacing in HPLC columns requires stable, uniform, spherical particles to avoid their packing together in a fashion which will block uniform flow through these tiny interstitial passages. Mobile phase solvents must be **filtered** to remove micron-size particles which could plug up these interstitial volumes and block or channel mobile phase flow.
- 8. Dissolved gases in the mobile phase may come out of solution and form bubbles as the pressure changes from the entrance to the exit of the column. Those will block and channel flow, degrading resolution or even blocking the column completely. Even if the bubbles redissolve, the resultant large cavity in the packing may introduce extra-column band broadening. Mobile phase liquids must be **degassed** prior to use, by filtering under vacuum or by **sparging** with a flow of fine bubbles of poorly soluble helium gas.
- 9. As the instrument cycles the column through very large pressure changes as the pumps turn flow on and off, the packed bed may move or settle, yet again introducing a **void** and its extra-column band broadening.



FIGURE 12.3 Typical HPLC columns. (Courtesy of Waters Corporation, Milford, MA. www. waters.com. Used with permission.)

- 10. Outside certain bounds of pH and/or temperature the liquid mobile phase may attack and gradually dissolve the silica support particles, and/or release the bonded stationary phase molecules.
- 11. Because of the smaller particle size and internal porosity of LC packings, the area covered by the molecular monolayer stationary "phase" is vastly greater than that of the thick polymer film stationary phase in GC columns of similar volume. This restores the analyte capacity of these columns to a level compatible with typical chromatographic detector designs.
- 12. The HPLC columns must operate at pressures of 500-6000 psi, orders of magnitude higher than GC columns. The mobile phase must be pumped instead of coming from a pressurized cylinder through a reducing valve. The columns are commonly fabricated from thick-walled stainless steel, with stainless steel mesh packing restraining frits, and use stainless steel or high impact plastic nut and ferrule fittings (Figure 12.3).

The effects on analyte resolution of particle size and column length in HPLC are analogous to those of capillary column diameter and length in GC. However, one does not vary the film thickness of the bonded phase molecules in HPLC. The percentage of available silanol sites to which stationary phase groups have been bonded can vary. A larger percentage does not directly translate into a larger effective volume of stationary phase. It is the surface density of the groups which varies, and with it the molecular interaction strength, not just the volume available for analyte partitioning. The percentage and completeness of endcapped silanol groups is an extra variable that also impacts the nature of the analyte interaction with the phase. The lesson here is that different preparations of a reverse phase packing category, such as the workhorse silica-ODS, can vary widely in their suitability for different analytes, depending on analyte size, polarity, acidity or basicity, and the characteristics of the interactions with the mobile phase. All ODS columns are not created equal! Even more so than with GC columns, comparison of manufacturer's specifications and application notes from catalogs or websites is the efficient first step in column selection.

12.1.1.1 SUPPORT PARTICLE CONSIDERATIONS

Silica can be prepared as micron-sized spheres. The internal porosity can be varied. The spheres can be generated to have a narrow range of diameters, so they will pack together uniformly. The surface silanol groups make ideal attachment points for the bonded phase molecules. At acidic low pH values, the organosilyl bonds may hydrolyze and the phase can degrade. More densely covered and appropriately endcapped silica surfaces may tolerate lower pH. At pH> 8, the silica itself may begin to dissolve at the surface. Recall that glass can be etched by strongly alkaline solutions. As will be discussed subsequently under mobile phases, there could be advantages to operating the column at elevated temperatures. Unfortunately, silica also becomes more soluble under these conditions. Recall that quartz crystals grow from hydrothermal solutions under pressure in the ground. HPLC column specifications need to be checked for their pH and temperature stability.




FIGURE 12.4 Electron micrograph of monolithic silica. (Used with permission from Sigma-Aldrich, a part of MilliporeSigma. www.sigmaaldritch.com. Copyright 2020 Sigma-Aldrich Co. LLC. All rights reserved.)

Zirconia (ZrO_2) is a new substitute for silica as an HPLC particle support, which has both greater pH range stability (1-14) and temperature stability (to 100 °C or even greater—recall that we are operating at many atmospheres pressure in HPLC, and this can elevate boiling points). For some analyses, the greater cost of zirconia columns may be offset by the improvements in analysis speed and performance they can bring to HPLC.

Another new development circumvents production of the individual particles. It casts the column as a **monolithic silica cylinder** which possesses both the macro- and micro-scale porosities and analogs to the interstitial volumes of a column packed with micron-scale spherical silica particles (Figure 12.4).

When techniques for achieving this were invented, two major new advantages ensued. First, such monolithic HPLC columns are mechanically far more stable than a packed bed of particles. There is far less possibility for development of voids and channels. Secondly, the size of the macro-scale void volumes is not constrained to the interstitial dimensions of a packed bed of spherical particles. Specifically, they can be larger, but the network of fused-together microporous support "particles" can still remain connected to one another. This additional degree of freedom in the column dimensions results in columns which can be operated at higher mobile phase flow rates, eluting analytes more quickly with lower column pressures, while still retaining the resolution performance of comparable packed columns.

A recent more sophisticated synthesis of spherical silica support particles has enabled the production of columns with much higher resolutions and shorter analysis times. The narrower and taller peaks from these columns produce better S/N sensitivity improvements. These **core-shell** column packings (sometimes called **superficially porous**) limit the small-scale intraparticle porosity to a shell-like layer (typically one half to one fifth the spherical particle radius) outside a solid impermeable core. This reduces the distance that analyte molecules can penetrate and allows them to equilibrate much faster with the flowing mobile phase. The superficially porous structure contributes to the flatter right-hand portion of the Van Deempter plot for UHPLC, and the particles' uniformity allows them to pack efficiently and reduce the A term contribution. Almost every major HPLC column supplier offers a line of core-shell particle columns: for example, Kinetex (Phenomenex), HALO (MacMod), Accucor (Thermo Scientific), Ascentis Express (SigmaAldrich), Poroshell (Agilent). Figure 12.5 displays electron micrographs of typical core-shell UHPLC particles, both surface and cross section.




FIGURE 12.5 Electron micrographs of core-shell UHPLC particles: on the left, a cross-section showing the core-shell structure; on the right, particle surfaces (note relative smooth, spherical surface of monodisperse particles). (Used with permission from Phenomenex, Inc., Torrance. CA. www.phenomenex.com.)

In an independent development, instrument manufacturers have redesigned the pumps, transfer lines, and connecters of the new model HPLC instruments to accommodate higher pressure operation with *smaller*, *fully porous* particles, which also leads to the same degree of improvement, albeit with more expense and concern about column clogging and stationary phase breakdown. These new technologies have led to **ultra-high-performance liquid chromatography** (UHPLC or UPLC) systems. So many older HPLC assays have been replaced by or converted to these UHPLC systems that they now comprise more than 50 % of the instrumental LC installed base, with this percentage continuing to rise. Performances similar to the ultra-high-pressure, small particle size instrumentation can often be achieved by converting assays on older, lower pressure instruments to those using larger core-shell phases not requiring the higher pressures required for use with the smaller particles. These developments led to the replacement of old large particle, vertical LC columns, operated with gravity driven flow (Figure 10.1), with instrumentally pumped, higher pressure, smaller particle HPLC.

Spherical, porous beads of organic polymer resin, particularly cross-linked styrene—divinylbenzene copolymer, can be used as HPLC phases. Unlike silica-ODS, the whole particle is the stationary phase. These are often designated as XAD resins. Unlike hard silica particles coated with a monomolecular layer, these resin beads will take up mobile phase solvent and swell in size. Resin bead sizes cannot be as small as the spherical silica particles, lest this swelling fill and block the interstitial macro pores. The higher pressures cannot be used, and the high-resolution efficiencies of true HPLC are rarely attained. These resins are very important as the substrates for attaching and supporting ion exchange groups to form the stationary phases for the technique of ion exchange chromatography. These will be discussed in Section 12.2. Pure polystyrene beads can serve as supports for covalent attachment of organic groups to make phases which are stable over the pH range of 8-12, but they also suffer from the structural shortcomings of the resin beads.

12.1.1.2 STATIONARY PHASE CONSIDERATIONS

Three of the most common nonpolar organic substituents employed in stationary phases for RP-HPLC with aqueous/polar mobile phases are:

Octadecyl (C18,ODS):
$$-(CH_2)_{17} CH_3$$

Octyl (C8): $-(CH_2)_7 CH_3$
Phenyl: $-(CH_2)_3 C_6 H_5$

The larger the substituent group, the more strongly and longer will it retain the nonpolar analyte, so retention will vary inversely to the order listed here.

Three examples of common polar organic substituents (incorporating functional groups to confer the desired polarity) for normal phase HPLC with less-polar mobile phases are:

Amino:
$$-(CH_2)_3NH_2$$

Cyano: $-(CH_2)_3-C \equiv N$
Diol: $-(CH_2)_2OCH_2CH(OH)CH_2OH$

Here, it is the functional groups which dominate retention. The amino and diol phases will retain compounds with pronounced hydrogen bonding potential more strongly, while the cyano phase interacts most strongly with analytes whose polar interactions result from strong dipole moments. Complex structures may interact in a combination of these mechanisms, so relative retention is less easy to predict than with the reversed phase columns.

12.1.1.3 CHIRAL PHASES FOR SEPARATION OF ENANTIOMERS

Even more specialized groups can be attached to supports to achieve particular separations. Complex cyclic carbohydrates called **cyclodextrins** exist in a single **enantiomeric form**. These are illustrated in Figure 12.6. They form a truncated conical pocket, into which different optical isomers of a compound (enantiomers) will bind with different strengths.




FIGURE 12.6 Structures of α -, β -, and γ -cyclodextrins. (Katz et al., Used with permission.)

This enables HPLC separation of these isomers, which have identical chemical structures and polarity, and differ only in their stereochemical orientation of substitution at asymmetric carbons. These are described as chiral compounds, and use of such stationary phases enables **chiral chromatography**. The cyclodextrin "pockets" come in a variety of sizes (α -, β -, γ -, etc.) suitable for separating enantiomer pairs of differing size. This capability is especially important for determining the relative amounts of each enantiomer which may be present. Solutions of individual enantiomers rotate the plane of oscillation of plane polarized light. At high concentrations, this may be measured by optical polarimetry instruments (not covered in this text). Polarimetric detectors also exist for HPLC. They are relatively insensitive (LOD ~ 5 ppm in eluent solution). For trace levels, use of even more sensitive chromatographic detectors makes resolution of enantiomers by chiral chromatography the method of choice. Often it is only one enantiomeric form of a drug compound which is active in the body. If the other form is toxic, the drug may have to be formulated to contain only the active, safe form. It then becomes critical to be able to determine whether, when, and to what extent this form may racemize (revert to an equilibrium mixture of both enantiomers) in the body. Chiral chromatography may be the only way to address this. A classic example is the drug thalidomide, originally marketed as a racemic mixture of N-phthalylglutamic acid imide. One enantiomer had the desired pharmacological activity, but it was not realized until too late that the other was a strong teratogen, capable of causing severe fetal malformations. While cyclodextrin substituent stationary phases can be used to create **chiral GC** columns as well, HPLC is better suited than GC for many chiral separations, as the elevated temperatures used in GC may induce racemization in the column. There are other chiral substituents which can be incorporated into HPLC columns to enable them to separate enantiomer pairs (see the book by Bruno and Svoronos for a more comprehensive discussion and listing), but the cyclodextrins possess exceptional discrimination ability.

12.1.1.4 NEW HPLC PHASE COMBINATIONS FOR ASSAYS OF VERY POLAR BIOMOLECULES

For highly polar biomolecules, RP phases have several shortcomings: low retention, often a need for derivatization, requirement for the use of ion-pairing reagents, analysis time too short, lack of robustness, and poor quantitation. More recently, systems have been developed to separate and quantify this class of compounds.

If the analytes are charged cations or anions (strong or weak acids or bases) then ion chromatography may perform better. This methodology is discussed in Section 12.2.

Hydrophilic Interaction Liquid Chromatography (HILIC) is a new combination of a column with more normal phase character using mobile phases with high organic content. HILIC was initially used to separate peptides on strong cation exchange columns, and later extended to other polar analytes using phases like bare silica, or highly polar cyano, diol, or amino coatings. Unlike classic NP-HPLC, which might use a pure nonpolar eluent like hexane, the HILIC system mobile phase might use a high percentage of organic solvent (e.g., > 70 % ACN) but with a critical addition of miscible 3 % water. The polar stationary phase particles will bond a small amount of water from the mostly organic stationary phase, and the separation mechanism will proceed by hydrophilic partitioning, H-bonding and electrostatic interaction from the mobile phase to the adsorbed water layer on the stationary phase. Hydrophilic analytes will have sufficient retention, and the mode of separation will be orthogonal to RP-HPLC. Additional strong advantages accrue if the separation is hyphenated to MS detection, where the sensitivity by HILIC separation is better than by RP separation in 89 % of the cases: e.g., 42 % 1-5X, 9 % 5-10X, 18 % 10-30X, and 14 % > 30X better. The highly organic mobile phase produces much less column back pressure in attaining the optimal flow rate. The best results are presently obtained with 2 µm fully porous particles that operate with pressures <400 bar under HILIC conditions. Combining HILIC and RP-HPLC orthogonally in a 2D-LC separation can be performed by off-line coupling, serial coupling, or comprehensive 2D RPLC-HILIC. The high ACN content mobile phase is especially favorable when HILIC is used to characterize large mixtures of small MW, highly polar metabolites in a metabolomic profiling study using a UHPLC-ESI MS/MS system.

Instead of the classic RP C18 ODS chains on the silica, one can attach a long organic chain which has a polar moiety embedded in it to produce a mixed mode of retention. Examples:

$$Silica - CH_2CH_2CH_2 - O - C = O - CHCH_2...CH_3$$

$$Silica - CH_2CH_2CH_2CH_2 - (3CH_2N_2 + Br_2) - CH_2CH_2CH_2...CH_3$$

In the 2nd structure above the moiety in parentheses is a five-membered, aromatic, positively charged heterocyclic ring attached in the chain through the 2 N atoms separated by both 1 and 2 carbons. This is the same cationic structure seen at either end of the GC ionic liquid phase depicted in Figure 11.9. This charged unit confers electrostatic and π -bonding retention while the long hydrocarbon tail confers hydrophobic nonpolar RP retention.

Alternatively, polar-endcapped short hydrocarbon chains on silica can be used.

A long hydrocarbon chain RP coating such C18 attached to silica will require endcapping of up to 50 % of unreacted silanol sites on the silica (cf. Section 12.1.2, point 5). If instead of the short $-Si-(CH_3)_3$ cap, a longer one with a hydrocarbon spacer holding a polar end group such as $-Si-CH_2CH_2CH_2NH_2$ is used, then another mixed polarity mode stationary phase is produced, with properties and usefulness similar to the polar embedded phase just described.

12.1.2 EFFECTS ON SEPARATION OF COMPOSITION OF THE MOBILE PHASE

In LC, the variable that affects elution and k' is mobile phase composition. The factor which is being varied is polarity of the solvent mixture. This is more complex and less easy to define rigorously than temperature in GC. It is a relative value applying to the molecules to be separated, and to both the mobile phase and stationary phase materials. Polarity interactions can be of several types (e.g., dipole-dipole interactions, π -bonding interactions, and acid-base or hydrogen-bonding interactions [proton donors or acceptors]). Both analytes and the chromatographic phases can display polarities which are combinations of these mechanisms. In GC, there were only two polarities involved: those of the analyte and those of the stationary phase. In LC we add the third—the mobile phase—and it is this one that we can vary most readily. A detailed discussion of how one would evaluate the polarity and interactive components of the analyte molecule, select the most appropriate stationary phase, and then adjust the solvent mixture in the mobile phase to optimize a separation is beyond the scope of this text. What follows are a few oversimplified, general "rules of thumb".

- 1. The overall polarity contributions from particular functional groups increase in the order: hydrocarbons < ethers < esters < ketones < aldehydes < amides < amines < alcohols.
- 2. For partition chromatography, it is best to use a stationary phase of polarity opposite to that of the analytes, and to elute with a mobile phase of different polarity.
- 3. In the extreme of normal phase HPLC, the stationary phase is highly polar, adsorbed water on silica or alumina supports, so the eluants should be nonpolar, often hydrocarbon solvents. The mechanism of normal phase HPLC is often classified as adsorption rather than partition, as the analytes are essentially binding to a highly polar surface.
- 4. Reverse phase (RP) partition HPLC uses less-polar bonded organic groups as the stationary phase, so the mobile phase is more polar. This is preferred for more polar biomolecules, since they have been selected by evolution to function in polar aqueous environments.
- 5. The most polar components of a RP-HPLC mobile phase will often be water (HOH), acetonitrile (CH $_3$ —C \equiv N), or methanol (CH $_3$ OH). The polarity of the mobile phase can be adjusted to values between these by mixing them in different proportions. Even less-polar compounds, such as ethanol, tetrahydrofuran, or diethyl ether, may be added to bring the overall eluent polarity down even more, or to introduce different interaction mechanisms of polarity which may increase the separation factor α between close pairs of analytes. Being at the extreme end of the polarity scale, water is often considered the fundamental component of the mobile phase mixture, and the other less-polar, organic solvents which may be added are termed "**organic modifiers**".

TABLE 12.1 Eluent Strengths, ε^0 , and Polarity Indices, P', of Selected Mobile Phase Solvents

Solvent	ϵ_{0}	P'
Cyclohexane	-0.2	0.04
<i>n</i> -Hexane	0.01	0.1
Carbon tetrachloride	0.18	1.6
Toluene	0.29	2.4
Tetrahydrofuran	0.57	4.0
Ethanol	0.88	4.3
Methanol	0.95	5.1
Acetonitrile	0.65	5.8
Ethylene glycol	1.11	6.9
Water	~∞	10.2

There are several methods of quantifying the relative solvent strengths or polarities of liquids used as mobile phases in HPLC. Table 12.1 displays values from two such systems for selected solvents. The first was developed to describe the relative ability of eluents in normal-phase adsorption LC to solvate analytes and move compounds through the column more quickly. This **eluent strength**, ε^0 , is ordered in the **eluotropic series**. The values are obtained using alumina (Al₂O₃) particle columns. Its zero point is defined by *n*-pentane, and it goes to very high values for highly polar water. The corresponding values on silica are about 80 % of the alumina values. Clearly, water as a mobile phase will very rapidly elute anything adsorbed to the adsorbed water of these stationary phases. The second column of Table 12.1 lists values for a **polarity index**, P', developed by L.R. Snyder. These indices are derived from solubility of the solvent in three test solvents chosen to have high- or low-dipole proton acceptor polarity or high-dipole proton donor polarity. The polarity index of mixtures of solvents can be calculated by summing the products of their respective polarity indices and volume fractions in the mixture ($P_{AB...} = \phi_A P'_A + \phi_B P'_B + \cdots$, where ϕ is the volume fraction).

It is possible to optimize a RP-HPLC separation of several compounds by systematically varying the proportions of three appropriate solvents, usually water and two organic modifiers. By observing the relative shifts of $R_{\rm t}$ as each change is made, and using as few as seven runs with well-chosen variations, one can create a *solvent polarity triangle* for the separations. Data from this will enable calculation of an optimum mobile phase composition for the separation. For HPLC instruments equipped with separate mobile phase solvent reservoirs and programmable precise mixing valves, this process can be automated, and the mobile phase optimization can even be done without operator intervention.

The major contrast with GC is that the mobile phase eluent strength (affecting k') and the relative selectivity between analytes (α) can both be readily varied. In GC, the carrier gas composition has practically no effect on selectivity, and varying temperature affects only k'. The large number and range of parameters to be evaluated to optimize the eluent composition makes HPLC method development more complex. The Agilent GC method translator was referenced in Appendix 11.A. Thermo Scientific offers on-line a LC method translator program, listed in Appendix 12.A. text website Experimenting with these shows the effects of parameter changes more rapidly than solving the relevant equations manually. Even more powerful is the DryLab 4 UHPLC computer-based modeling software from the Molnar Institute for Applied Chromatography (www.molnar-institute.com, info@molnar-institute.com) which employs the principles of quality by design (QbD) to select and model the most important factors affecting the quality and robustness in the development of proposed separations. Free examples are available on their websites for informational purposes.

12.1.3 DESIGN AND OPERATION OF AN HPLC INSTRUMENT

Figures 12.7(a) and (b) are photographs of a modern UPLC system.

Figure 12.8 is a schematic diagram of a typical HPLC instrument. We will use this figure to discuss the features of the major components, and describe the construction of some of them. We will use this discussion to illustrate some of the major modes of operation of HPLC instruments. We proceed in order of the numbered items of the figure:

1. *Mobile phase degassing*: the figure shows a setup designed to sparge four separate reservoirs with He gas. It is distributed by the fixed splitter valve to fritted glass or metal filters which disperse the gas into a fine cloud of bubbles, driving out (sparging) other dissolved gases. Removal of dissolved gases could alternatively be done by manually filtering over vacuum prior to placing in the reservoirs.



FIGURE 12.7 (a) Nexera 40 UHPLC system (b) Nexera 40 UHPLC with large autosampler racks on left. (Courtesy of Shimadzu Corporation, Kyoto, Japan. www.ssi.shimadzu.com. Used with permission.)




FIGURE 12.8 Diagram of conventional HPLC instrument. (© 2020 Perkin Elmer, Inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

- 2. *Mobile phase storage*: the figure shows four reservoirs, one for each of up to four pure solvents [e.g., water (perhaps with pH controlling buffer), ACN, MeOH, THF]. Note the use of inlet filters. Alternatively, one could prepare the mobile phase mixture to the desired composition manually, and store it in a single reservoir. Operation at a single, constant mobile phase composition is called **isocratic** HPLC elution.
- 3. Mobile phase mixing: the solvent proportioning valve can be programmed to mix solvents from the reservoirs to produce the desired mixture composition. This could be a constant proportion mixture for isocratic operation, or one could vary the solvent strength of the mobile phase with time by changing the mixture proportions. As a simple example, the mobile phase composition could be programmed to vary from 75 % water: 25 % ACN at time zero, to 25 % water: 75 % ACN at the end of the run. Such a variation of mobile phase solvent strength or polarity during a run is termed gradient elution. There is a "gradient" or variation in mobile phase composition and elution strength with time. A mixture of components of widely varying polarity can thus be separated and eluted more rapidly. In a RP separation, less-polar analytes will elute later during this gradient, but the run will be completed more rapidly than would be possible with isocratic operation. Gradient elution is the HPLC analog of programmed temperature GC, and it confers all the same advantages. It is especially valuable if there are "slow eluters" which must be removed before the next sample injection. If these are very slow eluters, which need not be measured, it may be better to reverse the flow through the column and backflush these off the front of the column and out a drain port located between the column and the injector, using backflush valves on each end of the column (not illustrated here). It takes considerable time to re-equilibrate the stationary phase with the starting mobile phase composition after a gradient run. Unless there is a wide polarity range of components to be eluted, isocratic elution is to be preferred. It is simpler to implement, and if R, values of separated components do not become too long, it will permit shorter analysis cycle times.
- 4. *HPLC pump*: a common type of HPLC pump is the reciprocating piston type illustrated in Figure 12.9. During *fill stroke* [Figure 12.9(a)], it is pulling mobile phase liquid from the solvent side, then on *exhaust stroke* [Figure 12.9(b)], it is pushed through the injector and to the head of the column. This is where the high pressure




FIGURE 12.9 Operation of piston and check valve reciprocating pump: **(a)** fill stroke and **(b)** exhaust stroke. (Katz et al., Used with permission.)

that permits the high performance in HPLC is generated. The figure illustrates a *single piston* design. The flow from the pump will rise during the exhaust stroke, and subside during the fill stroke. The *pulse dampener* shown downstream attempts to smooth the flow surges to approximate a steady constant flow. The stationary phase particle bed would become unsettled by repeated pressure surges. When using mass-flow rate detectors, variation in flow would be reflected in variation of their response. Both are undesirable consequences of pulsed flow. An improved pump design effects more uniform pressure and flow using *dual pistons* in an arrangement whereby one is in the exhaust stroke while the other is in the fill stroke.

- 5. Fill/drain valve: there are many liquid transfer lines and components that the mobile phase passes through before it gets to the head of the column. The analyst needs to fill all this with each new mobile phase, and after use one stores the system and column in a simple solvent or water rather than a complex mobile phase containing buffers, dissolved salts, and so on. A **priming syringe** pulls mobile phase through the lines of an empty system to remove air and "prime the pump". It can also be used to push mobile phase or storage solvent further downstream to clear out those lines. The **drain valve** can be opened so the pumps can quickly rinse storage solvent through the front half of the lines without having to work against the resistance of the column. Note that the solid black lines connecting the components of the system on the high-pressure side of the pump are narrow bore (e.g., 0.5 mm i.d.) stainless steel tubing. In automated systems, the cleanout cycle can be programmed to inject the storage solvent from an autosampler vial after completion of the analysis.
- 6. Rotary sample loop injector: figure 12.10 illustrates the most common design of HPLC injector. To introduce the sample with a syringe through a septum into the highly pressurized mobile phase liquid flow is impractical. The top portion of the figure is a schematic end-on view of the valve, which rotates on an axis coming out of the page. There are three inlet and three outlet fittings. The valve is shown in the "load" position. Sample from a syringe is pushed into a **sample loop** of tubing of








FIGURE 12.10 (a) Diagram of operation and (b) photo of two-position rotary injection valve. (a and b: Katz et al., used with permission.) (c) Actual manual injection through a rotary injection valve. (d) Typical HPLC microsyringe. (c and d: Courtesy of Hamilton Company, Reno, NV. www. hamiltoncompany.com.)

specified volume (e.g., 50 or $100\,\mu\text{L}$), with any excess flowing to waste. Mobile phase is flowing through one solid-line arc of the valve as shown. To *inject*, the valve is rotated 60° clockwise. Now the solid-line flow paths within the valve diagram are at the location of the dotted lines. The pump is now pushing the mobile phase and sample liquid in the loop in a direction *opposite* to that in which it was loaded, and it exits the valve to the column. All this occurs without leakage or introduction of bubbles at the high pressure maintained by the pump.

7. *The column*: HPLC columns were described in Section 12.1.1. When a fused silica capillary GC column accumulates unmoving contaminants at its front end, it is a simple matter to cut off some of it and reinstall it. This is not possible with HPLC columns. Even with the most careful filtration, the fine pores may become clogged with traces of particulate matter over time. The solution is to attach a very short, inexpensive **guard column**, often packed with **pellicular** particles

(i.e., without complete internal porosity, thus the bonded stationary phase layer is of much reduced area) in front of the **analytical column**. When the guard column becomes contaminated, it is detached, discarded, and replaced with a new guard column. If the stationary phase support will tolerate it, **operation of the column at elevated temperature** can confer advantages of both speed and improved resolution. Contrary to gases, the viscosity and resistance to flow of liquids decrease with increasing temperature. Diffusion and equilibration rates in the column are improved with increasing temperature as in GC. Unlike capillary GC, overall column temperature equilibration with an oven is not as fast in HPLC columns. To avoid radial temperature gradients across the diameter of the column which will degrade resolution, it is critical to ensure that the mobile phase is preheated to the desired elution temperature before it enters a thermostatted HPLC column. Even without operation at elevated temperature, thermostatting an HPLC column helps make elution times more reproducible.

8. HPLC detectors: HPLC has a wide variety of detectors: universal or specific, destructive or nondestructive, mass flow or concentration responsive, and with even more challenging requirements for interfacing to spectrometers in hyphenated techniques. Tubing of even smaller bore than described earlier in item 5 is necessary to connect the effluent end of the column to the detector to avoid extra-column band broadening effects. Pressures are lower, and high strength and density polyether ether ketone (PEEK) plastic may be used in place of stainless steel.

12.1.4 HPLC DETECTOR DESIGN AND OPERATION

Many of the principal features of HPLC detector operation are those described for GC detectors. The student is encouraged to reread Section 11.7. Only item number 4 in Section 11.7 is peculiar to GC. An analogous feature in HPLC would be *post-column derivatization*, which will be treated in Section 12.1.5. Hyphenated HPLC techniques are discussed separately in Section 12.1.6.

A common feature of many HPLC detectors is a small-volume **flow cell** through which the column effluent passes and in which the detector measurement is made. When acquired from within a flow cell, even detector response data files which contain full spectral information are sometimes not classified as hyphenated HPLC techniques. Those usually require the presence of a special interface device. Typical HPLC flow rates are on the order of 1 mL/min (1000 μ L/min). The analyte concentration in the effluent might be sampled on the order of once every second or two. It is necessary that the volume of effluent pass through the flow cell on this time scale. Thus, flow cell measurement volumes must be on the order of 5-50 μ L. Many HPLC detectors rely on emission or absorption of light, so their flow cells must have transparent entrance and exit windows. The requirement for small volumes limits the length of light paths (the "b" term in Beer's Law). This is one of the factors that affect the magnitude of optical spectroscopic signals that can be obtained from a given analyte concentration.

A comparison of the six major HPLC detectors is shown in Table 12.2.

TABLE 12.2 Comparison of Major HPLC Detectors

Detector Type	RI	ELSD	UV/VIS	Fluorescence	ECD	Conductivity
Typical LOD (ng/injection)	100	1	1	0.01-0.1	0.01	1
Selectivity	No	No	Moderate	Very High	High	Low
Robustness	High	High	Excellent	High	Poor	High
Gradient elution	No	Yes	Yes	Yes	No	Yes ^a
Microsystem usable	No	No	Limited	High	High	High

^a When used with suitable effluent suppression system.

12.1.4.1 REFRACTIVE INDEX DETECTOR

The RI detector is universal, nondestructive, a concentration detector, relatively insensitive, requires thermostatting, and is useable only with isocratic HPLC separations.

Every transparent substance will slow the speed of light passing through it, by an amount roughly proportional to its density (not mass density). As light is a wave phenomenon, this results in a bending of the light path as it passes at an angle to the interface from a less dense material to a more dense material, or vice versa. The quantity that defines this effective density is called the **refractive index** (RI). The presence of analyte molecules in the mobile phase liquid will generally change its RI by an amount almost linearly proportional to its concentration. At low concentrations, the change is small and could easily be masked by density and RI changes arising from temperature differences or slight changes in mobile phase solvent proportions, hence the need for careful thermostatting of an RI detector cell and the restriction to isocratic operation. Figure 12.11 diagrams one common differential type of RI detector. Mobile phase mixture and analyte containing eluent each pass through one of two transparent compartments separated by a tilted transparent plate. When the RI of the fluids in each compartment differs, the optics shift the *location* of source radiation beam's focus on a photocell sensor. The photocell's response surface is arranged so that this shift in position, rather than a change in beam intensity (as in absorption spectrometry) results in a signal linearly proportional to the RI change produced by the analyte concentration in the cell.

The RI detector is relatively insensitive but almost universal in its response, failing only in the unusual cases where the RI value of analyte and mobile phase are identical. It is more readily and stably operated without programmed variation of mobile phase concentrations. Response factors for most organic molecules vary over less than an order of magnitude. RI detection is used for analytes which give no response with other more sensitive or selective detectors. An example of analytes requiring HPLC with RI detection are mixtures of complex carbohydrates like sugars, which have no chromophores, fluorescence, electrochemical activity, and so on and which would be difficult, even after derivatization, to get through a GC column without decomposition. RI is not very sensitive to variation in mobile phase flow rate.

12.1.4.2 AEROSOL DETECTORS: EVAPORATIVE LIGHT SCATTERING DETECTOR AND CORONA CHARGED AEROSOL DETECTOR

The ELSD is universal, destructive, a mass-flow detector, sensitive, requires auxiliary gas, is useable with isocratic or gradient mobile phases but with *no buffer salts*, insensitive to flow variations, more expensive than an RI detector, and *not* usable with mobile phase buffers.




FIGURE 12.11 Schematic diagram of differential refractive index detector. (Katz et al., Used with permission.)

The ELSD is the other universal HPLC detector. Instead of absorption, stimulated emission, or refraction, it uses yet another interaction of analytes with light, that of **scattering**. Scattering occurs when light interacts with small particles of dimension comparable to its wavelength and is scattered, without change in wavelength, in a direction to the side of its original path. The particles are of a phase different from the one in which they and the light are embedded (e.g., liquid droplets or solid particles in a vapor or solid particles in a liquid). How could we employ this principle to measure concentrations of molecules, which are much smaller than visible light wavelengths, when they are dissolved in liquid mobile phases? These do not scatter light. The trick is to *nebulize* the mobile phase effluent into droplets and instantly evaporate each of these droplets, leaving behind a residue as a tiny solid particle of the nonvolatile analyte. The mechanism of particle formation from the droplets and the relation of scattering response to particle size is complex, but empirical calibration curves can be obtained. The response is roughly proportional to the mass of analyte eluting. As long as no buffer salts are present, so that all the mobile phase can be volatilized, the ELSD is insensitive to composition variations during gradient elution. It can be orders of magnitude more sensitive than RI detection. Modern instruments illuminate the particle cloud exiting a heated droplet evaporation tube with an intense monochromatic beam from a solid-state laser. Scattered light passes through a filter tuned to pass the same wavelength to a sensitive photocell which provides the detector signal.

Figure 12.12 illustrates the three steps in the operation of an ELSD: nebulization, evaporation, and light scattering. As we have seen for ICP-OES (Section 7.1.3) and will see later for LC-MS (Section 12.1.6.1), careful design of nebulizers or spray chambers and thermally-assisted droplet evaporation is key to many instrumental interfaces designed for introducing




FIGURE 12.12 The ELSD detects any compound less volatile than the mobile phase to low nanogram levels using a simple three-step process: **(a)** nebulization: the column effluent passes through a needle and mixes with N₂ gas to form a dispersion of droplets. **(b)** Evaporation: droplets pass through a heated drift tube where the mobile phase evaporates, leaving a fine mist of dried sample particles in solvent vapor. **(c)** Detection: sample particles pass through a cell and scatter light from a laser beam. The scattered light is detected, generating a signal. (D) Alltech* 3300 ELSD. **((a)** through **(d)** adapted with permission from Büchi Labortechnik AG, www.buchi.com.)




FIGURE 12.13 Illustrations of four advantages of ELSD versus other HPLC detectors. (Alltech* 3300 ELSD, adapted with permission from Büchi Labortechnik AG, www.buchi.com.)

Flowrate:

3.5 mL/min

analytes as liquid solutions. Figure 12.13 illustrates some advantages of the ELSD as a universal HPLC detector by comparing its response to the same effluent measured with other detectors.

The ELSD has a more uniform response to analytes than a UV absorption detector, whose response factors for different compounds vary widely and are wavelength dependent, and which gives no response at all to many compounds as shown in Figure 12.13(2).

Only one of five analytes eluting here [Figure 12.13(2)] is seen by the UV detector, and it misses the huge peak for PEG, gelatin, whereas all five are seen by the ELSD. The similarity of the mass proportionality responses enables one to immediately identify the major component.

ELSD has much better S/N response to three sugars, and better baseline stability than the RI detector. Note that the ELSD shows no solvent front peak, since the solvent droplets evaporate completely leaving no particle behind to scatter light [Figure 12.13(3)].

Figure 12.13(4) shows three derivatized amino acids or amino acid metabolites analyzed by both LC-MS and LC-ELSD. The mass spectra in the LC-MS contain much structural information, but MS ionization efficiencies and fragmentation yields vary widely, so TICs convey the relative concentrations less accurately than do the ELSD peaks.

A newer universal aerosol detector, the **corona charged aerosol detector** (CAD) operates similarly to the ELSD, but instead of measuring light scattered by particles from a laser beam, it adds charge to N_2 -dried vapor-borne particles formed by aerosol evaporation. As HPLC peak concentration increases, so do the sizes of the analyte particles. A second N_2 stream is positively charged by passing a high voltage through a corona discharge wire, and the charge is diffusively transferred to the analyte stream particles coming from the opposite direction. The amount of charge acquired is directly proportional to the particle size (and the analyte concentration). The charge is transferred to a collector where it is measured by an extremely sensitive electrometer (a voltmeter which operates while drawing almost no current [moving charge]). This signal is proportional to the analyte amount, and its sensitivity (picograms) and wide dynamic range of 4 orders of magnitude are claimed to surpass the performance of ELSDs.

12.1.4.3 UV/VIS AND IR ABSORPTION DETECTORS

A UV/VIS detector is compound-specific, nondestructive, and a concentration detector; compound sensitivities differ over a wide range; it is useable with isocratic or gradient mobile phases including buffer salts and pre- or post-column derivatization can be used to increase the number of measurable compounds.

The principles and operation of UV/VIS spectroscopic detectors are discussed at length in Chapter 3. The *detector* in HPLC refers to the whole spectroscopic assembly, whose design is optimized to make rapid, continuous measurements of solutions passing through a flow cell of volume much smaller than the typical sample cell or cuvette of a conventional spectrometer. The light source, optical train, dispersion device, and light detectors are similar in design to those discussed in Chapter 3, but they are often built on a much smaller compressed scale, to match the size of the other HPLC components. The major differences from the large spectrometers are the much smaller measurement volume of the flow cell, the necessity to route continuous flow through it, and the need to focus light on smaller areas on the flow cell windows and extract it efficiently to send it on to the light "detector".

Figure 12.14 displays a simple UV/VIS flow cell. These are typically glass with UV transparent quartz windows bonded at each end enclosing volumes of 1-10 μ L. Note that in this design the incoming flow is directed against one window, to induce turbulent mixing which breaks up the parabolic laminar flow velocity profile across the diameter of small-bore tubes. The flow exits in a similar fashion. This "Z-design" flow cell geometry reduces laminar flow velocity variation within the cell that could contribute to band spreading.




FIGURE 12.14 Diagram of HPLC UV/VIS detector flow cell. (Scott, used with permission.)

Compounds with aromatic rings, C=C double bonds, or with functional groups containing double bonds to some heteroatoms, particularly when these structures are multiply conjugated, may display widely varying degrees of absorption in the UV or visible regions (cf. Chapter 3). These features occur in many polar organic compounds which are separated and quantitated by RP-HPLC. In one survey, well over 70 % of compounds assayed by HPLC using nonhyphenated techniques employed UV/VIS detection, and another 15 % were measured with the related UV fluorescence detector. Despite not being as universal as the previously described detectors, UV/VIS and fluorescence are the workhorse detectors of HPLC. Their position is like that of the FID in GC. They possess the best combination of applicability to analytes of interest, compatibility with the widest range of mobile phases, and high sensitivity. Unlike the RI and ELSD detectors, these light absorption and emission detectors have compound response factors that vary widely, so calibration with standards of each analyte is mandatory. The optimum wavelengths for measurement will also vary with analyte structure.

There are three main classes of UV/VIS absorbance detectors: **single wavelength filter photometers, dispersive monochromator detectors (DMDs)**, and **diode array detectors DADs)**. The first of these often uses a source lamp which emits light at wavelengths specific to the excited, vaporized element employed in its design. These lines are isolated by wavelength-selective filters. The latter two use source lamps which emit over a wide wavelength range: tungsten filament for the visible and near-UV, or deuterium and xenon lamps which cover a broad emission range into the nonvacuum UV (down to around 190 nm). Many designs employ dual beam geometry, with the reference beam and its photocell monitoring a flow cell containing only mobile phase. Sometimes, the reference beam simply passes through a filter. In the first case, ratioing of the two signals can compensate for absorbance variations in the mobile phase. In both designs, variations in source intensity are compensated for. If absorbance data from a **single beam** design instrument is stored in a computer during a run, subtraction of mobile phase absorbance may be achieved post run, but stable source intensities must be maintained as source variations cannot be compensated.

Single Wavelength Filter Photometer. This simplest of detector designs often employs a mercury vapor lamp source, with filters between the flow cell and the photocell isolating a single line emission wavelength. The most useful such line is the intense one at 254 nm, a wavelength at which many UV-active compounds absorb strongly. Less generally useful, but sometimes more selective lines at 250, 313, 334, or 365 nm may be isolated and monitored by use of the appropriate filters. Interference filters may be used with deuterium sources to isolate specific wavelengths and measure absorbance at them.

Dispersive Monochromator Detector (DMD). Instead of a selected wavelength filter, a grating monochromator (Chapter 2) may be used to select a narrow wavelength band for absorption measurement. The wavelength is generally isolated *before* the beam passes through the detector flow cell. Such detectors are particularly useful when the analytes to be measured are known in advance (**target compound analysis**). The monochromator may be set to monitor the signal at the compound's wavelength of maximum absorption, and if operating under computer control, this wavelength can be varied to the optimal value for each chromatographic peak as it elutes. Conversely, if trying to use UV/VIS spectra to help identify unknown compounds, the eluent flow can be stopped while the top of the LC peak is in the flow cell, and the monochromator can be scanned across all accessible wavelengths to produce a spectrum.

Diode Array Detector (DAD). This semiconductor detector substitutes a linear array of light sensitive solid-state diodes for the photocell (Chapter 3). Light from the source passes through the flow cell and is then dispersed into its component wavelengths, which are directed to the different diodes of the array. The array itself is illustrated in Figure 3.24. Each diode responds to light from a narrow wavelength range of the dispersed light, so all wavelengths are monitored simultaneously. A computer is required to read out all these parallel signals and store them in files arrayed as a function of elution time. A diagram of a diode array UV/VIS spectrometer is presented




FIGURE 12.15 Schematic of diode array detector for HPLC. (Cazes, used with permission.)

in Figure 3.25. Figure 12.15 diagrams the components of a typical DAD designed for use in HPLC. Note that the wavelength dispersion take place after the beam from the source passes through the flow cell. By contrast, the DMD isolates a single wavelength before passage through the flow cell. In either design, there is a possibility that in some cases, the UV passing through the flow cell might excite fluorescent emission at longer wavelengths. In the DAD, this would distort the observed absorption spectrum at those longer wavelengths, and in either the DAD or DMD, it might add back to the absorption signal being recorded at detector and cause the absorption value to appear less. As the DAD illuminates the cell at all wavelengths, the probability of it falling victim to distortions arising by this mechanism is greater. The DAD data set can easily provide UV/VIS spectra of everything eluting during the chromatogram. If HPLC peaks are composed of a single UV-active component, the ratios of DAD responses at several different wavelengths will remain constant across the peak. If there is an impurity with a somewhat different UV spectrum within the HPLC peak, and it elutes with its peak at a slightly different retention time from that of the major component, then these wavelength response ratios will vary across the peak. This is a powerful method for detecting the presence of small impurities "buried" under the major component HPLC peak.

Infrared Absorbance Detector. A continuous rapid response HPLC-IR detector benefits from FTIR spectral acquisition and computerized data file storage. Spectra obtained have spectral peak widths more characteristic of a liquid matrix, instead of the more information rich, sharp gas phase GC-IR peaks. The major drawback to IR detection in HPLC is that most of the commonly useful HPLC mobile phases absorb strongly in many areas of the IR spectral region. HPLC-IR can be used for only a very limited set of analytes.

12.1.4.4 FLUORESCENCE DETECTOR

A fluorescence detector is compound-specific, nondestructive, and a concentration detector; compound sensitivities differ over a wide range; detection at right angles to and at a wavelength different from the excitation beam results in low background noise and higher S/N sensitivity than UV/VIS; it is useable with isocratic or gradient mobile phases including buffer salts; and pre- or post-column derivatization can be used to increase the number of measurable compounds.

The general principles of fluorescence spectrometry and the design of fluorescence spectrometers are discussed in Chapter 3. The simplest detectors for HPLC excite molecules with intense UV emission lines from a mercury lamp or wavelengths isolated by filters from a

xenon lamp. The fluorescent emission at longer wavelength is sampled at right angles to the excitation beam, and the desired wavelength is isolated by use of a suitable filter. A more versatile design employs one tunable monochromator to select the optimum excitation wavelength from a broad band source such as a deuterium or xenon lamp, and another to select the fluorescent emission wavelength passed to the photocell or diode detector. This permits operation at optimal sensitivity for a wider range of analytes. More recent designs employ an intense monochromatic laser beam to increase the energy used for excitation. While this provides for more intense excitation, limitations of available laser wavelengths sometimes preclude excitation of analytes at their absorption maxima unless expensive tunable lasers are used. A disadvantage of the detector is that only a limited subset of analytes display substantial fluorescence emission. Its greatest advantage by comparison with the UV/VIS absorption detector is its several orders of magnitude greater sensitivity for those compounds which do display such emission. This results from the very low noise background in the measured signal. This is a consequence of measuring at right angles to the incident beam against a dark background at a wavelength longer than and isolated from that of light which might be scattered from the excitation beam. Improved sensitivity results from an improved S/N ratio.

The extreme sensitivity of fluorescence detection encourages the use of derivatization reagents to react with a nonfluorescent analyte's functional group(s) to introduce or form a fluorescent structure in the derivative. This must be done prior to injection of the sample and HPLC separation, if the derivatization reaction is slow. More often, one attempts to quickly form derivatives of separated peaks as they elute from the column prior to passing into the detector. This procedure is called **post-column derivatization**, and it will be discussed in greater detail in Section 12.1.5. One common fluorescence derivatizing reagent is dansylchloride (**dansyl** is short for 5-dimethylaminonaphthalene-l-sulfonyl-). Dansyl derivatives of primary and secondary amines, amino acids, or phenolic compounds form readily and are highly fluorescent. A more comprehensive discussion and listing of derivatizing reagents can be found in the book by Bruno and Svoronos.

12.1.4.5 ELECTROCHEMICAL DETECTORS

Electrochemical detectors (ECDs) for the determination of trace amounts of ionic and molecular components in liquid chromatographic effluents are sensitive, selective, and inexpensive (Figure 12.16). They are compound-specific, destructive, are concentration or mass-flow detectors depending on operation; compound sensitivities differ over a wide range; are useable primarily with isocratic RP-HPLC including some buffer salts, and pre- or post-column derivatization can be used to increase the number of measurable compounds. Be careful not to confuse the abbreviation with the gas chromatography ECD, where EC denotes electron capture, not electrochemical.




FIGURE 12.16 A schematic of an HPLC system with electrochemical detection.

The fundamentals of electrochemistry are covered in Chapter 13, which should be reviewed if needed. There are two major categories of ECDs: **voltammetric** (subdivided into amperometric, polarographic, and coulometric), and **conductometric**. An efficient redox center in the ion or molecule to be detected is necessary for voltammetric methods, but this is not mandatory in the species actually undergoing separation, because many organic compounds can be derivatized with an electroactive constituent before or after column separation. Alternatively, certain classes of organic compounds can be photolytically decomposed by a post-column online UV lamp into electroactive products, which can be detected. For example, organic nitrocompounds can be photolyzed to nitrite and nitrate anions, which undergo electrolysis at suitable working electrode potentials. In the case of conductivity detectors, the method does not require species that are redox active; rather, changes in the resistivity of the electrolyte effluent are monitored. Examples of species that may be detected are simple ions such as halides, SO_4^{2-} , PO_4^{3-} , nitrate, metal cations, NH_4^+ , as well as organic ionic moieties.

Liquid chromatographic electrochemical detection has been widely used for metabolite studies in complex matrices and has general applicability in many fields, for example, the pharmaceutical industry, forensic science, medicine, the explosives industry, and agriculture.

Voltammetric Detectors. The usual design of electrochemical detectors employs a three-electrode configuration consisting of:

- 1. **The working electrode**, where electrons are transferred in a redox reaction;
- 2. An auxiliary electrode, to which the current flows from the working electrode; and
- 3. **A reference electrode**, which serves as a reference against which to control and maintain the potential of the working electrode relative to the auxiliary electrode.

Many different arrangements of these three electrodes are employed in the design of ECD cells. Five are depicted schematically in Figure 12.17.




FIGURE 12.17 Five HPLC electrochemical detector three-electrode arrangements. (Scott, used with permission.)

One must employ RP-HPLC aqueous or polar mobile phases capable of carrying dissolved electrolytes (i.e., the analytes measured by conductometric detectors or the supporting electrolytes to suppress migration current. Thus, ECDs are not suitable for normal phase HPLC separations. As distinguished from conductometric detectors, ECDs respond to substances which are oxidizable or reducible at a solid electrode surface. Their signal is the current which flows through the electrode circuit when these processes occur. If flow of analyte through the detector cell and the potentials applied to the electrodes are appropriately controlled, then the rate at which the analyte is provided to the **working electrode** surface to be consumed there to liberate electrons to the electrical circuit is proportional to its amount in the cell.

Various waveforms and signal presentation techniques are available, such as steady-state voltammetry with amperometric or coulometric (integrated current) outputs and sweep procedures such as differential pulse. In the simplest mode, a sufficient steady-state potential (constant E) is applied to a working electrode to reduce or oxidize the component(s) of interest. The output signal is a transient current peak collected and processed by a computer data system. To obtain reasonable chromatographic resolution, the electrochemical cell, positioned at the outlet of the column, must be carefully designed. The volume of the detector cell must be small to permit maximum band resolution. As the reduction or oxidation is performed under hydrodynamic flow conditions, the kinetic response of the electrode/ redox species should be as rapid as possible. Glassy (vitreous) carbon is a popular electrode material, and it is possible to chemically alter the electrode surface to improve the response performance. However, other substrates are available, such as Pt, Hg, and Au; these prove useful in cases where they are not passivated by the adsorption of organic reaction products. Platinum and gold electrodes are particularly prone to blockage from the oxidation products of amino acids, carbohydrates, and polyalcohols, for example. Typically, a three-electrode thin-layer cell is used, with the reference and auxiliary electrodes downstream from the working electrode. Dissolved oxygen may interfere in some assays and may therefore have to be removed by prior degassing.

If all the analyte is consumed, integration of the current determines the total charge transferred, and such a voltammetric detector is classified as coulometric (from the Coulomb unit of measurement of charge). Such complete electrolysis of the analyte in the short period of peak passage through the detector cell is difficult to achieve on a standard working electrode surface. A porous carbon electrode can be constructed as a frit in the detector cell through which all the effluent must pass. The pressure drop through such an electrode is small, and its huge internal surface area enables complete consumption of all analytes reacting at its potential, thus enabling coulometric rather than amperometric detection. A sequence of these electrodes (each with its accompanying auxiliary and reference electrodes) can be arrayed in series along the flow path to operate at intervals of increasing potential. Such a multielectrode array detector will sequentially and separately produce a signal only from analytes which react in the narrow potential interval around which each electrode is set. Analytes which would react at lower potentials have already been completely consumed by prior electrodes, and those requiring higher potentials will be measured by subsequent ones. The data acquisition and multianalyte capabilities of such an array are analogous to the DAD for UV/VIS spectral responses. An advantage of coulometric detection is that if the reaction is known, that is, the number of electrons consumed or released per mole of analyte is known, the integrated signal quantifies the analyte without need of a calibration standard.

The most common ECD for HPLC is the **amperometric detector**. Here, the analyte is completely depleted at the working electrode surface, but not in the bulk solution passing through the flow cell. An equilibrium diffusion current that is proportional to both the hydrodynamic flow parameters past the working electrode and the concentration of the oxidizable or reducible analyte is established. If steady-state effluent flow and diffusion conditions are maintained, then the amperometric current is proportional just to the analyte concentration in the cell. These conditions are more difficult to maintain during a gradient elution, so ECD detection works best with isocratic separations. There is a wide variety of modes of operation of amperometric ECDs. The working electrode may be an anode (where the analyte is oxidized). A useful material for oxidative analyses is vitreous, conductive, "glassy" carbon. Reductions can also be carried out on this electrode, and various metals

such as Pt, Au, and Hg are used as cathodes for reductions. These sometimes are vulnerable to buildup of contamination by adsorbing material. A mercury electrode can be extruded from a capillary as a hanging drop, which can be easily replaced with a fresh, clean surface. As described in Chapter 13, the high overvoltage for H⁺ reduction on Hg permits a considerable range of electrode potentials over which reductions may be induced without solvent reduction. This is the principle of polarographic analysis, and a detector with such a voltammetric working electrode is classified as a **polarographic detector**. When using such detectors, extensive de-gassing of the mobile phase becomes critical for the additional purpose of removing potentially interfering reduction of dissolved oxygen. A detector configured as a pair of amperometric electrode assemblies can be operated in series, with the first set to oxidize an analyte to a form suitable for subsequent reduction by the next detector in line, or vice versa. Optimization of the potentials for operation of each working electrode in such a chain can confer additional target analyte selectivity, which may also result in improved sensitivity by lowering background noise.

A recent refinement of such detectors is a combination of high-performance anion exchange (HPAE) separation in a capillary IE (Section 12.2) column using a capillary ED cell employing a chemically inert gold working electrode versus a Pd/H₂ reference electrode operated for **pulsed amperometric detection (PAD)**. In PAD, the electrical potential is cycled up to three times a second to clean and restore the detection electrode surface after the measurement and before the next detection by oxidative desorption for amino acids. Monoand disaccharides and higher sugars undergo adsorption followed by oxidative desorption. A prime application is determination of mono- and disaccharides (organic carbohydrate sugars) at very high pHs at which they acid dissociate (pH 11-13) by using very high stationary and mobile phase pHs. One key to this is the use of Carbopak™ columns capable of operating at extreme alkaline pH. Most other detectors give no response to this class of compounds. **HPAE-PAD** has been used to analyze hydrolysates of the polysaccharide Heparin, to determine its glucosamine content and the level of impurity, chondroitin sulfate, which releases galactosamine instead. The exceptional sensitivity of the PAD enables measurement of the latter sugar from very small samples, as less than 1 % of the total amount of analyte passing through the detection cell is consumed by the electrode reaction. Figure 12.18 shows the HPAE-PAD system.




FIGURE 12.18 Schematic diagram of HPAE-PAD system. (© Thermo Fisher Scientific (www. thermofisher.com). Used with permission.)




FIGURE 12.19 Three conductometric detector designs. (Scott, used with permission.)

Conductometric Detectors. Conductometric detectors are universal for all anions or cations in solution (i.e., a "bulk property of mobile phase" detector); nondestructive or destructive; a concentration detector; compound sensitivities differ over an order of magnitude range, are useable primarily with isocratic RP-HPLC without buffer salts (unless subsequent suppression column is used); and is the premier detector for ion chromatography (Section 12.2).

The conductometric detector is small, simple, and easy to construct. It consists of two electrically isolated electrodes immersed in or surrounding the mobile phase effluent flow, as illustrated in Figure 12.19. All ions in the mobile phase will participate in carrying current across the cell when an *alternating potential* (AC signal) of frequency 1000-5000 Hz is imposed between the electrodes. If a constant DC potential were imposed, the ions would migrate to the electrodes opposite to their charge, concentration polarization would occur, and current through the cell would decrease to zero. With an imposed AC voltage, this polarization is suppressed, and AC current passes through the cell. The conductance is proportional to the concentration of ions, and small changes in its inverse quantity (resistance, or with AC current, more properly impedance) may be measured directly or against a reference cell in a Wheatstone bridge arrangement.

The primary usefulness of the conductometric detector is for small anions or cations such as inorganic ions (e.g., Cl^- , ClO_4^- , NO_3^- , PO_4^{-3} , $Na^+NH_4^+$, etc.) or small organic anions (e.g., acetate, oxalate, citrate, etc.) or cations (e.g., di-, tri-, and tetra-alkyl ammonium ions). These often possess no useful chromophore or suitable redox activity at ECDs. The difficulty with these conductometric detectors is that they are bulk property detectors responding to all the ions present in the mobile phase. They cannot be made compound selective. Background ions from mobile phase buffers or the ionic eluents used in ion-exchange chromatography (Section 12.2.1) would swamp the conductance from low levels of ionic analytes. The conductometric detector first became generally useful when the ion suppressor column was developed to remove this background, giving rise to the method termed ion chromatography (Section 12.2.2).

The **Charge Detector** (QD, a Thermo Scientific trademark) is universal for anions and cations in solution; destructive; a concentration sensitive detector; with higher, more linear response for weakly dissociated species. Its response is proportional to both concentration and charge of analytes.




FIGURE 12.20 Charge detector (QD) operation diagram. (© Thermo Fisher Scientific (www. thermofisher.com). Used with permission.)

The charge detector mode of operation is illustrated in Figure 12.20. Analyte ions, cations (A⁺) or anions (Y⁻), in the suppressed column effluent flow through a central channel defined by cation exchange (CX) and anion exchange (AX) membranes and are drawn by the applied voltage towards the electrodes of the opposite polarity. A current derived at the electrodes by the transport of the ions to the electrodes is the detector signal. The transported ions combine with electrolysis-generated OH⁻ or H₃O⁺ ions at the electrodes to form a base (AOH) or acid (HY), respectively. The countercurrent flow of an aqueous stream in the electrode channels provides the water required for the electrolysis reaction which occurs at >1.5 V and aids in removing the base or acid products. The analyte ions are converted to these products and removed to waste. Thus, the QD is a destructive detector and must be placed at the end of a chain of multiple detectors. Advantages include stronger relative response for very weakly dissociated species such as boric acid, greater linearity than suppressed conductivity detection alone for such compounds, and the ability to combine its superior performance relative to the latter non-destructive detector by operating it in tandem behind the conductivity detector, which possesses greater sensitivity for strongly dissociated ions. Thermo Scientific now offers this small, low footprint QD for capillary IC systems. For some applications the tandem detector combo may provide additional information such as peak confirmation, and predict coeluting peaks and trigger the need to use serve MS detection to identify the co-eluting components in a sample.

12.1.5 DERIVATIZATION IN HPLC

The primary purpose for derivatization in HPLC is that of introducing substituents to increase sensitivity and selectivity of detection. One case where improvement of HPLC chromatography is a major goal is for analytes that exist as charged ions in solution: anions, cations, or zwitterions (containing both positively and negatively charged atoms). The very important group of amino acids falls into this category. Originally, complete separation of complex mixtures of these required very lengthy runs on ion-exchange resin columns. Reaction of physiological amino acids with orthophthaladehyde produces isoindole derivatives whose polarity is compatible with much more efficient RP-C18 columns, leading to much more rapid separations. Additionally, these derivatives display intense fluorescence at 425 nm, which greatly improves the detection limits when monitoring with a fluorescence detector.

The second benefit in the earlier example illustrates the primary application of derivatization in HPLC. Inspection of Table 12.2 suggests that if we want to derivatize for improved selectivity and sensitivity, introduction of fluorescence should be our first choice. Table 12.3 lists a number of fluorescence derivatization agents and their target functionalities (a more comprehensive listing can be found in the book by Bruno and Svoronos). Generally, we wish to derivatize only one group at a time.

TABLE 12.3 Reagents for Precolumn Fluorescence Labeling				
Reagent	Analytes	λ_{ex} (nm)	$\lambda_{\sf em}({\sf nm})$	
o-Phthalic anhydride (OPA)	Primary amines, thiols	340	455	
Fluorescamine	Primary amines	390	475	
Dansyl chloride (Dns-Cl)	Primary and secondary amines	350	530	
9-Fluorenylmethyl chloroformate (FMOC)	Primary and secondary amines	260	305	
Naphthyl Isocyanate	Hydroxy compounds	310	350	
Dansylhydrazine (Dns-H)	Aldehydes and ketones	365	505	
Anthryldiazomethane (ADAM)	Carboxylic acids	365	412	
N-Acridinyl maleimide	Thiols	355	465	
Source: Katz et al.				

The derivatization can be carried out in solution as a last step in sample preparation. This allows for whatever temperature and reaction time may be necessary to form the derivative. This is the standard practice for forming GC derivatives, and is termed precolumn derivatization (or labeling). In GC, we can sometimes avail ourselves of the very high temperatures in a GC injection port during flash vaporization to perform **on-column** derivatization. While this is not possible in HPLC, we have an even better option, postcolumn derivatization. Here, the labeling agent is added to the column effluent by constant rate infusion from a separate pump, passes through a mixing chamber or coil, possibly at elevated temperature, for a precisely regulated and reproducible interval, and then passes into the detector cell. A block diagram of such a system is displayed in Figure 12.21. When using this mode, the purpose is clearly only to convert the analyte to a better-detected form. The post-column reaction needs to be fast, as too long a mixing chamber could lead to extracolumn band broadening. However, the reproducibility of the mixing and its interval yields satisfactory quantitation even if the reaction does not proceed to completion. Additionally, should the derivative be unstable, it is being quickly measured at a highly reproducible interval after formation, which would not be the case when using precolumn derivatization. If the reagent is itself fluorescent in the range being monitored, the presence of the unreacted excess will interfere with the analyte measurement. If such a reagent is used in the precolumn mode and is separable from the derivatized analyte on the HPLC column, a fluorescent reagent may be usable. When properly implemented, post-column derivatization is more reproducible in its yield and quantitation than the pre-column mode. Additionally, if more than one fluorescent product may be formed in the reaction, they will all pass through the detector cell together, while the products of a pre-column procedure may elute separately in variable proportions from the HPLC column.

Derivatization can be employed to advantage with ECD detection as well. Both pre-column and/or post-column reactions may be employed to produce electroactive compounds analogous to the formation of fluorescent derivatives.




FIGURE 12.21 Block diagram of HPLC post-column derivatization system. (Katz et al., Used with permission.)

12.1.6 HYPHENATED TECHNIQUES IN HPLC

Adding a second dimension to an HPLC separation lagged behind the application of this idea to GC. True HPLC columns and instrumentation were just becoming available in the early to mid-1970s when the first commercial computerized GC-MS systems came on the market. It is easier to interface the less-dense vapor mobile phase of GC to the vacuum conditions required for MS operation. At the time of this writing, while comprehensive 2D-GC systems and their associated data handling software have become widely commercially available, 2D-LC or LC-GC systems are mostly confined to development in individual academic and research laboratories. Agilent has recently introduced a 2D-LC system which combines components from its LC product line with a novel 10 port valve having all equivalent liquid transport lengths and reverse flow for backwashing steps. When operated under computer control with Agilent software, it can provide automated heart-cutting or comprehensive 2D-LC and displays of separations similar to those in comprehensive 2D-GC, or even shift between these modes during the course of a run. There is no equivalent in LC of GC-GC's thermal modulator to refocus and transfer effluent peaks from one column to another continuously with few or no moving parts. The use of a DAD detector with HPLC does enable continuous acquisition of full UV/VIS spectra of peaks eluting from an HPLC column. This can be valuable in some applications; however, its utility does not begin to match that of GS-MS or GC-IR. The range of organic compounds which present useful UV/VIS spectra is much narrower than those which yield mass spectra or IR spectra (essentially all organic compounds). The UV/VIS spectra contain much less structure than mass or IR spectra, and are much less easy to interpret for identifying unknowns or to match unambiguously with library searching programs. LC full-scan-DAD instruments are therefore often not considered true hyphenated techniques. The IR absorption of most HPLC mobile phase solvents precludes use of IR detection as a full-scan second-dimension detector.

LC-NMR. One information-rich spectral technique that is more suited to the liquid mobile phase of HPLC than to the vapor phase of GC is NMR. LC-NMR has been implemented, but it has significant limitations. To obtain interpretable spectra of unknowns, concentrations in the measurement cell must be higher than with other detectors. The cell must be smaller than the usual NMR tube, so for any but the very highest concentrations of analytes, FT-NMR acquisition is preferred, with each eluted peak being retained in the measurement cell by a stopped-flow procedure similar to that employed to increase sensitivity in GC-IR (Section 12.8.2). Expensive deuterated mobile phase solvents are required for proton NMR, which mandates the use of low mobile phase volume flow columns: narrow bore or even capillary HPLC. LC-NMR is expensive to implement and only just becoming available from commercial vendors at this time.


LC-MS. Given the clear superiority of HPLC over GC for separations of large polar biomolecules, analysts yearned to interface its effluent to MS instrumentation. A huge market in the pharmaceutical and biomedical research field and in clinical biomonitoring beckoned. The difficulty was the approximately three orders of magnitude greater mass of less-volatile mobile phase which must be prevented from entering the MS vacuum system (while still letting the analytes in), since no imaginable MS pumping system could remove it fast enough. Consider that a vapor is ~1000× less dense than its parent liquid, and that typical mobile phase flow rates in capillary GC and packed column HPLC are both on the order of 1 mL/min. The jet separator design for GC-MS would only work with mobile phases of very light, fast-moving atoms or molecules like He or H₂. Chromatographers attempted to deposit HPLC effluent onto a moving conveyer belt which passed through vacuum interlocks into a pumped down chamber where the mobile phase would vaporize, leaving the analytes behind on the belt. The belt then passed through further interlocks to an even higher vacuum ion source chamber, where it was heated in hopes of volatilizing the analytes so they could be ionized and fragmented under EI-MS or CI-MS conditions as in classic GC-MS analyses. These contraptions were difficult to operate in a reproducible manner, and the prospect for volatilizing thermally-sensitive large biomolecules was not much better than trying to coax them to survive passage through the high-temperature gauntlet of a GC-MS system.

12.1.6.1 INTERFACING HPLC TO MASS SPECTROMETRY

Thermospray HPLC-MS Interface. The first really successful interface did in fact look something like the GC-MS jet separator, although its mechanism was different. The HPLC effluent from a microbore column or a fraction split from a regular diameter column was coupled to a capillary tube 10-20 cm long, nestled inside a tight fitting cylindrical electrically-heated tube. The exit end of the capillary pointed at a skimmer cone orifice leading to the first stage of a differentially pumped MS ion source. The arrangement was similar to the sample solution nebulizer feeding an ICP torch as described in Chapter 9 for ICP-MS instruments. If the temperature and heating rate from the heater were optimized to the mobile phase flow, it would begin to boil within the capillary close to the exit and emerge from its tip as a fine spray of droplets which would evaporate, leaving a portion of the analyte molecules to enter the ion source orifice, while the rest of the solvent vapor was pumped out of the spray chamber. Any nonvolatile salts or other material would deposit around the MS orifice entrance, requiring its frequent cleaning. Mobile phases with ions in solution often gave rise to strong analyte molecular ions, while weakly ionized solutions required an electron beam to produce EI-MS spectra. Sensitivity was not as high as could be due to the need to use lowcapacity HPLC columns or to split effluent flow, and because of inefficient transfer from the spray through the narrow MS entrance orifice. Nonetheless, it was an effective and useful general LC-MS interface.

Electrospray Interface (ESI) for HPLC-MS. The thermospray interface retained some disadvantages. Heating the transfer capillary to the boiling temperature of the mobile phase was not as great a shock to thermally labile compounds as attempted volatilization in GC or from the moving belt interface. Still, even lower temperatures would be preferable. Larger molecules might clump together and "precipitate out" as the spray droplets evaporated. Only a small proportion might travel on the right trajectory to enter the orifice, and only a portion of these might enter as separate molecules instead of the precipitated solid particulates. The key to an improved spray interface was in the observation that analytes already existing as ions in the mobile phase or capable of having charge transferred to them from other ions gave exceptionally strong MS signals.

Instead of heating the inlet capillary entering the spray chamber, in the ESI, its tip is electrically charged so that as droplets emerge from it, excess positive or negative charge is transferred to them. A dry heated stream of highly purified nitrogen gas is directed at the emerging spray of charged droplets to accelerate evaporation. Two things happen as the charged droplets rapidly shrink by evaporation. Analyte and/or solvent molecules bearing the charge with the polarity in excess migrate to the surface under mutual repulsion. As they are forced closer together, they induce a "coulomb explosion" whereby the droplets fragment into multiple smaller droplets with greater total surface area to support the excess charge. This process repeats in a cascade, almost instantly producing a spray of extremely small charged droplets. As the droplets' surface electric field continues to build, analyte ions begin to be individually expelled from the microdroplets as solvated clusters of one analyte ion embedded in a cluster of solvent molecules. This process is illustrated in Figure 12.22(a), and it is far more efficient in converting analyte molecules to ions than is the thermospray interface. The spray can be directed at right angles (orthogonal spray) to the ion entrance orifice and skimmer assemblies instead of directly at them. By appropriately charging the entrance orifice, the analyte ions can be electrically attracted to it and drawn in, while excess solvent droplets and particulate material pass by to waste. An example of such an ESI is illustrated in Figure 12.23. The region between the entrance orifice and capillary, and the illustrated **skimmer cone** seen in cross-section, contains high-purity nitrogen at low pressure. Collisions with this gas result in collision-induced dissociation (CID), which produces fragment ions from the original analyte molecular ions, in a process equivalent to the CID which takes place in the second stage of a tandem three-stage MS-MS instrument. These solvent molecules and any others pulled in through the capillary are swept away by the CID gas flow, while the analyte molecular and fragment ions are drawn on and focused through more electric field entrance lenses into the higher vacuum region of the quadrupole mass analyzer.






FIGURE 12.22 LC-ESI-MS interface ionization mechanism diagrams. **(a)** Coulomb explosion in ESI droplets and **(b)** reactions leading to molecular ion in APCI. (Adapted with permission from applied biosystems, San Francisco, CA and MDS SCIEX, Vaughan, Ontario, Canada.)

Originally, the electrospray interface was limited to use with very low flow rates of mobile phase from capillary or microbore HPLC columns or capillary electrophoretic separations. The acceleration of droplet evaporation by addition of heated gas flow enabled its use with higher flow rate separations. Some modern designs can even tolerate the 3-6 mL/min flow associated with high-speed separations on monolithic HPLC columns with large macropores. Electrospray can generate multiple charged ions from compounds which have multiple charge sites, such as peptides or oligonucleotides. This enables one to observe molecular ions or high mass fragments of high molecular weight species whose masses are greater than the nominal mass limit of the MS instrument. The multiple charges produce an ion whose mass-to-charge (m/z) ratio lies within the mass range of the instrument.

Note that all ionization is initiated at the entrance to the spray chamber, at the tip of the sprayer. There is no electron impact beam used to ionize and fragment analytes. Large molecules are treated gently through the whole process, and if they have natural charge centers at various pHs (as is especially the case with peptide chains comprising linked amino acids), they are ionized with great ease. This method of LC-MS interfacing, along with the one to be described next, was the long-sought solution for a practical, general, and easy-to-use interface. LC-MS instruments based on these two interfaces are used by the thousands in




FIGURE 12.23 Diagram of orthogonal electrospray LC-MS interface. (© 2020 Agilent Technologies [www.agilent.com/chem] All rights reserved. Used with permission.)

biomedical research laboratories, and they now outsell GC-MS instrumentation. It is difficult to predict for many analytes whether negative or positive ion LC-MS operation will produce the most sensitive signal, but it is easy to shift between modes, even within a single LC-MS run, and then to program an LC-ESI-MS instrument to shift to the optimal polarity for each analyte as it elutes.

Fluorescence detection of end nucleotides of capillary electrophoretic separations of DNA segments is key to the instruments that perform the DNA sequencing that supports the field of **genomics** (Section 12.1.7). The LC-ESI-MS instruments, with their superb ability to characterize analogous large peptide (polymer chains of amino acids) segments of protein macromolecules, are key to rapid characterization of the complex protein mixtures which reflect the various patterns of gene expression in biological systems. This is the foundation of the discipline of **proteomics**, whose full flowering will likely entail even more massive analytical determinations than the huge project of sequencing selected biota genomes (e.g., the 3 billion base sequence of the human genome). Achieving a full understanding of proteomics will likely occupy much of the 21st century. One of the inventors of the ESI-MS interface, Dr. John Fenn, shared the 2002 Nobel Prize in Chemistry for this contribution. He entitled his lectures on the subject: "Electrospray wings for molecular elephants". For massive "-omics" studies such as proteomics, genomics, metabolomics, lipidomics, and a host of others, chromatography-ESI-MS or -MS/MS systems have replaced many earlier ones using derivatization and fluorescence detection. Now, in their turn, they are beginning to be superseded by even faster, more powerful and cheaper, purpose-built systems designed around arrays of sensors on microchips. The day of the \$100 complete human genome is in sight, perhaps only two decades after the \$3,000,000,000 first human genome sequence publication at the turn of the past century.

Atmospheric Pressure Chemical Ionization (APCI) Interface. The other highly successful HPLC-MS interface design is illustrated in Figure 12.24. This is the atmospheric pressure chemical ionization (APCI) interface. Like the ESI interface, the sample is nebulized into a spray of fine droplets, aided by and entrained in a flow of nitrogen **sheath gas**, but without being charged by an applied potential at the spray tip. Heat conducted through the




FIGURE 12.24 Diagram of atmospheric pressure chemical ionization LC-MS interface. (Adapted with permission from applied biosystems, San Francisco, CA and MDS SCIEX, Vaughn, Ontario, Canada.)

sheath gas is supplied from a heated ceramic tube as the droplets are carried downstream. This gently accelerates droplet evaporation. The process occurs at atmospheric pressure. At the exit of the tube, ions are produced by the **corona discharge** of electrons emitted from the high-field gradient of a sharp metal needle charged to several thousand volts. The initial ions produced by the discharge are N_2^+ , O_2^+ , H_2O^+ , and NO^+ from air, and through a complex cascade of charge transfer they create **reagent ions** ([X + H]⁺ in positive mode or ([X – H]⁻ in negative mode, where X is a mobile phase solvent molecule). The reagent ions then produce stable sample ions upon collision with sample molecules. The final step in this mechanism is the same as that occurring in classical CI-MS and thus gives the name for APCI. Contrary to experience in GC-MS, LC-APCI-MS ion sources can be opened to the atmosphere for cleaning without venting and shutting down the rest of the MS instrument, since they operate under normal atmospheric conditions.

The reactions leading to the production of sample molecular ions are illustrated in Figure 12.22(b). Note the barrier to entry of solvent vapor into the vacuum pumped portions of the MS, which is produced by N₂ curtain gas flowing out between the curtain plate and orifice plates illustrated in Figures 12.22(b) and 12.24. The ions are drawn through this flow by the charges applied to these plates, while uncharged molecules are swept back and away. The various charge transfer reactions forming the sample ions occur as the ions are being drawn to the entrance orifices. This region between the corona discharge tip and the curtain plate orifice acts as an ideal "wall-less reactor". Remaining ions which do not make their way through the orifices eventually are neutralized by contact with a "wall" and play no further part in the process. While the ESI interface is especially suitable for large biomolecules with multiple charge sites, the APCI interface is more useful for smaller neutral molecules. Many analytes may be analyzed successfully using either interface. The one which produces the best sensitivity must be found by experiment. There are several modes (e.g., positive ion, negative ion, different mobile phase salts or components which affect ionization efficiency or CI ionization) which may be evaluated. Ionization voltage, orifice voltage, evaporation temperature, and flow parameters may be adjusted to maximize sensitivity. Fortunately, in LC-MS, one may easily continuously infuse into the MS interface a solution of a constant low-level concentration of analyte in a proposed LC mobile phase. The interface parameters may be quickly and automatically varied in sequence to find their optimal settings. Many modern general-purpose HPLC-MS instruments have interchangeable ESI or APCI spray and ionization assemblies which enable rapid conversion from one mode of operation to the other without requiring venting of the MS vacuum system.

12.1.7 APPLICATIONS OF HPLC

In Section 11.10, we described the scope of GC. It was easy to find large important classes of compounds for which it was unsuitable, either by lack of volatility associated with size, thermal instability, polarity or acid-base functionality, or existence as an ionized form, and so on. When considering HPLC, the question is reversed to define the much smaller range of analytes for which none of its manifold variations is suitable. These would be the substances which cannot be put into liquid solution or be easily retained therein. Highly volatile compounds or fixed gases are one category. GC handles these well. Materials that exist only in the solid state (e.g., metals, refractory and insoluble inorganics like ceramics and glasses, cross-linked polymers of indefinitely high molecular weight), are better handled by XRD, XRF, spectroscopic analysis, thermal analysis, and so on. We shall not attempt a comprehensive description of the range of compounds usefully characterized by the wide range of reverse phase or normal phase HPLC and their modifications, adsorption chromatography, ion chromatography (Section 12.2), affinity chromatography (Section 12.3), size exclusion chromatography (Section 12.4), and the similar but nonchromatographic separations using electrophoresis (Section 12.6). The student is referred to the references in the bibliography and to the resources listed in Appendix 12.A on the text website for thousands of applications.

Some of the varieties of analytes include:

Additives	Carbohydrates	Pesticides
Aflatoxins	Condensed aromatics	Plant pigments (cf. Tswett)
Amino Acids	Drugs	Phenols
Analgesics	Drug metabolites	Poisons
Antibiotics	Dyes	Propellants
Antioxidants	Estrogens	Sedatives
Artificial sweeteners	Herbicides	Steroids
Bile acids	Lipids	Surfactants
Blood alcohols	Narcotics	Urine extracts
Blood proteins		

As an example of the utility of LC techniques in support of biochemical research we shall focus the analysis of amino acids and peptides. **Peptides** are short polymer chains consisting of **amino acid** units. Figure 12.25 illustrates schematically a peptide structure consisting of four amino acid units. The "backbone" of the peptide polymer chain consists of "peptide bonds" between the amino end (—NH₂) and the carboxylic acid end (—COOH) of each of these amino acids. Even longer amino acid polymers form **proteins**, which are crucial for a vast variety of biological functions. Proteins form enzymes, which catalyze the chemical reactions in living systems. They form structural features, such as muscles, tendons, hair, and so on. They form compound selective receptors on cell surfaces which receive and "interpret" messenger compounds such as hormones which regulate biological functions. Some of these messengers are themselves amino acids or peptides. Clearly, we need to




FIGURE 12.25 Generic structure of a four-amino acid peptide chain. (Used with permission from Phenomenex Inc. www.phenomenex.com.)

characterize and measure an immense variety of these complex mixtures if we are to understand life at the molecular level. Of the thousands of possible amino acids, there are only 20 (called "essential" amino acids) which are incorporated in these biopolymers; each distinguished by a different "R-group" substituent structure. These are tabulated in Figure 12.26. Their R-group substituents are seen to have a wide variety of polarities; some have acidic or basic functionalities, and the ability to carry both positive and negative charge. HPLC in its various forms, perhaps using derivatization, and employing a variety of detectors to enhance measurement sensitivity and selectivity, is called for. Each essential amino acid in Figure 12.26 is named, and three letter and one letter abbreviations for each are also




FIGURE 12.26 Structures of the 20 essential amino acids, names, three-letter and one-letter abbreviations, and molecular weights. (Used with permission from Phenomenex Inc. www.phenomenex.com.)




FIGURE 12.27 HPLC of amino acid derivatives detected by 254 nm UV absorption: **(a)** 200 pmol of PTC-amino acid standard, including phosphoserine (PH-S), phosphothreonine (PH-T), hydroxyproline (OH-P), galactosamine (gal), norleucine (NLE, 1 nmol internal standard), excess reagent (Re), and other amino acids designated by one letter codes listed in figure 12.26. **(b)** Analysis of a human fingerprint, taken up from a watch glass using a mixture of water and ethanol. (Courtesy of national gallery of art and the Andrew W. Mellon foundation. Cazes, used with permission.)

listed. If amino acids 1 through 4 in the tetrapeptide in Figure 12.25 were alanine, glycine, phenylalanine, and arginine, in that order, the peptide would be designated: "Ala-Gly-Phe-Arg" or more compactly: "AGFR". The latter nomenclature is often encountered in the output of computerized, automated instrumentation for sequencing peptide chains.

Figure 12.27 displays chromatograms from HPLC analysis of amino acids derivatized with phenylisothiocyanate to yield derivatives with strong absorption at the common Hg-lamp line of 254 nm. The single letter component abbreviations are those of Figure 12.25, with some additional peaks such as ammonia (NH₃), phosphoserine (PH-S), phosphothreonine (PH-T), hydroxyproline (OH-P), galactosamine (Gal), and norleucine internal standard (NLE) and excess derivatizing reagent (Re). The fact that Re appears as a distinct peak indicates that derivatization took place in precolumn mode. The presence of altered or metabolized derivatives of the 20 essential amino acids is characteristic of actual biological samples. The top trace is of a standard mixture of 200 pM concentration amino acids, while the lower one is from fingerprint oils extracted by water and ethanol from a glass surface. This illustrates impressive sensitivity for HPLC with UV/VIS detection. A 20-fold greater sensitivity is possible when using fluorescence detectors with OPA derivatives of amino acids.

Highly sensitive detection of chromatographically (or electrophoretically) separated mixtures of fluorescent derivatives of amino acids or peptides is central to many of the instruments which support the new discipline of **proteomics**.

A fluorescent derivatizing agent can derivatize the terminal nucleotide of a mixture of all fragment lengths produced by sequential removal of one nucleotide at a time from one end of a DNA polymer. Chromatography or electrophoresis can separate and elute these in inverse order of their length. The smallest will elute first. There are four different nucleotides which could be at the end of each fragment, and each such derivative has a different fluorescence

emission wavelength. Use of a fluorescence detector capable of discrimination among each of these emissions allows one to identify the end nucleotide in each successively longer fragment. This then gives one the **sequence** of nucleotides (i.e., the order of the "letters" of the genetic code in the particular segment of the DNA chain being analyzed). By repeating this enough time, with hundreds of automated machines operating around the clock for years, the entire human genetic code of around 3 billion nucleotides has been sequenced.

12.2 CHROMATOGRAPHY OF IONS DISSOLVED IN LIQUIDS

Many compounds dissolve in polar and aqueous solutions to form charged species (ions). Inorganic salts dissociate (e.g., NaCl \rightarrow Na⁺ and Cl⁻). Depending on solution pH, organic acids may dissociate (e.g., RCOOH \rightarrow RCOO⁻ and H⁺) or bases may protonate (e.g., R₃N + HOH \rightarrow R₃NH⁺ and OH⁻) as pH varies. Peptide chains containing acidic amino acid residues such as aspartic or glutamic acids, or basic residues such as lysine, arginine, and histidine (cf. Figure 12.26) may contain both positive and/or negative-charged side groups, with one or the other in excess. The net charge can be balanced at a pH corresponding to the **isoelectric point**, where the molecule has equal amounts of positive and negative charges, but these continue to interact with the solvent by charge-dipole interactions. Small molecules with single positive and negative charges at either end can exist as **zwitterions**. Ionic species generally do not partition smoothly between the classical mobile and stationary phases of reverse phase or normal phase HPLC. Special modifications, either to the mobile phase to suppress the ionic nature of the analytes, or to the stationary phase to incorporate ions of the opposite charge to attract and retain analytes, are used to facilitate the chromatography of ionic species.

Ion-pairing chromatography. One way to render ions more suitable for separation by RP-HPLC is to incorporate a counter ion of opposite charge into the mobile phase. If the counter ion is fairly large, with relatively nonpolar organic substituents attached, then in the polar, aqueous mobile phase characteristic of RP-HPLC, it will associate with analyte ions to form a tight **ion-pair** with no net charge. This entity can now equilibrate and partition between the mobile and stationary phases in a fashion not possible for the parent analyte ion. The associated ion pair will often retain or even improve the spectroscopic or other detection characteristics of the original parent ion, allowing it to be measured by the standard HPLC detectors. Positively charged organic amines can be ion paired with alkyl sulfonic acids (e.g., C₁₂H₂₅SO₃), while negatively charged, dissociated carboxylic or sulfonic acids, and various dye molecules are often paired with long chain quaternary amines [e.g., tetrabutylammonium ion $(C_4H_9)_4$ N⁺]. Both are **strong** acidic or basic ions, respectively (i.e., they remain dissociated in an ionic form over a wide pH range). Neither of these counterions interferes with UV detection of the analyte at wavelengths above 210 nm. Ion-pairing chromatography (IPC) thus extends the scope of RP-HPLC. It is less practical for use with normal phase HPLC, as the less-polar normal phase mobile phases are not as capable of maintaining the counterions in solution. The ion-exchange columns to be described in the next section have difficulties separating large ionic species, as these cannot easily penetrate the cross-linked resin networks which comprise these phases. This hinders attainment of mass-transfer equilibrium and results in loss of chromatographic efficiency. Ion-pairing RP-HPLC works better for such ions. Ionic surfactant molecules (e.g., phospholipids, phosphate detergents) have such high affinity for the ion exchange resins that they are difficult to elute from them, so ion-pairing RP-HPLC is also preferred for this class of analyte.

Ion-exchange chromatography. For many years, it has been known that clays include metal ions in their mineral structure, and that these can exchange with other metal ions present in solutions in contact with the clay. **Zeolites** (sodium aluminum silicates) possess similar ion-exchange properties. Natural and artificial zeolites are employed in water softeners to remove the "hardness ions", Ca²⁺ and Mg²⁺, by binding them while releasing a charge equivalent number of more soluble Na⁺ ions. For application of ion-exchange to chromatographic separations, resin columns can be modified by introducing charged functional groups into the cross-linked 3D polymeric structure. These groups will have either positive or negative charges opposite to those of the ions to be exchanged.

FIGURE 12.28 Formation and structure of styrene-divinylbenzene resin polymer.

A particularly useful resin is that formed by the copolymerization of styrene (vinylbenzene) and divinylbenzene, and is illustrated in Figure 12.28. By varying the proportion of divinylbenzene incorporated in the polymerization one can vary the extent of cross-linking of the polystyrene chains, which confers greater stability to the polymer structure and affects the porosity and tendency of the polymer to swell as it takes up mobile phase liquid. The benzene rings in the polymer structure are ideal substrates for synthetic introduction of various charged functional groups, using standard aromatic substitution reactions.

1. Cation exchange resins. The functional group in cation exchange resins is usually an acid. Sulfonation reactions can add the sulfonic acid group, —SO₃H, to essentially all the benzene rings of the resin. The weaker carboxylic acid group, —COOH, may be added instead. The former produces a "strong acid" cation exchange resin of the formula Res—(SO₃H)_n, where Res represents the resin polymer matrix and — $(SO_3H)_n$, the numerous attached sulfonic acid groups. Introduction of the —COOH group yields a "weak acid" exchange resin whose pK_a is more similar to that of benzoic acid. In each case, an acidic hydrogen is attached to a functional group chemically bound to the resin. The number of such exchange sites, n, in a given weight of the ion exchange resin is a measure of its **exchange capacity**, usually expressed as milliequivalents/g (meq/g). To maintain charge balance in the resin, the exchange and binding of multiply charged ions require interaction with multiple singly charged sites. Thus, the equivalent value for such ions is calculated as m/z, where m is the number of moles, and z is the ionic charge. If the affinity of an ion such as Na⁺ in solution is greater than that of H⁺ for the functional group, and/or its solution concentration is sufficiently greater than the concentration (not to be confused with exchange capacity) of exchangable H+ on the resin functional groups, then exchange reactions of the following type establish an equilibrium:

(12.1)
$$Res - COOH + Na^{+} \rightarrow Res - COONa + H^{+}$$

(12.2)
$$Res - (SO_3H) + Na^+ \rightarrow Res - (SO_3Na) + H^+$$

Almost any metal ion will displace hydrogen ion from the resin under these circumstances. This provides a method for removing metal ions from aqueous solutions. The solution becomes acidic only if the metal is exchanging with a hydrogen ion. A cation exchange resin with H^+ on its functional groups is said to be in the *acid form*, and when Na^+ replaces the H^+ , it is said to be in the *sodium form*. Depending on the relative affinities of the metal ions for the resin functional group, further exchanges are possible. For example, Cu^{2+} will replace the sodium in a sodium form resin according to the process:

(12.3)
$$\operatorname{Res} - (SO_3)_2 2\operatorname{Na} + \operatorname{Cu}^{2+} \to \operatorname{Res} - (SO_3)_2\operatorname{Cu} + 2\operatorname{Na}^+$$

Note that the cupric ion is shown to be associated with two resin functional groups, releasing two sodium ions. Half the number of moles of doubly charged copper is

- equivalent on the basis of charge to sodium or hydrogen. If the copper were present as singly charged cuprous ion, the equivalents would contain equal numbers of moles.
- 2. Anion exchange resins. Anions can be removed from solution using the same principles which are applied to exchange cations. The functional groups of opposite positive charge are most commonly quaternary ammonium or polyalkyl amine groups, forming either **strong** or **weak base** exchangers according to the processes illustrated in Equations (12.4) and (12.5), respectively:

(12.4) Res
$$- CH_2N(CH_3)_3^+ OH^- + Cl^- \rightarrow Res - CH_2N(CH_3)_3^+Cl^- + OH^-$$

(12.5)
$$\operatorname{Res} - \operatorname{NH}(-R)_{2}^{+} \operatorname{OH}^{-} + \operatorname{Cl}^{-} \to \operatorname{Res} - \operatorname{NH}(-R)_{2}^{+} \operatorname{Cl}^{-} + \operatorname{OH}^{-}$$

The rate of ion exchange is controlled by the law of mass action. At *equal* concentrations, the greater affinity of Na⁺ replaces H⁺ from the cation exchange resins in the acid form. However, if a much higher concentration of strong (i.e., completely dissociated) acid is passed through the sodium form resin, it will reverse the equilibrium, displace the Na⁺ ions, and convert the resin back to the acid form. In general, it is usually possible to return an ion exchange resin column to a desired starting form by passing a large excess of the desired ion at very high concentration through the resin. Thus, one can use an ion exchange column to retain the majority of ions of higher affinity as a less concentrated solution of them is passed through it, until most of the binding sites or functional groups have been exchanged and the exchange capacity is exceeded—a situation analogous to "overloading" in partition chromatography. Subsequent passage of a smaller volume of a very concentrated solution of the initial form, lower affinity ions restore it to that form, **regenerating** the column, and effects a *concentration* of the originally more retained ions in the regenerating wash solution effluent.

The relative affinities (i.e., selectivities) of ions for the functional groups on the resin are governed by two rules:

- 1. Ions with higher charge have higher affinity (e.g., $Na^+ < Ca^{2+} < Al^{3+}$ and $Cl^- < SO_4^{2-}$).
- 2. The ion with the greatest size (radius) and the greatest charge has the highest affinity (e.g., Li⁺ < Na⁺ < K⁺ < Cs⁺ < Be²⁺ < Mg²⁺ < Cu²⁺ and F⁻ < Cl⁻ < Br⁻ < I⁻).

By a careful choice of the ionic composition of the eluent, and the gradual adjustment of its strength (i.e., ion concentration and/or pH, which can control concentration of ions resulting from acid-base equilibrium) during elution using a controlled gradient, the components of a mixture of ions can be induced to separate just as do the components of a mixture separated by partition chromatography. The chromatographic principles discussed for the latter technique also apply. For ion-exchange chromatographic separations, the concentrations of the analyte ions being separated by a resin column need to be much less than those which would be present at values close to its exchange capacity.

The fundamental parameters controlling relative residence times of analyte or other eluent ions in the resin stationary phase or the ionic solution mobile phase are: both the relative selectivity of the resin for the ions and their relative concentrations in each phase. In contrast, in reverse phase or normal phase HPLC, selectivity is controlled by the relative polarity interactions of different analytes with both phases. Until an overload occurs, this is independent of analyte concentration.

Another difference is that in ion exchange the selectivity resides in relative ion-pairing interaction strengths only in the stationary phase. The effects of mobile phase composition changes are manifested by the relative concentrations of other nonanalyte ions in the mobile phase competing for the fixed number of exchange sites on the resin.

Ion-exchange chromatography was initially developed during the Manhattan Project to preparatively separate the chemically very similar, triply charged lanthanide rare earth and actinide series cations on the basis of slight differences in their ionic radii. A generally useful instrumental version suitable for quantitative analysis of small organic and inorganic ions awaited the development of a universal, sensitive detector.




FIGURE 12.29 Schematic of the eluent suppression approach for ion chromatography that permits conductometric detection of analytes.

Many important inorganic and organic ions at the trace level are not easily detected by reduction—oxidation or spectroscopic methods. This has led to the development of sophisticated separation and conductometric detectors capable of ultrasensitive analyses. It is difficult to measure small changes in conductivity due to a trace analyte ion when the background level is orders of magnitude larger; consequently, procedures have been developed that are capable of suppressing high ionic strength backgrounds, allowing the net signal to be measured more easily. Combined with miniature conductance detectors, these procedures have led to a technique known as *ion chromatography* with eluant suppression (see section 12.2.1; Figure 12.30). Figure 12.29 shows the setup for a typical application: the analysis of the constituents of acid rain samples.

12.2.1 ION CHROMATOGRAPHY

As described earlier, when attempting to use a conductivity detector for ion-exchange chromatography, the high electrolyte concentration required to elute analyte ions in a reasonable time tends to overwhelm the much lower conductivity contributed by low levels of analyte ions. This problem was eventually overcome by introducing an **eluent suppressor column** to convert eluent ions to nonconductive, nonionized molecular forms, while leaving the low concentrations of analyte ions to be measured by a conductometric detector. This mode of analytical ion-exchange chromatography goes by the name of ion chromatography. **Ion chromatography** (IC) is defined as the analysis of ionic analytes by separation on ion exchange stationary phases with **eluent suppression** of excess eluent ions. Detection in most IC systems is by the universal (for ionic analytes) conductivity detector (Section 12.1.4.5).

When *cations* are being exchanged on the analytical column to affect a separation, variable concentrations of hydrochloric acid are often employed as the eluent. In this case, the




FIGURE 12.30 Three methods of suppressing mobile phase ions in IC: **(a)** packed bed suppression—batch suppression, **(b)** self-regenerating suppression—continuous regeneration, and **(c)** eluent generation from water. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

suppressor column is an anion exchange column in the hydroxide form. The hydroxide on the suppressor column reacts with the hydrogen ions in the eluent exiting the analytical column to form nonconductive water, which contributes no signal to the conductivity detector. The reaction on the suppressor column is:

(12.6)
$$H^{+}(aq) + Cl^{-}(aq) + Res^{+}(OH^{-}) \rightarrow Res^{+}(Cl^{-}) + HOH \text{ (water)}$$

The cations being separated on the analytical column pass through the anion exchange suppressor column without being retained. Conversely, for anion separations, the suppressor column is in the acid form of a cation exchange column. The eluent contains high concentrations of a displacing anion (e.g., OH^- or HCO_3^-) which can react with the exchangeable H^+ on the suppressor column to form a largely undissociated species (e.g., H_2O or carbonic acid, H_2CO_3 , respectively). Analysis of chloride anion, Cl^- by simple suppressor column IC is illustrated in Figure 12.30(a). In this case, Na^+ from NaOH eluent and NaCl analyte displaces H^+ from the head of the suppressor column, and the liberated H^+ reacts with

the OH^- to form water, leaving only the chloride ion and a balancing amount of hydrogen ion to produce a conductivity signal in the detector proportional to the small amount of eluted chloride. As more NaOH in the eluent displaces H^+ in the suppressor column, the portions which are "exhausted" increase and the "suppressing" portions decrease. Eventually, it becomes completely exhausted, and then must be **regenerated** by backflowing a high concentration of strong acid solution through it, to convert it back to the acid form, and then be rinsed with water to remove residual ions. The same process with a strong base is used to regenerate anion exchange suppressor columns employed in cation IC systems.

The need to periodically regenerate suppressor columns is an inconvenience, especially if one wishes to operate an ion chromatograph in an unattended, automated fashion over long periods. A **self-regenerating suppressor** continually regenerates the element in an ion chromatograph that performs the function of the suppressor column. It recycles the post-detector effluent of the ion chromatograph past an electrode which continuously electrolyzes water in the effluent to produce the desired H⁺ or OH⁻ regenerant ions. The suppressor ion-exchange column is replaced by an array of microvolume ion-exchange membranes. Effluent from the analytical column passes over one side of these membranes, while the regeneration ions produced by the electrode flow on the other. The excess eluent ions pass through the membrane and are carried to waste in the eluent recycle stream from which the electrode-generated ions were produced. These latter ions pass through the membrane to maintain the charge balance, and they react to suppress the charge of the excess eluent ions, just as did the corresponding ions bound on a regenerated suppressor column. Figure 12.30(b) illustrates this process for the same anion IC analysis of chloride illustrated in Figure 12.30(a).

The employment of an electrode system to generate H^+ or OH^- on demand in the amounts required to operate a self-regenerating membrane suppressor system led to the idea of using a similar generator to also produce the desired concentrations of these ions in the eluent streams with which analytes are eluted from analytical ion-exchange columns used for IC. For this to work effectively, it is desirable to use high-efficiency, low-capacity, ion-exchange columns for the separation. These are better suited for the low levels of analytes to be separated, and permit the use of lower eluent ion concentrations, which are easier to generate by these methods. Instead of the large porous resin beads, where diffusion in and out of the beads degrades chromatographic plate count and resolution, **pellicular packings** are used. An example of such an ion-exchange column "bead" is illustrated in Figure 12.31. The spherical bead consists of a rigid silica sphere of 5 μ m radius, coated on the surface with a 0.1 μ m




FIGURE 12.31 Pellicular anion exchange bead for ion chromatography. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

layer of latex to which sulfonate groups ($-SO_3^-$) are bonded. Large molecules containing multiple positively-charged alkyl ammonium ion substituents bond electrostatically to these $-SO_3^-$ groups. The outer layer of positively-charged ions serve as the site for exchange of anions with a mobile phase. Figure 12.29(c) displays a block diagram of an IC system which employs an eluent generating system, EG40 $^\circ$ (Thermo Fisher Scientific, Inc.), based on electrolysis of water. Such a system does away with the need for preparing and consuming eluent and regenerating solutions. The trademarked slogan used for such systems by their originator is "Just add water".

Figure 12.32 displays an IC separation of 34 small anions. Note that both inorganic halides and oxyanions such as sulfate and bromate are measured, as well as small organic anions like formate, malonate, and phthalate. Note that pairs of ions representing different oxidation states of inorganic atoms such as nitrite/nitrate and chlorite/chlorate are readily separable. IC is particularly appropriate for speciation of inorganic elements, and is a particularly useful mode for introduction to highly specific and sensitive detectors such as ICP-OES and ICP-MS when element-specific speciation is called for.

A final new version of ion exchange chromatography employs arguably the most sophisticated column packing technology yet, which combines RP-HPLC and ion exchange separation mechanisms on the same particle. This employs a novel nanopolymer-silica hybrid particle structure. Check the structure of porous silica particles illustrated in Figure 12.2. The interior pore surfaces are modified with a covalently bonded organic layer which provides both reversed-phase and anion-exchange retention properties. The outer surface is

10




FIGURE 12.32 Ion chromatography separation of 34 anions. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

electrostatically coated with nanopolymer particles with a cation-exchange functionality. This overall structure ensures spatial separation of the anion-exchange and cation-exchange regions, and allows both retention mechanisms to function simultaneously, and the retention properties of each to be varied independently. With enough design effort and experimentation with both mobile phase and stationary phase compositions suitable for a given separation problem, ideal selectivity may be attained for simultaneous separation of base, neutral, and acidic analytes, and retention of ionic and ionizable analytes without the use of ion-pairing reagents. These "triple-threat", one-pass columns are marketed by Thermo Scientific under the name Acclaim Trinity P1 Columns. Although sophisticated in phase design, Acclaim Trinity P1 is specially designed for simultaneous determination of pharmaceutical compounds and their counterions. Literature on the use of this column can be found at www.thermoscientific.com. To make the most of the full potential of these ever more complex and powerful phase designs, users need to have an in-depth knowledge of the phase chemistry, master the general application development strategy (adjusting selectivity by mobile phase ionic strength, pH, and solvent content), and most importantly, familiarize themselves with the column by hands-on experience. Mixed-mode columns including the Acclaim Trinity provide chromatographers with unique separation tools to complement general-purpose reversed-phase columns.

12.2.1.1 SINGLE-COLUMN IC

The development of ion-exchange columns with low exchange capacity has led to a mode of IC which dispenses with the suppressor column. When using such columns, a dilute eluent solution can be sufficient to displace ions from the column. If such an eluent can be found which has a substantially lower conductivity than the analyte ions, then the conductivity of the effluent will change (increase) as the more conductive analyte ions elute through the detector. Charge balance ensures that the number of charges (or ions of the same charge) will be constant as the exchange takes place. **Single-column anion chromatography** typically employs benzoate, *p*-hydroxybenzoate, or phthalate anions as eluent anions. These are either benzene mono- or dicarboxylate anions. Adjustment of eluent pH can control average eluent anionic charge and thus the eluent strength. **Single-column cation chromatography** is performed with nitric acid as eluent for singly charged cations or doubly charged ethylene-diammonium salts for doubly charged cations. While the instrumentation is much simpler, the sensitivity and linear dynamic range of single-column IC tends to be less than that of IC employing suppressor columns.

12.2.1.2 INDIRECT DETECTION IN IC

The use of anions such as phthalate in single-column IC enables another form of detection than conductivity. Many small anions will have no UV absorption in the range where the aromatic phthalate anion absorbs. If the latter is employed as an eluent, when it displaces non-UV-absorbing anions, the concentration of absorbing species passing a UV detector will decrease to the extent that the nonabsorbing analyte ions replace the eluent ions in the effluent. The effect is a drop in the previously constant level of absorbance from the eluent anions, which manifests itself as a negative peak. The peak area is proportional to the concentration of the analyte anion. A suitable UV-absorbing eluent for indirect detection in cation chromatography is cupric ion, as copper sulfate. This is called indirect detection, since we are not measuring the analyte directly, but instead a drop in the signal produced by absorbing eluent ions which have been replaced on an exactly equivalent basis by the "invisible" analyte ions with which they have exchanged on the column. It is the equivalence of charge exchange and balance in ion-exchange chromatography which enables this method to work quantitatively. We will see later that indirect detection can also be employed in the technique of capillary electrophoresis (CE), where again the analytes are ions, and can substitute for absorbing ions forming a background supporting electrolyte, which in this case is not an eluent.

12.3 AFFINITY CHROMATOGRAPHY

Chromatography interfaced with MS can separate and characterize peptide chains. With sufficient information of this sort, one might even reassemble the data on fragments of a tryptic digest of a large protein molecule, and chart the sequence of amino acids in the whole molecule, thus completely characterizing and identifying this macromolecule. Complex biological systems, even at the level of particular types of cells, may contain hundreds, even thousands of proteins. How might these be separated and isolated from one another, so that this sort of analysis may proceed on a single protein? We may expect that there are chromatographic procedures or electrophoresis procedures that can separate mixtures of proteins. These may not be satisfactory for isolating one out of the hundreds that might be present, especially if they are minor components of the mixture, and we do not know exactly which peak or spot is the particular molecule of interest. Many biological macromolecules (not only proteins) have been tailored by natural selection to bind very selectively to other specific biomolecules to perform their function in the organism. For example, enzymes bond selectively to their substrates, antibodies to their antigens, and receptors to their messenger hormone molecules.

If we wish to isolate a single biomolecule of this sort from a complex soup of other biomolecules, the technique of **affinity chromatography** is especially powerful. The appropriate biomolecule to which the target binds (e.g., an enzyme substrate, antigen, hormone) is isolated, and attached by a short molecular chain called a **spacer arm** to a chromatographic gel support material, which is permeable to solutions of the biological macromolecules. The spacer arm will have reactive functionalities (often carbamide groups) on either end which will attach to reactive groups on both the gel and the binding biomolecule. Dangling this target away from the gel on the spacer arm reduces the steric hinderance that the large target molecule might suffer were the binding molecule attached directly to the gel.

The steps for isolating a specific biomolecule are outlined in Figure 12.33. The stationary phase might be a permeable cross-linked agarose polymer, or perhaps an agarose-acrylamide copolymer gel, here represented by the coiled, looping lines in the column. The binding biomolecules (termed **ligands**) attached by the spacer arm, are represented by small open circles





FIGURE 12.33 Four steps in performing affinity chromatography. (Katz et al., Used with permission.)

linked to the gel polymer by a short line. A mixture containing three large target biomolecules is shown being applied to the column. Only one of these has a cavity of just the right shape to bind strongly to the ligand (adsorption step). This is done using a solvent designated as an application buffer, which is close to the pH, ionic strength, and polarity which the target and ligand experience in their natural environment. The other two nonbinding biomolecules are rinsed out of the column in the wash step using the application buffer. The next step is to remove the bound target compound in an **elution** step, using an **elution buffer**. If the target biomolecule to be eluted is very sensitive to changes in solvent condition (e.g., a protein structure that is easily denatured by changes in pH or solvent polarity), then one will not wish to break the binding by changing these buffer parameters too greatly from those of the application buffer. A gentler elution method is biospecific elution, in which the elution buffer contains a similar, competing biomolecule, which displaces the target molecule. This can be done either by adding an agent which competes with the column ligand for the target (normal-role elution) or one which competes with the target for ligand-binding sites (reversed-role elution). While biospecific elution is very gentle, it is generally slow, and the eluted target peaks are very broad. The competing molecule may have to be removed from the eluted solution, and if analytical affinity chromatography is being performed, it must not interfere by producing a large background signal under the detection conditions being used. For analytical rather than the preparative applications for which the gentle mechanism of biospecific elution may be required, nonspecific elution may be employed. This employs an elution buffer of substantially different pH, ionic strength, or polarity to lower the association constant of binding to the ligand. Under such conditions, the compound of interest is eluted much more rapidly, leading to higher, narrower peaks, and consequently lower limits of detection. After the target compound is detected or isolated, the column is regenerated by passing the application buffer through it before injecting the next sample.

12.4 SIZE EXCLUSION CHROMATOGRAPHY (SEC)

Size exclusion chromatography (SEC) or gel permeation (or filtration) chromatography (GPC/GFC) uses a porous material as the stationary phase and a liquid as a mobile phase. The diameters of the pores of the porous material can range from 5 to 100,000 nm, which are useful for the size range of molecules having molecular weights of ~500 to 1 million Da. The latter penetrate the pores according to their size. Small molecules penetrate more deeply into the pores than large molecules, which frequently are excluded from fully penetrating the smaller cavities of the pores. This results in a difference in the rates at which the molecules pass down the column, the larger molecules traveling faster than the smaller molecules. Ideally, there are no binding interactions between the analytes and the porous column particles, so the retention of smaller molecules is due solely to the relative ease and depth to which they can penetrate the pores by diffusion, before diffusing back again to re-enter the flow of the mobile phase. The principles of this separation are illustrated in Figure 12.34. They are the same as those which are used for the GC separation of fixed gases using Zeolite molecular sieves or Porapak materials. In the fixed gas examples, it is not so easy to rationalize relative retention strictly on the basis of analyte size or weight. There are some binding interactions of the analytes with the pore materials. SEC separations have lesser binding interactions but are not completely immune from them. Retention is more easily correlated with molecular size or weight.

There are generally two types of column packings: porous glasses or silicas and porous cross-linked organic gels such as dextrans, methacrylate-based gels, polyvinyl alcohol-based gels, and hydroxyethyl cellulose gels. GFC uses aqueous solvents and hydrophilic packings, while GPC employs nonpolar organic solvents and hydrophobic packings. The detectors used are based on UV fluorescence, UV absorption, or changes in refractive index. A given packing material is available in a range of pore sizes. Molecules above a given molecular weight are too large to enter the pores, and therefore elute in the void volume. Any molecule above this **exclusion limit** will elute in the minimum possible time, and molecules with molecular weights above this limit cannot be separated. Molecules small enough to freely diffuse



Schematic representation of GFC. Molecules of different size in the frame are separated according to size during migration through (b) the gel-filtration matrix as shown in the middle and right frames.

FIGURE 12.34 Mechanism of size exclusion chromatography; **(a)** size selectivity as a function of pore and analyte sizes and **(b)** separation process on a gel-filtration column. (Adapted with permission from Phenomenex, Inc., www.phenomenex.com.)

into all portions of the pores will be the most strongly retained, spending the same portion of time trapped in the pores, so they will elute at the same maximum time, called the **permeation limit**, and will likewise fail to be separated. In contrast to partition chromatography, SEC or GPC have not only a lower limit for peak retention times, but also an upper limit. This is actually an advantage, since chromatographic runs will not drag on too long with late eluters. In the molecular weight range between these limits (on the order of one to two orders of magnitude), the retention time of a molecule is inversely proportional to the logarithm of the molecular weight. A packing with the appropriate pore size to cover the anticipated range of weights must be selected. Particles with different pore sizes can be mixed to accomplish separation of mixtures of a wider range of molecular weights.

If the sample is a single polymer, the chromatogram represents the molecular weight distribution. This method is very valuable for determining the molecular weight distributions of polymers up to very high molecular weights. The actual calculation is usually based on a comparison with a standard polymer material of known molecular weight distribution. The procedure is also used to assess the molecular weights of biological compounds, such as proteins. GPC is capable of separating different polymers from each other and, under the correct conditions, mixtures of polymers can be characterized with respect to percentage and weight range of each polymer present. GPC has been used for such important analyses as the determination of somewhat toxic aldehydes and ketones in auto exhaust. It has also been used to separate C_{60} and C_{70} fullerenes (buckyballs). GPC has been used in a hyphenated HPLC-ICPOES study of silicones to separate and quantitate high MW PDMS polymers (Dorn and Skelly Frame). Figure 12.35 illustrates a GFC separation of several large protein molecules. An additional useful application of GFC is **desalting**, wherein salts of low molecular weight are separated from solutions of large macromolecules in order to facilitate changing the buffer composition of their solution to one suitable for a method such as electrospray LC-MS or CE.

Protein molecular weight standards




FIGURE 12.35 Gel filtration separation of five protein molecules. (Used with permission from Sigma-Aldrich, a part of MilliporeSigma. www.sigmaaldritch.com. Copyright 2020 Sigma-Aldrich Co. LLC. All rights reserved.)

Care must be taken in interpreting retention data to estimate molecular weights since the separation is based on the size of the molecule rather than on the actual molecular weight. This means that the shape of the molecule has a significant effect on the results. For example, two molecules of the same molecular weight, one straight chained and the other highly branched, will be retained somewhat differently because each has a different penetrating power into the column particle pores. This must be taken into account when selecting standards for calibrating the molecular weights.

An advantage of SEC is that it can be carried out at room temperature and the samples are not decomposed because of exposure to high temperature. This is especially important when dealing with some very high molecular weight compounds which are easily broken into two or three fragments, resulting in great changes in apparent molecular weight. It gives a limited range of retention times which facilitates rapid sample throughput, and the peaks are narrow and therefore give good sensitivity. Since analyte interaction with the particles is minimal, sample loss and deactivation of the column is also minimized. A disadvantage of the short time range for peak elution between the exclusion and permeation limits is the limitation this imposes on the number of peaks that can be accommodated. The method generally requires differences on the order of \pm 10 % in molecular weight for sample peaks to be resolved. Consequently, similar sized variants of large biomolecules (e.g., isomers) are better analyzed by affinity chromatography, if the appropriate ligand can be obtained and bound in an affinity chromatography column.

12.5 SUPERCRITICAL FLUID CHROMATOGRAPHY

A compound such as CO_2 is a gas at normal temperature and pressure (NTP). Like all gases below a certain critical temperature, further increasing the pressure results in the formation of a liquid. Above this critical temperature, increasing the pressure increases the density of

TABLE 12.4	Typical Values f	for Gases, L	iquids, and SCFs
1/10 12:1	I y picul Tulucs i	OI GUJCJ/ E	iquius/ uliu sei s

Property	Gas (NTP)	SCF	Liquid
Density	1×10^{-2}	0.3	1.0
Diffusion coefficient (cm ² /s)	3×10^{-1}	10-3	1×10^{-5}
Viscosity (g/cm/s)	2×10^{-4}	2×10^{-4}	2×10^{-2}

the fluid but a distinct transition to and boundary with a liquid phase never forms. At the critical temperature and pressure, the density of the gas phase and the liquid phase are the same. This state is neither a true liquid nor a true gas but is a supercritical fluid (SCF). Use of a compound in this fluid state as a chromatographic mobile phase provides different properties than when it is used as either a gas or a liquid in GC or HPLC, as shown in Table 12.4. To date, most attention has been focused on CO₂, C₂H₆, and N₂O, with critical temperatures of 31 °C, 32 °C, and 37 °C, respectively. The CO₂ phase diagram is in Section 1.3.4.1. The temperatures and the necessary pressures can be accommodated in conventional GC instruments if the effluent end of the column is maintained at a sufficiently high pressure above ambient. This can be achieved by the addition of suitable flow restrictors at the column end. An important property of SCFs is their ability to dissolve poorly volatile molecules. Certain important industrial processes are based upon the high solubility of organic species in supercritical CO₂. For example, CO₂ has been employed for extracting caffeine from coffee beans to produce decaffeinated coffee and for extracting nicotine from cigarette tobacco. Supercritical CO₂ readily dissolved *n*-alkanes containing up to 22 carbon atoms, di*n*-alkylphthalates with alkyl groups containing up to 16 carbon atoms, and various polycyclic aromatic hydrocarbons.

12.5.1 OPERATING CONDITIONS

To adapt equipment to supercritical applications, it is only necessary to provide an independent means for controlling the internal pressure of the system. Such systems are available as adaptations of commercial GC or HPLC instrument designs. The most widely used detectors are those found in both GC and LC (i.e., UV absorption and fluorescence, RI, flame ionization, and MS).

12.5.2 EFFECT OF PRESSURE

Pressure changes in supercritical chromatography affect k'. For example, increasing the average CO_2 pressure across a packed column from about 70 to 90 bar (1 bar = 0.987 atm) decreases the elution time for hexadecane from about 25 to 5 min. This effect is general and has led to the type of gradient elution in which the column pressure is increased linearly as the elution proceeds. The results are analogous to those obtained with programmed-temperature in GC and solvent-gradient elution in LC.

12.5.3 STATIONARY AND MOBILE PHASES

SFC has utilized column packings commonly used in LC. Capillary SFC has been performed with stationary phases of organic films bonded to capillary tubing. Because of the low viscosity of SCFs, long columns (50 m or more) can be used. This results in very high resolution in a reasonable elapsed time. This is the key advantage of SFC: it combines the low resistance to flow of GC, enabling longer columns with more theoretical plates, while the mobile phase density approaches that of a liquid, and thus introduces a liquid-like solvating power that is totally lacking in GC gases like H_2 , He, or N_2 .

The most commonly used mobile phase for SFC is CO_2 . It is an excellent solvent for many organic molecules, and it is transparent in the UV range. It is odorless, nontoxic, readily available, and inexpensive when compared with other chromatographic solvents. Carbon dioxide's critical temperature of 31 °C and its pressure of 72.9 bar at the critical point permit a wide selection of temperatures and pressures without exceeding the operating limits of modern chromatographic equipment. Other substances that have served as mobile phases for SFC include ethane, pentane, dichlorodifluoromethane, diethyl ether, and tetrahydrofuran.

12.5.4 SFC VERSUS OTHER COLUMN METHODS

As shown in Table 12.4, several physical properties of SCFs are intermediate between gases and liquids. Hence, SFC combines some of the characteristics of both GC and LC. For example, like GC, SFC is inherently faster than LC because of the lower viscosity and higher diffusion rates in supercritical fluids. High diffusivity leads to band spreading, a significant factor with GC but not with LC. The intermediate diffusivities and viscosities of supercritical fluids result in faster separations than are achieved with LC together with lower band spreading than encountered in GC.

Figure 12.36 compares the performance characteristics of a packed column when elution is performed with supercritical CO_2 versus a conventional HPLC mobile phase. The rate of elution is approximately $4\times$ faster using SFC. The roles of the mobile phase in GC, LC, and SFC are somewhat different. In GC, the mobile phase serves but one function-band movement. In LC, the mobile phase provides not only transport of solute molecules but also influences selectivity factors. When a molecule dissolves in a supercritical medium, the process resembles volatilization but at a much lower temperature than under normal circumstances. Thus, at a given temperature, the vapor pressure for a large molecule in a SCF may be orders of magnitude greater than in the absence of that fluid. As a result, important compounds such as high molecular weight compounds, thermally unstable species, polymers, and biological molecules can be brought into a much more fluid state than that of a




FIGURE 12.36 Comparison of SFC and HPLC separations (R_t in min).

normal liquid solution of these same molecules. Interactions between solute molecules and the molecules of a SCF must occur to account for their solubility in these media. The solvent power is thus a function of the chemical composition of the fluid. Therefore, in contrast to GC, there is the possibility of varying retention substantially by changing the mobile phase (i.e., by adding modifiers to the SFC mobile phase, as is done in HPLC). The solvent power of an SFC is also related indirectly to the gas density and thus the gas pressure. One manifestation of this relationship is the general existence of a threshold density below which no solution of solute occurs. Above this critical value, the solubility increases rapidly and then levels off.

12.5.5 APPLICATIONS

SFC can handle larger molecules than GC, with higher efficiencies than LC, and its largely normal phase packings provide separations orthogonal to RPLC. It was also considerably easier to interface with mass spectrometers than was its liquid counterpart prior to the advent of ESI and APCI-MS interfaces. The high chromatographic resolution achievable with coated capillary columns was particularly significant. Effluent collection was especially easy when using CO₂, as the mobile phase could be readily and gently removed from collected fractions by simply opening them to atmospheric pressure, bleeding the gas off slowly to avoid the condensation and dry ice crystal formation that occur using CO₂ fire extinguishers. This feature had made **preparative SFC** one of the major present applications of the technique, while **analytical SFC** was less often practiced.

12.5.6 ULTRA PERFORMANCE CONVERGENCE CHROMATOGRAPHY (UPCC OR UPC²) – A NEW SYNTHESIS

Analytical SFC did not live up to its promise due to difficulties in handling the largely supercritical CO₂-based mobile phase and blending in small amounts of organic modifiers, while avoiding difficulties of using such a carrier in the injectors, columns, valves, backpressure regulators, and detectors designed for UHPLC analyses. Waters Corporation redesigned all these elements from their Acquity UHPLC™ hardware to a new instrument called the Acquity UPC^{2™} system. This is capable of better controlling the parameters of SFC mode operation to enable greater peak shape resolution and reproducibility of retention times under gradient conditions, as well as remaining capable of standard UHPLC analyses. This new combination is named Ultra Performance Convergence Chromatography (UPC2), as it enables standard RP-UHPLC runs as well as greatly superior NP-SFC runs, thus achieving a convergence of these two very different LC separation methodologies. The former is developed using typically a single suitable column and varying the polar mobile phase mixture composition to achieve optimal separation. The latter uses a standard fixed set of mobile phase conditions (e.g., 150 bar pressure, 40 °C, and a generic gradient from 5 to 40 % methanol in CO₂) and tests the analyte mixture against a set of columns optimized for separation of basic compounds (which are the most problematic for SFC/UPC²: (e.g., a set of ethylpyridine columns)). Neutral and acidic analytes are much less problematic for NP-SFC assay development. The Acquity UPC^{2™} system is unique in that the dual instrument/column/mobile phase systems enable operation using either of the orthogonal RP-HPLC or NP-SFC separation techniques, with improvements in the normal-phase branch of this combination, which brings its performance back to parity with the dominant reverse-phase methodologies. Figure 12.37 illustrates this for a preparation of the antiemetic metoclopramide (large unlabeled peak 7), and 8 other contaminants. Note the radically different elution orders and positions of these contaminants relative to the metoclopramide peak. This is a dramatic example of the principle and use of orthogonal separations that we have already seen in 2D-GC, 2D-HPLC and 2D-TLC.




FIGURE 12.37 Orthogonal RP-UPLC and Acquity UPC² separations of metoclopramide and 8 contaminants. Waters BEH UPLC C18 RP-Column and Acquity UPC² BEH column with UV detection. (Used with permission from Waters Corp. [www.waters.com/upc2].)

12.6 ELECTROPHORESIS

In Section 10.4, we described the mechanism of the chromatographic separation process using an extended analogy to people stepping on and off a moving slideway. If different classes of people stayed on the slideway at all times but walked forwards or backwards at different constant rates, they would separate themselves along the slideway and exit it at different times. If molecules could be induced to behave in a column in a similar fashion, the process would not be chromatographic, as they would not be transferring back and forth between a stationary and mobile phase. The separation process would, however, appear very much like chromatography, with a mixture being introduced at one end of a column with flowing fluid, and the components exiting the other end as separated, Gaussian shaped peaks to be detected and quantitated by the same type of detectors employed in HPLC. This is the basis of electrophoresis.

12.6.1 CAPILLARY ZONE ELECTROPHORESIS (CZE)

If molecules in solution carry a charge, application of a sufficiently high voltage between two electrodes immersed in the solution will cause positively charged cations to migrate (i.e., move through the solvent in response to the electromotive force or voltage) toward the cathode. Likewise, anions will migrate toward the anode. Such a **migration** of ions in solution under the influence of an electric field is termed **electrophoresis**.

There is intimate interaction of the migrating ions with the surrounding solvent as they move through it, resulting in viscous frictional drag forces which act almost instantaneously to limit the motion of the ion to a steady speed through the liquid. This speed is that at which the retarding frictional force just balances the applied electromotive force (voltage). To attain useful electrophoretic migration speeds, electrical fields of thousands of volts/meter must be applied. It is the *effective size* of the ion, *not its mass*, which governs the frictional force

resisting the migration of the ion. The balance of the frictional force and the accelerating force at a given migration velocity is given by Equation 12.7:

$$qE = fu_{\rm ep}$$

where q is the charge on the ion (in C), and E is the applied field (in V/m), while f is the frictional coefficient and $u_{\rm ep}$ is the ion's velocity. Rearranging Equation 12.7 to Equation 12.8, we obtain:

(12.8)
$$u_{\rm ep} = \left(\frac{q}{f}\right)E = \mu_{\rm eq}E$$

where μ_{eq} , the electrophoretic mobility, is defined as the constant of proportionality between the speed of the ion and the electric field. This value is proportional to the charge on the ion and inversely proportional to the frictional coefficient. That coefficient, f, is proportional to the effective hydrodynamic radius, so the electrophoretic mobility is seen from Equation 12.8 to be inversely proportional to this "size" parameter of the ion. Note that this effective radius is not calculated from measurements of the molecular size, but is experimentally determined by measurements of μ_{eq} . A diprotic acid could bear either one or two negative charges depending on solution pH. Although the charge is exactly doubled, the effective size of the ion with its tightly bound, associated water molecules will vary with the degree of acid dissociation, so the mobility difference will not necessarily be exactly a factor of 2. Mobilities must be measured by experiment, as they are not subject to precise calculation. They will vary as the viscosity of the buffer solution changes, so they are specific for each buffer composition.

We can separate ions of different molecules by electrophoresis if they have different mobilities. Figure 12.38 is a schematic diagram of a CZE instrument. Two reservoirs connected by a length of capillary tubing are all filled with a buffer solution whose pH and electrolyte strength are adjusted to optimize the electrophoretic separation. A high voltage (typically 30-50 kV) is applied across the capillary between an anode and cathode in each of the reservoirs. Imagine that a narrow band of buffer solution containing a mixture of ions to be separated were somehow placed at the center of the capillary. Charge balance would require equal numbers of anions and cations. When the voltage was applied, anions would migrate to the anode, and cations to the cathode. Ions of greater μ_{eq} would move faster, and if the mobility differences among the components were great enough, they could be separated. Migration velocities are fairly slow, typically in the cm/min range, and if a long capillary were used, the experiment might take a long time. To measure both anions and cations, one would need a detector at each end, and ions of each charge would have only half the capillary length




FIGURE 12.38 Schematic of capillary zone electrophoresis apparatus. (Cazes, used with permission.)

to achieve separation. Note that the figure displays only one detector. If we introduced the sample mixture band at the left end of the capillary, and arranged for buffer to flow through it from left to right at a speed exceeding that of the greatest migration velocity of anions, then the cations would pass the detector first in order of their mobilities (fastest first). Following the cations, the anions migrating in a direction opposite to the faster buffer flow would pass the detector in inverse order of their mobilities. One detector gets them all, the sample is easily introduced at the end of the capillary, and we can choose the buffer flow to speed up or slow down the period of "elution" depending on how long we need the ions to remain migrating in the capillary to achieve a separation. The buffer can be made to flow toward the detector simply by raising the anode reservoir. Long (50-100 cm), narrow bore (50-100 μ m) fused silica capillaries are generally used for CZE. To obtain a desired buffer flow rate might require pressurizing the system. Adjustment and precise control of both voltage and pressure drop across the capillary would make for a more complex instrumental design, sacrificing the elegant simplicity of the system diagrammed in Figure 12.37. It turns out that there is a different and better way to induce buffer flow through the capillary.

One of the many useful features of fused silica capillary tubing is the ability of its surface silanol groups to lose H⁺ ions and form a chemically bound layer of negatively charged groups in aqueous solutions at pH above 2. When this happens, these excess bound negative charges are partially neutralized by tightly binding positive ions from the buffer electrolyte used in the CZE analysis. The rest of the excess negative surface charge is neutralized by the presence of an excess of cations in the **diffuse double layer** very close to the silica surface. Polarizing (adding charge to) an electrode in electrochemical techniques results in the establishment of both compact and diffuse electrical double layers at the electrode surface. The diffuse double layer cations are not tightly bound and can move in response to the applied electrophoretic voltage. Because they are in excess in this layer, more buffer cations are flowing toward the cathode than buffer anions towards the anode. This excess cationic flow in this layer drags the buffer solution as a whole towards the cathode. This motion is called the electroosmotic flow (EOF). Like the phenomenon of "osmotic pressure" established across semipermeable membranes, it arises from an imbalance of particles across a boundary, but the flow ends up being parallel to the boundary instead of across it, since the motion of interest is that of an excess of ions responding to a voltage gradient imposed along instead of across the surface. The thickness of the diffuse double layer which mediates this flow is inversely proportional to the ionic strength of the buffer. Changing the electrolyte composition of the buffer will affect and allow control of the velocity of the EOF. Lowering the pH of the buffer will decrease the dissociated silanol surface charge density and decrease the velocity of the EOF. The origin of the EOF is illustrated in Figure 12.39. Note that one siloxyl group lacks a tightly bound counter cation. It is the excess of mobile countering cations in the layer just below the "plane




FIGURE 12.39 Diagram showing origin of electroosmotic flow (EOF). (Cazes, used with permission.)

of shear" in the diagram that provides the "handle" for the applied voltage to move the buffer through the column. This mechanism is sometimes referred to as **electrokinetic pumping**, in contrast to the pressure driven, **hydrodynamic flow** produced by pumps in HPLC systems. For the EOF, we can write an equation similar to Equation 12.8, relating the velocity of the electroosmotic flow (μ_{eo}) to the electric field E:

$$(12.9) u_{eo} = \mu_{eo} E$$

where μ_{eo} is defined as the **electroosmotic mobility**. We can then define and measure an **apparent mobility** of an ion, which is the sum of μ_{eo} and μ_{eo} :

(12.10)
$$\mu_{app} = \mu_{ep} + \mu_{eo}$$

 μ_{ep} is positive for cations and negative for anions, so μ_{app} will be greater or less than μ_{eo} . The apparent mobility of an ion and the electrophoretic mobility can be calculated according to:

$$\mu = \frac{L_{\rm d}/t_{\rm x}}{V/L_{\rm t}}$$

where $L_{\rm d}$ and $L_{\rm t}$ are the length of the column from injector to detector and the total length of the column, respectively. In CZE, the detector usually is before the end of the capillary, as illustrated in Figure 12.38. V is the total voltage across the capillary. To measure $\mu_{\rm app}$, the time for the ion to migrate from the injector end of the column to the detector is substituted for t_x . To measure $\mu_{\rm eo}$, one substitutes in the equation the time for a neutral species capable of giving a detector response (e.g., a UV absorbing compound) to make the same journey. From these two measurements, the electrophoretic mobility $\mu_{\rm ep}$ can be calculated by taking their difference.

There is an additional important distinction between these two modes of inducing liquid flow within a narrow capillary. Figure 12.40(a) illustrates the profile of flow velocity across a capillary driven by EOF. Except at points very close to the inner wall, it is uniform.




FIGURE 12.40 Comparison of electroosmotic and hydrodynamic flow profiles: **(a)** uniform electroosmotic flow (electrically driven) and **(b)** laminar, parabolic, hydrodynamic flow (pressure driven). (Cazes, used with permission.)

In contrast, pressure-driven hydrodynamic flow is affected by shear forces varying with distance from the center to the wall, resulting in a parabolic, laminar flow velocity profile, Figure 12.40(b). Band spreading resulting from analyte diffusion across this hydrodynamic flow profile will be absent in electrokinetically pumped systems. The friction between solvent molecules and ions being pulled through them by the applied voltage, which creates both the EOF and the electrophoretic separation, can raise the temperature of the buffer by a process called **Joule heating**. This is closely analogous to the heating produced by a current of electrons passing through a resistor in an electrical circuit. In CZE, this heat is dissipated by flowing the short distance to the wall of the capillary. If a significant temperature gradient builds up across the radius of the capillary, the higher central temperature will cause the buffer viscosity to become lower at the center than at the capillary wall, across which the heat must be dissipated. This would act to disrupt the uniform EOF flow profile, making it resemble the pressure driven laminar flow profile, and introduce band broadening. The high thermal conductivity of fused silica helps alleviate this, and placing the capillary in a cooling bath may retard the onset of the problem, but this phenomenon places a limit on the inner diameter of capillaries that can be used to full efficiency. Typical ranges are 25-100 µm; larger diameters could not escape the bad effects of Joule heating.

Although we have emphasized that the fundamental principle of electrophoretic separation is different from that of chromatography, there are many similarities in the appearance of the separation. There is sample injection, flow of a "carrier fluid" along a column, similar detectors employed near the end of the column, and separated compounds being displayed as peaks emerging at characteristic times. Similar formulas can be used to describe the resolution of separations, and to characterize the separation efficiency of the system in terms of theoretical plates. It is instructive to revisit the Van Deempter equation (Equation 10.10) for evaluating the impact of various processes on the height equivalent to a theoretical plate (*H*) described in Section 10.8. Recall that minimizing this maximizes efficiency (i.e., permits more plates for a given column length).

$$H = A + \frac{B}{u} + Cu$$

Since CZE is an open tubular technique, there is no multipath A term. Since CZE is actually not a chromatographic technique, there being no stationary phase, there is no mass transfer C term. Recall that this is actually a term which combines several processes; namely, transfer in the mobile phase across the laminar flow velocity gradient, which we have shown is suppressed in a properly operated CZE system, and transfer to and from the stationary phase, of which there is none in CZE. The only remaining source of band broadening is the longitudinal diffusion term B. This is proportional to the diffusion coefficient of the analyte in the carrier fluid, and varies inversely with the size or mass of the analyte molecule. Consequently, very low values of H and correspondingly high plate counts are obtained for large molecule separations. Plate counts up to 500,000 are routinely achieved for large molecule separations by CZE, which is an order of magnitude better than those of which HPLC is capable. Biological macromolecules such as large peptides or proteins, which have multiple sites for bearing charge as a result of adding or abstracting H+ by pH variation, may often be separated with great efficiency by CZE, provided a pH can be found at which one charge predominates, and which is compatible with good electrophoretic operation. It can be demonstrated that the number of plates in a CZE separation of a given compound is related only to the voltage V across the capillary, the electrophoretic mobility, μ_{ep} , and diffusion coefficient, *D*, of the ion, according to Equation (12.12):

$$(12.12) N = \frac{\mu_{\rm ep}V}{2D}$$

Contrary to our experience with chromatographic separations, N is independent of column length. We would like to operate at higher voltages, but we will be limited by the onset of Joule heating, which is proportional to the field E. For a given applied voltage V, E is

proportional to V/L. We must increase column length and analysis time to keep E below the value at which Joule heating degrades resolution. This is the reason for using longer columns. One can see that larger ions, which have lower values of D, will achieve greater plate counts. This is why CZE is often superior to HPLC for separations of charged biological macromolecules.

If the absolute value of μ_{ep} is less than μ_{eo} for all anions and cations in a CZE separation, then they may all be observed whether the applied voltage directs EOF either to the cathode or anode. If not, then those migrating in a direction opposite to the EOF at greater than its velocity will never reach the detector. It may then be necessary to do a second electrophoretic separation with the electrode polarities reversed to measure these. An alternative is to reverse the direction of the EOF while maintaining the same electrode polarity. To do this, one must replace the siloxyl negative charges fixed to the column wall with bound positive charges. This may be accomplished by adding a cationic surfactant such as cetyltrimethyl ammonium ion $[n-C_{16} H_{33}N(CH_3]_3^+]$. The long C_{16} hydrocarbon tails attract one another and form a bilayer sandwich structure with the hydrophilic quaternary ammonium cation portions on the outer sides and the nonpolar organic chains grouping together on the inside. The forces driving this are twofold: cation charge repulsion and Van der Waals attractions of the adjacent nonpolar hydrocarbon chains. One layer of positive charges is fixed by electrostatic attraction to the negative siloxyl groups on the silica wall, and the buffer is presented with the other layer of positive charges. Now, excess ions in the diffuse double layer will be anions instead of cations, and the EOF will move in the opposite direction. This is illustrated in Figure 12.41.

The ability of some organic molecules to selectively bind to the silica surface in this fashion can become a problem if they are in fact the analytes one is trying to separate and measure by CZE. Such unintended "wall effects" superpose an adsorption chromatographic mechanism on the electrophoretic separation. If the binding is very tight, one may initially fail to see some components migrate to the detector, only to have them begin to appear as peaks with degraded resolution and shifting migration times, as successive injections result in saturation of such "binding sites". For some applications, it is necessary to pre-coat the capillary with a covalently bonded hydrophilic polymer to suppress this interference. Such complexities make developing CZE separations less simple than one might naively predict.

12.6.2 SAMPLE INJECTION IN CZE

Sample injection in CZE can be much simpler than in capillary GC or capillary HPLC. The injection volumes are much smaller, on the order of nanoliters. One wishes to introduce a plug or zone of analytes dissolved in aqueous buffer into the injection end of the capillary. This can be done in two ways: hydrodynamic injection or electrokinetic injection. For **hydrodynamic injection**, one often simply removes the injection end of the capillary




FIGURE 12.41 Use of cationic surfactant to reverse electroosmotic flow: **(a)** normal EOF toward cathode (no surfactant) and **(b)** reversed EOF toward anode (cationic surfactant bilayer). (Katz et al., Used with permission.)

from its buffer reservoir, and places it briefly in the sample buffer, which is elevated sufficiently above the detector end reservoir, and hydrostatic pressure causes sample solution to flow into the capillary. The volume of the sample flowing in will be given by:

(12.13)
$$Volume = \frac{\Delta P\pi d^4t}{128 \eta L_t}$$

where ΔP is the pressure difference between the ends of the capillary; d, its inner diameter; L_t , its total length; t, the time it spends in the sample solution; and η , the viscosity of the sample solution. If the capillary is too narrow and/or too long, it may be necessary to apply additional pressure at the injection end or suction at the detector end in order to introduce a sufficient volume in a reasonable time. For **electrokinetic injection**, one places the injector end of the column into the sample solution and applies a voltage across the column (for this, we will need to introduce an electrode into the sample solution). The sample ions will enter the column both by migration (at rates which will vary with their electrophoretic mobilities) and by entrainment in the EOF (at a constant rate for all ions). This difference in sample amount will cause problems in quantitative CZE work, so hydrodynamic injection is preferred in that case. In the capillary mode called capillary gel electrophoresis (Section 12.7.2), the gel in the capillary is much too viscous to employ that injection technique, so electrokinetic injection must be used.

To introduce a sufficient sample volume into a narrow CZE capillary, one might produce a band of sample much longer than the optimum bandwidth which would be implied by the number of plates calculated from Equation 12.12 operating on an ideally narrow injected band. This is an example of an "extra column band-broadening effect". It would be desirable to have a mechanism for "focusing" the injected sample mixture into a very narrow band, as happens in chromatographic injections when the analytes riding the mobile phase into the column are arrested at its head by the stationary phase, when k' is sufficiently high. Just such a focusing effect can be achieved in CZE if one employs a buffer electrolyte concentration in the sample which is much *lower* than that in the separation buffer. The conductivity of this more dilute sample plug is much lower (thus its resistance is higher), and since the ion current through the system must be constant, by Ohm's Law (E = IR), the field across the sample plug must become proportionally larger. The increased field causes ions in the sample plug to migrate more rapidly to the end nearest to the electrode of opposite charge. When they reach this interface, they slow down and continue to move with the velocities characteristic of the separation buffer. This process is called **sample stacking**, and it is illustrated in Figure 12.42




FIGURE 12.42 Sample stacking of anions in sample plug toward anode. (Katz et al., Used with permission.)

for anions in a sample plug. Cations would "stack" in a similar fashion at the opposite end of the plug. The result is to quickly produce two narrow bands of either cations or anions, separated by the width of the sample injection plug, which can then experience the full separation capability of the CZE process.

12.6.3 DETECTION IN CZE

In contrast to detectors used in GC and HPLC, those in CZE usually are placed at some point before the end dipping into the capillary reservoir, as indicated in Figure 12.38. Optical detectors are similar in design to HPLC detectors, but with modifications of the detector cell portion to fit the much smaller peak volumes encountered in CZE. For UV absorption or fluorescence detectors, the detection cell is often a portion of the capillary column itself. The polyimide protective coating of a short section of the fused silica column is removed, and the beams of the spectrometric detectors are focused with condensing optics on this small volume. This has the advantage of using a detector cell volume which is similar to the very small band volume of highly resolved CZE peaks. The very short path length of the beam across the diameter of the CZE capillary decreases sensitivity. This may be improved by bending the capillary at right angles or fitting a capillary length between two 90° fittings for a short distance approximating the bandwidth of a narrow peak, and introducing the illuminating beam lengthwise down the axis of this segment through optically flat windows. Another approach to increase the light path length is to coat the outside of a short length of the capillary with reflective silver beneath the protective polyimide coating. Light entrance windows are cleared at either end on opposite sides of this segment. Light enters one window at a slight angle to perpendicular to the capillary such that it is reflected multiple times back and forth across the capillary before exiting the other window of the detector.

Miniature amperometric or conductometric detectors can be introduced into the capillary, by plating the appropriate electrodes in the inside of the capillary walls. It is often necessary to employ a porous glass or graphite joint between the capillary containing the detector electrodes and the end of the capillary in the detector end electrode reservoir, in order to isolate the detector from the high voltage used to power the electrophoretic separation.

The extremely low flow rates of buffer in a CZE capillary separation make it especially easy to interface to a mass spectrometer by using an ESI interface for detection of large multiply charged biological macromolecules. Instead of a CZE detector end reservoir with its electrode, the voltage at that end is applied through a metallized coating on the inside and outside of the capillary end. This voltage also functions to charge the ions and droplets that exit the tip of the capillary end, and to form the "electrospray" with its process of coulomb explosion and charge transfer, yielding molecular ions suitable for MS analysis.

Because ions in CZE migrate past spectrometric or electrochemical detectors at different rates according to their electrophoretic mobilities, they pass through the detector zone at different rates, unlike chromatographic analytes, which enter the detector cell from the column at the constant rate of the mobile phase velocity. For concentration detectors, the peak areas are therefore independent of retention or elution time in chromatographic systems. However, this is **not** true in CZE. The same concentration of material giving the same response will pass more slowly through the detection region of the capillary if it has a lower migration velocity, and therefore will integrate over time to a larger peak area value. If one is quantitating against an IS of different mobility, and separation conditions and "apparent migration times" shift between the time a calibration run is made and an unknown sample quantitation run is made, calibration based on peak area ratios will become invalid.

Because CZE is a method for separating and measuring ions, like IC, considerations of charge balance make it particularly suitable for use of the method of indirect detection, as described at the end of Section 12.2.1.

12.6.4 APPLICATIONS OF CZE

CZE is useful for a wide range of ion sizes, and is particularly useful for small volumes of small organic and inorganic ions. Its inherent smaller sample size requirements (nL instead of μ L) make it particularly useful for sampling small volumes, even ones as small as the fluids inside a single biological cell. In its simplest form, the equipment is much less expensive than comparable IC or HPLC instruments. The interaction of so many variables: pH, electrolyte concentration, adsorption effects, and so on, on both the electrophoretic mobility and the electroosmotic mobility, make development and optimization of a CZE method for a particular separation less intuitive than for IC or HPLC. Once the CZE procedure is refined, it may be more cost effective to run than the corresponding chromatographic technique. It is even possible to separate and quantitate electrically neutral species using a CZE apparatus by combining it with a chromatographic partitioning process.

12.6.5 MODES OF CE

There are several different modes of conducting electrophoresis in capillary columns. We have just discussed at length the basic one, CZE, which is conceptually the simplest. It is conducted with a liquid buffer of uniform composition of electrolyte concentration and pH level. There are more complex versions, in which the buffer liquid is enmeshed in a porous gel of hydrophilic polymer, or the concentration or the pH of the separation buffer is not constant along the length of the column, leading to variations in the migration velocities of individual ions as the separation proceeds. Variations include capillary gel electrophoresis (Section 12.7.2), capillary isoelectric focusing, and micellar electrokinetic capillary chromatography. Discussion of these more advanced modes can be found in texts by Guzman; Landers; Camilleri; Robinson et al., and others listed in the bibliography.

12.7 PLANAR CHROMATOGRAPHY AND PLANAR ELECTROPHORESIS

If the stationary phase for a chromatographic separation, or a gel for an electrophoretic separation, is bound to a surface, it is possible to spot a sample on to one corner of such a flat plate or slab, and perform a separation directed along one edge, spreading out the bands separated by chromatographic partitioning or electrophoretic migration along that edge (without eluting them off the surface or through a detector). The linear array of separated bands can then be subject to another separation process using different chromatographic mobile phase or electrophoretic buffer parameters directed at right angles to the first separation. Bands which remained unresolved in the first step may be further separated in this new direction, and the final product is a surface covered with many separated spots, which may be scanned by some detector, or reacted to visualize the separated components. These basic principles were outlined in Section 10.3.

12.7.1 THIN LAYER CHROMATOGRAPHY (TLC)

Parallel 1D TLC Separations. In TLC, particles of stationary phase such as silica or alumina for a normal phase separation, or large diameter particle (10-100 μ m) RP-HPLC type packing, are coated and bound as a thin layer to a square planar supporting **plate**, usually of glass. A liquid mobile phase is placed in the bottom of a TLC **tank** or **chamber**, a rectangular glass tank with a tightly sealing glass plate top, and with dimensions that will contain the TLC plate when it is propped up in the tank at an angle inclined a little from the vertical. The tank contains an internal lip above the solvent reservoir or separating off an unfilled part, so that initially the plate can be set on it out of contact with the liquid to equilibrate with the solvent vapor. The mixtures for separation are **spotted** on the plate along an origin line parallel to one edge, at a distance sufficient for the spots to lie above the level of the mobile phase solvent when the edge with the sample spots is lowered into the reservoir. This can be done




FIGURE 12.43 TLC plate in enclosed developing tank.

crudely by using a glass capillary to pick up the sample and transfer it to the plate. For quantitative work, a measured volume is slowly put on the plate using a microliter syringe, allowing time for solvent to evaporate during the application in order to minimize spot spreading in the thin layer. Figure 12.43 displays a side view of a TLC plate in a sealed tank. Note the three numbers (1-3) within the sealed tank in the figure. Solvent vapors from the liquid in the bottom equilibrate with the headspace above it (Figure 12.43, point 1). Capillary attraction to the closely spaced stationary phase particles comprising the thin layer causes the mobile phase solvent to move up the plate. The leading edge of this flow is called the solvent front. Above the solvent front, the thin layer remains conditioned by solvent vapor diffusing into it (Figure 12.43, point 2). There will be no net evaporation from the solvent flowing up the plate (Figure 12.43, point 3), because the closed system establishes an equilibrium vapor pressure. Control of these variables ensures reproducible mobile phase flow in the system.

Multiple spots (e.g., standard mixtures, a blank, and several unknown samples) can be chromatographed in parallel. This facilitates direct comparisons of retention relative to the advance of the solvent front, and comparison of separated component spot densities for estimating relative quantities. The same separation principles apply as in HPLC column chromatography. Analytes must not have significant volatility, as there is no column to contain them. Figure 12.44 displays three stages in the process of obtaining a TLC chromatogram.




FIGURE 12.44 Steps in development of a TLC chromatogram.




FIGURE 12.45 Definition and calculation of retention factor (R_f) and plate number (N) from a developed TLC chromatogram.

The left-hand side view shows the initial, somewhat ragged line of spotted samples. If a strong elution solvent is used, initial ascent of its solvent front through the sample spots moves them to a line precisely at the solvent front, and compacts the spots into narrow elongated bands. This is called **beginning development** (center panel). As **development** continues, either with the beginning solvent or a weaker one which can discriminate better among the analytes, the bands separate until the solvent front has run up most of the plate (right-hand side panel). This is the TLC chromatogram. The various distances of the separated bands between the start point origin and the solvent front (which the analyst can see and mark when removing the plate before drying it to remove solvent) and the bandwidths are measured. The $R_{\rm f}$ values (corresponding to relative retention time in column chromatography), and the theoretical plate number, $N_{\rm f}$ are calculated as outlined in Figure 12.45.

Detection in TLC. The separated spots or bands may be detected in a variety of ways. In contrast to column chromatography, they remain on the stationary phase and are not eluted off it into a separate detection region. Detection is by scanning or imaging the "developed" plate. It is critical to understand that in the TLC context, development refers to the chromatographic separation process, and not the subsequent process of making the separated spots visible, as is done when one "develops" a latent image on a planar photographic film. If the spots are colored or opaque, imaging may be as simple as looking at them by eye. If the analytes are colorless, but are fluorescent under UV illumination, the dried, developed plate may be place in a darkened box, illuminated with UV, and the fluorescent spots imaged by eye. This can be done more precisely by using a plate position scanning (as opposed to wavelength scanning) fluorescence spectrometer. Fluorescence can be used as an indirect **detection method** if the TLC plate contains an "Flayer" incorporating a bound phosphor or fluorescent indicator such as zinc sulfide. Analyte spots containing compounds such as most organic aromatic compounds and those with conjugated double bonds, which are colorless in the visible range, but which absorb Hg-lamp UV at around 254 nm, will absorb the UV and **quench** the fluorescence of the plate at the position of their developed spots.

Some reagents or reactions will visualize almost all separated analytes. Examples of such **universal detection reagents** are: (a) iodine vapor, which will reversibly stain almost all analyte spots except some saturated alkanes, forming a dark brown color and (b) irreversible charring with heating in the presence of sulfuric acid or a mixture of 8 % phosphoric acid and 3 % copper sulfate. At the other end of the reagent spectrum are **selective detection reagents**, such as: (a) ninhydrin for α -amino acids, (b) 2,4-dinitrophenyl-hydrazone·HCl to produce orange zones by reaction with aldehydes, and (c) enzyme reactions with a substrate to form a colored product to generate uniform color over the plate except on bands containing biologically active compounds which act to block the enzyme function (e.g., cholinesterase inhibitors such as organophosphorus pesticides). These reagents are generally applied to the plates in one of two fashions: (a) **dipping** them for a set period of time in a solution of the reagent or (b) **spraying** solutions of the reagents as an aerosol mist from a handheld




FIGURE 12.46 Diagram of development of a 2D TLC chromatogram.

atomizer. Special dipping chambers can automatically perform a reproducibly timed immersion and gentle agitation of the plate. Dipping yields the best reactions for *quantitative* purposes. Spraying must often be done in a contained volume TLC spray chamber vented to a fume hood, in order to avoid exposure to hazardous solvent vapors. A complete listing of spray and dipping reagents can be found in the book by Bruno and Svoronos. Intermittent spraying with intervals for drying will minimize band spreading due to mobilization and expansion of the spots from accumulated spray solvent. TLC plates and slab gels can now be sampled and interfaced to MS by DESI or LAESI (Chapter 9), and other devices are marketed to dissolve analytes from locations on these 2-D media, and elute them to an MS ion source using a variety of LC-MS interfaces. All these move the plates in an X – Y plane to locate selected spots, or even to scan the whole plate in a raster pattern.

TLC separations rarely approach the resolution or quantitation accuracy of chromatographic instruments employing the sequence of injection, separation on a confined capillary column, and separate detection in a specially designed detector cell. For applications which do not require such precision, TLC's simplicity and the low cost of materials and equipment recommend it, especially for initial screening applications.

2D Separations using TLC (2D-TLC). Additional resolution of components which are incompletely separated by 1D development may be obtained by rotating the plate 90°, and redeveloping the single line of partially separated components of a single mixture sample originally spotted in one corner. For the second development, a different mobile phase solution having different selectivities for the partially separated compounds is used. This is illustrated in Figure 12.46. Only one sample can be separated on each plate. This 2D-TLC analysis is an example of a 2D separation employing a 2D stationary (i.e., planar) phase. This relatively simple trick can be contrasted with the extremely complex 2D column chromatographic separations employing modulator devices interfacing columns of two different selectivities and analysis speeds (e.g., comprehensive 2D-GC).

12.7.2 PLANAR ELECTROPHORESIS ON SLAB GELS

1D Planar Gel Electrophoresis. Prior to the development of CZE, the primary application of electrophoresis was for large biological macromolecule separations on planar gels. The gels were supported on glass plates not unlike the particles in the thin layer of a TLC plate. The separation buffer was applied to a porous hydrophilic gel matrix. This mixture retards dispersion of the analyte by diffusion and convection, and such a cast slab gel is easier to manipulate in the instrument and to place its opposite edges into the electrode reservoirs. The gels are commonly produced by polymerizing acrylamide (CH2 = CH—CO—NH2) in the presence of a cross-linking agent, or using other hydrophilic polymers such as agarose or polyethylene glycol. Increasing the degree of cross-linking reduces the size of the pores in the gel through which the buffer solution diffuses and the charged macromolecules and electrolyte migrate. It was found that the separation mechanism for macromolecules in such gels is actually a combination of differing migration velocities due to the charge and hydrodynamic radius of the ions, and a size discrimination effect due to the sieving action of the pores on

the ions. This sieving action is more effective than the differences in electrophoretic mobility in achieving separations of macromolecules such as oligonucleotides, DNA fragments, and proteins having similar total charges. While such gels can be formed within capillaries (called CGE, capillary gel electrophoresis), a cross-linked gel in CGE can be used only until clogging or other problems render it unusable, as it is nearly impossible to remove such a so-called chemical gel from the capillary by flushing. If the capillary is filled with a physical gel, formed by filling it with long linear polymer chains which produce pores by entangling randomly, this may be easily flushed and replaced by fresh physical gel material as needed.

It was easier to prepare cross-linked chemical gels on an open planar surface than in narrow capillaries, and to remove the gel from the support plate to prepare a fresh slab gel for a new analysis. Electrophoretic separations of multiple samples in 1D could be performed and easily visualized and compared. This was the standard tool for biochemists to compare distributions of peptides from enzymatic protein digests, or DNA or RNA fragments. Comparison of multiple lanes of 1D separations enabled easy illustration and identification of abnormal distributions, or the detection of the presence of unusual fragments, which might, for example, be indicators of a mutant form or a disease state. Such patterns looked similar to the diagram of a developed TLC plate shown in the right-hand panel of Figure 12.44. Thousands of photos of such multilane slab gel electropherograms grace the pages of the molecular biology literature.

2D Planar Gel Electrophoresis. Many DNA, RNA, or protein digests can contain hundreds to thousands of fragments, and extracts of particular tissues or cell types may contain similar numbers of proteins. 1D planar gel electrophoresis could not possibly resolve all of these. The same principle used with 2D-TLC was applied. There are many possible combinations of separation conditions which might be applied to sequential developments of a sample on a planar gel, to produce an array of hundreds of resolved spots. One particular sequence is a standard for **protein peptide mapping**. This procedure is so well standardized, and the reagents and instrumentation so widely commercialized, that such "maps" of the distribution of peptides as a particular array of separated spots on a 2D-gel, are archived in international computer-searchable databases, enabling researchers to submit new patterns which they have characterized, or to determine if a new pattern has already been described by others. This is analogous to the huge databases of full-scan mass spectra which help to identify unknown spectra by library searching. Similar libraries of the distributions of cell proteins are compiled by very similar procedures.

The most common standard protein or peptide mapping experiment employs first a slab gel electrophoretic separation employing **isoelectric focusing** (IEF) to spread the amphoteric analytes across one axis of the plate in order of their **isoelectric point pH** (pl) values. These partially separated components are then subjected to **sodium-dodecylsulphate-polyacryamide gel electrophoresis** (SDS-PAGE) separation in a direction at right angles to the initial IEF separation. The proteins are **denatured** (i.e., their specific tertiary folded structure is disrupted by elevated temperature or high ionic strength solution), and the micelle-forming SDS (at a concentration well below the critical micelle concentration) will bind an amount of anionic SDS proportional to the size of a denatured protein. The resulting protein-SDS complexes have approximately constant charge-to-mass ratios and therefore identical electrophoretic mobilities. In the sieving gel medium, the complexes migrate proportionally to their effective molecular radii and to the protein molecular weight. Thus, the 2D planar electrophoresis separation initially sorts the proteins (or peptides) by a charge-related parameter of their isoelectric points, and secondly, by the size-related parameter of the SDS-PAGE sieving process.

The 2D-SDS-PAGE separation described results in a planar array of separated compounds. If these are unknown proteins (perhaps just one or a few which interrupt a standard pattern, and may signal a mutant form or an abnormal biological state), the spots of interest may be cut out or dissolved out of the gel. The isolated spot can be subjected to tryptic digest, the peptide digest mixture separated by capillary HPLC, and the separated peaks characterized, and if necessary, sequenced by ESI-MS and ESI-MS-MS. If the 2D separation is of peptides from a single protein in a peptide mapping experiment, the developed slab gel may be put on an automatically positioned stage which will place each spot at the laser target point of a MALDI-TOF-MS, which may obtain enough information on each peptide to identify it based

on archival library lookup and matching. The plate positioning engine and the MALDI-TOF operate so quickly to acquire data, that for gel plates containing very large numbers of closely resolved components, it may be more efficient to sample the entire plate surface at points in a closely spaced grid, store all the data in a computer, and have it automatically processed. Pause for a moment to contemplate and marvel at the number of powerful separation and spectral characterization techniques that are being interfaced, automated, and having their output processed by complex computer algorithms in such an instrument. This melding of many instrumental techniques results in systems being successfully marketed today to support the enormous demands for analytical information in the disciplines of genomics, proteomics, and a burgeoning list of other "-omics".

PROBLEMS AND EXERCISES

- 12.1 Compare packed column LC, capillary column LC, and capillary zone electrophoresis (as best, intermediate, poorest, or inapplicable for the following categories)
 - a. Analyte capacity
 - b. Highest number of theoretical plates for large molecule separations
 - c. Suitability for separating charge neutral compounds
 - d. Ability to separate anions and cations in a single run
 - e. Suitability for analyzing 50 μL sample of mix of low MW alcohols
 - f. Suitability for analyzing 10 μ L sample of mix of low MW alcohols
 - g. Suitability for analyzing 10 μ L sample of peptides
- 12.2 a. List advantages and disadvantages of presence of free silanol groups on silica surfaces for applications in liquid phase separations.
 - b. How may the disadvantages be suppressed?
 - c. How may the advantages be enhanced?
- 12.3 Describe for the following HPLC procedures: (1) What is meant by? (2) What is the purpose of? (3) How is it done?
 - a. **Degassing** the mobile phase
 - b. **Filtering** the mobile phase
 - c. **Modifying** the mobile phase
 - d. **Endcapping** the stationary phase
 - e. Pulse-dampening the mobile phase
 - f. Introducing a Guard column
 - g. Introducing a **Suppressor column**
- 12.4 Describe three ways in which an HPLC support particle differs from one used in packed column GC.
- 12.5 Describe the primary purpose and advantages of using the following columns in HPLC:
 - a. Silica spheres with bonded organic substituents
 - b. Monolithic columns
 - c. Resin polymer spheres
 - d. Polyacrylamide gels of varying pore size
 - e. Zirconia spheres with bonded organic substituents
 - f. Bare silica spheres
 - g. Resin spheres with attached COOH groups
 - h. Silica spheres with attached latex coating with bonded —SO₃H groups
 - i. Resin spheres with bonded $-N(CH_3)_3^+$ groups
 - j. Completely endcapped C18 bonded silica
- 12.6 Answer questions (i) and (ii) for the following analyte mixtures:
 - a. A mixture of styrene-vinylbenzene polymer chain lengths
 - b. Organophosphorus pesticides in urine
 - c. Polynuclear aromatic hydrocarbons in hexane
 - d. Rare earth element ions in acidic aqueous solution
 - e. Peptides from a tryptic digest
 - f. A partially racemized, optically active, drug molecule containing phenolic groups
 - g. Isolation of a single antibody protein from a preparation of disrupted cells
 - h. A mixture of hydrocarbon ethers

- i. A mixture of polysaccharide polymers (e.g., starches or sugars)
- j. A mixture of inorganic halides and oxyhalides
- k. A preparative extract of a mixture of spice essences from leaves
 - i. Select one or more suitable liquid phase chromatographic or electrophoretic separation procedures from Sections 12.1-12.7.
 - ii. Select one or more suitable detectors and explain why.
- 12.7 Draw diagrams of the structures at the atomic level of the following silica surfaces:
 - a. Silica in aqueous solution at pH 1
 - b. Silica in aqueous solution at pH 9
 - c. An ODS-silica, bonded HPLC phase (indicate no. of C atoms n, by C_n)
 - d. An endcapped, octyl bonded silica HPLC phase
 - e. A silica surface with an additive which reverses electroosmotic flow
 - f. A silica surface treated to suppress electroosmotic flow
- 12.8 Using the style of the diagram of the six-port rotary HPLC injector valve (Figure 12.6), draw two diagrams showing the flow through the injection loop, the valve, and the column during the load and injection positions.
- 12.9 Using the information in Sections 12.1.4 and 12.1.6, construct a table contrasting the properties of various LC and CE detectors, indicating relative sensitivity, compound selectivity, gradient compatibility, buffer salt and pH compatibility, ability to extract analyte structural information, and mass or concentration mode of detection.
- 12.10 Contrast guard and suppressor columns with respect to their purpose, their position relative to the separation column, and the reason that pellicular packings are often desirable for use in each.
- 12.11 For a normal phase or reversed phase separation predict the elution order of:
 - a. *n*-octane, *n*-octanol, naphthalene
 - b. ethyl acetate, diethyl ether, nitrobutane
- 12.12 In HPLC:
 - a. Why is high pressure required?
 - b. Why are stationary phases bonded?
 - c. Why are supports endcapped?
 - d. Why are the buffers used usually at pH between 2 and 8?
- 12.13 In GC a plot of the Van Deempter equation is shaped like a severely distorted U. In HPLC using 3 μ m particles its shape is more like the letter "L". Explain.
- 12.14 Describe three different modes of use for SDS to change and improve separations in chromatography and electrophoresis.
- 12.15 In capillary electrophoresis, what is the effect on the electroosmotic flow of:
 - a. Increasing buffer pH
 - b. Increasing buffer concentration
 - c. Increasing the applied voltage
 - d. Increasing the capillary length for a constant applied voltage
 - e. Endcapping silanol groups on the silica capillary surface
- 12.16 In ion chromatography:
 - a. How does one increase the exchange capacity of the stationary phase?
 - b. Is the exchange group charge on the suppressor column the same or opposite that on the separating column? Explain why.
 - c. Why and how does one regenerate the separator column?
 - d. Why and how does one regenerate the suppressor column?
 - e. Describe how to regenerate the suppressor continuously.
- 12.17 Describe the instrumentation and separation media you would choose for:
 - a. Separation of amino acids by:
 - i. Ion exchange chromatography
 - ii. Reverse phase HPLC of derivatives
 - b. Separation of proteins by:
 - i. Size exclusion chromatography
 - ii. Capillary gel electrophoresis
 - iii. 2D -IEF -SDS-PAGE

- 12.18 What is the function of:
 - a. Crosslinked polyacrylamide in size exclusion chromatography?
 - b. Crosslinked polyacrylamide in SDS-PAGE planar electrophoresis?
 - c. Uncrosslinked polyacrylamide in rapid DNA sequencing by CGE?
 - d. Styrene-divinylbenzene copolymer resin in Ion Exchange Chromatography?
- 12.19 In what ways is supercritical fluid chromatography like LC?—Like GC? What are several advantages of the use of CO₂ as eluent in SFC?
- 12.20 a. How does the LC-APCI-MS interface differ from GC-CIMS?
 - b. In an orthogonal electrospray ionization MS interface, where does most of the LC mobile phase go?
 - c. Which LC-MS interface of (a) and (b) above works best for:
 - i. small molecules
 - ii. large molecules
 - iii. charged molecules (i.e., ions in solution)
 - iv. neutral (uncharged) molecules
- 12.21 Sample injection in CZE is by either hydrodynamic or electrokinetic injection
 - a. Which is better for capillary gel electrophoresis with physical gels?
 - b. Which is better for capillary gel electrophoresis with chemical gels?
 - c. How should an injection buffer differ from a separation buffer in order to achieve sample stacking? What is this, how does it work, and what are its benefits? Explain.
 - d. Neutrals move away from their position in the initial injection plug?
- 12.22 Consider the planar 2D separation illustrated in the last panel of Figure 12.46.
 - a. If this were on a TLC plate how do you think one might identify the separated spots by FAB-MS? By capillary LC-ESI-MS? Describe a proposed procedure.
 - b. If it were an SDS-PAGE separation on a slab gel, how do you think you might use MALDI-TOF-MS to identify the spots? Describe a proposed procedure.
- 12.23 "Literature Research" project. Choose one of the HPLC compound class applications in Section 12.1.7, and use the links in Appendix 12.A (textbook website) to download manufacturer's application notes, sample chromatograms, and suggested products for their analysis. Write a detailed experimental procedure to separate your chosen compounds.

BIBLIOGRAPHY

Anton, K.; Berger, C., Ed. Supercritical Fluid Chromatography; Marcel Dekker, Inc.: New York, 1998. Ardrey, R.E. Liquid Chromatography-Mass Spectrometry, An Introduction; Wiley: New York, 2003.

Bayne, S.; Carlin, M. Forensic Applications of HPLC, Taylor & Francis, Boca Raton, 2010.

Berthold, A, et al. Micellar Liquid Chromatography; Marcel Dekker, Inc.: New York, 2000.

Byrdwell, W.; Holcapek, M.E. *Extreme Chromatography*, AOCS Press, Taylor & Francis, CRC Press, 2011.

Bruno, T.J.; Svoronos, P.D.N., CRC Handbook of Basic Tables for Chemical Analysis – Data Driven Methods and Interpretation, CRC Press, Boca Raton, FL, 2021.

Camilleri, P. Capillary Electrophoresis: Theory and Practice; CRC Press: Boca Raton, FL, 1998.

Cazes, J. Encyclopedia of Chromatography; Marcel Dekker Inc.: New York, 2001.

Cohen, S.A.; Shure, M.R. Multidimensional Liquid Chromatography: Theory and Applications in Industrial Chemistry and the Life Sciences; Wiley, New York, 2008.

Corradini, D. Handbook of HPLC, 2nd edn; Taylor & Francis: Boca Raton, 2010.

Cunico, R.L. et al. Basic HPLC and CE of Biomolecules; Bay Analytical Laboratories, 1998.

Dong, M.W. Modern HPLC for Practicing Scientists, Wiley, New York, 2006.

Fritz, J.S.; Gjerde, D.T. Ion Chromatography; Wiley, New York, 2009.

Guillaume, D.; Venthey, J.L.; Smith, R.M.; Cahooter, D. *UHPLC in Life Sciences*, RSC Pub., Cambridge UK, 2012.

Guzman, N.A., Ed. Capillary Electrophoresis Technology; Marcel Dekker, Inc.: New York, 1993.

Hage, D.S.; Cazes, J. *Handbook of Affinity Chromatography*, 2nd edn; Taylor & Francis: Boca Raton, 2005.

Hahn-Deinstrop, E. *Applied Thin-Layer Chromatography—Best Practice and Avoidance of Mistakes*, 2nd; Wiley: New York, 2006.

Katz, E., et al., Eds. Handbook of HPLC; Marcel Dekker, Inc.: New York, 1998.

Kromidas, S. More Practical Problem Solving in HPLC, Wiley, New York, 2005.

Landers, J.P. Handbook of Capillary Electrophoresis; Marcel Dekker, Inc.: New York, 1997.

McMaster, M. HPLC: A Practical User's Guide, 2nd edn; Wiley: New York, 2006.

McMaster, M. LC/MS: A Practical User's Guide, Wiley, New York, 2005.

Meyer, V.R. Practical High-Performance Liquid Chromatography, 5th edn; Wiley: New York, 2010.

Niessen, W.M.A. *Liquid Chromatography – Mass Spectrometry*, 3rd edn; Taylor & Francis: Boca Raton, 2006.

Olsen, B.; Pack, B.W. *Hydrophilic Interaction Chromatography: A Guide for Practitioners*, Wiley, New York, 2013.

Pommerening, K., *Affinity Chromatography; Practical and Theoretical Aspects*; Marcel Dekker, Inc.: New York, 1985.

Robinson, J.W.; Skelly Frame, E.M.; Frame, G.M. *Undergraduate Instrumental Analysis*, 7th edn; Taylor & Francis: Boca Raton, 2014.

Scott, R.P.W. Chromatographic Detectors; Marcel Dekker, Inc.: New York, 1996.

Sherma, J.; Fried, B., Eds. *Handbook of Thin Layer Chromatography*; Marcel Dekker, Inc.: New York, 1996.

Dorn, S.B.; Skelly Frame, E.M. The Analyst, 119, 1687–1694, 1994.

Snyder, R.L., et al. Practical HPLC Method Development; Wiley: New York, 1997.

Snyder, L.R.; Kirkland, J.J.; Dolan, J. Introduction to Modern Liquid Chromatography, 3rd edn; Wiley: New York, 2009.

Spangenberg, B.; Poole, C.F.; Wiens, C. *Quantitative Thin-Layer Chromatography*, Springer VCH, Berlin, 2011.

Srinatava, M. High Performance Thin-Layer Chromatography, Springer VCH, Berlin, 2011.

Strengel, A. et al.; Modern Size-Exclusion Liquid Chromatography: Practice of Gel Permeation and Gel Filtration Chromatography 2nd edn. Wiley, New York, 2009.

Unger, K.K.; Tanaka, N.; Machtejevas, E. Monolithic Silicas in Separation Science Concepts, Wiley, New York, 2011.

Van Eeckhaut, A.; Michotte, Y. Chiral Separations in Capillary Electrophoresis, Taylor & Francis, Boca Raton, 2009.

Wang, P.G.; He, W. Hydrophilic Interaction Liquid Chromatography (HILIC) and Advanced Applications, Taylor & Francis, Boca Raton, 2011.

Wu, C.S., Ed. Handbook of Size Exclusion Chromatography; Marcel Dekker, Inc.: New York, 1995.

Electroanalytical Chemistry

13

Electrochemistry is the area of chemistry that studies the interconversion of chemical energy and electrical energy. Electroanalytical chemistry is the use of electrochemical techniques to characterize a sample. The original analytical applications of electrochemistry, electrogravimetry, and polarography, were for the quantitative determination of trace metals in aqueous solutions. The latter method was reliable and sensitive enough to detect concentrations as low as 1 ppm of many metals. Since that time, many different types of electrochemical techniques have evolved, each useful for particular applications in organic, inorganic, and biochemical analyses.

A species that undergoes reduction or oxidation upon application of a voltage or current is known as an **electroactive** species. Electroactive species in general may be solvated or complexed, ions or molecules, in aqueous or nonaqueous solvents and even in films. Electrochemical methods are now used not only for trace metal ion analyses, but also for the analysis of organic compounds, for continuous process analysis, and for studying the chemical reactions within a single living cell. Applications have been developed that are suited for quality control of product streams in industry, *in vivo* monitoring, materials characterization, and pharmaceutical and biochemical studies, to mention a few of the myriad applications. Concentrations as low as 1 ppm can be determined. By using electrodeposition and then reversing the current or potential, it is possible to extend the sensitivity limits for many electroactive species by three or four orders of magnitude, thus providing a means of analysis at the ppb level.

In practice, electrochemistry not only provides elemental and molecular analysis, but also can be used to acquire information about equilibria, kinetics, and reaction mechanisms from research using polarography, amperometry, conductometric analysis, and potentiometry. The analytical calculation is usually based on the determination of current or voltage, or on the resistance developed in a cell under conditions such that these measurable quantities are dependent on the concentration of the species under study. Electrochemical measurements are easy to automate because they are electrical signals, for which very sensitive measurements may be made. The equipment is often far less expensive than spectroscopy instrumentation. Electrochemical techniques are also commonly used as detectors for LC (Chapter 12).

13.1 FUNDAMENTALS OF ELECTROCHEMISTRY

Electrochemistry is the study of **reduction-oxidation** reactions (called **redox** reactions) in which electrons are transferred from one reactant to another. A chemical species that loses electrons in a redox reaction is **oxidized**. A species that gains electrons is **reduced**. A species that oxidizes is also called a **reducing agent** because it causes the other species to be reduced; likewise, an **oxidizing agent** is a species that is itself reduced in a reaction. An oxidation-reduction reaction requires that one reactant gain electrons (be reduced) from the reactant which is oxidized. We can write the reduction and the oxidation reactions

separately, as half-reactions; the sum of the half-reactions equals the net oxidation-reduction reaction. Examples of oxidation half-reactions include:

$$Fe^{2+} \rightarrow Fe^{3+} + e^{-}$$
 $Cu(s) \rightarrow Cu^{2+} + 2e^{-}$
 $AsH_3(g) \rightarrow As(s) + 3H^{+} + 3e^{-}$
 $H_2C_2O_4 \rightarrow 2CO_2(g) + 2H^{+} + 2e^{-}$

Examples of reduction half-reactions include:

$$Co^{3+} + e^{-} \rightarrow Co^{2+}$$

$$(IO_3)^{-} + 6H^{+} + 5e^{-} \rightarrow \frac{1}{2}I_2(s) + 3H_2O$$

$$Cl_2(g) + 2e^{-} \rightarrow 2Cl^{-}$$

$$Ag^{+} + e^{-} \rightarrow Ag(s)$$

If the direction of an oxidation reaction is reversed, it becomes a reduction reaction; that is, if Al^{3+} accepts 3 electrons, it is reduced to Al(s). All of the reduction reactions are oxidation reactions if they are written in the opposite direction. Many of these reactions are reversible in practice.

A net oxidation-reduction reaction is the sum of the appropriate reduction and oxidation half-reactions. If necessary, the half-reactions must be multiplied by a factor so that no electrons appear in the net reaction. For example, the reaction between Cu(s), Cu^{2+} , Ag(s), and Ag^+ is:

$$Cu(s) + 2Ag^+ \rightarrow Cu^{2+} + 2Ag(s)$$

We shall see why the reaction proceeds in this direction shortly. The net reaction is obtained from the half-reactions as follows:

Oxidation reaction:
$$Cu(s) \rightarrow Cu^{2+} + 2e^{-}$$

Reduction reaction $Ag^{2+} + e^{-} \rightarrow Ag(s)$

Each mole of copper gives up 2 moles of electrons, while each mole of silver ion accepts only 1 mole of electrons. Therefore, the entire reduction reaction must be multiplied by 2, so that there are no electrons in the net reaction after summing the half-reactions:

Oxidation reaction:
$$Cu(s) \rightarrow Cu^{2+} + 2e^{-}$$

Reduction reaction: $2(Ag^{+} + e^{-} \rightarrow Ag(s))$
Net reaction: $Cu(s) + 2Ag^{+} \rightarrow Cu^{2+} + 2Ag(s)$

The equal numbers of electrons on both sides of the arrow cancel out.

Electrochemical redox reactions can be carried out in an **electrochemical cell** as part of an electrical circuit so that we can measure the electrons transferred, the current, and the voltage. Each of these parameters provides us with information about the redox reaction, so it is important to understand the relationship between charge, voltage, and current. The absolute value of the charge of one electron is 1.602×10^{-19} coulombs (C); this is the fundamental unit of electric charge. Since 1.602×10^{-19} C is the charge of one electron, the charge of one mole of electrons is:

(13.1)
$$(1.602 \times 10^{-19} \text{ C/e}^{-})(6.022 \times 10^{23} \text{ e}^{-}/\text{mol}) = 96,485 \text{ C/mol}$$

This value, 96,485 C/mol, is called the Faraday constant (F), and provides the relationship between the total charge, q, transferred in a redox reaction and the number of moles, n, involved in the reaction.

$$(13.2) q = n \times F$$

In an electric circuit, the quantity of charge flowing per second is called the **current**, *i*. The unit of current is the ampere, A; 1 A equals 1 C/s. The potential difference, *E*, between two points in the cell is the amount of energy required to move the charged electrons between the two points. If the electrons are attracted from the first point to the second point, the electrons can do work. If the second point repels the electrons, work must be done to force them to move. Work is expressed in joules, J, and the potential difference, *E*, is measured in volts. The relationship between work and potential difference is:

(13.3)
$$w(\text{in joules}) = E(\text{in volts}) \times q(\text{in coulombs})$$

Since the unit of charge is the coulomb, 1 V equals 1 J/C.

The relationship between current and potential difference in a circuit is expressed by Ohm's Law:

$$(13.4) i = \frac{E}{R}$$

where i is the current; E, the potential difference, and R, the resistance in the circuit. The units of resistance are V/A or ohms, Ω .

13.2 ELECTROCHEMICAL CELLS

At the heart of electrochemistry is the electrochemical cell. We will consider the creation of an electrochemical cell from the joining of two half-cells. When an electrical conductor such as a metal strip is immersed in a suitable ionic solution, such as a solution of its own ions, a potential difference (voltage) is created between the conductor and the solution. This system constitutes a half-cell or electrode (Figure 13.1). The metal strip in the solution is called an **electrode** and the ionic solution is called an **electrolyte**. We use the term electrode to mean both the solid electrical conductor in a half-cell (e.g., the metal strip) and the complete half-cell in many cases, for example, the standard hydrogen electrode and the calomel electrode. Each half-cell has its own characteristic potential difference or *electrode potential*. The electrode potential measures the ability of the half-cell to do work, or the driving force for the half-cell reaction. The reaction between the metal strip and the ionic solution can be represented as:




FIGURE 13.1 A half-cell composed of a metal electrode M^0 in contact with its ions, M^+ , in solution. The salt bridge or porous membrane is shown on the lower right side.

where M^0 is an uncharged metal atom, M^{n+} is a positive ion, and e^- is an electron. The number of electrons lost by each metal atom is equal to n, where n is a whole number. This is an oxidation reaction, because the metal has lost electrons. It has been oxidized from an uncharged atom to a positively charged ion. In the reaction, the metal ions enter the solution (dissolve). By definition, the electrode at which oxidation occurs is called the **anode**. We say that at the anode, oxidation of the metal occurs according to the reaction shown in Equation 13.5.

Some examples of this type of half-cell are:

$$Cd(s) \rightarrow Cd^{2+} + 2e^{-}$$

 $Ag(s) \rightarrow Ag^{+} + e^{-}$
 $Cr(s) \rightarrow Cr^{3+} + 3e^{-}$

Note that the zero oxidation state of the solid metal is understood, not shown with a zero superscript. It has been found that with some metals the spontaneous reaction is in the opposite direction and the metal ions tend to become metal atoms, taking up electrons in the process. This reaction can be represented as:

(13.6)
$$M^{n+} + ne^- \rightarrow M^0$$

This is a reduction reaction because the positively charged metal ions have gained electrons, lost their charge, and become neutral atoms. The neutral atoms deposit on the electrode, a process called *electrodeposition*. This electrode is termed a **cathode**. At the cathode, reduction of an **electroactive species** takes place. An electroactive species is one that is oxidized or reduced during reaction. Electrochemical cells also contain nonelectroactive (or inert) species such as counterions to balance the charge, or electrically conductive electrodes that do not take part in the reaction. Often these inert electrodes are made of Pt or graphite, and serve only to conduct electrons into or out of the half-cell.

It is not possible to measure directly the potential difference of a single half-cell. However, we can join two half-cells to form a complete cell as shown in Figure 13.2. In this example, one half-cell consists of a solid copper electrode immersed in an aqueous solution of CuSO₄; the other has a solid zinc electrode immersed in an aqueous solution of ZnSO₄. The two half-cell reactions and the net **spontaneous** reaction are shown:

Anode (oxidation) reaction:
$$Zn(s) \rightarrow Zn^{2+} + 2e^{-}$$

Cathode (reduction) reaction: $Cu^{2+} + 2e^{-} \rightarrow Cu(s)$
Net reaction: $Zn(s) + Cu^{2+} \rightarrow Zn^{2+} + Cu(s)$

No reaction will take place, and no current will flow, unless the electrical circuit is complete. As shown in Figure 13.2, a conductive wire connects the electrodes externally through




FIGURE 13.2 A complete Zn/Cu galvanic cell with a salt bridge separating the half-cells.




FIGURE 13.3 A schematic complete cell with a semipermeable frit separating the half-cells.

a voltmeter (potentiometer). A salt bridge, a glass tube filled with saturated KCl in agar gel, physically separates the two electrolyte solutions. The salt bridge permits ionic motion to complete the circuit while not permitting the electrolytes to mix. The reason we need to prevent the mixing of the electrolytes is that we want to obtain information about the electrochemical system by measuring the current flow through the external wire. If we had both electrodes and both ionic solutions in the same beaker, the copper ions would react directly at the Zn electrode, giving the same net reaction but no current flow in the external circuit. In the electrolyte solution and the salt bridge, the current flow is ionic (ion motion); in the external circuit, the current flow is electronic (electron motion). This cell and the one in Figure 13.3 show the components needed for an electrochemical cell: two electrical conductors (electrodes), suitable electrolyte solutions and a means of allowing the movement of ions between the solutions (salt bridge in Figure 13.2, a semipermeable glass frit or membrane in Figure 13.3), external connection of the electrodes by a conductive wire and the ability for an oxidation reaction to occur at one electrode, and a reduction reaction at the other. Of course, there are counterions present in each solution (e.g., sulfate ions) to balance the charge; these ions are not electroactive and do not take part in the redox reaction. They do flow (ionic motion) to keep charge balanced in the cell. A cell that uses a spontaneous redox reaction to generate electricity is called a galvanic cell. Batteries are examples of galvanic cells. A cell set up to cause a nonspontaneous reaction to occur by putting electricity into the cell is called an electrolytic cell.

The complete cell has a potential difference, a cell potential, which can be measured by the voltmeter. The potential difference for the cell, $E_{\rm cell}$, can be considered to be equal to the difference between the two electrode potentials, when both half-cell reactions are written as reductions. That is,

$$(13.7) E_{\text{cell}} = E_{\text{cathode}} - E_{\text{anode}}$$

when the potentials are **reduction potentials**. This convention is necessary to calculate the sign of $E_{\rm cell}$ correctly, even though the anode reaction is an oxidation. The cell potential is also called the **electromotive force** or **emf**.

While we cannot measure a given single electrode potential directly, we can easily measure the cell potential for two half-cells joined as described. Now we have a means of measuring the **relative electrode potential** for any half-cell by joining it to a designated **reference electrode (reference half-cell)**. In real cells, there is another potential difference that contributes to $E_{\rm cell}$, called a junction potential. If there is a difference in the concentration or types of ions of the two half-cells, a small potential is created at the junction of the membrane or salt bridge and the solution. Junction potentials can be sources of error. When a KCl salt bridge is used, the junction potential is very small because the rates of diffusion of K⁺ and Cl⁻ ions are similar, so the error in measuring a given electrode potential is small.

13.2.1 LINE NOTATION FOR CELLS AND HALF-CELLS

Writing all the equations and arrows for half-cells and cells is time consuming and takes up space, so a shorthand or line notation is used. The half-cell composed of a silver electrode and aqueous $0.0001 \,\mathrm{M}$ Ag⁺ ion (from dissolution of silver nitrate in water) is written in line notation as:

$$Ag(s)|Ag^{+}(0.0001 M)$$

The *vertical stroke or line* between Ag and Ag⁺ indicates a *phase boundary*, that is, a difference in phases (e.g., solid | liquid, solid 1 | solid 2, or liquid | gas) in the constituents of the half-cells that are in contact with each other. The complete cell in Figure 13.2 can be represented as:

$$Zn(s)|Zn^{2+}(0.01M)||Cu^{2+}(0.01M)|Cu(s)$$

The *double vertical stroke* after Zn²⁺ indicates a membrane junction or salt bridge. The double stroke shows the termination of one half-cell and the beginning of the second. This cell could also be written to show the salts used, as shown:

$$Zn(s) \Big| ZnSO_4\big(aq\big) \Big\| CuSO_4\big(aq\big) \Big| Cu(s)$$

It is conventional to write the electrode that serves as the anode on the left in an electrochemical cell. The other components in the cell are listed as they would be encountered moving from the anode to the cathode.

13.2.2 STANDARD REDUCTION POTENTIALS: THE STANDARD HYDROGEN ELECTRODE

In order to compile a table of relative electrode potentials, chemists must agree upon the half-cell that will serve as the reference electrode. The composition and construction of the half-cell must be carefully defined. The value of the electrode potential for this reference half-cell could be set equal to any value, but zero is a convenient reference point. In practice, it has been arbitrarily decided and agreed upon that the **standard hydrogen electrode** (SHE) has an assigned electrode potential of exactly zero volts at all temperatures. The SHE, shown in Figure 13.4, consists of a platinum electrode with a surface coating of finely divided platinum (called a *platinized* Pt electrode) immersed in a solution of 1 M hydrochloric acid, which dissociates to give H⁺. Hydrogen gas, H₂, is bubbled into the acid solution over the Pt electrode. The finely divided platinum on the electrode surface provides a large surface area for the reaction:

(13.8)
$$2H^+ + 2e^- \rightarrow H_2(g) \quad E^0 = 0.000 \text{ V}$$

In addition, the Pt serves as the electrical conductor to the external circuit. Under standard state conditions, when the H_2 pressure equals 1 atm and the *ideal* concentration of the HCl is 1 M, and the system is at 25 °C, the reduction potential for the reaction given in Equation 13.8 is exactly 0 V. The potential actually depends on the chemical *activity* of the HCl, not on its concentration. The relationship between activity and concentration is discussed subsequently. For an ideal solution, concentration and activity are equal. The potential is symbolized by E^0 , where the superscript zero means standard state conditions. The term **standard reduction potential** means that the ideal concentrations of all solutes are 1 M and all gases are at 1 atm; other solids or liquids present are pure (e.g., pure Pt solid). By connecting the SHE half-cell with any other standard half-cell and measuring the voltage difference developed, we can determine the standard reduction potential developed by the second half-cell.




FIGURE 13.4 The standard hydrogen electrode (SHE). This design is shown with a pre-saturator containing the same 1 M HCl solution as in the electrode to prevent concentration changes by evaporation. (Aikens et al., Waveland press inc., Long Grove, IL, 1984. All rights reserved.)

Consider a cell at 25 °C made up of the two half-cells:

$$Zn(s)|Zn^{2+}(aq, 1 M)||H^{+}(aq, 1 M)|H_{2}(g, 1 atm)|Pt(s)$$

This cell has a Zn half-cell as the anode and the SHE as the cathode. All solutes are present at *ideal* 1 M concentrations, gases at 1 atm and the other species are pure solids, and so both half-cells are at standard conditions. The measured cell emf is +0.76 V and this is the standard cell potential, E^0 , because both half-cells are in their standard states. From Equation 13.7, we can write:

$$E_{\text{cell}}^0 = E_{\text{cathode}}^0 - E_{\text{anode}}^0$$

The total voltage developed under standard conditions is +0.76 V. But the voltage of the SHE is zero volts by definition; therefore, the standard reduction potential of the Zn half-cell is:

$$+0.76 \text{ V} = 0.000 - E_{Zn}^0$$

 $E_{Zn}^0 = -0.76 \text{ V}$

Therefore, we can write:

$$Zn^{2+} + 2e^{-} \rightarrow Zn(s)$$
 $E_{Zn}^{0} = -0.76 \text{ V}$

We have determined the Zn standard reduction potential even though the galvanic cell set up has Zn being oxidized. By substituting other half-cells, we can determine their electrode potentials (actually, their relative potentials) and build a table of standard reduction potentials. A galvanic cell with the SHE and Cu requires the SHE to be the anode in order for a spontaneous reaction to occur.

$$Pt(s)$$
, $| H_2(g, 1 \text{ atm}) | H^+ (aq, 1 M) | | Cu^{2+} (aq, 1 M) | Cu(s)$

This cell has a measured cell emf = +0.34 V. Therefore, the standard reduction potential for Cu is:

$$+0.34 \text{ V} = E_{\text{Cu}}^{0} - 0.000 \text{ V}$$

 $E_{\text{Cu}}^{0} = +0.34 \text{ V}$

The quantity E^0 is the emf of a half-cell under standard conditions. A half-cell is said to be under standard conditions when the following conditions exist at a temperature of 25 °C:

- 1. All solids and liquids are pure (e.g., a metal electrode in the standard state).
- 2. All gases at a pressure of 1 atm (760 mmHg).
- 3. All solutes are at 1 M concentration (more accurately, at **unit activity**).

The true electrode potential is related to the activity of the species in solution, not the concentration. For a pure substance, its mole fraction and its activity = 1. For a pure substance that is not present in the system, its mole fraction and its activity = 0. From general chemistry, you should remember that Raoult's Law predicts that for an ideal solution, the mole fraction of the solute and its activity are equal. However, most solutions deviate from ideality because of interactions between the solute and solvent molecules. These deviations can be positive or negative, because the species may attract or repel each other. The amount of attraction or repulsion affects the activity of the solute. For dilute solutions, the activity is proportional to concentration (Henry's Law). Activity is equal to the concentration times the activity coefficient for the species in solution. That is

(13.10)
$$a_{\text{ion}} = [M_{\text{ion}}]\gamma_{\text{ion}}$$

where a_{ion} is the activity of given ion in solution; $[M_{\text{ion}}]$, the molar concentration of the ion; and γ_{ion} , the activity coefficient of the ion.

For very dilute solutions (low ionic strength), the activity coefficient γ approaches 1, so concentration is approximately equal to activity. We will use concentrations in the calculations in this text instead of activities, but the approximation is only accurate for dilute solutions (<0.005 M) and for ions with single charges. Details on activity corrections can be found in most analytical chemistry texts, such as the ones by Harris or Enke listed in the bibliography.

Looking back at Figure 13.2, with the Zn half-cell as the anode and the Cu half-cell as the cathode, we can calculate the standard cell potential for this galvanic cell. In the spontaneous reaction, Zn is oxidized and Cu^{2+} is reduced; therefore, Zn is the anode and Cu is the cathode.

$$Zn^{2+} + 2e^{-} \rightarrow Zn^{0}$$
 $E^{0} = -0.76 \text{ V}$
 $Cu^{2+} + 2e^{-} \rightarrow Cu^{0}$ $E^{0} = +0.34 \text{ V}$

The standard cell potential developed is calculated from Equation 13.9:

$$+0.34 - (-0.76 \text{ V}) = +1.10 \text{ V}$$

In tables of standard potentials, all of the half-cell reactions are expressed as reductions. The sign is reversed if the reaction is reversed to become an oxidation. In a spontaneous reaction, when both half-cells are written as reductions, the half-cell with the more negative potential will be the one that oxidizes. The negative sign in Equation 13.9 reverses one of the reduction processes to an oxidation. Some standard reduction potentials for common half-cells are given in Appendix 13.A on the text website. These can be used to calculate E^0 for other electrochemical cell combinations as we have done for the Zn/Cu cell. More complete lists of half-cell potentials can be found in references such as Bard et al., listed in the bibliography.

In the reaction of our example, zinc metal dissolves, forming zinc ions and liberating electrons. Meanwhile, an equal number of electrons are consumed by copper ions, which plate out as copper metal. The net reaction is summarized as:

$$Zn^{0} + Cu^{2+} \rightarrow Cu^{0} + Zn^{2+}$$
 $E^{0} = +1.10V$

Zinc metal is oxidized to zinc ions, and copper ions are reduced to copper metal. The copper cathode becomes depleted of electrons because these are taken up by the copper ions in solution. At the same time, the zinc anode has an excess of electrons because the neutral zinc atoms are becoming ionic and liberating electrons in the process. The excess electrons from the anode flow to the cathode. The flow of electrons is the source of external current; the buildup of electrons at the anode and the depletion at the cathode constitute a potential difference that persists until the reaction ceases. The reaction comes to an end when either all the copper ions are exhausted from the system or all the zinc metal is dissolved, or an equilibrium situation is reached when both half-cell potentials are equal. If the process is used as a battery, the battery becomes "dead" when the reaction ceases.

When a cell spontaneously generates a voltage, the electrode that is negatively charged is the anode and the positively charged electrode is the cathode.

13.2.3 SIGN CONVENTIONS

The sign of half-cell potentials has been defined in a number of different ways, and this variety of definitions has led to considerable confusion. The convention used here is in accord with the recommendations of the IUPAC meeting in Stockholm in 1953. In this convention, the standard half-cell reactions are written as reductions. Elements that are more powerful reducing agents than hydrogen show negative potentials, and elements that are less powerful reducing agents show positive potentials. For example, the Zn \mid Zn²⁺ half-cell is negative and the Cu \mid Cu²⁺ half-cell is positive.

13.2.4 NERNST EQUATION

We have seen how to use standard reduction potentials to calculate E^0 for cells. Real cells are usually not constructed at standard state conditions. In fact, it is almost impossible to make measurements at standard conditions because it is not reasonable to adjust concentrations and ionic strengths to give unit activity for solutes. We need to relate standard potentials to those measured for real cells. It has been found experimentally that certain variables affect the measured cell potential. These variables include the temperature, concentrations of the species in solution, and the number of electrons transferred. The relationship between these variables and the measured cell emf can be derived from simple thermodynamics (see any introductory general chemistry text). The relationship between the potential of an electrochemical cell and the concentration of reactants and products in a general redox reaction:

$$aA + bB \rightarrow cC + dD$$

is given by the Nernst equation:

(13.11)
$$E = E^{0} - \frac{RT}{nF} \ln \frac{[C]^{c}}{[A]^{a}} \frac{[D]^{d}}{[B]^{b}}$$

where E is the measured potential (emf) of the cell; E^0 , the emf of the cell under standard conditions; R, the gas constant (8.314 J/K mol = 8.314 V C/K mol); T, the temperature (K); n, the number of moles of electrons transferred during reaction (from the balanced

half-reactions); *F*, the Faraday constant (96,485 C/mol e⁻); and ln = natural logarithm to base e.

The logarithmic term has the same form as the equilibrium constant for the reaction. The term is called Q, the reaction quotient, when the concentrations (rigorously, the activities) are not the equilibrium values for the reaction. As in any equilibrium constant expression, pure liquids and pure solids have activities equal to 1, so they are omitted from the expression. If the values of R, T (25 °C = 298 K), and F are inserted into the equation and the natural logarithm is converted to log to the base 10, the Nernst equation reduces to:

(13.12)
$$E = E^{0} - \frac{0.05916}{n} \log \frac{[C]^{c}}{[A]^{a}} \frac{[D]^{d}}{[B]^{b}}$$

It should be noted that the square brackets literally mean "the molar concentration of". For example, $[Fe^{2+}]$ means moles of ferrous ion per liter of solution.

The Nernst equation is also used to calculate the electrode potential for a given half-cell at nonstandard conditions. For example, for the half-cell Fe³⁺ + e⁻ \rightarrow Fe²⁺ which has an $E^0 = 0.77$ V and n = 1, the Nernst equation would be:

$$E = 0.77 - \frac{0.05916}{1} \log \frac{[\text{Fe}^{2+}]}{[\text{Fe}^{3+}]}$$

To calculate the electrode potential, the molar concentrations of ferrous and ferric ion used to construct the half-cell would be inserted. The general form of the Nernst equation for an electrode written as a reduction is:

(13.13)
$$E = E^0 - \frac{0.0591}{n} \log \left(\frac{[\text{red}]}{[\text{ox}]} \right)$$

where [red] means the molarity of the reduced form of the electroactive species and [ox] means the molarity of the oxidized form of the electroactive species. In cells where the reduced form is the metal, for example in the Cu/Cu^{2+} half-cell, [red] = 1 because pure metals such as Cu have unit activity.

The Nernst equation gives us the very important relationship between E, the emf of the half-cell, and the concentration of the oxidized and reduced forms of the components of the solution. Measurements using pH electrodes and ion-selective electrodes are based on this relationship. If the two electrode reactions are written as reductions, the potentials can be calculated for the cathode and anode (or the electrode inserted into the positive terminal of the potentiometer, E_+ and the electrode inserted into the negative terminal of the potentiometer, E_-) The cell voltage is the difference

(13.14)
$$E_{\text{cell}} = E_{+} - E_{-}$$

13.2.5 ACTIVITY SERIES

The tendency for a species to become oxidized or reduced determines the sign and potential of the half-cell. The tendency is strongly related to the chemical reactivity of the species concerned in aqueous systems. Based on the potential developed in a half-cell under controlled conditions, the elements may be arranged in an order known as the activity series or electromotive series (Table 13.1). In general, the metals at the top of the activity series are most chemically reactive and tend to give up electrons easily, following the reaction $M^0 \to M^{n+} + ne^-$. The metals at the bottom of the series are more "noble" and therefore less active. They do not give up electrons easily; in fact, their cations will accept electrons from metals above them in the activity series. In the process, the cations become neutral metal

TABLE 13.1	The Activity	v Series of	Metals
IADEL ISI	THE ACTIVITY	, series or	Mictais

Metal	<i>E</i> ⁰ (V)	Chemical Reactivity
Li	-3.05	These metals displace hydrogen from acids and dissolve in all acids, including water
K	-2.93	
Ва	-2.91	
Sr	-2.89	
Ca	-2.87	
Na	-2.71	
Mg	-2.37	These metals react with acids or steam
Al	-1.66	
Mn	-1.18	
Zn	-0.76	
Cr	-0.74	
Fe	-0.44	
Cd	-0.40	
Co	-0.28	These metals react slowly with all acids
Ni	-0.26	
Sn	-0.14	
Pb	-0.13	
H_2	0.00	
Bi	+0.32	These metals react with oxidizing acids (e.g., HNO_3)
Cu	+0.34	
Ag	+0.80	
Hg	+0.85	
Pd	+0.92	
Pt	+1.12	These metals react with aqua regia (3:1 v/v HCI/HNO_3)
Au	+1.50	

atoms and plate out of solution, while the more active metals become ionic and dissolve. This is illustrated as follows:

metal A (active)
$$\rightarrow$$
 metal ion A⁺ + e⁻
metal ion B⁺(noble) + e⁻ \rightarrow metal B
net result: A + B⁺ \rightarrow A⁺ + B

In short, the more active metals displace the less active metals from solution. As an example, if an iron strip is immersed in a solution of copper sulfate, some of the iron dissolves, forming iron ions, while the copper ions become metallic and copper metal plates out on the remaining iron strip. The activity series can be used to predict displacement reactions between atoms and ions in compounds of the type $A + BC \rightarrow AC + B$, where A and B are atoms. Using the activity series, any atom A will displace from a compound any element B listed below it, but will not displace any element listed above it.

This reaction is particularly important when B^+ in BC refers to a hydrogen ion solution (acid). Based on this principle, all elements above hydrogen in the activity series are capable of displacing hydrogen from solution; they will dissolve in an acid solution by reducing the H^+ ion. The metal ionizes (oxidizes) and enters the solution while the H^+ (acid) reduces to H_2 and usually bubbles off. We would predict that Al and Zn will dissolve in HCl, but that Cu will not. A simple mineral acid such as HCl cannot dissolve noble metals, such as platinum and gold, because the metals will not displace hydrogen ion. These metals require an oxidizing acid such as nitric acid plus a complexing ion such as the chloride ion from HCl, as is found in aqua regia, a mixture of HCl and HNO₃, to force them into solution.

13.2.6 REFERENCE ELECTRODES

In order to measure the emf of a given half-cell, it is necessary to connect it with a second half-cell and measure the voltage produced by the complete cell. In general, the second half-cell serves as a reference cell and should be one with a known, stable electrode potential. Although the standard hydrogen electrode serves to define the standard reduction potential, it is not used routinely because it is difficult to set up and control. Other, more convenient reference electrodes have been developed. In principle, any metal-ion half-cell could be used under controlled conditions as a reference electrode, but in practice, many metals are unsatisfactory materials. Active metals, such as sodium and potassium, are subject to chemical attack by the electrolyte. Other metals, such as iron, are difficult to obtain in the pure form. With some metals, the ionic forms are unstable to heat or to exposure to the air. Also, it is frequently difficult to control the concentration of the electrolytes accurately. As a result, only a few systems provide satisfactory stable potentials.

The characteristics of an ideal reference electrode are that it should have a fixed potential over time and temperature, long term stability, the ability to return to the initial potential after exposure to small currents (i.e., it should be reversible), and it should follow the Nernst equation. Two common reference electrodes that come close to behaving ideally are the saturated calomel electrode and the silver/silver chloride electrode.

13.2.6.1 SATURATED CALOMEL ELECTRODE

The **saturated calomel electrode (SCE)** is composed of metallic mercury in contact with a saturated solution of mercurous chloride, or *calomel* (Hg_2Cl_2). A Pt wire in contact with the metallic Hg conducts electrons to the external circuit. The mercurous ion concentration of the solution is controlled through the solubility product by placing the calomel in contact with a saturated potassium chloride solution. It is the saturated KCl solution that gives this electrode the "saturated" name; there are other calomel reference electrodes used that differ in the concentration of KCl solution, but all contain saturated mercurous chloride solution. A typical calomel electrode is shown in Figure 13.5. The half-cell reaction is:




FIGURE 13.5 The saturated calomel electrode (SCE). (Aikens et al., by permission, Waveland Press Inc., Long Grove, IL, 1984. All rights reserved.)

Applying Equation 13.12, we obtain:

$$E = E^{0} - \frac{0.05916}{2} \log \left(\frac{[Hg^{0}]^{2} [Cl^{-}]^{2}}{[Hg_{2}Cl_{2}]} \right)$$

But Hg₂Cl₂(s) and Hg(l) are in standard states at unit activity; therefore:

$$E = E^{0} - \frac{0.05916}{2} \log \left(\frac{1 \times [C1^{-}]^{2}}{2} \right)$$
$$= E^{0} - \frac{0.05916}{2} \log ([C1^{-}]^{2})$$

When the KCl solution is saturated and its temperature is 25 °C, the concentration of chloride ion, [Cl⁻], is known and E = +0.244 V for the SCE.

For a 1 N solution of KCl, the electrode is called a normal calomel electrode (NCE) and E(NCE) = +0.280 V. The advantage of the SCE is that the potential does not change if some of the liquid evaporates from the electrode, because the Cl⁻ concentration does not change. Remember that "saturated" for the SCE refers to the KCl concentration, not to the mercurous chloride (calomel).

13.2.6.2 SILVER/SILVER CHLORIDE ELECTRODE

Another common reference cell found in the chemical-processing industry and useful in organic electrochemistry is the silver/silver chloride half-cell. The cell consists of silver metal coated with a paste of silver chloride immersed in an aqueous solution saturated with KCl and AgCl. The half-cell reaction is:

$$AgCl(s) + e^{-} \leftrightarrow Ag(s) + Cl^{-}$$
 $E^{0} = +0.222 \text{ V}$

The same principle applies as in the SCE, but in this case, the silver ion activity depends on the solubility product of AgCl, which is in contact with a solution of known chloride ion activity. The measured E for an Ag/AgCl electrode saturated in KCl is +0.199 V at 25 °C. A saturated KCl solution is about 4.5 M KCl. This reference electrode can also be filled with 3.5 M KCl (saturated with AgCl); the potential in this case is +0.205 V at 25 °C. The silver/ silver chloride electrode provides a reproducible and reliable reference electrode free from mercury salts.

Both reference electrode designs can permit KCl to leak through the porous plug junction and contaminate the analyte solution. In addition, analytes that react with Ag or Hg ions, such as sulfides, can precipitate insoluble salts that clog the junction and impair the performance of the electrode. Electrode manufacturers have designed double-junction electrodes with an outer chamber that can be filled with an electrolyte that does not interfere with a given measurement and electrodes with large, flushable sleeve junctions that can be cleaned easily and are not prone to clogging.

13.2.7 ELECTRICAL DOUBLE LAYER

While it is easy to say that we can measure the potential difference in an electrochemical cell, the reality of what we are measuring is not obvious. The potential difference between a single electrode and the solution cannot be measured. A second electrode immersed in the solution is required. The second electrode has its own potential difference between itself and the solution; this difference cannot be measured either. All we can measure are relative potential differences. The potential difference between an electrode and the solution actually exists only in a very small region immediately adjacent to the electrode surface. This region

of potential difference is called the "electrical double layer" and is only nanometers wide. A very simplistic view of this interface is presented. A negatively charged electrode surface will have a "layer" of excess positive ions in solution adjacent to (or adsorbed to) the surface of the electrode; hence the term "double layer". Immediately adjacent to the positive ion layer, there is a complex region of ions in solution whose distribution is determined by several factors. Outside of that, only nanometers away from the electrode surface, there is the bulk solution. A positively charged electrode surface will have a similar interfacial region with the charges reversed. The exact nature of the charged interface and the ion distribution is very complex and is not yet completely understood. Outside of this very narrow region of high potential gradient next to each electrode, there is no potential gradient in the bulk of the solution. As a consequence of the placement of electrodes in solution and the creation of charged interfaces between the electrode surface and the solution, electrochemical measurements are made in a very nonhomogeneous environment.

Any reactions that occur must occur at the electrode-solution interface and the reacting species must be brought to the electrode surface by diffusion or mass transport through stirring of the solution (convection). The ions in the bulk of the solution are not attracted to the electrodes by potential difference; there is no potential gradient in the bulk of the solution. Even when we are interested in the bulk properties of the solution, we are only analyzing an extremely small amount of the solution that is no longer homogeneous because of the formation of the complex layers of charged species at the electrode interface.

13.3 ELECTROANALYTICAL METHODS

Diverse analytical techniques, some highly sensitive, have been developed based on measurements of current, voltage, charge, and resistance in electrochemical systems. One variable is measured while the others are controlled. Electroanalytical methods can be classified according to the variable being measured. Table 13.2 provides a summary of the more important methods. The methods are discussed at length in subsequent sections. A variety of electroanalytical methods are used as detectors for liquid chromatography (Chapter 12). Detectors based on conductometry, amperometry, coulometry, and polarography are commercially available.

13.3.1 POTENTIOMETRY

The Nernst equation indicates the relationship between the activity of species in solution and the emf produced by a cell involving those species. The electrochemical technique called **potentiometry** measures the potential developed by a cell consisting of an **indicator**

TABLE 13.2 Electroanalytical Techniques						
Technique	Controlled Parameter	Parameter Measured				
Conductometry	Voltage, V (AC)	Conductance $G = 1/R$				
Conductometric titration	Voltage, V (AC)	Titrant volume versus conductance				
Potentiometry	Current, $i = 0$	Potential, E				
Potentiometric titration	Current, $i = 0$	Titrant volume versus E				
Cyclic voltammetry	Potential, E	i versus E				
Polarography	Potential, E	i versus E				
Anodic stripping voltammetry	Potential, E	i versus E				
Amperometry	Potential, E	i				
Coulometry	Ε	Charge, q (integrated current)				
Electrogravimetry	E or i	Weight deposited				
Coulometric titration	i	Time, t				




FIGURE 13.6 An electrochemical measuring system for potentiometry. The indicator (sensing, working) electrode responds to the activity of the analyte of interest. The potential difference developed between the reference electrode and the indicator electrode is "readout" on the potentiometer (voltmeter). (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

electrode and a **reference electrode**. In theory, the indicator electrode response is a measure of the activity of a single component of the solution, the analyte. In practice, the indicator electrode is calibrated to respond to concentration rather than activity and is usually not specific for a single analyte. The potential, $E_{\rm cell}$, is measured under negligible current flow to avoid significant changes in the concentration of the component being measured, to ensure accurate determination of the potential developed by a cell. A flow of current would mean that a Faradaic reaction is taking place, which would change the potential from that existing when no current is flowing. Modern potentiometers permit measurement of potential with currents <1 pA, so potentiometry can be considered to be a nondestructive technique. Potentiometry is the basis for measurement of pH, ion-selective electrode measurements, and potentiometric titration.

Measurement of the potential of a cell can be useful in itself, but it is particularly valuable if it can be used to measure the potential of a half-cell or **indicator electrode** (also called a sensing electrode), which responds to the concentration of the species to be determined. This can be accomplished by connecting the indicator electrode to a reference half-cell to form a complete cell as shown in Figure 13.6. When the total voltage of the cell is measured, the difference between this value and the voltage of the reference electrode is the voltage of the indicator electrode. This can be expressed as:

$$E(total) = E(indicator) - E(reference)$$

By convention, the reference electrode is connected to the negative terminal of the potentiometer (the readout device). The common reference electrodes used in potentiometry are the SCE and the silver/silver chloride electrode. Their potentials are fixed and known over a wide temperature range. Some values for these electrode potentials are given in Table 13.3. The total cell potential is measured experimentally, the reference potential is known, and therefore, the variable indicator electrode potential can be calculated and related to the concentration of the analyte through the Nernst equation. In practice, the concentration of the unknown analyte is determined after calibration of the potentiometer with suitable standard solutions. The choice of reference electrode depends on the application. For example, the Ag/AgCl electrode cannot be used in solutions containing species such as halides or sulfides that will precipitate or otherwise react with silver.

TABLE 13.3	Potentials of Reference Electrodes at	
	Various Temperatures	

Potential	(W) W	ORCIIC	CHE

Temperature(°C)	Saturated calomel (SCE)	Saturated Ag/AgCl
15	0.251	0.209
20	0.248	0.204
25	0.244	0.199
30	0.241	0.194
35	0.238	0.189

13.3.1.1 INDICATOR ELECTRODES

The indicator electrode is the electrode that responds to the change in analyte activity. An ideal indicator electrode should be specific for the analyte of interest, respond rapidly to changes in activity, and follow the Nernst equation. There are no specific indicator electrodes, but there are some that show a high degree of selectivity for certain analytes. Indicator electrodes fall into two classes: metallic electrodes and membrane electrodes.

13.3.1.1.1 Metallic Electrodes A metal electrode of the **first kind** is just a metal wire, mesh, or solid strip that responds to its own cation in solution. Cu/Cu²⁺, Ag/Ag⁺, Hg/Hg⁺, and Pb/Pb²⁺ are examples of this type of electrode. There are significant problems encountered with these electrodes. They have poor selectivity, responding not only to their own cation but also to any other more easily reduced cation. Some metal surfaces are easily oxidized, giving erratic or inaccurate response unless the solution has been purged of air. Some metals can only be used in limited pH ranges because they will dissolve in acids or bases. Silver and mercury are the most commonly used electrodes of the first kind.

A metal electrode of the **second kind** consists of a metal coated with one of its sparingly soluble salts (or immersed in a saturated solution of its sparingly soluble salt). This electrode responds to the anion of the salt. For example, a silver wire coated with AgCl will respond to changes in chloride activity because the chloride ion activity is controlled by the solubility of AgCl. The electrode reaction is AgCl(s) + $e^- \leftrightarrow$ Ag(s) + Cl⁻, with a potential $E^0 = 0.222$ V. The Nernst equation expression for the electrode potential at 25 °C is $E = 0.222 - 0.05916 \log[Cl^-]$.

A metal electrode of the **third kind** uses two equilibrium reactions to respond to a cation other than that of the metal electrode. Ethylenediaminetetraacetic acid (EDTA) complexes many metal cations, with different stabilities for the complexes but a common anion (the EDTA anion) involved in the equilibria. A mercury electrode in a solution containing EDTA and Ca will respond to the Ca ion activity, for example. The complexity of the equilibria makes this type of electrode unsuitable for complex sample matrices.

The last type of metallic electrode is the **redox indicator electrode**. This electrode is made of Pt, Pd, Au, or other inert metals, and serves to measure redox reactions for species in solution (e.g., Fe^{2+}/Fe^{3+} , Ce^{3+}/Ce^{4+}). These electrodes are often used to detect the endpoint in potentiometric titrations. Electron transfer at inert electrodes is often not reversible, leading to nonreproducible potentials. Although not a metal electrode, carbon electrodes are also used as redox indicator electrodes, because carbon is also not electroactive at low applied potentials. Properties of the types of electrodes can be found in the book by Bruno and Svoronos.

13.3.1.1.2 Membrane Electrodes Membrane electrodes are a class of electrodes that respond *selectively* to ions by the development of a potential difference (a type of junction potential) across a membrane that separates the analyte solution from a reference solution. The potential difference is related to the concentration difference in the specific ion measured on either side of the membrane. These electrodes do not involve a redox reaction at the surface of the electrode as do metallic electrodes. Because these electrodes respond to ions,

they are often referred to as **ion-selective electrodes (ISEs)**. The ideal membrane allows the transport of only one kind of ion across it; that is, it would be specific for the measurement of one ionic species only. As of this writing, there are no specific ISEs, but there are some highly selective ones. Each electrode is more or less selective for one ion; therefore, a separate electrode is needed for each species to be measured. In recent years, many different types of membrane electrodes have been developed for a wide variety of measurements.

ISEs are relatively sensitive. They are capable of detecting concentrations as low as 10^{-12} M for some electrodes. To avoid writing small concentrations in exponential form, the term **pIon** has been defined, where pIon equals the negative logarithm (base 10) of the molar concentration of the ion. That is,

$$pIon = -log[Ion]$$

For example, pH is the term used for the negative logarithm of the hydrogen ion concentration, where H⁺ is expressed as (moles of H⁺)/L of solution. Concentrations of other ions can be expressed similarly: pCa for calcium ion concentration, pF for fluoride ion concentration, pOH for hydroxide ion concentration, and pCl for chloride ion concentration. If the concentration of H⁺ ion in solution equals 3.00×10^{-5} M, the pH = $-\log(3.00 \times 10^{-5}) = 4.522$. If the concentration is 1.00×10^{-7} M, the pH = $-\log(1.0 \times 10^{-7}) = 7.00$.

13.3.1.1.3 Glass Membrane Electrodes The first membrane electrode to be developed was the glass electrode for measurement of pH, the concentration of hydrogen ion, H⁺, in solution. The pH electrode consists of a thin hydrogen ion-sensitive glass membrane, often shaped like a bulb, sealed onto a glass or polymer tube. The solution inside the electrode contains a known concentration of H⁺ ion, either as dilute HCl or a buffer solution. The solution is saturated in AgCl. The activity of H⁺ inside the electrode is constant and keeps the internal potential fixed. An internal reference electrode is sealed inside the tube and is attached to one terminal of the potentiometer. The glass pH electrode is shown schematically in Figure 13.7(a). The glass pH electrode is used in combination with a reference electrode, either a separate Ag/AgCl electrode or an SCE, as shown in Figure 13.7(b). Both electrodes are immersed in a solution of unknown pH and the cell potential developed is a measure of the hydrogen ion concentration in the solution on the outside of the glass membrane of the pH electrode, since all other potentials are fixed.

In a standard pH electrode, the glass membrane is composed of SiO_2 , Na_2O , and CaO. The response of this glass to changes in hydrogen ion activity outside the membrane is complex. The glass electrode surfaces must be hydrated in order for the glass to function as a pH sensor. It is thought that a hydrated gel layer containing adsorbed H^+ ions exist on the inner and outer glass surfaces. It is necessary for charge to move across the membrane in order for a potential difference to be measured, but studies have proved that H^+ ion does not move through the glass membrane. The singly charged Na^+ cation is mobile within the 3D silicate lattice. It is the movement of sodium ions in the lattice that is responsible for electrical conduction within the membrane. The inner and outer glass membrane surfaces contain negatively charged oxygen atoms. Hydrogen ions from the solution inside the electrode equilibrate with the inner glass surface, neutralizing some of the negative charge. Hydrogen ions from the solution outside the electrode (the sample) equilibrate with the oxygen anions on the outer glass surface and neutralize some of the charge.

The side of the glass exposed to the higher H^+ concentration has the more positive charge. Na^+ ions in the glass then migrate across the membrane from the positive side to the negative side, which results in a change in the potential difference across the membrane. The only variable is the hydrogen ion concentration in the analyte solution. Because the electrode behavior obeys the Nernst equation, the potential changes by 0.05916~V for every ten-fold change in $[H^+]$ or for every unit change in pH. The glass pH electrode is highly selective for hydrogen ions. The major interfering ion is Na^+ . When Na^+ concentration is high and H^+ is very low, as occurs in very basic solutions of sodium hydroxide, the electrode responds to sodium ion as if it were hydrogen ion. This results in a negative error; the measured pH is

lower than the true pH. This is called the *alkaline error*. The use of pH electrodes to measure pH is discussed below under applications of potentiometry.

Commercial glass pH electrodes come in all sorts of shapes and sizes to fit into every imaginable container, including into NMR tubes and to measure pH in volumes of solution as small as a few microliters. Some electrodes come as complete cells, with a second reference electrode built into the body of the pH electrode. These are called **combination electrodes**, and eliminate the need for a second external reference electrode. Combination electrodes are required if you want to measure small volumes in small containers and have no room for two separate electrodes. A combination electrode is shown schematically in Figure 13.7(c). Many




FIGURE 13.7 (a) A schematic glass electrode for pH measurement. (b) A complete pH measurement cell, with the glass indicator electrode and an external saturated calomel reference electrode. (c) A commercial combination pH electrode, with built-in internal Ag/AgCl reference electrode.




FIGURE 13.8 A commercial microelectrode for pH measurements in volumes as small as $10 \, \mu L$. The electrode has a solid-state pH sensor and a flexible polypropylene stem, making it extremely rugged and suitable for use in the field. This electrode can be used to determine pH in single droplets of water on leaves of plants or blades of grass to study acid rain deposition. (Courtesy of Lazar Research Laboratories, Inc., Los Angeles, CA [www.lazarlab.com].)

glass pH electrodes have polymer bodies and polymer shields around the fragile glass bulb to help prevent breakage. A microelectrode for measuring microliter volumes in well plates is shown in Figure 13.8.

Other glass compositions incorporating aluminum and boron oxides have been used in membrane electrodes to make the membrane selective for other ions instead of hydrogen ion. For example, a glass whose composition is 11 % Na₂O, 18 % Al₂O₃, 71 % SiO₂ is highly selective toward sodium, even in the presence of other alkali metals. At pH 11, this electrode is approximately 3000× more sensitive to Na⁺ than to K⁺. The ratio of the response of the electrode to a solution of potassium to its response to a solution of sodium, the analyte, for solutions of equal concentration, is called the *selectivity coefficient*. The selectivity coefficient should be a very small number (\ll 1) for high selectivity for the analyte. An ISE has different selectivity coefficients for each ion that responds. Commercial glass ISEs are available for all of the alkali metal ions (Li, Na, K, Rb, and Cs), and for ammonium ion (NH₄⁺), Ag⁺, Fe³⁺, Pb²⁺, and Cu²⁺.

13.3.1.1.4 Crystalline Solid-State Electrodes Crystalline solid-state electrodes have membranes that are single crystal ionic solids or pellets pressed from ionic salts under high pressure. The ionic solid must contain the target analyte ion and must not be soluble in the solution to be measured (usually aqueous solution). These membranes are generally about 1-2 mm thick and 10 mm in diameter. Sealing the solid into the end of a polymer tube forms the electrode. Like the pH electrode, the interior of the polymer tube contains an internal electrode to permit connection to the potentiometer and a filling solution containing a fixed concentration of the analyte ion. A concentration difference in the analyte ion on the outside of the crystalline membrane causes the migration of charged species across the membrane. These electrodes generally respond to concentrations as low as 10^{-6} M of the analyte ion.

The fluoride ion selective electrode is the most commonly used single-crystal ISE. It is shown schematically in Figure 13.9. The membrane is a single crystal of LaF_3 doped with EuF_2 . The term "**doped**" means that a small amount of another substance (in this case, EuF_2)




FIGURE 13.9 A commercial solid-state fluoride ISE. The ion-sensitive area is a solid crystal of LaF₃ doped with EuF₂. The filling solution contains NaF and NaCl. The electrical connection is made by an Ag/AgCl electrode. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

has been added intentionally into the LaF_3 crystal. (If the addition were not intentional, we would call the europium an impurity or contaminant!) Note that the two salts do not have the same stoichiometry. Addition of the europium fluoride creates fluoride ion vacancies in the lanthanum fluoride lattice. When exposed to a variable concentration of F^- ion outside the membrane, the fluoride ions in the crystal can migrate. Unlike the pH electrode, it is the F^- ions that actually move across the membrane and result in the electrode response. The F^- ISE is extremely selective for fluoride ion. The only ion that interferes is OH^- , but the response of the electrode to fluoride ion is more than $100\times$ greater than the response of the electrode to hydroxide. The hydroxide interference is only significant when the OH^- concentration is 0.1 M or higher. The electrode only responds to fluoride ion, so the pH of the solution must be kept high enough so that HF does not form.

Other crystalline solid-state electrodes are commercially available to measure chloride, bromide, iodide, cyanide, and sulfide anions. Most of these electrode membranes are made from the corresponding silver salt mixed with silver sulfide, due to the low solubility of most silver salts in water. In addition, mixtures of silver sulfide and the sulfides of copper, lead, and cadmium make solid-state electrodes for Cu^{2+} , Pb^{2+} , and Cd^{2+} available. An advantage of the silver sulfide-based electrodes is that a direct connection can be made to the membrane by a silver wire, eliminating the need for electrolyte filling solutions. These electrodes will also respond to silver ion and sulfide ion as well as the intended analyte.

13.3.1.1.5 Liquid Membrane ISEs Liquid membrane electrodes are based on the principle of ion exchange. Older electrodes, such as the one diagrammed in Figure 13.10(a), consisted of a hydrophilic, porous membrane fixed at the base of two concentric tubes. The inner tube contains an aqueous solution of the analyte ion and the internal reference electrode. The outer tube contains an ion-exchanger in organic solvent. The ion-exchanger may be a cation exchanger, an anion exchanger, or a neutral complexing agent. Some of the organic phase is absorbed into the hydrophilic membrane, forming an organic ion-exchange phase separating the aqueous sample solution and the aqueous internal solution with a known concentration of analyte ion. An ion-exchange equilibrium is established at both surfaces of the membrane and the concentration difference results in a potential difference. Modern liquid membrane electrodes have the liquid ion-exchanger immobilized in or covalently bound to a polymer film, shown schematically in Figure 13.10(b). The selectivity of these electrodes is determined by the degree of selectivity of the ion-exchanger for the analyte ion. Selective




FIGURE 13.10 (a) A liquid membrane ISE. (b) An ISE with ion exchange material in a solid polymer membrane. The sensed ion is exchanged across the membrane, creating the potential. This type of ISE is available for Ca²⁺, K⁺, nitrate ion, and nitrite ion determinations. (b: © Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

lipophilic complexing agents have been developed and this area is still an important area of research.

Commercial liquid membrane electrodes are available for calcium, calcium plus magnesium to measure water hardness, potassium, the divalent cations of Zn, Cu, Fe, Ni, Ba, and Sr, and anions BF_4^- and nitrate, NO_3^- , among others. In general, these electrodes can be used only in aqueous solution, to avoid attack on the membrane. Lifetimes are limited by leaching of the ion-exchanger from the membrane, although newer technology (such as covalent attachment of the ion-exchanger) is improving this.

Polymer film membranes are being used to coat metal wire electrodes to make miniature ISEs for *in vivo* analysis. These coated wire ISEs require no internal reference solution and have been made with electrode tip diameters of about 0.1 μ m. Electrodes have been made small enough to measure ions inside a single cell, as seen in Figure 13.11.

13.3.1.1.6 Gas-Sensing Electrodes Gas-sensing electrodes are really entire electrochemical cells that respond to dissolved gas analytes or to analytes whose conjugate acid or base is a gaseous species. Because they are complete cells, the term "probe" is often used instead of electrode. A typical gas-sensing probe consists of an ISE and a reference electrode sealed behind a gas-permeable membrane, through which the analyte gas diffuses. The ISE used can be selective for the species, for example, an Ag_2S electrode to measure hydrogen sulfide that




FIGURE 13.11 Microscopic carbon-fiber electrodes for measurements in a single cell. (From Michael and Wightman, used with permission.)

diffuses through the gas permeable membrane. Several gas-sensing probes use a glass pH electrode as the indicator electrode for gas species that change the pH of the internal solution. Examples include the determination of CO_2 , which dissolves in the aqueous internal solution to form H^+ and HCO_3^- , and the determination of ammonia, which dissolves to form NH_4^+ and OH^- . The potential that develops in all of these cells depends on the concentration of the analyte gas in the external sample solution. Gas-sensing electrodes typically have long response times, on the order of a few minutes, because the gas must cross the membrane. These electrodes are highly selective and free from interference from nonvolatile species; only gases can cross the gas-permeable membrane. If a pH electrode is used as the ISE, obviously any gas that dissolves and changes the internal solution pH will be detected; therefore, some gases may interfere with other gas analytes.

13.3.1.7 Immobilized Enzyme Membrane Electrodes Enzymes are biocatalysts that are highly selective for complex organic molecules of biochemical interest, such as glucose. Many enzymes catalyze reactions that produce ammonia, carbon dioxide, and other simple species for which ISEs are available as detectors. Coating an ISE with a thin layer of an enzyme holds the promise of making highly selective biosensors for complex molecules with the advantages of potentiometry—speed, low cost, and simplicity. The enzyme is generally immobilized on the electrode by incorporation into a gel, by covalent bonding to a polymer support or by direct adsorption onto the electrode surface, so that a small amount of enzyme may be used for many measurements. Very few species interfere with enzyme-catalyzed reactions, although the enzyme can be inhibited. No commercial potentiometric enzyme-based electrodes are available; however, considerable research in this area is in progress (Zhao and Jiang).

13.3.1.1.8 Ion-Selective Field Effect Transistors Ion-selective field effect transistors (ISFETs) are semiconductor devices related to the solid-state detectors used in spectroscopy. In this case, the surface of the transistor is covered with silicon nitride, which adsorbs H⁺ ions from the sample solution. The degree of adsorption is a function of the pH of the sample solution and the adsorption of H⁺ ions result in a change in the conductivity of the ISFET channel. The cell requires an external reference electrode. ISFET pH sensors can be made extremely small (about 2 mm²) and are extremely rugged, unlike the fragile glass bulb pH electrode. They have rapid response times and can operate in corrosive samples, slurries, and even wet solids such as food products. The sensor can be scrubbed clean with a toothbrush, stored in a dry condition, and does not require hydrating before use. The price of an ISFET pH electrode is about half that of a standard glass electrode. An ISFET pH electrode is shown in Figure 13.12, with the ISFET sensor embedded in a polymer body electrode.



FIGURE 13.12 A commercial ISFET pH probe, with a silicon chip pH sensor, a built-in reference electrode, and a built-in temperature sensor. This pH probe is housed in a stainless steel body with a slanted tip for easy insertion into meat or other soft solid samples. (Courtesy of IQ Scientific Instruments, Inc., Carlsbad, CA., www.phmeters.com.)

13.3.1.2 INSTRUMENTATION FOR MEASURING POTENTIAL

Understanding electrochemical instrumentation requires a basic knowledge of electricity and basic electronics. Coverage of these fundamentals is impossible in a text of this size. The student is advised to review the concepts of electricity learned in general physics, and to understand the definitions of current, voltage, resistance, and similar basic terms. The texts by Kissinger and Heineman, Malmstadt et al., or Diefenderfer and Holton, listed in the bibliography, are excellent sources of information on electronics used in instrumentation. The electrochemical cell is one circuit element with specific electrical properties in the complete instrumentation circuit.

A **potentiometric cell** is a galvanic cell connected to an external potential source that is exactly equal but opposite to that of the galvanic cell. Negligible current flows in this type of cell. The potential of a complete cell can be measured with a solid-state circuit that requires negligible input current but can output the voltage to a meter, digital readout, recorder, or computer. The circuit should have high input impedance, high gain, low output impedance, and ideally, no output signal when there is no input signal. **Operational amplifiers** have these properties. Figure 13.13 illustrates an operational amplifier (op-amp) set up as a voltage follower. The triangle represents the amplifier with two inputs on the left and an output on the right. It may contain a large number of discrete components, for example, transistors.




FIGURE 13.13 Schematic of an operational amplifier (called an op-amp) with voltage feedback (the voltage follower).

Usually, such devices require \pm 15V power lines, which are omitted in circuit diagrams. The voltage input marked with the + sign is called a *noninverting input*, and the one marked with the – sign is the *inverting input*. If *A* is the gain (typically 10⁵), the output voltage E_{out} is:

(13.16)
$$E_{\text{out}} = -A(E^{-} - E^{+})$$

where E^- and E^+ are the voltage values at the inverting and noninverting inputs, respectively. The minus sign means that the polarity of the voltage difference is reversed. Rearranging, we have:

$$E^- = E^+ - \frac{E_{\text{out}}}{A}$$

and because A is very large,

$$E^- \approx E^+$$

Notice that $E_{\rm out}$ is fed back into the noninverting input (E^-). This is termed voltage feedback. The function of this type of circuit is to offer high-input impedance which can be typically 10^5-10^{13} ohms (Ω). This means that the + and – input require negligible current and can be used to monitor the voltage of a highly resistive source such as a glass electrode. However, the output current and voltage capabilities are considerable, depending on the device properties and the power supply limitations. It seems odd, at first, that the circuit just reproduces the voltage of the cell but does so in such a way as to make available much larger currents than are available from the electrochemical cell. The electrical resistance of the glass electrode for pH measurement is enormous ($50-10,000~{\rm M}\Omega$). An ordinary potentiometer or voltmeter would indicate practically no observable voltage, which is why a high-impedance solid-state measuring circuit is required. Modern instruments drain no more than $10^{-10}-10^{-12}$ A from the cell being measured.

Commercial solid-state potential measuring devices based on the type of op-amp described are often called **pH or pIon meters** and are designed to work with glass pH electrodes, ion selective electrodes, and other indicator electrodes described earlier. Research quality pIon meters have built-in temperature measurement and compensation, autocalibration routines for a three-point (or more) calibration curve, recognition of electrodes (so you do not try measuring fluoride ion with your pH electrode!), and the ability to download data to computer data collection programs. The relative accuracy of pH measurements with such a meter is about \pm 0.005 pH units. Meters are available as handheld portable devices for field or plant use; these meters have less accuracy, on the order of \pm 0.02 pH units, but are much less expensive. The field portable meters are battery-powered and waterproof. Commercial meters will read out in mV, pH, concentration of ion for an ISE, in mS for conductivity measurements and many will also read out the temperature.

A second important use of operational amplifiers and feedback circuits is to control the potential at a working electrode. The circuit that performs this task is called a **potentiostat**. Potentiostats and modern polarography equipment are called **three-electrode devices** because they attach to a working electrode, a reference electrode, and an auxiliary electrode, also called a counter-electrode (Figure 13.14). The principle of operation is that the potential between the working electrode (WE) and the reference electrode (REF) is maintained by a feedback circuit. The applied voltage $E_{\rm appl}$ may be a constant voltage or some signal generator voltage, such as a linear ramp. To understand how this circuit works, consider starting with no potential at the amplifier output. The output voltage $E_{\rm out}$ will be given, as before, by:

$$E_{\text{out}} = -A(E^{-} - E^{+})$$

Because at time t=0, $E^-=E_{\rm appl}$, the voltage $E_{\rm out}$ will rise, with the same sign, until $E_{\rm out}=E_{\rm appl}$ at the point REF. Assuming that the uncompensated resistance $R_{\rm u}$ between WE and REF can be essentially ignored, this ensures that WE is held at $E_{\rm appl}$ and the potential of the counterelectrode can "float" to maintain zero differential input at the – and + inputs. Note that negligible




FIGURE 13.14 Schematic of a simple potentiostat and representation of the cell as an electrical (equivalent) circuit.

current flows to the inverting (–) input through the reference electrode. The measured cell current flows between the WE and the counter-electrode (CE). In practice, the uncompensated resistance $R_{\rm u}$ is kept small by placing the reference electrode close to WE, by using an excess of supporting electrolyte, and by keeping the net cell current small by using microelectrodes, such as a dropping mercury electrode. Then the voltage drop in the electrolyte between WE and REF, $iR_{\rm u}$, need not be compensated for.

On modern potentiostats, the applied voltage is given as the *actual* sign of the voltage on the WE, and there is no need to assume a potential reversal. In other words, if you set the potentiostat at -0.500 V, WE is at -0.500 V versus whatever reference electrode you have in the actual cell. If, for example, this electrode was a SCE, then on the SHE scale at 25 °C,

$$E_{\text{WE}} = -0.500 + 0.241$$

= -0.259 V vs. SHE

If the cell had a silver/silver chloride reference (3.5 M) and the equipment were set at -0.500 V versus REF, then:

$$E_{\text{WE}} = -0.500 + 0.205$$

= -0.295 V vs. SHE

In each of these cases, when we state our values on the hydrogen scale, the potential at the working electrode is numerically less. On the other hand, for an applied potential of +0.500 V versus SCE on the potentiostat,

$$E_{\text{WE}} = +0.500 + 0.241$$

= 0.742 V vs. SHE

This raises an important point. It does not matter which reference electrode we use; it is best to use the one most suited for the chemical system being studied. We should always, however, quote the potentials versus the particular reference and be sure to label the axes of current-voltage curves with the appropriate reference electrode. Electrode potentials are relative values.

13.3.1.3 ANALYTICAL APPLICATIONS OF POTENTIOMETRY

Potentiometry is widely used in industrial, environmental, agricultural, clinical, and pharmaceutical laboratories to measure ions, acids, bases, and gases. Measurements may be made in a standard laboratory setting, but potentiometry is ideal for online process monitoring, *in vivo* monitoring, and field measurements using flow-through or portable instruments. Quantitative measurement of pH is extremely important and will be discussed in detail below. Quantitative measurement of inorganic and organic ions, acidic and basic ions, and

gases, and determination of ions in specific oxidations states are commonly performed by potentiometry. Potentiometry is used in research to determine stability constants of complexes, solubility product constants, to determine reaction rates and elucidate reaction mechanisms, and to study enzyme and other biochemical reactions.

Samples must be in the form of liquids or gases for analysis. Sample preparation may include buffering the sample to an appropriate pH for some ISE and gas measurements or adding ionic strength "buffer" to make all samples and standards of equivalent ionic strength. For a comprehensive listing and recipes for many buffers, consult the book by Bruno and Svoronos. The detection limit for most common electrodes is about 10^{-6} M, while gas probes have detection limits in the low ppm range.

An understanding of stoichiometry, acid-base theory, and simple equilibrium calculations is required for the following quantitative applications. Review your introductory chemistry text or a basic quantitative analysis text such as those by Harris or Enke listed in the bibliography.

13.3.1.3.1 Direct Measurement of an Ion Concentration The concentration of an ion in solution may be measured directly via the potential developed by the half-cell involved and by applying the Nernst equation. For example, a silver/silver ion half-cell plus an SCE gives the following relationship:

$$E(\text{cell}) = E(\text{Ag}) - E(\text{SCE})$$

where E(Ag) is the emf of the silver half-cell. But:

$$E(Ag) = E^{0}(Ag) - \frac{RT}{nF} \ln \frac{1}{[Ag^{+}]}$$

Therefore:

$$E(\text{cell}) = E^{0}(\text{Ag}) - (0.05916)\log \frac{1}{[\text{Ag}^{+}]} - E(\text{SCE})$$

and at 25 °C, E(SCE) = 0.244 V. From Appendix 13.A (text website), $E^0(Ag) = 0.799$ V. Substituting, we get:

$$E(\text{cell}) = 0.799 - (0.05916)\log \frac{1}{[\text{Ag}^+]} - 0.244$$

This gives us $E = 0.555 + 0.05916 \log [Ag^+]$. In an experiment conducted at 25 °C, the cell potential for such a cell was measured and found to be = 0.400 V. Therefore:

$$log[Ag^{+}] = \frac{0.400 - 0.555}{0.05916}$$
$$= -\frac{0.155}{0.05916}$$
$$log[Ag^{+}] = -2.62$$

The concentration of
$$Ag^+ = antilog(-2.62)$$

= $2.4 \times 10^{-3} M$

13.3.1.3.2 Potentiometric Titrations Potentiometry is a useful way to determine the endpoint in many titrations. For example, the concentration of Ag^+ ion in solution can be used to determine the **equivalence point** in the titration of Ag^+ with Cl^- . In this titration, the following reaction takes place:

$$Ag^+ + Cl^- \rightarrow AgCl(s) \downarrow (precipitation)$$

The concentration of the Ag⁺ in solution steadily decreases as Cl⁻ is added. At the equivalence point, [Ag⁺] = [Cl⁻]. But, for the sparingly soluble salt silver chloride, [Ag⁺][Cl⁻] is a constant called the *solubility product*, $K_{\rm sp}$. In the case of the AgCl precipitation reaction, $K_{\rm sp}$ = 1×10^{-10} at 25 °C. Therefore:

$$[Ag^+][Cl^-] = 1 \times 10^{-10}$$

But, as we have seen, $[Ag^+] = [Cl^-]$ at the equivalence point; therefore:

$$[Ag^{+}]^{2} = 1 \times 10^{-10}$$
$$[Ag^{+}] = \sqrt{1 \times 10^{-10}} = 1 \times 10^{-5} M$$

From this calculation, at the equivalence point $[Ag]^+ = 1 \times 10^{-5}$ M. By applying the Nernst equation to this solution, we get:

$$E(Ag) = E^{0} + \frac{0.05916}{1} \log[Ag^{+}]$$

and

$$E^{0}(Ag) = +0.799$$

therefore

$$E(Ag) = +0.799 + \frac{0.05916}{1} \times (-5)$$
$$E(Ag) = +0.799 - 0.295$$
$$E(Ag) = +0.504$$

At the equivalence point, the emf of the half-cell is calculated to be 0.504~V versus SHE. If we make a complete cell by using the silver half-cell and an SCE half-cell ($\pm 0.244~V$), the observed voltage at the equivalence point will be given by the relationship:

$$E(\text{observed}) = E(Ag) - E(\text{reference})$$
$$= +0.504 - 0.244$$
$$= +0.260 \text{ V versus SCE}$$

At the equivalence point, the measured cell emf is ± 0.260 V versus SCE. In the titration of silver ion, the chloride solution should be added in small portions and the emf of the cell measured after each addition. By plotting the relationship between the volume of Cl $^-$ solution added and the voltage of the cell, we can determine the volume of Cl $^-$ solution necessary to reach the equivalence point. A typical curve relating the volume of chloride to the voltage for titration of silver ion with 0.100 N Cl $^-$ solution is shown in Figure 13.15. In a real titration, the endpoint is determined from the inflection point in the titration curve, not from the calculated voltage.

In the following example, the equivalence point is reached after adding 2.00 mL of 0.100 Cl^{-} solution to 5.00 mL of silver solution. The normality of the silver can be determined from the equation:

(volume of
$$Cl^-$$
)×(normality of Cl^-)=(volume of Ag^+)×(normality of Ag^+)

We have $(2.00 \text{ mL})(0.100 \text{ N}) = (5.00 \text{ mL})(\text{N Ag}^+) \text{ or}$

normality of silver solution =
$$\frac{2.00 \text{ mL} \times 0.100 \text{ N}}{5.00 \text{ mL}} = 0.0400 \text{ N}$$




FIGURE 13.15 Relationship between Ag⁺ concentration, the cell potential and the volume of Cl⁻ solution added.

From this, the weight of Ag+ present in the solution can be calculated as follows:

1L of 1N Ag⁺ contains 108 g Ag⁺, thus g Ag =
$$(108 \text{ g Ag / eq})(0.0400 \text{ eq/L})(1\text{L}/1000 \text{ mL})(5.00 \text{ mL})$$
 g Ag = 0.0216 g

In the example above, we used the known $K_{\rm sp}$ to calculate the potential at the equivalence point. Clearly, it is possible to work backwards and to use the measured potential at the equivalence point to determine the $K_{\rm sp}$ for a sparingly soluble salt.

In Figure 13.15, the titration curve was simple and the equivalence point easily detected; however, in dilute solutions, nonaqueous solvents and titrations involving slower reactions, the titration curve may be flatter (with the inflection point being difficult to find) and difficult to interpret. The problem can be simplified by using equipment that records the first and/or second derivative of the titration curve. The curves obtained for a relationship such as that in Figure 13.15 are shown in Figure 13.16. When the first derivative of the curve is taken, the slope is measured and plotted against the volume added. As the potential changes, the slope changes. At the endpoint, the slope of the curve ceases to increase and begins to decrease, that is, the slope goes through a maximum. This can be seen in the curve of Figure 13.16(b). The second derivative measures the slope of the first derivative curve and plots this against the volume added. At the endpoint, the curve in Figure 14.16(b) goes through a maximum. At the maximum, the slope of the curve is horizontal; that is, it has a zero slope. The second differential curve is shown in Figure 13.16(c). As can be seen, there is a rapid change in the second derivative curve, whose values go from positive to negative, and at the equivalence point, the value of the second derivative equals zero. There are commercial automatic potentiometric titrators available that accurately and rapidly deliver titrant, perform the potentiometric measurements, calculate the derivatives, stop the titrant after the equivalence point is reached, and accurately calculate the concentration of the analyte. Many of these come with autosamplers and computer data handling systems so that multiple titrations can be performed unattended. Companies that make commercial automatic titrators (potentiometric, volumetric, and coulometric systems) include, but are not limited to, Hach Instruments (www.hach.com), Hanna Instruments (www.hannainst.com), Mettler-Toledo (www.mt.com), and Metrohm AG (www.metrohm.com). Their websites provide a wealth of information, methodology, tutorials and so on.

13.3.1.3.3 pH Measurements One of the most important applications of potentiometry is the determination of [H⁺] or the pH of a solution, where pH is defined as the negative logarithm to the base 10 of the hydrogen ion activity (and is approximately equal to the negative




FIGURE 13.16 Relationship between **(a)** a simple potentiometric titration curve and its **(b)** first, and **(c)** second derivatives.

logarithm to the base 10 of the hydrogen ion concentration under certain conditions discussed subsequently),

(13.17)
$$pH = -\log(H^+) \approx -\log[H^+]$$

where (H^+) stands for the activity of the hydrogen ion and $[H^+]$ is the molar concentration of the hydrogen ion.

The procedure can be used for the determination of the pH of most solutions, which is important if the solution is drinking water, the water in a swimming pool, your favorite soda, or a chemical in an industrial process. Frequently, organic and inorganic synthetic reactions, biochemical reactions, and other chemical reactions carried out by research or industrial chemists are very sensitive to pH, which therefore must be measured and controlled.

The determination of [H⁺] in a solution is a special case of the determination of ion concentration (activity). The importance of this determination has merited special equipment designed for specific applications —field-portable, online analysis, and a wide variety of benchtop units.

The most common hydrogen half-cell in practical use is the glass electrode. An SCE is commonly used as the reference electrode. The cell may be formulated as:

$$SCE \bigg\| \Big[H_3O^+ \Big]_{(unknown)} \big| glass \ membrane \big| \Big[H_3O^+ \Big]_{(internal \ reference)} \bigg\| 0.1 \ M \ Cl^-, AgCl(sat.) \big| AgCl(s), Ag(s) \bigg| \\$$

The SCE is the external reference electrode and the Ag/AgCl electrode is the internal reference electrode. Theoretically, the only unknown is the activity (concentration) of the H^+ in the sample (unknown) solution. The Nernst equation tells us that the voltage of the pH electrode should change by 59.16 mV for every unit change in pH at 25 °C. However, we cannot in practice ignore the junction potential. The real equation for a cell is given by:

$$(13.18) E_{\text{cell}} = E_{\text{ind}} - E_{\text{ref}} + E_{\text{j}}$$

In addition to the junction potential E_j , membrane electrodes have asymmetry potentials of unknown magnitude. These potentials cannot be computed theoretically or easily measured individually, so direct pH measurements require that the pH electrode system be calibrated. In fact, the definitions of pH used by NIST and IUPAC are *operational definitions* based on calibration with a series of standard buffer solutions.

Buffer solutions are those in which the pH remains relatively constant (1) over wide ranges of concentration and (2) after the addition of small quantities of acid or base. Standard buffer solutions to calibrate pH electrode systems are commercially available from most major science supply companies, from electrode manufacturers, or may be formulated from mixtures described in chemical handbooks such as those by Dean and Bruno and Svoronos, listed in the bibliography. Certified buffers can be purchased from NIST, but these are only needed for extremely accurate work.

The pH meter is calibrated (to compensate for asymmetry and other potentials and variations in the reference electrode) by immersing the glass electrode and the reference electrode in a buffer solution of known pH, which we will call pH_{std}. The potential of the cell is measured, and is designated $E_{\rm std}$. The electrodes are then placed in the sample, pH_{unk}, and the potential $E_{\rm unk}$ is measured. The pH of the sample is calculated from:

(13.19)
$$pH_{unk} = pH_{std} - \frac{(E_{unk} - E_{std})}{0.05916}$$

Equation 13.19 is the operational definition of pH at 25 °C.

It is best to calibrate the instrument at a pH near to that of the sample or at two pH values that bracket the sample pH. If necessary, calibration can be performed at multiple pH levels, such as pH 4.00, 7.00, and 10.00 to check the linearity of the system. The use of a calibration curve gives the best empirical relationship between voltage and concentration, but the accuracy depends on matching the ionic strength of the sample to that of the standards to avoid differences in activity coefficients. This can be difficult to do in high ionic strength samples and complex matrices. In these cases, the method of standard additions (MSA) may be used to advantage (Section 13.3.1.3.6).

There are several sources of error in the routine measurement of pH. One source of error that may occur with any pH probe, not just glass electrodes, is in the preparation of the calibration buffer or buffers. Any error in making the buffer or any change in composition on storage of the buffer will result in error in the pH measured. Common problems with buffers are bacterial growth or mold growth in organic buffers, and absorption of CO_2 from air by very basic buffers (thereby making them less basic). Guidelines on storage of buffers, preservatives that can be added, and other practical advice can be found in the reference by Dean. The accuracy of the measured pH can be no more accurate than the pH of the calibration buffer.

Glass electrodes become sensitive to alkali metal ions in basic solution (pH > 11) and respond to H⁺ and Na⁺, K⁺, and so on. This results in the measured pH being *lower* than the true pH. The magnitude of this **alkaline error** depends on the composition of the glass membrane and the cation interfering. It results from ion-exchange equilibria at the glass membrane surface between the alkali metal ions in the glass and the alkali metal ions in solutions. Special glass compositions are made for electrodes that are used in highly alkaline solutions to minimize the response to non-H⁺ ions.

Glass electrodes also show an error in extremely acidic solutions (pH < 0.5). The **acid error** is in the opposite direction to the alkaline error; the measured pH values are too high. The cause of the acid error is not understood.

Variations in junction potential between calibration standards and samples lead to errors in pH measurement. Absolute accuracy of 0.01 pH units is difficult to obtain, but relative differences in pH as small as 0.001 pH units can be measured. The operational definition of pH is only valid in dilute solutions, with ionic strengths <0.1 and in the pH range 2-12. Both very high ionic strength solutions and very low ionic strength solutions (e.g., unpolluted lake water) can have serious errors in pH measurement caused by nonreproducible junction potentials.

13.3.1.3.4 pH Titrations Direct measurement of pH can be used for quantitative acid-base titrations. For example, if NaOH is added slowly to HCl, the following reaction takes place:

Original solution :
$$HCl \rightarrow H^+ + Cl^-$$

Addition of NaOH : $H^+ + Cl^- + Na^+ + OH^- \rightarrow H_2O + Na^+ + Cl^-$

In the process, $[H^+]$ decreases and the potential of the pH electrode changes 59.16 mV for every unit change in pH. Near the neutralization point, the pH changes very rapidly with the addition of small amounts of NaOH. A plot of cell potential versus the volume (in mL) of NaOH added gives the relationship in Figure 13.17. The equivalence point of the titration is the inflection point of the curve.

Use of potentiometry for pH titration allows analyses to be carried out in colored or turbid solutions. Also, it solves the problem of selecting the correct indicator for a particular acid-base titration. The endpoint can be determined more accurately by using a first or second derivative curve as described earlier. It also permits pH titrations in nonaqueous solvents for the determination of organic acids and bases as described subsequently. In addition, it can be readily automated for unattended operation.

Most organic acids and bases and some inorganic weak acids and bases are too weak to be titrated in aqueous solution. This is a result of the **leveling effect**; the strongest acid that can exist in water is H⁺ and the strongest base that can exist in water is OH⁻. All acids that dissociate to give a proton are leveled to the same acid strength in water. For very weak acids and bases, the equilibrium constant for the titration reaction in water may not be large enough to give a distinct endpoint. It is common practice, therefore, to choose a nonaqueous solution for these determinations. In a nonaqueous solvent, different acids are not leveled to the same extent. The nonaqueous solvents are chosen based on their acidity, dielectric constant, and the solubility of the sample in the solvent. It is important that the acidity of the solvent not be too great; otherwise, the titrant is used up in titrating the solvent rather than the sample. The same principles apply to the titration of bases, in that the solvent must not be too basic;




FIGURE 13.17 Schematic plot of the potentiometric titration of a strong acid with NaOH. A pH electrode can be used as the indicator electrode.

otherwise, reaction between the sample base and the titrant is not observed. The dielectric constant affects the relative strength of dissolved acids. For example, negatively charged acids become relatively stronger compared to uncharged acids (such as formic acid) as the dielectric constant of the solvent is decreased. It is also important that the sample be soluble in the solvent, otherwise the reactions will be incomplete and unobservable. An advantage of using an organic solvent is that substances that are not soluble in water may be determined.

The types of cells used vary with the solvent employed. Glass and SCE electrodes may be used if the solvent is an alcohol, ketone, or acetonitrile but special modification of the salt bridge in the SCE is necessary. Platinum electrodes may be used for titrations with tetrabutylammonium hydroxide (TBAH), (C_4H_9) $_4$ NOH, dissolved in a benzene-methanol mixture or in MIBK. When TBAH is added to a sample that contains more than one acid functionality, it first reacts with the strongest acid in solution until reaction is virtually complete. It then commences reaction with the second strongest acid until the second reaction is complete, and so on. In a solution containing two different acid groups, if the K_a values differ enough, two equivalence points can be observed in a plot of emf (in mV) versus mL of titrant. These two acid groups may be on the same compound, that is, a diprotic acid, or they could be two different monoprotic acids (a mixture). A schematic illustration of a titration of a mixture of three weak organic acids with TBAH is shown in Figure 13.18. **Nonaqueous titrations** have been used to determine amino acids, amines, alkaloids, carboxylic acids, many drugs such as barbiturates and antihistamines, and alcohols, aldehydes, and ketones.

The experimental setup for titrations in nonaqueous solvents differs from those in aqueous solution and specialized texts (e.g., Huber) should be consulted.

13.3.1.3.5 Quantitative Determination of lons Other than Hydrogen ISEs can be used for the analysis of aqueous and nonaqueous solutions alike and have found increasing applications in organic chemistry, biochemistry, and medicine. Furthermore, in many circumstances, no sample preparation is necessary. As a result, the use of ISEs is particularly valuable for obtaining rapid results with no loss of volatile analytes. ISE potentiometry can be considered




FIGURE 13.18 Schematic plot of the potentiometric titration of three weak acids with tetrabutylammonium hydroxide. Note the equivalence points after the addition of 3.5, 8.5, and 13.0 mL of titrant.

nondestructive, since the amount of contamination of the sample by leaking electrolyte is usually negligible. These electrodes can even be used for continuous analysis of waters and industrial plant streams simply by inserting the electrodes into the sample (such as the river or plant stream) and measuring the voltages generated.

It must be remembered that the cell potential is proportional to the ln(activity) of the ion rather than its concentration. The activity is a measure of the extent of thermodynamic nonideality in the solution. The activity coefficient is usually less than unity, so the activity of a solution is generally lower than the total concentration, but the values of activity and concentration approach each other with increasing dilution. If a compound is not completely ionized, the activity is further decreased. Decreased ionization can be brought about because of a weak ionization constant, chemical complexation, or a high salt concentration in the solution. Any of these factors will cause a change in the potential of the cell, even if the ion concentration is constant. In practice, it is better to determine the relationship between the cell potential and ion *concentrations* experimentally.

ISEs are calibrated in a manner similar to pH electrodes. Standard solutions of known concentrations of the ion to be measured are used and a plot of the cell emf versus concentration is made. It is important to keep the ionic strength and other matrix components of the samples and standards the same. This is often done by adding the same amount of a high ionic strength buffer to all samples and calibration standards. In some cases, the buffer may also adjust the pH if the form of the ion to be measured is pH-dependent. The determination of fluoride ion is an example of this approach. All samples and standards have the same amount of a commercial buffer called TISAB (total ionic strength adjusting buffer) that also controls pH to ensure that fluoride is present as F-, not HF, because the fluoride electrode does not respond to HF.

Electrodes that behave in a Nernstian manner will have slopes equal to 59.16 mV per pIon unit for monovalent cations, (59.16/2) mV per pIon unit for divalent cations, –59.16 mV per pIon unit for monovalent anions, and so on, at 25 °C. pIon is defined exactly as is pH, as the negative logarithm to the base 10 of the ion concentration (activity) in M, giving pF, pCa, pAg, and so on. Many plots of concentration versus voltage for ISEs deviate from linearity due to activity coefficient effects, so an alternate approach is to use the MSA for calibration, especially for complex matrices.

ISEs have been used for the determination of sodium and potassium in bile, nerve and muscle tissue, kidneys, blood plasma, urine, and other body fluids. ISEs are used for the analysis of ions in sea water, river water, and industrial water and wastewater, as well as in a wide variety of commercial products, such as personal care and cosmetic products. The advantages of ISEs are that they are fast, with response times <1 min for most ISEs; they are a nondestructive technique, have a linear range of about six orders of magnitude in concentration, usually over the 10^{-6} to 1 M range, and they can be used in turbid or highly colored solutions. The disadvantages are that a different electrode is needed for each ionic species, the electrodes are selective but not specific, so interferences can occur, and the electrodes can become plugged or contaminated by components of the sample. The ionic species must be in solution and in the proper oxidation state to be detected by the electrode.

13.3.1.3.6 Calibration by Method of Standard Additions In the construction of standard addition curves for calibration, we assume that the potential is proportional to the log of the concentration. Let the original ion concentration be C_0 and the solution volume be V_0 (in L). The initial potential is given by:

(13.20)
$$E_1 = \text{const.} + 2.303 \frac{RT}{nF} \log C_0$$

It is usual to add a **small** volume V_s of a standard solution of concentration C_s from a microliter pipette such that the concentration becomes $(C_0V_0 + C_sV_s)/(V_0 + V_s)$ and the new potential E_2 is given by:

(13.21)
$$E_2 = \text{const.} + 2.303 \frac{RT}{nF} \log \left(\frac{C_0 V_0 + C_s V_s}{V_0 + V_s} \right)$$

Subtracting Equation 13.20 from Equation 13.21, we have:

$$\Delta E = 2.303 \frac{RT}{nF} \log \left(\frac{C_0 V_0 + C_s V_s}{C_0 (V_0 + V_s)} \right)$$

If we note that $V_0 \gg V_s$,

$$\Delta E \approx 2.303 \frac{RT}{nF} \log \left(\frac{C_0 V_0 + C_s V_s}{C_0 V_0} \right) \approx 2.303 \frac{RT}{nF} \log \left(1 + \frac{C_s V_s}{C_0 V_0} \right)$$

This expression, in turn, can be rearranged as:

(13.22)
$$1 + \frac{C_{\rm s}V_{\rm s}}{C_{\rm 0}V_{\rm 0}} = 10^{nF\Delta E/2.303RT}$$

from which we can obtain the concentration of the unknown by plotting $(10^{n\text{F}\Delta E/2.303RT}-1)$ versus V_s for several additions of the standard. Then, the slope m will have the value C_s/C_0V_0 and the unknown concentration is calculated from:

(13.23)
$$C_0 = \frac{C_s}{mV_0}$$

The method is usually very sensitive. Special buffers may be required to avoid problems with interfering ions. In general, two additions should be made where possible, with the concentration doubled from the original concentration. It is assumed that the additions do not change the ionic strength or the junction potentials significantly.

13.3.1.3.7 Oxidation-Reduction Titrations Potentiometry can be used to follow reduction-oxidation (redox) titrations. For example, the oxidation of stannous ions by ceric ions follows the chemical reaction:

$$\text{Sn}^{2+} + 2\text{Ce}^{4+} \rightarrow \text{Sn}^{4+} + 2\text{Ce}^{3+}$$

It is usually best to first identify the two half-cell reactions and to find the total number of electrons n in the reaction (n must be the same for each half-cell reaction, so it may be necessary to balance the half-reactions) and to look up the standard reduction potentials in Appendix 13.A (text website):

$$Sn^{2+} \rightarrow Sn^{4+} + 2e^{-}$$
 $E^{0} = +0.13 \text{ V}$
 $2Ce^{4+} + 2e^{-} \rightarrow 2Ce^{3+}$ $E^{0} = +1.74 \text{ V}$

The net $E_{\text{cell}}^0 = 1.74 \text{ V} - 0.13 \text{ V} = +1.61 \text{ V}$. The emf E(A) of the half-cell is given by the Nernst equation for a stannous/stannic half-cell, with the stannous ion oxidizing to stannic ion:

(13.24)
$$E(A) = E^{0}(Sn^{2+}/Sn^{4+}) + \frac{0.05916}{2} \log \left(\frac{[Sn^{4+}]}{[Sn^{2+}]} \right)$$

For the ceric/cerous half-cell, with ceric ion reduced

(13.25)
$$E(B) = E^{0}(Ce^{3+}/Ce^{4+}) - \frac{0.0591}{2} \log\left(\frac{[Ce^{3+}]^{2}}{[Ce^{4+}]^{2}}\right)$$

At all times, the emf produced by each half-cell must be equal to that of the other because the mixture cannot exist at two potentials. Therefore, from the Nernst equation, we have:

$$E_{\text{cell}} = E_{\text{cell}}^0 - \frac{0.05916}{2} \log \frac{[\text{Sn}^{4+}][\text{Ce}^{3+}]^2}{[\text{Sn}^{2+}][\text{Ce}^{4+}]^2}$$

Since the equilibrium constant for this reaction is:

$$K_{\text{eq}} = \frac{[\text{Sn}^{4+}][\text{Ce}^{3+}]^2}{[\text{Sn}^{2+}][\text{Ce}^{4+}]^2}$$

at equilibrium,

(13.26)
$$E_{\text{cell}}^0 = \frac{0.0591}{2} \log K_{\text{eq}}$$

A similar relationship is true for all equilibrium redox reactions. With knowledge of $E^0(Sn^{2+}/Sn^{4+})$ and $E^0(Ce^{3+}/Ce^{4+})$ it is possible to calculate the equilibrium constant for the reaction.

It is possible to calculate the *equivalence point potential* by noting that we cannot ignore the small concentrations of Sn^{2+} and Ce^{4+} remaining, even though the overall reaction may be close to completion. The stoichiometry at the equivalence point demands that:

$$2\left[\operatorname{Sn}^{4+}\right] = \left[\operatorname{Ce}^{3+}\right]$$

and

$$2\left[\operatorname{Sn}^{2+}\right] = \left[\operatorname{Ce}^{4+}\right]$$

If we let the potential at equivalence be E_{eq} ,

$$E_{\text{eq}} = E^{0} (\text{Ce}^{3+}/\text{Ce}^{4+}) + \frac{0.0591}{2} \log \left(\frac{[\text{Ce}^{4+}]^{2}}{[\text{Ce}^{3+}]^{2}} \right)$$
$$2E_{\text{eq}} = 2E^{0} (\text{Sn}^{2+}/\text{Sn}^{4+}) + \frac{0.0591}{2} \log \left(\frac{[\text{Sn}^{4+}]^{2}}{[\text{Sn}^{2+}]^{2}} \right)$$

Adding these two expressions and substituting the values for the Ce ion species in terms of Sn, the log term becomes equal to zero:

$$\log\left(\frac{2[Sn^{2+}]^2[Sn^{4+}]^2}{2[Sn^{4+}]^2[Sn^{2+}]^2}\right) = \log 1 = 0$$

Thus $3E_{\rm eq}=E^0({\rm Ce^{3+}/Ce^{4+}})+2E^0({\rm Sn^{2+}/Sn^{4+}})$. In practice, it is often easier to observe the equivalence point than to calculate it! If you must calculate the shape of a redox titration curve, the use of a spreadsheet program such as Excel is invaluable because of the multiple equilibrium equations that must be solved. (See the text by Harris for excellent examples of spreadsheet calculations for redox titrations.)

The relationship between the emf of the cell and the number of milliliters of ceric salt added to the stannous solution is of the same form as Figure 13.15. The equivalence point is denoted by a rapid change in potential as the ceric salt is added. If necessary, the first and second derivatives of the curve may be taken to detect the endpoint as shown in Figure 13.16. From the data obtained, calculations of solution concentrations and other variables are done in the same manner as in conventional volumetric analysis.

The same principle can be used for many redox reactions. The potential of the cell depends on the concentration of the oxidized and reduced forms of ions present. During a titration these concentrations vary as the chemical reaction proceeds:

$$red(A) + ox(B) \rightarrow ox(A) + red(B)$$

where red(A) is the reduced form of ion A, ox(B) is the oxidized form of ion B, and so on. At the equivalence point there is a rapid change in potential with the addition of the titrating solution. This change makes it possible to detect the equivalence point of the reaction. Typical inorganic oxidation—reduction reactions include:

$$2Fe^{2+} + Sn^{4+} \rightarrow 2Fe^{3+} + Sn^{2+}$$

$$5V^{2+} +3MnO_{4}^{-} + 4H^{+} \rightarrow 5VO_{2}^{+} + 3Mn^{2+} + 2H_{2}O$$

$$IO_{3}^{-} + 8I^{-} + 6H^{+} \rightarrow 3H_{2}O + 3I_{3}^{-}$$

$$I_{3}^{-} + 2S_{2}O_{3}^{2-} \rightarrow 3I^{-} + S_{4}O_{6}^{2-}$$

Organic compounds may be determined by redox titrimetry, including glucose and other reducing sugars, vitamin C, thiols such as cysteine, and many other organic chemicals of biological importance. There are thousands of potentiometric redox titration methods published in the chemical literature.

It may be necessary to correct for interferences to a method depending on your sample. For example, the presence of traces of other oxidizing or reducing compounds may displace the equilibrium and give an incorrect voltage for the equivalence points. Many equilibria are pH sensitive, and this too may generate inaccurate results. Care must be taken to correct for these interference effects.

13.3.2 COULOMETRY

Coulometry is the term used for a group of methods based on electrolytic oxidation or reduction of an analyte. The electrolysis is performed by controlling the potential, and is carried out to quantitatively convert the analyte to a new oxidation state. Coulometry is based on Faraday's Law, which states that the extent of reaction at an electrode is proportional to the current. It is known that 1 F (96,485 C) of electricity is required to reduce (or oxidize) 1 gram-equivalent weight of an electroactive analyte. By measuring the quantity of electricity required to reduce (or oxidize) a given sample exhaustively, the quantity of analyte can be determined, provided the reaction is 100 % efficient (or of known efficiency). Mass, or charge q = i (A) × t (s), can be used as a measure of the extent of the electrochemical reaction.

A cell operating spontaneously is called a **galvanic cell** (cf. Figure 13.2). It is possible to cause a cell to react in the nonspontaneous direction by application of a sufficient potential. A cell operated in this manner is called an **electrolytic cell**. The process of causing a thermodynamically nonspontaneous oxidation or reduction reaction to occur by application of potential or current is called **electrolysis**. Electrolysis is carried out for a sufficient length of time to convert a species quantitatively to a new oxidation state. There are three primary electroanalytical methods based on electrolysis; they are **constant-current coulometry** (coulometric titrimetry), **constant-potential coulometry**, and **electrogravimetry**. In electrogravimetry, the product of the electrolysis (usually a metal) is plated out on one of the electrodes and the amount is determined by weighing the electrode. The charge is measured in the **coulometric methods**. In contrast to potentiometry, where we did not want to change the concentration of the species in solution, electrolytic methods are designed to completely consume the species being measured by converting it quantitatively to a new species.

If we consider the Zn/Cu galvanic cell, we might consider how to reverse the reaction. If a sufficient voltage is applied in the opposite direction, from a power source or battery, there will be a tendency for these reactions to reverse, provided that no new reactions occur. In this case, if we try to electrodeposit Zn from aqueous solution by forcing the

reaction $Zn^{2+} + 2e^- \rightarrow Zn(s)$, the evolution of hydrogen from the water will take precedence by the reaction $2H^+ + 2e^- \rightarrow H_2(g)$.


There is much more water in the cell than Zn^{2+} , so the applied voltage goes to form H_2 and we get no deposition of Zn(s). We say that the Zn/Zn^{2+} (aq) half-cell is *chemically irreversible*. On the other hand, the copper will dissolve if made an anode in an acidic solution, so the reaction $Cu(s) \rightarrow Cu^{2+} + 2e^-$ is said to be *chemically reversible*.

The differences and similarities between an electrochemical cell and an electrolysis cell are summarized in Figure 13.19. Oxidation always occurs at the anode and reduction always occurs at the cathode; notice, however, that in a spontaneous cell, the positive electrode is the one at which reduction takes place, whereas in an electrolysis cell, the negative electrode is the one at which reduction takes place. Negatively charged anions, such as Cl^- , NO_3^- , and $SO_4^{2^-}$, are attracted to a positive electrode. Positively charged cations, such as Na^+ , Ca^{2^+} , and Mg^{2^+} , are attracted to a negative electrode. Under the influence of the applied voltage in an electrolysis cell, the H^+ and Zn^{2^+} ions are attracted to the negative electrode, the cathode; the $SO_4^{2^-}$ and OH^- ions are attracted to the positive electrode, the anode. Electrons are consumed at the cathode by H^+ ions to evolve hydrogen gas in the electrolysis cell, but are consumed by Cu^{2^+} ions in the spontaneous cell to deposit Cu atoms. For continuous operation of either type of cell, it is necessary for both the anode and cathode reactions to proceed with equal numbers of electrons.

Frequently, the reaction that proceeds at either the anode or cathode is the decomposition of the solvent; if water is the solvent, it may electrolyze. Note that water electrolysis depends on the pH:

For reductions:
$$2H^+ + 2e^- \rightarrow H_2$$

 $2H_2O + 2e^- \rightarrow H_2 + 2OH^-$
For oxidations: $2H_2O - 4e^- \rightarrow O_2 + 4H^+$
 $4OH^- - 4e^- \rightarrow O_2 + 2H_2O$



Spontaneous reactions:

 $Zn \rightarrow Zn^{2+} + 2e^-$ (anodic oxidation) $Cu^{2+} + 2e^- \rightarrow Cu$ (cathodic reduction) (a) Electrolysis:

 $2H^+ + 2e^- \rightarrow H_2$ (cathodic reduction) $Cu \rightarrow Cu^{2+} + 2e^-$ (anodic oxidation) (b)

FIGURE 13.19 Comparison of (a) a galvanic cell and (b) an electrolysis cell.

The major advantage of coulometry is its high accuracy, because the "reagent" is electrical current, which can be well controlled and accurately measured. Coulometry can be considered to be an analytical technique that requires no chemical standards. Coulometry is used for analysis, for generation of both unstable and stable titrants "on demand", and for studies of redox reactions and evaluation of fundamental constants. With careful experimental technique, it is possible to evaluate the Faraday constant to seven significant figures, for example.

Some typical important industrial applications of coulometry include the continuous monitoring of mercaptan concentration in the materials used in rubber manufacture. The sample continuously reacts with bromine, which is reduced to bromide. A third electrode measures the potential of Br₂ versus Br and, based on the measurement, automatically regulates the coulometric generation of the bromine. Coulometry is used in commercial instruments for the continuous analysis and process control of the production of chlorinated hydrocarbons. The chlorinated hydrocarbons are passed through a hot furnace, which converts the organic chloride to HCl. The latter is dissolved in water and the Cltitrated with Ag⁺. The Ag⁺ is generated by coulometry from a silver electrode, Ag⁰. It is necessary for the sample flow rate to be constant at all times. Integration of the coulometric current needed to oxidize the silver-to-silver ion results in a measurement of the Cl⁻ concentration.

Another interesting application of coulometry is in the generation of a chemical reagent in solution. Acids, bases, reducing agents, and oxidizing agents can all be generated in solution and allowed to react in exactly the same manner as reagents in volumetric analysis. In effect, volumetric titrations can be carried out by generating the titrant electrochemically; the amount of titrant used is then measured directly by the amount of electricity used to generate it. This method is very exact, frequently more so than weighing the reagent. Reagents generated electrochemically are extremely pure. With coulometry we can obtain results that are more accurate than those possible with the purest commercially available reagents.

13.3.2.1 INSTRUMENTATION FOR ELECTROGRAVIMETRY AND COULOMETRY

The basic apparatus required is a power supply (potentiostat with a DC output voltage), an inert cathode and anode [usually platinum foil, gauze, or mesh (Figure 13.20)], and arrangements for stirring. Sometimes a heater is used to facilitate the processes.

Electrogravimetry is usually carried out under conditions of controlled potential, so an auxiliary reference electrode is used together with the working electrode. The working electrode can be either the anode or the cathode. The auxiliary electrode-working electrode pair



FIGURE 13.20 A variety of Pt electrodes for electrochemistry. (Courtesy of XRF Scientific, www.xrfscientific.com.)

is connected to a potentiostat that fixes the potential of the working electrode by automatically adjusting the applied emf throughout the course of the electrolysis.

The working electrode should have a large surface area. Platinum is used because it is inert; Pt gauze or mesh electrodes are used to provide a large surface area (Figure 13.20). The electrode "mesh" is like wire window-screening material, with the wire diameter about 0.2 mm. The mesh is welded into an open cylinder to make the electrode. A standard size is a cylinder about 5 mm high and 5 mm in diameter, but Pt mesh electrodes of many sizes are available. See the XRF Scientific website at xrfscientific.com for examples.

Because the deposition needs to be quantitative, the solution must be stirred during electrolysis. A magnetic stirrer is commonly used, often as a combination stirrer-hot plate. For electrogravimetry, an analytical balance of the appropriate capacity and sensitivity is needed. The electrode on which deposition will occur is weighed before the experiment is started. The electrode with the deposit is removed from solution upon completion of the electrolysis, washed, dried, and then reweighed. For coulometric methods, the charge is measured. The charge is obtained by integration of the current using an electronic integrator.

It is critical for these techniques that the current efficiency be as close to 100 % as possible. The percent current efficiency tells us how much of the applied current results in the reaction of interest. The percent current efficiency is defined as being equal to $100 \times (i_{\rm applied} - i_{\rm residual})/i_{\rm applied}$, where $i_{\rm applied}$ is the current applied to the cell and $i_{\rm residual}$ is the "background" current. All real cells have some residual current. To achieve a 99.9 % current efficiency, the applied current must be approximately $1000 \times$ the residual current. This is readily achieved for currents in the μA to 100 mA range used in constant-current coulometry.

13.3.2.2 APPLIED POTENTIAL

We may now consider on a more quantitative basis what influence the applied potential has. If the cell could behave as a thermodynamic cell and the reactants were under standard conditions, we might expect that the voltage needed would be that given by the net reaction, for example, for electrodeposition of Cu from a NiCu alloy,

Net reaction:
$$2H_2O + 2Cu^{2+} \rightarrow 2Cu + O_2 + 4H^+$$
 $E_{net} = -0.892 \text{ V}$

But this would be for an infinitesimal, reversible change and, similar to any other chemical reaction, an electrochemical reaction has an *activation energy* that must be overcome for the reaction to occur. In fact, an additional voltage termed the **overpotential**, η , is required to drive the electrode reactions. About 2 V has to be applied to reach the current onset of the cell described, and this threshold is sometimes called the *decomposition voltage*. Thus, the total potential that we must apply across the cell is:

$$(13.27) E_{\text{decomp}} = E_{\text{net}} + IR + \eta$$

An overpotential contribution is required for both the anodic and the cathodic reaction and, in this case, it is mainly to oxidize water at the Pt anode. As copper is deposited and the concentration of Cu^{2+} ions fall, both the ohmic potential drop, IR, across the electrolyte and the overpotential decrease. If we assume that the solution resistance R remains fairly constant, the ohmic potential drop is directly proportional to the net cell current. The overpotential increases exponentially with the rate of the electrode reaction. Once the Cu^{2+} ions cannot reach the electrode fast enough, we say that *concentration polarization* has set in. An ideally polarized electrode is one at which no Faradaic reactions ensue; that is, there is no flow of electrons in either direction across the electrode-solution interface. When the potential of the cathode falls sufficiently to reduce the next available species in the solution (H⁺ ions, or nitrate depolarizer), the copper deposition reaction is no longer 100 % efficient.

Vigorous stirring, therefore, is necessary for several purposes. It helps to dislodge the gas bubbles that form at the electrodes. More importantly, it provides convective transport of the Cu^{2+} ions to the cathode as the solution becomes increasingly dilute in Cu^{2+} ion. At this point, if the applied voltage is raised to increase the current density, the potential could

become sufficiently negative to cause the reduction of the next easiest reduced species present, in this case H⁺ ions:

$$2H^+ + 2e^- \rightarrow H_2$$
 $E^0 = 0.00 \text{ V}$

Such evolution of H_2 gas can produce unsatisfactory copper deposits in electrogravimetry, which may flake off and lead to a poor analytical determination. To prevent this, it is usual to add a cathodic depolarizer of NO_3^- ion to the solution. A *depolarizer* is a species more readily reducible than H^+ ion but one that does not complicate the cathodic deposit by occlusion or gas entrapment. In this instance, the product is ammonium ions:

$$NO_3^- + 10H^+ + 8e^- \rightarrow NH_4^+ + 3H_2O$$

If the potential becomes too negative at the cathode, the Ni²⁺ ion from our alloy sample might commence to deposit and form an alloy deposit. Note that the order of selectivity is not always that predicted by the standard potentials in the activity series. Control of the pH and the chelates or complexing agents in a solution may alter the reduction-oxidation potentials from those of an uncomplexed species.

Perhaps the most common example of overvoltage encountered in electrochemistry is that needed to reduce H^+ ions at a mercury electrode. On a catalytic Pt surface (platinized Pt, which is a large-surface-area, black Pt deposit on Pt metal) the H_2/H^+ ion couple is said to behave reversibly. This means that one can oxidize hydrogen gas, or reduce H^+ ions, at the standard reduction potential, 0.00 V, under standard conditions. At a mercury cathode, however, it takes about -1 V versus SHE to reduce H^+ ions, because hydrogen evolution is kinetically slow. This phenomenon has great importance in polarography, because it enables the analysis of many of the metals whose standard potentials are negative versus the SHE.

13.3.2.3 ELECTROGRAVIMETRY

If a solution of a metallic ion, such as copper, is electrolyzed between electrodes of the same metal (i.e., copper), the following reaction takes place:

$$Cu^0 \rightarrow Cu^{2+} + 2e^-$$
 (anode)

$$Cu^{2+} + 2e^{-} \rightarrow Cu^{0}$$
 (cathode)

The net result is that metal dissolves from the anode and deposits on the cathode. The phenomenon is the basis of electroplating (e.g., chromium plating of steel). Also, it is the analytical basis of an electrodeposition method known as *electrogravimetry*. This involves the separation and weighing of selected components of a sample. Most metal elements can be determined in this manner, usually deposited as the M⁰ species, although some metal elements can be deposited as oxides. The halides can be determined by deposition as the silver halide. Metals commonly determined include Ag, Bi, Cd, Co, Cu, In, Ni, Sb, Sn, and Zn.

Electrogravimetry is generally performed under a constant, controlled potential but can also be performed under conditions of controlled current. For example, a metal alloy may contain nickel and copper. The alloy can be dissolved and the solution electrolyzed, with the result that the copper is selectively and exhaustively deposited on the cathode. The electrodeposited copper should form an adherent coating so that it can be washed, dried, and weighed. (The formation of appropriate forms of deposit has been studied thoroughly and is critical to obtaining accurate results. See the handbook by Dean for detailed information and references.) Instead of dissolution of the platinum metal taking place at the platinum anode, oxygen gas is liberated from the aqueous solution. As a consequence, platinum is a useful electrode material for redox purposes, since it is not consumed in the process. The initial reactions are as follows:

cathode:
$$Cu^{2+} + 2e^{-} \rightarrow Cu$$
 $E^{0} = +0.337 \text{ V}$
anode: $2H_{2}O - 4e^{-} \rightarrow O_{2} + 4H^{+}$ $E^{0} = -1.229 \text{ V}$
Net reaction: $2H_{2}O + 2Cu^{2+} \rightarrow 2Cu + O_{2} + 4H^{+}$ $E_{\text{net}} = -0.892 \text{ V}$

Controlled potential electrolysis (potentiostatic control) requires a three-electrode cell, so as not to polarize the reference electrode. Controlled potential methods enable one to be very selective in depositing one metal from a mixture of metals. If two components have electrochemical potentials that differ by no more than several hundred millivolts, it may still be possible to shift these potentials by complexing one of the species. One disadvantage of exhaustive electrolysis is the time required for analysis, and faster methods of electrochemical analysis are described. Electrogravimetry depends on weighing the WE before and after plating out the element under test. Therefore, it is limited to the determination of electroactive species where the product of electrolysis is a solid that forms a suitable deposit.

In summary, important practical considerations in precise electrodeposition are (1) rapid stirring, (2) optimum temperature, (3) correct controlled potential or correct current density (usually expressed in A/dm²), and (4) control of pH. The proper conditions have all been worked out for hundreds of systems; when these conditions prevail, deposits are bright and adherent and no unusual precautions are necessary in handling (washing, drying, weighing, etc.) the electrode. In commercial electroplating, additives (glue, gelatin, thiourea, etc.) are used as brighteners and for good adherence. They are not used in analytical deposition, because they would cause the weight of deposit to be erroneously high and would create interferences in the method. Electrodeposits improve the appearance, wear, and corrosion resistance of many fabricated metal parts. Electrolysis is also used to recharge batteries, study electrode reactions, extract pure metals from solutions, create shapes that cannot be machined (electroforming) and eliminate metallic impurities from solutions.

13.3.2.4 ANALYTICAL DETERMINATIONS USING FARADAY'S LAW

As an alternative to weighing the deposit in electrogravimetry, the quantity of electricity used to deposit the metal can be measured. From this measurement, the quantity of metal deposited or the quantity of ions reduced or oxidized can be calculated. This is an advantage if the product of electrolysis is a gas or another soluble ionic species; electrogravimetry will not work for these analytes. The calculation is based on Faraday's Law, which states that equal quantities of electricity cause chemical changes of equivalent amounts of the various substances electrolyzed. The advantage of measuring the charge is that coulometry can measure electroactive species that do not form solid deposits, so it has much wider application. The accuracy is as good as gravimetric methods and coulometry is much faster than gravimetry and classical volumetric methods of analysis.

Charge is measured in either Coulombs or Faradays. One Coulomb (C) is the amount of charge transported in one second by a current of 1 ampere. One Faraday (F) is the charge in coulombs of one mole of electrons, so $1 \text{ F} = 96,485 \text{ C/mol e}^-$.

The relationship between charge and amount of analyte for a constant current, *i*, can be stated as:

$$(13.28) q = nFVM = \frac{nFw}{M_{W}} = i \times t$$

when q is the charge (in Coulombs); n, the number of equivalents per mole of analyte; F, the Faraday constant; V, the volume (L); M, the molar concentration of analyte (mol/L); w, the weight of analyte (g); M_w is the molecular weight of the analyte (g/mol); i, the current (A); and t, time(s). This relationship involves only fundamental quantities; there are no empirically determined "calibration factors", so standardization and calibration are not required. This makes coulometry an **absolute method**; it does not require calibration with external standards. The current efficiency must be 100 %. For a variable current, the charge is given by:

$$q = \int_{0}^{t} i \, \mathrm{d}t$$

Example A

A sample of stannic chloride was reduced completely to stannous chloride according to the reaction $\text{Sn}^{4+} + 2e^- + \text{Sn}^{2+}$.

The applied current was 9.65 A and the time taken for reduction was 16.0 min 40 s. What was the initial weight of stannic ion present? First, convert the time to seconds. $16.0 \, \text{min} \times 60 \, \text{s/min} = 960 \, \text{s}$. Adding the additional 40 s gives a total time of $1.00 \times 10^3 \, \text{s}$.

number of coulombs =
$$i(A) \times t(s)$$

= $9.65A \times 1.00 \times 10^3 s$
= $9650 C$
number of faradays = $\frac{9650}{96,500}$ = $0.100 F$

But 1 F will reduce 1 g-eq weight of stannic ion:

1 g-eq wt. =
$$\frac{\text{atomic wt. of tin}}{\text{valence change}} = \frac{118.69 \text{ g/mol}}{2 \text{ eq/mol}}$$

that is, 1 F will reduce 59.35 g of stannic ion, or 0.100 F will reduce 5.935 g of stannic ion.

Example B

If the original volume of the solution was 250.0 mL, what was the molarity of the solution?

Molarity means moles of solute contained in exactly 1 L of solution. The atomic weight of tin, the solute, is 118.69 g/mol. It was shown in example A that 5.935 g of tin were reduced and example A stated that the reduction was complete. The molarity of the solution is calculated from:

mol Sn = 5.935 g Sn
$$\times \frac{1 \text{ mol Sn}}{118.69 \text{ g}}$$

mol Sn = 0.05000 mol

and

$$L_{\text{solution}} = 250.0 \,\text{mL} \times \frac{1.000 \,\text{L}}{1000 \,\text{mL}} = 0.2500 \,\text{L}$$

Therefore, the molarity of the solution was 0.05000 mol Sn/0.2500 L = 0.200 M stannic chloride to three significant figures.

Equation 13.28 allows us to calculate the amount of an electroactive species in either molarity or weight of material electrolyzed.

Amperometry is the measurement of current at a fixed potential. An analyte undergoes oxidation or reduction at an electrode with a known, applied potential. The amount of analyte is calculated from Faraday's Law. Amperometry is used to detect titration end-points, as a detector for liquid chromatography and forms the basis of many new sensors for biomonitoring and environmental monitoring applications.

13.3.2.5 CONTROLLED POTENTIAL COULOMETRY

Coulometry is frequently carried out under conditions of controlled potential. This is achieved by using a third electrode in the system, as described earlier. The three-electrode system maintains the potential at the working electrode at a constant value or permits an

applied voltage pulse or ramp to be added to the working electrode. The reason for using controlled potential can be seen when we examine the Nernst equation. As a metal is oxidized or reduced under experimental conditions, the concentration of the remaining metal ions in the original oxidation state in solution steadily decreases. Therefore, in order to continue the deposition, the potential applied to the system must be steadily increased. When the potential is increased, different elements may begin to react or deposit and interfere with the results. Their deposition results in an increased weight of metal deposited (in electrogravimetry) and an increased number of coulombs passing through the cell in all coulometric methods. Controlled potential is therefore used to eliminate interferences from other reactions that take place at different potentials.

In theory, the equivalence point is never reached, because the current decays exponentially. Since a small amount of material always remains in solution, a correction must be made for it by measuring the current flowing at the end of the analysis. This quantity should be subtracted from the integrated signal in order to give an accurate measure of the material that has deposited or reacted during the experiment.

Controlled potential coulometry, also called bulk electrolysis, is usually used to determine the number of electrons involved in a reaction when studies are being carried out on new inorganic or organic compounds. Using a coulometer, we measure q. If we know $M_{\rm w}$, from mass spectrometric measurements, for example, the number of moles of electrons can be calculated using Equation 13.28. This indicates how the species oxidizes or reduces; it gives us information about the reaction chemistry of new compounds. Controlled potential coulometry is also valuable in generating unstable or highly reactive substances *in situ* with good quantitative control.

13.3.2.6 COULOMETRIC TITRATIONS

An aqueous iodide sample may be titrated with mercurous ion by anodizing a mercury pool electrode. When metallic mercury is oxidized to mercurous ion by a current passing through the system, the mercurous ion reacts directly with the iodide ion to precipitate yellow Hg₂I₂:

$$2Hg - 2e^{-} \rightarrow (Hg_{2}^{2+})$$

 $Hg_{2}^{2+} + 2I^{-} \rightarrow Hg_{2}I_{2}$

The reaction continues and current passes until all the iodide is used up. At this point some means of endpoint detection is needed. Two methods are commonly adopted. The first uses an amperometric circuit with a small imposed voltage that is insufficient to electrolyze any of the solutes. When the mercury ion concentration suddenly increases, the current will rise because of the increase in the concentration of a conducting species. The second method involves using a suitable indicator electrode. An indicator electrode may be a metal electrode in contact with its own ions or an inert electrode in contact with a redox couple in solution. The signal recorded is potentiometric (a cell voltage versus a stable reference electrode). For mercury or silver, we may use the elemental electrodes, because they are at positive standard reduction potentials to the hydrogen/hydrogen ion couple.

Figure 13.21 illustrates an apparatus suitable for the coulometric titration described. The anode and cathode compartments are separated with a fine porous glass membrane to prevent the anode products from reacting at the cathode, and vice versa. The porosity should be such as to allow minimal loss of titrant in the course of the experiment. The electrolysis circuit is distinct from the endpoint detector circuit. A constant current source may be used, but it is not mandatory, provided that the current is integrated over the time of the reaction, that is

$$q = it$$
 (constant current)

or

$$q = \int_{0}^{t} i(t) dt \text{ (integrator)}$$




FIGURE 13.21 Apparatus for coulometric titration with potentiometric endpoint detection.

The potentiometric cell can be written as:

SCE
$$|| 0.1 \text{ M HClO}_4 || \text{Hg}_2^{2+}, 0.2 \text{M NaNO}_3 || \text{Hg}$$

The endpoint is sensed by recording the voltage across the potentiometric cell.

The **Luggin probe** used to monitor the potential of the Hg indicator electrode is spaced close (~1 mm) to the mercury droplet to reduce ohmic resistance. The top barrel is cleaned, wetted with concentrated NaNO₃ solution, and closed. Sufficient conductivity exists in this solution layer to permit the small currents necessary for potentiometric determination. When an excess of mercurous ion is generated, the potential of the Hg/Hg_2^{2+} couple varies in accordance with the Nernst equation, and a voltage follower may be used to output the voltage curve to a computer data system. For precise work, dissolved oxygen should be removed from the supporting electrolyte and efficient stirring is needed.

Coulometric titrimetry has been used for the determination of mercaptan, halide, and phosphorus compounds by using a silver electrode. The principle has also been used for many other types of titrations. Another example is the determination of ferrous ion, Fe²⁺, in the presence of ferric ion, Fe³⁺. This reaction can be controlled directly by coulometric analysis, but cannot be carried out to completion. As the concentration of Fe²⁺ decreases, the Nernst equation indicates that the potential necessary to continue oxidation will steadily increase until water is oxidized and oxygen is evolved. This will take place before completion of the oxidation of ferrous to ferric ions. The problem can be overcome by adding an excess of cerous ions, Ce³⁺, to the solution. The Ce³⁺ ion acts as a *mediator* and itself undergoes no net reaction. With coulometry, the cerous ions can be oxidized to ceric ions, which are then immediately reduced by the ferrous ions present back to cerous ions, generating ferric ions. The reaction continues until all the ferrous ions have been oxidized. At this point any new ceric ions that are formed are not reduced but remain stable in solution, and there is a change in the current flow that signals the endpoint. The endpoint can also be detected using an indicator sensitive to ceric ions.

13.3.3 CONDUCTOMETRIC ANALYSIS

In **conductometry**, an alternating (AC) voltage is applied across two electrodes immersed in the same solution. The applied voltage causes a current to flow. The magnitude of the current depends on the electrolytic conductivity of the solution. This method makes it possible to detect changes of composition in a sample during chemical reactions (e.g., during a titration) although the measurement itself cannot identify the species carrying the current. Conductivity or conductance measurements are used routinely to monitor water quality and process streams. Conductivity detectors are used for measuring ion concentrations in commercial ion chromatography instruments.

The ability of a solution to conduct electricity can provide analytical information about the solution. The property measured is electrical conductivity between two electrodes by ions in solution. All ions in solution contribute to the electrical conductivity, so this is not a specific method of analysis. Electrical conductivity is used to provide qualitative analysis, such as the purity of an organic solvent and relative quantitative analysis for quality control of materials, or comparison of drinking water quality in terms of total ionic contaminants.

Ohm's Law states that the resistance of metal wire is given by the equation:

$$(13.29) R = \frac{E}{i}$$

where E is the voltage applied to the wire (V); i, the current of electrons flowing through the wire (A); and R, the resistance of the wire (Ω).

The resistance R depends on the dimensions of the conductor:

$$(13.30) R = \frac{\rho L}{A}$$

where ρ is the resistivity; *L*, the length; and *A*, the cross-sectional area.

Another valuable parameter, especially when we consider the mechanisms of current flow in solutions, is electrolytic conductivity, κ , where:

(13.31)
$$\kappa = \frac{1}{\rho} = \frac{(L/A)}{R}$$

The units of electrolytic conductivity are Ω^{-1} m⁻¹ (reciprocal ohm m⁻¹ also called mho/m, mho m⁻¹, or S m⁻¹, where S is the siemens). The SI unit is the S/m, but practical measurement units are usually in μ S/cm. **Electrolytic conductivity** is also called *specific conductance*, not to be confused with conductance. The electrolytic conductivity of a solution is a measure of how well it carries a current, in this instance by ionic carriers rather than electron transfer, and it is an intrinsic property of the solution. A related property, the conductance, *G*, is also used and defined as G = 1/R. The **conductance** is a property of the solution *in a specific cell*, at a specific temperature and concentration. The conductance depends on the cell in which the solution is measured; the units of *G* are siemens (S).

The charge carriers are ions in electrolyte solutions, fused salts, and colloid systems. The positive ions M⁺ migrate through the solution toward the cathode, where they may or may not react Faradaically to pick up electrons. Anions, symbolized as A⁻, migrate toward the anode, where they may or may not deliver electrons. The net result is a flow of electrons across the solution, but the electron flow itself stops at each electrode. Faradaic reaction of the easiest reduced and oxidized species present may occur, and hence compositional changes (reduction and oxidation) may accompany ionic conductance.

Electrolyte conductivity depends on three factors: the ion charges, mobilities, and concentrations of ionic species present. First, the number of electrons each ion carries is important, because A^{2-} , for example, carries twice as much charge as A^{-} . Second, the speed with which each ion can travel is termed its *mobility*. The mobility of an ion is the limiting

velocity of the ion in an electric field of unit strength. Factors that affect the mobility of the ion include (1) the solvent (e.g., water or organic), (2) the applied voltage, (3) the size of the ion (the larger it is, the less mobile it will be), and (4) the nature of the ion (if it becomes hydrated, its effective size is increased). The mobility is also affected by the viscosity and temperature of the solvent. Under standard conditions, the mobility is a reproducible physical property of the ion. Because in electrolytes the ion concentration is an important variable, it is usual to relate the electrolytic conductivity to **equivalent conductivity**. This is defined by:

(13.32)
$$\Lambda = \frac{\kappa}{C_{eq}}$$

where Λ is the equivalent conductivity (Ω^{-1} cm²/equivalent or S cm²/equivalent); κ , the electrolytic conductivity (mho/m); and $C_{\rm eq}$, the equivalent concentration (i.e., normality of solution, where N = M × charge on ion).

Electrolyte solutions only behave ideally as infinite dilution is approached. This is because of the electrostatic interactions between ions, which increase with increasing concentration. As infinite dilution is approached, the equivalent conductance of the electrolyte Λ approaches Λ^0 , where:

(13.33)
$$\Lambda^{0} = F(U_{+}^{0} + U_{-}^{0}) = \lambda_{+}^{0} + \lambda_{-}^{0}$$

where U_+^0 and U_-^0 are the cation and anion mobilities, respectively, and λ_+^0 and λ_-^0 are the cation and anion equivalent limiting ion conductivities, respectively, at infinite dilution.

The λ^0 values are not accessible to direct measurement, but they may be calculated from transport numbers. The transport number (or ion transport number, transference number) is the fraction of the total electrical current carried in an electrolyte by a given ionic species. It is typically measured by the moving boundary method, frequently incorporated in physical chemistry lab courses and manuals. Kohlrausch's law of independent ionic conductivities states that at low electrolyte concentrations the conductivity is directly proportional to the sum of the n individual ion contributions, that is:

$$\Lambda^0 = \sum_{i=1}^n \lambda_i^0$$

Table 13.4 shows some typical limiting ionic equivalent conductivities. From this, we can deduce that the limiting equivalent conductivity of potassium nitrate is $(K^+) + (NO_3^-) = 74 + 71 = 145$, and that of nitric acid is $(H^+) + (NO_3^-) = 350 + 71 = 421$, assuming 100 % dissociation into ions. The change in conductivity of a solution upon dilution or replacement of one ion by another by titration is the basis of conductometric analysis.

TABLE 13.4 Equivalent Conductance of Various Ions at Infinite Dilution at 25 °C

Anions	$(\Omega^{-1} \ cm^2/eq)$	Cations	$(\Omega^{-1} \text{ cm}^2/\text{eq})$
OH-	198	H ⁺	350
CI-	76	Na ⁺	50
Br-	78	K ⁺	74
NO_3^-	71	NH_4^+	74
CIO ₄	67	Ag+	62
HCOO-	55	Cu ²⁺	55
CH ₃ COO-	41	Zn^{2+}	53
SO ₄ ²⁻	80	Fe³+	68

The electrolytes KNO_3 and HNO_3 are strong and dissociate completely in water. Weak electrolytes do not dissociate completely. For weak electrolytes, the effects of interionic forces are less important because the ion concentrations are lower and, in fact, the degree of ionization (α) is readily obtainable from conductance measurements:

(13.35)
$$\alpha \approx \frac{\Lambda}{\Lambda^0}$$

For example, the weak acid HA partially dissociates into H⁺ and A⁻:

$$HA \longleftrightarrow H^+ + A^- \text{ with } K' = \frac{[H^+][A^-]}{HA}$$

If the initial total molar concentration of HA = c, at equilibrium, the molar concentration of $HA = (1-\alpha)c$, and the molar concentration of $H^+ = A^- = \alpha c$.

We can express an apparent dissociation constant in terms of conductivities by substitution.

(13.36)
$$K' = \frac{\alpha^2 c^2}{(1 - \alpha)c} \approx \frac{\Lambda^2 c}{\Lambda^0 (\Lambda^0 - \Lambda)}$$

This is an expression of Ostwald's dilution law, and the equation can be used to determine K', α , or Λ^0 . For example, from Table 13.4, we can calculate Λ^0 for formic acid, HCOOH, to be equal to 350 + 55 = 405 S cm²/eq. If we measure the equivalent conductance of a 0.020 N solution of formic acid, we find it equal to 36.6 S cm²/eq at 25 °C. The degree of dissociation, α , is calculated to be:

$$\alpha = \frac{\Lambda}{\Lambda^0} = \frac{36.6}{405} = 9.04 \times 10^{-2}$$

and from this we can calculate the dissociation constant, K',

$$K' = \frac{(9.04 \times 10^{-2})^2 (0.020)}{1 - 9.04 \times 10^{-2}} = 1.8 \times 10^{-4}$$

This agrees well with the literature value for the K_a for HCOOH. Conductance measurements may also be used to find the solubility of sparingly soluble salts and complexation equilibrium constants.

13.3.3.1 INSTRUMENTATION FOR CONDUCTIVITY MEASUREMENTS

The equipment is basically a Wheatstone bridge and conductivity cell, as illustrated in Figure 13.22.

Resistance A is made up of the cell containing the sample; B is a variable resistance; resistances D and E are fixed. Resistor B and variable capacitor C may be adjusted so that the balance point can be reached. At this point:

$$\frac{R_{\rm A}}{R_{\rm B}} = \frac{R_{\rm D}}{R_{\rm E}}$$

The resistances B, D, and E can be measured, and from these measurements the resistance and hence the conductance of the cell can be calculated. A *small* superimposed AC voltage (~20 mV peak to peak) at 1000 Hz is best as a signal, because then Faradaic polarization at the electrodes is minimized. The null detector may be a sensitive oscilloscope or a tuned amplifier and meter. Stirring is often used to minimize polarization.

A wide variety of cell geometries and sizes are available for conductivity measurements, designed with two, three, or four electrodes, depending on the use. A typical dip cell (so called because it is dipped into a beaker containing the sample) usually is constructed with




FIGURE 13.22 Wheatstone bridge arrangement for conductometric analysis.

two parallel, platinized Pt foil electrodes, each about 1 cm² in area. Because the dimensions of a constructed cell are not exact, one must calibrate a particular cell. The recommended method of calibration is to use primary standard KCl solutions of known strength. For example, at 25 °C, 7.419 g of KCl in 1000 g of solution (or 0.1 molal) has a specific conductivity of 0.01286 Ω^{-1} /cm. Primary standard solutions are not always practical to make. One has to include the conductivity of the water used to prepare the standard, for example. NIST has a set of standard reference materials (SRMs) covering the range 5 μ S/cm to 100,000 μ S/cm that are satisfactory for most calibration needs. Platinizing the Pt electrodes is achieved by cleaning the Pt in hot concentrated HNO3 and electrodepositing a thin film of Pt black from a 2 % solution of platinic chloride in 2 N HCl. The Pt black is a porous Pt film, which increases the surface area of the electrodes and further reduces faradaic effects.

Cells are available for sample volumes as small as 2 mL, while standard sample size is 25-50 mL. Special cells for highly accurate conductivity measurements are available for research purposes. Flow-through cells are available for online monitoring of process streams. The book by Berezanski depicts several cell types.

Very accurate measurements of conductivity require the use of a thermostatted bath with temperature controlled to within 0.005 °C. Fluctuations of \pm 0.005 °C fluctuation will cause a \pm 0.01 % change in conductivity.

In addition to the laboratory meter setup described, there are handheld devices available for making conductivity measurements in the field. These are generally battery-powered and are far less accurate than laboratory meters.

13.3.3.2 ANALYTICAL APPLICATIONS OF CONDUCTOMETRIC MEASUREMENTS

Conductivity measurements can be performed on many types of solutions with no sample preparation required. The method is used to monitor solutions for their ionic content. Examples include drinking water, natural water, high-purity (deionized) water, high-purity solvents, and potable beverages. Conductivity is common as a detector in ion chromatography, HPLC, and other chromatographic techniques where charged species are produced (Chapter 12). Conductivity is a powerful tool for endpoint detection in titrimetry in aqueous and nonaqueous solvents.

One application is conductimetric titration in aqueous solution. When one ion is replaced in solution by a different ion with a significantly different equivalent conductivity, a change in total conductivity occurs. As seen in Table 13.4, hydrogen ion and hydroxide ion have the highest equivalent conductivities; replacing them with less conductive ions can form the basis of conductimetric titrations for acids and bases. For example, when NaOH is added to HCl, the following reaction occurs:

Chemical reaction: $HCl + NaOH \rightarrow NaCl + H_2O$ Ionic reaction: $H^+ + Cl^- + Na^+ + OH^- \rightarrow Na^+ + Cl^- + H_2O$




FIGURE 13.23 Solution conductivity during an HCl-NaOH titration. Point C is the neutralization point.

The original solution contains $H^+ + Cl^-$ in water; the final solution contains $Na^+ + Cl^-$ in water. It can be seen that Na^+ replaces H^+ . If we plot the conductivity measured while NaOH is being added, we observe the relationship depicted in Figure 13.23. In part A of the curve, H^+ ions are being removed by the OH^- of the NaOH added to the solution. The conductivity slowly decreases until the neutralization point C is reached. In part B of the curve, the H^+ ions have been effectively removed from solution. Further addition of NaOH merely adds Na^+ and OH^- to the solution. An increase in conductivity results. The contribution of the Cl^- , Na^+ , H^+ , and OH^- ions to the total conductivity of the solution can be seen from Figure 14.22. The volume of NaOH required to titrate the HCl can be measured by extrapolating lines A and B to the intersection C. Point C indicates the required volume of NaOH to neutralize the acid present.

Weak acids can also be titrated with NaOH and the endpoint detected by conductivity. A typical curve is shown in Figure 13.24. As with all weak acids, the H⁺ concentration is low and in equilibrium with the acetate ion. At the equivalence point, however, all the H⁺ has been neutralized. Any further addition of NaOH has the effect of adding Na⁺ and OH⁻ to the solution. A sharp increase in conductivity occurs, as shown by point C in Figure 13.24. Mixtures of weak and strong acids can be titrated with NaOH and the endpoints detected by conductivity changes. In such mixtures, the strong acid is neutralized before the weak acid.




FIGURE 13.24 Solution conductivity during an acetic acid (CH₃COOH)–NaOH titration. Point C is the neutralization point.




FIGURE 13.25 Solution conductivity during titration of a mixture of HCl and CH₃COOH with NaOH. Here C' and C" designate the respective endpoints. HCl is titrated first and then the weaker acetic acid is neutralized.

Titrations involving mixtures of acids such as these are difficult to perform using indicators because of the problem involved in detecting both endpoints separately. With conductimetric titration the problem is simplified, as shown in Figure 13.25. It can be seen that two abrupt changes in conductivity take place (C' and C"); these correspond to the titration endpoints for the strong and weak acid, respectively. For known acids, we can determine the concentrations present in the sample quantitatively. The contributions from the Na⁺, Cl⁻, acetate⁻, OH⁻, and H⁺ to the total conductivity are noted in the figure. But remember that the conductivity measurement itself cannot distinguish individual ion contributions in a mixture. The method can be used to show how many acids are in a mixture and to indicate whether they are weak or strong acids, but not to identify them if the sample is an unknown. Conductimetric titrations can also be used to find the endpoints of reactions where precipitation takes place, as in the titration of silver solution with chloride solution. Again, the endpoint is manifested by a sharp change in conductivity.

Conductimetric titrations can also be performed in nonaqueous solvents. In nonaqueous solvents, such as alcohol, toluene, or pyridine, it is possible to titrate Lewis acids or bases that cannot be titrated in aqueous solutions. For example, it is possible to titrate phenols dissolved in an organic solvent. Phenols act as Lewis acids, releasing hydrogen ion, which can be titrated with a suitable basic material. Since the titration is carried out in a nonaqueous medium, it is necessary to use a base that is soluble in the solvent. A base commonly used is tetramethylammonium hydroxide (TMAH). This material is basic but soluble in organic solvents and will neutralize Lewis acids. Nonaqueous solvents can be used to advantage to investigate molecular species that are not soluble in water. However, interpretation of the titration curve may not be straightforward. Solvent effects, viscosity, temperature, intermolecular attractions between solvent and solute (e.g., ion-pairing, complexation) are some of the factors that must be considered. Methods and more detail may be found in the book by Huber and Kucharsky listed in the bibliography.

Conductivity is used to determine the purity of drinking water and other natural waters and wastewaters. Dedicated instruments for this purpose, including handheld, portable meters, are often calibrated to read in "total dissolved solids" or TDS, or in "salinity". These tell the environmental scientist, water treatment plant operator, or geochemist about the amounts of ionized species (e.g., sodium chloride is assumed to be the species for salinity of seawater) in solution. It is important to remember that the conductivity measurement cannot tell if the conductivity really is due to sodium chloride. It measures any ion that contributes to conductivity. The chemist or engineer must know something about the sample, or make good scientific judgments based on other information before drawing conclusions from a salinity or TDS reading on an unknown sample. Methods for conductivity measurements in potable water and wastewater may be found in "Standard Methods for Examination of Water and Wastewater" and for all types of water, deionized

to brackish, in the ASTM standards Volumes 11.01 and 11.02. The references are listed in the bibliography.

In addition to drinking water and environmental applications, water purity is critical to many industries. Conductivity detectors are used in semiconductor and chip fabrication plants, to monitor cleanliness of pipelines in the food and beverage industry, to monitor incoming water for boilers to prevent scale buildup and corrosion. Any process stream with ions in it can be analyzed by conductometry. Conductivity detectors are part of commercial laboratory deionized water systems, to indicate the purity of the water produced and to alert the chemist when the ion-exchange cartridges are exhausted. The detector usually reads out in resistivity; theoretically, completely pure water has a resistivity of 18 $\mathrm{M}\Omega$ cm.

Conductivity detectors are widely used in ion chromatography instruments using eluant suppression detection (Chapter 12). The detectors are inexpensive, simple, rugged, and easy to miniaturize. The same type of detectors can be used for any chromatographic process to detect charged species in a nonionic eluent.

13.3.4 POLAROGRAPHY

Polarography is the study of the relationship between the current flowing through a conducting solution and the voltage applied to a **dropping mercury electrode** (DME). It was discovered by Jaroslav Heyrovsky and has since resulted in tens of thousands of research studies. Heyrovsky's pioneering work in the field earned him the Nobel Prize in 1959. Many variations of Heyrovsky's classical polarographic method have evolved, principally to improve the sensitivity and resolution of this analytical method. Two important variations are described below, namely, normal pulse polarography and differential pulse polarography.

Polarography is a technique that requires three electrodes. Polarography uses as the **working electrode** (WE) a dropping mercury electrode (DME) or a static (hanging) mercury drop. The auxiliary electrode or counterelectrode (CE) is normally a Pt wire or foil. A third reference electrode is used as a basis for control of the potential at the working electrode. The current of analytical interest flows between the working and auxiliary electrodes, and the reference acts only as a high-impedance probe. As the voltage is progressively increased or decreased with time (sweep voltammetry), resultant changes in the anodic or cathodic currents occur whenever an electroactive species is oxidized or reduced, respectively. Polarography is a special case of *linear sweep voltammetry* because the electrode area increases with time as each Hg drop grows and falls every 4 s or so; that is, the voltage is changing as the electrode area increases. Polarography is especially useful for analyzing and studying metal ion and metal complex reductions and solution equilibria.

When a potential difference is applied across two electrodes immersed in a solution, even in the absence of an electroactive species of interest, a small current arises due to background reactions and dissolved impurities. If the solution contains various metal ions, these do not electrolyze until the applied negative potential exceeds the reduction potential of the metal ion, that is, becomes more negative than the reduction potential. The difference in the current flowing through a solution under two conditions—(1) with the potential less negative than the metal ion reduction potential and (2) with the potential more negative than the metal ion reduction potential—is the basis of polarography. Polarography is not restricted to reductions (negative potential sweep), although these are more common. It is also possible to sweep to positive potentials and obtain oxidation curves. Metal cations, anions, complexes, and organic compounds all can be analyzed using polarography. The plot of current against applied potential for a sample solution is called a polarogram.

Classical DC polarography uses a linear potential ramp (i.e., a linearly increasing voltage). It is, in fact, one subdivision of a broader class of electrochemical methods called **voltammetry**. Voltammetric methods measure current as a function of applied potential where the working electrode is *polarized*. This polarization is usually accomplished by using microelectrodes as working electrodes; electrode surface areas are only in the μ m² to mm² range. The term *polarography* is usually restricted to electrochemical analyses at the dropping




FIGURE 13.26 (a) Linear potential excitation and (b) the resulting polarographic wave.

mercury electrode. Figure 13.26 illustrates the potential excitation used in DC polarography and the net current waveform relationship, usually shown as an i–E rather than an i–t curve. The net S-shaped, or sigmoidal, curve obtained when a substance is reduced (or oxidized) is called a **polarographic wave** and is the basis for both qualitative and quantitative analyses. The *half-wave potential* E_{y_2} is the potential value at a current one-half of the limiting **diffusion current** i_L of the species being reduced (or oxidized). The magnitude of the limiting diffusion current i_L , obtained once the half-wave potential is passed, is a measure of the species concentration. It is standard to extrapolate the background residual current to correct for impurities that are reduced (or oxidized) before the E_{y_2} potential of the species of interest is reached. Although DC polarography is no longer commonly used for analytical purposes, it provides the basis of the newer, more powerful variants of classical polarography.

13.3.4.1 CLASSICAL OR DC POLAROGRAPHY

A modern apparatus for DC polarography is shown in Figure 13.27. The three-electrode system for aqueous work consists of the DME as the working electrode, a Pt wire or foil auxiliary electrode, and an SCE for reference. The potential of the working electrode (DME) is changed by imposition of a slow voltage ramp versus a stable reference (Figure 13.26). At the heart of polarography is the DME. A very narrow capillary is connected to a mercury column, which has a pressure head that can be raised and lowered. A drop of mercury forms at the tip of the capillary, grows, and finally falls off when it becomes too large. Typically, the level




FIGURE 13.27 Modern polarographic cell and three-electrode circuit.

of the mercury column above the tip of the capillary is about 60 cm and the natural interval between drops is 2-6 s. The choice of mercury for the electrode is important for several reasons:

- 1. Each fresh drop exposes a new Hg surface to the solution. The resulting behavior is more reproducible than that with a solid surface, because the liquid drop surface does not become contaminated in the way solid electrodes can be contaminated. Organic contaminants or adsorbants must undergo re-equilibration with each new drop and are less likely to interfere.
- 2. As mentioned earlier, there is a high overpotential for H^+ ion reduction at mercury. This means that it is possible to analyze many of the metal ions whose standard reduction potentials are more negative than that of the H_2/H^+ ion couple. It is easier, too, to reduce most metals to their mercury amalgam than to a solid deposit. Conversely, however, mercury is easily oxidizable, which severely restricts the use of the DME for the study of oxidation processes.

3. Solid electrodes have surface irregularities because of their crystalline nature. Liquid mercury provides a smooth, reproducible surface that does not depend on any pretreatment (polishing or etching) or on substrate inhomogeneity (epitaxy, grain boundaries, imperfections, etc.).

In electroanalysis, diffusion currents are quite small ($< 100 \mu A$), which means that the aqueous solution IR drop between the reference electrode and the DME can be neglected in all but the most accurate work. Electrolytes prepared with organic solvents, however, may have fairly large resistances, and in some instances IR corrections must be made.

As each new drop commences to grow and expand in radius, the resulting current is influenced by two important factors. The first is the depletion by electrolysis of the electroactive substance at the mercury drop surface. This gives rise to a diffusion layer in which the concentration of the reactant at the surface is reduced. As one travels radially outward from the drop surface, the concentration increases and reaches that of the bulk homogeneous concentration. The second factor is the outward growth of the drop itself, which tends to counteract the formation of a diffusion layer. The net current waveform for a single drop is illustrated in Figure 13.28.

A mathematical description of the diffusion current, in which the current i_L is measured at the top of each oscillation just before the drop dislodges, is given by the following equation:

(13.37)
$$i_{\rm L} = 708nCD^{1/2}m^{2/3}t^{1/6}$$

where i_L is the maximal current of the Hg drop (μ A); n, the number of electrons per electroactive species; C, the concentration of electroactive species (mM); D, the diffusion coefficient of electroactive species; m, the mercury flow rate (mg/s); and t, the drop time (s).

This is called the **Ilkovic equation**. For a particular capillary and pressure head of mercury, $m^{2/3}t^{1/6}$ is a constant. Also, the value of n and that of the diffusion coefficient for a particular species and solvent conditions are constants. Thus, i_L is proportional to the concentration C of the electroactive species, and this is the basis for quantitative analysis. The Ilkovic equation is accurate in practice to within several percent, and routinely ± 1 % precision is possible. It is commonplace to use standard additions to obtain a calibration curve, or an internal standard. Internal standards are useful when chemical sampling and preparation procedures involve the possibility of losses. The principle is that the ratio of the diffusion currents due to the sample and the added standard should be a constant for a particular electrolyte.




FIGURE 13.28 (a) Current waveform and (b) time frame of an expanding drop.

Before a polarogram can be obtained from a sample, two important steps are necessary: (1) the sample must be dissolved in a suitable **supporting electrolyte** and (2) the solution must be adequately **degassed**. To understand the purpose of the supporting electrolyte, we should first review the three principal forms of transport that occur in ionic solutions: (1) diffusion, (2) convection, and (3) migration.

Diffusion is the means by which an electroactive species reaches the electrode when a concentration gradient is created by the electrode reaction. The electron transfer process can decrease the concentration of an electroactive species or produce a new species (not originally present in the bulk solution) that diffuses away from the electrode surface. Convection, that is, forced motion of the electrolyte, can arise from natural thermal currents always present within solutions, by density gradients within the solution or be produced deliberately by stirring the electrolyte or rotating the electrode. In general, natural convection must be minimized by electrode design and by making short time scale measurements (on the order of a few seconds). The third form of transport is migration of the charged species. Migration refers to the motion of ions in an electric field and must be suppressed if the species is to obey diffusion theory. This is done by adding an excess of inert supporting electrolyte to the solvent. The role of the supporting electrolyte is twofold: it ensures that the electroactive species reaches the electrode by diffusion and it lowers the resistance of the electrolyte.

Typically, supporting electrolyte concentrations are 0.1-1 M. An example is KCl solution. The K^+ ions in this solution are not easily reduced and have the added advantage that the K^+ and Cl^- ions migrate at about equal velocities in solution. In a solution of $ZnCl_2$ (0.0001 M) and KCl (0.1 M), the migration current of the zinc is reduced to a negligible amount, and we are therefore able to measure the current response due to zinc ion reduction under diffusion conditions.

In polarography, even though measurements are made in a quiescent solution (no stirring by either gas bubbling or magnetic bar is permissible), the transient currents arising with each drop depend on both diffusion and the convective motion due to the expanding mercury drop. These effects combine to produce a current that is proportional to $t^{1/6}$.

A further important step is the adequate degassing of the electrolyte by bubbling purified nitrogen or argon. This is necessary because dissolved oxygen from the air is present in the electrolyte and, unless removed, would complicate interpretation of the polarogram. Figure 13.29 shows an actual polarogram of a supporting electrolyte that is air saturated and without added electroactive sample. The abrupt wave at -0.1 V versus SCE is due to the reduction of molecular oxygen, and the drawn-out wave at -0.8 V versus SCE is assigned to reduction of hydrogen peroxide, a product from the oxygen reduction. Once the potential exceeds the threshold for peroxide reduction, both of these reactions can occur at each new drop as it grows, and the limiting current is approximately twice as large. The first reaction




FIGURE 13.29 Polarogram of dissolved oxygen in an electrolyte, 1 M KNO₃ (scan rate 5 mV/s, 2 s drop time).




FIGURE 13.30 Normal pulse polarogram of Pb²⁺ ions (5 ppm) in 1 M KNO₃ (scan rate 5 mV/s, 2 s drop time).

is sharp and can be used for the determination of dissolved oxygen in solutions. The addition of a few drops of a dilute Triton X-100 solution is necessary to prevent the formation of maxima in the current at the diffusion plateau. Such maxima distort the waveforms and complicate the measurement of the diffusion currents. Maximum suppressants, such as gelatin and Triton X-100, are capillary-active substances, which presumably damp the streaming currents around the drop that cause the current distortions.

The relationship between current and voltage for a well-degassed solution of $Pb(NO_3)_2$ is shown in Figure 13.30. This polarogram is actually a normal pulse polarogram, not a DC polarogram. The difference is discussed below. Within the voltage range of 0 to -0.3 V versus SCE, only a small *residual current* flows. It is conventional in polarography to represent cathodic (reduction) currents as positive and anodic (oxidation) currents as negative. The residual current actually comprises two components, a faradaic contribution and a charging or double-layer current contribution:

$$i_{\rm res} = i_{\rm F} + i_{\rm ch}$$

The Faradaic current $i_{\rm F}$ arises from any residual electroactive species that can be electrolyzed in this potential range, such as traces of metals or organic contaminants. Such impurities may be introduced by the supporting electrolyte, which will have to be purified for some trace analyses. The charging current $i_{\rm ch}$ is non-Faradaic; in other words, no electron flow occurs across the metal-solution interface, and neither redox nor permanent chemical changes result from its presence. The mercury-solution interface acts, to a first approximation, as a small capacitor, and charge flows to the interface to create an electrical double layer. At negative potentials, this can be thought of as a surplus of electrons at the surface of the metal and a surplus of cations at the electrode surface. In reality, the electrical double layer capacity varies somewhat with the potential; so, the fixed capacitor analogy is not strictly accurate. An important consequence of charging currents is that they limit the analytical sensitivity of polarography. This is why pulse polarographic methods, which discriminate against charging currents, can be used to determine much lower concentrations of analyte.

In Figure 13.30, we can see that as the potential becomes increasingly negative, it reaches a point where it is sufficient to cause the electroreduction:

$$Pb^{2+} + 2e^{-} \rightarrow Pb\big(Hg\big)$$

The Pb^{2+} concentration in the immediate vicinity of the electrode decreases as these ions are reduced to lead amalgam. With a further increase in negative potential, the Pb^{2+} concentration at the surface of the electrode becomes zero, even though the lead ion concentration

in the bulk solution remains unchanged. Under these conditions, the electrode is said to be polarized. The use of an electrode of small area, such as the DME, means that there is no appreciable change of Pb²⁺ ions in the bulk of the solution from a polarographic analysis.

When the electrode has become polarized, a fresh supply of M^+ ions to its surface is controlled by the diffusion of such ions from the bulk of the solution, through the zone depleted of M^+ . In other words, the current flowing is dependent on the diffusion of ions from the bulk liquid. This current is called the diffusion current and the plateau region of the curve can be used to measure the limiting diffusion current i_L . It is usual to extrapolate the residual current background and to construct a parallel line through the diffusion current plateau to correct for the residual current contribution to i_L .

13.3.4.2 HALF-WAVE POTENTIAL

An important point on the curve is that at which the diffusion current is equal to one-half of the total diffusion current; the voltage at which this current is reached is $E_{\frac{1}{2}}$, the *half-wave potential*. The half-wave potential is used to characterize the current waveforms of particular reactants. Whether a process is termed reversible or not depends on whether equilibrium is reached at the surface of the electrode in the time frame of the measurements. In other words, a process is reversible when the electron transfer reactions are sufficiently fast so that the equilibrium:

$$ox + ne^- \leftrightarrow red$$

is established and the Nernst equation describes the ratio [ox]/[red] as a function of potential, that is,

$$E = E^{0} + 2.303 \frac{RT}{nF} \log \left(\frac{[ox]}{[red]} \right)$$

When this is the case, it can be shown that there is a relation between the potential, the current, and the diffusion current i_L , which holds true throughout the polarographic wave:

(13.38)
$$E = E_{\frac{1}{2}} + \frac{0.0591}{n} \log \left(\frac{i_{L} - i}{i} \right) \text{ at } 25 \text{ °C}$$

This equation may be practically used to test the reversibility (or Nernstian behavior) of an electroactive species. The graph of E versus $\log[i_L - i)/i]$ will be linear with a slope of 0.0591/n and intercept $E_{\frac{1}{2}}$. Determination of the slope enables us to determine n, the number of electrons involved in the process. $E = E_{\frac{1}{2}}$ when the surface concentrations [ox] and [red] are equal.

The half-wave potential $E_{\frac{1}{2}}$ is usually similar but not exactly equivalent to the thermodynamic standard potential E^{0} . First, the product of reduction may be stabilized by amalgam formation in metal ion reductions; second, there will always be a small liquid junction potential in electrochemical cells of this type that should be corrected for.

In most analytical work, activity corrections are ignored and the diffusion coefficients, $D_{\rm ox}$ and $D_{\rm red}$, are approximately equal, because the size of the electroactive product and reactant is not greatly affected by the gain (or loss) of an electron. The value of the half-wave potential is that it can be used to characterize a particular electroactive species qualitatively. It is not affected by the analyte concentration or by the capillary constant. It can, however, be severely affected by changes in the supporting electrolyte medium. Table 13.5 lists some half-wave potentials of diverse species that may be analyzed by polarography.

13.3.4.3 NORMAL PULSE POLAROGRAPHY

Unlike classical DC polarography, normal pulse polarography does not use a linear voltage ramp; instead, it synchronizes the application of a square-wave voltage pulse of progressively increasing amplitude with the last 60 ms of the life of each drop. This is shown in

TABLE 13.5	Half-Wave Potentials of Common
	Metal Ions

		E _{1/2} versus SCE
Ag(I)	1 M NH ₃ /0.1 M NH ₄ Cl	-0.24
Cd(II)	1 M HCl	-0.64
	0.1 M CH₃COONa/0.1 M CH₃COOH	-0.65
Cu(II)	1 M HCl	-0.22
	0.1 M CH₃COONa/0.1 M CH₃COOH	-0.07
O_2	0.1 M KNO ₃	-0.05
Pb(II)	1 M HCl	-0.44
	0.1 M CH₃COONa/0.1 M CH₃COOH	-0.50
T1(I)	1 M HCl	-0.48
Zn(II)	1 M NH ₃ /0.1 M NH ₄ Cl	-1.35
	1 M CH₃COONa/0.1 M CH₃COOH	-1.1

Note: More complete data are available from textbooks (e.g., Bard, 1980) and from polarographic equipment suppliers (e.g., EG&G Princeton Applied Research Application Briefs and Application Notes, www.princetonappliedresearch.com).

Figure 13.31. It is necessary to use an electronically controlled solenoid to knock the drop from the capillary at a preset time, for example, every 2 s. Each drop has the same lifetime, which is shorter than its natural (undisturbed) span. The initial voltage $E_{\rm init}$ is chosen such that no faradaic reactions occur during most of the growth of the drop. Then, when the rate of change of the drop surface area is less than during the drop's early formation stages, the pulse is applied. As a first approximation, the drop surface area can be considered to be constant during the pulse application. If the potential is such that Faradaic reaction can take place at the pulse potential, the resultant current decay transient has both a Faradaic and a charging current component, as shown in Figure 13.31. The measurement of current may be made during the last 17 ms of the pulse by a sample-and-hold circuit. This outputs the average current and holds this value until the next current is ready for output. Thus, the output current is a sequence of steady-state values lasting the drop life, for example, 2 s. The i-E curve does not have the large oscillations reminiscent of classical polarography (compare Figures 13.29 and 13.30), but may provide a Nernstian waveform directly.




FIGURE 13.31 (a) Waveform for normal pulse polarography and (b) current transient response (not to scale).

It is readily seen from Figure 13.31 why the current is sampled in this manner. A Faradaic current $i_{\rm F}$ at an electrode of constant area will decay as a function of $t^{-1/2}$ if the process is controlled by diffusion; on the other hand, the charging current transient $i_{\rm ch}$ will be exponential, with a far more rapid decay. This permits better discrimination of the faradaic current and charging current contributions.

A further important advantage of this technique is that during the first 1.94 s of the life of each drop, no current flows (remember, the pulse is applied in the last 0.060 s of a 2 s drop life). To understand how this is advantageous, we must reconsider what happens in classical DC polarography. At the start of a drop life, the potential is at a given value and increases slowly as the drop grows. If Faradaic reaction can occur, this means that the electroactive species is being depleted during the whole life of the drop, such that when it has grown for about 1.94 s, there is a large depletion region extending from the surface. In normal pulse polarography, no reaction occurs until the drop area is quite large, and this enhances the current response considerably. The analytical implication is that it is possible to detect concentration levels of about 1×10^{-6} M with the normal pulse technique, which is much better than the useful range of about $1 \times 10^{-4} - 1 \times 10^{-2}$ M in classical DC polarography.

13.3.4.4 DIFFERENTIAL PULSE POLAROGRAPHY

Differential pulse polarography has the most complex waveforms of the polarographic methods discussed, but it is the easiest to interpret for analytical purposes. The applied voltage is a linear ramp with imposed pulses added during the last 60 ms of the life of each drop (Figure 13.32).




FIGURE 13.32 Differential pulse polarography (not to scale). **(a)** Voltage vs. time sequence in DPP and **(b)** current response vs. time during DPP pulse.




FIGURE 13.33 Waveform obtained in differential pulse polarography.

In this technique, however, the pulse height is maintained constant above the ramp and is termed the *modulation amplitude*. The modulation amplitude may be varied between 10 and 100 mV. As in normal pulse polarography, the current is not measured continuously, but in this technique, it is sampled twice during the mercury drop lifetime: once just prior to the imposition of a pulse and once just before each drop is mechanically dislodged. As in classical DC polarography, the presence of a potential at the start of the life of each drop reduces the analyte concentration by creating a depleted diffusion layer. However, the sampled current output is a differential measurement,

$$\Delta i_{
m out} = i_{
m after~pulse} - i_{
m before~pulse}$$

and, as in normal pulse polarography, the time delay permits the charging current to decay to a very small value. As the measured signal is the difference in current, a peak-shaped i–E curve is obtained, with the peak maximum close to E_½ if the modulation amplitude is sufficiently small. A differential pulse waveform is shown in Figure 13.33.

To understand why the waveform is a peak, consider what is being measured. The output is a current difference arising from the same potential difference, that is, $\Delta i/\Delta E$. If ΔE becomes very small ($\Delta E \rightarrow dE$), we should obtain the first derivative of the DC polarogram, and the peak and $E_{1/2}$ would coincide. However, because the modulation amplitude is finite and has to be reasonably large in order to produce an adequate current signal, the $E_{\rm peak}$ value of the differential pulse polarogram is shifted positive at the half-wave potential for reduction processes:

$$E_{\text{peak}} = E_{\frac{1}{2}} - \Delta E/2$$

where ΔE is the modulation amplitude. Increasing ΔE increases the current response but reduces the resolution of the waveform, and experimentally it is best to vary the instrument parameters until a suitable combination is found for the ramp scan rate and the modulation amplitude.

The simplicity of the differential pulse polarographic method lies in the fact that the peak height is proportional to the analyte concentration (Figure 13.34). If adequate resolution exists, it is possible to analyze several ionic species simultaneously with polarography. Differential pulse polarography is especially useful for trace analyses when working close to the electrolyte background reduction or oxidation wave. Its limit of detection is typically 1×10^{-7} M or better, depending on the sample and conditions.

The addition of surfactants is not always recommended in normal and differential pulse polarography, because their presence may reduce the sensitivity of these methods in




FIGURE 13.34 Effect of standard additions on a differential pulse polarogram.

certain circumstances. Many other forms of polarography have been suggested and tested. Prominent among these are AC polarographic methods, which use sinusoidal and other periodic waveforms. Most modern instruments offer a range of techniques to the electroanalytical chemist.

The solvent used plays a very important role in polarography. It must be able to dissolve a supporting electrolyte and, if necessary, be buffered. In many cases, the negative potential limit involves the reduction of a hydrogen ion or a hydrogen atom on a molecule. It is therefore vital to control the pH of the solution with a buffer. The buffer normally serves as the supporting electrolyte. Furthermore, it must conduct electricity. These requirements eliminate the use of many organic liquids such as benzene. A polar solvent is necessary, the most popular being water. To dissolve organic compounds in water, a second solvent, such as ethanol, acetone, or dioxane, may first be added to the water. The mixture of solvents dissolves many organic compounds and can be conditioned for polarography. As an alternative to the aqueous/nonaqueous systems, a pure polar solvent may be used, especially if water is to be avoided in the electrolysis. Commonly used solvents are acetonitrile, dimethylformamide, dimethylsulfoxide, and propylene carbonate. Tetralkylammonium perchlorates and tetrafluoroborates are useful supporting electrolytes because their cations are not readily reduced. A list of functional groups that can be determined by polarography is shown in Table 13.6.

TABLE 13.6 Typical Functional Groups that can be Determined by Polarography

Functional Group	Name	$E_{y_2}(V)$		
RCHO	Aldehyde	-1.6		
RCOOH	Carboxylic acid	-1.8		
RR'C=O	Ketone	-2.5		
R-O-N=O	Nitrite	-0.9		
R-N=O	Nitroso	-0.2		
R—NH ₂	Amine	-0.5		
R—SH	Mercaptan	-0.5		

Note: Electrochemical data on a large number of organic compounds are compiled in the CRC Handbook Series in Organic Electrochemistry. www.crc.press.com.

In general, simple saturated hydrocarbons, alcohols, and amines are not readily analyzed at the DME. However, aldehydes and quinones are reducible, as well as ketones.

Similarly, olefins (in aqueous solution) may be reduced according to the equilibrium

$$R - C = C - R' + 2e^{-} + 2H_{2}O \leftrightarrow R - CH_{2}CH_{2} - R' + 2OH^{-}$$

Polarography can be used for the analysis of C—N, C—O, N—O, O—O, S—S, and C—S groups and for the analysis of heterocyclic compounds. Also, many important biochemical species are electroactive, such as vitamin C (ascorbic acid), fumaric acid, vitamin B factors (riboflavin, thiamine, niacin), antioxidants such as tocopherols (vitamin E), *N*-nitrosamines, ketose sugars (fructose and sorbose), and the steroid aldosterone.

13.3.5 VOLTAMMETRY

In **voltammetry**, a controlled potential is applied to one electrode and the current flowing through the cell is monitored over time. A powerful family of techniques is available using voltammetry. Polarography is a form of voltammetry in which the electrode area does not remain constant during electrolysis. It is possible, however, to use electrode materials other than mercury for electroanalysis, provided that the potential "window" available is suitable for the analyte in question. In polarography, the DME is renewed regularly during the voltage sweep, with the consequence that the bulk concentration is restored at the electrode surface at the start of each new drop at some slightly higher (or lower) potential. At a solid electrode, the electrolysis process initiated by a voltage sweep proceeds to deplete the bulk concentration of analyte at the surface without interruption. This constitutes a major difference between classical polarography and sweep voltammetry at a solid electrode. Normal pulse polarography is a useful technique at solid electrodes, because the bulk concentration is restored by convection at the surface during the off-pulse, provided that this is at least $10 \times longer$ than the electrolysis period.

Table 13.7 summarizes the accessible potential ranges for liquid mercury and for solid platinum electrodes. The precious metals and various forms of carbon are the most common electrodes in use, although a great many materials, both metallic and semiconducting, find use as analytical electrode substrates. Voltammetry is conducted using a microelectrode as the working electrode under conditions where polarization at the working electrode is enhanced. This is in sharp contrast to both potentiometry and coulometry, where polarization is absent or minimized by experimental conditions. In voltammetry, very little analyte

TABLE 13.7	Potential Windows for Commonly Used
	Electrodes and Solvents

		Range (V versus SCEa)
Mercury		
Aqueous	1 M HCIO ₄	+0.05 to -1.0
	1 M NaOH	−0.02 to −2.5
Nonaqueous	0.1 M TEAP/CH ₃ CN ^b	+0.6 to -2.8
Platinum		
Aqueous	1 M H ₂ SO ₄	+1.2 to -0.2
	1 M NaOH	+0.6 to -0.8
Nonaqueous	0.1 M TBABF ₄ /CH ₃ CN ^c	+2.5 to -2.5

- ^a The SCE may only be used in nonaqueous systems if traces of water are acceptable.
- ^b TEAP, tetraethylammonium perchlorate.
- TBABF4, tetrabutylammonium tetrafluoroborate.

is used up in the measurement process, unlike coulometry, where complete consumption of the analyte is desired.

13.3.5.1 INSTRUMENTATION FOR VOLTAMMETRY

A voltammetry mode of operation is featured on many modern polarographs, or a suitable voltage ramp generator may be used in combination with a potentiostat. The three-electrode configuration is required. Pretreatment of the working electrode is necessary for reproducibility (unless a hanging MDE is used), and normally this entails polishing the electrode mechanically with successively finer grades of abrasives.

Some confusion results in choosing an initial voltage at which to start the voltammogram. It is best to measure the open-circuit voltage between the working and reference electrodes with a high-impedance digital voltmeter. This emf is known as the **rest potential**, $E_{\rm rp}$. Scans may then be made in the negative and/or positive directions starting at the rest potential set on the potentiostat. By this means, the potentials for reductions and oxidations, respectively, and the electrolyte limits (the "windows") are established. In other words, it is generally necessary to commence at a potential at which no faradaic reaction is possible, or else voltammograms will be distorted and irreproducible.

Scan rates typically vary from 10 mV/s to 1 V/s. The lower limit is due to thermal convection, which is always present in an electrolyte. All modern potentiostats operate at fast scan voltages. The limit is determined by the sampling rate and the rise time of the operational amplifiers. The currents in successive scans differ from those recorded in the first scan. For quantitation purposes, the first scan should always be used.

13.3.5.2 CYCLIC VOLTAMMETRY

A powerful group of electrochemical methods uses reversal techniques. Foremost among these is cyclic voltammetry. This technique involves reversing the potential sweep direction to reveal the electroactive products formed in the forward sweep. In this way, it is possible to see if the products undergo reaction with other species present or with the solvent. Cyclic voltammetry is usually carried out at a solid electrode. Cyclic voltammetry is invaluable for identifying reaction mechanisms, for studying electrochemical reaction rates and for studying reactive species in unusual oxidation states. In cyclic voltammetry, a microelectrode is used as the WE. The potential is increased linearly and the current is measured. The current increases as the potential of the electroactive material is reached. The area of the working electrode and the rate at which the analyte can diffuse to the electrode surface limits the current. A single voltage ramp is reversed at some time after the electroactive species reacts and the reverse sweep is able to detect any electroactive products generated by the forward sweep. A cyclic voltammogram of a typical reversible oxidation-reduction reaction is shown diagrammatically in Figure 13.35. A computer data system is used to track the voltage on the time axis, so that the reverse current appears below the peak obtained in the forward sweep, but with opposite polarity. The shapes of the waves and their responses at different scan rates are used for diagnostic purposes. Substances are generally examined at concentrations around the millimolar level, and the electrode potentials at which the species undergo reduction and oxidation may be rapidly determined.

The height of the current peak of the first voltage sweep can be calculated from the Randles-Sevcik equation:

(13.39)
$$i_{\rm p} = 2.69 \times 10^5 \, n^{2/3} A D^{1/2} C v^{1/2}$$

where n is the number of electrons transferred; A, the electrode area (cm²); D, the diffusion coefficient of the electroactive species (cm²/s); C, the concentration of the electroactive species (mol/cm³); and v, the potential scan rate (V/s). The standard potential E^0 is related to the anodic and cathodic peak potentials, $E_{\rm pa}$ and $E_{\rm pc}$:

(13.40)
$$E^0 = \frac{1}{2} (E_{pc} + E_{pa})$$




FIGURE 13.35 (a) Excitation waveform and **(b)** current response for a reversible couple obtained in cyclic voltammetry.

The peak separation is related to the number of electrons involved in the reaction:

(13.41)
$$E_{\rm pa} - E_{\rm pc} = \frac{0.059}{n}$$

assuming that the *IR* drop (resistance) in the cell is not too large, which will increase the peak separation.

Cyclic voltammetry is not primarily a quantitative analytical technique. The bibloigraphy at the end of this chapter provide additional guidance to its applications and interpretation. Its real value lies in the ability to establish the nature of the electron transfer reactions—for example, fast and reversible at one extreme, slow and irreversible at the other—and to explore the subsequent reactivity of unstable products formed by the forward sweep. Such studies are valuable for learning the fate and degradation of such compounds as drugs, insecticides, herbicides, foodstuff contaminants or additives, and pollutants.

13.3.5.3 STRIPPING VOLTAMMETRY

The technique of *stripping voltammetry* may be used in many areas requiring trace analyses to the ppb level. It is especially useful for determining heavy metal contaminants in natural water samples or biochemical studies. Either anodic or cathodic stripping is possible in principle, but analyses by **anodic stripping voltammetry** are more often used. Stripping analysis is a two-step technique involving (1) the preconcentration of one or several analytes

by reduction (in anodic stripping) or oxidation (in cathodic stripping) followed by (2) a rapid oxidation or reduction, respectively, to strip the products back into the electrolyte. Analysis time is on the order of a few minutes. The overall determination involves three phases:

- 1. Preconcentration
- 2. Quiescent (or rest) period
- 3. Stripping process, for example, by sweep voltammetry or differential pulse

It is the preconcentration period that enhances the sensitivity of this technique. In the preconcentration phase, precise potential control permits the selection of species whose decomposition potentials are exceeded. The products should form an insoluble solid deposit or an alloy with the substrate. At Hg electrodes, the electroreduced metal ions form an amalgam. Usually, the potential is set 100-200 mV in excess of the decomposition potential of the analyte of interest. Moreover, electrolysis may be carried out at a sufficiently negative potential to reduce all of the metal ions possible below hydrogen ion reduction at Hg, for example. Concurrent H^+ ion reduction is not a problem, because the objective is to separate the reactants from the bulk electrolyte. In fact, methods have been devised to determine the group I metals and (NH_4^+) ion at Hg in neutral or alkaline solutions of the tetraalkylammonium salts. Exhaustive electrolysis is not mandatory and 2-3 % removal suffices. Additionally, the processes of interest need not be 100 % Faradaically efficient, provided that the preconcentration stage is reproducible for calibration purposes, which is usually ensured by standard addition.

Typical solid substrate electrodes are wax-impregnated graphite, glassy (vitreous) carbon, platinum, and gold; mercury electrodes are more prevalent in the form of either a **hanging mercury drop electrode (HMDE)** or thin-film mercury electrode (TFME). In a so-called "static" or "**hanging**" mode, a stationary Hg droplet may be suspended from a micrometer syringe capillary. Alternatively, commercially available electrodes have been developed that inject an Hg drop of varying size to the opening of a capillary.

TFMEs may be electro-deposited on glassy carbon electrodes from freshly prepared $Hg(NO_3)_2$ dissolved in an acetate buffer (pH 7). There is an art to obtaining good thin films, and usually some practice is necessary to get uniform, reproducible coverage on the carbon substrates. It is recommended that literature procedures be adhered to carefully. Some procedures recommend simultaneously pre-electrolyzing the analyte and a dilute mercury ion solution ($\sim 10^{-5}$ M), so that the amalgam is formed in a single step.

It is important to stir the solution or rotate the electrode during the preconcentration stage. The purpose of this is to increase the analyte mass transport to the electrode by convective means, thereby enhancing preconcentration. In general, in electroanalysis, one seeks to obtain proper conditions for diffusion alone to permit mathematical expression of the process rate (the current). In stripping voltammetry, it is advantageous to purposely increase the quantity of material reaching the electrode surface. Preconcentration times are typically 3 min or longer.

In the rest period or quiescent stage, the stirrer is switched off for perhaps 30 s but the electrolysis potential is held. This permits the concentration gradient of material within the Hg to become more uniform. The rest period is not obligatory for films produced on a solid substrate.

A variety of techniques have been proposed for the stripping stage. Two important methods are discussed here. In anodic stripping, the potential is scanned at a constant rate to more positive values. With this single sweep voltammetry, the resolution of a TFME is better than that of an HMDE, because stripping of the former leads to a more complete depletion of the thin film. As illustrated in Figure 13.36, it is possible to analyze for many metal species simultaneously. The height of the stripping peak is taken to be directly proportional to concentration. Linearity should be established in the working range with a calibration curve. The second method of stripping involves the application of a differential pulse scan to the electrode. As in polarographic methods, an increase in sensitivity is obtained when the differential pulse waveform is used.

Extremely high sensitivities in trace analyses require good analytical practice, especially in the preparation and choice of reagents, solvents, and labware. Glass cells and volumetric




FIGURE 13.36 Stripping voltammogram of metal-ion species at a TFME.

glassware must be soaked for 24 h in trace-metal purity 6 M HNO $_3$. Plastic electrochemical cells are recommended if loss of sample by adsorption to the vessel walls is a likely problem. The inert gas (N_2 or Ar) used to remove dissolved oxygen should be purified so as not to introduce additional contaminants. Solid catalysts and drying agents are recommended for oxygen and water removal. A pre-saturator is recommended to reduce electrolyte losses by volatilization, especially when low vapor pressure organic solvents are used. A major source of contamination is the supporting electrode itself. This may be purified in part by recrystallization, but the use of sustained pre-electrolysis at a mercury pool electrode may ultimately be required. Dilute standards and samples ought to be prepared daily because of the risk of chemical (e.g., hydrolysis) or physical (e.g., adsorption) losses.

Anodic stripping voltammetry is readily applicable for those metals that form an amalgam with mercury, for example, Ag, As, Au, Bi, Cd, Cu, Ga, In, Mn, Pb, Sb, Sn, Tl, and Zn. One important cause of interferences is intermetallic compound formation of insoluble alloys between the metals within the amalgam. For example, In/Au and Cu/Ni can form in the Hg drop and then not respond to the stripping stage, so their measured concentrations will be too low. It is imperative to carefully select the electrolyte such that possibly interfering compounds are complexed and electroinactive. This is also a means of improving resolution when there are two overlapping peaks. Some elements can be analyzed in aqueous electrolytes only with difficulty (groups I and II), but, fortunately, their determinations by atomic spectroscopy methods are sensitive and easy to carry out. Anions of carbon compounds can also be stripped by either (1) anodic preconcentration as sparingly soluble Hg salts, (2) adsorption and decomposition, or (3) indirect methods, such as displacement of a metal complex. Examples of complexes used include thiourea, succinate, and dithizone. Anions may be determined as mercurous or silver salts if these are sparingly soluble. Based on solubility determinations, it is possible to estimate some theoretical values for the minimum determinable molar concentrations of anions at mercury: Cl⁻, 5×10^{-6} ; Br, 1×10^{-6} ; I⁻, 5×10^{-8} ; S^{2-} , 5×10^{-8} ; CrO_4^{2-} , 3×10^{-9} ; WO_4^{2-} , 4×10^{-7} ; MoO_4^{2-} , 1×10^{-6} ; and $C_2O_4^{2-}$, 1×10^{-6} . With the exception of Cl, the mercurous salts are less soluble than the silver salts.

In conclusion, stripping voltammetry is an inexpensive, highly sensitive analytical tool applicable to multicomponent systems; in fact, it is not recommended for metal-ion samples whose concentrations are greater than 1 ppm. Careful selection of operating conditions and especially the electrolyte buffer is necessary. The sensitivity of stripping voltammetry is less for nonmetallic and anionic species than for metals. More recently, flow-through systems have been devised for continuous monitoring purposes. Stripping voltammetry has been applied to numerous trace metal analyses and environmental studies, for example, to determine impurities in oceans, rivers, lakes, and effluents; to analyze body fluids, foodstuffs, and soil samples; and to characterize airborne particulates and industrial chemicals.

13.4 SPECTROELECTROCHEMISTRY

Spectroelectrochemistry (SEC), also called photoelectrochemistry, combines the two techniques of spectroscopy and electrochemistry. The whole range of the electromagnetic spectrum can be employed from NMR to X-ray absorption. SEC can be used to study materials, surfaces, inorganic, organic, and biological substances. SEC techniques allow in-situ spectroscopic measurements of electrogenerated species, permitting the study of the chemical reversibility of reactions, the study of short-lived species and the identification of unknown intermediate species and products in redox reactions. Because of the wide range of spectroscopy techniques that can be used, most instrumentation is custom-designed by the researcher, using some commercial components such as potentiostats. We will focus on electrochemistry coupled to UV-VIS-NIR and IR systems, since these can be set up relatively inexpensively or are available commercially.

Figure 13.37 shows a schematic spectroelectrochemistry instrument. For UV-VIS-NIR work, the light source could be a white light LED or a tungsten light source and the spectrometer a UV-VIS-NIR diode array spectrometer.

The electrochemical cell would need quartz windows. A typical three-electrode system, with working electrode, counter electrode and reference electrode, is used. For IR work, the source and spectrometer would have to be suitable and the windows of the cell would have to be IR-transparent, e.g., CaF₂. Suitable materials have been discussed for both techniques in Chapters 3 and 4. Commercial systems are available from BioLogic Science Instruments, Claix, France (www.bio-logic.info) and from ZAHNER-Elektrik GmbH & Co. KG, Kronach, Germany (www.zahner.de). Their websites contain pictures and detailed instrument descriptions as well as a number of application notes and technical notes.

Optically transparent electrodes (OTEs) can be used to construct optically transparent cells for use in a conventional UV-VIS or IR spectrometer (Plieth et al. 1998). OTEs are of various types, depending on the application and can include:

- A thin metal film on a transparent substrate. The thickness should not exceed 100 nm for the film to remain optically transparent. This can result in high electrical resistance.
- A glass plate with a thin film of an optically transparent, conducting material, for example, indium tin oxide (ITO).
- A gold minigrid between transparent substrates.
- A thicker free-standing metal mesh.





FIGURE 13.37 Schematic basic spectroelectrochemistry instrument.



Actuator for automatic change between reference and measurement cell

FIGURE 13.38 The ZAHNER CIMPS (controlled intensity modulated photocurrent spectroscopy) photoelectrochemical system, in one of its multiple commercially-available configurations. Basics of the system include the Zennium® Electrochemical Workstation, an XPot external potentiostat, a light source, photochemical cells (one reference cell and one measurement cell), a UV-VIS-NIR spectrometer, software and an optical bench (not shown). (Courtesy of C.-A. Schiller, ZAHNER-Elektrik GmbH & Co. KG, Kronach, Germany [www.zahner.de].)

The OTE is used as a single working electrode or a stack of working electrodes and is combined with a reference electrode and a counterelectrode (auxiliary electrode) in a spectrochemical cell. Variations of the OTE include thin layer cells and long optical pathlength thin layer cells. Perforated and reflective electrodes are also used as working electrodes.

Plots derived from spectroelectrochemistry experiments can include, among others, absorbance as a function of potential at a constant wavelength, absorbance as a function of the wavelength at a constant potential, or absorbance as a function of time after a potential step or scan, which gives a derivative of the signal with respect to time in the shape of a cyclic voltammogram. In general, the approach taken is to set a potential, allow the system under study to equilibrate, collect a spectrum and then repeat at different potentials.

A commercial system set up for transmission or absorption measurements in the UV-VIS-NIR range (from 245–1550 nm) is shown in Figure 13.38.

In the ZAHNER CIMPS system, the light source and the cells are aligned on an optical track. Switching between the reference and the measurement cell is automatic. A closeup of the measurement cell is shown in Figure 13.39, set up for a study of a multilayer organic solar cell model system, shown schematically on the left side. In the PECC-2 cell shown, the reference electrode is Ag/AgCl and the counterelectrode is a Pt coil. The cell construction from PTFE or similar polymers allows use of aggressive and non-aqueous electrolytes.

By choosing "plug and play" components for the CIMPS system, more than 20 separate photoelectrochemical and spectroelectrochemical measurements can be made on processes and materials used in organic LEDs, electronic displays, and various types of solar cells. Examples of the types of data that can be obtained are shown in Figures 13.40-13.41.

Researchers at the University of Melbourne, Australia, have been performing IR-SEC studies of transition metal complexes, such as nickel carbonyl clusters, containing IR-active ligands like NO, CO and CN $^-$. (See Best et al. and the website listed in the bibliography for photos of the system and sample spectra.) The researchers use a three-electrode system designed into a central multi-electrode and an external reflectance IR-SEC cell. A thin film (10-20 μ m) of sample solution is trapped between the central electrode and an IR-transparent




FIGURE 13.39 A photo of the ZAHNER PECC-2 cell (left side) and a schematic diagram of a model system for an organic solar cell film sample with electrode positions shown on the right side. The schematic is not to scale. (Courtesy of C.-A. Schiller, ZAHNER-Elektrik GmbH & Co. KG. *ZAHNER-Elektrik GmbH & Co. KG, Kronach, Germany [www.zahner.de].)




FIGURE 13.40 Spectra series for the model solar cell layer system from the previous figure. The plots are of extinction versus wavelength at a series of cell voltages. (Courtesy of C.-A. Schiller, ZAHNER-Elektrik GmbH & Co. KG. *ZAHNER-Elektrik GmbH & Co. KG, Kronach, Germany [www.zahner.de].)




FIGURE 13.41 Plots of stability (left) and electrochemical reversibility (right) of the model organic solar cell system. Note that the reversibility is shown as a plot of current versus potential and has the same form as a cyclic voltammogram. (Courtesy of C.-A. Schiller, ZAHNER-Elektrik GmbH & Co. KG. *ZAHNER-Elektrik GmbH & Co. KG, Kronach, Germany [www.zahner.de].)




FIGURE 13.42 A schematic cell for IR-SEC studies. Note the IR-transparent CaF₂ window. (Courtesy of Professor Stephen P. Best, University of Melbourne, Australia.)

 ${\rm CaF_2}$ window and IR spectra recorded as the sample is oxidized or reduced. Figure 13.42 shows an IR-SEC cell design by Best's group, while Figure 13.43 shows an external reflectance cell design and how such a cell fits into an FTIR spectrometer. Transmission cells for IR-SEC can also be constructed, using the standard salt plate IR transmission cells described in Chapter 4.

IR-SEC is used to study electrochemically reversible reactions of a wide variety of molecules and biomolecules, including hemoglobin, myoglobin, and hydrogenase enzymes with CO or CN ligands at their Fe-Fe or Ni-Fe active sites. Depending on the cell design, sample volumes of $1\mu L$ can be studied.

"Quantum dots" are semiconductor nanocrystals with specific optical and electronic properties. Their use has grown in recent years in diodes, lasers, photovoltaic cells, and for labeling and tracking cells and other bioimaging applications. Researchers at Los Alamos




FIGURE 13.43 Schematic diagrams of an IR-SEC cell (left) and how the cell fits into a commercial FTIR spectrometer (right). (From Best, S.P.; Borg, S.J.; Vincent, K. A. Infrared spectroelectrochemistry in *spectroelectrochemistry*, Kaim, W.; Klein, A., Eds., RSC Publishing: Cambridge, UK, 2008. Reproduced by permission of the Royal society of chemistry.)

National Laboratory have studied the photoluminescence behavior of single quantum dots, CdSe-CdS core shell nanocrystals, using laser-based fluorescence microspectroscopy while manipulating the charge state of the particles in a working electrochemical cell. (See www.cen.acs.org/articles/89/2011/12/Quantum-Dots-Blink.html). A good introduction to luminescence spectroelectrochemistry is the article by Kirchhoff listed in the bibliography. Other luminescence phenomena, such as chemiluminescence, can be electrochemically induced and this technique is used in biochemical and clinical research, as described in the book by Bard (2004).

SUGGESTED EXPERIMENTS

- Run a DC polarogram with a known volume of 1 M KNO₃ electrolyte that has not been de-aerated. Observe and identify the two reduction waves of dissolved oxygen.
- 13.2 Purge the electrolyte in Experiment 13.1 with purified nitrogen gas for 20 min or so. Add sufficient lead nitrate solution to make the electrolyte 1.0×10^{-4} M in Pb²⁺ ion. Record the DC polarogram and measure the limiting current and the half-wave potential (E_{ν}) for the lead ion reduction wave.
- 13.3 Measure the mercury flow rate with the column height set as for Experiment 13.2. Collect about 20 droplets under the electrolyte (why?) and determine the drop lifetime with a stopwatch. Use the Ilkovic equation to calculate the diffusion equation for Pb²⁺ ion and compare your derived value with a literature value.
- 13.4 Record a normal pulse polarogram of (a) 1.00×10^{-5} M $\rm Zn^{2+}$, (b) Cd ion and, (c) Cu ion in a degassed 1 M KNO₃ electrolyte. Construct a graph of potential (*E*) versus $\log[(i_{\rm L}-i)/i]$. Determine the value of *n* from the slope and comment on the reversibility of this reaction. How does the electrolyte temperature affect the slope of this curve?
- 13.5 Record a differential pulse polarogram of a background electrolyte without and with added tapwater. Which metal species are present? Use a standard additions calibration to quantify one of the metal impurities. Compare E_{peak} with $E_{1/2i}$.
- 13.6 Use a F⁻ ion selective electrode per manufacturer's instructions to find the concentration of F⁻ ion in your drinking water and in your brand of (a) toothpaste and (b) mouthwash. Use a standard additions calibration procedure. Some sample preparation may be needed for the toothpaste. Several extraction procedures are available in the literature.
- 13.7 Collect some samples for pH analyses, for example, rainfall, snow, lake water, pool water, soft drinks, fruit juice. Standardize the pH meter with a standard buffer of pH close to the particular sample of interest. Design some experiments to change the temperature of these samples. What is the influence of temperature on pH measurements?

- 13.8 a. Use a glass pH electrode combination and titrate unknown strength weak acid(s) with 0.2000 N NaOH. Stir the electrolyte continuously.
 - b. Calculate the strength(s) of the acid(s) (i.e., the pK_a) and explain the shape of the curve.
- 13.9 Copper sulfate may be analyzed by gravimetry by exhaustive electrolysis at a weighed platinum electrode. Add 2 mL H₂SO₄, 1 mL HNO₃, and 1 g urea to 25 mL of the copper solution.
- 13.10 Tap waters, as well as a variety of biological fluids and natural waters, can be analyzed for heavy metals by anodic stripping voltammetry at a hanging mercury drop electrode. Clean glassware and sample bottles by leaching for about 5 h in 6 N HNO $_3$. First, analyze for Cd $^{2+}$ and Pb $^{2+}$ ions at acidic pH (2-4). Deposition is made with gentle stirring for 2 min exactly. After a 15 s quiescent period, scan from -0.7 V SCE in the positive direction. Zn $^{2+}$ and Cu $^{2+}$ ions can be analyzed by raising the pH to 8-9 with 1 M NH $_4$ Cl/1 M NH $_4$ OH buffer. Deposit at -1.2 V SCE and strip as before. It will be necessary to adjust the deposition time and/or current output sensitivity to achieve best results.
- 13.11 Cyclic voltammetry can be used to study the reversible reduction—oxidation couple of $[Fe(CN)_6]^{3-} + e^- \leftrightarrow [Fe(CN)_6]^{4-}$. You will need solutions of 1 M KNO₃, 5×10^{-3} M K₃ $[Fe(CN)_6]$ in 1 M KNO₃, and 5×10^{-3} M VOSO₄ in 1 M KNO₃. A CV equipped with a three-electrode cell (Pt microelectrode as the working electrode, Pt foil electrode as the auxiliary electrode and a calomel reference electrode) and an X-Y recorder (or computer data system) is required. The potassium nitrate solution serves as the baseline. All solutions must be purged with nitrogen to eliminate oxygen before scanning the potential. A sweep from 0.80 to -0.12 V and back versus SCE is suitable for the Fe system. The range may need to be changed for the vanadium system. Can you evaluate n for each system? Is the value what you expect for each reaction? Evaluate n for each system. Do these values agree with those in the literature? (Experiment courtesy of Professor R.A. Bailey, Department of Chemistry, Rensselaer Polytechnic Institute.)

PROBLEMS

- 13.1 Give an example of a half-cell. The absolute potential of a half-cell cannot be measured directly. How can the potential be measured?
- 13.2 Using the Nernst equation, complete the following table:

pH of Solution	Concentration of H+	E of Hydrogen Half-Cell
		0
1.2		
3		
	10-5	
	10-10	
7		
12		
14		

- 13.3 Describe and illustrate an SCE. Write the half-cell reaction.
- 13.4 How is pH measured with a glass electrode? Why does a glass electrode give pH readings lower than the actual pH in strongly basic solutions? What other errors can occur in pH measurement with a glass electrode?
- 13.5 Calculate the theoretical potential of the following cell. Is the cell as written galvanic or electrolytic?

$$\text{Pt} \Big| \text{Cr}^{\text{3+}} \Big(3.00 \times 10^{-2} \, \text{M} \Big), \text{Cr}^{\text{2+}} \Big(4.00 \times 10^{-5} \, \text{M} \Big) \Big\| \text{Sn}^{\text{2+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big), \text{Sn}^{\text{4+}} \Big(2.00 \times 10^{-4} \, \text{M} \Big) \Big| \text{Pt} \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big), \text{Cr}^{\text{2+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{\text{3+}} \Big(2.00 \times 10^{-2} \, \text{M} \Big) \Big| \text{Cr}^{$$

13.6 A salt of two monovalent ions M and A is sparingly soluble. The E^0 for the metal is +0.621 V versus SHE. The observed emf of a saturated solution of the salt is 0.149 V versus SHE. What is the solubility product $K_{\rm sp}$ of the salt? (Neglect the junction potential.)

- 13.7 Describe the process of electrodeposition and how it is used for electrogravimetric analysis.
- 13.8 Can two metals such as iron and nickel be separated completely by electrogravimetry? Explain your answer and state any assumptions you make.
- 13.9 State Faraday's Law. A solution of Fe³⁺ has a volume of 1.00 L, and 48,246 C are required to reduce the Fe³⁺ to Fe²⁺. What was the original molar concentration of iron? What is the molar concentration of Fe²⁺ after the passage of 12,061 C?
- 13.10 What are the three major forms of polarography? State the reasons why pulse polarographic methods are more sensitive than classical DC polarography.
- 13.11 What are the advantages of mercury electrodes for electrochemical measurements? What are the advantages of the dropping mercury electrode versus a Pt microelectrode for polarography? What are the disadvantages of the DME?
- 13.12 Describe the method of anodic stripping voltammetry. What analytes can it be used to determine? Why is stripping voltammetry more sensitive than other voltammetric methods?
- 13.13 Describe the principle of an ISE. Why is the term ion-specific electrode not used?
- 13.14 How can conductometric measurements be used in analytical chemistry? Give two examples.
- 13.15 Briefly outline two types of electrochemical detectors used for chromatography (See Chapter 12).
- 13.16 The fluoride ISE is used routinely for measuring fluoridated water and fluoride ion in dental products such as mouthwash. A 50 mL aliquot of water containing sodium fluoride is analyzed using a fluoride ion electrode and the method of standard additions. The pH and ionic strength are adjusted so that all fluoride ion is present as free F^- ion. The potential of the ISE/reference electrode combination in a 50 mL aliquot of the water was -0.1805 V. Addition of 0.5 mL of a 100 mg/L F^- ion standard solution to the beaker changed the potential to -0.3490 V. Calculate the concentration of (1) fluoride ion and (2) sodium fluoride in the water sample.
- 13.17 Copper is deposited as the element on a weighed Pt cathode from a solution of copper sulfate in an electrolytic cell. If a constant current of 0.600 A is used, how much Cu can be deposited in 10.0 min? (Assume no other reductions occur and that the reaction at the anode is the electrolysis of water to produce oxygen.)
- 13.18 Why does coulometry not require external calibration standard solutions?
- 13.19 Explain why a silver electrode can be an indicator electrode for chloride ion.
- 13.20 What are the three processes by which an analyte in solution is transported to an electrode surface? What single transport process is desired in polarography? Explain how the other transport processes are minimized in polarography.
- 13.21 Would you expect the half-wave potential for the reduction of copper ion to copper metal to be different at a Hg electrode from that at a platinum electrode? Explain your answer.
- 13.22 Sketch a schematic cyclic voltammogram for a nonreversible reduction reaction. (See Figure 14.34 for a CV of a reversible reaction.)
- 13.23 What is meant by spectroelectrochemistry? What types of electromagnetic radiation can be used in this technique?
- 13.24 Describetwotypesofopticallytransparentelectrodesforuseinspectroelectrochemistry.

BIBLIOGRAPHY

Adams, R. Electrochemistry at Solid Electrodes; Marcel Dekker, Inc.: New York, 1969.

Aikens, D.; Bailey, R.; Moore, J.; Giachino, G.; Torukins, R. *Principles and Techniques for an Integrated Chemistry Laboratory*; Waveland Press, Inc.: Prospect Heights, IL, 1985.

ASTM. Annual Book of ASTM Standards, Water and Environmental Technology; ASTM: West Conshohocken, PA, 2000; Vols. 11.01 and 11.02.

Bard, A.J., Ed. Electroanalytical Chemistry; Marcel Dekker, Inc.: New York, 1993.

Bard, A.J., Ed. *Electrogenerated Chemiluminescence*, CRC Press: Boca Raton, 2004.

Bard, A.J.; Faulkner, L.R. *Electrochemical Methods—Fundamentals and Applications*; John Wiley and Sons, Inc.: New York, 1980.

Bard, A.J.; Parsons, R.; Jordan, J., Eds. Standard Potentials in Aqueous Solution; Marcel Dekker, Inc.: New York, 1985.

Baizer, M.M.; Lund, H. Organic Electrochemistry; Marcel Dekker, Inc.: New York, 1983.

Bates, R.G. Determination of pH; John Wiley and Sons, Inc.: New York, 1973.

Best, S.P.; Borg, S.J.; Vincent, K.A. Infrared spectroelectrochemistry in *Spectroelectrochemistry*, Kaim, W.; Klein, A., Eds., RSC Publishing: Cambridge, UK, 2008. (See also www.chemistry.unimelb.edu.au/staff/spbest/techniques/SEC.htm.)

Berezanski, P. In *Handbook of Instrumental Techniques for Analytical Chemistry*; Settle, F.A., Ed.; Prentice-Hall PTR: NJ, 1997.

Bockris, J.O. Modern Electrochemistry; Plenum Press: New York, 1970; Vols. 1 and 2.

Bond, A.M. Modern Polarographic Methods in Analytical Chemistry; Marcel Dekker, Inc.: New York, 1980.

Curie, P.; Curie, J.C. R. Acad. Sci. 1880, 91, 294.

Dean, J.A. Analytical Chemistry Handbook; McGraw-Hill, Inc.: New York, 1995.

Diefenderfer, A.J.; Holton, B.E. Principles of Electronic Instrumentation, 3rd; Saunders College Publishing: Philadelphia, PA, 1994.

Dryhurst, G. Electrochemistry of Biological Molecules; Academic Press: New York, 1977.

Enke, C.G. The Art and Science of Chemical Analysis; John Wiley and Sons, Inc.: New York, 2000.

Evans, A. Potentiometry and Ion Selective Electrodes; John Wiley and Sons, Inc.: New York, 1987.

Ewing, G.W., Ed. Analytical Instrumentation Handbook, 2nd; Marcel Dekker, Inc: New York, 1997.

Fritz, J.S. Acid—Base Titrations in Non-Aqueous Solvents; G. Frederick Smith Chemical Company: Columbus, OH, 1952 (This publication had been available from GFS Chemicals upon request.)

Fry, A.J. Synthetic Organic Electrochemistry; Harper and Row: New York, 1972.

Gale, R.J., Ed. Spectroelectrochemistry; Plenum Press: New York, 1988.

Greenberg, A.; Clesceri, L.; Eaton, A., Eds. Standard Methods for the Examination of Water and Wastewater, 18th; American Public Health Association: Washington, DC, 1992.

Harris, D.C. Quantitative Chemical Analysis, 5th; W.H. Freeman and Co: New York, 1999.

Hart, J.P. Electroanalysis of Biologically Important Compounds; Ellis Horwood: New York, 1990.

Huber, W. Titrations in Nonaqueous Solvents; Academic Press: New York, 1967.

Ives, D.J.G.; Janz, G.J., Eds. Reference Electrodes—Theory and Practice; Academic Press: New York, 1961.

Kaim, W.; Klein, A., Eds. Spectroelectrochemistry; RSC Publishing: London, 2008.

Kalvoda, R. *Operational Amplifiers in Chemical Instrumentation*; Ellis Horwood: Chichester, 1975.

Kirchhoff, J.R. Current Separations 1997, 16 (1), 11.

Kissinger, P.T.; Heineman, W.R. *Laboratory Techniques in Electroanalytical Chemistry*, 2nd; Marcel Dekker, Inc: New York, 1996.

Koryta, J.; Stulik, K. Ion-Selective Electrodes, 2nd; Cambridge University Press: Cambridge, 1983.

Kucharsky, J.; Safarik, L. Titrations in Nonaqueous Solvents; Elsevier: Amsterdam, 1965.

Malmstadt, H.V.; Enke, C.G.; Crouch, S.R. *Microcomputers and Electronic Instrumentation: Making the Right Connections*; American Chemical Society: Washington, DC, 1994.

Meites, L.; Zuman, P.; Rupp, E.B., Eds. CRC Handbook Series in Organic Electrochemistry; CRC Press, Inc.: Boca Raton, FL, 1982; Vols. 1–5.

Michael, A.; Wightman, R.M. In *Laboratory Techniques in Electroanalytical Chemistry*, 2nd Ed.; Kissinger, P., Heineman, W., Eds.; Marcel Dekker, Inc.: New York, 1996.

Plieth, W.; Wilson, G.S.; Gutierrez de la Fe, C. *Pure and Appl. Chem* 1998, 70 (7), 1395 ©IUPAC. Sauerbrey, G. *Z. Phys.* 1959, 155, 206.

Settle, F.A., Ed. *Handbook of Instrumental Techniques for Analytical Chemistry*; Prentice-Hall PTR: NJ, 1997.

Streuli, C.A. Titrimetry: acid-base titrations in non-aqueous solvents. In *Treatise on Analytical Chemistry, Part I*; Kolthoff, I.M.; Elving, P.J., Eds.; Wiley-Interscience: New York, 1975, Vol. II.

Vydra, F.; Stulik, K.; Julakova, E. Electrochemical Stripping Analysis; Ellis Horwood, 1976.

Wang, J. Stripping Analysis; VCH Publishers, Inc.: Deerfield Beach, FL, 1985.

Warner, M. Anal. Chem. 1994, 66, 601A.

Zhao, Z.; Jiang, H. Enzyme-based electrochemical biosensors. In *Biosensors*; Serra, P.A., Ed.; InTech, DOI: 10.5772/7200. http://www.intechopen.com/books/biosnsors/enzyme-based-electrochemical-biosensors. February 1, 2010.

Thermal Analysis

14

When matter is heated, it undergoes certain physical and chemical changes. Physical changes include phase changes such as melting, vaporization, crystallization, transitions between crystal structures, changes in microstructure in metal alloys and polymers, changes in protein structure, volume changes (expansion and contraction), adsorption, absorption and desorption of gases, and changes in mechanical behavior. Chemical changes include reactions to form new products, oxidation, corrosion, decomposition, dehydration, chemisorption, binding between compounds (proteins and drugs, for example), and the like. These physical and chemical changes take place over a wide temperature range. The rates of chemical reactions vary with temperature and the properties of some materials, such as semicrystalline polymers and metal alloys, depend on the rate at which they are cooled. Materials are used over a wide range of temperatures, from arctic cold to tropical heat, in corrosive environments, variable humidity and under load (stress). It is necessary to characterize materials and their behavior over a range of temperatures to determine what materials are suitable for specific uses and to determine what temperature range materials or chemicals can withstand without changing. This sort of information is used in many ways: to predict safe operating conditions for products, such as which type of tire material is best for vehicles in extremely cold or extremely hot climates, the average expected lifetime of materials such as paints and polymers exposed to temperature changes, processing conditions for materials, the curing times and temperatures for dental filling material, and optimum storage conditions for food, among other uses.

The physical changes and chemical reactions a sample undergoes when heated are characteristic of the material being examined and the atmosphere in which the heating occurs. By measuring the temperature at which such reactions occur and the heat involved in the reaction, we can determine a great deal about the material. Composition of pure compounds and mixtures, including polymer blends, can be determined. The purity of pharmaceutical compounds can be determined. Rate of reaction, rate of crystallization, glass transition temperatures, decomposition temperatures, and catalysis can be studied. The effectiveness of additives and stabilizers in materials can be evaluated. Enthalpy changes (ΔH) of reactions can be measured. Percent crystallinity of polymers, which greatly affects the mechanical properties of polymers, can be determined. By heating materials under load (stress), mechanical properties such as modulus, ductility, yield point (the point at which nonpermanent elastic deformation changes to permanent plastic deformation), and volume change as a function of the load can be measured. These parameters are very important in engineering design to ensure safe and functional products.

Heat is involved in most real-life processes. This permits heat-into or out-of a system to serve as a universal detector. In many cases, the heat into or out of a system can be measured non-destructively. Heat transfer occurs in three ways: conduction, convection, and radiation. Conduction occurs between solid materials when placed in contact with each other. Convection occurs when a hot material and a cold material are separated by a fluid (gas or liquid). Radiative heat transfer involves the emission and consequent absorption of electromagnetic radiation between a hot and cold material.

The analytical techniques used to study changes in physical properties with temperature are called **thermal analysis** techniques. They include thermogravimetric analysis (TGA), differential thermal analysis (DTA), differential scanning calorimetry (DSC), thermometric titration (TT), isothermal titration calorimetry (ITC), microcalorimetry, direct

TABLE 14.1 Thermal Analysis Methods

Thermal Analysis Technique	Principle	Information Obtained
TGA	Measures change in weight with respect to temperature and time in an inert or reactive atmosphere	Thermal stability, oxidative stability, kinetics, degradation, and shelf life. EGA when coupled to gas chromatography (GC), infrared (IR), and/or mass spectrometry (MS) for chemical composition and identification.
DSC	Monitors the difference in temperature between a sample and a reference material as a function of time and temperature in a specified atmosphere. Quantitatively measures heat absorbed or released by a material undergoing a physical or chemical change	Glass transition, melt and phase change temperatures, heats of reaction, heat capacity, crystallinity, aging, degradation, and thermal history.
DTA	Monitors the difference in temperature between a sample and a reference material as a function of time and temperature in a specified atmosphere. Qualitative or semiquantitative measurement of heat absorbed or released by a material undergoing a physical or chemical change	Same as DSC but heat capacity and ΔH results are qualitative or semiquantitative.
TMA, dilatometry	Measurement of dimensional change with temperature in a specified atmosphere	Coefficient of thermal expansion (CTE), transition temperatures, and stress relaxation.
DMA	Measurement of viscoelastic properties of solid materials as a function of temperature and time	Glass transition, brittleness, anisotropy, crystallinity, residual stress, residual cure, and aging.

injection enthalpimetry, dynamic mechanical analysis (DMA), and thermomechanical analysis (TMA). Thermal analysis techniques are used in the characterization of inorganic and organic compounds, polymers, cosmetics, pharmaceuticals, metals, alloys, geological samples, ceramics, glasses, and many manufactured products, as well as biological systems. Table 14.1 summarizes some common thermal analysis techniques and the information they provide. Table 14.2 presents a brief overview of some applications for various

TABLE 14.2 Some Applications of Thermal Analysis Methods

Applications	TGA	DSC, DTA	TMA	DMA
Compositional analysis	×	×		
Curing studies		×		×
Glass transition		×	×	×
Heat of reaction		×		
Oxidative stability	×	×		
Corrosion	×	×		
Creep			×	×
Stress relaxation			×	×
Thermal stability	×	×		
Viscoelastic properties			×	×
Protein denaturation		×		
Shrinkage			×	×

Note: \times indicates thermal analysis method(s) used to study this property.

TABLE 14.3 Partial List of Sample Types and Properties Examined by Thermal Analysis

Samples						
Chemicals	Elastomers	Explosives	Soils	Plastics	Textiles	Metals
×	×	×	×	×	×	×
×	×	×	×	×	×	
×	×	×		×		×
×	×	×		×	×	
×	×			×	×	
×						×
×	×			×	×	×
×	×	×	×	×		×
×	×	×		×	×	×
	× × × × × × × ×	× × × × × × × × × × × × × × × ×	ChemicalsElastomersExplosivesXXXXXXXXXXXXXXXXXXXXXXXXXXX	Chemicals Elastomers Explosives Soils X X X X X X X X X X X X X X X X X X X X X X X X X X X	<pre></pre>	ChemicalsElastomersExplosivesSoilsPlasticsTextilesXX

Note: \times = Sample type that has been characterized for this property.

thermal analysis methods. Table 14.3 lists some typical sample types and some of the properties that have been measured by thermal analysis methods.

14.1 THERMOGRAVIMETRY

Thermogravimetry or thermogravimetric analysis (TGA) measures the mass (weight) of a sample in a specified atmosphere as the temperature of the sample is changed. The most common temperature program is a linear increase in temperature with time, although isothermal programs, stepped temperature programs, and others can be used. In the most common TGA experiment, the sample temperature is increased linearly over a time period and the mass of the sample is constantly recorded. The output from a TGA experiment is a plot of mass (or mass %) versus temperature. The TGA plot is called a **thermal curve**. An example of a TGA thermal curve for the decomposition of calcium carbonate is shown in Figure 14.1. Weight or weight % is plotted along the *y*-axis and temperature (or time for a linear temperature ramp) along the *x*-axis. The change in weight of a sample as the temperature changes tells us several things. First, this determines the temperature at which the material loses (or gains) weight. Loss of weight indicates decomposition or evaporation of the sample. A gain in weight can indicate adsorption by the sample of a component in the atmosphere or a chemical reaction with the atmosphere, such as oxidation. Second, the temperatures at which no




FIGURE 14.1 TGA thermal curve for pure anhydrous calcium carbonate, $CaCO_3$. The loss in mass is due to the loss of $CO_2(g)$ and the compound remaining is CaO_3 .

weight change takes place are determined, which indicate the temperature stability of the material. These weight changes at certain temperatures are physical properties of chemical compounds under the conditions of the experiment (atmosphere, heating rate). This information can be used to determine if a sample is the same as a "standard" or "good" material in a production process, for example. Knowledge of the temperatures at which a sample is unstable and subject to decomposition or chemical change is important to the engineer because it reveals the temperature above which such materials as polymers, alloys, and building materials may *not* be used, as well as the temperatures at which they may be used safely.

The *weight lost* by a sample heated to a given temperature helps the analytical chemist to determine the composition of a compound and follow the reactions involved in its decomposition. It also enables the analytical chemist to identify crystals of unknown composition or determine the percentage of a given compound in a mixture of compounds. For example, if pure calcium carbonate, $CaCO_3$, is heated to 850 °C, it loses 44 % of its weight (Figure 14.1). Also, the gas evolved can be collected and identified as CO_2 . This observation confirms that the reaction:

$$CaCO_3(s) \rightarrow CaO(s) + CO_2(g)$$

takes place at this temperature. How do we know this? If we know our sample was pure $CaCO_3$ and CO_2 is identified as a product of the reaction, the need for mass balance tells us that CaO is a reasonable "other" product. If we had 50.0 mg of $CaCO_3$ to start with, the mass loss due to CO_2 can be calculated:

mg
$$CO_2 = (50.0 \text{ mg } CaCO_3) \times [1 \text{ mmol } CaCO_3 / 100.00 \text{ mg } CaCO_3] \times [1 \text{ mmol } CO_2 / 1 \text{ mmol } CaCO_3] \times [44.00 \text{ mg } CO_2 / \text{ mmol } CO_2] = 22.0 \text{ mg}$$

The loss of CO_2 equals a loss in weight of (22.0 mg/50.0 mg) × 100 % = 44 %. From the stoichiometry, it is expected that 1 mole of CO_2 is lost for every mole of $CaCO_3$ present, which corresponds to a loss of 44 % of the mass of 1 mole of $CaCO_3$. The experimental mass loss supports the theoretical loss if the decomposition of $CaCO_3$ proceeds according to the reaction proposed. The formation of CO_2 can be verified by having the evolved gas analyzed by MS or by online IR spectroscopy. The CaO can be confirmed by analysis of the residue by XRD or other techniques.

The TGA technique was developed to solve problems encountered in gravimetric analysis. For example, a common precipitating and weighing form for the determination of calcium was calcium oxalate. In practice, the calcium oxalate was precipitated, filtered, and the filtrate dried and weighed. The drying step was difficult to reproduce. A particular procedure might recommend drying at 110 °C for 20 min and cooling prior to weighing. The analyst would then obtain very reproducible results derived from his or her own work. A second procedure might recommend drying at 125 °C for 10 min, cooling, and weighing. As before, the analyst using this method would obtain very reproducible results, but these results might not agree with those of the first research worker. The thermal curve of hydrated calcium oxalate is shown in Figure 14.2. When we examine the thermal curve, we find that calcium oxalate loses weight over a range of temperatures from 100 °C up to 225 °C. The most logical explanation for this weight loss is that water is evaporating from the sample. The water that is driven off includes not only absorbed or adsorbed water from the precipitating solution, but also water of crystallization (also called water of hydration) that is bound to the calcium oxalate as CaC₂O₄·nH₂O. It is only when both types of water are driven off that reproducible results are achievable. If the sample were heated to 110 °C, the absorbed water would be driven off, but a small amount of bound water (i.e., water of crystallization) would also be lost. Similarly, if the drying temperature were 125 °C, the absorbed water would be driven off and a different small amount of bound water would be lost. As long as a drying temperature was rigidly adhered to, the results would be reproducible, but results using different drying temperatures would show differences because the amount of bound water lost would vary.




FIGURE 14.2 TGA thermal curve of hydrated calcium oxalate, $CaC_2O_4 \cdot nH_2O$, with both adsorbed water from the precipitation process and water of crystallization. There is a loss of adsorbed water starting at about 90 °C, and loss of bound water at about 150 °C. The stable compound above 225 °C is anhydrous calcium oxalate, CaC_2O_4 . This loses CO at about 450 °C to form $CaCO_3$. The calcium carbonate is stable until approximately 600 °C, when it loses CO_2 to form CaO. (Compare this step with figure 14.1).

The TGA experiment shows that drying to a temperature above 225 °C but below 400 °C will result in a stable form suitable for gravimetric analysis.

14.1.1 TGA INSTRUMENTATION

Modern TGA equipment has a sensitive microbalance for continuously measuring sample weight, a furnace surrounding a sample holder, and a purge gas system for providing inert or reactive atmospheres. A computer controls the furnace and the data (weight versus sample temperature) is collected and processed by computer. Intelligent autosamplers are available for most instruments that permit the unattended analysis of samples.

Modern analytical microbalances of several different designs are commercially available—torsion balances, spring balances, and electrobalances have been used in TGA instruments. In general, the balance is designed so that a change in sample weight generates an electrical signal proportional to the weight change. The electrical signal is transformed into weight or weight loss by the data processing system and plotted on the γ -axis of the thermal curve. TGA balances are available for sample masses from 1 to 1000 mg, with the usual sample weighing between 5 and 20 mg. There are specialized high-capacity TGA systems available that can accommodate samples of up to 100 g and systems that can handle microgram quantities of sample. Figures 14.3 and 14.4 show schematics of a TGA electrobalance. The usual sample size for TGA is very small, so care must be taken to obtain a homogeneous or representative sample. The balance itself must be thermally isolated from the furnace, although the sample holder and sample must be in the furnace. There are two possible configurations of the balance and furnace, a horizontal furnace or a vertical furnace. Both types of configuration suffer from drift as the temperature increases. Vertical configurations suffer from buoyancy effects due to the change in gas density with temperature. The horizontal configuration was designed to minimize buoyancy effects, but horizontal configurations experience changes in the length of the quartz rod connecting the sample to the balance as the temperature changes. Buoyancy effects and changes in the quartz rod result in error in determining the mass of the sample.

The furnace surrounds the sample and sample holder. It must be capable of being programmed for a linear heating rate. Modern instruments can be heated and cooled rapidly, which increases sample throughput. Instruments that heat at rates of up to 1000 °C/min




FIGURE 14.3 (a) Block diagram of a TGA system. S represents the sample pan hanging from the balance arm in position in the furnace (represented by the solid bars on each side). (b) Schematic of a commercial TGA, showing the purge gas inlet and outlet and the thermocouple position beneath the sample pan. (b: © 2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)




FIGURE 14.4 (a) Electrobalance for a TGA. As the sample weight changes, the balance arm tips, resulting in a change in the amount of light reaching the photocell. This generates a current to restore the arm position; the current is proportional to the change in weight of the sample. (© Thermo Fisher Scientific [www.thermofisher.com]. Used with permission.)

are available. One commercial instrument can heat at rates up to 200 °C/min from room temperature to about 1200 °C; cooling by forced air can be done at ~50 °C/min. There are furnaces available with upper temperatures of 1500 °C, 1700 °C, or 2400 °C; these higher temperature instruments are useful for studying refractory materials and engineering materials. The furnace must be able to be purged with a desired gas, to provide the correct atmosphere for the experiment and to remove gaseous products from the sample compartment. Argon or nitrogen is used when an inert atmosphere is desired. Reactive gas atmospheres can be used for certain studies. Air is often used for oxidation and combustion studies. Hydrogen gas may be used to provide a reducing atmosphere, with the appropriate precautions to prevent explosions. Modern instruments permit the purge gas to be switched automatically, so that the sample can start heating in an inert atmosphere and be switched to air or other reactive gas at high temperatures, for example.

The sample holder and any instrument parts inside the furnace, such as the thermocouple for measuring the temperature, must be able to withstand high temperature and be inert at these high temperatures. Quartz, platinum, and various ceramics are used for the sample holder and other parts. The sample is placed in a small pan or crucible made of Pt, aluminum, quartz, or ceramic. Pan volumes of 20, 50, 100, and 250 μ L are common.

Ideally, the temperature recorded is the exact temperature of the sample. This entails measuring the temperature of the sample while the analysis is carried out. It is particularly important to measure the temperature of the sample rather than that of the furnace. This is difficult because the temperature is measured with a thermocouple that is near but not in the sample. The temperature of the sample inside the furnace is measured with a thermocouple, either a chromel/alumel thermocouple or one made of Pt alloy. The thermocouple is never inserted directly into the sample because of possible sample contamination (or contamination of the thermocouple resulting in errors in temperature), inadvertent initiation of a catalytic reaction, particle size effects, sample packing effects, and possible weighing errors. The thermocouple is made as small as possible and placed close to the sample holder, sometimes in contact with the bottom of the sample pan. The temperature actually recorded may be slightly different from the sample temperature; the sample temperature generally is lower than the temperature recorded by the thermocouple. This is due to factors such as rate of heating, gas flow, thermal conductivity of the sample, and the sample holder. Modern instruments have a temperature-voltage control program in the computer software that permits reproducible heating of the furnace. With precise, reproducible heating, the thermocouple can be calibrated to provide accurate furnace temperatures, but the relationship between actual sample temperature and recorded temperature is complex. The problem is compounded by the fact that at temperatures below 500 °C, most of the heat transferred from the furnace to the sample takes place by convection and conduction, but at temperatures above 500 °C, where the furnace is red-hot, most of the energy is transferred by radiation. The switch from conduction-convection to radiative energy transfer makes choosing the position of the thermocouple to obtain accurate temperature measurements of the sample quite a complicated problem.

Temperature calibration of TGA instruments with samples of pure materials with well-characterized weight losses can be done, but often is not satisfactory. For example, one problem with this approach is that black samples such as coal behave differently from white samples such as calcium phosphate under the influence of radiant energy, and the sample temperatures will therefore be different under the same furnace conditions. A more accurate calibration method uses the Curie temperature of various ferromagnetic standard materials. The materials undergo specific and reversible changes in magnetic behavior at their Curie temperature. Standards are available covering the temperature range of 242-771 °C. A **ferromagnetic material** is magnetic under normal conditions, but at a characteristic temperature (**the Curie temperature**), its atoms become disoriented and paramagnetic and the material loses its magnetism. To take advantage of this phenomenon, we weigh the ferromagnetic material continuously, with a small magnet placed above the balance pan. The standard's apparent weight is then its gravitational weight minus the magnetic force it experiences due to the magnet immediately above. At the Curie temperature, the standard loses its magnetism and the effect of the magnet is lost. There is a change in the apparent weight of the




FIGURE 14.5 The TGA curie point method records for each standard an apparent sharp weight change at a well-defined temperature, which corresponds to a known transformation in the standard's ferromagnetic properties at that temperature. The figure shows the relative temperature precision from three replicate calibration runs using alumel and nickel Curie point standards. (Courtesy of TA instruments, New Castle, DE, www.tainstruments.com.)

standard, and this can be recorded. The temperatures of the Curie transitions of ferromagnetic materials are well known and therefore can be used for calibration purposes. An example of calibration using the Curie temperatures of alumel and nickel is shown in Figure 14.5.

14.1.2 ANALYTICAL APPLICATIONS OF THERMOGRAVIMETRY

One of the first important applications of thermogravimetry was the determination of correct drying temperatures for precipitates used in gravimetric analysis, as already described. A second important application was the identification of the gases given off while a sample's temperature is increased. In addition, the composition of the residue can be determined using techniques such as XRD, XRF, and other techniques. This information reveals the chemical decomposition process occurring when materials are heated and permits identification of the formulas of the starting materials. TGA is very important in determining the upper use temperatures of materials such as polymers by identifying the temperature at which oxidative degradation occurs on heating in air.

From Figure 14.6, it can be determined that when pure calcium oxalate monohydrate, CaC_2O_4 · $H_2O(s)$, is heated, it first loses water of crystallization and forms $CaC_2O_4(s)$. The fact




FIGURE 14.6 TGA thermal curve of calcium oxalate monohydrate, $CaC_2O_4 \cdot H_2O$.

that the compound contains only 1 mole of water of hydration can be determined from the mass loss. The reaction is:

$$CaC_2O_4 \cdot H_2O(s) \rightarrow CaC_2O_4(s) + H_2O(g)$$
Molecular weights (g/mol): 146 128 18

Therefore the %W lost due to 1 mole of water of crystallization = $(18/146) \times 100 = 12.3$ %. If our initial sample mass was 20.00 mg, the mass loss at the first step would be 2.46 mg if there is 1 mole of water of crystallization. If the mass loss actually measured was 4.92 mg, it would mean that there were 2 moles of water of crystallization and the formula would be $CaC_2O_4 \cdot 2H_2O(s)$, a dihydrate.

Upon further heating up to about 400 °C, CO(g) is given off and the reaction that occurs is:

$$\label{eq:CaC2O4} \text{CaC}_2\text{O}_4(\text{s}) \to \text{CaCO}_3(\text{s}) + \text{CO}(\text{g}) \uparrow$$
 Molecular weights (g/mol) 28

The %W lost from the initial compound = $(28/146) \times 100 = 19.2$ %. The total %W lost at this point is the sum of the two steps, 12.3 + 19.2 = 31.5 %.

Finally, at even higher temperatures (about $800\,^{\circ}\text{C}$), the CaCO $_{\!3}$ formed at $400\,^{\circ}\text{C}$ decomposes:

$$\label{eq:CaCO3} \mbox{CaCO}_3(s) \rightarrow \mbox{CaO}(s) + \mbox{CO}_2(g) \uparrow$$
 Molecular weights (g/mol) $\qquad \qquad 44$

The %W lost from the original compound = $(44/146) \times 100 = 30.1$ %. The total mass loss is the sum of all three steps: 12.3 + 19.2 + 30.1 = 61.6 %. The losses correspond to what is seen in the decomposition of calcium oxalate monohydrate in Figure 14.6. The \uparrow symbol indicates gas evolved from the sample and swept out of the TGA system. The gases may be identified if the TGA analyzer is connected to an IR spectrometer or a mass spectrometer, as described in Section 14.4.

TGA can be used for the identification of compounds present in mixtures of materials. When such mixtures are heated using a thermogravimetric analyzer, the thermal curve produced consists of all possible weight losses from all components superimposed on each other. Interpretation of the complete thermal curve requires that the individual thermal events be separated and identified. In many cases, the components of the mixture can be identified and a quantitative determination of each is possible from the thermal curve. An example of how this can be done is shown in Figure 14.7. The uppermost curve is the weight loss curve for pure compound A. The next lower curve is the weight loss curve for pure compound B. The bottom curve is the weight loss curve for a mixture of A and B. The amount of A present in the mixture can be determined from the weight loss between points δ and ε , while the amount of B is determined from the weight loss between points β and γ .

An illustration of the application of TGA to quantitative analysis of mixtures is the determination of the magnesium oxalate content of a mixture of magnesium oxalate and magnesium oxide, MgO. Magnesium oxalate decomposes to magnesium oxide, MgO, at ~500 °C. Pure MgO is stable at room temperature and to well above 500 °C; MgO does not lose any weight. The TGA curve for this mixture shows two mass losses, one at about 200 °C. The second mass loss occurs in the 397-478 °C range. It is reasonable to suppose that the first mass loss is due to loss of water, both adsorbed and water of crystallization. From the formula for MgC₂O₄·2H₂O, we see that there are 2 moles of water of crystallization for every mole of magnesium oxalate. Only one other mass loss is seen, and we know MgO is stable at these temperatures. We can assume that when MgC₂O₄· 2H₂O is heated to a temperature above 500 °C, it forms MgO according to the reaction:

$$\label{eq:MgC2O4} MgC_2O_4\cdot 2H_2O\to MgO(s) + CO + CO_2 + 2H_2O$$
 Molecular weights (g/mol)
$$148 \qquad 40 \qquad 28 \qquad 44 \qquad 18$$




FIGURE 14.7 TGA thermal curves for (top) pure A, (middle) pure B, and (bottom dotted line) a mixture of A and B. Because A and B have unique temperatures at which mass is lost, the composition of the mixture may be determined.

The final weight loss is therefore: $\%W = ([28 + 44 + 2(18)]/148) \times 100 = 73 \%$

We would lose 73 mg for every 100 mg of pure magnesium oxalate dihydrate we had in the mixture on heating the mixture to 500 $^{\circ}$ C. Note that the decomposition of magnesium oxalate does not follow the same process as the decomposition of calcium oxalate (Figure 14.6). Magnesium oxalate appears to decompose directly to MgO in one step at about 500 $^{\circ}$ C. The weight remaining from the magnesium oxalate is equal to:

$$\begin{split} \frac{\text{mol wt MgO}}{\text{mol wt Mg C}_2\text{O}_4 \cdot 2\text{H}_2\text{O}} \text{ per gram of MgC}_2\text{O}_4 \cdot 2\text{H}_2\text{O} \\ = & \left(\frac{40}{148}\right) = 0.27\text{g MgO/g MgC}_2\text{O}_4 \cdot 2\text{H}_2\text{O} \end{split}$$

If following data were obtained from a TGA curve:

Original weight of sample	25.00 mg
Weight of sample after heating to 500 °C	10.40 mg
Loss in weight	14.60 mg

the weight of $MgC_2O_4 \cdot 2H_2O$ in the original sample was:

mg
$$MgC_2O_4 \cdot 2H_2O = (14.60 \text{ mg lost})[100/73] = 20 \text{ mg}$$

Then the concentration of $MgC_2O_4 \cdot 2H_2O$ in the original sample was:

% Mg oxalate dihydrate = $(mg Mg oxalate dihydrate/total sample weight in mg) \times 100$

% Mg oxalate dihydrate =
$$(20 \text{ mg})/25.00 \text{ mg}) \times 100 = 80\%$$

Thus, the other 20 % of the starting mixture is MgO.

Similarly, we can determine the magnesium oxalate content and the calcium oxalate content in a mixture of the two compounds. The TGA curve of the mixture is shown in Figure 14.8.




FIGURE 14.8 TGA thermal curve of a mixture of calcium oxalate monohydrate and magnesium oxalate dihydrate. The last weight loss is due to the loss of CO₂ only from calcium oxalate monohydrate. Therefore, the composition of the mixture can be determined, even though the other steps have combined mass losses from both compounds.

We have already seen in Figure 14.6 that calcium carbonate decomposes to calcium oxide above 600 °C. We can deduce from the thermal curve for magnesium oxalate that magnesium carbonate is not stable because the oxalate decomposes directly to MgO. So, at temperatures above 500 °C, but below 600 °C, we should have a mixture of MgO and CaCO $_3$. Above 850 °C, the CaCO $_3$ will have decomposed to CaO, so the residue is a mixture of CaO and MgO. By examining Figure 14.6 and the information we have above on the magnesium salt, it is evident that the weight loss in Figure 14.8 above 600 °C is due to the evolution of CO $_2$ from the CaCO $_3$ that came from the CaC $_2$ O $_4$ ·H $_2$ O. We know one molecule of CaC $_2$ O $_4$ ·H $_2$ O generates one molecule of CO $_2$. If the weight loss above 600 °C (due to CO $_2$ loss) was 18 %, then the weight % of CaC $_2$ O $_4$ ·H $_2$ O in the mixture is

(mol wt
$$CaC_2O_4 \cdot H_2O$$
 / mol wt CO_2)×18% = (146 / 44)×18% = 60%

Assuming that the weights of calcium oxalate and magnesium oxalate total 100 %, then it follows that the percentage of Mg $(COO)_2$ ·2H₂O = 100 – 60 = 40 %. As you can see from the examples given, TGA can be used for quantitative analysis, but not without some knowledge of the sample. If there were other components in our mixture of oxalates that we did not know about, our assumption that the two oxalates composed 100 % of the sample would be wrong. If there is another component that loses weight above 600°C, we have another error. Without some knowledge of the sample, our calculated value for one (or both) of the components could be wrong.

TGA also provides quantitative information on organic compound decompositions, and is particularly useful for studying polymers. An example is the use of TGA to determine the amount of vinyl acetate in copolymers of vinyl acetate and polyethylene. On heating, each mole of vinyl acetate present loses 1 mole of acetic acid. A TGA study of several vinyl acetate-polyethylene copolymers is presented in Figure 14.9.

TGA is very useful for providing qualitative information about samples of many types. TGA can provide qualitative information on the stability of polymers when they are heated in air or under inert atmospheres. From the decomposition temperatures of various polymers heated in a TGA in an air atmosphere, the upper use temperatures of polymer materials can be determined. Figure 14.10 presents the decomposition temperatures for a variety of common polymeric materials; such a TGA comparison can be used to choose a polymer that will be stable below a certain temperature for a given application.

Another example of the application of thermogravimetry is in the characterization of coal. A TGA thermal curve for a coal sample heated in nitrogen or some other inert atmosphere




FIGURE 14.9 TGA thermal curves of vinyl acetate copolymers. The weight loss at 340 °C is due to loss of acetic acid and gives a quantitative measure of the amount of vinyl acetate in the polymer. (Courtesy of TA instruments, New Castle, www.tainstruments.com.)

indicates, in a single analysis, the percentage of volatiles present and the "fixed carbon"; if the atmosphere in the TGA is then automatically switched to air, the fixed carbon will burn and the amount of ash in the coal is determined as the residue left. This is very valuable information in the characterization of the quality of the coal and for its handling and subsequent use. Coals vary in their volatiles content and in their carbon content. Coals often contain a considerable amount of volatile material. The composition of this volatile material is variable and may contain valuable chemicals that can be used in the pharmaceutical industry, the dyestuff industry, and the chemical industry. Of course, it can be used as a fuel, "coal gas". The newest form of carbon to be discovered, C_{60} , called buckminsterfullerene, and related fullerene compounds are found in soot. TGA can be used to characterize soot for its fullerene content, as the fullerenes are more volatile than graphite. Similarly, nonvolatile additives in polymers can be measured quantitatively by TGA. The pigment additive "carbon black", which is not




FIGURE 14.10 TGA thermal curves showing the decomposition temperatures of some common polymers: PVC, polyvinylchloride; PMMA, polymethylmethacrylate; HDPE, high-density polyethylene; PTFE, polytetrafluoroethylene; PI, polyimide. (Courtesy of TA instruments, New Castle, www.tainstruments.com.)




FIGURE 14.12 (a) TGA (solid line) and DTG (dotted line) thermal curves of a pure hydrated sodium silicate. The TGA mass loss from 50-150 °C suggests loss of water in more than one form because of the change in slope seen during the step. The first derivative DTG plot clearly shows three separate mass losses due to water bound in different forms. (© 2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].) (b) Partial TGA (bottom curve) and DTG (top curve) thermal curves for a mixture of hydrated barium, strontium, and calcium oxalates. L. Erdey et al. (*Talanta* 1962, *9*, 489–493) showed that the three hydrated oxalates lost water at three different temperatures. The TGA seems to show only one step, but the DTG clearly shows the three separate losses, one for each salt.

of barium, strontium, and calcium. From the TGA, there appears to be a single weight loss occurring between 130 °C and 210 °C. This might be misinterpreted to be a single pure compound if all we had was the TGA thermal curve. But from the very sensitive DTG, it is clear that there are three different losses of water, occurring at 140 °C, 180 °C, and 205 °C, respectively. These peaks are in fact loss of water first from the barium salt, then from the strontium salt, and finally from the calcium salt. The DTG gave us a clue that more than one event was taking place, a clue that the TGA did not provide. Consequently, DTG is a valuable method of data presentation for thermal analysis. A similar example of the power of the DTG plot is shown in Figure 14.13, which shows desorption of chemisorbed basic compounds from the acidic sites of a zeolite catalyst. **Zeolites**, an important class of catalysts, are porous crystalline aluminosilicates with acidic sites. The number and relative strength of the acidic sites can be estimated by chemisorption of a basic compound, such as ammonia, and then studying its desorption by TGA/DTG. As seen in Figure 14.13, the weight change is small, about 1 % total spread over two broad steps, but the two steps are clearly evident from the DTG plot.




FIGURE 14.13 TGA and DTG thermal curves showing desorption of basic compounds from the acidic sites of a zeolite catalyst. Losses from weakly acidic sites can be distinguished from strongly acidic sites using the DTG curve, despite the fact that the overall mass loss is only about 1 %. The mass scale is on the left *y*-axis. (Courtesy of TA instruments, New Castle, from thermal analysis applications brief TA-231. www.tainstruments.com.)

The decomposition of polyvinyl chloride polymer (PVC) also demonstrates the power of the DTG plot. The TGA curve (solid line in Figure 14.14) seems to show two weight loss events, but the DTG plot (dotted line in Figure 14.14) clearly shows three steps. The loss at 280 $^{\circ}$ C is due to loss of HCl, while the mass losses at 320 $^{\circ}$ C and 460 $^{\circ}$ C are due to loss of hydrocarbons. We will learn how we know this later in the chapter.

14.1.4 SOURCES OF ERROR IN THERMOGRAVIMETRY

Errors in thermogravimetry can lead to inaccuracy in temperature and weight data. Proper placement of the TGA instrument in the laboratory, away from sources of vibration and heat, is essential to minimize fluctuations in the balance mechanism. Older instruments suffered




FIGURE 14.14 TGA (solid line) and DTG (dotted line) thermal curves of polyvinylchloride polymer heated under nitrogen. The first mass loss at 280 °C is due to loss of HCl. (© 2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

from an apparent gain in weight of a sample container when heated, known as the buoyancy effect. This effect, due to the decreased buoyancy of the atmosphere, changes in convection on heating and other complex factors, has been to a large extent eliminated in modern TGA instruments. The buoyancy effect can be evaluated and compensated for by running a blank (empty sample container) under the same conditions of heating and gas flow used for the samples. Errors can arise due to turbulence caused by the gas flow and due to convection on heating. Gas flow rates and heating rates should be kept as low as possible to minimize these effects.

Placement of the thermocouple is critical to accurate temperature measurement. Ideally, having the thermocouple in the sample itself would give the most accurate reading of the sample temperature. However, there are problems associated with putting the thermocouple into the sample. These include reaction with the sample, reproducible sample packing, sample mass, and thermal conductivity, among others. Modern instruments generally have the thermocouple in contact with the sample pan or close to the sample pan. The sample temperature is generally lower than the recorded temperature due to several factors including the finite heating rate, thermal conductivity of both the sample itself and the sample container, the gas flow rate, and similar factors. There is also the heat of reaction to take into account. An endothermic reaction will cause self-cooling of a sample and therefore an even greater lag in the sample temperature than would otherwise occur, while an exothermic reaction will decrease the lag in sample temperature.

14.2 DIFFERENTIAL THERMAL ANALYSIS

Differential thermal analysis (DTA) is a technique in which the difference in temperature, ΔT_i between the sample and an inert reference material is measured as a function of temperature. Both sample and reference material must be heated under carefully controlled conditions. If the sample undergoes a physical change or a chemical reaction, its temperature will change while the temperature of the reference material remains the same. That is because physical changes in a material such as phase changes and chemical reactions usually involve changes in **enthalpy**, the heat content of the material. Some changes result in heat being absorbed by the sample. These types of changes are called **endothermic**. Examples of endothermic changes include phase changes such as melting (fusion), vaporization, sublimation, and some transitions between two different crystal structures for a material. Chemical reactions can be endothermic, including dehydration, decomposition, oxidation-reduction, and solid-state reactions. Other changes result in heat being given off by the sample. Such changes are termed **exothermic**. Exothermic changes include phase changes such as freezing (crystallization), some transitions between different crystal structures and chemical reactions; decomposition, oxidation-reduction, and chemisorption can be exothermic. There are also physical changes that are not simple phase changes that still cause the sample temperature to change. Examples of such physical changes include adsorption and desorption of gases from surfaces and glass transitions in amorphous glasses and some polymers. The glass transition is a change in an amorphous material from a brittle, vitreous state to a plastic state. Glass transitions are second order phase

DTA and the related technique of DSC to be discussed are capable of measuring many types of physical and chemical changes that result in enthalpy changes. It is not necessary that the sample's weight change in order to produce a DTA response. However, if a weight change does take place, as occurs on loss of water, the enthalpy of the sample invariably changes, and a DTA response will be observed. So, DTA is capable of measuring the same changes measured by TGA, plus many additional changes that TGA cannot measure because no mass change occurs. A DTA plot has ΔT on the y-axis and T (or time) on the x-axis, as shown schematically in Figure 14.15. The x-axis temperature can be the temperature of the heating block, the temperature of the sample or the temperature of the reference, or it can be time. By convention, exothermic changes are plotted as positive, and the peaks point up, while endothermic changes are plotted as negative, and the peaks point down. (The same convention may be used for DSC; however, some instrument software uses the opposite convention.




FIGURE 14.15 Hypothetical DTA thermal curve for a semicrystalline polymer with the ability to crosslink. The plot shows the baseline shift that occurs at the glass transition temperature, T_g , exothermic peaks for crystallization and cross-linking (or curing), an exothermic peak (off scale) for oxidative decomposition, and an endothermic peak for melting of the polymer. A similar thermal plot would be obtained by DSC analysis. (Courtesy of TA instruments, New Castle, DE, www.tainstruments.com.)

We will see examples of both conventions.) Some changes, such as the glass transition shown in Figure 14.15, do not result in a peak, but only a step change in the baseline. The reason will be discussed later in the chapter.

14.2.1 DTA INSTRUMENTATION

The equipment used in DTA studies is shown schematically in Figure 14.16. The sample is loaded into a crucible, which is then inserted into the sample well (marked S). A reference sample is made by placing a similar quantity of inert material (such as Al_2O_3) in a second crucible. This crucible is inserted in the reference well, marked R. The dimensions of the two crucibles and of the cell wells are as nearly identical as possible; furthermore, the weights of the sample and the reference should be virtually equal. The sample and reference should be matched thermally and arranged symmetrically with the furnace so that they are both heated or cooled in an identical manner. The metal block surrounding the wells acts as a heat sink. The temperature of the heat sink is slowly increased using an internal heater. The sink in turn simultaneously heats the sample and reference material. A pair of matched thermocouples is used. One pair is in contact with the sample container (as shown); the other




FIGURE 14.16 Schematic DTA instrument. (© 2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

pair is in contact with the reference. The output of the differential thermocouple, $T_{\rm s}-T_{\rm r}$ or $\Delta T_{\rm r}$ is amplified and sent to the data acquisition system. This allows the difference in temperature between the sample and the reference to be recorded as a function of the sample temperature, the reference temperature, or time. If there is no difference in temperature, no signal is generated, even though the actual temperatures of the sample and reference are both increasing. Operating temperatures for DTA instruments are generally room temperature to about 1600 °C, although one manufacturer makes a DTA capable of operating from –150 °C to 2400 °C. To reach the very low sub-ambient temperatures, a liquid nitrogen cooling accessory is needed. Some low temperatures (but not –150 °C) may be reached with electrical cooling devices or with forced air-cooling.

When a physical change takes place in the sample, heat is absorbed or generated. For example, when a metal carbonate decomposes, CO₂ is evolved. This is an endothermic reaction; heat is absorbed and the sample temperature decreases. The sample is now at a lower temperature than the reference. The temperature difference between the sample and reference generates a net signal, which is recorded (Figure 14.15). If, in the course of heating, the sample undergoes a phase transition or a reaction that results in the generation of heat, that is, an exothermic reaction, the sample becomes hotter than the reference material. In this case, the sample heats up to a temperature higher than that of the reference material, until the reaction is completed. The sample then cools down or the temperature of the reference cell catches up until its temperature and that of the heat cell once again become equal. Such an effect is shown on the thermal curve as a peak that moves in a positive (upward) direction rather than in the negative direction, which allows us to distinguish between exothermic and endothermic reactions. The DTA experiment is performed under conditions of constant pressure (usually atmospheric pressure). Under constant pressure, the change in heat content of a sample (the change in *enthalpy*) is equal to the heat of reaction, ΔH . Any chemical or physical change that results in a change in ΔH gives a peak in the DTA thermal curve. There are some types of changes that do not result in a peak in the thermal curve but only a change in the baseline, as shown schematically in Figure 14.15. These types of changes do not undergo a change in ΔH , but a change in heat capacity, C_p . Heat capacity is sometimes referred to as specific heat, and is the amount of heat required to raise the temperature of a given amount of material by 1 K. If the amount of material is specified to be 1 mole, the heat capacity is therefore the molar heat capacity, with units of J/mol K. The most common process that gives rise to a change in baseline but not a peak in the DTA is a "glass transition" in amorphous materials such as polymers or glasses. The glass transition is discussed briefly under applications of DTA.

Modern DTA instruments have the ability to change atmospheres from inert to reactive gases, as is done in TGA. As is the case with TGA, the appearance of the DTA thermal curve depends on the particle size of the sample, sample packing, the heating rate, flow characteristics inside the furnace, and other factors. Thermal matching between the sample and the reference is often improved by diluting the sample with the inert reference, keeping the total masses in each crucible as close to each other as possible.

The peak area in a DTA thermal curve is related to the enthalpy change for the process generating the peak, so DTA instruments must be calibrated for both temperature and for peak area. The National Institute of Standards and Technology (NIST), a US government agency, has certified high-purity metals like indium, tin, and lead with melting points known to six significant figures and enthalpies known to three or four significant figures, and a series of high-purity salts with solid-state transition enthalpies which are accurately known. These materials can be used to calibrate both temperature and peak area.

Sample crucibles are generally metallic (Al, Pt) or ceramic (alumina, silica, zirconia) and may or may not have a lid. Many metal pans with lids have the lid crimped on using a special tool. Best results are obtained when the area of contact between the sample and the pan or crucible is maximized. Samples are generally in the 1-10 mg range for analytical applications. For applications where corrosive gases may evolve, boron nitride crucibles may be used. At very high temperatures, graphite and tungsten crucibles may be used, but only under inert atmospheres. Tungsten may be needed in hydrogen atmospheres if the temperature exceeds 1000 °C, since Pt will react with hydrogen.

The peak area in DTA is related to the enthalpy change, ΔH , to the mass of sample used, m, and to a large number of factors like sample geometry and thermal conductivity. These other factors result in the area, A, being related to the mass and ΔH by an empirically determined calibration constant, K:

$$(14.1) A = K(m)(\Delta H)$$

Unfortunately, K is highly temperature-dependent in the DTA experiment, so it is necessary to calibrate the peak area in the same temperature region as the peak of interest. This may require multiple calibration standards and can be time consuming. As we shall see, the calibration constant K for DSC is not temperature dependent; therefore, DTA is usually used for qualitative analysis, while DSC is used for quantitative measurements of ΔH and heat capacity.

14.2.2 ANALYTICAL APPLICATIONS OF DTA

DTA is based on changes of heat flow into the sample. Using DTA, we can detect the decomposition or volatilization of the sample, just as we can with TGA. In addition, however, physical changes that do not involve weight changes can be detected by DTA. Such changes include crystallization, melting, changes in solid crystal phases, and homogeneous reactions in the solid state. In each of these changes, there is a flow of heat between the sample and its surroundings caused by endothermic or exothermic transitions or by changes in the heat capacity. The main use of DTA is to detect thermal processes and characterize them as exothermic or endothermic, reversible or irreversible, but only qualitatively. DTA thermal curves can be used to determine the order of a reaction (kinetics), and can provide the information required to construct phase diagrams for materials. DTA can be used for characterization of engineering materials, for the determination of the structural and chemical changes occurring during sintering, fusing, and heat treatments of alloys to change microstructure, identification of different types of synthetic rubbers, and determination of structural changes in polymers.

An instance of the use of transitions where no change in weight occurs is the DTA characterization of polymers. The physical properties of a polymer, such as strength, flexibility, and solubility, depend (among other things) on its degree of crystallinity. Crystalline materials are those materials that exhibit a high degree of long-range and short-range order in the arrangement of their molecules or atoms. No polymers are 100 % crystalline, but some polymers can partially crystallize; these are called **semicrystalline** polymers. A polymer is a gigantic organic molecule, or **macromolecule**, with a high molecular weight, typically 5000-40,000 g/mol. Polymer molecules generally exist as long and flexible chains. The chains are capable of bending and twisting, as shown in Figure 14.17(a). A bulk polymer consists of large




FIGURE 14.17 (a) Amorphous polymer structure **(b)** semicrystalline polymer structure with aligned chains in the crystalline regions and random structure in the amorphous region.

numbers of these chains intertwined like a bowl of cooked spaghetti noodles or rumpled pieces of string. A polymer in this state, with no short-range or long-range order, is said to be **amorphous**. With some types of polymers and proper treatment, such as slow cooling from the molten state, some of these long chains can form crystal-like zones that are regularly oriented [Figure 14.17(b)]. The DTA curves of the two samples in Figure 14.17 would appear as in Figure 14.18 for samples that had been rapidly cooled (quenched) from the liquid state. At the glass transition temperature, $T_{\rm g}$, an amorphous material goes from a glassy, rigid state to a rubbery, flexible state as the temperature now permits large-scale molecular motion. Only amorphous materials or the amorphous regions of a semicrystalline material can exhibit a glass transition. On the molecular level, it is the temperature at which segments of 35-50 "backbone" atoms in the material can move in a concerted motion. At the glass transition, there is a change in the heat capacity, Cp, of the polymer, which is seen as a step-change in the baseline of the thermal curve. There is no change in the enthalpy at $T_{\rm g}$, so no peak occurs in the thermal curve; the glass transition is <u>not</u> melting. There is also a change in the rate of volume expansion of the polymer at T_g , which can be measured by thermomechanical analysis, TMA. On further heating, crystallization of the semicrystalline polymer occurs as the viscosity drops, molecular mobility increases, and the chains align themselves into ordered




FIGURE 14.18 Schematic DTA thermal curves for the totally amorphous polymer structure and the semicrystalline polymer structure shown in figure 14.17. Both show T_g ; only the semicrystalline polymer has a crystallization exotherm.

regions, resulting in an exothermic peak. The amorphous polymer shows no such exothermic peak. Additional heating will generally result in the melting of semicrystalline polymer, seen as an endothermic peak in the thermal curve. None of these transitions involves a change in mass of the sample, so none of these changes would be seen in a TGA thermal curve. Amorphous polymers do not melt, but may show an endothermic decomposition peak on continued heating. This decomposition would be seen by both DTA and TGA, since decomposition does involve weight loss. The degree of crystallinity in the semicrystalline polymer can be calculated from the heat of fusion (the area under the crystallization exotherm), but quantitative measurements of this sort are usually performed by DSC because DSC is more accurate than DTA for quantitative analysis.

Qualitative identification of materials is done by comparing the DTA of the sample to DTA thermal curves of known materials. DTA thermal curves serve as fingerprints for materials.

Theoretically, the area under each DTA peak should be proportional to the enthalpy change for the process that gave rise to the peak. Unfortunately, in a traditional simple DTA, there are many factors that are not compensated for. For example, DTA response generally decreases as the temperature increases. This makes the area under the peaks unreliable for enthalpy measurements unless the DTA has been calibrated in the temperature range of interest. Semiquantitative results for enthalpies can be obtained, but for quantitative enthalpy measurements, we turn to the DSC.

14.3 DIFFERENTIAL SCANNING CALORIMETRY

Calorimetry is the measurement of the heat of a process. The first calorimeter was developed by Lavoisier and Laplace in 1782.

In differential scanning calorimetry (DSC), differences in heat flow into a reference and sample are measured versus the temperature of the sample. The difference in heat flow is a difference in energy; DSC is a calorimetric technique and results in more accurate measurement of changes in enthalpy and heat capacity than those obtained by DTA.

The heat flow into or out of the sample, in the absence of any transition is:

$$dQ/dt = dQ/dT \times dT/dt$$

where dQ/dt is the heat flow, dQ/dT is the heat capacity and dT/dt is the heating rate.

When a transition occurs, either the heat capacity changes or some kinetic event changes the heat flow:

(14.3)
$$dQ/dt = dQ/dT \times dT/dt + f(T,t)$$

where the first three terms are as described above and f(T, t) is the kinetic events term.

14.3.1 DSC INSTRUMENTATION

The DSC measurement requires a sample and a reference, as does DTA. Modern DSC sample and reference pans are small and usually made of aluminum, although alodine-coated aluminum, gold, copper, platinum, graphite, and stainless-steel pans are available. They may or may not have lids, and the lids may be crimped on or hermetically sealed (capable of containing pressure). Crimping or hermetic sealing of pans generally requires a press for reproducible sample preparation. Sample size is generally 1-10 mg. The reference pan is often left empty, but an inert reference material such as is used in DTA may be used. Commercial DSC equipment can operate at temperatures from –180 °C to 725 °C, with specialized instruments capable of maximum temperatures of 2000 °C. The exact temperature range depends on the model of the instrument and most commercial thermal instrument companies offer a variety of operating ranges. The DSC must be able to be heated and cooled in a controlled manner. To achieve the very low end of the temperature range, a special liquid nitrogen




FIGURE 14.19 Schematic of a heat-flux DSC. (Courtesy of TA instruments, New Castle, www. tainstruments.com.)

cooling accessory is needed; for other cooling applications, electrical cooling or forced air cooling is used. Modern DSC instruments are available with automatic intelligent sample changers that permit the unattended analysis of as many as 50 samples or more in any order specified by the analyst.

There are two main types of DSC instrumentation: heat flux DSC and power compensated DSC. A schematic of a commercial **heat flux DSC** is presented in Figure 14.19. In a heat flux instrument, the same furnace heats both the sample and the reference. In heat flux DSC, the temperature is changed in a linear manner while the differential heat flow into the sample and reference is measured. The sample and reference pans sit on the heated thermoelectric disk, made of a Cu/Ni alloy (constantan). The differential heat flow to the sample and reference is monitored by area thermocouples attached to the bottom of the sample and reference positions on the thermoelectric disk. The differential heat flow into the pans is directly proportional to the difference in the thermocouple signals. The sample temperature is measured by the alumel/chromel thermocouple under the sample position. This temperature is an estimated sample temperature because the thermocouple is not inserted into the sample itself. The accuracy of this temperature will depend on the thermal conductivity of the sample and its container, the heating rate, and other factors. As shown in Figure 14.19, the sample and reference pans both have lids and the reference pan is an empty pan. A schematic of a power **compensated DSC** is presented in Figure 14.20. The major difference in power compensated DSC instruments is that two separate heating elements are used for the sample (marked P in Figure 14.20) and the reference. A change in temperature between the sample and the reference serves as the signal to "turn on" one of the heaters so that the sample and the reference




FIGURE 14.20 Schematic of a power-compensated DSC. (© 2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)

stay at the same temperature. When a phase change, reaction, glass transition, or similar event occurs in the sample, the sample and reference temperatures become different. This causes extra power to be directed to the cell at the lower temperature in order to heat it. In this manner, the temperatures of the reference and sample cells are kept virtually equal ($\Delta T=0$) throughout the experiment. The power and temperature are measured accurately and continuously. The temperatures of the sample and reference are measured using Pt resistance sensors, shown in Figure 14.20. The difference in power input is plotted versus the average temperature of the sample and reference. Power compensation provides high calorimetric accuracy, high precision, and high sensitivity. This permits analysis of very small samples as demonstrated in Figure 14.21, showing the determination of the heat of fusion of a 6 μ g sample of indium metal. Note that this figure is plotted opposite to the convention normally used for endothermic peaks. In theory, since electrical power is the quantity being measured, no calibration of the output should be necessary. In practice, these instruments are calibrated using standards to obtain the most accurate results.

The DSC peak area must be calibrated for enthalpy measurements. The same types of high-purity metals and salts from NIST discussed for calibration of DTA equipment are also used to calibrate DSC instruments. As an example, NIST SRM 2232 is a 1 g piece of high-purity indium metal for calibration of DSC and DTA equipment. The indium SRM is certified




FIGURE 14.21 DSC thermal curve showing the determination of the enthalpy of fusion of 6 μg of indium metal. (© 2020 PerkinElmer, inc. All rights reserved. Printed with permission. [www.perkinelmer.com].)




FIGURE 14.22 DSC thermal curve for a sample of polyethylene terephthalate (PET). $T_{\rm g}$ is observed at 78.9 °C. Crystallization begins at 137 °C and the area under the exothermic peak is equivalent to 36.36 J/g PET. Melting begins at about 323 °C; the area under the endothermic peak is equivalent to 40.13 J/g PET. (Courtesy of TA instruments, New Castle, DE, www.tainstruments.com.)

to have a temperature of fusion equal to 156.5985 °C \pm 0.00034 °C and a certified enthalpy of fusion equal to 28.51 ± 0.19 J/g. NIST offers a range of similar standards. These materials and their certified values can be found on the NIST website at www.nist.gov. Government standards organizations (national measurement laboratories) in other countries offer similar reference materials.

The resultant thermal curve is similar in appearance to a DTA thermal curve, but the peak areas are accurate measures of the enthalpy changes. Differences in heat capacity can also be accurately measured and are observed as shifts in the baseline before and after an endothermic or exothermic event or as isolated baseline shifts due to a glass transition. Because DSC provides accurate quantitative analytical results, it is now the most used of the thermal analysis techniques. A typical DSC thermal curve for polyethylene terephthalate, the polymer used in many soft drink bottles, is shown in Figure 14.22.


A third type of differential calorimeter design is the Tian-Calvet system first introduced commercially in the 1960's by Setaram Instrumentation (www.setaram.com). The Calvet type DSC detector is a 3D detector in a heat flux system [Figure 14.23(b-d)]. Instead of two thermocouples [Figure 14.23(a)], the sample and reference chamber are completely surrounded by an array of thermocouples that captures and measures almost all heat flow from the sample (94 \pm 1 %). A variety of Calvet detectors are available, with from 10-120 thermocouples surrounding the sample and reference. A 3D thermopile detector using Peltier elements is available for micro-DSC (μ DSC), shown in Figure 14.23(e and f). The advantages of the Calvet type detector over 2D plate-type DSC detectors are significant. The Calvet design allows the use of more sample mass with corresponding increased sensitivity.

Heat capacity, C_p , is measured using the following equation:

(14.4)
$$A_{\mu V} = S_{\mu V/mW} \times m_{kg} \times C_p \times V_{\circ C/min}$$

where A is the measured signal, S is the sensitivity, m is the sample mass, and V is the heating rate. By increasing both sample mass and sensitivity, the signal is increased over traditional DSC sensors. Accuracy and precision of the $C_{\rm p}$ determination are 1-3 %, versus 7-15 % for traditional DSC.

The plate type sensor measures heat only through the bottom of the sample, with efficiencies of 20-50 %, depending on the sensor thickness and the conductivities of the crucible, sample, and purge gas. The Calvet detector is 93-95 % efficient, and is independent of the






FIGURE 14.23 Two-dimensional plate detector versus 3D Calvet detector design. **(a)** A 2D plate detector with thermocouples under the two pans. Only the heat flow from the bottom of the pans is measured. **(b and c)** 3D Calvet calorimetric sensors (one cutaway) with arrays of thermocouples surrounding both the sample and reference chambers, capturing 94 % of the heat flow. **(d)** A Calvet detector with ten thermocouples each for the sample and reference. **(e and f)** A 3D heat flow detector using Peltier elements for the Setaram μ DSC7. (Courtesy of Setaram Instrumentation, SA, Caluire, France, www.setaram.com. Used with permission.)

variables just listed, resulting in more accurate quantitative measurement. Calibration of the sensor and measurements are independent of sample shape or type, contact between sample and crucible, pressure or flow rate. Larger sample size allows more accurate measurement on heterogeneous samples.

14.3.2 APPLICATIONS OF DSC

DSC is used to study all of the types of reactions and transitions that can be studied using DTA, with the added advantage of accurate quantitative measurements of ΔH and ΔC_p . Polymer chemists use DSC extensively to study percent crystallinity, crystallization rate, polymerization reaction kinetics, polymer degradation, the effect of composition on the glass transition temperature, heat capacity determinations, and characterization of polymer blends. Materials scientists, physical chemists, and analytical chemists use DSC to study corrosion, oxidation, reduction, phase changes, catalysts, surface reactions, chemical adsorption and desorption (chemisorption), physical adsorption and desorption (physisorption), fundamental physical properties such as enthalpy, boiling point, and equilibrium vapor pressure. DSC instruments permit the purge gas to be changed automatically, so sample interactions with reactive gas atmospheres can be studied. Food chemistry, pharmaceuticals, and biological materials can be studied and some examples will be discussed. Samples can be solids, liquids, creams, gels, emulsions, and so on. Homogeneity of the sample is critical for accurate results.

For example, from Figure 14.22, the heat of crystallization is measured to be 36.36 J/g and the heat of melting (or fusion) is measured to be 40.13 J/g by integration of the respective peaks by the instrument data analysis software. For this polymer sample, the measured heat of crystallization is slightly lower than the measured heat of melting, indicating that the polymer was partly crystalline at the start of the experiment. The $T_{\rm g}$ and the specific heat can also be accurately measured from this thermal curve.

DSC can be used to study the heat treatment of synthetic fibers, including heat-setting, drying, autoclaving, and dyeing, which often change the morphology of the fibers. Figure 14.24




FIGURE 14.24 PET heat-treatment and the resulting changes in the DSC thermogram. (Courtesy of TA instruments, New Castle. from thermal analysis applications brief TA-128. www.tainstruments.com.)

TABLE 14.4	DSC Results for	Three Sam	ples of Pol	vethylene
IADEL IT.T	DOC NEGULIS IOI	IIII CC Jaiii	DIES OI I OI	ActilAicile

Sample	Melt Onset (°C)	Melt Peak (°C)	Enthalpy (J/g)	% Crystallinity
1	121.9	132.9	195.9	67.6
2	121.3	132.6	194.5	67.1
3	122.3	131.6	180.1	62.1

Source: From TA Instruments Applications Brief TA-123, courtesy of TA Instruments, Inc., New Castle. DE. USA.

shows the polyethylene terephthalate (PET) fibers heat-treated (textured) at temperatures between 190-225 °C. The pseudo-endothermic event observed in all four thermograms is due to a volume relaxation phenomenon occurring at the $T_{\rm g}$ of the PET fibers as a result of physical aging. In addition, the larger endothermic peak (off scale) moves to higher temperatures with increasing heat-treatment temperature.

The **heat of fusion** is a useful measure of the **percent crystallinity** of polymers. Table 14.4 presents heat of fusion data and the calculated percent crystallinity for three different samples of polyethylene. The percent crystallinity is calculated from calibration with a sample of known crystallinity. The first two samples in the table are very similar in percent crystallinity and in their melting behavior; the third sample, however, has a lower percent crystallinity and a sharper melting profile (compare the melt onset and melt peak temperature columns). This tells the polymer chemist that sample 3 has been processed differently and will have different physical and mechanical properties than samples 1 and 2. The sharp melting of sample 3 is shown in Figure 14.25.

Food chemistry can be studied by DSC. Carrageenans are extracted from algae and are used in food processing for their gelation properties, forming rigid, high-strength gels used in dessert gels, pet foods, and other foods. DSC is used to study the order-disorder transitions on heating, the formation and melting behavior of these gels. The melting and solidification of cheese is studied by DSC to determine optimal thermal processing conditions and optimum storage temperatures. Dry milk powder and whey powder contain amorphous lactose. Storage of these products under high relative humidity conditions results in an unusable dense powder due to formation of α -lactose monohydrate. The measurement of α -lactose in dry milk and whey powder is detected by DSC by measuring the dehydration of α -lactose monohydrate. Similarly, the polymorphic forms of cocoa butter, one of the main ingredients in chocolate, have been studied by DSC to determine what occurs during chocolate




FIGURE 14.25 Melting point of a polyethylene sample by DSC. (Courtesy of TA instruments, New Castle. From thermal analysis applications brief TA-123. www.tainstruments.com.)

processing. Only one polymorph results in chocolate that melts near body temperature. The others melt too easily or at too high a temperature (see Olivon, et al.).

Biological and pharmaceutical applications for DSC include the study of protein denaturation, enzymatic reactions, phase changes in lipid bilayers and nucleic acid studies. DSC is used in the pharmaceutical and personal care industries to study phase changes in creams, gels and emulsions. Excipient compatibility is easily studied for drug formulation. For example, aspirin mixed with magnesium stearate exhibits a large endothermic reaction, while aspirin mixed with lactose shows no reaction; magnesium stearate would not make a good excipient for an aspirin formulation.

14.3.2.1 PRESSURE DSC

Normally, DSC experiments are run at atmospheric pressure. Running samples under different pressures can extend the usefulness of DSC. DSC instruments are available with high-pressure cells capable of operating at up to 500 bar (50 MPa or 493 atm). Changing the pressure will affect any reactions involving gases, while not having any significant effect on condensed phases. Boiling is the phase change of a material from liquid to gas. The boiling point of a material increases as the pressure increases, while the melting point (a phase change involving only solid and liquid) does not change significantly with pressure. Therefore, changing the pressure facilitates interpretation of peaks in a DSC thermal curve. If the peak shifts in temperature as a function of pressure, a gas is involved in the reaction that gave rise to the peak. Because the pressure affects the boiling point of a liquid, a series of experiments in a pressure DSC cell at known pressures yields boiling point shifts. These shifts can be used to obtain quantitative vapor pressure information on liquids. This has been especially useful in the characterization of fuels and alternative/renewable fuels.

Increasing the pressure will often increase the rate of a reaction involving gases. Adsorption of hydrogen is often used as a means of characterizing precious metal catalysts, such as the platinum catalysts used in automobile catalytic converters and the Pt and Pd catalysts used in large-scale organic chemical synthesis. A typical adsorption study may require large samples and take 6 h or more. The same type of study can be run in a pressure DSC cell in ~15 min. The high pressure of hydrogen accelerates the reaction. The adsorption and desorption of hydrogen on palladium as studied by DSC is shown in Figure 14.26. Many sample-atmosphere reactions such as oxidation of oils and greases can be accelerated by increasing the pressure of air or oxygen and can also be studied effectively by pressure




FIGURE 14.26 DSC thermal curve of adsorption and desorption of hydrogen from a precious metal catalyst under constant pressure.

DSC. Other pressure sensitive reactions, such as volatilization, are slowed down by increased pressure. Suppression of these reactions can be a valuable tool when pressure DSC is used to study a complex system.

14.3.2.2 MODULATED DSC

Modulated DSC* (MDSC*) is a patented technique from TA Instruments, New Castle, DE, USA. In MDSC, a controlled, single-frequency sinusoidal temperature oscillation is overlaid on the linear temperature ramp. This produces a corresponding oscillatory heat flow (i.e., rate of heat transfer) proportional to physical properties of the sample. Deconvolution of the oscillatory temperature and heat flow lead to the separation of the overall heat flow into heat capacity and kinetic components, called reversing and non-reversing heat flow. The overall heat flow (dQ/dt) may be described as the sum of a heat capacity term, $C_p\beta$, which is heating-rate dependent, with β representing the heating rate and a kinetic term, f(T, t), which is time and temperature dependent (Mohomed and Bohnsack 2013; Kraftmakher 2004).

Modulated DSC enables the separation of the total measured heat flow into two constituents, providing increased understanding of simultaneously occurring phenomena in a sample. For example, in a polymer like semicrystalline PET, MDSC can separate the glass transition and melting from the kinetic processes of enthalpic recovery (a measure of physical aging in polymers), cold crystallization, crystal perfection (the process of the least perfect crystals melting below the thermodynamic melting point, then crystallizing and remelting one or more times as the temperature increases). These pieces of information cannot all be obtained by conventional DSC since several of these processes overlap. All of the processes are critical to understanding failure in polymeric materials. In pharmaceutical studies, recrystallization of a drug may be seen in the non-reversing signal only, while $T_{\rm g}$ and melting are seen in both signals.

A disadvantage to the method is that calibration is required for temperature, enthalpy, and the heat capacity, as opposed to temperature and enthalpy only for standard DSC.

14.4 HYPHENATED TECHNIQUES

14.4.1 HYPHENATED THERMAL METHODS

While TGA provides useful data when a mass change is involved in a reaction, many reactions do not have a change in mass associated with them. The use of both TGA and DTA or TGA and DSC provides much more information about a sample than either technique alone provides. There are several commercial thermal analysis instrument manufacturers who offer simultaneous combination systems, often called STA systems (simultaneous thermal analysis). Simultaneous TGA-DTA and simultaneous TGA-DSC instruments are available. Instrument combinations cover a wide temperature range and come in both "analytical sample" size (1-20 mg) and high-capacity sample size. A schematic of a simultaneous TGA-DTA instrument is presented in Figure 14.27, showing the dual sample and reference pans. The instrument monitors both the weight change and the temperature difference between the sample and reference, and plots both the TGA and DTA thermal curves simultaneously. The hypothetical sample plots in Figure 14.28 show that two of the DTA peaks are clearly associated with the mass losses in the TGA, and there are two other "events" with enthalpy changes but no mass changes.

A slightly different approach to hyphenation of instruments is simultaneous analysis, where two or more methods are applied to the same sample. An example of this approach is the commercially available DSC-Raman system from PerkinElmer, Inc. (Menard et al.). In this system, a three-axis positioning adapter with optics allows accurate placement of the Raman probe over the sample in the DSC. Raman spectra can be collected as the DSC experiment progresses. The authors give an example of the ability to positively identify three solid polymorphs of acetaminophen. The combination of Raman and DSC gives the precise temperatures at which the solid-state conversions from one polymorph to the next occur. The




FIGURE 14.27 A schematic simultaneous TGA-DTA instrument. A weight change on the sample side displaces the beam and a drive coil current returns the beam to zero. The current is proportional to the weight change and serves as the TGA signal. The temperature change between the sample and reference pans is measured by thermocouples attached to the pans. The temperature differential is the DTA signal.




FIGURE 14.28 The TGA and DTA curves of a hypothetical sample. The two steps in the TGA curve result from weight losses. They correspond to the endothermic peaks A and C in the DTA plot. The DTA thermal curve also shows an exothermic event, B, and an endothermic event, D, that do not involve a change in mass.

DSC provides the temperature data and the information about exothermic and endothermic changes in the material while the polymorphs are identified from their Raman spectra.

14.4.2 EVOLVED GAS ANALYSIS

The evolution of gas from a thermal analyzer such as a TGA, DTA, or DSC may be determined using *evolved gas detection* (EGD) or, if qualitative or quantitative analysis of the gas is required, *evolved gas analysis* (EGA). These techniques are essentially a combination of thermal analysis and MS, tandem mass spectrometry (MSⁿ), GC-MS or other species-selective detectors, such as FTIR. The evolved gases from the furnace are carried through a heated




FIGURE 14.29 Schematic of a TGA coupled to a GC-MS through a heated transfer capillary line. (© 2020 PerkinElmer, inc. All rights reserved. Printed with permission. www.perkinelmer.com.)

transfer line to the mass spectrometer or FTIR or other gas analyzer. This permits real-time identification of the gases given off by the sample during the thermal program. Figure 14.29 presents a schematic of a TGA coupled to a GC-MS.

The alternative to real-time detection is to have a system for trapping the evolved gases and storing the trapped gases for analysis at a later time. Sorbents for collecting the evolved gases can be liquid or solid. The sorbents can be selective for a specific gas or a class of gaseous compounds. If no adsorbent material is desired, cryogenic trapping may be used.

The most common instruments interfaced to thermal analyzers are FTIR instruments and GC-MS instruments. FTIR is less sensitive and less versatile than MS, but is simpler and cheaper. For hyphenated thermal analysis-FTIR, a heated transfer line from the thermal analyzer is normally connected to a heated FTIR gas cell, as shown in Figure 14.30. The interface is relatively simple, because FTIR normally operates at ambient pressure as does the thermal analyzer. IR spectra are simple to interpret and reference libraries of gas phase IR spectra are available for common gases and volatile organic compounds. This makes positive identification of the evolved gas straightforward if the gas is one of the gases that often accompany the decomposition of a material, such as water vapor, CO, or HCl, for example. The decomposition of PVC polymer can be studied by TGA-FTIR. Looking back at Figure 14.14, we have the TGA thermal curve for PVC heated in nitrogen atmosphere. If the TGA is connected to an FTIR, the spectrum corresponding to the gas evolved at the first mass loss is the gas phase spectrum of HCl, Figure 14.31, indicating that the first step in the decomposition of PVC in an inert atmosphere is loss of HCl from the polymer.

Disadvantages to the use of a separate transfer line and separate FTIR include the need for a separate heater for the transfer line, hot or cold spots in an improperly heated line, leading to the possibility of contamination due to build-up of condensable gases in the transfer line. In addition, more linear bench space is required for side-by-side instruments. New instruments are now available with no separate transfer line between the thermal analysis system and the FTIR spectrometer. In the Netzsch *Perseus* TGA-DSC-FTIR system, a Bruker Optics ALPHA FTIR spectrometer is connected directly to the thermal analyzer in a vertical arrangement (Figure 14.30b). The built-in heated gas cell of the spectrometer is directly connected to the gas outlet of the furnace. No separate heating controller is needed. The low volume of the short gas path results in rapid response and is especially useful where condensable evolved gases are present.

MS has more analytical flexibility than FTIR, but interfacing a thermal analyzer is more difficult because of the low operating pressure required for MS. MS instruments typically operate at approximately 10^{-5} torr, while thermal analyzers are usually at atmospheric pressure. One approach is to evacuate the thermal analyzer, but the common method used is a






FIGURE 14.30 (a) Hyphenated TGA-FTIR, showing the heated transfer line and heated IR gas cell. (b) The *perseus* TGA-DSC-FTIR system with a vertical arrangement of the FTIR and thermal analysis system, with no external transfer line. (Courtesy of NETZSCH instruments, inc., Burlington, MA. www.netzsch-thermal-analysis.com.)




FIGURE 14.31 Gas phase FTIR spectrum of HCl.




FIGURE 14.32 (a) Commercial "supersonic" interface between a thermal analyzer and a mass spectrometer. The mass spectrum of evolved gases (up to molecular weights of 1024 Da) can be obtained to provide identification of the structure with no condensation during transfer between the thermal analyzer and the mass spectrometer. (Courtesy of Setaram Instrumentation, SA, Caluire, France. www.setaram.com). (b) A different commercial TG-GC-MS system, showing the Netzsch TG 209 on the right, connected to a GC-MS via an external transfer line. (Courtesy of NETZSCH Instruments, Inc., Burlington, MA. www.netzsch-thermal-analysis.com.)

differential pumping system such as that used for GC-MS. This reduces the pressure from the thermal analyzer in several stages prior to allowing the gas flow into the mass analyzer. A commercial interface for a thermal analyzer-MS system can be a supersonic jet to skim analyte molecules into the MS, in a manner similar to the jet separators used in GC-MS (Figure 14.32). Jet separator operation is discussed in the chapter on GC (Chapter 11) under hyphenated techniques.

Evolved gas analysis is used for materials characterization, polymer analysis, characterization of oil shale, oxidation and reduction studies, evaluation of catalysts, and many other applications.

In the environment, persistent organic pollutants such as polyaromatic hydrocarbons have been shown by TGA-GC-MS to exhibit a six- to ten-fold increased partitioning to the water phase in an octanol-water solution in the presence of ${\rm TiO_2}$ nanoparticles, suggesting that the increasing use of engineered nanoparticles may influence the transport of pollutants and other chemicals in the environment (Sahle-Demessie, et al).

14.5 THERMOMETRIC TITRIMETRY

Thermometric titration depends on measuring the heat generated during a chemical reaction; therefore, it is another **calorimetric technique**. Usually, the reactions take place at room temperature under conditions such that no heat enters or leaves the titration cell except that brought in by introduction of the titrant. A titrant of known concentration is added to a known volume of sample. The titration reaction follows the generalized chemical equation

$$A(sample) + B(titrant) \rightarrow C(products) + heat$$

For any particular reaction, a mole of A titrated with a mole of B will generate a fixed quantity of heat, which is the heat of reaction. If there is half a mole of A present, half as much heat is generated, even if there is an excess of B. Heat is generated only while A and B




FIGURE 14.33 Representative thermometric titration plot. The endpoint is denoted by an abrupt change in the slope of the curve. The thermometric titration plot for HCl (a strong acid) with NaOH would look virtually identical to the thermometric titration plot for boric acid (a very weak acid) with NaOH because the ΔH of reaction is almost the same for both acids.

react with each other; an excess of either one does not cause generation of heat. The reaction is usually set up in an insulated beaker, a Dewar flask, or a Christiansen adiabatic cell. This ensures a minimum of heat loss from the system during titration.

In practice, the temperature of the system is measured as the titrant is added to the sample. A thermometric titration plot generally has ΔT on the y-axis and volume of titrant on the x-axis. A typical plot for an exothermic reaction is shown in Figure 14.33. We will assume that the sample solution and the titrant are initially at room temperature. As titrant is added and the exothermic reaction occurs, the temperature of the solution increases. It can be seen that the temperature of the mixture increases until approximately 4.5 mL of titrant have been added to the sample. This is the equivalence point of the titration. Further addition of titrant causes no further reaction, because the entire sample A has been consumed. The temperature of the mixture steadily decreases as the cooler titrant is added to the warm mixture. The endpoint can therefore be determined as the abrupt change in slope that occurs at the equivalence point. In these circumstances, it is not necessary to add exactly the stoichiometric amount of titrant. Any excess added does not result in an increase in temperature, and is therefore not a source of error as it is in conventional volumetric analysis.

For simple titrations, the equipment necessary is not particularly sophisticated; a thermometer, a burette, and an insulated beaker (or even two Styrofoam cups, one sitting in the other) will do. However, to measure specific heats or the heat of reaction, better control is required. Modern automated thermometric titrators consist of a constant delivery pump for the titrant, a temperature control system for the titrant, an insulated cell, calibration circuitry, electronic temperature sensing, and a data processing system. Most modern instruments are totally computerized, so different methods can be programmed and run unattended.

The titrant is delivered with a motorized syringe pump. This permits the volume of titrant to be calculated from the rate of delivery. These pumps are able to deliver rates of flow down to microliters per minute with high precision. The temperature control system, usually a

thermostatted bath for the titrant and a heater for the sample cell, is used to bring the titrant and the sample to exactly the same temperature. This is required for high precision measurements of heat capacity and enthalpy. Modern thermostats can maintain the temperature to within $0.001\,^{\circ}\text{C}$.

For precise measurements of reaction parameters such as rate constants, equilibrium constants, and enthalpies, a well-designed insulated titration cell is required. The cell should have minimum heat loss to the surroundings. It should have as small a mass as possible to minimize the contribution of the cell to the total heat capacity and to maximize the response of the system to temperature changes. The calibration circuitry is used to determine the heat capacity of the system, which must be known if accurate heats of reaction are to be measured. Thermistors, which are temperature-sensitive semiconductors, are used as the temperature sensors in these systems due to their small size, fast response, and sensitivity.

A major use of thermometric titrimetry is for the titration of very weak acids or bases. The pH for the titration of a weak acid with a strong base (or vice versa) is easily calculated and such calculations can be found in standard analytical chemistry texts. Strong acids such as HCl, when titrated with strong base, give a large change in pH as the equivalence point is reached; therefore, the quantitative determination of a strong acid using a potentiometric titration with a glass pH electrode is very simple. As the acid becomes weaker, the change in pH near the equivalence point decreases until the equivalence point becomes too shallow to detect by potentiometric titration. For example, the weak acid boric acid, with p K_1 = 9.24 and p K_2 = 12.7, does not give a good endpoint in a potentiometric titration with NaOH because the inflection is too small. However, in a thermometric titration with NaOH, boric acid gives a sharply defined endpoint, and is easily determined, because the ΔH for the boric acid neutralization is large. It is very similar in magnitude to that for neutralization of HCl by NaOH. Thermometric titrations can be used for quantitative analysis using neutralization reactions, oxidation-reduction reactions, and complexation reactions, as well as to determine heats of mixing and to determine equilibrium constants.

In thermometric titration, it is assumed that the rate of reaction is relatively fast and that the endpoint will occur as soon as a small excess of titrant is added. This assumption is not valid if the reaction is slow. The position of the endpoint will be distorted and the results will be inaccurate.

14.6 DIRECT INJECTION ENTHALPIMETRY

When a chemical reaction occurs at constant pressure, heat is liberated or absorbed. The heat flow into or out of a system at constant pressure is quantified using a quantity called enthalpy, H. We usually measure the change in enthalpy, ΔH , called the enthalpy of reaction. It is a reproducible physical property for a given reaction $A + B \rightarrow C + \Delta H$. Therefore, the magnitude of ΔH depends on the quantity of reactants involved in the reactions (e.g., multiplying all of the reaction coefficients by 2 means we have to multiply ΔH by 2). Excess amounts of any of the reactants do not take part in the generation or absorption of heat.

Direct injection enthalpimetry (DIE) is similar in many respects to thermometric titrimetry. One essential difference is that an excess of titrant is added very rapidly to the sample and the reactants mixed vigorously. The temperature is then measured against time following the injection of the titrant, as shown in Figure 14.34. We may suppose that the following exothermic reaction takes place:

$$A(analyte) + B(titrant) \rightarrow C(products) + heat$$

The quantity of heat generated is a function of the number of moles that take part in the reaction. This, in turn, is controlled by the amounts of A and B. Any excess of either A or B does not react. In this instance, we have added an excess of B; therefore, the amount of heat generated must be a function of the amount of A present in the mixture. If the amount of A present were halved, then the amount of heat generated would be halved. Since there is an excess of B present in both cases, only the amount of A affects the amount of heat generated.




FIGURE 14.34 DIE titration plot. An excess of reactant B is added rapidly. The amount of analyte a is calculated from the final temperature.

The method is quite useful, particularly if the rate of chemical reaction between A and B is slow. The final quantity of heat evolved is not a function of time, but a function of the concentration of sample. This is a distinct advantage over conventional volumetric analysis and, in some instances, thermometric titrations, as slow reactions give rise to errors in the endpoint determination in thermometric titrations.

The equipment used for DIE is identical to that for thermometric titrimetry. The titrant must be at the same temperature as the sample at the start of the experiment, and the syringe is emptied rapidly into the cell to deliver the titrant "instantaneously".

DIE may be used for the same applications as discussed for thermometric titrations. DIE can also be used in biological studies where the reaction rates may be slow. For example, proteins have been titrated with acid or base, antibodies have been titrated with antigen, and enzyme-coenzyme systems have been studied. DIE is used to determine kinetic parameters for slow reactions. The use of a large excess of one reactant (the titrant) favors the forward reaction (according to Le Chatelier's principle) even if the equilibrium constant is small, so equilibria may be studied using DIE that cannot be studied using other titrimetric methods.

A word of caution should be mentioned about possible interferences, particularly if two simultaneous reactions take place. Since both reactions may generate heat, a direct error will be involved with injection enthalpimetry methods. However, with thermometric titrations, frequently reactions take place consecutively and can be determined consecutively without prior separation. This has been demonstrated in the titration of calcium and magnesium with oxalate.

14.7 MICROCALORIMETRY

Calorimetry is the science of measuring heat changes from chemical reactions and physical events. DSC has been a staple method of analysis for materials scientists. Classical DSC instruments and classical calorimetric titrimetry instruments often lack the sensitivity required for the study of biological samples, where processes like the folding or unfolding of a protein may exchange only microjoules of heat. A new class of ultrasensitive microcalorimetry instrumentation has been developed primarily for studies in the life sciences, where sample amounts may be extremely limited.

Ultrasensitive calorimetry now plays an integral role in biotechnology, providing researchers with essential information on the thermodynamics, structure, stability, and functionality of proteins, nucleic acids, lipids, and other biomolecules. Ultra-sensitive calorimetry is a vital tool for R&D in pharmaceuticals, genetics, energy, materials—in almost any area where the measurement and controlled manipulation of substances and interactions is required at the molecular level.

Ultrasensitive calorimeters enable researchers and product developers to gain thermodynamic information that was previously impossible to gain with earlier models or by other techniques. The capabilities of advanced, ultra-sensitive calorimeters are enormously helpful because of the amount and accuracy of the data they extract, as well as their abilities to obtain data using very small samples.

Microcalorimetry is used to study reactions involving biomolecules, interactions between molecules like ligand-binding and physical changes such as protein unfolding. The advantage to using microcalorimetry for these types of studies is that assay development is relatively simple compared to other bioanalytical approaches. No radiolabeling or derivatization of compounds is required and since it is not an optical technique, samples without chromophores, turbid solutions, and suspensions are easily studied. Microcalorimetry instrumentation is available for micro- or nano-scale DSC, isothermal titration calorimetry (ITC), and isothermal calorimetry.

DSC measures heat as a function of changing temperature. It is typically used to discern a wide range of thermal transitions in biological systems and the thermodynamic parameters associated with these changes. ITC is typically used for monitoring a chemical reaction initiated by the addition of a binding component, and has become the method of choice for characterizing biomolecular interactions.

Instruments are available from several manufacturers, including TA Instruments and GE Healthcare Life Sciences. Some companies use "micro" in their instrument names; some use "nano" and some use the Greek letter μ in their names. For the sake of simplicity, the term "micro" will be used unless a specific instrument is discussed by name.

14.7.1 MICRO-DSC INSTRUMENTATION

DSCs designed for the measurement of extremely small amounts of samples must be sensitive and designed to accurately and precisely control the temperature of the sample. Sensitivity is a byproduct of sample size, signal-to-noise, and baseline stability. Today's calorimeters incorporate new control capabilities that produce baseline stability that previously has not been available. This control also makes the instrument less susceptible to external environmental influences, and with the pressure control capabilities built into the newer models the instruments are now appropriate for the study of volumetric properties (pressure perturbation) of biopolymers.

The Nano-DSC (TA Instruments) is a power compensation DSC with a dual capillary cell design. The capillary cells (sample and reference) confer some advantage in studying proteins (discussed in Sec. 14.7.2), with internal surfaces that can be completely and rapidly flushed with cleaning solutions. It uses the same solid-state thermoelectric elements for heating and cooling the sample; this results in equal sensitivity for upward and downward temperature scans. Pressure control is maintained by a built-in high-pressure piston driven by a computer-controlled linear actuator. Constant pressure is applied during the DSC experiment to obtain the constant pressure heat capacity of the sample and to prevent boiling or bubble formation. The pressure can be varied up to 6 atm during "pressure perturbation" experiments to obtain compressibility and thermal expansion data. The operating temperature range is from –10 °C to 130 °C or 160 °C. The DSC scan rate is from 0.0001-2 °C /min with a response time of 5 sec. The sample cell volume is 300 μL with cells made of Pt or Au.

The MicroCal VP-Capillary DSC system from GE Healthcare Life Sciences (hereafter referred to as GE) uses a nonreactive material called Tantalum 61 for its matched capillary cells, which have an "active" cell volume of 130 μ L. It has a fully automated autosampler that permits unattended analysis of 50 samples/day.

14.7.2 APPLICATIONS OF MICRO DSC

Minute alterations in the structure, stability and affinity of proteins and other biological macromolecules can dramatically alter the function of the protein or biopolymer. Biopolymers can be free in solution proteins, nucleic acids), associated with another molecule (as in a DNA/drug complex) or part of an assembly of molecules, like lipids in a membrane. Micro-DSC is the most direct and sensitive approach for characterizing the thermodynamic parameters controlling noncovalent bond formation (and therefore stability) in proteins, other macromolecules and even whole cells. Proteins and other biomolecules in solution are in equilibrium between the normal "folded" state (see Figure 14.35) and the denatured "unfolded" state, with the folded structure being thermodynamically more stable by only about 20-30 kcal/mol for a medium-sized protein, or the equivalent of 5-8 hydrogen bonds. Many factors are responsible for the stability of proteins, including hydrogen bonds to the solvent and intramolecular interactions. Some proteins denature on heating; others, on




FIGURE 14.35 (a) A schematic DSC scan, showing how T_m , ΔH and ΔC_p are obtained. (b) A temperature scan, converted to partial molar heat capacity for 1 mg/mL⁻¹ hen egg white lysozyme (shown in the upper right corner) in 0.2 M glycine buffer, pH 2.7. Data obtained at a scan rate of 1 °C/min in a nano DSC. (Courtesy of TA instruments, New Castle, DE. www.tainstruments. com.)

cooling. Correlation of thermodynamic properties with stability is needed for, among other uses, the rational design of protein-based therapeutics and small molecule protein-specific drugs, and for assessing the long-term stability of biotherapeutic formulations. DSC studies to determine the intrinsic stability of proteins in dilute solution require dilute buffer solutions with concentrations of 0.2 mg-2 mg protein mL⁻¹ needed. In a single thermal unfolding experiment, DSC can measure and permit calculation of all the thermodynamic parameters characterizing a biological molecule: the enthalpy due to thermal denaturation, ΔH ; T_m , the transition midpoint, where half of the macromolecules are folded and half are unfolded; the change in heat capacity, ΔC_p . The type of information available from a DSC experiment is shown in Figure 14.34.

Figure 14.36(a and b) shows stability assessments of proteins. The stability is analyzed in dilute buffer solution by determining the changes in the partial molar heat capacity at constant pressure, ΔC_p . The contribution of the protein to the calorimetrically measured heat capacity is determined by subtracting a scan of a buffer blank from the sample data. As can




FIGURE 14.36 (a) Three overlaid baseline temperature scans and three overlaid scans of 60 mg barnase in 0.3 mL 20 mM phosphate buffer, pH 5.5. (Courtesy of TA instruments, New Castle, DE. www.tainstruments.com.) (b) Stability assessment of two biomolecules using the MicroCal VP-DSC. (©2020 General electric company doing business as GE Healthcare [www.gelifesciences.com/microcal].)




FIGURE 14.37 A temperature scan, converted to molar heat capacity, for hen egg white lysozyme solution in 0.2 M glycine buffer, pH 4.0. Lysozyme concentrations ranged from 400 μ g to 2 μ g in the 300 μ L sample cell of the nano DSC. Curves are offset to see them clearly. (Courtesy of TA instruments, New Castle, DE. www.tainstruments.com.)

be seen in Figure 14.36(a), heating the protein solution initially produces a slightly increasing baseline but as heating progresses, heat is absorbed by the protein and causes it to unfold over a characteristic temperature range for that protein. This gives rise to an endothermic peak. The midpoint T of the peak is denoted as the thermal transition midpoint (T_m) ; at this point, half the macromolecules are folded and half are unfolded. Once unfolding is completed, heat absorption decreases and a new baseline is established. Figure 14.36(b) shows two biomolecules in solution. The higher the thermal transition midpoint, the more stable the molecule. The solid line shows the raw data while the dotted line is the result of statistical processing of the data. The experiment provides the ΔH for each transition as well as the partial molar heat capacity of the molecule at constant pressure, ΔC_n , and T_m .

In a DSC experiment lasting about 1 hour, using as little as 2 μ g of material, a protein can be thermally unfolded, allowing the enthalpy and entropy of the denaturation process to be measured, as seen in Figure 14.37. The thermodynamic data collected are presented in Table 14.5. As can be seen in this table, the thermodynamic data obtained was accurate even for the 2-microgram sample.

TABLE 14.5 Thermodynamic Data Collected from the Scans in Figure 15.35

	Calorimetric		Van't Hoff	
Lysozyme in Cell (μg)	ΔH (kJ mol ⁻¹)	ΔS (kJ K ⁻¹ mol ⁻¹)	T _m (°C)	ΔH (kJ mol ⁻¹)
400	512	1.46	78.0	515
100	512	1.46	78.0	509
50	517	1.47	77.9	513
25	513	1.46	77.8	513
10	515	1.47	78.0	515
5	490	1.40	78.0	510
2	503	1.43	77.8	499

Source: Courtesy of TA Instruments, New Castle, DE. www.tainstruments.com.




FIGURE 14.38 Simulated DSC data showing the higher temperature stability of a tightly-associated protein/ligand complex (PL) compared with the free protein (P) and ligand (L). (Courtesy of TA instruments, New Castle, DE. www.tainstruments.com.)

Proteins are large flexible molecules capable of recognizing and binding specific molecules such as other proteins and drugs. A ligand will bind to a protein only if the resulting complex is more stable than the original protein. Ligands can bind to native folded proteins, stabilizing the folded state or they can bind to the denatured unfolded protein, destabilizing the folded state. Binding triggers conformational transitions and these can be measured by DSC. If a ligand binds preferentially to the native state of the protein, the temperature at which the ligand-protein complex denatures will be higher than the temperature at which the free protein unfolds. If the ligand (L) binds tightly to the native conformation of a protein (P), the resulting complex PL will have a higher thermal stability (higher $T_{\rm m}$) than either of the free components (Jelesarov and Bosshard). Figure 14.38 shows an idealized example of this behavior.

14.7.3 ISOTHERMAL TITRATION CALORIMETRY

Isothermal titration calorimetry (ITC) is a small-scale, small sample size, high-sensitivity version of the thermal titrimetry already discussed. The instrumentation consists of a highly sensitive calorimeter, capable of detecting heat effects as small as 100 nanojoules on one nanomole or less of a biopolymer. Temperature stability is critical; the TA Instruments Nano ITC provides temperature stability of 0.0002 °C at 25 °C, for example. Sample cells are made of Hastelloy or gold with a sample volume of 1-2 mL required, depending on the manufacturer. The titrant is delivered with a precision 300 μL volume syringe with a mechanical stirrer at the end. Various mixing speeds can be selected depending on the physical nature of the sample. Response time is 12-20 seconds, again depending on the manufacturer. Sample throughput is estimated by GE Healthcare to be 4-8 samples per 8 hr day for its MicroCal VP-ITC system.

ITC is a universally-applicable technique for determining the thermal effects arising from molecular interactions. It is a powerful approach for quantifying the molecular interactions between two or more proteins, macromolecules, or between macromolecules such as protein and nucleic acids with small molecule ligands such as drugs and enzyme inhibitors. Life science applications of ITC can be broadly characterized as either binding interactions or enzyme-substrate interactions. The most frequent use of ITC is in the study of binding interactions. In a single titration experiment, through the heat released or absorbed, ITC can measure binding affinity, stoichiometry, enthalpy, and entropy for nanomolar amounts of sample. Millimolar to picomolar binding constants can be measured. Common binding studies include protein-ligand binding, protein-protein interactions, biopolymer-drug binding, and lipid vesicle and liposome interactions.

To determine the affinity with which a protein binds a small ligand, such as a drug candidate molecule, a solution of the protein (1 mL of an approximately 10 μ M solution) is loaded into the calorimeter sample cell and the ligand solution (approximately 100 μ L) is loaded into the injector syringe connected to the sample cell. The ligand is titrated incrementally into the protein solution [Figure 14.39(a)]. Heat is generated and registered as a deflection peak by the instrument. The peaks are integrated over the time of the experiment and plotted as area/ μ J versus mole ratio of titrant to titrate [Figure 14.39(b)]. ITC can characterize the kinetics of essentially any enzymatic reaction or any catalytic reaction. Both kinetic and thermodynamic data are generated. A typical fully automated ITC experiment takes about one hour and allows determination of the association constant, binding enthalpy, stoichiometry, and reaction rate.

ITC is the most popular type of ultra-sensitive calorimetry today. In the pharmaceuticals area, this technique is used in the testing of drugs aimed at a very specific target in the human body, possibly a particular gene or receptor. Various biomolecular interactions can be studied using ITC, such as protein-ligand, protein-protein, protein-DNA, and antibody-antigen.

While ITC is particularly suitable to follow the energetics of an association reaction between biomolecules, the combination of ITC and DSC provides a more comprehensive description of the thermodynamics of an associating system. Instrumentation diagrams, videos, and applications for ITC and microcalorimetry may be found atwww.tainstruments.com andwww.gelifesciences.com.




FIGURE 14.39 (a) Simulated raw incremental titration data for an ITC experiment. Each peak corresponds to the heat produced upon injection of a fixed amount of titrant at specific time intervals. (b) Simulated binding analysis. Area under each peak in (a) is integrated and fit to a binding model to permit calculation of affinity, enthalpy and stoichiometry for the interaction. (Courtesy of TA instruments, New Castle, DE. www.tainstruments.com.)

14.7.4 MICROLITER FLOW CALORIMETRY

Microcalorimeters, as discussed above, are well-established instruments for protein chemistry. They typically require several hundred microliters of sample and up to one hour for a measurement. Today's biotech industries use enzymes in biofuels, textiles, detergent, and food manufacturing. The design and selection of cost effective, high-specificity enzymes require high-throughput, low-volume screening methods. TTP Labtech Ltd. (Melbourn, UK, www.ttplabtech.com) has developed a flow microliter calorimeter (FMC), called the chip-CAL, for enzyme studies, that requires only 15 μL of sample and 8 minutes of analysis time. Using two syringe pumps, 15 μL each of enzyme and substrate are passed through a flow cell simultaneously. The heat evolved or absorbed is detected by a thermopile chip. The system is suitable for real time monitoring of enzyme activity, substrate profiling to determine specificity, monitoring the metabolic activity of cell cultures and similar processes in the biopharmaceutical, food, and fermentation industries. Enzyme kinetic parameters can be determined from a single run. The flow microcalorimeter offers a universal, label-free approach to enzyme assays with minimal sample volumes. Schematics of the system and application notes can be found on the website at www.ttplabtech.com.

A NOTE ABOUT REFERENCE MATERIALS

In several places throughout this book, we have discussed the standardization or calibration of instrumentation by use of standards available from the National Institute of Standards and Technology (NIST). While many analytical instruments are dependent on calibration, thermal analysis methods are especially prone to bias and systematic uncertainty due to poor calibration or worse, no calibration. Every industrialized country maintains a national measurement laboratory (NML), and in the United States, NIST satisfies this requirement by statute (in fact, the duties of NIST are specifically called out in the U.S. constitution). Several different kinds of materials are available from NIST.

Reference Materials (RM): A reference material is a material sufficiently homogeneous and stable with respect to one or more specified properties established to be fit for its intended use in a measurement process. The term RM is generic and not fixed by statute. A RM can be used for calibration, identification, procedure assessment or quality control. A RM generally cannot be used for both validation and calibration in the same instrument or procedure.

Certified Reference Material (CRM): A CRM is a reference material characterized by a metrologically valid procedure for one or more specified properties. It is provided with a certificate listing the value of the specified property, its associated uncertainty (which may be expressed as an expanded uncertainty or a probability statement), and a statement of traceability. The certificate lists the numerical value of the property (e.g., enthalpy, density, etc.) and the traceability.

Standard Reference Material: A SRM is a CRM that meets additional certification criteria that might differ material to material. These criteria are determined by NIST, and may include the requirement of two separate, orthogonal measurement methods for the property, the value for which is listed on the accompanying certificate. An SRM is prepared and used for three main purposes: (1) to help develop accurate methods of analysis; (2) to calibrate measurement systems used to facilitate exchange of goods, institute quality control, determine performance characteristics, or measure a property at the state-of-the-art limit; and (3) to ensure the long-term adequacy and integrity of measurement quality assurance programs. The term "Standard Reference Material" is fixed by statute and is a registered trade mark.

For more details, the student is referred to the NIST Standard Reference Materials Catalog, available as a pdf:https://nvlpubs.nist.gov/nistpubs/SpecialPublications/NIST.SP.260-176-2018.pdf (accessed October, 2020).


It is of interest to note that a NIST supplied material may very well not be the highest purity material available; it is simply a material that is provided from a consistent and large enough batch to ensure the long-term integrity of the measurement process. For example, NIST provides a SRM sample of toluene for the calibration of density measurement instruments. The toluene that is provided may have a small quantity of known and characterized impurities, however the density has been measured precisely with the best metrology available. That density value is listed on the certificate. Additional details on this topic can be found in the book by Bruno and Svoronos.

SUGGESTED EXPERIMENTS


- 14.1 Using a TGA instrument determine the TGA thermal curve for copper sulfate pentahydrate. A sample size of approximately 10 mg should be heated in nitrogen from room temperature until at least 300 °C. Explain the thermal plot in terms of loss of the water of hydration.
- 14.2 Repeat experiment 14.1 using KCl. Note the initial loss of free (adsorbed) water and then the loss of bound interstitial water up to temperatures above 200 °C. Could temperatures below 200 °C be used to dry KCl crystals successfully?
- 14.3 Using a solution of AlCl₃ (in acid), neutralize and precipitate the Al as Al(OH)₃ by the addition of NH₄OH. Filter the precipitate. Obtain the TGA thermal curve of the precipitate. Heat the precipitate until no change in mass occurs (to at least 1000 °C). Could this precipitate be dried to a constant weight at any temperature below 1000 °C?
- 14.4 Take a fresh piece of ham (about 10 mg for an analytical TGA). Obtain the TGA thermal plot in air up to 150 °C. Note the loss in weight due to (a) water evaporation. Do any other losses occur? What is being lost, do you think? Run six additional samples of the same ham. Evaluate the accuracy and precision of the water loss measurement and explain your observations. Many commercial hams (and other meats) contain added water or broth. State regulations may specify how "water-added" products are labeled. Would there be an advantage to a high-capacity TGA if you had to determine if the amount of water in hams met the labeling regulations on a routine basis?
- 14.5 Obtain the TGA curve of butanol. Heat slowly. Note the slow evaporation of the butanol throughout and then the rapid loss at the boiling point.
- 14.6 Using about 10 mg samples of polyvinylchloride (PVC) powder, obtain the TGA thermal curves (to at least 700 °C) in air and in nitrogen. Compare the curves. The first loss in mass was described in the text. What is it due to? Explain any other mass losses and note any differences in the two curves.
- 14.7 Using DTA or DSC equipment, obtain the thermal curve of benzoic acid. In the first instance, heat the acid rapidly; in the second, heat it slowly. Note the difference in the apparent melting and boiling ranges of the benzoic acid when the different heating rates are used. Which rate gives the more accurate data?
- 14.8 Obtain the DTA (or DSC) and TGA curves of benzoic acid. Note that the TGA curve does not indicate the melting point but does indicate the boiling point.
- 14.9 Obtain the DSC curves for samples of commercial butter, margarines, lard, and solid butter substitutes. The temperature range for the DSC should be from -50 °C to 150 °C. Compare the melting behavior and explain your observations. You can also run this experiment with various types of solid chocolate.
- 14.10 Obtain DSC thermal curves of several semicrystalline polymers such as polymethylene, low-density polyethylene and look for the glass transition in these polymers. The DSC run may need to be repeated twice with rapid cooling between runs. Many "as received" polymers will show a small peak on top of the glass transition on the first run due to "relaxation effects" in the polymer. The second run should not show this "peak", but only a step change in the baseline. Compare your values of $T_{\rm g}$ to literature values. Deviations may indicate the presence of plasticizers or other additives in the polymer.

PROBLEMS


- 14.1 Describe the major components of a TGA instrument. Draw a schematic for a simple TGA instrument. What is measured by the TGA experiment?
- 14.2 A sample of mixed calcium oxalate monohydrate and anhydrous silica weighed 7.020 mg. After heating to 600 °C, the weight of the mixture was 6.560 mg. What was the weight of calcium oxalate in the original sample?
- 14.3 What information can be obtained by DTA that cannot be obtained by TGA?
- 14.4 Describe the components of a DTA instrument and discuss the differences between a DTA and a TGA instrument.
- 14.5 What are the advantages of using a combination of DTA and TGA to characterize a sample?
- 14.6 Describe the components of a DSC instrument. Draw a schematic of a heat-flux DSC. What is measured in DSC?
- 14.7 Make a list of the types of changes that can give exothermic peaks in DSC and DTA. Make a list of the types of changes that can give endothermic peaks in DSC and DTA.
- 14.8 What applications can you find for DSC that cannot be performed by TGA?
- 14.9 Why are Pt and quartz commonly used for sample holders in thermal analysis?
- 14.10 The following figure shows the TGA thermal curves of a glass-fiber filled polymer (solid line) and the nonfilled polymer (dotted line). (a) If the original sample weight for the glass-fiber filled polymer was 23.6 mg, what is the weight % glass fiber in the sample? (b) What would you recommend as the upper temperature limit for the use of this material, assuming you want to build in a safety factor of 20 % (i.e., you want to be no higher than 80 % of the decomposition temperature)?




14.11 The following figure shows the TGA thermal curves for copper sulfate pentahydrate, $CuSO_4 \cdot 5H_2O$. The solid line is the TGA of the crystalline salt. (a) Assuming that all of the losses are due to water, how many different types of water are present? (b) How many moles of water are lost in each step? (c) Does the total mass loss confirm that this is $CuSO_4 \cdot 5H_2O$? The dotted line is the TGA of the crystalline salt that has been stored in a desiccator with magnesium perchlorate as the desiccant. (d) Comment on the differences observed between the two thermal curves. (e) How much water has the desiccant removed from the compound?




14.12 Shown in the following figure are the TGA (solid line) and the DTG (dotted line) thermal curves for a sample of hydrated citric acid, $C_6H_8O_7 \cdot nH_2O$. The formula for anhydrous citric acid is $C_6H_8O_7$. The mass of the sample used is 20.09 mg. (a) Assuming the first mass loss is the loss of water, how many moles of water of hydration are present? (What is the value of n in the formula $C_6H_8O_7 \cdot nH_2O$?) (b) What decomposition temperature would you report for anhydrous citric acid? (c) What drying temperature would you recommend for producing anhydrous citric acid from the hydrated form? Which thermal curve is more useful for assigning the temperatures in (b) and (c)?



14.13 The DTA thermal curves for two polyolefins are shown in the following figure. Curve 1 is a sample of low-density polyethylene. Curve 2 is a sample of stabilized polypropylene. The melting points, T_m , are shown. (a) What are the melting points for each polymer? (b) Which polymer would be better to use for hot water pipes in houses? Why? (c) What process is occurring at the high temperature end of each thermal curve?



14.14 The DSC thermal curve of a sample of "light" margarine is shown. (*Note*: This plot has the endothermic peaks pointing up!) (A) What process and what substance do you think gives rise to the endothermic peak at 4.60 °C? (Think about what might be added to margarine to reduce the calories.) (B) Is the endothermic peak at –24.6 °C due to the melting of the oil used to make the margarine? Explain your answer.



(*Note*: The figures for Problems 14.10, 14.11, 14.12, and 14.14 are courtesy of PerkinElmer, Inc, Shelton, CT. The figure for Problem 14.13 is courtesy of Mettler-Toledo GmbH, Switzerland.)

- 14.15 Describe the advantages of microcalorimetry for biological and pharmaceutical applications.
- 14.16 What analyses can be performed by isothermal titration calorimetry?

BIBLIOGRAPHY

Brown, M.E. Introduction to Thermal Analysis: Techniques and Applications; Chapman and Hall: New York, 1988.

Bruno, T.; Svoronos, P. *CRC Handbook of Basic Tables for Chemical Analysis*, Fourth Edition; CRC Press: Boca Raton, FL, 2020.

Callister, W.D. *Materials Science and Engineering: An Introduction*, 5th; John Wiley and Sons: New York, 2000.

Connolly, M.; Tobias, B. Am. Lab. 1992, 1, 38.

Craig, D.Q.M.; Reading, M.; Eds. *Thermal Analysis of Pharmaceuticals*; CRC Press, Taylor & Francis Group: Boca Raton, FL, 2007.

Duval, C. Inorganic Thermogravimetric Analysis, 2nd ed.; American Elsevier: New York, 1963.

Earnest, C. Modern thermogravimetry. Anal. Chem. 1984, November, 1471A.

Gallagher, P.K. Thermoanalytical methods. In *Materials Science and Technology, A Comprehensive Treatment, Part 1*; Cahn, R.W.; Haasen, P.; Kramer, E.J., Eds.; VCH: Weinheim, 1992, Vol. 2A.

Groves, I.; Lever, T.; Hawkins, N. TA Instruments Applications Brief TA-123; TA Instruments, Ltd: UK.

Jelesarov, I.; Bosshard, H.R. ITC and DSC as complementary tools to investigate the energetics of biomolecular recognition, J. Mol. Recognit. 1999, 12, 3.

Kraftmakher, Y. Modulation Calorimetry-Theory and Applications; Springer: New York, 2004.

Menard, K.P.; Spragg, R.; Johnson, G.; Sellman, C. Hyphenation: the next step in thermal analysis, *Am. Lab.* 2010, *1*, 42.

Mohomed, K.; Bohnsack, D.A. Differential scanning calorimetry as an analytical tool in plastics failure analysis. *Am. Lab.* 2013, *3*, 45.

Olivon, M.R. et al. Phase transitions and polymorphism of cocoa butter. JAOCS 1998, 75, 4.

Pazstor, A.J. Thermal analysis techniques. In *Handbook of Instrumental Techniques for Analytical Chemistry*; Settle, F.A. Ed.; Prentice-Hall, Inc.: NJ, 1997.

Sahle-Demessie, E.; Zhao, A.; Salamon, A.W. *PerkinElmer Application Note*, www.perkinelmer.com/nano. PerkinElmer, Inc., Waltham, MA.

Speyer, R.F. Thermal Analysis of Materials; Marcel Dekker, Inc.: New York, 1994.

Turi, E.A., Ed. *Thermal Characterization of Polymeric Materials*, 2nd Ed.; Academic Press: New York, 1996.

Tyrell, H.V.; Beezer, A.E. Thermometric Titrimetry; Chapman and Hall: London, 1968.

Utschick, H. Methods of Thermal Analysis: Applications from Inorganic Chemistry, Organic Chemistry, Polymer Chemistry and Technology; Ecomed Verlagsgesellschaft AG and Co KG: Landsberg, Germany, 1999.

Venturelli, C. Heating microscopy and its applications. *Microscopy Today* 2011, 19, 20.

Washall, J.W.; Wampler, T.P. Direct-pyrolysis fourier transform-infrared spectroscopy for polymer analysis. *Spectroscopy* 1992, 6 (4), 38.

Wendlandt, W.W. *Thermal Methods of Analysis*, 3rd; John Wiley and Sons, Inc: New York, 1986. Wunderlich, B. *Thermal Analysis*; Academic Press: Boston, MA, 1990.



Index

Activation energy, 789

 $\textbf{Note:} \ \textbf{Page numbers in} \ \textit{italics} \ \textbf{indicates figures and} \ \textbf{bold} \ \textbf{indicates tables in the text}.$

A	Active pharmaceutical ingredient (API), 134, 296, 486	quantitative analysis, 339–341 sample analysis, 341–347
AAS, see Atomic absorption spectrometry	Active sites, 612–613, 617, 622, 636, 643,	flame OES, 360–362
Absolute deviation, 35	675–676, 685, 820	infrared (IR) spectroscopy, 201–209
Absolute error, 31, 34	Activity series, 760–761, 761 , 790	qualitative analyses, 202–206
Absolute method, 791	Acylate alcohols, 676	quantitative analyses, 206–209
Absorbance, 47–49, 71, 71–76, 73, 86, 95,	Adjusted retention time, 609, 617	structural determination, 202–206
135–137, 139–141, 143–146, 205	Adsorption step, 728	of luminescence, 153–156
Absorption	AED, see Atomic emission detector	measurement of color, 142-144
air, IR absorption, 191	Aerosol detectors, 698–701	multicomponent determinations, 139-140
atomic, 333	Affinity chromatography, 716, 727,	nuclear magnetic resonance (NMR),
background, 51, 190, 306, 332–338, 333	727–728, 730; see also	275–291
fine structure, 334	Chromatography	2D NMR, 284–287
frequencies in wavenumbers, 170–171	AFS, see Atomic fluorescence spectrometry	¹³ C NMR, 280–284
of IR radiation by molecules, 164–169	Agricultural sampling, 11	molecular structure determination,
measurement, 184–190	Air absorption, 191; see also Absorption	276–280
by molecules, 107	Air-acetylene flame, 320	qualitative analyses, 276-280, 287-288
process, 249	Aliquot, 11, 26, 50–51, 346	quantitative analyses, 288–291
radiant energy, 306	Alizarin garnet R, 153–154, 154–155	sample preparation, 275–276
of radiation by sample, 71, 71	Alkaline error, 768, 780	samples, 275–276
of radiation by two identical sample cells,	Alpha particle X-ray spectrometer (APXS),	of potentiometry, 775–776
72	437, 509–510, 509–510	qualitative structural analysis, 134
solvent, 190–191	Alternating current (AC), 318, 335, 364, 383,	quantitative analysis, 134–139
width of lines, 252–255	551–552, 617, 708, 761, 795, 811	reaction kinetics, 140–141
Absorption band, 70–71, 107, 109–110, <i>110</i> ,	American Association of Official Analytical	spectroelectrochemistry, 142
112, 134, 206	Chemists (AOAC), 9, 12, 25	spectrophotometric titrations, 141–142
Absorption curves, 109–111	American Chemical Society, 112, 275	Analytical column, 641, 697, 722–724; see
Absorption edges, 435–436, 435–437, 448	American Petroleum Institute (API), 134	also Column
Absorption filters, 79–80	American Public Health Association (APHA),	Analytical determinations using Faraday's
Absorption laws, 71–78	9	law, 791–792
Absorption maxima, 109	American Society for Testing and Materials	Analytical method, 9-10, 32, 54-55, 154,
Absorption of radiant energy by atoms,	(ASTM International), 9, 489	338-339, 346, 764-816
303–306	American Society of Brewing Chemists	Analytical SFC, 733; see also Supercritical
Absorption spectra/spectrum, 67, 69–71, 101,	(ASBC), 143, 146	fluid chromatography
<i>102</i> , 104, 109–111, <i>111</i> , 134, 142,	Amino acid, 135, 140, 153, 236, 564, 576, 701,	Analytical spectroscopy, 64, 74, 78-79
163, 189, 191, 201, 303	704, 716–718, 717–718; see also	Analyzed layer, XRF, 477–479, 478, 478–479
Absorption wavelengths, 68, 108 , 109, 142,	Acids	Analyzer, 527
305–306, 318	Amorphous, 63	automated, 8, 345
Absorptivity, 73–74, 108–109, 109 , 209	crystalline material and, 289	mass, see Mass analyzers
AC, see Alternating current	distribution, 236	moisture, 210
Accelerated solvent extraction (ASE), 22, 22 Accepted true value, 29	NMR, 288	multichannel pulse height, see
	polymer, 1, 227, 498, 842, 843, 844, 844	Multichannel pulse height analyzer
Accuracy and precision, 29–30	transitions in materials, 508	on-line, 202
Acids amino, 135, 140, 153, 236, 564, 576, 701,	XRD, 509	portable handheld XRF, 485
	Amount of substance detector, 612; see also	process, 145, 495
704, 716–718, <i>717–718</i>	Detectors	real-time field, 216
concentrated, 15, 20 organic, 676, 719, 781	Amperometric detector, 706	thermogravimetric, 202
oxidizing, 16	Amperometry, 751, 764, 792	Analyzing crystals, 460–461, 462–463,
purity, 16, 339, 395, 416	Amplitude of wave, 61	462–465, 464 , 471, 476, 499
strong, 193	Analysis of solids, 142	Angle of dispersion, 315
weak, 781	Analyst error, 32	Anion exchange (AX), 709
	Analyte, defined, 3	bead, 724
Acid digestion, 15–18, 320, 342, 416	Analytical applications, 134–144	column, 723
Acid dissolution, 15–18, 18 , 342 Acid error, 780	analysis of solids, 142	resins, 721
Acid form, 138 , 720–721, 723–724	atomic absorption spectrometry (AAS),	retention properties, 725
Activated charcoal, 13, 677	338-347	suppressor columns, 724
Activated charcoal, 13, 6//	qualitative analysis, 338	Annual Book of ASTM Standards, 12

Anode, 117, 307, 365, 440–443, 754, 787	Atomic emission detector (AED), 387,	energy levels in, 427–433
Anodic stripping voltammetry, 814, 816	664–665	exciting, 67
Antibonding π^* (pi star) orbital, 106,	Atomic emission in flames, 355	in gas, 63
106–107	Atomic emission spectrometer, 55, 355, 387	motion in, 64
Anti-Stokes direct-line fluorescence, 407	Atomic emission spectroscopy/spectometry,	vibrations of bonded, 70
Anti-Stokes lines, 218–219	353–423, <i>379</i> , 489	ATR, see Attenuated total reflectance
Anti-Stokes scattering, 217–218	atomic fluorescence spectroscopy,	Attenuated light beam, 192
AOAC, see American Association of Official	406-412	Attenuated total reflectance (ATR), 184,
Analytical Chemists	atomic optical emission spectroscopy,	191–193 , 192 , <i>1</i> 92
APCI, see Atmospheric pressure chemical	362–382	Aufbau principle, 68
ionization	flame atomic emission spectroscopy,	Auger electron, 428, 428
APHA, see American Public Health	353–362	spectrometry, 353, 487
Association	glow discharge emission spectrometry,	Automated sample preparation, 2; see also
API, see Active pharmaceutical ingredient;	404–406	Sample/sampling
American Petroleum Institute;	Laser-Induced Breakdown Spectroscopy	Autosamplers, 638, 638–639
Atmospheric pressure ionization	(LIBS), 412–419	Auxiliary electrode, 705–706, 774, 788,
Apparent mobility, 737	literature and resources, 419	801–802, 818
Application buffer, 728	plasma emission spectroscopy, 382–404	Average capacity factor, 619
Applied magnetic fields, 247, 248, 249–250,	Atomic energy levels and symbols, 430	AX, see Anion exchange
252, 254, 257–260, 260, 263, 523;	Atomic fluorescence spectrometry (AFS), 353,	
see also Magnetic field	406–412	В
Approximate quantitation, 658	applications, 411–412	P.14
APXS, see Alpha particle X-ray spectrometer	chemical interference, 410–411	Babington nebulizer, 391–392
Aqua regia, 16, 761	hydride generation, 412	Bacillus anthracis, 415
Arc emission spectroscopy, 376–382	instrumentation, 409–410	Bacillus cereus, 415
Arc/spark/GD emission, 420–421	interferences, 410–411	Bacillus thuringiensis, 415
Area of peak, 276–277	mercury determination, 411	Background absorption, 51, 190, 306, 332–
Argon ICP torch, 385	speciation, 411–412	338, 333; see also Absorption
Argon ionization detector, 663	spectral interference, 411	Background correction
Arkansas Public Health Laboratory, 26	Atomic fluorescence transitions, 408	continuum source, 333–334, <i>334</i>
Array detectors, 93, 562–563, 563; see also	Atomic MS, 580–598; see also Mass	off-line, 360
Detectors	spectrometry	simultaneous, 319
ASBC, see American Society of Brewing	applications of, 583–585, 588–590	single-point, 399
Chemists	inductively coupled plasma mass	Smith-Hieftje, 336–337
ASE, see Accelerated solvent extraction	spectrometry (ICP-MS), 580–583,	spectral interference correction, 374
ASTM, see American Society for Testing and	581 , 582 interferences, 591–597	in transmission measurements,
Materials	collision cells, 594–595	190–191 two-point, 399
Aston, F. W., 519, 570, 586	high-resolution ICP-MS (HR-ICP-MS),	Zeeman, 335–339
Asymmetric stretch, 166–167 Atmospheric pressure chemical ionization	594	Background emission, 50–51, 359, 359–361,
(APCI), 531, 539, 714–715	instrumental approaches to	361, 374, 383–384, 398, 411, 431
Atmospheric pressure ionization (API),	eliminating, 594–597	Background interference, 332, 377, 397
531–535	matrix effect, 591	Background radiation, 359, 393, 440
Atomic absorption spectrometry (AAS), 8,	MS/MS interference removal, 595–597	Background signal, 338, 361, 384, 398, 538,
22, 79, 89, 95, 303–350, 333, 334	reaction cells, 594–595, 595	
absorption of radiant energy by atoms,		
absorption of radiant energy by atoms,	spectral (isobaric) interferences	583, 626, 728 Bands
303-306	spectral (isobaric) interferences,	Bands
303–306 degree of radiant energy absorption.	592–594	Bands absorption, 70–71, 109–110, 134, 164,
degree of radiant energy absorption,	592–594 limitations, 597–598	Bands absorption, 70–71, 109–110, 134, 164, 167, 204
degree of radiant energy absorption, 306	592–594 limitations, 597–598 Atomic number, 433, 434, 491	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619
degree of radiant energy absorption, 306 spectral linewidth, 305–306	592–594 limitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy,	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623,
degree of radiant energy absorption, 306 spectral linewidth, 305–306 analytical applications, 338–347	592–594 limitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy, 362–382	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623, 740
degree of radiant energy absorption, 306 spectral linewidth, 305–306 analytical applications, 338–347 qualitative analysis, 338	592–594 limitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy, 362–382 arc emission spectroscopy, 376–382	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623, 740 emission, 359
degree of radiant energy absorption, 306 spectral linewidth, 305–306 analytical applications, 338–347 qualitative analysis, 338 quantitative analysis, 339–341	592–594 limitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy, 362–382 arc emission spectroscopy, 376–382 instrumentation, 363–376	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623, 740
degree of radiant energy absorption, 306 spectral linewidth, 305–306 analytical applications, 338–347 qualitative analysis, 338	592–594 limitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy, 362–382 arc emission spectroscopy, 376–382 instrumentation, 363–376 spark emission spectroscopy, 376–382	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623, 740 emission, 359 energy, 118
degree of radiant energy absorption, 306 spectral linewidth, 305–306 analytical applications, 338–347 qualitative analysis, 338 quantitative analysis, 339–341 sample analysis, 341–347	592–594 limitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy, 362–382 arc emission spectroscopy, 376–382 instrumentation, 363–376	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623, 740 emission, 359 energy, 118 gap, 114, 118–119, 121, 155, 182
degree of radiant energy absorption, 306 spectral linewidth, 305–306 analytical applications, 338–347 qualitative analysis, 338 quantitative analysis, 339–341 sample analysis, 341–347 atomization process, 319–326	592–594 limitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy, 362–382 arc emission spectroscopy, 376–382 instrumentation, 363–376 spark emission spectroscopy, 376–382 Atomic spectral interference, 332	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623, 740 emission, 359 energy, 118 gap, 114, 118–119, 121, 155, 182 NIR vibrational, 210–212
degree of radiant energy absorption, 306 spectral linewidth, 305–306 analytical applications, 338–347 qualitative analysis, 338 quantitative analysis, 339–341 sample analysis, 341–347 atomization process, 319–326 flame atomization, 319–324	1592–594 limitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy, 362–382 arc emission spectroscopy, 376–382 instrumentation, 363–376 spark emission spectroscopy, 376–382 Atomic spectral interference, 332 Atomic spectroscopy, 19, 67–69, 102 , 490, 816	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623, 740 emission, 359 energy, 118 gap, 114, 118–119, 121, 155, 182 NIR vibrational, 210–212 overtone, 168
degree of radiant energy absorption, 306 spectral linewidth, 305–306 analytical applications, 338–347 qualitative analysis, 338 quantitative analysis, 339–341 sample analysis, 341–347 atomization process, 319–326 flame atomization, 319–324 graphite furnace atomization,	limitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy, 362–382 arc emission spectroscopy, 376–382 instrumentation, 363–376 spark emission spectroscopy, 376–382 Atomic spectral interference, 332 Atomic spectroscopy, 19, 67–69, 102, 490, 816 Atomic theory, 7 Atomic weight, 480, 520, 525 Atomization efficiency, 322, 323, 324	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623, 740 emission, 359 energy, 118 gap, 114, 118–119, 121, 155, 182 NIR vibrational, 210–212 overtone, 168 pure quartz, 12
degree of radiant energy absorption, 306 spectral linewidth, 305–306 analytical applications, 338–347 qualitative analysis, 338 quantitative analysis, 339–341 sample analysis, 341–347 atomization process, 319–326 flame atomization, 319–324 graphite furnace atomization, 324–326	1592–594 limitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy, 362–382 arc emission spectroscopy, 376–382 instrumentation, 363–376 spark emission spectroscopy, 376–382 Atomic spectral interference, 332 Atomic spectroscopy, 19, 67–69, 102, 490, 816 Atomic theory, 7 Atomic weight, 480, 520, 525	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623, 740 emission, 359 energy, 118 gap, 114, 118–119, 121, 155, 182 NIR vibrational, 210–212 overtone, 168 pure quartz, 12 vibrational absorption, 164
degree of radiant energy absorption, 306 spectral linewidth, 305–306 analytical applications, 338–347 qualitative analysis, 338 quantitative analysis, 339–341 sample analysis, 341–347 atomization process, 319–326 flame atomization, 319–324 graphite furnace atomization, 324–326 components, 307	limitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy, 362–382 arc emission spectroscopy, 376–382 instrumentation, 363–376 spark emission spectroscopy, 376–382 Atomic spectral interference, 332 Atomic spectroscopy, 19, 67–69, 102, 490, 816 Atomic theory, 7 Atomic weight, 480, 520, 525 Atomization efficiency, 322, 323, 324	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623, 740 emission, 359 energy, 118 gap, 114, 118–119, 121, 155, 182 NIR vibrational, 210–212 overtone, 168 pure quartz, 12 vibrational absorption, 164 visualizing, 605
degree of radiant energy absorption, 306 spectral linewidth, 305–306 analytical applications, 338–347 qualitative analysis, 338 quantitative analysis, 339–341 sample analysis, 341–347 atomization process, 319–326 flame atomization, 319–324 graphite furnace atomization, 324–326 components, 307 instrumentation, 306–319	1592–594 limitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy, 362–382 arc emission spectroscopy, 376–382 instrumentation, 363–376 spark emission spectroscopy, 376–382 Atomic spectral interference, 332 Atomic spectral interference, 332 Atomic spectroscopy, 19, 67–69, 102, 490, 816 Atomic theory, 7 Atomic weight, 480, 520, 525 Atomization efficiency, 322, 323, 324 Atomization process, 319–326	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623, 740 emission, 359 energy, 118 gap, 114, 118–119, 121, 155, 182 NIR vibrational, 210–212 overtone, 168 pure quartz, 12 vibrational absorption, 164 visualizing, 605 Barrier layer cell, 115–117, 116
degree of radiant energy absorption, 306 spectral linewidth, 305–306 analytical applications, 338–347 qualitative analysis, 338 quantitative analysis, 339–341 sample analysis, 341–347 atomization process, 319–326 flame atomization, 319–324 graphite furnace atomization, 324–326 components, 307 instrumentation, 306–319 atomizers, 310–315 commercial AAS systems, 318–319 detectors, 317	1592–594 Ilimitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy, 362–382 arc emission spectroscopy, 376–382 instrumentation, 363–376 spark emission spectroscopy, 376–382 Atomic spectral interference, 332 Atomic spectroscopy, 19, 67–69, 102, 490, 816 Atomic theory, 7 Atomic weight, 480, 520, 525 Atomization efficiency, 322, 323, 324 Atomization process, 319–326 flame atomization, 316–324	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623, 740 emission, 359 energy, 118 gap, 114, 118–119, 121, 155, 182 NIR vibrational, 210–212 overtone, 168 pure quartz, 12 vibrational absorption, 164 visualizing, 605 Barrier layer cell, 115–117, 116 Baseline, defined, 42
degree of radiant energy absorption, 306 spectral linewidth, 305–306 analytical applications, 338–347 qualitative analysis, 338 quantitative analysis, 339–341 sample analysis, 341–347 atomization process, 319–326 flame atomization, 319–324 graphite furnace atomization, 324–326 components, 307 instrumentation, 306–319 atomizers, 310–315 commercial AAS systems, 318–319	limitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy, 362–382 arc emission spectroscopy, 376–382 instrumentation, 363–376 spark emission spectroscopy, 376–382 Atomic spectral interference, 332 Atomic spectroscopy, 19, 67–69, 102, 490, 816 Atomic theory, 7 Atomic weight, 480, 520, 525 Atomization efficiency, 322, 323, 324 Atomization process, 319–326 flame atomization, 316–324 graphite furnace atomization, 324–326 Atomization signals, 325, 325, 331, 331 Atomizers, 306	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623, 740 emission, 359 energy, 118 gap, 114, 118–119, 121, 155, 182 NIR vibrational, 210–212 overtone, 168 pure quartz, 12 vibrational absorption, 164 visualizing, 605 Barrier layer cell, 115–117, 116 Baseline, defined, 42 Base peak, 523, 567 Beads, 24, 145, 481, 489, 661, 677, 688, 724 Beam optics
degree of radiant energy absorption, 306 spectral linewidth, 305–306 analytical applications, 338–347 qualitative analysis, 338 quantitative analysis, 339–341 sample analysis, 341–347 atomization process, 319–326 flame atomization, 319–324 graphite furnace atomization, 324–326 components, 307 instrumentation, 306–319 atomizers, 310–315 commercial AAS systems, 318–319 detectors, 317	limitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy, 362–382 arc emission spectroscopy, 376–382 instrumentation, 363–376 spark emission spectroscopy, 376–382 Atomic spectral interference, 332 Atomic spectral interference, 332 Atomic steeral interference, 322 Atomic weight, 480, 520, 525 Atomization efficiency, 322, 323, 324 Atomization process, 319–326 flame atomization, 316–324 graphite furnace atomization, 324–326 Atomization signals, 325, 325, 331, 331	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623, 740 emission, 359 energy, 118 gap, 114, 118–119, 121, 155, 182 NIR vibrational, 210–212 overtone, 168 pure quartz, 12 vibrational absorption, 164 visualizing, 605 Barrier layer cell, 115–117, 116 Baseline, defined, 42 Base peak, 523, 567 Beads, 24, 145, 481, 489, 661, 677, 688, 724 Beam optics micro X-ray, 473–475, 474, 475
degree of radiant energy absorption, 306 spectral linewidth, 305–306 analytical applications, 338–347 qualitative analysis, 338 quantitative analysis, 339–341 sample analysis, 341–347 atomization process, 319–326 flame atomization, 319–324 graphite furnace atomization, 324–326 components, 307 instrumentation, 306–319 atomizers, 310–315 commercial AAS systems, 318–319 detectors, 317 modulation, 317–318 radiation sources, 307–310 spectrometer optics, 315–317	limitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy, 362–382 arc emission spectroscopy, 376–382 instrumentation, 363–376 spark emission spectroscopy, 376–382 Atomic spectral interference, 332 Atomic spectroscopy, 19, 67–69, 102, 490, 816 Atomic theory, 7 Atomic weight, 480, 520, 525 Atomization efficiency, 322, 323, 324 Atomization process, 319–326 flame atomization, 316–324 graphite furnace atomization, 324–326 Atomization signals, 325, 325, 331, 331 Atomizers, 306 atomic absorption spectrometry (AAS), 310–315	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623, 740 emission, 359 energy, 118 gap, 114, 118–119, 121, 155, 182 NIR vibrational, 210–212 overtone, 168 pure quartz, 12 vibrational absorption, 164 visualizing, 605 Barrier layer cell, 115–117, 116 Baseline, defined, 42 Base peak, 523, 567 Beads, 24, 145, 481, 489, 661, 677, 688, 724 Beam optics micro X-ray, 473–475, 474, 475 single-beam and double, 89–91, 92
degree of radiant energy absorption, 306 spectral linewidth, 305–306 analytical applications, 338–347 qualitative analysis, 338 quantitative analysis, 339–341 sample analysis, 341–347 atomization process, 319–326 flame atomization, 319–324 graphite furnace atomization, 324–326 components, 307 instrumentation, 306–319 atomizers, 310–315 commercial AAS systems, 318–319 detectors, 317 modulation, 317–318 radiation sources, 307–310 spectrometer optics, 315–317 interferences, 326–338	limitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy, 362–382 arc emission spectroscopy, 376–382 instrumentation, 363–376 spark emission spectroscopy, 376–382 Atomic spectral interference, 332 Atomic spectroscopy, 19, 67–69, 102, 490, 816 Atomic theory, 7 Atomic weight, 480, 520, 525 Atomization efficiency, 322, 323, 324 Atomization efficiency, 319–326 flame atomization, 316–324 graphite furnace atomization, 324–326 Atomization signals, 325, 325, 331, 331 Atomizers, 306 atomic absorption spectrometry (AAS), 310–315 in commercial AAS systems, 305	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623, 740 emission, 359 energy, 118 gap, 114, 118–119, 121, 155, 182 NIR vibrational, 210–212 overtone, 168 pure quartz, 12 vibrational absorption, 164 visualizing, 605 Barrier layer cell, 115–117, 116 Baseline, defined, 42 Base peak, 523, 567 Beads, 24, 145, 481, 489, 661, 677, 688, 724 Beam optics micro X-ray, 473–475, 474, 475 single-beam and double, 89–91, 92 Beam splitter, 90–91, 91–92, 94
degree of radiant energy absorption, 306 spectral linewidth, 305–306 analytical applications, 338–347 qualitative analysis, 338 quantitative analysis, 339–341 sample analysis, 341–347 atomization process, 319–326 flame atomization, 319–324 graphite furnace atomization, 324–326 components, 307 instrumentation, 306–319 atomizers, 310–315 commercial AAS systems, 318–319 detectors, 317 modulation, 317–318 radiation sources, 307–310 spectrometer optics, 315–317 interferences, 326–338 non-spectral interferences, 326–332	limitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy, 362–382 arc emission spectroscopy, 376–382 instrumentation, 363–376 spark emission spectroscopy, 376–382 Atomic spectral interference, 332 Atomic spectral interference, 332 Atomic spectroscopy, 19, 67–69, 102, 490, 816 Atomic theory, 7 Atomic weight, 480, 520, 525 Atomization efficiency, 322, 323, 324 Atomization process, 319–326 flame atomization, 316–324 graphite furnace atomization, 324–326 Atomization signals, 325, 325, 331, 331 Atomizers, 306 atomic absorption spectrometry (AAS), 310–315 in commercial AAS systems, 305 flame, 305, 310–312	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623, 740 emission, 359 energy, 118 gap, 114, 118–119, 121, 155, 182 NIR vibrational, 210–212 overtone, 168 pure quartz, 12 vibrational absorption, 164 visualizing, 605 Barrier layer cell, 115–117, 116 Baseline, defined, 42 Base peak, 523, 567 Beads, 24, 145, 481, 489, 661, 677, 688, 724 Beam optics micro X-ray, 473–475, 474, 475 single-beam and double, 89–91, 92 Beam splitter, 90–91, 91–92, 94 Beer, August, 73
degree of radiant energy absorption, 306 spectral linewidth, 305–306 analytical applications, 338–347 qualitative analysis, 338 quantitative analysis, 339–341 sample analysis, 341–347 atomization process, 319–326 flame atomization, 319–324 graphite furnace atomization, 324–326 components, 307 instrumentation, 306–319 atomizers, 310–315 commercial AAS systems, 318–319 detectors, 317 modulation, 317–318 radiation sources, 307–310 spectrometer optics, 315–317 interferences, 326–338	limitations, 597–598 Atomic number, 433, 434, 491 Atomic optical emission spectroscopy, 362–382 arc emission spectroscopy, 376–382 instrumentation, 363–376 spark emission spectroscopy, 376–382 Atomic spectral interference, 332 Atomic spectroscopy, 19, 67–69, 102, 490, 816 Atomic theory, 7 Atomic weight, 480, 520, 525 Atomization efficiency, 322, 323, 324 Atomization efficiency, 319–326 flame atomization, 316–324 graphite furnace atomization, 324–326 Atomization signals, 325, 325, 331, 331 Atomizers, 306 atomic absorption spectrometry (AAS), 310–315 in commercial AAS systems, 305	Bands absorption, 70–71, 109–110, 134, 164, 167, 204 analyte, 619 broadening, 611–612, 614, 620, 622–623, 740 emission, 359 energy, 118 gap, 114, 118–119, 121, 155, 182 NIR vibrational, 210–212 overtone, 168 pure quartz, 12 vibrational absorption, 164 visualizing, 605 Barrier layer cell, 115–117, 116 Baseline, defined, 42 Base peak, 523, 567 Beads, 24, 145, 481, 489, 661, 677, 688, 724 Beam optics micro X-ray, 473–475, 474, 475 single-beam and double, 89–91, 92 Beam splitter, 90–91, 91–92, 94

Beer's Law, 74–78, 189, 195, 207, 236, 306,	Carbon dioxide, 20, 24, 24, 166, 175, 181, 191,	in more than one dimension, 607–608
312, 339, 361, 491, 494	196, 224, 228, 419, 568, 732, 772	process, 604–607
Beginning development, TLC plates, 743, 744	Carbowax, 642, 643, 649, 669	qualitative chromatography, 623-624
Bell-shaped curve, 33, 36, 609	Carrier gas, 529, 633	quantitative analysis, 624–627
Bending vibrations, 166–167, 167, 169	CAT, see Computed axial tomography	sample input of MS, 528-529
Biodiesel fuel, 205	Cathode, described, 754	separations, 616–619, 621–622
Biologically active compound, 5, 744	Cation exchange (CX), 709, 720-721	silicon-oxygen compounds in, 613-616
Bioluminescence, 147	CCD, see Charge coupled device	visualization of process, 608-612
Biospecific elution, 728	CE, see Capillary electrophoresis;	Chromatography with liquid mobile phases,
Blackbody radiator, 113, 113	Counter-electrode	683–747
Blackbody source, 172	Cell, see specific cells	affinity chromatography, 727, 727–728
Blank emission signal, 361	CEM, 23	capillary zone electrophoresis (CZE),
Blank solution, 9, 139	Cement industry, 490	734–742, 735
Blazed diffraction grating, 86	Centre National d'Études Spatiales (CNES),	electrophoresis, 734–742
Bohr model of the atom, 305	417	high-performance liquid chromatography,
Boiling temperature, 5, 15	Ceramics industry, 490	683–719
Bolometers, 181–182	Certified reference material (CRM), 29, 868	applications of, 716–719
Boltzmann distribution, 250, 305, 357, 407,	CFFAB, see Continuous-flow FAB	column and stationary phases,
542	Chamber, see Thin layer chromatography	<i>684</i> – <i>686</i> , 684–691
Boltzmann excess, 252	Channel electron multiplier (CEM), see	derivatization in, 709–710, 710
Boltzmann ratio, 251	Continuous-dynode EM	design and operation of instrument,
Bonded phase column, 643	Channels, 121, 458, 623	693–697
Bond force constant, 169	Characteristic emission lines, 360, 412, 433,	detector design and operation,
Bradbury-Nielsen (B-N) design ion gate,	442, 448	697–709
565	Characteristic radiation, 431, 442, 477, 478	hyphenated techniques in, 711–715
Bradford assay, 136	Charge coupled device (CCD), 221, 236, 375,	separation of composition of mobile
Bragg equation, 439	375–376	phase, 691–692
Bragg's Law, 463, 471	Charge detector (QD), 708-709, 709	of ions dissolved in liquids, 719-726
Breakthrough, 233, 294, 677	Charge-injection device (CID), 374-375, 375	planar chromatography, 742–747
Bremsstrahlung radiation, 431	Charge transfer detectors, 89	planar electrophoresis, 742-747
Buffer solutions, 180; see also Application	Charge transfer devices (CTD), 374	size exclusion chromatography (SEC),
buffer	"Char" step, 325	728–730, <i>729–730</i>
Bulk analysis, 1, 405–406, 477, 487	Chemical bonds, <i>168</i> , 169	supercritical fluid chromatography,
Buoyancy effect, 840	Chemical exchange, 277	730–733
Burner assembly, 311–312, 321, 355	Chemical imaging, 233-240	Chromophores, 107, 109, 231
Burning velocity, 312	Chemical interference, 324, 326–327, 397	CI, see Chemical ionization
	atomic fluorescence spectroscopy,	CID, see Charge-injection device;
C	410–411	Collision-induced dissociation
	flame atomic emission spectroscopy, 358	CIE, see Commission internationale de
CAD, see Corona charged aerosol detector	Chemical ionization (CI), 530–531	l'eclairage
Calculation errors, 32; see also Errors	Chemical modification, 330–332, 331	Classical analysis, 2, 205
Calculations, chromatography, 627–629,	Chemical reduction, 345	Classical polarography, 802–807
628-629	Chemical shifts, 254–255, 258–263,	Clinical chemistry analysis, 10
Calibration, 42, 45–54, 339–341	261–262 , <i>281</i> , <i>284</i> , <i>288</i>	CNES, see Centre National d'Études Spatiales
curve, 45–47, 361	Chemigram, 233	Coblentz, 163
data, 369	Chemiluminescence, 147, 155, 661	Co-elute, 608, 653, 669, 671
equation, 45	Chemistry and Camera (ChemCam),	Coherent line sources, 79
with external standards, 47–49, 626	417–419, <i>418</i>	Cold vapor-AAS technique (CVAAS), 314,
factors, 791	Chemometrics, 212–213	346, 410–411
internal standard, 51–54, 626–627	Chiral chromatography, 5, 690	Cold vapor mercury technique, 345, 345-346
method of standard additions, 49-51,	Chiral compounds, 5, 690	Collector electrodes, 658
783–784	Chiral GC, 690; see also Gas chromatography	Collector ring, 658
plasma emission spectroscopy, 395–401	Chiral molecules, 5	Collimator masks, 462, 462
standards, 10	Chiral phases for separation of enantiomers,	Collimators, 460–462, 461–462
Calibration Standard Devices (CSDs), 209	689–690	Collision cells, 594–595, 597
Calomel electrode, 753, 762; see also	Chlorinated hydrocarbons, 788	Collision-induced dissociation (CID), 712
Saturated calomel electrode	Chopper, 91, 318	Color comparators, 115
Calorimetric technique, 858	Chromatograms, 634, 650	Colorimetry, 101, 134
Calvet type detector, 848, 849–850	Chromatographic separation, 121, 572, 606,	Color measurement, 142-144
Capacity factor, 616	608, 616–619, 621–622	Column, 696–697
Capillary dimension, 614	Chromatography, 291, 603–631; see also Gas	analytical, 641, 697, 722–724
Capillary electrophoresis (CE), 5, 8, 529, 614,	chromatography	bleeding, 633, 642
726	affinity, 716, 727, 727–728, 730	design GC, 642–647
Capillary zone electrophoresis (CZE), 611,	analyte identification, 623–624	dimensions and elution values, 648–650
734–742	calculations, 627–629, 628–629	radius r_c , 617
apparatus, 735	column variables affecting efficiency,	regeneration, 728
applications, 742	619–621	stationary phase, 404, 642–644, 642–645
detection in, 741	defined, 603	temperature and elution values, 650–654
modes of, 742	extra-column band broadening effects,	variables affecting efficiency, 619–621
sample injection, 739–741	622–623	Column chromatography, 2D, 608

Combination band, 168, 209-210, 212, 227	Cool plasma, 389, 593	D
Combination electrodes, 768, 768	Core-shell column packings, 687	Dark current, 118
Combination instruments, 386	Core-shell particles, 616	Data assessment, 54–56
Combinatorial chemistry, 291	Corona charged aerosol detector (CAD),	DCP, see Direct current plasma
Combustion, 8, 16, 20, 205, 320, 332–333,	698–701	Dead time, 467, 650
342, 356, 358–359, 364, 403, 489,	Corona discharge of electrons, 715	Dead time correction, 471
591, 831 Commission internationale de l'eclairage	Coronation, 418, 418 Corrected signals, 47	Debye-Scherrer photograph, 503
(CIE), 143–144	Correction, 398–401	Decomposition voltage, 789
Composite sample, 11, 13	Correlation coefficient, 46–47	Deformations, 166, 508, 825
Comprehensive 2D chromatograms, 608	COSY experiment, 284–286, 285–287, 295	Degassed solution, 805
Comprehensive 2D-gas chromatography	Coulomb (C), 791	Degree of radiant energy absorption, 306
(GCxGC or GC ²), 669–673,	Coulomb explosion, 712	Degrees of freedom, 36, 40, 46, 167
670-672	Coulometric detector, 706	Demountable Micro-Volume (DMV)-Bio
Comprehensive technique, 672	Coulometric methods, 786	Cell, 123
Computed axial tomography (CAT), 427	Coulometric titrations, 793–794, 794	Denaturation of protein, 746
Computed tomography (CT), 427	Coulometry, 10, 786–794	Depolarizer, 790
Concentrated acids, 15; see also Acids	advantage of, 788	Depth profiling, 395, 406, 407
Concentration, 7–8, 40, 45, 72–77, 202, 624,	analytical determinations using Faraday's	Derivative thermogravimetry (DTG), 837–839, 838–839
721	law, 791–792	Derivatization in HPLC, 709–710, 710; see
of analyte, 10	applied potential, 789–790	also High-performance liquid
defined, 6	constant-current, 786 constant-potential, 786	chromatography
detector, 612 easily ionized element (EIE), 397–398	controlled potential, 780	Desalting, 729
fluorescence and, 148–149, <i>150</i>	electrogravimetry, 760–791, 786	Designing analytical method, 9–10
polarization, 789	industrial applications of, 788	Desorption chemical ionization, 531
relative error, 75	instrumentation for, 788–789	Desorption electrospray ionization (DESI)
relative uncertainty, 76	Counter-electrode (CE), 363, 365, 775, 801	source, 538–539
of species in samples, 104	Counter ion, 719	Desorption ionization, 535–540
Concentric nebulizer, 391	Count rate, 465	Destructive qualitative analysis, 4
Conditioning columns, 646	Coupled chromatography-ICP-MS,	Destructive <i>versus</i> nondestructive,
Conductance, 795	587–588	characteristics of GC detectors, 65
Conduction band, 118	Coupled elemental analysis-MS,	Detection in TLC, 744
Conductivity	590–591	Detection limit (DL), 55, 346, 360, 362 , 366 , 390 , 395, 406, 411–412
detectors, 800–801	Coupling, 168	Detector cell, 612
measurements	Coupling constant, 267	Detectors, 42, 115–122, 152–153; see also
analytical applications of, 798–801	Crack cocaine, 223	Atomic emission detector
instrumentation for, 797–798 Conductometric analysis, 795–801	Critical angle, 191 Cross-flow nebulizer, 392, 392	aerosol, 698–701
Conductometric detectors, 708	Cross-polarization, 284	amperometric, 706
Conductometry, 795	Crouch, S. R., 107, 109, 408, 411	argon ionization, 663
Cone and quarter method of sampling, 11, 11	Cryogrinding, 14	array, 93, 562–563, <i>563</i>
Confidence level (CL), 29, 36	Cryotrapping, 677	artifact escape peaks, 458-459
Confidence limit (CL), 39	Crystal, defined, 63	atomic absorption spectrometry (AAS),
Confirmation column, 624; see also Column	Crystal growing, X-ray diffractometry (XRD),	317
Confocal Raman imaging, 236, 238	499–501	barrier layer cell, 115–117, <i>116</i>
Confocal Raman Imaging, 3D, 235	Crystal lattice, 438, 496	charge transfer, 89
Confocal Raman microscopy, 232, 233, 235	Crystal lattice, 3D, 497	conductometric, 708 coulometric, 706
Connes' advantage, 179	Crystalline solid-state electrodes, 769–770	dead volume, 655
Constant-current coulometry, 786	Crystal structure, 438, 496, 501–503, 502,	energy dispersive X-ray (EDXRF)
Constant proportial aculamentary 796	508, 840	spectrometry, 454–456
Constant-potential coulometry, 786 Consumer Product Safety, 489	CSDs, see Calibration Standard Devices CT, see Computed tomography	flame OES, 356
Consumer Protection and Safety	CTD, see Charge transfer devices	fluorescence, 703–704
Improvement Act 2008 (CPSIA),	Curie temperature, 831	gas-filled, 465–468, 466–467
489	Curiosity (Mars rover), 417	HPLC's design and operation, 697–709
Contamination, 10, 13, 32–33, 48, 127,	Current, defined, 753	infrared absorbance, 703
130, 208–209, 217, 311, 315, 340,	Current response vs. time during DPP pulse,	infrared (IR) spectroscopy, 181–184
342-343, 369, 530, 577, 639, 643,	809	InGaAs, 214, 221–222
816, 831, 856	Curtain gas, 715	instrument component design, 654–665
Continued washing (elution), 604	Cuvettes, 72, 83, 122, 153	line voltage to, 90
Continuous discharge, 365, 367	CVAAS, see Cold vapor-AAS technique	mass spectrometry (MS), 559–563 multichannel, 89
Continuous-dynode EM, 561	CX, see Cation exchange	optical systems, 89
Continuous-flow FAB (CFFAB), 538	Cycle, defined, 61	photoelectric, 95
Continuous wave (CW) instruments, 269	Cyclic voltammetry, 813–814, 814	photomultiplier tube (PMT), 117–118,
Continuum of colors, 61 Continuum sources, 79, 94, 333–334, 334	Cyclodextrins, 689, 689–690 Cylindrical electrostatic-sector energy filter,	117–118
Controlled potential electrolysis, 791	543	photon, 76, 89, 181–183
Convection, 14, 329, 745, 805, 812–813, 825,	CZE, see Capillary zone electrophoresis	polarographic, 707
831, 840	Czerny-Turner spectrometers, 127, 413	pyroelectric, 181–182

radiation intensity, 92	Direct current plasma (DCP), 353	ECD, μ, 660
response time, 183–184	Direct exposure probe, sample input of MS,	Echelle grating, 86, 87
scintillation, 470, 470	528	Echelle monochromators, 86–87, 87,
selective, 624	Direct injection enthalpimetry (DIE),	371–374, 372–373; see also
semiconductor, 118–122, 183, 454–456	860–861, 861	Monochromators
silicon PIN diode, 456, 456–457	Direct insertion nebulizers (DIN), 392	Echelle spectrometers, 316, 413
solid-state imaging, 95	Direct insertion probe, sample input of MS,	EDL, see Electrodeless discharge lamp
thermal, 75, 89, 181	528, 528	Effective hydrodynamic radius, 735
thermionic, 661	Direct measurement of ion concentration, 776	Effluent, 604
time-gated, 413	Direct on-column injection, 646 Discharge electrodes, 660, 663	EGA, see Evolved gas analysis
voltammetry, 705		EGD, see Evolved gas detection
wavelength dispersive X-ray (WDXRF) spectrometry, 465–470	Discharge ionization detectors (DIDs), 663 Discrete-dynode EM, 560, 560	EIE, see Easily ionized element ELCD, see Electrolytic conductivity detector
Determinate errors, 30–33, 36	Dispersion of grating monochromator, 85, 86	ELDS, see Evaporative light scattering
Deuterium arc lamp, 113–114	Dispersive IR, 180	detector
Deviations from Beer's law, 74–75; see also	Dispersive magnetic sector mass analyzer,	Electrical conductivity, 795
Beer's Law	542	Electrical conductor, 753
Dextrorotatory compound, 5	Dispersive monochromator detector (DMD),	Electrical double layer, 763–764
Diamagnetic shielding constant, 258	702	Electrical excitation sources, 364–368
Diamond anvil cell, 186–187	Dispersive optical layouts, 92–93	Electrical glow plug, 658
Diatomic molecules, 165-167, 217	Dispersive power, 83–84	Electrically heated rigid ceramic rods, 173
DIDs, see Discharge ionization detectors	Dispersive Raman Echelle spectrometer	Electric sector, 543
DIE, see Direct injection enthalpimetry	(PerkinElmer), 221	Electric sector instruments, 542–546
Dielectric Barrier Discharge Ionization	Dispersive Raman spectrometer, 221	Electroactive species, 751, 754
Detector (BID), 663	Dispersive spectrometers systems, 221,	Electroanalytical methods, 764–816
Difference band, 168	221–222	conductometric analysis, 795–801
Differentially pumped system, 666	Dispersive spectrophotometer, 176	coulometry, 786–794
Differential mobility spectrometers (DMS),	Displacement of liquid, 8	polarography, 801–812
563–564	Dissolved test portion, 11	potentiometry, 764–786, 765
Differential pulse polarography (DPP), 809,	Distribution ratio, see Equilibrium partition	techniques, 764
809–812, 810, 811 Differential genuing colorimatry (DSC)	ratio, Kx DL, see Detection limit	voltammetry, 812–816 Electrochemical cell, 752, 753–764, 786
Differential scanning calorimetry (DSC), 845–854	DMA-80, 346	Electrochemical detector (ECD), 704–709; see
applications, 851–854	DMD, see Dispersive monochromator	also Detectors
instrumentation, 845–851	detector	Electrochemical methods, 751
Differential thermal analysis (DTA), 840–845,	DME, see Dropping mercury electrode	Electrochemistry, 751–821
841	DMS, see Differential mobility spectrometers	analytical applications of, 751
analytical applications, 843-845	Dopant, 119	analytical calculation, 751
instrumentation, 841–843	Doped, defined, 769–770	described, 751
Differential type of RI detector, 698	Doppler broadening, 306	electroanalytical methods, 764-816
Diffraction gratings, 80–82, 81–82, 86, 115	Double-beam AAS system, 334	electrochemical cell, 753–764
Diffraction of radiation, 498	Double-beam instrumentation, 124	fundamentals of, 751–753
Diffraction of X-rays by crystal planes, 438	Double-beam monochromators, 163	overvoltage encountered in, 790
Diffraction pattern, 496	Double-beam optics, 89–92, 92	redox reactions, 751–753
Diffuse double layer, 736	Double-beam spectrophotometers, 176	spectroelectrochemistry (SEC), 817,
Diffuse reflectance infrared Fourier	Double-beam system, 317	817–821
transform spectroscopy (DRIFTS),	Double resonance, 277–280, 280	techniques, 751
184, 194–195, <i>195</i>	DPP, see Differential pulse polarography	variety of Pt electrodes, 788
Diffusion, 805 Diffusion current, 802	Drift, 90, 90, 258 Drift noise, 44	Electrodeless discharge lamp (EDL), 309, 309–310
Digestion	DRIFTS, see Diffuse reflectance infrared	Electrodeposition, 754
acid, 15–18	Fourier transform spectroscopy	Electrodes
microwave, 16, 17	Drift tube, 563	calomel, 753
Digital pulse processor, see Multichannel	Dropping mercury electrode (DME), 801–807	combination, 768
pulse height analyzer	Dry ashing, 20, 342, 376	glass indicator, 768
DIN, see Direct insertion nebulizers	"Dry" step, 325	glass membrane, 767–769, 768
Diode array, 121–122, <i>121–122</i> , 142	DSC, see Differential scanning calorimetry	immobilized enzyme membrane, 772
Diode array detector (DAD), 702–703	DSC-Raman system, 854	manufacturers, 763
Diodes, 120-121; see also Anode; Cathode	DSC thermogram, 851	membrane, 766-767
Dipole, 642	DTG, see Derivative thermogravimetry	metallic, 766
Dipole moments, 164–166	Dual pistons, HPLC, 695	microscopic carbon-fiber, 772
Dipping reagents, 744	Duane-Hunt Law, 433, 442	normal calomel electrode (NCE), 763
Direct Analysis in Real Time (The DART	Dynodes, 117, 117	potential, 753
source), 533–535, 534		reference, 755, 762–763
Direct coupling, 666	E	saturated calomel electrode (SCE), 762,
Direct current (DC), 318, 335	Facility destinant and a CEO	762–763
arc, 364–365, 364–367, 366	Early eluting peaks, 650	silver/silver chloride, 763
glow discharge (GD) sources, 404–405, 405	Easily ionized element (EIE), 397–398 ECD, see Electrochemical detector; Electron	standard hydrogen electrode (SHE), 753 working electrode (WE), 774
polarography, 802–807	capture detector	Electrogravimetry, 751, 786, 788–791

Electrokinetic injection, 739–740	Energy dispersive X-ray (EDXRF)	External calibration, 47, 47
Electrokinetic pumping, 737	spectrometry, 440, 445-459, 476	External standard in calibration, 626; see also
Electroluminescence, 147	detector artifact escape peaks, 458–459	Calibration
Electrolysis, 786	detectors, 454–456	Extra-column band broadening effects,
Electrolysis cell, 786, 787	excitation source, 446–447, 447	622–623
Electrolyte, 753	multichannel pulse height analyzer, 457,	Extracted ion chromatograms (XIC), 667
Electrolytic cell, 755, 786 Electrolytic conductivity, 795	457–458 primary beam modifiers, 447–449	Extraction, 20–28 QuEChERS, 25–26
Electrolytic conductivity, 793 Electrolytic conductivity detector (ELCD),	sample holders, 450–454	solid phase extraction (SPE), 24–25
660–661	sum peaks, 458–459	solid phase microextraction (SPME),
Electromagnetic radiation, 61–67	with X-ray tube source, 446	26–28, 27–28
interaction with matter, 61, 63–67, 95	Energy levels in atoms, 427–433	solvent, 21–24, 22, 23
units for, 63	Enthalpy, 840, 845	Extra virgin olive oil (EVOO), 135
Electromagnetic spectrum, 62, 63, 63, 79	Enthalpy change, 843	Extrinsic conduction, 119
Electromotive force (emf), 755	Enthalpy of fusion, 847	
Electron bonding interaction, π , 642	Entrance slit, 78, 80, 84, 87, 88, 88, 91	F
Electron capture (EC), 576	Environmental applications of molecular	
Electron capture detector (ECD), 658–660,	MS, 578	FAB, see Fast atom bombardment
659	Environmental sampling, 11	Factors, defined, 212
Electron configurations of elements, 429	Enzymes, 135, 140, 153, 603, 679, 716, 727,	Faradaic current, 806, 809
Electronic excitation, 104–107	772, 820, 868	Faradaic polarization, 797
Electronic Laboratory Notebooks (ELNs), 2	EOF, see Electroosmotic flow	Faraday cup, 559, 562
Electronic pulse processing units, WDXRF	Equilibrium partition ratio, Kx, 616	Faraday's law, 786, 791–792
spectrometry, 470–471, 471	Equivalence point, 776, 785	FAR-IR sources, 175
Electronic transitions, 70–71, 108–110, <i>110</i> , 146	Equivalent conductance, 796 Equivalent conductivity, 796	Fast atom bombardment (FAB), 536–538, 537–538
Electron ionization (EI), 521, 529, 529–530	Equivalent conductivity, 796 Equivalent hydrogen atoms, 265	Fast Fourier transform (FFT), 44, 94, 559
Electron micrograph, 469, 496, 687	Errors, 9, 30–34	Fast GC, 650, 665
Electron multiplier (EM), 559–561,	analysis, 9	"Fast scan" approach, 488
560–561	analyst, 32	Fatigue, 117, 508
Electrons, π , 260, 260	associated with Beer's law, 75–78	Fatty acid distribution, 206
Electron transitions, 431, 431	by baseline drift in spectroscopic	Fatty acid methyl esters (FAME), 205, 643
Electroosmotic flow (EOF), 736, 736, 740	measurement, 90	Fellgett's advantage, 94, 179
Electroosmotic mobility, 737, 737	calculation, 32	Ferromagnetic material, 831
Electrophoresis, 528-529, 604, 734-742	carelessness, 32	FFT, see Fast Fourier transform
Electrophoresis gels, 126	constant, 30	F-function, 41
Electrophoretic mobility, 735	determinate, 30–33, 36	FIA, see Flow injection analysis
Electrospray interface for HPLC-MS, 712	indeterminate, 33	Fiber optic-based modular systems, 223–224
Electrospray ionization (ESI), 531–532	percent, 53–54	Fiber optic probes, 126, 127
Electrostatic analyzer (ESA), 545	proportional, 31	Fiber-reinforced plastic (FRP), 287
Electrothermal atomizers (ETA), 312–314	quantifying random, 35–41	FID, see Flame ionization detector;
Electrothermal vaporization (ETV), 394–395	relative concentration, 75	Free induction decay Fill/drain valve, 695
Elements, 121	sources in thermogravimetry, 839–840 systematic, 31, 35, 40	Film thickness d_{ν} 617
analysis, 303, 431	transcription, 45	Filters, 79–80, 83
electron configurations of, 429	Escape peak, 467	absorption, 79–80
isotope patterns, 584	Essential amino acids, 717, 717	interference, 80
semiconductor devices, 119	Esterification of organic acids, 676	wavelength selection devices, 356
ELNs, see Electronic Laboratory Notebooks	Ethylenediaminetetraacetic acid (EDTA), 766	Fine structure, 263, 265, 267, 334
Eluent, 604	ETV, see Electrothermal vaporization	First and/or second derivative, 778, 779
Eluent strength, 692	European Union (EU), 135, 403, 416	First kind of metallic electrodes, 766
Eluent suppression, 722, 722	Evanescent wave, 192	First order proton spectra, 268–269
Eluotropic series, 692	Evaporative light scattering detector (ELSD),	First order spectra, 268
Elution, 604	698–701, <i>699–700</i>	Fixed gases, 657, 677, 678
buffer, 728	Evolved gas analysis (EGA), 855–858	Flame AAS (FAAS), 310, 320, 324, 327, 334
gas chromatography (GC), 675–676	Evolved gas detection (EGD), 855	Flame atomic emission spectroscopy,
step, 728	Exact mass calculator, 600	353–362
Emissions	Exchange capacity, 720	flame OES
IR, 195–196	Excitation energy, 253 Excitation interferences, 358–359	analytical applications, 360–362
measurements, 191–196 process, 354	Excitation monochromator, 150	instrumentation, 354–358 interferences, 358–360
spectrometer, 363	Excitation process, 354	Flame atomization, 319–324
spectrum of flame, 359	Excitation process, 357 Excitation source, EDXRF spectrometry,	Flame atomizers, 310–312
Empirical formula, 4–5, 8	446–447, 447	Flame emission, 419–420
Emulsifying layer, 13	Excitation sources, plasma emission	Flame excitation source, 356–358
Enantiomeric form, 689	spectrometry, 382–386	Flame ionization detector (FID), 635,
Enantiomers, 5, 689–690	Excitation waveform, 814	657–658, 658
End capping, 614, 685	Excited state, 104, 146, 146	Flame microsampling, 347
Endothermic change, 840, 848	Exclusion limit, 728	Flame oxidizer, 658
Energy bands, 118; see also Bands	Exothermic change, 840, 848	Flame profile, 321, 321

F layer, 744	derivatization of difficult analytes,	Gas phase absorption spectrum, 111
Flicker noise, 44	675–676	Gas phase FTIR spectrum, 857
Flow cell, 697	elution behavior, 675–676	Gas samples, 13, 189–190, 344–345
Flow injection analysis (FIA), 346–347	hyphenated GC techniques, 665-673	Gas sampling valve, 638
Flow microliter calorimeter (FMC), 868	comprehensive 2D-gas	Gas-sensing electrodes, 771–772, 782
Flow parameters, 646–647	chromatography (GCxGC or GC 2),	Gaussian distribution, 33, 34, 35–36
Flow proportional counter (FC), 468	669–673, 670–672	Gaussian-like distribution, 609
Flow spoiler, 310–311	gas chromatography-IR spectrometry	Gaussian peak-shaped signal, 325, 325
Flow-through samplers, 125	(GC-IR), 668–669	Gaussian profile, 572
Fluorescence, 146–148, 219	gas chromatography-mass	Gaussian pulse height distribution, 470
advantages of, 155	spectrometry (GC-MS), 665-668,	GC, see Gas chromatography
concentration and, 148–149, <i>150</i>	666	GC-IR-MS, 569–570
detector, 703–704	instrumentation, 606, 606, 635–636	GC-MS, see Gas chromatography-mass
disadvantages of, 155–156	instrument component design (detectors),	spectrometry
intensity, 148–149, <i>150</i>	654–665	Geiger counter, 467
monochromator, 150	atomic emission detector (AED),	Geiger-Müller plateau, 467
radiation, 409	664–665	Gel filtration separation, 730
spectrometry, 8	electrolytic conductivity detector	Gel holder for UV/VIS absorption
Fluorometry, 153–155	(ELCD), 660–661	spectroscopy, 126
Fluorophore, 147	electron capture detector (ECD),	Genomics, 604, 714
Fluxers, 19, 342, 403, 481	658–660, 659	Geological characterization applications,
Fluxes, 19–20, 416, 490	flame ionization detector (FID),	586–587
FMC, see Flow microliter calorimeter	657–658, 658	GFAAS, see Graphite furnace atomic
Focal plane array (FPA), 234	helium ionization detector (HID), 663,	absorption spectroscopy
Focal plane camera (FPC), 562	663-664	Glass capillary column for gas
Forward bias, 120, 120–121	nitrogen-phosphorous detector (NPD),	chromatography, 615
Four-amino acid peptide chain, 716	661–662, 662	Glass indicator electrodes, 768
Fourier transform (FT), 269, 499, 557	photoionization detector (PID), 662	Glass membrane electrodes, 767–769, 768
IR spectrum, 45, 164, 180, 196–200	sulfur chemiluminescence detector	Glass transitions, 840, 844
Raman spectrometers, 222, 222–223	(SCD), 661	Globars, 172–173
spectrometers/spectroscopy, 44–45,	sulfur-phosphorous flame	Glow discharge (GD), 404–405, 405, 540, 580
93–95, 176–179	photometric detector (SP-FPD),	applications of atomic emission
Fourier transform ion-cyclotron resonance	661	spectrometry, 405–406, 406
(FTICR), 557, 557–558	thermal conductivity detector (TCD),	atomizers, 342
Fourier transform ion-cyclotron resonance	656–657, 657 instrument component design (injectors),	emission spectrometry, 404–406
mass spectrometry (FTICR-MS), 557–558	637–642	Goniometer, 460, 464, 464, 504 Göttingen Barfüßer altarpiece, 486
FPA, see Focal plane array	autosamplers, 638, 638–639	Grab sample, 13
FPC, see Focal plane camera	solid phase microextraction (SPME),	Gradient elution, 694
Franck-Condon principle, 109	639–640, 640	Graphite furnace atomic absorption
Free induction decay (FID), 257, 257	split injections, 640, 641	spectroscopy (GFAAS), 313, 320,
Frequency of vibration, 169; see also	splitless injections, 641, 641–642	324, 326–330, 332, 334, 337–338,
Vibrations	syringes, 637, 637–638	367, 402, 411
Frequency of wave, 61	instrument component design (the	Graphite furnace atomization, 324–326
Fronting peak shape, 635	column), 642–647	Graphite furnace atomizer, 313, 313–314
FRP, see Fiber-reinforced plastic	column stationary phase, 642–644,	Gratings
F-test, 41	642-645	blazed diffraction, 86
FTNMR, 246, 255–258, 269, 284, 289, 295	flow parameters, 646–647	diffraction, 115
Fuel supply, 657	mobile phase choice, 646–647	dispersion of monochromator, 85, 86
Fukushima Daiichi plant, 419	selecting stationary phase for	echelle, 86, 87
Full-scan, 666–667	application, 645–646	master, 81
Full-width at half-maximum (FWHM), 89,	instrument operation (column	resolution of, 84–85, 85
470–471, 526	dimensions and elution values),	Gravimetric analyses, 1, 212, 828-829, 832
Full XRD goniometer, 504		
Fundamental parameters method, 488	648-650	Gravimetry, 7, 791
Fundamental transition, 167	648–650 instrument operation (column	
F 1 11: 610 615		Gravimetry, 7, 791 Gravity column LC, 607 Green chemistry, 9
Fused silica, 613, <i>615</i>	instrument operation (column	Gravity column LC, 607
Fusions, 18–20, 19, 481, 481	instrument operation (column temperature and elution values),	Gravity column LC, 607 Green chemistry, 9
	instrument operation (column temperature and elution values), $650-654$ limitations, 679 relative $R_{\rm t}$, $673-674$	Gravity column LC, 607 Green chemistry, 9 Grinding, 11–12, 14, 184, 213, 342–343, 376,
Fusions, 18–20, 19, 481, 481	instrument operation (column temperature and elution values), $650-654$ limitations, 679 relative R_v , $673-674$ retention indices, $673-674$	Gravity column LC, 607 Green chemistry, 9 Grinding, 11–12, 14, 184, 213, 342–343, 376, 480–481, 503
Fusions, 18–20, <i>19</i> , 481, <i>481</i> Fusion bead, 342, 481, <i>481</i> , 490	instrument operation (column temperature and elution values), 650–654 limitations, 679 relative R_v , 673–674 retention indices, 673–674 scope of, 674–679	Gravity column LC, 607 Green chemistry, 9 Grinding, 11–12, 14, 184, 213, 342–343, 376, 480–481, 503 Gross representative sample, 11 Grotrian diagrams, 304, 304–305 Guard column, 696–697
Fusions, 18–20, <i>19</i> , 481, <i>481</i> Fusion bead, 342, 481, <i>481</i> , 490 FWHM, <i>see</i> Full-width at half-maximum	instrument operation (column temperature and elution values), 650–654 limitations, 679 relative <i>R</i> _v , 673–674 retention indices, 673–674 scope of, 674–679 steel packed column coiled, 634	Gravity column LC, 607 Green chemistry, 9 Grinding, 11–12, 14, 184, 213, 342–343, 376, 480–481, 503 Gross representative sample, 11 Grotrian diagrams, 304, 304–305
Fusions, 18–20, <i>19</i> , 481, <i>481</i> Fusion bead, 342, 481, <i>481</i> , 490	instrument operation (column temperature and elution values), 650–654 limitations, 679 relative R_v , 673–674 retention indices, 673–674 scope of, 674–679 steel packed column coiled, 634 Gas chromatography-IR spectrometry	Gravity column LC, 607 Green chemistry, 9 Grinding, 11–12, 14, 184, 213, 342–343, 376, 480–481, 503 Gross representative sample, 11 Grotrian diagrams, 304, 304–305 Guard column, 696–697
Fusions, 18–20, <i>19</i> , 481, <i>481</i> Fusion bead, 342, 481, <i>481</i> , 490 FWHM, <i>see</i> Full-width at half-maximum G Galvanic cell, 755, 786, <i>787</i>	instrument operation (column temperature and elution values), 650–654 limitations, 679 relative R _v , 673–674 retention indices, 673–674 scope of, 674–679 steel packed column coiled, 634 Gas chromatography-IR spectrometry (GC-IR), 668–669	Gravity column LC, 607 Green chemistry, 9 Grinding, 11–12, 14, 184, 213, 342–343, 376, 480–481, 503 Gross representative sample, 11 Grotrian diagrams, 304, 304–305 Guard column, 696–697 Gulf of Mexico, 26
Fusions, 18–20, 19, 481, 481 Fusion bead, 342, 481, 481, 490 FWHM, see Full-width at half-maximum G Galvanic cell, 755, 786, 787 Gas analysis, 577–578	instrument operation (column temperature and elution values), 650–654 limitations, 679 relative R _v 673–674 retention indices, 673–674 scope of, 674–679 steel packed column coiled, 634 Gas chromatography-IR spectrometry (GC-IR), 668–669 Gas chromatography-mass spectrometry	Gravity column LC, 607 Green chemistry, 9 Grinding, 11–12, 14, 184, 213, 342–343, 376, 480–481, 503 Gross representative sample, 11 Grotrian diagrams, 304, 304–305 Guard column, 696–697 Gulf of Mexico, 26
Fusions, 18–20, <i>19</i> , 481, <i>481</i> Fusion bead, 342, 481, <i>481</i> , 490 FWHM, <i>see</i> Full-width at half-maximum G Galvanic cell, 755, 786, <i>787</i> Gas analysis, 577–578 Gas cells, 122–124	instrument operation (column temperature and elution values), 650–654 limitations, 679 relative R _v , 673–674 retention indices, 673–674 scope of, 674–679 steel packed column coiled, 634 Gas chromatography-IR spectrometry (GC-IR), 668–669 Gas chromatography-mass spectrometry (GC-MS), 8, 519, 529, 665–668, 666	Gravity column LC, 607 Green chemistry, 9 Grinding, 11–12, 14, 184, 213, 342–343, 376, 480–481, 503 Gross representative sample, 11 Grotrian diagrams, 304, 304–305 Guard column, 696–697 Gulf of Mexico, 26 Gyromagnetic ratio, see Magnetogyric ratio
Fusions, 18–20, 19, 481, 481 Fusion bead, 342, 481, 481, 490 FWHM, see Full-width at half-maximum G Galvanic cell, 755, 786, 787 Gas analysis, 577–578 Gas cells, 122–124 Gas chromatography (GC), 5, 8, 26, 575, 605,	instrument operation (column temperature and elution values), $650-654$ limitations, 679 relative $R_{\rm t}$, $673-674$ retention indices, $673-674$ scope of, $674-679$ steel packed column coiled, 634 Gas chromatography-IR spectrometry (GC-IR), $668-669$ Gas chromatography-mass spectrometry (GC-MS), 8 , 519 , 529 , $665-668$, 666 Gas expansion in sample input of MS, 528	Gravity column LC, 607 Green chemistry, 9 Grinding, 11–12, 14, 184, 213, 342–343, 376, 480–481, 503 Gross representative sample, 11 Grotrian diagrams, 304, 304–305 Guard column, 696–697 Gulf of Mexico, 26 Gyromagnetic ratio, see Magnetogyric ratio H Half-cells
Fusions, 18–20, <i>19</i> , 481, <i>481</i> Fusion bead, 342, 481, <i>481</i> , 490 FWHM, <i>see</i> Full-width at half-maximum G Galvanic cell, 755, 786, 787 Gas analysis, 577–578 Gas cells, 122–124 Gas chromatography (GC), 5, 8, 26, <i>575</i> , 605, 633–679	instrument operation (column temperature and elution values), 650–654 limitations, 679 relative R _v , 673–674 retention indices, 673–674 scope of, 674–679 steel packed column coiled, 634 Gas chromatography-IR spectrometry (GC-IR), 668–669 Gas chromatography-mass spectrometry (GC-MS), 8, 519, 529, 665–668, 666 Gas expansion in sample input of MS, 528 Gas-filled detectors, 465–468, 466–467	Gravity column LC, 607 Green chemistry, 9 Grinding, 11–12, 14, 184, 213, 342–343, 376, 480–481, 503 Gross representative sample, 11 Grotrian diagrams, 304, 304–305 Guard column, 696–697 Gulf of Mexico, 26 Gyromagnetic ratio, see Magnetogyric ratio H Half-cells chemically irreversible, 787
Fusions, 18–20, 19, 481, 481 Fusion bead, 342, 481, 481, 490 FWHM, see Full-width at half-maximum G Galvanic cell, 755, 786, 787 Gas analysis, 577–578 Gas cells, 122–124 Gas chromatography (GC), 5, 8, 26, 575, 605,	instrument operation (column temperature and elution values), $650-654$ limitations, 679 relative $R_{\rm t}$, $673-674$ retention indices, $673-674$ scope of, $674-679$ steel packed column coiled, 634 Gas chromatography-IR spectrometry (GC-IR), $668-669$ Gas chromatography-mass spectrometry (GC-MS), 8 , 519 , 529 , $665-668$, 666 Gas expansion in sample input of MS, 528	Gravity column LC, 607 Green chemistry, 9 Grinding, 11–12, 14, 184, 213, 342–343, 376, 480–481, 503 Gross representative sample, 11 Grotrian diagrams, 304, 304–305 Guard column, 696–697 Gulf of Mexico, 26 Gyromagnetic ratio, see Magnetogyric ratio H Half-cells

reaction, 762–763	pump, 694–695	Impact bead, 310
reference, 755	separation of composition of mobile	IMS, see Ion mobility spectrometry
solid electrical conductor in, 753	phase, 691–692	INCOS dot-product algorithm, 568
Half-wave potential, 802, 807, 808	High-resolution continuum source AAS, 319	Indeterminate error, 33; see also Errors
Hand-held IR pellet press, 186	High-resolution ICP-MS (HR-ICP-MS), 594	Indicator electrodes, 764–772
Handheld systems, Raman spectroscopy,	High-resolution mass spectrometry, 570-571	analytical applications of potentiometry,
223–224	High-temperature furnace atomizer, 313	775–776
Hand-held UV/VIS spectrometers, 127–133	Hollow cathode lamp (HCL), 307–309, 308,	calibration by method of standard
Handheld XRF analyzer (HHXRF), 485, 485	336–337, 345, 396	additions, 783–784
Hanging mercury drop electrode (HMDE),	Homogeneous field of absorption lines,	crystalline solid-state electrodes, 769–770
815	252–253	direct measurement of an ion
HaySep, 678	Homogeneous laboratory sample, 11	concentration, 776
• •		
Head pressure, 637 Headspace, 26, 639	Homogeneous sample, 3, 10, 13–14	gas-sensing electrodes, 771–772
	Homonuclear decoupling, 278–279, 279	glass membrane electrodes, 767–769
Heart-cutting, 2D chromatography, 608	Homonuclear diatomic molecules, 217	immobilized enzyme membrane
Heart-cutting 2D GC, 672	Hooke's Law, 168	electrodes, 772
Heat capacity, 842, 845	Hope Diamond, 415	instrumentation for measuring potential,
Heated wires, for IR sources, 172	HPLC, see High-performance liquid	773–775
Heat flux DSC, 846, 846	chromatography	ion-selective field effect transistors
Heat of fusion, 852	HPLC-NMR-MS, 245	(ISFET), 772, 773
Height equivalent to a theoretical plate	Humble Oil Company, first commercial	liquid membrane ISEs, 770–771
(HETP), 606, 619	NMR, 245	membrane electrodes, 766–767
Heisenberg uncertainty principle, 253, 305	Hund's rule, 68	metallic electrodes, 766
Helium ionization detector (HID), 663,	Hybrid spectrometers, 460	oxidation-reduction titrations, 784-786
663-664	Hybrid XRD/XRF systems, 504–506	pH measurements, 778–781
Helmholtz coils, 269, 270	Hydride generation (HGAAS), 314, 346, 410,	pH titrations, 781–782
HETCOR, 284	412	potentiometric titrations, 776–778
Heterogeneous sample, 3; see also Sample/	Hydrocarbon contamination, 208	quantitative determination of ions other
sampling	Hydrodynamic flow, 737, 737	than hydrogen, 782–783
Heteronuclear decoupling, 279, 282, 282	Hydrodynamic injection, 739	redox, 766
HGAAS, see Hydride generation	Hydrofluoric acid (HF), 16, 18	Indirect detection in ion chromatography,
HID, see Helium ionization detector	Hydrogen bonding, 642	726
High-energy pre-spark (HEPS), 368, 381	Hydrophilic interaction liquid	Indirect detection method, 744
High-energy UV radiation, 662	chromatography (HILIC), 690;	Indium tin oxide (ITO), 817–818
High-performance anion exchange (HPAE),	see also High-performance liquid	Induced energy, 383
707	chromatography	Inductively coupled plasma (ICP), 353, 404,
High Performance Ion Mobility Spectrometry	Hyperspectral imaging, 235	421, 540–541, 541, 580
(HPIMS [™]), 564–565, 565		
	Hyphenated chromatography-ICP-MS, 519	Inductively coupled plasma atomic emission
High-performance liquid chromatography	Hyphenated GC techniques, 665–673	spectrometry (ICP-AES), 4, 367,
(HPLC), 8, 25, 28, 28, 404, 607,	Hyphenated instrument, 404	382, 395, 402–403, 416
683–719	Hyphenated systems, 608	Inductively coupled plasma mass
applications of, 716–719	Hyphenated techniques, 272, 291–292, 657	spectrometry (ICP-MS), 6, 8, 19,
column and stationary phases, 684–686,	in high-performance liquid	52, 338, 403, 589
684–691	chromatography, 711–715	Infrared absorbance detector, 703
chiral phases for separation of	thermal analysis, 854–858	Infrared (IR) spectroscopy, 4–5, 8, 70–71, 75,
enantiomers, 689–690	evolved gas analysis (EGA), 855–858	88, 93–94, 163–242
phase combinations for assays of very	hyphenated thermal methods,	absorption by molecules, 164–169
polar biomolecules, 690–691	854-855	analytical applications, 201–209
stationary phase considerations, 689	Hyphenated TGA-FTIR, 857	chemical imaging, 233-240
support particle considerations,	Hyphenated thermal methods, 854–855	FTIR microscopy, 196–200
686–688		instrumentation, 169–184
derivatization in, 709–710, 710	1	near-IR spectroscopy, 209–217
design and operation of instrument,	•	nondispersive systems, 200-201
693–697	ICP, see Inductively coupled plasma	Raman spectroscopy, 217–233
detector design and operation, 697-709	ICP-AES/ICP-OES, see Inductively coupled	sampling technique, 184-196
aerosol detectors, 698-701	plasma atomic emission	InGaAs detectors, 214, 221–222
corona charged aerosol detector,	spectrometry	Injection internal standard, 627
698–701	ICP-MS, see Inductively coupled plasma mass	Injector, instrument component design,
electrochemical detectors (ECDs),	spectrometry	637–642
704–709	Idealized interferogram, 178	Injector spreading and tailing, 623
evaporative light scattering detector,	IDMS, see Isotope-dilution mass	Inorganic compounds, 1, 142, 496
698–701	spectrometry	qualitative identification, 163
fluorescence detector, 703–704	IEC, see Interelement correction	quantitative analyses, 226
IR absorption detectors, 701–703	IEF, see Isoelectric focusing	Inorganic mass spectrometry, 8
refractive index detector, 698, 698	Ilkovic equation, 804	Inorganic molecules, 105, 107
UV/Vis absorption detectors, 701,	Image current, 557	Inorganic MS, 540–541; see also Mass
-		•
701–703	Immiscible liquids, 13	spectrometry Instrumental analysis 2
hyphenated techniques in, 711–715	Immiscible solvents, 21 Immobilized enzyme membrane electrodes	Instrumental analysis, 2
interfacing HPLC to mass spectrometry,	Immobilized enzyme membrane electrodes,	Instrumental analytical chemistry, 1–56
712–715, <i>713–715</i>	772	approach, 2–15

designing analytical method, 9-10	mass analyzers, 541-559	spectral (isobaric) interferences,
problem defining, 3–8	sample input systems, 528–529	592–594
sampling, 10–14	for measuring potential, 773–775	flame atomic emission spectroscopy,
storage of samples, 14–15	microcalorimetry, 862	358–360
calibration, 45–54	microvolume, 127–133	plasma emission spectroscopy, 395-401
calibration curve, 45–47	monochromators, 115	in spark emission spectroscopy, 376–378
with external standards, 47–49	nanovolume, 127–133	spectral, 51
internal standard calibration, 51–54	nuclear magnetic resonance (NMR),	Interferogram, 94–95, 178, <i>178</i>
		Interferometers, 93
Method of Standard Additions (MSA),	269–275, 294–296	
49–51	computer, 274–275	components, 179–181
data assessment, 54–56	magnet, 272–273	infrared (IR) spectroscopy, 175–181
limit of detection (LOD), 55	RF generation and detection, 274	Internal standard, 397
limit of quantitation (LOQ), 56	sample holder, 269–272	Internal standard calibration, 51–54, 377–
defined, 1	sample probe, 272	378, 626–627; <i>see also</i> Calibration
measurement, 42–45	signal integrator, 274–275	International Centre for Diffraction Data
noise, 42–45	optical system, 112–113	(ICDD), 507
signals, 42–45	plasma emission spectroscopy, 382–395	Intersystem crossing (ISC), 147, 147
sample preparation, 15–28	radiation sources, 113–115	Inverting input, 774; see also Noninverting
acid digestion, 15–18	Raman spectroscopy	input
acid dissolution, 15–18	dispersive spectrometers systems, 221,	Ion chromatography, 8, 20, 722–726, 723–725
combustion, 20	221–222	Ion concentrations, 776, 783
dry ashing, 20	fiber optic-based modular systems,	Ion-exchange chromatography, 719
extraction, 20–28	223–224	Ion-extraction field, 547
fusions, 18–20	FT-Raman spectrometers, 222, 223	Ionic liquids, 643
statistics and data handling, 29-42	handheld systems, 223–224	Ionization buffer, 328
accuracy, 29–30	light sources, 219–221	Ionization counters, 466
errors, 30–33	samples and sample holders, 224-226	Ionization detectors, 635
precision, 29–30	sample holders, 122–127	Ionization interferences, 328, 358–359
quantifying random error, 35–41	fiber optic probes, 126, 127	Ionization sources in MS, 529–541; see also
rejection of results, 41–42	flow-through samplers, 125	Mass spectrometry
Instrumental drift, 52	gas cells, 122–124	atmospheric pressure ionization (API)
	liquid cells, 122–124	
Instrumentally distorted peak, 666		sources, 531–535
Instrumentation, 112–133, 150–153	matched cells, 124–125	chemical ionization (CI), 530–531
atomic fluorescence spectroscopy,	solid sample holders, 126	desorption ionization, 535–540
409–410	thermogravimetry, 829–832	electron ionization (EI), 529, 529–530
for conductivity measurements, 797–798	for voltammetry, 813	for inorganic MS, 540–541
detectors, 115–122	X-ray fluorescence	Ionization suppressant, 359
barrier layer cell, 115–117, <i>116</i>	energy dispersive X-ray (EDXRF)	Ion lines, 363
photomultiplier tube (PMT), 117–118,	spectrometry, 445–459, 476	Ion mobility spectrometry (IMS), 563-566
117–118	micro-XRF, 473-476	Ion-pair, 719
semiconductor detectors, 118-122	wavelength dispersive X-ray (WDXRF)	Ion-pairing chromatography, 719
differential scanning calorimetry (DSC),	spectrometry, 460–473, 476	Ions dissolved in liquids, chromatography of,
845–851	Instrument detection limit (IDL), 55	719–726
	Instrument nomenclature, 95	Ion-selective electrodes (ISE), 767
differential thermal analysis (DTA),	· · · · · · · · · · · · · · · · · · ·	, ,
841–843	Insulator, 118	Ion-selective field effect transistors (ISFET),
double-beam, 124	Integrated peak area, 341	772, 773
for electrogravimetry, 788–789	Intensity, 65, 67, 69, 71–72, 73, 74–75, 78–79,	Ion selective potentiometry, 20
flame OES, 354–358	88–95	Ion-trap, 556, 665, 668
gas chromatography (GC), 635–636	colored solutions, 101	Ion trap, 3D, 556
hand-held UV/VIS spectrometers,	fluorescence, 148-149, 150	IR absorption detectors, 701–703
127-133	Interelement correction (IEC), 400	IR-active, 167
HPLC's design and operation, 693-697	Interelement effect, 376	IR emission, 195–196
infrared (IR) spectroscopy, 169–184	Interfacing chromatographic effluent, 665	IR-inactive, 167, 217
detectors, 181–184	Interference filter, 80	IR laser sources, 175
FAR-IR sources, 175	Interferences, 3, 9	IR microscope, 196
interferometers, 175–181	in arc emission spectroscopy, 376–378	IR-SEC cell, 821
IR laser sources, 175	atomic absorption spectrometry (AAS),	IR-SEC studies, 820
monochromators, 175–181	326–338	IR spectrum, 220
NIR sources, 174	atomic fluorescence spectroscopy,	IR-transparent CaF ₂ window, 820
radiation sources, 172–174	410-411	ISE, see Ion-selective electrodes
Laser-Induced Breakdown Spectroscopy	atomic MS	ISFET, see Ion-selective field effect transistors
(LIBS), 413–414	collision cells, 594-595	Isobaric interference problem, 597
luminescence	high-resolution ICP-MS (HR-ICP-MS),	Isocratic HPLC elution, 694
detectors, 152-153	594	Isoelectric focusing (IEF), 746
radiation sources, 151–152	instrumental approaches to	Isoelectric point, 719, 746
sample cells, 153	eliminating, 594–597	Isomers, 5, 5, 8, 202, 229, 568, 574–575, 578,
wavelength selection devices, 150–151	interference removal, 595–597	580, 624, 667–669, 673–675, 690
mass spectrometry (MS), 527–563	matrix effect, 591	Isothermal GC, 650
detectors, 559–563	reaction cells, 594–595, 595	Isothermal titration calorimetry (ITC), 862,
ionization sources, 529–541		866-867

Isotope dilution, 573–574	Ligands, 727	Magnetic sector instruments, 542–546
Isotope-dilution mass spectrometry (IDMS),	Light-emitting diodes (LEDs), 114, 114-115	Magnetic sector mass analyzers, 541
668 Isotopically labelled, 574	Light pipe, 668 Light sources, Raman spectroscopy, 219–221	Magnetic sector mass spectrometer, 521, 521, 542
ITC, see Isothermal titration calorimetry	Limit of detection (LOD), 55, 656	Magnetogyric ratio, 247, 249–250, 252–253,
•	Limit of quantitation (LOQ), 56	283, 297
J	LIMS, see Laboratory Information	Makeup gas, 623, 650, 655
Jacquinot's advantage, 94, 179	Management Systems Linear dynamic range, 655	MALDI, see Matrix-assisted laser desorption ionization
"Jake Matijevic" rock on mars, 510	Linearly proportional signal response, 655	MALDI-TOF-MS, 578, 580
Jake rock, 510, <i>510</i>	Linear mobile phase velocity, 619	Malleable metals, 12
Jet separator, 666 Jet tip, 658	Linear photodiode array (LPDA), 121 Linear potential excitation, 802	Manual septum injector, <i>634</i> Manufacturers' applications literature, <i>645</i>
Joule heating, 738	Linear sweep voltammetry, 801	Mapping across pharmaceutical tablet, 486
Joules (J), 753	Line broadening, 254–255	Mass absorption coefficient, 434, 437
	Line notation, half cells, 756	Mass accuracy, 526–527, 570, 572
K	Line overlap, 377 Line sources, 79	Mass analyzers, 532, 532, 540, 541–559 Mass analyzers of mass spectrometry, 541–
K absorption edge, 435, 436	Liquid cells, 122–124	559; see also Mass spectrometry
Karl Fischer titration, 216	Liquid chromatography (LC), 5, 8, 25	electric sector instruments, 542-546
Katharometer, 635, 657	Liquid chromatography-mass spectrometry	Fourier transform ion-cyclotron
KBr pellet method, 185 KED, see Kinetic energy discrimination	(LC-MS), 8, 25, 519, 529–530, 538, 553, 556, 569, 575, 577, 665, 711,	resonance (FTICR), <i>557</i> , 557–558 magnetic sector instruments, 542–546
Kinetic energy discrimination (KED), 594	729, 745	MS/MS instruments, 554–555, 555
Kjeldahl method, 216, 224	Liquid-liquid extraction, 21–22	MS ^N instruments, 554–555
Kohlrausch's law, 796	Liquid membrane ISE, 770–771, 771	Orbitrap™ mass analyzer, 558–559,
Korean Food Code, 135 Kovats RI system, 673	Liquid mobile phase, 404 Liquid samples, 13, 187–189, <i>188</i> , 341–342,	558–559 quadrupole ion trap (QIT), 556–557, 557
Kubelka-Munk relationship, 195	369, 390–391	quadrupole mass analyzer, 551–553,
Kumakhov optics, 475	Literature and resources, atomic emission,	552–553
	419	time of flight (TOF) analyzer, 546-551,
L	Lithium-drifted silicon diode, 454, 455 Lock mass, 571	547–550 Mass attenuation coefficient, 43
Laboratory Information Management	LOD, see Limit of detection	Mass chromatograms, 667
Systems (LIMS), 2, 15	Logarithmic progression, 673	Mass defect, 570
Laboratory sample	London's dispersion forces, 642	Mass detector, 612
homogeneous, 11 LAESI, see Laser ablation electrospray	Longitudinal diffusion term, 620–621 Longitudinal relaxation, 253	Mass discrimination, 561–562 Mass flow <i>versus</i> concentration response,
ionization	Long-term precision, 39	characteristics of GC detectors,
Laminate, 197, 198	LOQ, see Limit of quantitation	655
Landhanum fluoride lattice, 770	Low resolution MS instruments, 572 L-PAD, see Large Format Programmable	Mass spectrometry (MS), 5, 8, 93, 519–600, 524, 543, 567
Large Format Programmable Array Detector (L-PAD), 374	Array Detector	applications, 566–580
Larmor equation, 249, 258, 272	Luggin probe, 794	atomic MS, 580–598
Laser ablation, 342, 395, 396, 401, 402	Luminescence, 64, 67	block diagram of, 527
Laser ablation electrospray ionization (LAESI), 539–540	analytical applications of, 153–156 instrumentation	instrumentation, 527–563 detectors, 559–563
Laser desorption, 535	detectors, 152–153	ionization sources, 529–541
Laser-Induced Breakdown Spectroscopy	radiation sources, 151–152	mass analyzers, 541–559
(LIBS), 412–419	sample cells, 153	sample input systems, 528–529
applications, 414–419 instrumentation, 413–414	wavelength selection devices, 150–151 measurements, 150–153	ion mobility spectrometry (IMS), 563–566 limitations, 580
principle of operation, 412–413	Lundegardh burner, 355	principles of, 520–527
qualitative analysis, 415–416	,	resolution, 525–527
quantitative analysis, 416–417	M	resolving power, 525–527
remote analysis, 417–419 Laser-Induced Plasma Spectroscopy, 412	Macromolecule, 101, 246, 294, 603, 714, 727,	spurious effects in, 598, 598 Mass-to-charge ratio, 520, 523, 525, 557
Laser Spark Spectroscopy (LASS), 412	729, 738–739, 741, 745, 843	Mass transfer term, 621
Late eluters, 653	Magic angle spinning (MAS), 254, 284	Master grating, 81
Later eluting peaks, 650	Magnet, NMR, 272–273	Matched cells, 124–125
Lattice, 253 LC-MS, see Liquid chromatography-mass	Magnetic anisotropy, 254 Magnetic energy, 247	Materials characterization applications, 586–587
spectrometry	Magnetic fields	Materials used in mid-IR optics, 172
LC-NMR, 711	alignments of, 264	Matrix, 3, 325, 327
Leading peak shape, 612, 612, 635	applied, 247, 248, 249–250, 252, 254,	Matrix-assisted laser desorption ionization
Le Chatelier's principle, 861 Levelling effect, 781	257–260, 260, 263, 523 strength, 250–252	(MALDI), 535 , 535–536, <i>536–537</i> Matrix blank, 10
Leverotatory compound, 5	Magnetic moment, 245–249, 255, 257, 297	Matrix effects, 50, 376, 591
LIBS, see Laser-Induced Breakdown	Magnetic resonance imaging (MRI), 245,	Matrix interference, 327–328
Spectroscopy	292–294, 293–294	Matrix-matching, 395

Matrix modification, see Chemical	Mixed crystal, 507, 509	MS ^N instruments, 554–555
modification	Mixed mode retention mechanism, 643	Multichannel detectors, 89
Matrix modifier, 332	Mixed modifier, 332	Multichannel pulse height analyzer, 457,
Mattauch-Herzog dispersive design, 544	Mixing in too large a detector volume,	457–458
Mattauch-Herzog geometry, 545, 546	622–623	Multichannel system, see Simultaneous
Matter, electromagnetic radiation interaction	Mobile phase, 604	WDXRF spectrometers
with, 61, 63–67, 95	choice, 646–647	Multicomponent determinations, 139–140
Maxwell-Boltzmann equation, 305	degassing, 693	Multiplement 208
Measurement, 42–45 absorption, 184–190	mixing, 694 of SFC, 731–732, see also Supercritical	Multipath term, 620, 620
of color, 142–144	fluid chromatography	Multiphase material, 506
digression on, 527	storage, 694	Multiplex, 179
emissions, 191–196	Mobility, 563	Multiplex instrument, 93
luminescence, 150–153	Modes of vibration, 166, 167	Multiplicity, 265
near-IR spectroscopy (NIR spectroscopy),	Modulation	Multipulse, NMR sequence, 280
213	amplitude, 810	Multiwavelength filter photometer, 200
noise, 42–45	atomic absorption spectrometry (AAS),	
reflectance, 191-196	317–318	N
signals, 42-45	Molar absorptivity, 73, 108–109, 109	
transmission, 184–190	Molecular emission spectrometry, 146–150	NaCl, 331–332
Mechanical chopper, 318	concentration, 148–149, <i>150</i>	Nano-DSC (TA Instruments), 862
Mechanical energy, 246	fluorescence, 146–149, 150	Nanovolume, 127–133
Mechanical slit width, 88	phosphorescence, 146–148	NASA Martian Space Laboratory, 509
Membrane electrodes, 766–767; see also Glass	Molecular formula, 4–5, 8	National Center for Forensic Science, 136
membrane electrodes	Molecular ion, 521	National Institute of Standards and
Mercury arc lamp, 149, 152	"Molecular leak" inlet, 528	Technology (NIST), 10, 29, 205,
Mercury determination, 411 Metabolomics, 604	Molecular sieve, 677, 678 Molecular spectroscopy, 69–71	227, 340, 381, 416, 488, 568, 842, 847
Metal atom, 754; see also Uncharged metal	Molecular structure, 276–280	National magnetic resonance facility at
atom	Molecular vibrations, 170–171	Madison (NMRFAM), 271
Metallic electrodes, 766	Molecules, 69–71	National Research Council of Canada
first kind, 766	absorption by, 107	(NRCC), 10
redox indicator electrode, 766	absorption of IR radiation by, 164–169	Nd:YAG, see Neodymium yttrium aluminum
second kind, 766	diatomic, 165–167	garnet
third kind, 766	dipole moments in, 164–166	Near-IR and Raman imaging microscope
Metal oxide-semiconductor (MOS), 374	electronic excitation in, 104–107	system (NIRIM), 236, 237
Method detection limit (MDL), 55	electronic transitions in, 70-71	Near-IR spectroscopy (NIR spectroscopy),
Method internal standard, 627	inorganic, 105, 107	209–217
Method of least squares, 46	organic, 105, 107	applications of, 214–217
Method of Standard Additions (MSA), 49–51,	rotational transitions in, 69–70	chemical imaging, 233–240
<i>51</i> , 327, 359, 395, 626, 780	triatomic, 166–167	chemometrics, 212–213
Method sensitivity, 339	vibrational transitions in, 70	instrumentation, 209–217
Methylate alcohols, 676	vibrations in, 166–168	measurement, 213
Methyl isobutyl ketone (MIBK), 341–342 Michelson interferometer, 176	vibrations of bonded atoms, 70	NIR calibration, 212–213 NIR vibrational bands, 210–212
Microcalorimetry, 862; see also Calorimetric	Molnar Institute for Applied Chromatography, 692	sampling techniques, 213–214
technique	Molten salt fusions of materials, 18, 20 ; see	sources, 174, 175
thermal analysis, 861–868	also Fusions	Nebulizer, 310–311, <i>391</i> –392, 391–393
applications, 863–866	Mono-capillary X-ray optic, 474	Negative ion chemical ionization (NICI), 576
instrumentation, 862	Monochromatic light, 61, 69, 94–95	Neodymium yttrium aluminum garnet
isothermal titration calorimetry,	Monochromators, 80–82, 82, 115, 315,	(Nd:YAG) laser, 152, 395, 412-413
866-867	315-316, 463, 472; see also Echelle	415
microliter flow calorimetry, 868	monochromators	Nephelometry, 144-146, 145
Microcells, 189	double-beam, 163	Nernst equation, 759–760, 767, 776–777, 780
Microconcentric nebulizers, 392	excitation, 150	Nernst glowers, 172–173
Microliter flow calorimetry, 868	fluorescence, 150	NeXRD, 504
Microscopic carbon-fiber electrodes, 772	infrared (IR) spectroscopy, 175–181	Nier-Johnson double focusing mass
Microvolume, 127–133	resolution of, 83–84	spectrometer, 544, 544
Microwave digestion, 16, 17	wavelength accuracy, 83	NIRIM, see Near-IR and Raman imaging
Microwave-induced He plasma, 664	wavelength selection devices, 355	microscope system
Microwave induced plasma (MIP), 382	Monodisperse, 616, 684	Nitric acid (HNO ₃), 16
Microwave plasma (MP), 353 Micro X-ray beam optics, 473–475, 474, 475	Monolithic silica cylinder, 687 Moseley's Law, 433–434, 434	Nitrogen-phosphorous detector (NPD), 661–662, 662
Micro-XRF instrumentation, 473–476	Motion, vibrational, 168–169	NMR, see Nuclear magnetic resonance
Micro-XRF system, 475, 475–476, 476	MP-AES instrument (4100) (Agilent	NMR, 2D, 280 , 284–287
Mid-IR absorption spectroscopy, 202–206	Technologies), 389	NMR, ¹³ C, 280–284
Migration, 734, 805	MP Source, 386	NOE, see Nuclear Overhauser effect
Mining companies, 490	MRI, see Magnetic resonance imaging	Noise, 42–45, 43
MIP, see Microwave induced plasma	MS/MS instruments, 554–555, 555	Nomenclature, 78, 95
MIP Source, 386	MS/MS interference removal, 595–597	Nonaqueous titrations, 782

Ni dittii 2	Outies II	Dl.:
Non-destructive analysis, 2	Optically matched cells, 124	Paul ion trap, 556
Non-destructive qualitative analysis, 4	Optically transparent electrodes (OTE), 817	PDA, see Photodiode array
Nondispersive IR systems, 200–201	Optical slits, 88, 88–89	Peaks, 42, 605
Non-instrumental analysis, 603	Optical systems, 78–95, 112–113	Peak area, 625–626
Noninverting input, 774	detectors, 89	Peak broadening, 612
Nonmoving floor/stationary phase, 609	dispersive optical layouts, 92–93	Peak height, 625–626
Nonpolar solvents, 21	double-beam optics, 89-92	Peak ratio, 627
Nonspecific elution, 728	Fourier Transform spectrometers, 93–95	Peak resolution, R_s , 618
Non-spectral interference, see Chemical	optical slits, 88–89	Peak width at base (w_b) , 617
interference	radiation sources, 79	Pellicular anion exchange bead, 724
Non-spectral interferences, 326–332	single-beam optics, 89–92	Pellicular packings, 724
Normal analytical zone, 384	wavelength selection devices, 79–87	Pellicular particles, 696
Normal calomel electrode (NCE), 763	Optics, 78	Peltier effect, 455
Normal distribution, 33, 34	configuration, 316–317	Penning Ionization, 533
	e e	
Normal Gaussian peaks shapes, 612	double-beam, 89–92, 92	Penning ion trap, 557
"Normal phase" chromatography, 613, 683	single-beam, 89–92	People-on-a-moving-belt analogy, 611
Normal pulse polarogram, 806, 807-809, 808	Order of diffraction, 498	Peptides, 716
Normal Raman spectrum, 230	Organic compounds, 1, 5, 8, 16, 142,	Percent absorption, 71
		-
Normal-role elution, 728	261–262 , 496	Percent crystallinity, 852
NRC, see Nuclear Regulatory Commission	atomic weights, 520	Percent error, 53–54
N-type semiconductor, 119–121, 121	gas chromatography (GC), 675	Percent relative deviation, 35
Nuclear magnetic resonance (NMR), 4–5, 8,	qualitative analyses, 226	Percent relative standard deviation, 35
45, 93, 245–300	qualitative identification, 163	Percent transmittance, 71
analytical applications, 275–291	quantitative analyses, 201, 226	Permanent gases, 677
chemical shifts, 258–263, 261–262	Organic functional groups, UV-Vis	Permeation limit, 729
FTNMR experiment, 255–258	absorptions, 107–108	Persistent organic pollutants (POPs), 671, 671
	-	
hyphenated techniques, 291–292	Organic materials, 15	Petroleum hydrocarbon cracking catalysts,
instrumentation, 269–275, 294–296	Organic matrix, 20	489
computer, 274–275	Organic modifiers, 691	Petroleum industry, 489
magnet, 272–273	Organic molecules, 105, 107, 263	pH
	•	*
RF generation and detection, 274	absorption spectra, 102	defined, 778–780
sample holder, 269–272	containing π bonds, 105	measurements, 778–781
sample probe, 272	with nonbonding electron, 106	meter, 780
signal integrator, 274–275	Organic MS, 555; see also Mass spectrometry	operational definition of, 781
		-
limitations, 297	Organic sample, 4, 16, 135, 192	pIon meters, 774
magnetic resonance imaging (MRI) and,	Orthogonal spray, 712	titrations, 781–782
292–294, 293–29 <i>4</i>	Oscillator strength, 306	Pharmaceutical tablets, 216
national magnetic resonance facility at	Osmotic pressure, 736	Phase combinations for assays of very polar
· · · · · · · · · · · · · · · · · · ·		
Madison (NMRFAM), 271	Ostwald's dilution law, 797	biomolecules, 690–691
properties of nuclei, 246–247	OTE, see Optically transparent electrodes	Phase ratio, 648
quantization of ¹ H nuclei in magnetic	Outer shell electron, 465	Phenolphthalein, 141
field, 247–252	Outlier, 41	Phosphorescence, 146–148
	*	
spectrometer components, 270	Out-of-plane (oop) bending modes, 166–167	advantages of, 155
spectrum, 250, 264	Overlapping line emission, 359	disadvantages of, 155–156
spin-spin coupling, 263–269, 266	Overpotential, 789	Photodiode array (PDA), 121, 221
width of absorption lines, 252–255	Overtone bands, 168	Photoelectric detectors, 95
Nuclear Overhauser effect (NOE), 280 ,	Oxidation half-reactions, 752	Photoelectric transducers, 115
		Filotoelectric transducers, 115
282–283		DI (DID) 11E 660
NT 1 D 1 C ' ' (NIDC) ((0)	Oxidation-reduction reaction, 751–752; see	Photoionization detector (PID), 117, 662
Nuclear Regulatory Commission (NRC), 660	also Reduction-oxidation reactions	Photoionization detector (PID), 117, 662 Photoluminescence, 147, 821
	also Reduction-oxidation reactions	Photoluminescence, 147, 821
Nuclear spin, 245–246, 247 , 284	<i>also</i> Reduction-oxidation reactions Oxidation-reduction titrations, 784–786	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362
Nuclear spin, 245–246, 247 , 284 Nuclear Zeeman splitting, 248	also Reduction-oxidation reactions	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118,
Nuclear spin, 245–246, 247 , 284 Nuclear Zeeman splitting, 248 Number of orientations, 248	<i>also</i> Reduction-oxidation reactions Oxidation-reduction titrations, 784–786	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317
Nuclear spin, 245–246, 247 , 284 Nuclear Zeeman splitting, 248	also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118,
Nuclear spin, 245–246, 247 , 284 Nuclear Zeeman splitting, 248 Number of orientations, 248	<i>also</i> Reduction-oxidation reactions Oxidation-reduction titrations, 784–786	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89
Nuclear spin, 245–246, 247, 284 Nuclear Zeeman splitting, 248 Number of orientations, 248 Number of theoretical plates, 618	also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183
Nuclear spin, 245–246, 247 , 284 Nuclear Zeeman splitting, 248 Number of orientations, 248	also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751 P Packed column GC, 633, 645; see also Gas	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183 Photon-sensitive detectors, 181
Nuclear spin, 245–246, 247, 284 Nuclear Zeeman splitting, 248 Number of orientations, 248 Number of theoretical plates, 618 O	 also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751 P Packed column GC, 633, 645; see also Gas chromatography 	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183 Photon-sensitive detectors, 181 Photovoltaic cell, see Barrier layer cell
Nuclear spin, 245–246, 247, 284 Nuclear Zeeman splitting, 248 Number of orientations, 248 Number of theoretical plates, 618 O Observed value, 34	 also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751 P Packed column GC, 633, 645; see also Gas chromatography PAD, see Pulsed amperometric detection 	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183 Photon-sensitive detectors, 181 Photovoltaic cell, see Barrier layer cell Pi (π) bond, 105, 105
Nuclear spin, 245–246, 247, 284 Nuclear Zeeman splitting, 248 Number of orientations, 248 Number of theoretical plates, 618 O	 also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751 P Packed column GC, 633, 645; see also Gas chromatography PAD, see Pulsed amperometric detection 	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183 Photon-sensitive detectors, 181 Photovoltaic cell, see Barrier layer cell
Nuclear spin, 245–246, 247, 284 Nuclear Zeeman splitting, 248 Number of orientations, 248 Number of theoretical plates, 618 O Observed value, 34 Octadecyl silyl group (ODS), 684, 684	also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751 P Packed column GC, 633, 645; see also Gas chromatography PAD, see Pulsed amperometric detection Partial Least Squares, 414	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183 Photon-sensitive detectors, 181 Photovoltaic cell, see Barrier layer cell Pi (π) bond, 105, 105 PID, see Photoionization detector
Nuclear spin, 245–246, 247, 284 Nuclear Zeeman splitting, 248 Number of orientations, 248 Number of theoretical plates, 618 O Observed value, 34 Octadecyl silyl group (ODS), 684, 684 OES, see Optical emission spectroscopy	 also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751 P Packed column GC, 633, 645; see also Gas chromatography PAD, see Pulsed amperometric detection Partial Least Squares, 414 Particle-induced X-ray emission (PIXE), 437, 	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183 Photon-sensitive detectors, 181 Photovoltaic cell, see Barrier layer cell Pi (π) bond, 105, 105 PID, see Photoionization detector Plon, 767
Nuclear spin, 245–246, 247, 284 Nuclear Zeeman splitting, 248 Number of orientations, 248 Number of theoretical plates, 618 O Observed value, 34 Octadecyl silyl group (ODS), 684, 684 OES, see Optical emission spectroscopy Ohm's Law, 753, 795	also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751 P Packed column GC, 633, 645; see also Gas chromatography PAD, see Pulsed amperometric detection Partial Least Squares, 414 Particle-induced X-ray emission (PIXE), 437, 440, 509	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183 Photon-sensitive detectors, 181 Photovoltaic cell, see Barrier layer cell Pi (π) bond, 105, 105 PID, see Photoionization detector PIon, 767 PIXE, see Particle-induced X-ray emission
Nuclear spin, 245–246, 247, 284 Nuclear Zeeman splitting, 248 Number of orientations, 248 Number of theoretical plates, 618 O Observed value, 34 Octadecyl silyl group (ODS), 684, 684 OES, see Optical emission spectroscopy Ohm's Law, 753, 795 On-column derivatization, 676, 710	also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751 P Packed column GC, 633, 645; see also Gas chromatography PAD, see Pulsed amperometric detection Partial Least Squares, 414 Particle-induced X-ray emission (PIXE), 437, 440, 509 Partition chromatography, 683; see also	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183 Photon-sensitive detectors, 181 Photovoltaic cell, see Barrier layer cell Pi (π) bond, 105, 105 PID, see Photoionization detector Plon, 767 PIXE, see Particle-induced X-ray emission Pixels, 121
Nuclear spin, 245–246, 247, 284 Nuclear Zeeman splitting, 248 Number of orientations, 248 Number of theoretical plates, 618 O Observed value, 34 Octadecyl silyl group (ODS), 684, 684 OES, see Optical emission spectroscopy Ohm's Law, 753, 795	also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751 P Packed column GC, 633, 645; see also Gas chromatography PAD, see Pulsed amperometric detection Partial Least Squares, 414 Particle-induced X-ray emission (PIXE), 437, 440, 509	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183 Photon-sensitive detectors, 181 Photovoltaic cell, see Barrier layer cell Pi (π) bond, 105, 105 PID, see Photoionization detector PIon, 767 PIXE, see Particle-induced X-ray emission
Nuclear spin, 245–246, 247, 284 Nuclear Zeeman splitting, 248 Number of orientations, 248 Number of theoretical plates, 618 O Observed value, 34 Octadecyl silyl group (ODS), 684, 684 OES, see Optical emission spectroscopy Ohm's Law, 753, 795 On-column derivatization, 676, 710 Online IR spectroscopy, 828	also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751 P Packed column GC, 633, 645; see also Gas chromatography PAD, see Pulsed amperometric detection Partial Least Squares, 414 Particle-induced X-ray emission (PIXE), 437, 440, 509 Partition chromatography, 683; see also Chromatography	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183 Photon-sensitive detectors, 181 Photovoltaic cell, see Barrier layer cell Pi (π) bond, 105, 105 PID, see Photoionization detector Plon, 767 PIXE, see Particle-induced X-ray emission Pixels, 121 Planar chromatography, 742–747
Nuclear spin, 245–246, 247, 284 Nuclear Zeeman splitting, 248 Number of orientations, 248 Number of theoretical plates, 618 O Observed value, 34 Octadecyl silyl group (ODS), 684, 684 OES, see Optical emission spectroscopy Ohm's Law, 753, 795 On-column derivatization, 676, 710 Online IR spectroscopy, 828 Open space within a packed column, 623	also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751 P Packed column GC, 633, 645; see also Gas chromatography PAD, see Pulsed amperometric detection Partial Least Squares, 414 Particle-induced X-ray emission (PIXE), 437, 440, 509 Partition chromatography, 683; see also Chromatography Part per billion (ppb), 6, 16	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183 Photon-sensitive detectors, 181 Photovoltaic cell, see Barrier layer cell Pi (π) bond, 105, 105 PID, see Photoionization detector Plon, 767 PIXE, see Particle-induced X-ray emission Pixels, 121 Planar chromatography, 742–747 Planar electrophoresis, 742–747
Nuclear spin, 245–246, 247, 284 Nuclear Zeeman splitting, 248 Number of orientations, 248 Number of theoretical plates, 618 O Observed value, 34 Octadecyl silyl group (ODS), 684, 684 OES, see Optical emission spectroscopy Ohm's Law, 753, 795 On-column derivatization, 676, 710 Online IR spectroscopy, 828 Open space within a packed column, 623 Operational amplifier (op-amp), 773, 773	also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751 P Packed column GC, 633, 645; see also Gas	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183 Photon-sensitive detectors, 181 Photovoltaic cell, see Barrier layer cell Pi (π) bond, 105, 105 PID, see Photoionization detector Plon, 767 PIXE, see Particle-induced X-ray emission Pixels, 121 Planar chromatography, 742–747 Planar electrophoresis, 742–747 Planar gel electrophoresis, 1D, 745–746
Nuclear spin, 245–246, 247, 284 Nuclear Zeeman splitting, 248 Number of orientations, 248 Number of theoretical plates, 618 O Observed value, 34 Octadecyl silyl group (ODS), 684, 684 OES, see Optical emission spectroscopy Ohm's Law, 753, 795 On-column derivatization, 676, 710 Online IR spectroscopy, 828 Open space within a packed column, 623 Operational amplifier (op-amp), 773, 773 Operational definitions, 180	also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751 P Packed column GC, 633, 645; see also Gas	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183 Photon-sensitive detectors, 181 Photovoltaic cell, see Barrier layer cell Pi (\$\pi\$) bond, 105, 105 PID, see Photoionization detector Plon, 767 PIXE, see Particle-induced X-ray emission Pixels, 121 Planar chromatography, 742–747 Planar gel electrophoresis, 742–747 Planar gel electrophoresis, 1D, 745–746 Planar gel electrophoresis, 2D, 746
Nuclear spin, 245–246, 247, 284 Nuclear Zeeman splitting, 248 Number of orientations, 248 Number of theoretical plates, 618 O Observed value, 34 Octadecyl silyl group (ODS), 684, 684 OES, see Optical emission spectroscopy Ohm's Law, 753, 795 On-column derivatization, 676, 710 Online IR spectroscopy, 828 Open space within a packed column, 623 Operational amplifier (op-amp), 773, 773	also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751 P Packed column GC, 633, 645; see also Gas	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183 Photon-sensitive detectors, 181 Photovoltaic cell, see Barrier layer cell Pi (π) bond, 105, 105 PID, see Photoionization detector Plon, 767 PIXE, see Particle-induced X-ray emission Pixels, 121 Planar chromatography, 742–747 Planar electrophoresis, 742–747 Planar gel electrophoresis, 1D, 745–746
Nuclear spin, 245–246, 247, 284 Nuclear Zeeman splitting, 248 Number of orientations, 248 Number of theoretical plates, 618 O Observed value, 34 Octadecyl silyl group (ODS), 684, 684 OES, see Optical emission spectroscopy Ohm's Law, 753, 795 On-column derivatization, 676, 710 Online IR spectroscopy, 828 Open space within a packed column, 623 Operational amplifier (op-amp), 773, 773 Operational definitions, 180	also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751 P Packed column GC, 633, 645; see also Gas	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183 Photon-sensitive detectors, 181 Photovoltaic cell, see Barrier layer cell Pi (\$\pi\$) bond, 105, 105 PID, see Photoionization detector Plon, 767 PIXE, see Particle-induced X-ray emission Pixels, 121 Planar chromatography, 742–747 Planar gel electrophoresis, 742–747 Planar gel electrophoresis, 1D, 745–746 Planar gel electrophoresis, 2D, 746
Nuclear spin, 245–246, 247, 284 Nuclear Zeeman splitting, 248 Number of orientations, 248 Number of theoretical plates, 618 O Observed value, 34 Octadecyl silyl group (ODS), 684, 684 OES, see Optical emission spectroscopy Ohm's Law, 753, 795 On-column derivatization, 676, 710 Online IR spectroscopy, 828 Open space within a packed column, 623 Operational amplifier (op-amp), 773, 773 Operation of the column at elevated temperature, 697	also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751 P Packed column GC, 633, 645; see also Gas	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183 Photon-sensitive detectors, 181 Photovoltaic cell, see Barrier layer cell Pi (π) bond, 105, 105 PID, see Photoionization detector Plon, 767 PIXE, see Particle-induced X-ray emission Pixels, 121 Planar chromatography, 742–747 Planar gel electrophoresis, 742–747 Planar gel electrophoresis, 2D, 746 Plane-polarized light, 61, 62 Plasma, 364, 382
Nuclear spin, 245–246, 247, 284 Nuclear Zeeman splitting, 248 Number of orientations, 248 Number of theoretical plates, 618 O Observed value, 34 Octadecyl silyl group (ODS), 684, 684 OES, see Optical emission spectroscopy Ohm's Law, 753, 795 On-column derivatization, 676, 710 Online IR spectroscopy, 828 Open space within a packed column, 623 Operational amplifier (op-amp), 773, 773 Operational definitions, 180 Operation of the column at elevated temperature, 697 Optical configuration, 78–79	also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751 P Packed column GC, 633, 645; see also Gas	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183 Photon-sensitive detectors, 181 Photovoltaic cell, see Barrier layer cell Pi (π) bond, 105, 105 PID, see Photoionization detector Plon, 767 PIXE, see Particle-induced X-ray emission Pixels, 121 Planar chromatography, 742–747 Planar gel electrophoresis, 742–747 Planar gel electrophoresis, 1D, 745–746 Plane-polarized light, 61, 62 Plasma, 364, 382 Plasma emission spectroscopy, 382–404
Nuclear spin, 245–246, 247, 284 Nuclear Zeeman splitting, 248 Number of orientations, 248 Number of theoretical plates, 618 O Observed value, 34 Octadecyl silyl group (ODS), 684, 684 OES, see Optical emission spectroscopy Ohm's Law, 753, 795 On-column derivatization, 676, 710 Online IR spectroscopy, 828 Open space within a packed column, 623 Operational amplifier (op-amp), 773, 773 Operation of the column at elevated temperature, 697	also Reduction-oxidation reactions Oxidation-reduction titrations, 784–786 Oxidizing agent, 751 P Packed column GC, 633, 645; see also Gas	Photoluminescence, 147, 821 Photometer, 95, 97, 200, 201, 355–356, 362 Photomultiplier tube (PMT), 117–118, 117–118, 121, 152, 317 Photons, 62, 89 Photon detectors, 76, 89, 182–183 Photon-sensitive detectors, 181 Photovoltaic cell, see Barrier layer cell Pi (π) bond, 105, 105 PID, see Photoionization detector Plon, 767 PIXE, see Particle-induced X-ray emission Pixels, 121 Planar chromatography, 742–747 Planar gel electrophoresis, 742–747 Planar gel electrophoresis, 2D, 746 Plane-polarized light, 61, 62 Plasma, 364, 382

chemical speciation with hyphenated	Principal component analysis, 234, 414	chromatography, 624-627
instruments, 403–404	Principles of chromatography, see	of compounds and mixtures, 573–576
instrumentation, 382-395	Chromatography	elemental, 4, 6, 7, 8
interferences, 395–401	Prisms, 80, 80, 82, 84	flame OES, 360–362
Plate position scanning, 744	Probability Based Matching, 568	infrared (IR) spectroscopy, 206–209
Plate theory, 606	Probe, 272, 771	inorganic compounds, 226
PMT, see Photomultiplier tube	Problem defining, 3–8	inorganic elemental, 7–8
P-n junction, <i>120</i> , 120–121	Process analysis, 200	Laser-Induced Breakdown Spectroscopy
Polar, 165	Programmed temperature GC, 652	(LIBS), 416–417
Polar biomolecules, phase combinations for	Properties of nuclei, 246–247	molecular, 6
assays of, 690–691	Proportional counter, 466	nuclear magnetic resonance (NMR),
Polarity index, 692	Proportional errors, 31	288–291
Polarizability, 217, 659	Protein peptide mapping, 746	organic compounds, 201, 226
Polarogram of dissolved oxygen, 805	Proteins, 716	spark emission spectroscopy, 381–382
Polarographic detector, 707	Protein-sequencing analysis (proteomics),	XRF, 487–490
Polarography 751 811	576–577 Proteomics, 604, 714, 718	Quantitative analytical range, 339
Polarography, 751, 811		Quantitative determination, 782–783
classical, 802–807	Proton adduct, 530	Quantization of ¹ H nuclei in magnetic field, 247–252
DC, 802–807	Proton NMR spectrum, 263, 266–267	
differential pulse, 809, 809–812	Pseudo-endothermic event, 852	Quantized energy, 247
electroanalytical methods, 801–812	P-type semiconductor, 119–121	Quantum dots, 820
polarographic cell, modern, 803	Pulsed ampener, 695	Quantum mechanical selection rules, 429
Polar solvents, 21	Pulsed amperometric detection (PAD), 707	Quantum mechanics, 107
Polychlorinated biphenyls (PCBs), 33	Pulsed NMR experiment, 256, 257	Quantum theory, 304
Polychromatic light, 61, 80	Pulse height discriminator, 471	Quartz, 613
Polychromators, 370, 370–371; see also	Purge and trap samplers, 677	Quartz optical fibers, 210
Monochromators	Pyroelectric detectors, 181–182	QuEChERS, 25–26
Poly(dimethylsiloxane) (PDMS), 26, 287, 615	"Pyrolyze" step, 325	Quench/quenching, 148, 744
Polyimide coating, 614		
Polymerase chain reaction (PCR), 604	Q	R
Polymer characterization, 216	OD Channel detector	D
Population mean, 34	QD, see Charge detector	Racemize, 690
Population standard deviation, 35–36	Q-switched Nd:YAG laser, 412–413	Radial viewing, 389
Porapack*, 678	Q-test, 42	Radiant energy, 61, 67–68, 70–71
Pores, 616	Quadrupole ion deflector (QID), 581	absorption, 306
Porous carbon electrode, 706	Quadrupole ion trap (QIT), 556–557, 557	distribution curves, 172
Porous layer open tubular (PLOT), 645, 678,	Quadrupole ion trap mass spectrometer, 553,	Radiant power, 71
678–679	556	Radiation sources, 79, 90, 113–115, 151–152
Porous polymer, 678	Quadrupole mass analyzers, 542, 551–553,	atomic absorption spectrometry (AAS),
Post-column derivatization, 697, 704, 710, <i>710</i> Potential difference, 753	552–553, 582	307–310 commercial IR, <i>173–174</i>
	Quadrupoles, 665	
Potentiometry, 764–786; see also Indicator electrodes	Quadrupole tandem MS/MS instrument, 555	infrared (IR) spectroscopy, 172–174 Radiofrequency (RF), 245, 249–250, 255, 551
	Qualitative analysis, 1, 4–6, 227, 338	crystal oscillator, 274
advantages of, 772	arc emission spectroscopy, 376	•
applications, 775–776, 778 cell, 773, 794	destructive, 4 elemental, 4, 6	generation and detection, 274
	flame OES, 360	glow discharge (GD) sources, 404–405, 405
common reference electrodes, 765 electrochemical measuring system for,	infrared (IR) spectroscopy, 202–206	sources, 272 Radioisotope sources, 444–445, 445
765		•
for pH titration, 781	Laser-Induced Breakdown Spectroscopy	Raies ultimes, 378–379, 380
titrations, 776–778, 781–782	(LIBS), 415–416 molecular, 4, 6	Raman-active, 217, 224, 230 Raman anti-Stokes lines, 219
	non-destructive, 4	Raman band frequencies, 228
Potentiostat, 774, 775		÷ ,
Powder X-ray diffractometry, 503, 503–504	nuclear magnetic resonance (NMR),	Raman excitation laser, 231 Raman lines, 218
Procession 272 278 280	276–280, 287–288 organic compounds, 201, 226	Raman microscopy, 232–233
Precession, 272, 278–289 Precision, 9, 29–30	-	= *
Precolumn derivatization, 710	spark emission spectroscopy, 376	Raman scattering, <i>218</i> , 219–220, 230 Raman shifts, 219
	structural, 134 XRF, <i>482–486</i> , 482–487	Raman spectroscopy, 206, 217–233, 220, 226,
Precolumn fluorescence labeling, 710 Precursor ion, 554	Qualitative chromatography, 623–624; see	229–230, 238
Preferred orientation, 508		
	also Chromatography Qualitative structural identification, 201	applications of, 226–230
Premix burner, 355		chemical imaging, 233–240
Preparative GC, 645 Preparative SFC, 733; see also Supercritical	Quality by design (QbD), 692	instrumentation, 219–226
•	Quantifying random error, 35–41	dispersive spectrometers systems, 221,
fluid chromatography Proccure (Lorentz) broadening 306	Quantitation, 625–626	221–222 fiber optic based modular systems
Pressure (Lorentz) broadening, 306	accuracy of isotope ratios, 572–573	fiber optic-based modular systems,
Pressure DSC, 853–854	internal standard, 629	223–224 ET Paman spactromators 222 222
Primary beam, 437	Quantitative analysis, 1, 3, 6–8, 30, 134–139,	FT-Raman spectrometers, 222, 223
Primary ion pair 465–466	339–341	handheld systems, 223–224
Primary ion pair, 465–466 Priming syringe, 695	arc emission spectroscopy, 381–382 calibration, 339–341	light sources, 219–221
1 Hilling Syllinge, UZJ	Campianon, Joy-J41	samples and sample holders, 224–226

principles, 217–219	fluorescence, 407	matched cells, 124-125
Raman microscopy, 232-233	lines, 304	NMR, 269–272
resonance Raman effect, 230-231	Raman effect, 230–231, 231	solid sample holders, 126
surface-enhanced Raman scattering	Raman spectroscopy, 224	homogeneous, 3, 10, 13–14
(SERS), 231–232, 232	Response curve, 118, <i>118</i>	infrared (IR) spectroscopy, 184-196
Random composition, 3	Response time of detectors, 183-184	background correction in
Random diffusion, 609	Rest potential, 813	transmission measurements,
Range, defined, 55	Restricted/Prohibited Elements, 489	190-191
Raoult's Law, 758	Restriction of the use of Hazardous	reflectance and emission
Rastering, 395	Substances (RoHS), 403, 416, 489	measurements, 191–196
Rayleigh frequency, 219	Retardation, 93	transmission (absorption)
Rayleigh scattering, 217, 218, 221	Retention factor, 616	measurements, 184-190
RDE, see Rotating disk electrode	Retention gap, 645, 646	input systems for MS, 528–529
Reaction cells, 594–595, 595	Retention index (RI), 673-674	introduction systems, 389–395
Reaction kinetics, 1, 140–141	Retention time, 623–624	laboratory, 11
Reagent blank, 9–10	Reverse bias, 120, 120–121	liquid, 13, 187–189, <i>188</i> , 341–342
Reagent gas, 530	"Reversed phase" HPLC (RP-HPLC), 683	loop, sample, 695
Reagent ions, 715	"Reversed phase" LC, 613	from lot sampling, 11
Reagents and instrumentation, 32	Reversed-role elution, 728	mean, 34
Reciprocal centimeter, 163	Reversible lines, 379	NIR spectroscopy, 214
Redox indicator electrode, 766	RF, see Radiofrequency	nuclear magnetic resonance (NMR),
Reducing agent, 751	RF ICP Source, 382–386	275–276
Reduction-oxidation reactions, 751–752; see	Rh target side-window tube (ARTAX system),	organic, 4
also Oxidation-reduction reaction	443	preparation, 15–28
Reduction potentials, 755	Riffle, 11	acid digestion, 15–18
REF, see Reference electrode	Ringbom plot, 76–77, 77	acid dissolution, 15–18
Reference beam, 90–91, 317	Ring current, 260	arc emission spectroscopy, 376
Reference electrode (REF), 705, 755, 762–765,	Robustness, 39	automated, 2
766, 774	RoHS, see Restriction of the use of Hazardous	combustion, 20
Reference half-cell, 755	Substances	dry ashing, 20
Reference materials (RM), 868	Rotary sample loop injector, 695–696, 696	extraction, 20–28
Reference standard, 10	Rotating disk electrode (RDE), 369	fusions, 18–20
Reflectance measurement, 191–196	Rotating disk electrode (RDE), 507 Rotational transitions in molecules, 69–70	nuclear magnetic resonance (NMR),
Reflectron, 548	Rowland circle polychromator, <i>370</i> , 371	275–276
Refractive index (RI), 5, 80, 84, 145, 698, 698	Rowland circle type monochromator, 472	spark emission spectroscopy, 376
Regenerating the column, 721	Ruggedness, 39	XRF, 479–482, 480
Rejection of results, 41–42	"Runaway reactions," 15	probe in NMR, 272
Relative abundance, 523	Rullaway reactions, 15	problems, 10
Relative concentration error, 75		process/procedures, 11–12
Relative deviation, 35	S	Raman spectroscopy, 224–226
	Same crystal lattice, 507	
Relative electrode potential, 755 Relative error, 34	•	representative, 9–11 saturated, 252
•	Same wavelength, 358, 360, 377, 379, 408, 410–411	•
Relative response factor (RRF), 627		segregated material, 12
Relative retention times (RRT), 624	Sampler cone, 581, 582, 583	solid, 14, 184–187
Relative R_t , 673–674	Sample/sampling, 10–14	solutions, 9
Relative standard deviation, 36	absorption of radiation, <i>71</i>	stacking, 740, 740
Relaxation, 68, 253	agricultural, 11	standard deviation, 35–37
Relaxation time of absorption lines, 253–254	analysis, 341–347	storage of, 14–15
Releasing agent, 327, 358	beam, 90	Saturated calomel electrode (SCE), 762,
Reliability, 39	cells, 72, 72, 153	762–763, 767, 779–780, 782
Remote analysis, 417–419	changers for WDXRF spectrometry, 471	Saturated fluorescence, 409
Repeatability, 39	"collection in the field," 11	Saturated sample, 252
Representative sample, 9–11	composite, 11, 13	Saturation, 250–252, 409
Reproducibility, 39	computer program, 11	Scattering, defined, 699
Requirement for auxiliary gases,	cone and quarter method for bulk	SCD, see Sulfur chemiluminescence detector
characteristics of GC detectors,	materials, 11, <i>11</i>	SCE, see Saturated calomel electrode
655	containers, 14–15	Schöniger flask, 20
Residual current flows, 806	electrode, 363	Scintillation, 469, 473
Residual gas analyzers (RGA), 577	environmental, 11	Scintillation counter (SC), 469–470, 470
Resistance, 753	gas, 13, 189–190	Scintillation detector, 470, 470
Resolution, 83, 570	grab, 13	Screening constant, 258
defined, 571	gross representative, 11	Scrubbing gas sample, 13; see also Gas
of grating, 84–85, 85	heterogeneous, 3	samples
mass spectrometry (MS), 525–527	holders, 122–127, 368–369	SDS-PAGE, see Sodium-dodecylsulphate-
of monochromator, 83–84	energy dispersive X-ray (EDXRF)	polyacryamide gel electrophoresis
of prism, 84	spectrometry, 450–454	Sealed gas proportional counter, 468–469
for separating lines of different	fiber optic probes, 126, 127	SEC, see Size exclusion chromatography
wavelength, 83–87	flow-through samplers, 125	Secondary electron multiplier (SEM)
Resolving power, 83–84, 525–527	gas cells, 122–124	detector, 562
Resonance, 245, 250	liquid cells, 122–124	Secondary internal porosity, 684

Secondary ion mass spectrometry (SIMS),	Sine amplifier, 471	Spectrometers/spectrometry, 74, 78–79, 95,
535	Single-beam absorption spectrometer,	112, 369–374, 460
Secondary X-rays, 437	78, 78	configuration, 316–317
Secondary XRF, 444 Second kind of metallic electrodes, 766	Single-beam optics, 89–92	optics in atomic absorption spectrometry
Segregated composition, 3	Single-beam system, 317 Single-column anion chromatography, 726	315–317 plasma emission spectrometry,
Selected ion monitoring (SIM), 667–668	Single-column cation chromatography, 726	386–389
Selecting stationary phase for application,	Single-column ion chromatography, 726	sequential, 462
645–646	Single crystal X-ray diffractometry, 499, 499	Spectrophotometers, 95, 176
Selective detection reagents, 744	Single-focusing magnetic sector mass	Spectrophotometric titrations, 141–142
Selectivity, 619	analyzer, 542	Spectrophotometry, 95, 134, 138
Selectivity coefficient, 769	Single piston, 695	Spectroscopes, 115
Self-regenerating suppressor, 724	Single-point background correction, 399	Spectroscopy, 61-99; see also Raman
Semiconductor detectors, 118–122, 183,	Single quadrupole 7700-series benchtop	spectroscopy
454–456; <i>see also</i> N-type	ICP-MS (Agilent Technologies),	absorption laws, 71–78
semiconductor	553	atomic spectroscopy, 67–69
Semicrystalline polymers, 843	Singlet state, 146, 146–147	atoms, 67–69
Sensitivity, 54, 655 Sensor, see Transducer	Single wavelength filter photometer, 702	defined, 61, 95
Separations	Size exclusion chromatography (SEC), 728–730, 729–730	electromagnetic radiation, 61–67 instrument nomenclature, 95
C14 hydrocarbons, 652	Skimmer cone, 581, 582, 583, 712	molecular spectroscopy, 69–71
chiral phases of enantiomers, 689–690	Slab gel electrophoresis, 624	molecules, 69–71
chromatography, 616–619, 621–622	Slope of addition calibration line, 50	near-IR, 209–217
of colored compounds, 605	Smith-Hieftje background correction,	nomenclature, 78
of composition of mobile phase in HPLC,	336–337	optical systems, 78–95
691–692	Society for Applied Spectroscopy, 275	technique, 95
of ink dyes through chromatography, 607	Sodium-dodecylsulphate-polyacryamide gel	transitions, 64, 64
spotting, 742	electrophoresis (SDS-PAGE), 746	Specular reflectance, 193–194
Separations using TLC (2D-TLC), 2D, 745	Sodium form, 720	Spin decoupling, 277
Septum, 633	Solid electrical conductor, 753	Spin-lattice relaxation, 284; see also
Septum core, 637 Septum disc, 637, 638	Solid phase extraction (SPE), 24–25, 604	Longitudinal relaxation Spin-spin coupling, 263–269, 266
Sequence of nucleotides, 719	Solid phase microextraction (SPME), 26–28, 27–28, 639–640, 640	Spin-spin coupling, 203–209, 200 Spin-spin relaxation, see Transverse
Sequential spectrometers, 386, 460, 462	Solid sample holders, 126, 369	relaxation
Sequential systems, 92	Solid samples, 14, 184–187, 342–344	Spin-spin splitting, 263
SFC, see Supercritical fluid chromatography	Solid sampling systems, 394	Split injections, 640, 641
Shape of UV absorption curves, 109–111	Solid-state imaging detectors, 95	Splitless injections, 641, 641–642
SHE, see Standard hydrogen electrode	Solubility product, 777	Split mode, 640
Sheath gas, 714	Solution conductivity, 799-800	Split ratio, 640
Shielding, 254	Solvated clusters, 712	Split-splitless injector, 640
Shimadzu Scientific Instruments AAS, 113,	Solvent absorption, 190–191	Splitting of sample, 636
115, 347, 663	Solvent extraction, 21–24, 22, 23	Spontaneous reaction, 754
Shim coils, 252, 270, 273	Solvent focusing approach, 641 Solvent polarity triangle, 692	Spray chamber, 391–393, 394 Spraying reagents, 744
Shimming, 273 Short-term precision, 38–39	Solvents for UV/VIS spectroscopy, 111–112,	Spurious effects in mass spectrometry, 598,
Shot noise, 44, 76	112	598
Side-window X-ray tube, 441	Sorbent (solid phase extractant), 25	Standards
Siegbahn notation, 430–431	Soxhlet extractor/extraction, 22–23, 23	buffer solutions, 780
Sigma (σ) bonds, 105–106	Space charge, 467, 522	curves, 626
Sigma (σ) orbitals, 70	Spacer, 642	reduction potentials, 756-759
Sigma star orbital (σ^*), $106-107$	Spacer arm, 727	solutions, 47
Signal integrator, NMR, 274-275	Sparging, 685	suspension, 145
Signals, 42–45, 43	Spark ablation, 395	wavelength, 139
Signal-to-noise ratio (S/N), 43–44, 45, 56, 94,	Spark emission spectroscopy, 376–382	Standard deviation, 29, 35–37, 41
122, 317, 376, 540, 625, 655, 673	Spark-like discharge, 367 Spark source, 367–368, 368–369, 540	Standard hydrogen electrode (SHE), 753,
Sign conventions, 759 Silanization, 676	Speciation, 403, 411–412	756–757, 757 Standard Methods for Examination of Water
Silica gel, 613	Specificity, 54	and Wastewater, 800
Silicones, 615	Spectral accuracy, 572	Standard operating procedures (SOPs), 32
Silicon-oxygen compounds in	Spectral bandpass/bandwidth, 86, 88–89	Standard reference materials (SRM), 29, 340,
chromatography, 613-616; see also	Spectral interference, 353, 360, 377, 398–401	798, 868
Chromatography	arc emission spectroscopy, 377	Standards Methods for the Analysis of Water
Silicon PIN diode detectors, 456, 456–457	atomic fluorescence spectroscopy, 411	and Wastewater, 12
Silver/silver chloride electrode, 763	spark emission spectroscopy, 377	Standing current, 659
Simple potentiometric titration curve, 779	Spectral interferences, 51, 332–338, 359–360	Stark broadening, 306
SIMS, see Secondary ion mass spectrometry	Spectral line width 205 206	Stationary phase
Simultaneous system, 93	Spectral linewidth, 305–306 Spectral slit width, 88	considerations, 689 film thickness, 648, 648
Simultaneous system, 93 Simultaneous WDXRF spectrometers,	Spectral siit width, 88 Spectrochemical buffer, 365	HPLC's column and, 684–686, 684–691
471–473	Spectrochemical buner, 303 Spectrograph, 95	of SFC, 731–732
		•

Statistics and data handling, 29–42	Tetramethylsilane (TMS), 259	Total ion chromatogram (TIC), 666–667
accuracy, 29–30	Thermal analysis, 825–869	Total reflection XRF (TXRF), 476
errors, 30–33	defined, 825	Trace organic/inorganic analysis, 33
precision, 29–30	differential scanning calorimetry (DSC),	Transcription errors, 32, 45
quantifying random error, 35–41	845-854	Transducer, defined, 42
rejection of results, 41–42	applications, 851–854	Transitions
Step-on-and-off/partition, anology, 609	instrumentation, 845–851	electronic in molecules, 70–71
Stokes direct-line fluorescence, 407	differential thermal analysis (DTA),	rotational in molecules, 69–70
Stokes scattering, 217	840–845, 841	spectroscopy, 64, 64
Stopped-flow-analysis, 669	analytical applications, 843–845	vibrational in molecules, 70
Storage of samples, 14–15	instrumentation, 841–843	Transmission measurements, 184–191
Stretching vibrations, 166	direct injection enthalpimetry (DIE),	Transmission quadrupole mass spectrometer
Stripping voltammetry, 814–816, 816	860–861, 861	553
Strong acid cation exchange, 720	hyphenated techniques, 854–858	Transmittance, 71–72, 75–77, 95
Strong acidic ion, 719	evolved gas analysis (EGA), 855–858	Transverse relaxation, 253
Strong base, 721	hyphenated thermal methods,	Trap, sampling, 677
Structural determination, IR spectroscopy,	854-855	Triatomic molecules, 166–167
202–206	methods, 826	True 2D chromatography, 608
Styrene-divinylbenzene resin polymer, 720,	microcalorimetry, 861–868	True Surface Microscopy, 236
720	applications, 863–866	True value, 34
Suitable ionic solution, 753	instrumentation, 862	Tunable gas phase lasers, 175
Sulfur chemiluminescence detector (SCD),	isothermal titration calorimetry,	Tunable lasers, 175
338, 661	866–867	Tungsten-halogen lamp, 113, 114
Sulfur-phosphorous flame photometric	microliter flow calorimetry, 868	Tungsten lamp, 113
detector (SP-FPD), 661	thermogravimetry, 827–829, 827–840	Turbidimetry, 144–146, <i>145</i>
Sum peaks, EDXRF spectrometry, 458–459	analytical applications of, 832–837	Turbidity, 139
Supercritical fluid, 23	derivative thermogravimetry (DTG).,	Turnaround time, 9, 121
Supercritical fluid chromatography (SFC),	837–839, 838–839	
529, 730–733	instrumentation, 829–832	U
applications, 733	sources of error in, 839-840	
effect of pressure, 731	thermometric titrimetry, 858–860, 859	Ultra-high-performance liquid
mobile phases, 731–732	Thermal conductivity detector (TCD), 635,	chromatography (UHPLC), 616,
operating conditions, 731	656–657, 657	688
other column methods <i>versus</i> , 732–733	Thermal curve, 827, 827, 828, 829, 832, 834,	Ultrasensitive calorimeters, 862
preparative, 733	835, 836, 838, 839, 841, 844, 848,	Ultrasensitive calorimetry, 862, 867
stationary phase, 731–732	853	Ultrasonic nebulizers (USN), 392–393, 393
ultra performance convergence	Thermal detectors, 75, 89, 181	Ultratrace, 33
chromatography (UPC2), 733, 734	Thermal equilibrium, 357	Uncharged metal atom, 754
Supercritical fluid extraction (SFE), 23	Thermal liquid crystal paint, 142	Unified atomic mass units, 520
Superficially porous, 687	Thermal modulator, 671	Unit activity, 758
Super notch filters, 221	Thermal noise, 44	Unit cell, 496, 497
Supporting electrolyte, 805	Thermionic detectors, 661	United States Pharmacopeia (USP), 589
Support particle considerations, 686–688	Thermogravimetry, thermal analysis,	Universal Cell, 595
Surface analysis, 1, 428, 477, 487, 535	827–829, 827–840	Universal detection reagents, 744
Surface-enhanced Raman scattering (SERS),	analytical applications of, 832–837	Universality <i>versus</i> selectivity, characteristics
231–232, 232	derivative thermogravimetry (DTG).,	of GC detectors, 655
Surface plasmons, 231, 232	837–839, 838–839	Unretained component, 617
Surfactant, 739	instrumentation, 829–832	US Coast Guard, 2
SWATH, 577	sources of error in, 839–840	US Department of Agriculture, 25
SWIFT technique, 294	Thermometric titration, 859	US Environmental Protection Agency (EPA),
Symmetrical Gaussian peak, 625	Thermometric titrimetry, 858–860, 859	9, 23, 48, 55, 419
Symmetric stretch, 166	Thermospray HPLC-MS interface, 712	US Food and Drug Administration, 589
Syringes, 633, 637, 637–638	Thin-film mercury electrode (TFME), 815	US Los Alamos National Laboratory, 418
Syringe-through-septum technique, 639	Thin layer chromatography (TLC), 232, 608,	US National Institute of Standards and
Systematic errors, 30–31, 35, 40; see also	742–745, 743–745	Technology, 2
Errors	Third kind of metallic electrodes, 766	UV/VIS
Système International d'Unités (SI system), 2	Three-electrode circuit, 803	absorption detectors, 701, 701–703
	Three-electrode devices, 774	absorption spectrometry, 71, 79
T	Tian-Calvet system (Setaram	radiation, 107
	Instrumentation), 848	spectrometers, 75–76
Tailing character, 617	Time domain, 177	spectrum, 83
Tailing peak shapes, 612	Time-gated detectors, 413	wavelength reference spectra, 83
Tandem in space, 554	Time of flight (TOF) analyzer, 546–551,	UV/VIS molecular spectroscopy, 101–160,
Target compound analysis, 702	547–550	102
TCD, μ, 657	Titrations with tetrabutylammonium	absorption by molecules, 107
Teflon, 18	hydroxide (TBAH), 782	analytical applications, 134–144, 153–156
Temperature programming, 622	Titrimetry, 7, 786, 794, 798, 861	electronic excitation in molecules,
Temperature programs, 647	TLC, see Thin layer chromatography	104–107
Tenax particles, 677	TOFMS, 549, 563, 665, 667–668	instrumentation, 112–133, 150–153
Test portions, 11	Total dissolved solids (TDS), 800	molar absorptivity, 108–109

molecular emission spectrometry,	resolution for separating lines of different,	hybrid XRD/XRF systems, 504–506
146–150	83–87	powder X-ray diffractometry, 503,
nephelometry, 144–146, 145	symbols, 63 X-ray diffractometry (XRD) of, <i>498</i>	503–504
overview, 101–104 shape of UV absorption curves,	Wavelength dispersive X-ray (WDXRF)	single crystal X-ray diffractometry, 499, 499
109–111	spectrometry, 440, 460–471, 476	X-ray emission, <i>432</i> , 433, 478 , <i>509</i> , 509–510
solvents for, 111–112, 112	analyzing crystals, 462–463, 462–465,	X-ray fluorescence, 437, 439–490, 511
turbidimetry, 144–146, <i>145</i>	464	applications, 476–490
	collimators, 461–462, 461–462	analyzed layer, 477–479, 478, 478–479
V	detectors, 465–470	qualitative analysis, 482–486,
V	electronic pulse processing units,	482–487
Vacuum systems, 527	470–471, 471	quantitative analysis, 487–490
Valence band, 118	sample changers, 471	sample preparation, 479–482, 480
Van Deempter curves, 646, 647, 650	Wavelength selection devices, 79-87,	instrumentation
Van Deempter Equation, 619–620, 620, 622,	150–151, 355–356	energy dispersive X-ray (EDXRF)
738	filters, 79-80, 83	spectrometry, 445-459, 476
Van der Waals forces, 642	monochromator, 80-82, 82	micro-XRF, 473-476
Vapor-phase FTIR spectrum, 165	resolution for separating lines of different	simultaneous WDXRF spectrometers,
Variance, 35, 40	wavelength, 83–87	471–473
Varian HR-30, 245	Wavenumbers, 163, 170–171	wavelength dispersive X-ray (WDXRF)
V-groove nebulizer, 392, 392	WCOT, see Wall-coated open tubular	spectrometry, 460-471, 476
Vibrations	columns	source, 439–445
absorption bands, 164	Weak acid exchange resin, 720	radioisotope, 444–445, 445
bending, 166	Weak base, 721	secondary XRF, 444
modes of, 166, 167	WEEE, see Waste Electrical and Electronic	X-ray tube, 440–444, 441–442
molecular, 170–171	Equipment	total reflection XRF (TXRF), 476
in molecules, 166–168	Weight lost, 828	X-ray fluorescence spectroscopy (XRF), 4, 8,
motion, 168–169	Wet ashing, 16, 20, 342, 376	19, 69, 338, 403, 414, 416, 439–440
stretching, 166	Wet chemical methods, 1–2	X-ray photographs of human colon, 493
transitions in molecules, 70	Wheatstone bridge, 656, 797, 798	X-ray photographs of human hand, 492
Vigorous stirring, 789–790	White noise, 44	X-ray photon, 427, 428, 429, 456
Virtual state, 218	White radiation, see Bremsstrahlung	X-ray preferential absorption analysis, 494
Visible absorption spectra, 104	radiation	X-ray spectroscopy, 427–517
Visible light (white light), 61	Width of absorption lines, 252–255	origin, 427–439
Visualization of process in chromatography,	Work, 753	energy levels in atoms, 427–433
608-612 Valida (22 605	Working electrode (WE), 705–706, 774–775,	Moseley's Law, 433–434, 434
Voids, 623, 685	801	X-ray methods, 434–439
Voltage vs. time sequence in DPP, 809	Working range, see Concentration	X-ray absorption, 490–495
Voltammetry, 801, 812–816		X-ray diffractometry (XRD), 496–509
cyclic, 813–814, <i>814</i> detectors, 705	X	X-ray emission, 509–510 X-ray fluorescence, 439–490
instrumentation for, 813	Xenon arc lamps, 114, 151, 151–152	X-ray transmission, 454
potential ranges for liquid mercury, 812	XIC, see Extracted ion chromatograms	X-ray tube, 440–444, 441–442
stripping, 814–816, 816	X-ray absorption, 434–437, 435, 490–495,	X-ray tube source, EDXRF spectrometry,
Volumetric analyses, 1–2, 7	492; see also Absorption	446
volumetric unulyses, 1 2, 7	coefficient, 491	XRF, see X-ray fluorescence spectroscopy
144	in medicine, 493	rent, see it tay hadrescence spectroscopy
W	photograph of mechanical weld, 494	7
Wall-coated open tubular columns (WCOT),	spectrum, 435	Z
643, 645	X-ray astronomy, 427	Zeeman background correction, 335,
Wash step, 728	X-ray crystallography, 498	335–336
Waste Electrical and Electronic Equipment	X-ray diffraction, 511–512	Zeeman effect, 335
(WEEE), 403, 489	X-ray diffractometry (XRD), <i>438</i> , 438–439,	Zeeman splitting, 306, 335
Water-cooled spray chambers, 393	496–509	Zeolites, 719, 838
Wave interactions, 176	applications, 506–509	Zero oxidation state, 754
Wavelengths, 61, 62, 163	crystal growing, 499–501	Zeropath length difference (ZPD), 176–177,
absorption band, 107, 108	crystal structure, 501–503, 502	177
absorption edges, 433	of different wavelengths, 498	Zinc metal, 759
range of UV radiation, 101	electron micrograph, 469	Zwitterions, 611, 719